

---

**2000 Test Pad™**  
**2310 SONET Field Services Module**  
**User's Guide**

Document 50-16348-01, Rev. E  
December 2000



### **Notice**

Every effort was made to ensure that the information in this document was accurate at the time of printing. However, information is subject to change without notice, and Acterna, formerly TTC and WWG, reserves the right to provide an addendum to this document with information not available at the time that this document was created.

### **Copyright**

Copyright 2000 Dynatech, LLC., doing business as Acterna. All rights reserved. No part of this guide may be reproduced or transmitted electronically or otherwise without written permission of the publisher.

### **Trademarks**

Acterna and 2000 Test Pad are trademarks or registered trademarks of Acterna in the United States and/or other countries. Microsoft, Windows, Windows CE, and Windows NT are either trademarks or registered trademarks of Microsoft Corporation in the United States and/or other countries.

Specifications, terms, and conditions are subject to change without notice. All trademarks and registered trademarks are the property of their respective companies.

### **Ordering Information**

This guide is a product of Acterna's Technical Publications Department, issued as part of the TTC 2000 Platform. The ordering number for this document is 80-16348-01, Rev G.



20400 Observation Drive, Germantown, Maryland 20876-4023

**USA** 1-800-638-2049 • + 1-301-353-1550 • FAX + 1-301-353-9216

**Canada** 1-888-689-2165 • + 1-905-812-7471 • FAX + 1-905-812-3892

**[www.acterna.com](http://www.acterna.com)**

### **Federal Communications Commission (FCC) Notice**

This product was tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. For units equipped up to OC-48, the 2310 complies to Part 15 of the FCC Rules up to 1 GHz. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This product generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this product in a residential area is likely to cause harmful interference, in which case you will be required to correct the interference at your own expense.

The authority to operate this product is conditioned by the requirements that no modifications be made to the equipment unless the changes or modifications are expressly approved by Acterna.

### **Industry Canada Requirements**

This Class A digital apparatus complies with Canadian ICES-003. For units equipped up to OC-48, the 2310 complies to Canadian ICES-003 up to 1 GHz.

Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

### **EMC Directive Compliance**

This product was tested and conforms to the EMC Directive, 89/336/EEC as amended by 92/31/EEC and 93/68/EEC for electromagnetic compatibility. A copy of the Declaration of Conformity is provided in this manual.

### **Low Voltage Directive Compliance**

This produce was tested and conforms to the Low Voltage Directive, 73/23/EEC as amended by 93/68/EEC. Conformity with this directive is based upon compliance with the harmonized safety standard, EN60950. A copy of the Declaration of Conformity is provided in this manual.

**WARNING:** This is a Class A product. In a domestic environment, this product may cause radio interference, in which case, the user may be required to take adequate measures.

## Important Safety Instructions

When using the product, basic safety precautions should always be followed to reduce the risk of fire, shock, and injury to persons, including the following:

- 1 Read and follow all warning notices and instructions marked on the product and included in the manual.
- 2 Use only the AC Adapter/Charger supplied with the product.
- 3 Do not use AC Adapter/Charger outdoors or in wet or damp locations.
- 4 Connect the AC Adapter/Charger to the correct mains voltage, as indicated on the ratings label.
- 5 Do not allow anything to rest on the power cord, and do not locate the product where persons can walk on the power cord.
- 6 Avoid using this product during an electrical storm. There may be a remote risk of electric shock from lightning.
- 7 Do not use this product in the vicinity of a gas leak or in any explosive environment.
- 8 Do not attempt to service this product yourself, as opening or removing covers may expose you to dangerous, high voltage points and other hazards. Refer all servicing to qualified service personnel.
- 9 **CAUTION:** Danger of explosion if battery is incorrectly replaced. Dispose of used batteries according to the manufacturer's instructions.
- 10 **CAUTION:** Never look into the optic transmitters when the unit is ON.



## Declaration of Conformity



**ACTERNA**

### Application of Council Directive(s):

LVD: 73/23/EEC as amended by 93/68/EEC  
EMC: 89/336/EEC as amended by 92/31/EEC and 93/68/EEC

### Standard(s) to which Conformity is Declared:

EN60950 (A1-A4 & A11), EN55022:1994 (A1 & A2), EN50082-1:1992, EN61000-4-2,  
EN61000-4-3, ENV50204, EN61000-4-4, EN61000-3-2, EN61000-3-3

**Manufacturer:** Acterna  
20400 Observation Drive  
Germantown, MD 20876  
USA

**EU Address:** Acterna LLC through its  
subsidiary at:  
Portland House  
Aldermaston Park  
Aldermaston  
Berkshire  
RG7 4HR  
United Kingdom

### Model No.:

TIC2000 with  
T-Berd 2310

### Product Description:

User Interface Module with  
Applications Module

*I, the undersigned, hereby declare that the equipment specified above  
conforms to the above Directive(s) and Standard(s).*

Germantown, MD USA

4 December, 2000

Date

Signature

John Paul Williams

Print Name

Director, Corporate Quality and Customer Satisfaction

Print Title

Acterna Doc. No. 50-17316-01 Rev B

# Contents

|                                     |       |
|-------------------------------------|-------|
| <b>About This Guide</b> .....       | xvii  |
| Purpose and scope .....             | xvii  |
| Assumptions.....                    | xvii  |
| Getting technical assistance .....  | xviii |
| Using this guide.....               | xix   |
| Conventions.....                    | xx    |
| <b>Chapter 1—Introduction</b> ..... | 1     |
| About the 2310 .....                | 2     |
| Features and capabilities .....     | 3     |
| Options .....                       | 4     |
| System requirements .....           | 6     |
| Hardware requirements .....         | 6     |
| Physical description .....          | 8     |
| Front-panel features .....          | 8     |
| Bottom-panel features .....         | 9     |
| Top-panel features.....             | 10    |
| Interface connector layouts.....    | 11    |
| <b>Chapter 2—Operation</b> .....    | 13    |
| About operating the 2310 .....      | 14    |

|   |    |
|---|----|
| Using the front panel .....                             | 14 |
| LCD functional description .....                        | 14 |
| LCD features .....                                      | 14 |
| Extended permanent softkeys .....                       | 14 |
| <i>Color display</i> .....                              | 15 |
| <i>Transflective-monochrome display</i> .....           | 16 |
| LED display panel .....                                 | 17 |
| Working with the 2310 user interface .....              | 21 |
| Working with application setup property sheets .....    | 28 |
| Operating the printer .....                             | 31 |
| Setting up the printer .....                            | 31 |
| <i>Connecting the printer</i> .....                     | 31 |
| <i>Settings</i> .....                                   | 31 |
| <i>Using the PRINTOUTS property sheet</i> .....         | 32 |
| <i>Using the EVENTS property sheet</i> .....            | 34 |
| <i>Using the Printer Settings property sheet</i> .....  | 35 |
| Getting started .....                                   | 36 |
| Basic test setup .....                                  | 36 |
| Error LEDs .....  | 39 |
| Recharging the battery .....                            | 39 |
| Battery replacement .....                               | 40 |
| <b>Chapter 3—Common Applications</b> .....              | 41 |
| Using the T1 option .....                               | 43 |
| Monitoring T1 performance .....                         | 43 |
| <i>Configuring the 2310</i> .....                       | 43 |
| <i>Connecting the 2310 to the circuit</i> .....         | 44 |
| <i>Connecting the 2310 to the circuit diagram</i> ..... | 45 |
| T1 BERT Termination setup .....                         | 46 |
| <i>Configuring the 2310</i> .....                       | 46 |
| <i>Connecting the 2310 to the circuit</i> .....         | 47 |
| <i>Connecting the 2310 to the circuit diagram</i> ..... | 48 |
| T1 Loopback BER Testing .....                           | 49 |
| <i>Configuring the 2310</i> .....                       | 49 |

|   |    |
|---|----|
| Connecting the 2310 to the circuit.....         | 51 |
| Connecting the 2310 to the circuit diagram..... | 52 |
| T1 Timing Slip Analysis .....                   | 52 |
| Configuring the 2310.....                       | 52 |
| Connecting the 2310 to the circuit.....         | 55 |
| Connecting the 2310 to the circuit diagram..... | 56 |
| Using the Fractional T1 (FT1) option .....      | 57 |
| FT1 Loopback BER testing.....                   | 57 |
| Configuring the 2310.....                       | 57 |
| Connecting the 2310 to the circuit.....         | 59 |
| Connecting the 2310 to the circuit diagram..... | 61 |
| FT1 Drop and Insert testing .....               | 61 |
| Configuring the 2310.....                       | 62 |
| Connecting the 2310 to the circuit.....         | 63 |
| Connecting the 2310 to the circuit diagram..... | 66 |
| Using the DDS option.....                       | 67 |
| DDS Loopback BER testing.....                   | 67 |
| Configuring the 2310.....                       | 67 |
| Connecting the 2310 to the circuit.....         | 69 |
| Connecting the 2310 to the circuit diagram..... | 70 |
| DDS Drop and Insert Testing.....                | 71 |
| Configuring the T-BERD 2310.....                | 71 |
| Connecting the 2310 to the circuit.....         | 73 |
| Connecting the 2310 to the circuit diagram..... | 76 |
| Using the Signaling option .....                | 77 |
| Monitoring A/B/C/D signaling bits .....         | 77 |
| Configuring the 2310.....                       | 77 |
| Connecting the 2310 to the circuit.....         | 78 |
| Signaling Monitor (Call Capture).....           | 79 |
| Configuring the 2310.....                       | 79 |
| Connecting the 2310 to the circuit.....         | 82 |
| PBX/Switch Emulation (originating a call).....  | 83 |
| Configuring the 2310.....                       | 83 |
| Connecting the 2310 to the circuit.....         | 84 |
| PBX/Switch Emulation (terminating a call) ..... | 85 |

|   |     |
|---|-----|
| <i>Configuring the 2310</i> .....                       | 85  |
| <i>Connecting the 2310 to the circuit</i> .....         | 87  |
| T1 Drop and Insert (Place Call) .....                   | 87  |
| <i>Configuring the 2310</i> .....                       | 87  |
| <i>Connecting the 2310 to the circuit</i> .....         | 89  |
| Using the VF option.....                                | 91  |
| VF Channel Drop/Monitoring from DS1 .....               | 91  |
| <i>Configuring the 2310</i> .....                       | 91  |
| <i>Connecting the 2310 to the circuit</i> .....         | 92  |
| <i>Connecting the 2310 to the circuit diagram</i> ..... | 94  |
| Transmitting VF Tones .....                             | 95  |
| <i>Configuring the 2310</i> .....                       | 95  |
| <i>Connecting the 2310 to the circuit</i> .....         | 97  |
| <i>Connecting the 2310 to the circuit diagram</i> ..... | 98  |
| Using the Intelligent Repeater Span option.....         | 99  |
| <i>Configuring the 2310</i> .....                       | 100 |
| <i>Connecting the 2310 to the circuit</i> .....         | 102 |
| <i>Connecting the 2310 to the circuit diagram</i> ..... | 103 |
| Using the DS3 option .....                              | 105 |
| Monitoring DS3 performance.....                         | 105 |
| <i>Configuring the 2310</i> .....                       | 105 |
| <i>Connecting the 2310 to the circuit</i> .....         | 107 |
| <i>Connecting the 2310 to the circuit diagram</i> ..... | 107 |
| DS3 BER testing.....                                    | 108 |
| <i>Configuring the 2310</i> .....                       | 108 |
| <i>Connecting the 2310 to the circuit</i> .....         | 110 |
| <i>Connecting the 2310 to the circuit diagram</i> ..... | 111 |
| Using the STS-1 option .....                            | 113 |
| Monitoring STS-1 performance.....                       | 113 |
| <i>Configuring the 2310</i> .....                       | 113 |
| <i>Connecting the 2310 to the circuit</i> .....         | 115 |
| <i>Connecting the 2310 to the circuit diagram</i> ..... | 116 |
| STS-1 BER testing.....                                  | 117 |
| <i>Configuring the 2310</i> .....                       | 117 |
| <i>Connecting the 2310 to the circuit</i> .....         | 118 |

|   |     |
|---|-----|
| Connecting the 2310 to the circuit diagram..... | 120 |
| VT1.5 Drop/Monitoring from STS-1 .....          | 121 |
| Configuring the 2310.....                       | 121 |
| Connecting the 2310 to the circuit.....         | 122 |
| Connecting the 2310 to the circuit diagram..... | 123 |
| Using the OC-3/OC-12/OC-48 option .....         | 125 |
| Monitoring OC-3/OC-12/OC-48 performance .....   | 126 |
| Configuring the 2310.....                       | 126 |
| Connecting the 2310 to the circuit.....         | 128 |
| Connecting the 2310 to the circuit diagram..... | 129 |
| OC-3/OC-12/OC-48 BER testing .....              | 130 |
| Configuring the 2310.....                       | 130 |
| Connecting the 2310 to the circuit.....         | 132 |
| Connecting the 2310 to the circuit diagram..... | 133 |
| Optical Power measurement .....                 | 134 |
| Configuring the 2310.....                       | 134 |
| Connecting the 2310 to the circuit.....         | 135 |
| Connecting the 2310 to the circuit diagram..... | 136 |
| Using the VT100 Emulation option.....           | 137 |
| Configuring the 2310.....                       | 137 |
| Using the OC-3c/12c ATM option .....            | 141 |
| Profiling with the Search Mode .....            | 142 |
| Monitoring ATM payloads .....                   | 143 |
| Configuring the 2310.....                       | 143 |
| Connecting the 2310 to the circuit.....         | 145 |
| Connecting the 2310 to the circuit diagram..... | 146 |
| Terminating ATM payloads.....                   | 147 |
| Configuring the 2310.....                       | 147 |
| Connecting the 2310 to the circuit.....         | 150 |
| Connecting the 2310 to the circuit diagram..... | 151 |
| Using the GR-303 option.....                    | 153 |
| Level 3 call statistics .....                   | 154 |
| Monitoring GR-303 performance .....             | 155 |
| Configuring the 2310.....                       | 155 |

|   |     |
|---|-----|
| <i>Connecting the 2310 to the circuit</i> .....         | 158 |
| <i>Connecting the 2310 to the circuit diagram</i> ..... | 159 |
| Using the ISDN PRI option.....                          | 161 |
| Monitoring ISDN PRI calls .....                         | 161 |
| <i>Configuring the 2310</i> .....                       | 162 |
| Connecting the 2310 to the circuit .....                | 165 |
| <i>Connecting the 2310 to the circuit diagram</i> ..... | 166 |
| Using PRI ISDN in Terminate mode .....                  | 167 |
| Placing a call.....                                     | 167 |
| <i>Configuring the 2310</i> .....                       | 168 |
| <i>Connecting the 2310 to the circuit</i> .....         | 171 |
| Receiving a call.....                                   | 173 |
| <i>Configuring the 2310</i> .....                       | 173 |
| <i>Connecting the 2310 to the circuit</i> .....         | 174 |
| <i>Connecting the 2310 to the circuit diagram</i> ..... | 175 |
| NFAS and D channel backup testing .....                 | 175 |
| <i>Configuring the 2310</i> .....                       | 175 |
| <b>Chapter 4—Test Results</b> .....                     | 179 |
| Results Categories.....                                 | 181 |
| Summary Category .....                                  | 181 |
| DS1 Summary Category test results .....                 | 181 |
| DS3 Summary Category test results .....                 | 182 |
| SONET Summary Category test results .....               | 182 |
| LED Category.....                                       | 183 |
| DS1 LED Category test results.....                      | 184 |
| DS3 LED Category test results.....                      | 185 |
| SONET LED test results .....                            | 186 |
| Signal Category.....                                    | 188 |
| DS1 Signal test results .....                           | 188 |
| DS3 Signal test results .....                           | 189 |
| SONET Signal test results .....                         | 190 |
| BPV Category .....                                      | 192 |
| DS1 BPV test results .....                              | 192 |

|  |     |
|--|-----|
| DS3 BPV test results .....                   | 193 |
| Frame Category .....                         | 193 |
| DS1 Frame test results .....                 | 194 |
| DS3 Frame test results .....                 | 195 |
| Parity Category .....                        | 197 |
| DS3 Parity test results .....                | 197 |
| SONET Section Category .....                 | 199 |
| SONET Section test results .....             | 199 |
| SONET Line Category .....                    | 200 |
| SONET Line test results .....                | 201 |
| SONET Path Category .....                    | 204 |
| SONET Path test results .....                | 205 |
| SONET Path Trace Category .....              | 206 |
| SONET Path Trace test results .....          | 207 |
| SONET VT Category .....                      | 207 |
| SONET VT test results .....                  | 208 |
| SONET ATM Category .....                     | 210 |
| SONET ATM VPI/VCI test results .....         | 210 |
| Channel Category .....                       | 212 |
| Channel VF and DDS test results .....        | 212 |
| Reportable DS0 Control Codes .....           | 214 |
| Call Signal Category .....                   | 215 |
| Call Signal test results .....               | 216 |
| Traffic Category .....                       | 217 |
| Traffic Category test results .....          | 217 |
| Logic Category .....                         | 218 |
| DS1, DS3, and SONET Logic test results ..... | 218 |
| Time Category .....                          | 220 |
| Time Category test results .....             | 220 |
| GR-303 Category .....                        | 221 |
| GR-303 Level-2 test results .....            | 221 |



|   |            |
|---|------------|
| GR-303 Level-3 test results .....                     | 223        |
| GR-303 Cause Codes .....                              | 223        |
| PRI ISDN Category .....                               | 225        |
| PRI ISDN test results .....                           | 225        |
| PRI ISDN Cause Codes .....                            | 227        |
| National-specific Cause Codes .....                   | 229        |
| Quad Results .....                                    | 230        |
| Quad customized test results .....                    | 230        |
| Using Quad results .....                              | 231        |
| Configuring the 2310 for Quad results .....           | 231        |
| <b>Chapter 5—Customer Services .....</b>              | <b>235</b> |
| About our services .....                              | 236        |
| Customer service locations .....                      | 236        |
| Instrument services .....                             | 237        |
| Product Enhancement Group .....                       | 238        |
| Test systems field engineering and installation ..... | 238        |
| Technical training .....                              | 239        |
| Warranty information .....                            | 240        |
| Equipment return instructions .....                   | 242        |
| <b>Appendix A—Specifications .....</b>                | <b>245</b> |
| Physical specifications .....                         | 246        |
| Environmental specifications .....                    | 246        |
| Electrical specifications .....                       | 247        |
| DS1 input specifications .....                        | 248        |
| DS1 output specifications .....                       | 249        |
| DS3 and STS-1 input specifications .....              | 250        |
| DS3 and STS-1 output specifications .....             | 251        |
| Optical specifications for OC-3/12/48 .....           | 252        |
| ISDN PRI specifications .....                         | 254        |
| ISDN PRI characteristics .....                        | 254        |

|                                |     |
|--------------------------------|-----|
| ISDN PRI status messages ..... | 254 |
| ATM specifications .....       | 255 |
| GR-303 specifications .....    | 255 |

# Figures

|             |  |    |
|-------------|--|----|
| Figure 1 —  | The 2000 Platform 2310 module .....                | 2  |
| Figure 2 —  | 2000 Test Pad and 2310 module .....                | 7  |
| Figure 3 —  | 2310 front panel .....                             | 9  |
| Figure 4 —  | The 2310 bottom panel .....                        | 9  |
| Figure 5 —  | The 2310 top panel .....                           | 10 |
| Figure 6 —  | Available interface connectors .....               | 12 |
| Figure 7 —  | LED display for Current/History signal alarm ..... | 17 |
| Figure 8 —  | Main screen and extended softkeys .....            | 21 |
| Figure 9 —  | Application icons with pull-down lists .....       | 22 |
| Figure 10 — | Results Group selection on main menu screen .....  | 23 |
| Figure 11 — | Pull-down list in Results Category .....           | 23 |
| Figure 12 — | Quick Configuration/Action buttons .....           | 25 |
| Figure 13 — | Sample Configuration/Action button usage .....     | 27 |
| Figure 14 — | Dual-Test Results display (labeled) .....          | 28 |

|   |     |
|---|-----|
| Figure 15 — Setup Summary property sheet.....                 | 29  |
| Figure 16 — Property sheet tabs set test parameters .....     | 30  |
| Figure 17 — PRINTOUTS property sheet.....                     | 32  |
| Figure 18 — Preview screen of files within print buffer ..... | 33  |
| Figure 19 — EVENTS property sheet .....                       | 34  |
| Figure 20 — Printer Settings property sheet.....              | 35  |
| Figure 21 — T1 Monitor test setup.....                        | 45  |
| Figure 22 — T1 Termination test setup.....                    | 48  |
| Figure 23 — T1 Loopback test setup .....                      | 52  |
| Figure 24 — DS1 Timing Slips test setup .....                 | 56  |
| Figure 25 — FT1 Loopback test setup .....                     | 61  |
| Figure 26 — FT1 Drop and Insert setup .....                   | 66  |
| Figure 27 — DDS Loopback BER test setup .....                 | 70  |
| Figure 28 — DDS Drop and Insert setup .....                   | 76  |
| Figure 29 — Drop and Insert test setup .....                  | 89  |
| Figure 30 — DS0 (VF) Drop/Monitor test setup .....            | 94  |
| Figure 31 — VF Tone Insertion test setup .....                | 98  |
| Figure 32 — Intelligent Repeater loop code test setup .....   | 103 |
| Figure 33 — DS3 Monitor test setup.....                       | 107 |
| Figure 34 — DS3 Termination test setup.....                   | 111 |
| Figure 35 — STS-1 Monitor test setup.....                     | 116 |

|   |     |
|---|-----|
| Figure 36 — STS-1 BER test setup .....                          | 120 |
| Figure 37 — STS-1/VT 1.5 Drop/Monitor test setup .....          | 123 |
| Figure 38 — MON/THRU Mode Error/Alarm Insert test setup .....   | 129 |
| Figure 39 — SONET Termination BER test setup .....              | 133 |
| Figure 40 — OC-3/12/48 Power Measurement setup .....            | 136 |
| Figure 41 — TTC ATM Test Cell #1 .....                          | 142 |
| Figure 42 — Monitoring OC-3c/12c ATM test setup .....           | 146 |
| Figure 43 — Terminating OC-3c/12c ATM test setup .....          | 151 |
| Figure 44 — GR-303 test setup .....                             | 159 |
| Figure 45 — Monitor ISDN PRI test setup .....                   | 166 |
| Figure 46 — Terminate ISDN PRI Test Setup .....                 | 175 |
| Figure 47 — Sample Quad Results screen on 2310 .....            | 232 |
| Figure 48 — Custom Results property sheet .....                 | 233 |
| Figure 49 — Custom Results enable/disable property sheets ..... | 234 |

# Tables

|  |     |
|--|-----|
| Table 1 — Front-panel features .....                           | 8   |
| Table 2 — Bottom-panel features .....                          | 10  |
| Table 3 — Top-panel features .....                             | 11  |
| Table 4 — Color extended softkey icons .....                   | 15  |
| Table 5 — Transflective-monochrome extended softkey icons .... | 16  |
| Table 6 — Green Status LEDs.....                               | 18  |
| Table 7 — Red Alarm LEDs.....                                  | 19  |
| Table 8 — DATA Category Red Alarm LEDs.....                    | 20  |
| Table 9 — Description of PRINTOUTS action buttons .....        | 32  |
| Table 10 — Description of <i>EVENTS</i> property sheet .....   | 34  |
| Table 11 — Description of Printer Setting property sheet.....  | 35  |
| Table 12 — OC-3c/12c ATM TX and RX Profile setup fields.....   | 142 |
| Table 13 — D channel states and descriptions.....              | 178 |
| Table 14 — DS1 LED test results .....                          | 184 |

|   |     |
|---|-----|
| Table 15 — DS3 LED test results .....                                     | 185 |
| Table 16 — SONET LED test results .....                                   | 186 |
| Table 17 — DS1 Signal test results .....                                  | 188 |
| Table 18 — DS3 Signal test results .....                                  | 189 |
| Table 19 — SONET Signal test results .....                                | 190 |
| Table 20 — DS1 BPV test results .....                                     | 192 |
| Table 21 — DS3 BPV test results .....                                     | 193 |
| Table 22 — DS1 Frame test results .....                                   | 194 |
| Table 23 — DS3 Frame test results .....                                   | 195 |
| Table 24 — DS3 Parity test results .....                                  | 197 |
| Table 25 — SONET Section test results .....                               | 199 |
| Table 26 — SONET Line test results .....                                  | 201 |
| Table 27 — SONET Path test results .....                                  | 205 |
| Table 28 — SONET Path Trace test results .....                            | 207 |
| Table 29 — SONET Virtual Tributary Overhead test results .....            | 208 |
| Table 30 — ATM VPI/VCI Stats, Cell, and Cell Type Category results<br>210 |     |
| Table 31 — Channel VF and DDS Category test results .....                 | 212 |
| Table 32 — Reportable DS0 Control Codes .....                             | 214 |
| Table 33 — Call Signal Category test results .....                        | 216 |
| Table 34 — Traffic Category test results .....                            | 217 |
| Table 35 — DS1, DS3, and SONET Logic test results .....                   | 218 |

|  |     |
|--|-----|
| Table 36 — Time Category test results.....                   | 220 |
| Table 37 — GR-303 Level-2 Protocol Link test results .....   | 221 |
| Table 38 — GR-303 Level-3 call statistical test results..... | 223 |
| Table 39 — GR-303 Cause Codes .....                          | 223 |
| Table 40 — ISDN PRI category descriptions .....              | 225 |
| Table 41 — Cause Codes descriptions.....                     | 227 |
| Table 42 — National-specific Cause Codes .....               | 229 |
| Table 43 — Custom Results for DS0, T1, DS3, and SONET .....  | 230 |
| Table 44 — Physical characteristics for 2310 .....           | 246 |
| Table 45 — Electrical characteristics for 2310.....          | 246 |
| Table 46 — Electrical characteristics .....                  | 247 |
| Table 47 — Input specifications for DS1 .....                | 248 |
| Table 48 — Output specifications for DS1 .....               | 249 |
| Table 49 — Input specifications for DS3 and STS-1.....       | 250 |
| Table 50 — Output specifications for DS3 and STS-1 .....     | 251 |
| Table 51 — Optical specifications for OC-3/12/48 .....       | 253 |
| Table 52 — ISDN option characteristics .....                 | 254 |
| Table 53 — ISDN PRI status messages .....                    | 254 |



# About This Guide

## Purpose and scope

The purpose of this guide is to help you successfully use the 2310 features and capabilities. This guide includes task-based instructions that describe how to operate and use the 2310. Additionally, this guide provides a complete description of Acterna's warranty, services, and repair information, including terms and conditions of the licensing agreement.

## Assumptions

This guide is intended for novice, intermediate, and experienced users who want to use the 2310 effectively and efficiently. We are assuming that you have basic computer and mouse/track ball experience and are familiar with basic telecommunication concepts and terminology.

## Getting technical assistance

If you need assistance or have questions related to the use of this product, call or email Acterna's Technical Assistance Center (TAC) for customer support.

### *Technical assistance centers*

| Region                          | Phone Number                               | Hours of Operation                  |
|---------------------------------|--|-------------------------------------|
| Americas                        | 1-800-638-2049                             | M-F, 8:00 a.m. to 8:00 p.m.,<br>EST |
| Europe, Africa, and<br>Mid-East | +800 882 85822<br>(European Freephone)     | M-F, 8:30 a.m. to 5:00 p.m.,<br>GMT |
|                                 | +44 (0) 118 940-9200<br>(Acterna UK)       |                                     |
|                                 | +49 (0) 6172 59 11 00<br>(Acterna Germany) |                                     |
|                                 | +33 (0) 1 39 30 24 24<br>(Acterna France)  |                                     |
| Asia and the Pacific            | +852 2892 0990<br>(Hong Kong)              | M-F, 9:00 a.m. to 5:30 p.m.         |
|                                 | +8610 6833 7477<br>(Beijing-China)         |                                     |

During off hours, you can leave a voice mail message; send an email to [tac@acterna.com](mailto:tac@acterna.com) (in Europe, [eurotac@acterna.com](mailto:eurotac@acterna.com)); or submit your question using our online Technical Assistance Request form at [www.acterna.com](http://www.acterna.com).

## Using this guide

The following table is a roadmap to using this guide efficiently; however, all chapters in this guide can be used for reference purposes:

### *Locating information*

| To   | Refer to                        |
|--|---------------------------------|
| Become familiar with the 2310                          | Chapter 1 "Introduction"        |
| Perform basic and general operations of the 2310       | Chapter 2 "Operation"           |
| Learn to use and apply features in a field environment | Chapter 3 "Common Applications" |
| Access and understand test results                     | Chapter 4 "Test Results"        |
| Learn about the warranty                               | Chapter 5 "Customer Services"   |
| Identify specifications                                | Appendix A "Specifications"     |

## Conventions

This guide uses naming conventions and symbols, as described in the following tables:




### Typographical conventions

| Description  | Example                                 |
|--|---|
| Commands appear in this <b>typeface</b> .                                    | On the Status bar, click <b>Start</b> . |
| Switches that you press on a unit appear in this <b>TYPEFACE</b> .           | Press the <b>AUX</b> switch.            |
| Variables such as names or arguments appear in this <i>typeface</i> .        | Enter new <i>hostname</i> .             |
| Computer code and output messages appear in this <code>typeface</code> .     | All results okay                        |
| Text you must enter exactly as shown appear in this <code>typeface</code> .  | Type: a: \set.exe in the dialog box     |
| Directories, websites, and filenames appear in this <code>typeface</code> .  | filename.txt                            |
| Square brackets [ ] indicate an optional argument.                           | login [platform name]                   |
| A vertical bar   means "or": only one option can appear in a single command. | platform [a b e]                        |
| Slanted brackets < > are used to group required arguments.                   | <Enter your name>                       |
| Brackets { } indicate a set of choices from which you must choose one.       | {file1 file2 file3}                     |

*Keyboard and menu conventions*

| Description  | Example                             |
|--|-------------------------------------|
| A plus sign + indicates simultaneous keystrokes          | Press Ctrl+s                        |
| A comma indicates consecutive key strokes                | Press Alt+f,s                       |
| A slanted bracket indicates choosing a submenu from menu | Click <b>Start&gt;Program Files</b> |

*Warnings, cautions, and notes*

| Icon  | Description   |
|---|---|
|  | <b>WARNING:</b><br><i>Action results in a serious injury or death.</i>                                |
|  | <b>CAUTION:</b><br><i>Action could cause minor or moderate injury and damage to you or equipment.</i> |
|  | <b>NOTE:</b><br><i>Provides related information or tip.</i>   |

---

# Introduction

This chapter provides a general description of the 2310. Topics discussed in this chapter include the following:

- “About the 2310” on page 2
- “Features and capabilities” on page 3
- “Options” on page 4
- “System requirements” on page 6
- “Physical description” on page 8

## About the 2310

The 2310 Communication Analyzer is the perfect telecommunications installation and maintenance tool for a mobile workforce. A hand-held tester, its ease-of-use, flexibility, and functionality have established it as the next generation in test instruments. The 2310 is the *smallest* OC-48, battery-powered, integrated tester available. As a member of the 2000 Test Pad family of products, it combines a graphical user interface with a touch-sensitive screen to simplify test setup and reduce test configuration time. The “smart tester,” icon-driven interface is easy to learn, and the large display screen provides ample space for displaying test results. Figure 1 shows the 2310.



**Figure 1** — The 2000 Platform 2310 module

## Features and capabilities

Even though the 2310 weighs only 5 pounds, it provides integrated test capabilities:

- DS1, DS3, and SONET interfaces
  - Standard Dual Receive for DS1
  - Dual Receive for DS3, and STS-1 (optional)
  - OC-3, OC-12, and OC-48 interfaces (optional)
  - DS0, DS1, Muxed DS3, and VT1.5 in SONET testing
  - Controls and Results Print capability
  - Monitor/Thru and Terminate applications for DS1, DS3, STS-1, OC-3/OC-12/OC-48 interfaces
  - DS1, DS3, and SONET (OC-3/3c, OC-12/12c, OC-48/48c) BERT patterns
  - DS1 Unframed, D4, ESF and SLC 96 framing, T1 BERT, VF tone testing, and insertion of frame, BPVs, and logic errors
  - DS3 Unframed, M13, C-bit BERT or Muxed DS3 testing, internal or recovered timing, RX/TX at HIGH, DSX, and LOW levels, insertion of frame, BPVs, and logic errors, as well as, FEBE and yellow alarm emulation
  - SONET SPE Payloads (Async DS1 mapping, DS3 mapping, full SPE BERT), SPE pointer manipulation, K-byte manipulation, STS-1 RX/TX at HIGH, DSX, and LOW levels, insertion of Line and Path AIS alarms, FEBE, LOP, and BIP errors, as well as frame, logic, and BPV (STS-1 only) errors, and TX/RX path trace for viewing
- On-Line Help



## Options

The touch-screen user interface enables these test capabilities in an easy, step-by-step manner:

- Primary Rate ISDN analysis: part number TB2310-PRI

This option adds Primary Rate ISDN testing capabilities for DS1, DS3, and STS-1. It enables the ability to place and receive multiple voice/data calls, perform D channel backup, support NFAS, and monitor the circuit via D channel decodes. It also supports AT&T 5ESS, NT DMS100 and NI-2 call controls, as well as, supports multiple call types such as voice, 56K, 64K, Nx64, Nx56, and H0.

- GR-303 analysis: part number TB2310-GR303

This option includes the ability to verify the connectivity of the TMC/CSC and EOC management channels. It also verifies report-call setup and teardown information.

- Advanced stress patterns: part number TB2310-ASP

This option adds the ability to transmit and receive fixed, long patterns beyond the standard patterns offered in the test set. The seven T1 stress patterns that are added to the 2310 are designed to stress test the timing recovery circuits and span-line repeater ALBO circuitry. The seven patterns include: T1-DALY, 55 octet, 2-96, 3-54, 4-120, 5-53, and MIN/MAX.

- Fractional T1 analysis: part number TB2310-F11

This option provides fractional T1 modes for contiguous and noncontiguous, 56KxN and 64KxN, and FT1 testing capabilities. This option enables complete qualification and testing of new FT1 circuits before connecting customer premises equipment. The V.54 FT1 loop code is also added to the features list and allows for single-set testing of FT1 circuits from a convenient T1, DS3 or STS-1 access point.

- **DDS Analysis:** part number TB2310-DDS

This option provides T1 DDS modes for 56K and 64K DDS circuits. It enables complete qualification and testing of new DDS circuits using the DDS1-6, 63, 511 and 2047 stress patterns. The OCU, DSO-DP, CSU, and Channel loop codes allow for single-set testing of DDS circuits from a convenient T1 access point.

- **Signaling Analysis:** part number TB2310-SIG

This option enables you to test the ability of a switch/PBX to handle incoming calls and allows you to emulate switch-to-switch communications. You can place, receive and monitor calls over several trunk types. Features include the ability to send and receive DTMF/MF/DP digits to and from switches and PBXs, as well as the ability to measure inter-digit delay and digit/tone duration.

- **VF PCM TIMS Analysis:** part number TB2310-VF

This option enables the 2310 to perform a frequency sweep test to qualify VF circuits. Features such as noise measurements including SNR, C-Message, C-Notch, 3k-Flat, and 3k-Notch are also part of this option. Voice Drop, variable tone, level insertion, and level frequency results are standard with the 2310.

- **VT100 Emulation:** part number TB2310-VT100

This option enables the 2310 to emulate a VT100 terminal. The option includes an RS-232 interconnect cable.

- **Intelligent Line Equipment Analysis:** part number TB2310-ILE

This option provides the ability to loop up and loop down individual T1 addressable office repeaters, line repeaters, and to transmit maintenance switch commands. Additionally, you can loop up and loop down HDSL line units, doublers, and remote units. Supported T1 equipment include units by Teltrend, Westell, and XEL. Supported HDSL equipment include units by Adtran and PairGain.

- OC-3c and OC-12c ATM Analysis: part numbers TB2310-ATM-OC3 and TB2310-ATM-OC12

This option provides OC-3c and OC-12c ATM test functionality for the 2310. This option enables the 2310 to transmit and receive ATM cell streams with different VPI/VCI addresses, measure ATM QoS parameters like dropped cells, mis-inserted cells, and out-of-sequence cells. It automatically identifies multiple cell streams on an ATM circuit, allowing complete qualification and testing of new ATM circuits before connecting customer premises equipment and/or Network Elements.

## System requirements

The 2310 is a hand-held tester that is designed around a powerful and flexible 2000 Test Pad architecture, which includes a touch-sensitive screen that supports various application modules. The modular design enables the 2000 Test Pad to easily convert from one test technology to another.

### Hardware requirements

The modular design includes a 2000 Test Pad for simple release and swapping of application modules (see Figure 2). The 2310 also comes with a hand strap that can be mounted on the left side of the test pad.

The LED display for Primary and Secondary DS1/DS3/SONET signals in both current and history is also depicted.





Figure 2 — 2000 Test Pad and 2310 module

## Physical description

### Front-panel features

The 2310 provides transmitters and receivers for DS1/DS3/SONET circuit analysis and offers a touch-sensitive liquid crystal display (LCD) for test configuration and results selection (see Figure 3).



**Figure 3** — 2310 front panel

Callouts in Figure 3 are described in Table 1.

**Table 1** — Front-panel features

| # | Item      | Description   |
|---|-----------|---|
| 1 | Speaker   | Provides audio output for active voice calls.                                       |
| 2 | Power LED | Illuminates when power is supplied either from the battery or the AC power adaptor. |


**Table 1 — Front-panel features (continued)**

| # | Item                      | Description  |
|---|---------------------------|--|
| 3 | Charging LED <sup>a</sup> | Illuminates when the battery is charging. The battery charges when AC power is connected to the unit. However, if performing an optical test, the battery does not recharge. |
| 4 | Low Battery LED           | Illuminates when only 25% or less of battery power remains. Use the AC power adaptor to recharge the battery and continue testing.   |
| 5 | LCD                       | Divides into two, touch-sensitive screen areas for test configuration and test results display. Refer to Section 2 for a detailed description of the LCD and how it works.   |
| 6 | LED display panel         | Illuminates whenever physical errors from the signal, frame, or pattern appear in the Summary Result Window of the LCD for DS1, DS3, and/or SONET signals.                   |

a. The charging LED is not always on when plugged into the AC adapter. If the battery is above 85% charged, the charging LED blinks. If the battery is above 95%, the charging LED does not illuminate.

### Bottom-panel features

The 2310 bottom panel provides the power switch, AC adaptor plug, and battery access panel (see Figure 4).

**Figure 4 — The 2310 bottom panel**


Callouts in Figure 4 are described in Table 2.

**Table 2 — Bottom-panel features**

| # | Item                | Description   |
|---|---------------------|---|
| 1 | Battery Access Door | Provides access to the rechargeable battery compartment.            |
| 2 | Adaptor Plug        | Connects an 18 VDC connector to the AC Power Adaptor.               |
| 3 | Power Switch        | Turns the test set on or off.                                       |
| 4 | Bottom Vent         | Allows air to circulate through the module to the side-mounted fan. |

### Top-panel features

The 2310 top panel provides the printer connector, Dual-PCMCIA card slot, and DS1/DS3/SONET connections (see Figure 5).



**Figure 5 — The 2310 top panel**

Table 3 describes the top panel of the test unit.

**Table 3 — Top-panel features**

| # | Item  | Description  |
|---|---|--|
| 1 | Printer Connector                                 | Provides the connection for a serial printer (PR-40A/B) for printing the test configuration and test results.                              |
| 2 | Dual-PCMCIA Card Door/Slot                        | Allows for software upgrades via two Type II PCMCIA cards or one Type III PCMCIA card.   |
| 3 | DS1/DS3/STS-1 Primary and Secondary RX & TX Jacks | Supplies the DS1 and DS3/STS-1 connections to the Primary and Secondary Receiver and Transmitter.  |
| 4 | OC-3/OC-12/OC-48 RX & TX Jacks                    | Connects the OC-3, OC-12, and OC-48 connectors to the SONET Receiver/Transmitter via the FC, SC, or ST jacks.                              |
| 5 | Active Port LEDs                                  | Illuminates yellow to indicate which specific jack is active as designated by the test setup.  |
| 6 | RX Pulse and TX Laser LEDs                        | Illuminates red when RX Pulse LED optical power is received. TX Laser LED illuminates red when the 2310 laser transmits an optical signal. |


### Interface connector layouts

The 2310 top panel provides six external interface connector layouts:


- Dual DS1 RX
- Dual DS1/DS3 RX or Single DS1/DS3 RX
- Dual DS1/DS3/STS-1 RX or Single DS1/DS3/STS-1 RX
- Single OC-3 with Dual DS1/DS3/STS-1 RX or with Single DS1/DS3/STS-1 RX
- Single OC-3/OC-12 with Dual DS1/DS3/STS-1 RX or with Single DS1/DS3/STS-1 RX
- Single OC-3/OC-12/OC-48 with Dual DS1/DS3/STS-1 RX or with Single DS1/DS3/STS-1 RX




Figure 6 depicts the external interface connector layouts for the 2310.




Dual DS1/DS3/STS-1 RX or Single DS1/DS3/STS-1 RX



Single OC-3 with Dual DS1/DS3/STS-1RX or with Single DS1/DS3/STS-1 RX



Single OC-3/OC-12 with Dual DS1/DS3/STS-1 RX or with Single DS1/DS3/STS-1 RX



3/OC-12/OC-48 with Dual DS1/DS3/STS-1 RX or with Single DS1/DS3/STS-1 RX

Figure 6 — Available interface connectors

---

# Operation

This chapter describes the 2310 instrument and graphical user interface (GUI) functionality. Topics discussed in this chapter include the following:

- “About operating the 2310” on page 14
- “Using the front panel” on page 14
- “Working with the 2310 user interface” on page 21
- “Working with application setup property sheets” on page 28
- “Operating the printer” on page 31
- “Getting started” on page 36

## About operating the 2310

As a member of the 2000 Test Pad™ family of products, the 2310 combines a GUI with a touch-sensitive screen to simplify test setup and reduce test configuration time. The “smart tester,” icon-driven interface is easy to learn, and the large display screen provides ample space for displaying test results. When you activate the 2310, it displays the main screen (see Figure 8 on page 21), which is the application configuration area.

## Using the front panel

### LCD functional description

There are two LCD types:

- Active-Transmissive Color LCD (on P/N TTC 2000-C)
- Transflective-Monochrome LCD (on P/N TTC 2000-XF)

The active-transmissive color display gives improved viewing angle, brightness, and clarity. We recommend the transflective-monochrome display if you frequently use the test pad in high-ambient lighting conditions, such as full sunlight.

### LCD features

2000 color and transflective-monochrome LCD features include the following:

- Brightness-control extended softkey for the color display
- Contrast-control extended softkey for the transflective-monochrome display
- Two gradients of brightness

### Extended permanent softkeys







There are six permanent softkeys located off the right side of the main screen that provide housekeeping functions for the 2310. Depending on the application module option, one of the sets of softkeys displays. These softkeys are shown in Table 4 and Table 5 with accompanying

descriptions of their functions. You can also see the softkeys in relation to the main screen as callout number 4 in Figure 8 on 21.

### **Color display**

Table 4 shows the extended softkeys for the color display.







**Table 4 — Color extended softkey icons**

| Icon  | Description   |
|---|---|
|    | Restart — Performs the test restart function, including resetting the current test result totals and clearing any errors and/or alarms.   |
|   | File — Activates the Auxiliary Functions screen, which allows you to view the software revision level and installed options and to set the volume, time and date, and brightness. It also provides access to the VT100 Emulator when the VT100 option is installed. |
|  | Brightness — Adjusts the brightness on the color screen display. There are two gradients of brightness:<br>Low brightness (maximizes battery life)<br>High brightness (enhances viewing)  |
|  | Battery Status — Activates the Battery Status screen, which displays the current battery strength.  |
|  | Printer Setup — Activates the Printer Setup screen, which enables you to select the printer interface parameters (Baud Rate and Parity), clear the print buffer, print results, or abort printout.  |
|  | Help (?) — Launches the Help system.  |

**Transflective-  
monochrome display**

Table 5 shows the extended softkeys for the transflective-monochrome display:

**Table 5 — Transflective-monochrome extended softkey icons**

| Icon  | Description   |
|---|---|
|    | Restart — Performs the test restart function, including resetting the current test result totals and clearing any errors and/or alarms.   |
|    | File — Activates the Auxiliary Functions screen, which allows you to view the Software Revision Level and Installed Options, and set the Speaker Volume, Time and Date, and Brightness. It also provides access to the VT100 Emulator when the VT100 option is installed. |
|    | Contrast — Adjusts the level of detail on the screen display. Pressing the left side lightens images, and pressing the right side darkens images.   |
|   | Battery Status — Activates the Battery Status screen, which displays the current battery strength.  |
|  | Printer Setup — Activates the Printer Setup screen, which enables you to select the printer interface parameters (Baud Rate and Parity), clear the print buffer, print results, or abort printout.  |
|  | Help (?) — Launches the Help system.  |

**NOTE:**

The only difference between the extended softkeys of the two touch-screens is the Contrast (transflective-monochrome) and Brightness (active-transmissive color) icons.

**LED display panel**

The Current/History error LED display panel illuminates to visually display the performance of the test being performed. Figure 7 depicts the LED display panel.




Figure 7 — LED display for Current/History signal alarm

**NOTE:**

*Your LED panel may be a subset of the one in Figure 7, depending on what option-equipped 2310 module is purchased. For example, a DS1 Module will not have SONET LEDs.*

The red alarm LEDs provide information about the current and historical alarm conditions related to the received signal. These LEDs are divided into two columns (Current and History). When the Current alarm condition is cleared (e.g., pattern sync reestablished), its History LED illuminates. The History LEDs are located on the outside column and indicate past occurrences of the alarm and remain illuminated until a test restart occurs.

The inside “green” LEDs for Signal, Frame, Pattern, and Path/VT PTR (SONET only) are key to knowing the Current status of the test, and you need to wait to see if they illuminate when performing a test. If any one of these conditions is lost while performing the specified test, a History red LED illuminates and the green Current LED light extinguishes. The remaining Current LED lights are red (ERRORS, ALARMS, PTR ADJ) and illuminate when errors are present in the Current test, then change to History when error alarm is removed. Table 6 describes the green status LEDs.

**Table 6 — Green Status LEDs**

| LED       | Description   |
|-----------|---|
| SIGNAL    | Recognizes a signal is present.   |
| FRAME     | Establishes synchronization with the framing of a signal.               |
| PATTERN   | Establishes synchronization with the pattern of a signal.               |
| PATH & VT | Receives a valid pointer with SONET pointer bytes and VT pointer bytes. |
| SYNC      | Receives six consecutive ATM cells with an unerrored HEC field.         |

Table 7 describes the Red Alarm LEDs.

**Table 7 — Red Alarm LEDs**

| LED          | Description  |
|--------------|--|
| <b>DS1</b>   |  |
| SIGNAL       | Displays an alarm if DS1 signal is lost.   |
| FRAME        | Displays an alarm if DS1 frame synchronization is lost.  |
| PATTERN      | Displays an alarm if DS1 pattern synchronization is lost.  |
| SUMMARY      | Displays an alarm if an error has been recorded by the unit, as shown in the DS1 Results Summary window.                   |
| <b>DS3</b>   |  |
| SIGNAL       | Displays an alarm if DS3 signal is lost.   |
| FRAME        | Displays an alarm if DS3 frame synchronization is lost.  |
| PATTERN      | Displays an alarm if pattern synchronization is lost.  |
| SUMMARY      | Displays an alarm if an error has been recorded by the unit, as shown in the DS3 Results Summary window.                   |
| <b>SONET</b> |  |
| SIGNAL       | Displays an alarm if SONET signal is lost.   |
| FRAME        | Displays an alarm if SONET frame synchronization is lost.  |
| PATH PTR     | Displays an alarm when the path pointer byte is lost after initial synchronization.  |
| VT PTR       | Displays an alarm when the virtual tributary overhead path pointer byte changes after initial synchronization.             |
| PATTERN      | Displays an alarm if pattern synchronization is lost.  |
| PTR ADJ      | Displays an alarm if overhead path pointer byte pointer adjustments are recorded.  |
| ALARMS       | Displays an alarm when an AIS (blue alarm) or RDI (yellow alarm) is detected since the last test restart or history reset. |
| SUMMARY      | Displays an alarm if an error has been recorded by the unit, as shown in the SONET Results Summary window.                 |



**Table 7 — Red Alarm LEDs (continued)**

| LED          | Description   |
|--------------|---|
| SYNC FAILURE | Indicates synchronization loss is present for 2.5 seconds. This clears when cell synchronization is regained and loss of synchronization has not occurred in 10 seconds. This is equivalent to a loss of cell delineation failure (LCD failure) indication. |


Table 8 describes the Red Alarm LEDs for the DATA Category.

**Table 8 — DATA Category Red Alarm LEDs**

| LED     | Description   |
|---------|---|
| SYNC    | Displays an alarm if ATM synchronization has been lost. Synchronization loss is characterized by reception of at least seven consecutive errored HECs after cell synchronization. |
| SUMMARY | Illuminates when an ATM error has been recorded by the unit, as shown in the ATM Results Summary Window.  |

## Working with the 2310 user interface

The main screen is divided into eight areas (see Figure 8). The main screen is used to provide setup and configuration data and to display test-specific action buttons.



**Figure 8 — Main screen and extended softkeys**

Each area has a function, as described in the following paragraphs:

- 1 **Application icon selection** — This area displays the **MON/THRU** (Monitor and Through), **TERM** (Terminate), **D&I** (Drop and Insert), **MUX** (Multiplexer), and **QUAD** (Quadruple Split Screens) icon buttons used to select a test application. Refer to Figure 9 for a display of the icons and their associated pull-down menus.
  - For **MON/THRU** modes, the timing of the interface is set to recovered and the data is passed from the primary receiver to

the primary transmitter, unchanged, **except** for automatically correcting BPVs and SONET BIPs.

**THRU** mode allows error and alarm insertion to be performed. Outside of changing test applications for output levels, the transmit data stream does not fluctuate when you change setups or restarts. If installed and applicable to the test, the secondary receiver is active and collects results.

- For **TERM** mode, unless otherwise noted by special test operations (such as loop backs), the transmitter and receiver are entirely independent except for setup. If a secondary receiver is activated (for DS1, DS3/STS-1), results are collected on that receiver.
- **D&I** mode allows for in-service testing of one channel (DS0) from a higher rate signal (DS1). Example: Place a call on one channel while allowing the T1 to remain operational.
- **MUX** mode allows for simultaneous testing of two signals. Example: Transmit a T1 signal and Receive an OC-3 signal.
- **QUAD** results is a results function that displays up to four embedded signal rates at once in the Results Window of the 2310. For example, by pressing the Quad Results icon, you could monitor a STS-1 signal with a DS3 mapped payload, a T1 signal, and measure the VF tone within a specific DS0, in both the primary *and* secondary directions (if the dual Rx option is installed).




Figure 9 — Application icons with pull-down lists

- 2 **Result Group display** — The first button in this dual-feature display depicts a pull-down list of the current test results, and lets you change the *source* between the Primary and Secondary receivers, such as T1 Pri (T1 Primary), T1 Sec (T1 Secondary), DS3 Pri, DS3 Sec, SONET Pri, and SONET Sec (see Figure 10).




Figure 10 — Results Group selection on main menu screen

- 3 **Results Category display** — The second button in this dual-feature display offers a pull-down list allowing you to choose test results in numerous *categories*. Categories change according to the application selected. Figure 11 shows an example of categories listed for SONET applications.




Figure 11 — Pull-down list in Results Category

Descriptions of the categories available are as follows:

- **Summary** — This is the default category that automatically displays results that are non-zero or out-of-specification.
- **LED** — Selection of this category activates the Signal Alarm LEDs display. Two columns of LEDs reflect the current and history condition for each alarm. When an alarm first occurs, the appropriate current LED illuminates and remains illuminated until the condition clears. If the condition clears, the History LED for that alarm illuminates and the current LED is extinguished. If the condition occurs again, the current LED illuminates and the History LED remains illuminated to show the condition also occurred in the past.
- **Signal** — The Signal category results include signal losses, frequency, level, and power measurements. Timing slips, as well as BPVs for STS-1 applications, are also recorded in this category.
- **BPV** — Bipolar Violations are caused by successive pulses with the same polarity being detected (except those pulses that are part of the B8ZS encoding). Bipolar violation results are accumulated when the signal is present.
- **Frame** — Frame errors are based on counting framing bits and identifying frame errors in the incoming signal after initial frame synchronization. The results are available whenever the receiver detects a valid framed signal, regardless of the transmitter framing mode. For DS3 analysis, DS2 frame errors and FEAC history are recorded here. CRC errors found in DS1 analysis are also recorded in this category.
- **Logic** — Logic errors are based on discrepancies between the transmitted and received bit stream. The accumulation of logic errors is dependent on frame synchronization (if in a framed mode) and pattern synchronization. During loss of frame or pattern synchronization, the accumulation of errors halts. Pattern losses and slips are also recorded under this category.

- **Channel** — The Channel category displays the result associated with the DS0 channel under test.
  - **Parity** — Parity errors are based on detecting whether bits of data have been altered during transmission of that data. Parity errors, C-bit errors, and FEBEs are recorded in this category.
  - **Section** — The Section category is only available when performing SONET testing. Frame errors and Section BIP errors are recorded in this category.
  - **Line** — The Line category is only available when performing SONET testing. Here, APS and Pointer analyses are recorded, as well as Line BIP errors and Line FEBEs. These measurements are available once SONET frame synchronization has occurred.
  - **Path** — The Path category is present when performing SONET testing. Path BIP errors and FEBEs, as well as viewing the Path Trace, are recorded in this category. SONET frame synchronization is required before results can be obtained.
  - **VT** — The VT category is active when performing VT analysis. VT BIP errors and FEBEs are recorded here as well as VT pointer analysis. SONET frame synchronization must be established prior to recording these results.
  - **Path Trace** — SONET Path Trace displays the path trace byte (J1) of the STS-1 signal under test.
  - **Traffic** — The Traffic category displays results for all 24 DS0 time slot or channel signaling bits and channel assignments.
  - **Call Sig** — The Call Signal category is active when placing, receiving, and monitoring a call. It displays supervisory events, digits, and their associate parameters.
  - **Time** — The Time category shows elapsed time of the test, current date, and time.
- 4 **Permanent softkeys** — This area includes six permanent softkeys that provide housekeeping functions for the 2310 (see “Transflective-monochrome display”, on page 16).

- 5 Quick Configuration softkeys** — These multiple configuration buttons display setups based upon the type of test initiated. Only those pertaining to the specific test display, depending on what test application you choose. The following figures show two depictions; Figure 12 is a diagram showing various possible configurations, while Figure 13 shows real-test usage. Refer to “Working with application setup property sheets” on page 28 for information on how these buttons apply to the property sheets.
- 6 Action softkeys** — These action buttons are designed to take specific action during a test to initiate and measure the test (see Figure 12 and Figure 13).






Figure 12 — Quick Configuration/Action buttons



**Figure 13** — Sample Configuration/Action button usage

- 7 **Dual-Test Results display** — This area (see Figure 14) displays two test results windows associated with the current test application. Each window has a button for selecting the Result Group and a button for selecting the Result Category. Figure 14 shows a sample depiction of the Dual-Test Results display.





**Figure 14 — Dual-Test Results display (labeled)**


- 8 Message display** — This area (see Figure 8 and Figure 14) displays messages regarding activity associated with the current test application. The message display is comprised of:
- **Test State/Status** — Shows the current test application.
  - **Setup** — Shows what part of the segment is being tested.

In the example above (see Figure 14), the Message Display indicates that the test pad is in Terminate OC-12c BERT state, set up to test SONET Internal Timing, using the SONET Primary receiver as its source for results. The bit errors and BIP errors in the Result Value window appear after you choose that selection from the Result List.

## Working with application setup property sheets


When any of the Quick Configuration buttons are pressed, setup property sheets (which are tabulated for subsequent choices) appear on the LCD. These property sheets consist of a Setup Summary (see

Figure 15) and tabulated property sheets (see Figure 16) that provide the parameters for all test settings not already determined by the test application (default settings).




**Figure 15** -- Setup Summary property sheet

When pressed, the Setup configuration key prompts a Summary sheet that allows you to confirm the configuration of the test set matches the test to be performed. Behind the Summary sheet, there are tabs of additional setup sheets that prompt you to set additional parameters for the test application. Figure 16 shows a random sampling of property tabs within the property sheets.



The Internal Timing property sheet tab displays after selecting the Setup configuration button (for Terminate DS3 Bert in OC-3).

The Channel property sheet tab displays after selecting the Setup configuration button (for Monitor VT1.5 VF in OC-3).



**Figure 16** — Property sheet tabs set test parameters

#### NOTE:

Using the Setup property sheets disables the extended digitized soft-keys (RESTART, PRINT, FILE, BATTERY, CONTRAST, and HELP).

Remember to press **OK** on the property sheet to set the value. You can also cancel the settings by pressing **CANCEL**. If you have multiple property sheets to set, it is not necessary to press **OK** until the last parameter is set.

## Operating the printer

The 2310 provides print capability for both test configuration (Controls Print) and test results (Results Print). This section describes each of the printouts and how to generate them using the Print feature.

The 2310 can generate a printout manually or automatically (via timed and errored event prints). When a results printout is initiated either manually or automatically, the test results are dumped to the print buffer.

### Setting up the printer

The following connections and controls are used to set up the printer and the 2310.

### Connecting the printer

The printer connector on the top of the mainframe is an 8-pin connector used to connect the 2310 to a serial printer like the Acterna PR-40A/B. The connector is configured as a Data Communications Equipment (DCE) connection, which allows you to connect the 2310 to Data Terminal Equipment (DTE).

### Settings

The 2310 printout generation is controlled through the Printer Screen (see Figure 17), which is activated by pressing the Printer permanent softkey on the right side of the main display.




The print function displays three property sheets:

- **PRINTOUTS** — Enables you to generate and print current results, print the configuration of controls that generated the test results, and to preview the printout.

- **EVENTS** — Enables you to set timed result printouts, automatically create a Print File when an error is detected, and allows you to specify a test duration.
- **Printer Settings** — Enables you to select the baud rate and parity for the printer interface.

### Using the PRINTOUTS property sheet

To use the Printouts property sheet, press the **Printer** permanent softkey. It is the first tab (see Figure 17) to exhibit.



The Printouts tab displays all printouts that are currently stored on the 2310. The print buffer stores up to 20 printouts. After storing 20 printouts, the oldest printout is deleted if a new printout is added.

Figure 17 — PRINTOUTS property sheet

Table 9 describes the functions of the PRINTOUTS tab buttons.


Table 9 — Description of PRINTOUTS action buttons

| Item    | Description   |
|---------|---|
| Results | Generates a date-and-time, stamped printout of current test results. Test results become available only after the 2310 has received a valid signal.                       |
| Control | Generates a date-and-time, stamped printout of the current test configuration. This printout includes the test application and parameters associated with the test setup. |

**Table 9** — Description of PRINTOUTS action buttons (continued)


| Item       | Description   |
|------------|---|
| Delete All | Deletes all print files contained in the print buffer of the 2310.  |
| Delete     | Deletes a selected print file contained in the print buffer of the 2310.  |
| View       | Previews each print file as it would be printed.  |
| Print      | Sends the selected print file contained in the print buffer to the 2310 external printer port. Select the appropriate file and press <b>Print</b> to send the file to the printer port. |

To select a file in the Print Buffer, use your stylus and press the view button to review it (see Figure 18).

**Figure 18** — Preview screen of files within print buffer

**Using the EVENTS  
property sheet**

To use the EVENTS property sheet, press the **Printer** permanent softkey. Selecting EVENTS (see Figure 19) allows you to set timed result printouts, automatically create a print file when an error is detected, and allows you to specify a test duration before the 2310 creates a Results print file.



**Figure 19** — EVENTS property sheet

Table 10 describes the choices on the Events property sheet.


**Table 10** — Description of EVENTS property sheet

| Item                 | Description   |
|----------------------|---|
| Timed Printouts      | Allows results to be printed every 15 minutes, every 2 hours, every 24 hours, or at user-defined timed intervals. <sup>a</sup>        |
| Enable Error Logging | Automatically creates a print file when an error is detected. The file will contain a time/date stamp and the type of error detected. |
| Print on Test End    | Allows you to specify a test duration before the 2310 creates a Results print file.   |

a. If you select Disabled, printouts are performed manually only if you press Results or Control on the Printouts tab.

### Using the Printer Settings property sheet

To use the Printer Settings property sheet, press the **Printer** permanent softkey. It allows you to select the baud rate and parity for the printer interface (see Figure 20).



**Figure 20** — Printer Settings property sheet

Table 11 describes the choices on the **Printer Setting** property sheet.

**Table 11** — Description of Printer Setting property sheet

| Item      | Description   |
|-----------|---|
| Baud Rate | Allows you to specify which baud rate (transmission speed) to set when printing a file.     |
| Parity    | Allows you to specify odd, even, or no parity before the 2310 creates a Results print file. |



## Getting started

### Basic test setup

To operate the 2310, turn on the test set, wait for the main screen to appear, and then perform the following steps:


#### NOTE:

*We recommend using the stylus supplied with the 2310 to activate functions on the touch-sensitive screen. However, any blunt device, including your finger, can be used.*


- 1 Select an application icon, the first step of any test.



- 2 Select an application from the list of applications in the pull-down menu that appears when the icon is selected (you can choose up to three levels deep).




When you have reached the desired level of test setup, the unit automatically configures to a default starting point for testing.



- 3 The buttons below **Setup** in the configuration section show the current settings. To change a setting, press the appropriate button to go to the corresponding property sheet. (Remember, you can press **Setup** or any of the Quick Configuration buttons.)
  - To check or change the configuration, press **Setup**, which replaces the main screen with the property sheets (which are tabulated for subsequent choices). These setup sheets consist of a setup Summary (see Figure 15 on page 29) and property sheets (see Figure 16 on page 30) that provide the parameters for all test settings not already determined by a default test setup.
  - By pressing any of the tabs, you can immediately bring up the desired screen to set parameters. To change a parameter, press

or click on the appropriate tab folder to move it to the front. Set the desired parameters accordingly.



- 4 When all parameters are correct, connect to the circuit being tested using the Primary and/or Secondary TX and RX jacks. For instrument safety, we recommend connecting the cables to the 2310 first, then the circuit. Test results begin accumulating automatically.
- 5 For several applications, secondary action buttons appear in the Quick Configuration area. Press the appropriate button to perform the labeled function.
- 6 To clear alarms and begin testing, press the **RESTART** permanent softkey.



- 7 Observe the test results in the Dual-Test Results display. To observe specific test results, select the source receiver using the Result Group button, then press the Result Category button to reveal the list of categories. Press the desired category. The Test

Results List immediately shows all the test results in that category.

- 8 All available results are listed in the Test Results List, while the currently selected result is shown in the Test Result display above the list. Press a specific test result in the Test Results List to see it in the Test Result display.

**NOTE:**

*The Dual Test Results display enables selection of two different categories to show on the screen.*

## Error LEDs

Errored LEDs are illuminated by specific errored events that show up in the Summary Category (see Figure 11 on page 23). Refer to Table 14 on page 184 for the first of several tables describing LED results.

Some summary items illuminate a red error LED on the front panel when they appear in Summary. The possible error LEDs are DS1, DS3, and SONET. An LED that is not illuminated indicates that the result does not cause the error LED to light when present in Summary (see Figure 7 on page 17).

## Recharging the battery

The 2310 comes equipped with a rechargeable Nickel-Metal Hydride (NiMH) battery. A fully-charged battery is good for about 1.5 hours of continuous use for electrical testing and 0.5 hours for optical testing. The recharge time is approximately 1.5 hours with the unit turned OFF. The recharge period begins as soon as an external AC or DC power supply is connected to the unit. Overcharge protection is provided, so continuous operation from an AC power supply is possible.

The Low Battery LED illuminates when the battery is at 25% of full charge to indicate the battery needs to be recharged.

To fully charge the battery quickly, turn the unit off, connect the AC adaptor from the power adaptor plug to a 120 VAC power supply and let the 2310 sit for about 1.25 hours. The battery can also be charged by using the optional car adapter.

## Battery replacement

The Nickel-Metal Hydride (NiMH) battery is easy to replace.

- 1 Turn off the 2310.
- 2 Tilt the unit onto the back panel. (The bottom panel faces you.)
- 3 Lift up the latch on the battery cover. Pull the battery out of the battery compartment. With newer 2000 UIMs, you will need to use a screwdriver to unscrew the battery cover latch.
- 4 Install the replacement battery by lining up the contacts and snapping it into place.
- 5 Secure the battery cover.
- 6 Turn on the 2310 and continue testing.

### **NOTE:**

*After 100 charge/discharge cycles, the battery performance may degrade.*

# Common Applications

This chapter includes task-based instructions using the 2310 options. Topics discussed in this chapter include the following:

- “Using the T1 option” on page 43
- “Using the Fractional T1 (FT1) option” on page 57
- “Using the DDS option” on page 67
- “Using the Signaling option” on page 77
- “Using the VF option” on page 91
- “Using the Intelligent Repeater Span option” on page 99
- “Using the DS3 option” on page 105
- “Using the STS-1 option” on page 113
- “Using the OC-3/OC-12/OC-48 option” on page 125
- “Using the VT100 Emulation option” on page 137
- “Using the OC-3c/12c ATM option” on page 141
- “Using the GR-303 option” on page 153
- “Using the ISDN PRI option” on page 161

These setup procedures are the most commonly used tests for the 2310. *As in any test, always configure the 2310 before connecting the test set to the circuit.*

## Using the T1 option

This option allows you to qualify T1 circuit error performance by testing for logic errors, BPVs, frame errors, and CRC errors (if applicable) on T1 lines.


### Monitoring T1 performance

This test allows you to monitor errors on a T1 circuit.

#### Configuring the 2310

To perform monitor T1 BER testing


- 1 On the menu bar, press **MON/THRU > Monitor T1 > T1 BERT**. The unit automatically configures to a default setup.






- 2 Press **Setup**. Ensure the characteristics shown in the Summary setup screen match the network characteristics (such as T1D4, etc.).

To change the settings, select the desired tabs in the property setup sheets.



- 3 Press **OK**. If monitoring a second signal, press one of the buttons labeled **T1 PRI** in the Results Group window and select **T1 Sec** from the pull-down menu. Set both Results Category buttons to **Summary**.



- 4 Verify the yellow active port LEDs next to the DS1 PRIMARY RX and SECONDARY RX jack are illuminated.

#### Connecting the 2310 to the circuit

To connect the 2310 to the circuit

- 1 Connect a cable from the PRIMARY RX jack to the DSX-1 A-Side MON jack.
- 2 Connect a cable from the SECONDARY RX jack to the DSX-1 Z-Side MON jack.

- 3 Press the **RESTART** permanent softkey to clear alarms and begin the test.



- 4 Verify the green SIGNAL and FRAME LEDs are illuminated and the Primary and Secondary Results Displays show Results OK.

### Connecting the 2310 to the circuit diagram

Figure 21 diagram is a sample depiction of cable connections from the DSX-1 panel to the inputs on the 2310 for T1 monitoring.




Figure 21 — T1 Monitor test setup


## T1 BERT Termination setup

This test allows you to test a T1 circuit for logic errors, BPVs, frame errors, and CRC errors (if applicable) on T1 lines.


### Configuring the 2310

To perform terminate T1 BER testing


- 1 On the menu bar, press **TERM > Terminate T1 > T1 BERT**. The unit automatically configures to a default setup.



- 2 Press **Setup**. The Summary property sheet displays. Ensure the characteristics shown in the Summary setup screen match the network characteristics (such as T1D4, etc.).



- 3 Press the RX Input tab and select TERM.



- 4 Press the **LBO** tab and select appropriate dB level.
- 5 Press the **Error Insert** tab and select **DS1 Logic**.
- 6 Press the **Timing** tab and select the appropriate timing.
- 7 Press **OK**.
- 8 Ensure Results Category is set to **Summary**.



- 9 Verify the yellow DS1 PRIMARY RX and TX active port LEDs are illuminated.

### Connecting the 2310 to the circuit

To connect the 2310 to the circuit

- 1 Connect a cable from the DS1 PRIMARY TX jack to the appropriate DSX-1 TX (IN) jack.
- 2 Connect a cable from the DS1 PRIMARY RX jack to the appropriate DSX-1 RX (OUT) jack.
- 3 Loop the Far-end DSX-1.

- 4 Press the **RESTART** permanent softkey to clear alarms and begin the test.



- 5 Verify the green PRI DS1 SIGNAL, FRAME, and PATTERN LEDs are illuminated, and the SUMMARY Results displays **Results OK**.
- 6 Press **DS1 Logic Error** five times. Verify five logic errors are received in the Results Display windows.

### Connecting the 2310 to the circuit diagram

Figure 22 is a sample depiction of cable connections from the DSX-1 panel to the inputs on the 2310 for T1 termination testing.




Figure 22 — T1 Termination test setup


## T1 Loopback BER Testing

This test allows you to qualify T1 circuit error performance by testing for logic errors, BPVs, frame errors, and CRC errors (if applicable) on T1 lines.

### Configuring the 2310


To perform terminate T1 Loopback BER testing

- 1 On the menu bar, press **TERM > Terminate T1 > T1 LOOP**, followed by the appropriate T1 loop code (such as **NIU**). The unit automatically configures to a default setup screen.



- 2 Press **Setup**. Ensure the characteristics shown in the Summary setup screen match the network characteristics (such as T1D4,


etc.). To change the settings, select the desired tabs in the property setup sheets.




- 3 Select the **Loop Code** tab. Select the appropriate Loop Code.

Depending upon your choice in the third pull-down menu during Setup, the Loop Code tab displays the possible selections which pertain to that menu selection. In this case, NIU was selected during the setup process.

- 4 Select the proper setting in the **Pattern** tab.



- 5 Press **OK**. Set the Results Category buttons to **Summary**.




- 6 Press the **RESTART** permanent softkey to clear alarms and begin connecting to the circuit.



### Connecting the 2310 to the circuit

To connect the 2310 to the circuit

- 1 Connect a cable from the DS1 PRIMARY TX jack to the appropriate DSX-1 TX (IN) jack.
- 2 Connect a cable from the PRIMARY RX jack to the appropriate DSX-1 RX (OUT) jack.
- 3 Press **Loop Up**. Verify the green SIGNAL, FRAME, and PATTERN LEDs are illuminated, and the SUMMARY Results displays Results OK.



Loop Up on the main screen enables you to send the appropriate Loop Code.

- 4 Send bit errors to verify the loop.



### Connecting the 2310 to the circuit diagram

Figure 23 diagram is a sample depiction of cable connections from the DSX-1 panel to the inputs on the 2310 for T1 Loopback BER testing.




Figure 23 — T1 Loopback test setup

### T1 Timing Slip Analysis


This test allows you to qualify T1 circuit timing slips by testing elapsed time since the test started, as well as the date and time, on T1 lines.

#### Configuring the 2310


To perform T1 timing slip analysis

- 1 On the menu bar, press **MON/THRU**. Select the appropriate signal to be tested. Then select the mapping for the DS1 within the signal (**VT1.5** or **DS3 Muxed** until **T1 BERT** is available).


- 2 Select **T1 BERT**. The unit automatically configures to a default setup.



- 3 Press **Setup**. The Summary property sheet displays.



- 4 Press **Rx Input**. For DS1, DS3, or STS-1 access, select the appropriate Rx Input level (DSX for DS3/STS-1 and DSX MON, BRIDGE, or TERM for DS1).
- 5 Press **Framing**. Select the T1 framing (D4, ESF, unframed) and the appropriate DS3 framing (M13/C-BIT).



- 6 Press **Channel**. Select the appropriate SONET, DS1, and VT 1.5 channel.
- 7 Press **OK**.
- 8 Verify the yellow DS1 SECONDARY RX/BITS and appropriate signal level RX active port LEDs are illuminated.


### Connecting the 2310 to the circuit

To connect the 2310 to the circuit

- 1 Connect a cable from the SECONDARY RX/BITS jack to the DS1 BITS Clock or a known good reference signal (see Figure 24).
- 2 Connect a cable from the DSX RX jack to the signal to be tested (see Figure 24).
- 3 Press the **RESTART** permanent softkey to clear alarms and begin the test.



- 4 Verify the appropriate green signal LEDs are illuminated for the tested signal (DS3 or SONET) and DS1.
- 5 To display timing calculations, press one of the Results Group buttons and select **T1 Pri**. Press the Results Category button and select **Signal > Timing Slips** as the result.



- 6 Verify test results in the Results display windows. If the signal is error free, Results OK displays in the Summary Category and/or 0 is displayed under the Timing Slip result.

### Connecting the 2310 to the circuit diagram

Figure 24 is a sample depiction of cable connections from the Master Clock to the inputs on the 2310 for DS1 Timing Slips testing.




Figure 24 — DS1 Timing Slips test setup

## Using the Fractional T1 (FT1) option

This option provides Fractional-T1 (FT1) modes for contiguous and non contiguous, 56KxN and 64KxN, channel formats. This option enables complete qualification and testing of new FT1 circuits before connecting customer premises equipment. The V.54 FT1 loop code is also added to the feature list and allows for single test set testing of FT1 circuits from a convenient T1 access point. These tests can:

- Test aggregate bandwidths on contiguous/non-contiguous channels in 56xN or 64xN format.
- Test Fractional T1 circuits bandwidths and measure the round trip path delay of any group of channels.
- Confirm that the Fractional T1 signal is properly received by the network equipment.


### FT1 Loopback BER testing

This test allows you to qualify T1 circuit error performance by testing for logic errors, BPVs, frame errors, and CRC errors (if applicable) on Fractional T1 lines.

#### Configuring the 2310

To perform terminate FT1 Loopback BER testing


- 1 On the menu bar, press **TERM > Terminate T1 > T1 LOOP > FT1 CSU**. The unit automatically configures to a default setup screen.



- 2 Press **Setup**. Ensure the characteristics shown in the Summary setup screen match the network characteristics (such as T1D4, etc.).


To change the settings, select the desired tabs in the property setup sheets.

- 3 Press the **Rx Input** tab and select **TERM**.




You can always change parameters via the setup property sheets. For this example, the Summary Rx Input is correct for FT1 CSU.

- 4 Press the **LBO** tab and select appropriate dB level.
- 5 Press the **Error Insert** tab and select DS1 LOGIC.
- 6 Press the **Timing** tab and select the appropriate timing selection for the T1 under test.
- 7 Press the **Channel** tab and select the appropriate FT1 channels and bandwidth (Nx56 or Nx64k).



- 8 Press **OK**.
- 9 Ensure Results Category is set to **Summary**.



- 10 Verify the yellow DS1 PRIMARY RX and TX active port LEDs are illuminated.


### Connecting the 2310 to the circuit

To connect the 2310 to the circuit

- 1 Connect a cable from the DS1 PRIMARY TX jack to the appropriate DSX-1 TX (IN) jack.
- 2 Connect a cable from the DS1 PRIMARY RX jack to the appropriate DSX-1 RX (OUT) jack. Verify T1 Frame SYNC.



- 3 Press the **Loop Up** action button.



- 4 Press the **RESTART** permanent softkey to clear alarms and begin the test.



- 5 Verify the green PRI DS1 SIGNAL, FRAME, and PATTERN LEDs are illuminated and the Primary and Secondary Results Displays show Results OK.
- 6 Send Bit Errors to verify loop.

### Connecting the 2310 to the circuit diagram

Figure 25 diagram is a sample depiction of cable connections from the DSX-1 panel to the inputs on the 2310 for T1 Loopback BER testing.





Figure 25 — FT1 Loopback test setup

### FT1 Drop and Insert testing


This test allows you to qualify FT1 circuit error performance by demultiplexing (dropping) at an intermediate point and entering (inserting) different information on the specific FT1 channels under test on the T1 circuit.

**Configuring the 2310** To perform FT1 drop and insert testing


- 1 On the menu bar, press **D&I > D&I Loop FT1 CSU**. The 2310 configures to a default setup.




- 2 Press **Setup**. Ensure the characteristics shown in the Summary property sheet match the network characteristics (such as T1D4, etc.). To change the settings, select the desired tabs in the property setup sheets.



- 3 Press the **Rx Input** tab and select MON (select BRIDGE if you are bridging on the circuit).
- 4 Press the **Error** tab and select DS1 LOGIC.
- 5 Press the **Timing** tab and select RECOVERED.
- 6 Press the **Channel** tab and select the appropriate FT1 channels and bandwidth (Nx56 or Nx64k).



- 7 Press **OK**.
- 8 Press one of the buttons labeled **T1 Pri** in the Results Group and select **T1 Sec** from the pull-down menu. Set both Results Category buttons to **Summary**.



- 9 Verify the yellow DS1 PRIMARY TX/RX active port LEDs and SECONDARY TX/RX LED are illuminated.

### Connecting the 2310 to the circuit

To connect the 2310 to the circuit

- 1 Connect a cable from the DS1 PRIMARY and SECONDARY RX jack to the appropriate DSX-1 MON jacks.

**NOTE:**

*The PRIMARY RX needs to be connected to the DSX-1 MON point facing the direction of the test (see Figure 26 on page 66).*

- 2 Check that the SIGNAL and FRAME SYNC LEDs illuminate, as well as the message **Results OK** displays before patching into the TX jacks.
- 3 Connect a cable from the PRIMARY TX jack to the appropriate DSX-1 A-Side (IN) jack. The PRIMARY TX must be cabled to the same side as the PRIMARY RX (see Figure 26 on page 66). Immediately insert a 100 ohm terminating plug into the Z-Side (OUT) jack, on the opposite side of the DSX.


**NOTE:**

*The PRIMARY TX should face the direction of the device under test.*

- 4 Connect a cable from the SECONDARY TX jack to the appropriate DSX-1, Z-Side (IN) jack (the SECONDARY TX must be cabled to the same side as the SECONDARY RX (see Figure 26 on page 66).
- 5 Immediately insert a 100 ohm terminating plug into the Z-Side jack, on the opposite side of the DSX.
- 6 Press **OK**.
- 7 Press the **RESTART** permanent softkey to clear alarms and begin the test.




- 8 Press the **Loop Up** action button.



- 9 Verify the green PRI DS1 SIGNAL, FRAME, and PATTERN LEDs are illuminated and the Primary and Secondary Results Displays show Results OK.
- 10 Press the **DS1 Logic Error** action button five times. Verify five logic errors are received in the Results Display windows.

**Connecting the 2310  
to the circuit diagram**

Figure 26 diagram is a sample depiction of cable connections from the DSX-1 panel to the inputs on the 2310 for FT1 Drop and Insert testing.



**Figure 26 — FT1 Drop and Insert setup**

## Using the DDS option


### DDS Loopback BER testing

This test allows you to test Digital Data System (DDS) circuits and generate alternating/latching DDS loop codes for sectionalizing and troubleshooting DDS circuits.

#### Configuring the 2310


To perform DDS Loopback BER testing (T1 Terminate test)

- 1 On the menu bar, press **TERM > Terminate T1 > T1 DDS**. The unit automatically configures to a default setup screen.







- 2 Press **Setup**. Ensure the characteristics shown in the Summary setup screen match the network characteristics (such as T1D4, etc.). To change the settings, select the desired tabs in the property setup sheets.




- 3 Press the **Rx Input** tab and select TERM.
- 4 Press the **Tx LBO** tab and select appropriate dB level.
- 5 Press the **Error** tab and select DS1 LOGIC and the appropriate Insertion Type.
- 6 Press the **Timing** tab and select the appropriate timing selection for the T1 under test.
- 7 Press the **Channel** tab and select appropriate DDS channel and bandwidth (DS0A56 or DS064).



- 8 Press the **Loop Code** tab and select appropriate DDS Loop Code. If the DS0-DP Loop Code is selected, press the DS0-DP button to select the desired DS0-DP Port address.



- 9 Press **OK**.
- 10 Ensure Results Category is set to **Summary**.



- 11 Verify the yellow DS1 PRIMARY RX and TX active port LEDs are illuminated.


### Connecting the 2310 to the circuit

To connect the 2310 to the circuit

- 1 Connect a cable from the DS1 PRIMARY RX jack to the appropriate DSX-1 RX (OUT) jack.
- 2 Connect a cable from the DS1 PRIMARY TX jack to the appropriate DSX-1 TX (IN) jack.

3 Verify SIGNAL and FRAME SYNC.

4 Press the **Loop Up** action button.



5 Press the **RESTART** permanent softkey to clear alarms and begin the test.



6 Verify the green PRI DS1 SIGNAL, FRAME, and PATTERN LEDs are illuminated and the Primary Summary Results displays Results OK.

7 Send Bit Errors to verify loop.

### Connecting the 2310 to the circuit diagram

Figure 27 diagram is a sample depiction of cable connections from the DSX-1 panel to the inputs on the 2310 for DDS Loopback BER testing.




Figure 27 — DDS Loopback BER test setup


## DDS Drop and Insert Testing

This tests allow you to test DDS circuits from a T1 access point and generate alternating/latching DDS loop codes without removing the other T1 channels from service.

### Configuring the T-BERD 2310


To perform DDS Drop and Insert testing

- 1 On the menu bar, press **D&I > D&I T1 DDS**. The 2310 configures to a default setup.




- 2 Press Setup. Ensure the characteristics shown in the Summary property sheet match the network characteristics (such as T1D4).

To change the settings, select the desired tabs in the property setup sheets.




- 3 Press the **Rx Input** tab and select the appropriate Rx input, MON or BRIDGE.
- 4 Press the **Error** tab and select DS1 LOGIC.
- 5 Press the **Channel** tab and select the appropriate DDS channels and rate (DS0A56 or DS064).




- 6 Press OK.

- 7 Press the **Loop Code** tab and select the appropriate DDS piece of equipment to be looped. If DS0-DP is selected, press the **DS0-DP** button to select the DS0-DP address.



- 8 Press **OK**.
- 9 Press **T1 Pri** in the Results Category window. Set the left Results Category button to **Summary** and right to **Channel**.



- 10 Verify the yellow DS1 PRIMARY TX/RX active port LEDs and SECONDARY TX/RX LED are illuminated.

### Connecting the 2310 to the circuit

To connect the 2310 to the circuit

- 1 Connect a cable from the DS1 PRIMARY and SECONDARY RX jack to the appropriate DSX-1 MON jacks.

### NOTE:

The PRIMARY RX must be in the DSX facing the direction of the device under test.

- 2 Check for good SIGNAL and FRAME SYNC before transmitting into the circuit.
- 3 Connect a cable from the PRIMARY TX jack to the appropriate DSX-1 A-Side (IN) jack, which is the same side of the DSX as the PRIMARY RX (see Figure 28 on page 76).
- 4 Immediately insert a 100 ohm terminating plug into the Z-Side (OUT) jack on the opposite side of the DSX.

**NOTE:**


*Never insert the terminating plug first and the PRIMARY TX should face the direction of the device under test.*

- 5 Connect a cable from the SECONDARY TX jack to the appropriate DSX-1 Z-Side (IN) jack on the same side of the DSX-1 as the SECONDARY RX (see Figure 28 on page 76).
- 6 Immediately insert a 100 ohm terminating plug into the Z-Side jack, which is the OUT Jack on the opposite side of the DSX. *Never insert the terminating plug first.*
- 7 Press the **RESTART** permanent softkey to clear alarms and begin the test.



Check for SINGAL and FRAME SYNC before proceeding to the next step.

- 8 Press **Insert Primary > Loop Up**.



- 9 Verify the green PRI DS1 SIGNAL, FRAME, and PATTERN LEDs are illuminated and the Primary and Secondary Results Displays show Results OK.
- 10 Press **DS1 Logic Error** five times. Verify five logic errors are received in the Results Display windows.



### Connecting the 2310 to the circuit diagram

Figure 28 diagram is a sample depiction of cable connections from the DSX-1 panel to the inputs on the 2310 for DDS Drop and Insert testing.




Figure 28 — DDS Drop and Insert setup

## Using the Signaling option

This option enables you to test the ability of a switch/PBX to handle incoming calls and allows you to emulate switch-to-switch communications. You can place, receive and monitor calls over several trunk types. Features include: Send/Receive DP, DTMF, and MF digits to/from switches and PBXs. You can also measure inter-digit delay and digit/tone duration.


### Monitoring A/B/C/D signaling bits

This tests allow you to view the signaling bits for all of the 24 channels for both the Primary and Secondary lines, simultaneously.


### Configuring the 2310

To perform monitoring signal bits testing


- 1 On the menu bar, press **Mon/Thru > Monitor T1 > T1 VF**. The unit automatically configures to a default setup screen.



- 2 Press **Setup**. Ensure the characteristics shown in the Summary setup screen match the network characteristics (such as T1D4). To change settings, select the desired property sheet tabs in the property setup sheets.



- 3 Exit the configuration setup screen by pressing **OK**.
- 4 Set Result Group buttons to **T1 Pri** (left) and **T1 Sec** (right).



- 5 Set Result Category buttons to **Traffic**.

### Connecting the 2310 to the circuit

To connect the 2310 to the circuit

- 1 Connect two cables, one from the PRIMARY RX jack, and the other from the SECONDARY RX jack to the DSX-1 MON access point.
- 2 Press the **RESTART** permanent softkey to clear alarms and begin the test.



- 3 Verify the SIGNAL and FRAME LEDs are illuminated. Observe all 24 channels for Primary and Secondary.

## Signaling Monitor (Call Capture)


This test allows you to perform Call Capture.

### Configuring the 2310

To perform Call Capture testing


- 1 On the menu bar, press **MON > Monitor T1 > Monitor Call**. The unit automatically configures to a default setup screen.

Selecting choices from the menu bar always gives you a default setup screen.




- 2 Press **Setup**. Ensure the characteristics shown in the Summary property setup screen match the network characteristics. To

change the settings, select the desired tabs in the property setup sheets.




- 3 Press the **Trunk** tab and select the appropriate trunk type (e.g., Loop Start, Ground Start, or E&M).
- 4 Select the type of circuit equipment (e.g., SLC office, SLC station, FXO, or FXS) of the source of the call. Select the side from which the call is originating using the **Call Source** button.

- 5 Select the **Channel** tab and select the DS0 that you want to monitor. Press **OK**.



- 6 Set both Result Group buttons to **Primary**.

- 7 Set Result Category buttons to **Call Sig** on the left and **Traffic** on the right.



### Connecting the 2310 to the circuit

To connect the 2310 to the circuit

- 1 Connect two cables, one from the PRIMARY T1 interface, and the other from the SECONDARY T1 interface to the DS1 test access point (DSX-1 patch panel).
- 2 Press the **RESTART** permanent softkey to clear alarms and begin the test.



- 3 Verify the SIGNAL and FRAME LEDs are illuminated (green).
- 4 Observe the signaling activities in the results display.


## PBX/Switch Emulation (originating a call)

This test allows you to originate a call while terminating the T1 circuit.

### Configuring the 2310


To perform PBX/Switch Emulation to originate a call

- 1 On the menu bar, press **TERM > Terminate T1 > Place Call**. The unit automatically configures to a default setup screen.



- 2 Press **Setup**. Ensure characteristics shown in the setup Summary screen match the network characteristics. To change settings, select the desired property sheet tabs in the property setup sheets.
- 3 Select the **Channel** tab in property sheet to choose the T1 channel (DS0) on which to transmit the call.
- 4 Select the appropriate trunk type (e.g., Standard E&M, Loop Start, or Ground Start) using the **Trunk** tab. If Loop Start or Ground Start is selected, choose FX or SLC as circuit type. Select the Tone (MF, DP, or DTMF) from the Trunk property sheet.






- 5 Press **OK**.

### Connecting the 2310 to the circuit

To connect the 2310 to the circuit

- 1 Connect a cable from the PRIMARY RX jack to the OUT jack of the DSX-1. Connect a cable from the PRIMARY TX jack to the IN jack of the DSX-1.
- 2 Press the **RESTART** permanent softkey to clear alarms. Verify the **SIGNAL** and **FRAME** LEDs are illuminated (green).
  - a Select **Call Sig Results** Category.
  - b Verify that **On Hook** is observed in the **Call Sig Results** Category.
  - c Press **Off Hook**. Verify that **Off Hook** appears in the Results display, followed by either a **WINK** (on standard E&M trunks) or **Dial Tone** (on Loop and Ground Start trunks).
  - d Press **Enter Dial** to display the signaling keypad.



| MF  |      |      |
|-----|------|------|
| 1   | 2    | 3    |
| 4   | 5    | 6    |
| 7   | 8    | 9    |
| kp  | 0    | st   |
| stp | st2p | st3p |

You can also dial on the MF keypad, if chosen on the Trunk tab.

- 3 Dial the test number on the numeric keypad. Press **Push 2 Talk** or use the handset when you want to talk into the 2310 (keep button pressed while talking).
- 4 Press **On Hook** to complete the call.
- 5 Press **DS0# X/X** to select another DS0 channel to test.


### PBX/Switch Emulation (terminating a call)

The following test enables the 2310 to terminate a call while terminating the T1 under test.


#### Configuring the 2310

To perform PBX/Switch Emulation to terminate a call

- 1 On the menu bar, press **TERM > Terminate T1 > Receive Call**. The unit automatically configures to a default setup screen.
- 2 Press **Setup**. Ensure characteristics shown in the setup Summary screen match the network characteristics. To change settings, select the desired property sheet tabs in the property setup sheets.



- 3 Select the **Channel** tab in property sheet to choose the T1 channel (DS0) on which to receive the call.
- 4 Select the appropriate trunk type (e.g., Standard, Loop Start, or Ground Start) using the **Trunk** tab. If Loop Start or Ground Start is selected, choose FX or SLC as circuit type. Press **OK**.




To connect the 2310 to the circuit

- 1 Connect a cable from the PRIMARY TX jack to the IN jack of the DSX-1. Connect a cable from the PRIMARY RX jack to the OUT jack of the DSX-1.
- 2 Press the **RESTART** permanent softkey to clear alarms. Verify the SIGNAL and FRAME LEDs are illuminated (green).
- 3 Select the **Call Sig** Results Category button beside the Primary Results Group selection. Verify that **On Hook** is observed in the **Call Sig** Results Category display.
- 4 Press the **Off Hook** action button to initiate a call and then **Push 2 Talk** to establish voice connection.
- 5 Observe call sequence events as the call is established.


The following test enables Drop and Insert testing when placing a call.

To perform Drop and Insert to place a call

- 1 On the menu bar, press **D&I > D&I Place Call**. The 2310 configures to a default setup.



- 2 Press **Setup**. Ensure the characteristics shown in the Summary setup screen match the network characteristics.
- 3 To change baseline settings, select the desired property sheet tabs in the property setup sheets. Set the **Framing**, **Code**, **Rx Input**, and **Channel** tabs to appropriate settings.
- 4 Select the **Trunk** tab. Select the appropriate trunk type (standard E&M, Loop Start, Ground Start). If Loop Start or Ground Start is selected, choose FXS or SLC as the type of card emulation. Remember to also select the appropriate digit type (MF, DP, or DTMF). Press **OK**.



**Connecting the 2310  
to the circuit**

To connect the 2310 to the circuit

- 1 Connect a cable from the PRIMARY RX jack to the appropriate DSX-1 A-Side MON jack (see Figure 29). The PRIMARY RX must be in the DSX jack facing the direction of the device under test.
- 2 Connect a cable from the SECONDARY RX jack to the appropriate DSX-1 Z-side MON jack (see Figure 29).
- 3 Check for FRAME and SIGNAL SYNC.
- 4 Simultaneously, connect a cable from the Primary TX jack to the appropriate DSX-1 A-side (IN) jack while inserting a 100 ohm terminating plug into the DSX-1 Z-side (OUT) jack. This connection should be on the same side of the DSX as the PRIMARY RX (see Figure 29).

**NOTE:**

Never insert the terminating plug first.





Figure 29 — Drop and Insert test setup

- 5 Press the **RESTART** permanent softkey to clear alarms.
- 6 Verify the Primary and Secondary **SIGNAL** and **FRAME** LEDs are illuminated and the Primary and Secondary Results display shows **Results Ok** (under **Summary** Category).
- 7 Press **Insert Primary > Enter Dial** to bring up the numerical keypad.
- 8 Select **Call Sig** in left Results Category and **Traffic** in right Results Category. Verify that **ON Hook** is observed in the **Call Sig** Results Category.



Action buttons enable variances in testing.

- 9 Press **Off Hook**. Verify that **Off Hook** appears in the Results display, followed by either a WINK (on standard E&M trunks) or dial tone (on Loop and Ground Start trunks).
- 10 Press **Push 2 Talk** and speak into the microphone to establish a voice path.
- 11 Dial the test number on the numeric keypad.
- 12 Press **ON Hook** to complete the call.
- 13 Press **DS0# X/X** to select another DS0 channel to test.
- 14 Repeat procedures from Step 11 to continue testing remaining DS0 channels.
- 15 Disconnect from the circuit in the reverse order to prevent service disruption.

## Using the VF option

The following procedure outlines how to use the 2310 to monitor DS0 (VF) channels out of a DS1 signal. These tests allow you to

- Qualify voice-grade VF circuits by measuring Signal-to-Noise ratio (S/N), C-Message, and C-Notch.
- Qualify data-grade VF circuits with the 3 kHz Flat, and 3 kHz Notch filters.
- Perform automated frequency sweeps.


### VF Channel Drop/ Monitoring from DS1

The following test enables you to drop and monitor voice frequency channels from a DS1 signal.




**Configuring the 2310** To drop and monitor DS0 (VF) Channels out of a DS1 signal

- 1 On the menu bar, press **MON/THRU > Monitor T1 > T1 VF**. The unit automatically configures to a default setup.




- 2 Press **Setup**. Ensure the characteristics shown in the Summary setup screen match the network characteristics (such as AMI), as well as the desired VF/DS0 channel. To change the settings, select the desired tabs in the property setup sheets.



- 3 Press **OK**.

- 4 If monitoring a second line, press one of the buttons labeled **T1 PRI** in the Results Group window and select **T1 Sec** from the pull-down menu. Set both Results Category buttons to **Channel**.

Category buttons



- 5 Verify the yellow active port LEDs next to the DS1 PRIMARY RX and SECONDARY RX jacks are illuminated.

### Connecting the 2310 to the circuit

To connect the 2310 to the circuit

- 1 Connect a cable from the PRIMARY and SECONDARY DS1 RX jack to the appropriate DSX monitor point.
- 2 Press the **RESTART** permanent softkey to clear alarms and begin the test.



- 3 Verify the green SIGNAL and FRAME LEDs are illuminated and the Primary and Secondary Results displays show **Results OK**.
- 4 Press **DS0# X/X** to change the channel that is dropped to the speaker if you want to test another channel.
- 5 To adjust the volume level, press the File Cabinet permanent softkey and select the Speaker tab.



### Connecting the 2310 to the circuit diagram

Figure 30 depicts a diagram sample depiction of cable connections from the DSX-1 panel to the inputs on the 2310 for a DS0 (VF) Drop/Monitor test.




Figure 30 — DS0 (VF) Drop/Monitor test setup


## Transmitting VF Tones

The following test enables you to transmit voice frequency tones on a DS1 signal, while terminating the T1 circuit.


### Configuring the 2310

To transmit DS0 (VF) Channels on a DS1 signal

- 1 On the menu bar, press **TERM** > **Terminate T1** > **T1 VF**. The unit automatically configures to a default setup.




- 2 Press **Setup**. From the Summary window, select the **RX Input** tab and select **TERM**.



- 3 Press the **Tx LBO** tab and select the appropriate dB level.

- 4 Press the **Channel** tab and select the appropriate channel to transmit tone.
- 5 Press the **VF** tab and select tone to be transmitted.
- 6 Press the **Timing** tab and set timing to the appropriate setting for the T1 circuit under test.



- 7 Press the **Summary** tab. Ensure DS1 Framing and TX Line Code settings are correct.
- 8 Press **OK**.
- 9 Verify that the yellow DS1 PRIMARY TX and RX active port LEDs are illuminated.

**Connecting the 2310  
to the circuit**

To connect the 2310 to the circuit

- 1 Connect a cable from the DS1 PRIMARY RX jack to the appropriate DSX-1 RX (OUT) jack.
- 2 Connect a cable from the DS1 PRIMARY TX jack to the appropriate DSX-1 TX (IN) jack.
- 3 Loop the end of the network to be tested.
- 4 Press the **RESTART** permanent softkey to clear alarms and begin the test.



- 5 Verify the green PRI DS1 SIGNAL, and FRAME LEDs are illuminated.

If the Primary DS1 signal is free of errors, the Summary Results displays *Results Ok*.

- 6 To view VF measurements, select the channel Results Category.
- 7 Press **DS0# X/X** to change the channel that is dropped to the speaker if you want to test another channel.
- 8 To adjust the volume level, press the File Cabinet permanent softkey and select the Speaker tab.



### Connecting the 2310 to the circuit diagram

Figure 31 is a sample depiction of cable connections from the DSX-1 panel to the inputs on the 2310 for VF Tone Insertion testing.




Figure 31 — VF Tone Insertion test setup

## **Using the Intelligent Repeater Span option**

The following test application provides an example of how you can sectionalize addressable repeater spans by transmitting appropriate pre-programmed loop codes from the central office (CO).

The Intelligent Repeater Span option provides the intelligent span equipment loop codes used to loop up and loop down individual, addressable, office repeaters and line repeaters, or to transmit maintenance switch commands.

The following devices can be armed, disarmed, queried, and looped back when the TB2310-ILE option is installed.

- Teltrend Model 7231LP IOR/ 7239LP ILR Intelligent Repeaters
- Teltrend Model 9132LP IHR Intelligent Repeater
- Teltrend Model 7231LW IOR / 7239LW ILR Intelligent Repeaters
- Teltrend Model 9132LW IHR Intelligent Repeater
- Westell 3130-80 IOR Intelligent Repeater
- Westell 3150-80 ILR Intelligent Repeater
- Westell 3150-81 ILR Intelligent Repeater
- Westell 3150-56 ILR Intelligent Repeater
- Westell 3151-56 ILR Intelligent Repeater
- Westell 3130-56 IOR Intelligent Repeater
- XEL 7853-200 ILR Intelligent Repeater
- Westell 3171 T1 Network Interface and Maintenance System (60 Series)


This test allows you to qualify T1 circuit error performance by testing for logic errors, BPVs, and frame errors (if applicable) on T1 spans.



**Configuring the 2310**

To transmit pre-programmed loop codes on addressable repeater spans from the CO.

- 1 On the menu bar, press **TERM > Terminate T1 > T1 Loop > Repeater**. The unit automatically configures to a default setup screen.




- 2 Press **Setup**. Ensure the characteristics shown in the Summary setup screen match the network characteristics. To change settings, select the desired tabs in the property setup sheets.

**NOTE:**


Make sure you select the *Receive Input* tab and select *TERM* for each receiver for this test.

- 3 Select the proper setting in the **Framing** tab (AUTO, T1, T1D4, T1 ESF, or T1 SLC96).
- 4 Select the proper setting in the **Pattern** tab.



- 5 Set **Tx Coding** as appropriate (B8ZS or AMI).
- 6 Set **Timing** to INTERNAL if emulating central office equipment. Set **Timing** to RECOVERED (loop) if emulating customer premises equipment.
- 7 Set **Tx LBO** to appropriate value (typically 0 dB).
- 8 Set **Rx Input** to TERM.
- 9 Set **Error** to DS1 LOGIC.
- 10 Set **Insertion Type** to SINGLE.

- 11 Set **Repeater Commands** to the desired Repeater Model and Repeater Command.




- 12 Press OK.

### **Connecting the 2310 to the circuit**

To connect the 2310 to the circuit

- 1 Connect a cable from the PRIMARY TX jack to the appropriate DSX-1 IN jack.
- 2 Connect a cable from the PRIMARY RX jack to the appropriate DSX-1 OUT jack.
- 3 Press Arm.



Pressing Arm equips the T1 Span.

- 4 Press **Loop Up**.
- 5 Press the **RESTART** permanent softkey to clear alarms and begin the test.



- 6 Verify the Primary SIGNAL, FRAME, and PATTERN LEDs are illuminated and the Primary Results display shows Results OK.
- 7 Insert one or two errors by pressing **Start DS1 Logic Error** action button to verify connectivity.

### Connecting the 2310 to the circuit diagram

Figure 32 depicts a diagram sample depiction of cable connections from the DSX-1 panel to the inputs on the 2310 for an intelligent repeater loop code test.




Figure 32 — Intelligent Repeater loop code test setup



## Using the DS3 option

This option adds DS3 testing to the already extensive DS1/DS0 testing capabilities of the 2310. Without adding any size to the existing test set, this option lets you qualify DS3 circuits with BERT patterns for both M13 and C-bit framing, insert patterns on one or all DS3 channels, drop DS1 and DS0 channels from DS3 signals to test and monitor, and verify frame synchronization on DS3 lines.

### Monitoring DS3 performance


The following test enables you to monitor DS3 signals.

#### Configuring the 2310

To monitor the DS3 signal


- 1 On the menu bar, press **MON/THRU > Monitor DS3 > DS3 BERT**. The unit automatically configures to a default setup for the chosen application.

Initial setup screen for DS3 Monitor testing. You can press Setup to change configurations.



- 2 Press **Setup**. Ensure the characteristics shown in the Summary setup screen match the network characteristics.


- 3 To change these default settings, select the desired tabs in the property setup sheets.



- 4 Press **OK**.
- 5 If monitoring a second signal, press one of the buttons labeled **DS3 PRI** in the Results Group window and select **DS3 Sec**. Set both Category buttons to **Summary**.

**NOTE:**

The Dual RX option must be present to use the Secondary DS3 receiver.



- 6 Verify the yellow active port LEDs next to the DS3 PRIMARY RX and SECONDARY RX jacks are illuminated.

### Connecting the 2310 to the circuit

To configure the circuit

- 1 Connect a cable from the DS3 PRIMARY RX jack to the DSX-3 A-SIDE MON jack.
- 2 Connect a cable from the DS3 SECONDARY RX jack to the DSX-3 Z-SIDE MON jack.
- 3 Press the **RESTART** permanent softkey to clear alarms and begin the test.



- 4 Verify the green SIGNAL and FRAME LEDs are illuminated and the Primary and Secondary Results displays show Results Ok.

### Connecting the 2310 to the circuit diagram

Figure 33 depicts a diagram sample depiction of cable connections from the DSX-3 panel to the inputs on the 2310.




Figure 33 — DS3 Monitor test setup




## DS3 BER testing

This test lets you qualify DS3 circuits with BERT patterns for both M13 and C-bit framing, insert patterns on one or all DS3 channels, drop DS1 and DS0 channels from DS3 signals to test and monitor, and verify frame synchronization on DS3 lines.

### Configuring the 2310


To perform DS3 BER testing

- 1 On the menu bar, press **TERM > Terminate DS3 > DS3 BERT**. The unit automatically configures to a default setup.




- 2 Press **Setup**. The Summary property sheet displays.
- 3 Press the **Tx LBO** tab and select the appropriate level. (DSX-450 ft. if accessing from DSX-3)
- 4 Press the **Rx Input** tab and select the appropriate receiver input (DSX-450 ft. if accessing from DSX-3).

- 5 Press the **Timing** tab and select the appropriate timing for the DS3 circuit under test.
- 6 Press the **Error** tab and select DS3 LOGIC.



- 7 Press the **Summary** tab. Ensure the characteristics shown in the setup screen match the network characteristics and test to be performed.
- 8 Press **OK**.
- 9 Set the Results Category button to **Summary**.

Category buttons



- 10 Verify the yellow DS3 PRIMARY RX and TX active port LEDs are illuminated.

**Connecting the 2310  
to the circuit**

To connect the 2310 to the circuit

- 1 Connect a cable from the DS3 PRIMARY RX jack to the appropriate side of the DSX-3 RX (OUT) jack.
- 2 Connect a cable from the DS3 PRIMARY TX jack to the appropriate DSX-3 TX (IN) jack.
- 3 Loop back the far-end DSX-3 (either manually or by using the DS3 FEAC loop code).
- 4 Press **RESTART** to clear alarms and begin the test.



- 5 Verify the green PRI DS3 SIGNAL, FRAME, and PATTERN LEDs are illuminated and the SUMMARY Results displays **Results Ok**.
- 6 Press the **Logic Error Insert** action button five times. Ensure five logic errors are received in the Results Summary.

### Connecting the 2310 to the circuit diagram

Figure 34 is a sample depiction of cable connections from the DSX-3 panel to the inputs on the 2310 for DS3 Termination testing.




Figure 34 — DS3 Termination test setup



## Using the STS-1 option

The STS-1 option provides SONET receive and transmit signal and payload insert error and alarm capabilities at the Synchronous Transport Signal - Level 1 (STS-1) Rate.


### Monitoring STS-1 performance

The following test enables you to monitor STS-1 signals for framing, path pointer adjustments, and BPVs.


#### Configuring the 2310

To receive STS-1 signals


- 1 On the menu bar, press **MON/THRU > Monitor STS-1** and the appropriate payload mapping (in this case, **DS3 Drop** was chosen). The unit automatically configures to a default setup for the chosen application.



- 2 Press **Setup**. Ensure the characteristics shown in the Summary setup screen match the network characteristics.




- 3 To change these default settings, select the desired tabs in the property setup sheets. Note the differences between the baseline DS3 setup property sheets and the baseline STS-1 setup property sheets.



Property setup tabs for STS-1 Monitor Testing. You can press any tab to change configurations.

- 4 Press **OK**.
- 5 If monitoring a second signal, press one of the buttons labeled **SONET Pri** in the Results Group window and select **SONET Sec**. Set both Category buttons to **Summary**.

**NOTE:**

*The Dual RX option must be present to use the Secondary STS-1 receiver.*

- 6 Verify the yellow active port LEDs next to the STS-1 PRIMARY RX and SECONDARY RX jacks are illuminated.

### Connecting the 2310 to the circuit

To connect the 2310 to the circuit

- 1 Connect a cable from the STS-1 PRIMARY RX jack to the STS-1 PRIMARY MON jack.
- 2 Connect a cable from the STS-1 SECONDARY RX jack to the STS-1 SECONDARY MON jack.
- 3 Press the **RESTART** permanent softkey to clear alarms and begin the test.




- 4 Verify the green SIGNAL, FRAME, PATTERN, and PATH PTR LEDs are illuminated and the Primary and Secondary Results displays show Results Ok.



### Connecting the 2310 to the circuit diagram

Figure 35 depicts a diagram sample depiction of cable connections from the DSX-3 panel to the inputs on the 2310.



**Figure 35 — STS-1 Monitor test setup**


**STS-1 BER testing**

The following test enables the 2310 to perform STS-1 BER tests with a DS3 or VT1.5 muxed payload.


**Configuring the 2310**

To transmit the DS3 signal on an STS-1 rate


- 1 On the menu bar, press **TERM > Terminate STS-1** and the appropriate payload mapping (in this case, **Muxed DS3** and **T1 BERT** were chosen). The unit automatically configures to a default setup for the chosen application.



- 2 Press **Setup**. Ensure the characteristics shown in the Summary setup screen match the network characteristics.



- 3 To change these default settings, select the desired tabs in the property setup sheets.
- 4 Press **OK**.
- 5 Set one Results Group to **SONET Pri** and the other to **T1 PRI**, and set the Category buttons to **Summary**.



- 6 Verify the yellow active port LEDs next to the STS-1 PRIMARY TX and RX jacks are illuminated.

### Connecting the 2310 to the circuit

To connect the 2310 to the circuit

- 1 Connect a cable from the STS-1 PRIMARY RX jack to the DSX OUT jack.
- 2 Connect a cable from the STS-1 PRIMARY TX jack to the DSX IN jack.
- 3 Establish a far-end loop.

- 4 Press the **RESTART** permanent softkey to clear alarms and begin the test.



- 5 Verify the green **SIGNAL**, **FRAME**, and **PATTERN** for T1 and SONET signals (and **PATH PTR** LEDs for SONET only) are illuminated, and the **Primary** and **Secondary Results** displays show **Results Ok**.

### Connecting the 2310 to the circuit diagram

Figure 36 depicts a diagram sample depiction of cable connections from the STS-1 panel to the inputs on the 2310.




Figure 36 — STS-1 BER test setup


## VT1.5 Drop/ Monitoring from STS-1

The following procedure outlines how to setup the 2310 to monitor VT1.5 or DS1 signals dropped from an STS-1 signal.


### Configuring the 2310

To receive VT1.5 or DS1 signals dropped from an STS-1 rate

- 1 On the menu bar, press **MON/THRU > Monitor STS-1 (or OC-3/OC-12/OC-48) > VT1.5 Drop > T1 BERT**. The unit automatically configures to a default setup for the chosen application.




- 2 Press **Setup**. Ensure the characteristics shown in the Summary setup screen match the network characteristics.
- 3 To change these baseline settings, select the desired tabs in the property setup sheets.



Property setup tabs for VT 1.5 from an STS-1 Monitor testing. You can press any tab to change configurations.

- 4 Press **OK**.
- 5 Press the **SONET Pri** button in one Results Group and the **T1 Pri** button in the second Results Group.
- 6 Set both Results Category buttons to **Summary**.



- 7 Verify the yellow active port LEDs next to the DS3/STS-1 PRIMARY RX and SECONDARY RX jacks are illuminated.

#### Connecting the 2310 to the circuit

To connect the 2310 to the circuit


- 1 Connect a cable from the DS3/STS-1 PRIMARY and SECONDARY RX jack to the Primary and/or Secondary side of the DSX-3/STX-1 MON jack.
- 2 Press the **RESTART** permanent softkey to clear alarms and begin the test.



- 3 Verify the green SIGNAL, FRAME, PATTERN, and PATH PTR LEDs are illuminated and the Primary and Secondary Results displays show Results Ok.

**Connecting the 2310 to the circuit diagram**

Figure 37 depicts a diagram sample depiction of cable connections from the DSX-3/STS-1 panel to the inputs on the 2310 for a DS1/VT1.5 Drop/Monitor test.



**Figure 37 — STS-1/VT 1.5 Drop/Monitor test setup**






## Using the OC-3/OC-12/OC-48 option

The OC-3/OC-12/OC-48 option enables transmitting or receiving SONET signals from optical carriers, as well as, concatenated Optical Carrier- Levels OC-3/12/OC-48 signals. It can analyze signal overhead and drop/insert DS3 or DS1 payloads.

Cautions must be observed before and during all phases of instrument operation. The following symbol designates that the 2310 is a Class 1 Laser product and you must be careful not to incur hazardous laser light exposure. This symbol carries the following warning:



### **WARNING: HAZARDOUS LASER LIGHT EXPOSURE!**

*Do not look directly into the 2310 optical output. The optical source is designed for safe Class I operation. However, it is recommended that you not look directly into the optical output of the unit or at the output of any optical cable connected to the unit. If a fiber optic connection is removed from a transmitting connector, screw the safety cap onto the connector to prevent inadvertent exposure to the laser output. Use of controls, adjustments or procedures other than those specified herein may result in hazardous laser light exposure.*

## Monitoring OC-3/ OC-12/OC-48 performance


The following procedure outlines how to setup the 2310 to monitor and perform error/alarm insertion using the Thru mode.

### Configuring the 2310


To monitor an OC-3/OC-12/OC-48 rate

- 1 On the menu bar, press **MON/THRU > Monitor OC-3/OC-12/OC-48 > OC-3c/OC-12c/OC-48c BERT**. The unit automatically configures to a default setup screen.



OC-3c BERT is similar to the OC-12c/48c menu with the exception that you cannot test OC-12c from the OC-3 menu. In the same manner, you cannot test OC-48c from the OC-12 menu.





- 2 Press **Setup**. The Summary property sheet displays.



- Press the **Summary** property sheet tab. Ensure the settings shown in the Summary tab match the network characteristics and the test to be performed. Press **OK**.
- Set parameters for **Pattern**, **Error**, **Alarm**, and **TX Wavelength** tabs.



Property sheets are the same for OC-3c/12c/48c with respect to setting parameters for your tests.



The dual wavelength property sheet is only applicable with an OC-48 equipped module.

- 5 Verify the yellow active port LEDs next to the OC-3/OC-12/OC-48 jacks are illuminated.

**Connecting the 2310  
to the circuit**

To connect the 2310 to the circuit


- 1 Connect a fiber cable from the OC-3/OC-12/OC-48 RX jack to the network's RECEIVE optical splitter access jack.
- 2 Press the **RESTART** permanent softkey to clear alarms and begin the test.



- 3 Verify the green SONET SIGNAL, FRAME, and PATH PTR LEDs are illuminated (green) and the Results Window displays `Results OK`.
- 4 Press the **RESTART** permanent softkey to clear old test results and start a new test.
- 5 Verify test results in the Results display windows. If the signal is error free, `Results OK` displays.

**Connecting the 2310  
to the circuit diagram**

Figure 38 is a sample depiction of cable connections from the OC-3c/12c/48c panel to the inputs on the 2310 for OC-3/OC-12/OC-48 for in-service monitoring and error/alarm insert testing.



**Figure 38** — MON/THRU Mode Error/Alarm Insert test setup

## OC-3/OC-12/OC-48 BER testing

The following procedure outlines how to setup the 2310 to terminate a SONET signal for BER testing and perform Error/Alarm Insertion on concatenated SONET signals.




### **WARNING: DAMAGE TO TEST PAD**

*Never loop the high-power TRANSMIT on OC-48 modules to the RECEIVE of the 2310. It will result in serious damage to the 2310.*

### **Configuring the 2310**

To test an OC-3/OC-12/OC-48 rate for BER testing

- 1 On the menu bar, press **TERM > Terminate OC-3/OC-12/OC-48 > OC-3c/OC-12c/OC-48c BERT**. The unit automatically configures to a default setup.



- 2 Press **Setup**. The Summary property sheet displays.

Terminate DS3 BERT in OC-3

| Alarm   | Pointer | Channel | Beep   | Path Trace |
|---------|---------|---------|--------|------------|
| Summary | Framing | Pattern | Timing | Rx Input   |
| Error   |         |         |        |            |

**SONET Setup Summary**

|  |                |                    |
|--|----------------|--------------------|
| Type                                   | SONET Channel: | (STS-1) Tx/Rx: 1/1 |
| <input checked="" type="radio"/> SONET | Timing:        | INTERNAL           |
| <input type="radio"/> DS3              | Path Pointer:  | +1 INC             |
| <input type="radio"/> T1               | Alarm Insert:  | PATH AIS           |
|  | Error Insert:  | FRAME WORD         |

- 3 Press the **Timing** tab. If an external timing source is used, select EXTERNAL T1 BITS. If the timing is received from the network, select RECOVERED. If the 2310 is the timing source, select INTERNAL.
- 4 Press the **Error** tab. Select SONET LOGIC.

Terminate DS3 BERT in OC-3

| Alarm   | Pointer | Channel | Beep   | Path Trace |
|---------|---------|---------|--------|------------|
| Summary | Framing | Pattern | Timing | Rx Input   |
| Error   |         |         |        |            |

**SONET**

☒ INTERNAL

☐ RECOVERED (loop)

☐ EXTERNAL T1 BITS

**DS3**

☒ INTERNAL

OK Cancel

Terminate OC-3c BERT

| Pointer  | Beep    | Path Trace |
|----------|---------|------------|
| Summary  | Pattern | Timing     |
| Rx Input | Error   | Alarm      |

**Error Type**

☐ FRAME WORD

☐ SECTION BIP

☐ LINE BIP

☐ PATH BIP

☐ LINE FEBE

☐ PATH FEBE

☒ SONET LOGIC

Frame Word Errors: 1

OK Cancel

- 5 Press **OK**.



- 6 Set the Results Category button to **Summary**.

Category buttons




- 7 Verify the yellow OC-3/OC-12/OC-48 active port LEDs are illuminated.

### Connecting the 2310 to the circuit

To connect the 2310 to the circuit

- 1 Connect a fiber cable from the OC-3/OC-12/OC-48 RX jack to the network's RECEIVE optical access jack.
- 2 Connect a fiber cable from the OC-3/OC-12/OC-48 TX jack to the network's TRANSMIT optical access jack.
- 3 Press the **Laser ON** action button.



- 4 Loop back the far-end of the network.
- 5 Press **RESTART** to clear alarms and begin the test.



- 6 Verify the green PRI SONET SIGNAL, FRAME, PATTERN, and PATH PTR LEDs are illuminated and the Results Window displays Results OK.

- 7 Press **SONET Logic Error** on the main screen five times to insert errors. Verify five logic errors are received.
- 8 Press **RESTART** to clear old test results and start a new test.

### Connecting the 2310 to the circuit diagram

Figure 39 is a depiction of cable connections from a SONET signal to the input/output on the 2310 for a SONET Termination BER test.





Figure 39 — SONET Termination BER test setup

## Optical Power measurement


This test measures the optical power of a signal in an optical fiber. The following symbol refers to Class 1 laser products. Refer to the warning for Class 1 laser products on page 125 and follow all precautions.




### Configuring the 2310

To measure optical power in an OC-3/OC-12/OC-48 rate

- 1 On the menu bar, press **MON/THRU > Monitor OC-3/OC-12/OC-48 > OC-3c/OC-12c/OC-48c BERT**. The unit automatically configures to a default setup.



- 2 Set Category buttons to **Signal**, then select **Optical Power dBm** at 1310 nm or 1550 nm.



- 3 Verify that the yellow OC-3/OC-12/OC-48 active port LEDs are illuminated.

### Connecting the 2310 to the circuit

To connect the 2310 to the circuit

- 1 Connect the fiber to be tested to the OC-3/OC-12/OC-48 RX jack.
- 2 Press the **RESTART** permanent softkey to clear alarms and begin the test.



- 3 Ensure the green PRI SONET SIGNAL LED is illuminated.
- 4 Read the optical power measured in the Results Screen.

### Connecting the 2310 to the circuit diagram

Figure 40 depicts cable connections from the OC-3/OC-12/OC-48 panel to inputs on the 2310 for Power Measurement.




Figure 40 — OC-3/12/48 Power Measurement setup

## Using the VT100 Emulation option

The 2310 can be configured to perform VT-100 terminal emulation. For this function, the TB2310-VT100 option is required.

In this mode, you can locally access network components, such as HDSL units or performance monitoring devices (e.g., PMNIU or PMDNI), and provision them or obtain performance information from them. When the VT100 option is installed in your 2310, there is no need to carry a laptop computer to do VT100 emulation.

### Configuring the 2310

To do VT-100 terminal emulation

- 1 Connect the RS-232 interconnect cable (supplied) from the printer port on the 2310 to the network device under test (e.g., HDSL unit). If necessary, connect a “gender changer” to the DB-9 connector end.


#### **NOTE:**

*There are two interconnect cables provided with 2000 products; you must verify that the 9-pin connector is used for the VT100 Emulator.*

- 2 Access the VT100 emulator by pressing the **Aux** permanent softkey icon (file cabinet).




3. Press the **VT100 Emulation** tab in the auxiliary functions screen, followed by VT100 Emulator in the middle of the screen.




The screen turns into a VT100 terminal with a cursor blinking at the top left hand corner.

4. Press the keypad icon located on lower right of the screen to access the keypad.



Keypad Icon becomes the VT100 keypad when pressed.

- 5 Change the size of the keypad by clicking the **Bigger/Smaller** button on the keyboard. You can also move/drag the keyboard to any desired location.




Notice the Keypad Icon has moved from status bar onto the pop-up keypad.

- 6 Access the menu of the network unit by either waiting a few seconds (e.g., Westell devices) or by touching the **<ESC>** key (e.g., Teltrend devices). Often, pressing the space bar works. If nothing appears on the screen after trying the above procedures, press **Settings > Terminal Preferences/Communications** from the menu bar to ensure settings are correct.

For example, in the **Terminal Preferences** screen, you may want to have **Local Echo** turned off, especially if double characters are



appearing on the screen. If settings are incorrect, change and save the settings. Try step 6 again.



#### NOTE:

*In the Communications Screen, DO NOT change the Connector setting. The setting is correct for the application, and should always remain on COM2.*

The menu for the network unit should appear and the format should be correct. If not, go back to **Settings > Terminal Preferences** and check the CR/LF insert.

- 7 Perform operations according to menu selections of the network device connected to the 2310 VT100 Emulator.
  - a Press **Exit VT100** to exit VT 100 Emulation.
- 8 Minimize the VT 100 keyboard if it is displayed on your screen.

## Using the OC-3c/12c ATM option

The OC-3c/12c ATM options enable you to generate and analyze OC-3c/12c ATM payloads. With these options, you can test the ATM signal at the OC-3c/12c rate to check HEC framing, generate TTC ATM test cells (see Figure 41 on page 142), and record measurements on specific ATM streams.

ATM is a communications transport technology that formats, multiplexes, cross-connects, and switches voice, video, and data traffic. The 2310 stores four user-programmable virtual path identifier (VPI) and virtual channel identifier (VCI) transmit profiles, and one receive profile. These VPI/VCI profiles allow a specific value to be entered into the generic flow control (GFC), payload type identifier (PTI), and cell loss priority (CLP) fields in the ATM headers. These four profiles enable you to do the following:

- Analyze overall ATM measurements, which may include header-error control (HEC) errors, dropped cells, cell types, correlation tag, and bandwidth utilization.
- Generate ATM compliant idle cells, which fill unallocated payload bandwidth.
- Generate ATM compliant TTC test cells, which are comprised of TTC cell profiles.
- Support network node interface (NNI) and user-to-network interface (UNI) cell formats.

Table 12 shows the primary user-configurable settings for transmit and receive profile setup per VPI/VCI. These profiles represent the four possible ATM virtual connections. The 2310 transmits one primary and one secondary profile continuously chosen from these four profiles. In the Rx Profile, all of the fields can be set to "X," which matches any value. When monitoring a virtual connection,

GFC, PTI, and CLP are commonly set to “X.” When monitoring a virtual path, the VCI may also be set to “X.”

**Table 12 — OC-3c/12c ATM TX and RX Profile setup fields**


| TX and RX Profile(s) | GFC        | VPI          | VCI              | PTI      | CLP      |
|----------------------|------------|--------------|------------------|----------|----------|
| TX Profile P1 - P4   | 00-15      | 000-255      | 00000-65535      | 0-7      | 0-1      |
| Rx Profile           | 00-15 or X | 000-255 or X | 00000-65535 or X | 0-7 or X | 0-1 or X |

**NOTE:**

The above table is for both UNI and NNI, with the exception that NNI does not have a GFC setup field and its VPI = 0 - 4095.

### Profiling with the Search Mode

If the profile selected is inactive, you can use Search mode. In this mode, the 2310 actively searches for TTC ATM Test Cell #1 or live ATM cells. The results of the search are displayed on the user interface. Figure 41 shows the composition of the TTC ATM Test Cell #1.



**Figure 41 — TTC ATM Test Cell #1**


## Monitoring ATM payloads

The following procedure outlines how to setup the 2310 to monitor OC-3c/12c ATM payloads.


### Configuring the 2310

To monitor an OC-3c/OC-12c ATM circuit

- 1 On the menu bar, press **Mon/Thru > Monitor OC-3/12 > OC-3c/12c > OC-3c/12c ATM**. The unit automatically configures to a default setup screen.




- 2 Press **Setup**. Ensure the characteristics shown in the Summary property setup screen match the network characteristics.



- 3 Select the **ATM Search** tab and designate the type of cells for which you want to search. Press **OK**.

**NOTE:**

The ATM Search mode can be used to actively search for ATM cells.



- 4 Set left and right Result Group buttons to **ATM** and Category buttons to **Summary** on the main screen.

Result Category Buttons

| ATM                 | Summary | ATM                 | Summary |
|---------------------|---------|---------------------|---------|
| Results Unavailable |         | Results Unavailable |         |

- Press **Start Search** to initiate a search for specific ATM streams. The results of the search are displayed in the ATM Results Category window (when **Stats** is selected).

You can also begin searches by pressing the appropriate VPI/VCI buttons.

When Start Search is pressed while viewing ATM results, the Results Category defaults to Stats.

Start Search becomes Stop Search when pressed.

### Connecting the 2310 to the circuit

To connect the 2310 to the circuit

- Connect a cable from the Rx OC-3c/12c interface to the OC-3c/12c test RECEIVE access point. Using laser safety guidelines found on page 125, press **Laser ON**.

- 2 Press the **RESTART** permanent softkey to clear alarms and begin the test.



- 3 Verify that the SONET SIGNAL, FRAME, PATH PTR, and ATM SYNC LEDs are illuminated (green).
- 4 Select a Result Category. Observe the ATM activities in the display.

### Connecting the 2310 to the circuit diagram

Figure 42 is a sample depiction of cable connections from the OC-3c/12c panel to the inputs on the 2310 for monitoring OC-3c/12c ATM traffic.




Figure 42 — Monitoring OC-3c/12c ATM test setup


## Terminating ATM payloads

This test enables you to generate and analyze OC-3c/12c ATM payloads by checking HEC framing, generating TTC ATM test cells, and recording measurements on specific ATM streams.

### Configuring the 2310

To configure the 2310

- 1 On the menu bar, press **TERM > Terminate OC-3/OC-12 > OC-3c/12c > OC-3c/12c ATM**. The unit automatically configures to a default setup screen.




### NOTE:

The default Results Category display is Summary. For ATM results, choose from the Category pull-down menu. When Stats is selected, the 2310 is set up to display VPI and VCI results.



- 2 Press **Setup**. Ensure that the characteristics shown in the Summary property setup screen match the network characteristics.



- 3 Select the **ATM Profiles** tab to set the appropriate Terminate profile parameters. First, indicate your network interface (UNI or NNI); this choice determines the GFC and VPI formats.
  - UNI is the default, enabling you to set profile numbers for all setup fields.
  - If NNI is selected, there is no GFC field, and the VPI becomes a 12-bit field instead of an 8-bit field.
- 4 Select the Pri Tx Profile, Rx Profile, and the Sec Tx Profile from the Tx/Rx Profile Selections box.
  - Select Scramble OFF/ON (to determine whether the traffic should be scrambled). The default for Scramble is ON.
  - Choose one of four possible profiles and an Rx profile from the Profile Settings box. For each profile, set the numbers for the GFC, VPI, VCI, PTI, and CLP setup fields. Press **OK**.

Generate OC-3c ATM

Summary | Timing | Rx Input | Error | Alarm | Pointer  
 Path Trace | ATM Profiles | ATM Search | ATM Tx

**Tx/Rx Profile Selections**

**Pri Tx Profile**   **Rx Profile**   **Sec Tx Profile**

☐ P1   ☐ P3   ☐ P1   ☐ P4   ☐ P2   ☐ P4

☐ P2   ☐ P4   ☐ P3   ☐ P3

**Scramble**   ☐ OFF   ☐ ON

**Profile Settings**

**Profiles**

Profile 1   GFC   VPI   VCI   PTI   CLP   User Tag

Profile 1   0   0   0   0   0   User

Profile 2   OK   Cancel

Profile 3

Profile 4

Rx Profile

7 8 9  
 4 5 6  
 1 2 3  
 0 X <<  
 CE OK

When you use the down arrows beside the boxes in the setup fields, a keypad displays so you can type in the values you want for Tx/Rx profile setup fields.

- 5 Select the **ATM Tx** tab and designate the Primary and Secondary Tx Profile Cell bandwidths. Select the default Correlation Tag or a specific User Tag. Press **OK**.

Generate OC-3c ATM

Summary | Timing | Rx Input | Error | Alarm | Pointer  
 Path Trace | ATM Profiles | ATM Search | ATM Tx

**Primary Tx Profile Cells**   **Correlation Tag**

Cont. Bandwidth %   Default = 2310

0.0   User

**Secondary Tx Profile Cells**

Cont. Bandwidth %   User Tag


0.0

OK   Cancel

A B C  
 D E F  
 7 8 9  
 4 5 6  
 1 2 3  
 0 X <<  
 CE OK


The Correlation Tag allows cells from multiple 2310 units to be differentiated from one another. You can also designate a specific User Tag.

- 6 Set both Result Group buttons to **ATM**.



- 7 Set the Result Category buttons to **ATM** on the left and **Summary** on the right. Press **Start Search** to start the search function.

Press Summary, LED, Stats, Cell, Cell Type, or Time for ATM Category Results.



To reconfigure for more searches, press the appropriate ATM profile buttons.

**Connecting the 2310 to the circuit**

To connect the 2310 to the circuit

- 1 Connect two cables, one from the Tx OC-3c/12c interface and the other from the Rx OC-3c/12c interface, to the OC-3c/12c test access point. Using laser safety guidelines, press **Laser ON**.


- 2 Press the **RESTART** permanent softkey to clear alarms and begin the test.



- 3 Verify that the SONET SIGNAL, FRAME, PATH PTR, and ATM SYNC LEDs are illuminated (green).
- 4 Observe the ATM activity in the Results display.

**Connecting the 2310  
to the circuit diagram**

Figure 43 is a sample depiction of cable connections from the OC-3c/12c ATM switch to the inputs on the 2310 for terminating OC-3c/12c ATM testing.



**Figure 43 — Terminating OC-3c/12c ATM test setup**



## Using the GR-303 option

GR-303 is a protocol which enables service for circuit-switched services. It efficiently deploys transport voice and/or data traffic using GR-303 based digital loop carriers.

The 2310 performs basic GR-303 protocol link packet analysis on a user-specified DS0 time slot within a framed T1 signal drop. These DSOs are either the embedded-operations channel (EOC), typically channel 12, or the time-management channel (TMC)/ common-signaling channel (CSC), typically channel 24. The analysis is conducted non-intrusively on the link, on Level-2 layer (LAPD) packets sent across the GR-303 protocol link.

The 2310 enables you to choose packets with a specific SAPI/TEI filter value and display their counts. These packets include the following:

- Total packets
- Information packets
- Receiver-Ready packets
- Receiver-Not-Ready packets
- Reject packets

The 2310 also enables you to display counts for packets with CRC errors, the number of seconds with at least one CRC-errored packet, the rate at which CRC-errored packets are received, and those packets discarded due to misalignments, aborts, or sizing constraints. These packets include the following:

- CRC-Errored packets
- CRC-Errored seconds
- CRC-Error rate
- Discarded packets

The 2310 displays the current state of the link under analysis (via virtual LEDs in the LED Category). The link is considered “ready” if an Unnumbered Acknowledgement (UA) response or a Receiver-Ready (RR) Packet is received. The link is considered “not ready” if a Disconnect Mode (DM) response or a Receiver-Not-Ready (RNR) Packet is received, or if the carrier signal is lost for that link.

### **Level 3 call statistics**

The 2310 also performs basic GR-303 call analysis within framed DS1 signal drops of a duplex T1 circuit. It is non-intrusive and performed on Layer-3 packets sent across the GR-303 time slot management channel/customer service center (TMC/CSC) protocol link, typically channel 24.

The 2310 enables you to acknowledge basic telephone events. These events include the following:

- Call attempts
- Call connects
- Call releases
- Percentage of blocked calls


## Monitoring GR-303 performance

The following test enables you to monitor GR-303 performance.

### Configuring the 2310


To configure the 2310

- 1 On the menu bar, press **MON/THRU > Monitor T1 > GR-303**. The unit automatically configures to a default setup.






- Press **Setup**. Ensure that the characteristics shown in the Summary tab match the network characteristics, such as T1 ESF.



- Select the **Rx Input** tab and select DSX-MON. Press **OK**.
- Select the **Code** tab and select B8ZS. Press **OK**.
- Select the **Channel** tab and select the DS0 channel for the link under analysis: EOC (typically Channel 12) or TMC/CSC (typically Channel 24). Press **OK**.



You need to select Channel 24 to get link statistics and call statistics results on the TMC/CSC.

- 6 Select the **GR-303** tab. Select the type of service access point identifier (SAPI) filter value, terminal endpoint identifier (TEI) filter value for link analysis, and the Cause Code value for call analysis. Press **OK**.

Select ANY in the TEI Filter field if you do not want to engage a filter.

- 7 Set both Result Group buttons to **T1 Pri**.
- 8 Set the Result Category buttons to **Link Stats** on the left and **Call Stats** on the right.

|                |            |                      |            |
|----------------|------------|----------------------|------------|
| T1 Pri         | Link Stats | T1 Pri               | Call Stats |
| Packets<br>117 |            | Call Attempts<br>101 |            |

- 9 If monitoring a second signal, press **T1 PRI** in the Results Group window and **T1 Sec** from the pull-down menu.

Result Group Buttons

|        |                        |        |                        |
|--------|------------------------|--------|------------------------|
| T1 Pri | Summary                | T1 Sec | Summary                |
| T1 Pri | Results<br>Unavailable | T1 Sec | Results<br>Unavailable |

- 10 Verify that the yellow active port LEDs next to the DS1 PRIMARY RX and SECONDARY RX jack are illuminated.

### **Connecting the 2310 to the circuit**

To connect to a circuit

- 1** Connect a cable from the PRIMARY RX jack to the DSX-1 A-Side MON jack.
- 2** Connect a cable from the SECONDARY RX jack to the DSX-1 Z-Side MON jack.
- 3** Press the **RESTART** permanent softkey to clear alarms and begin the test.



- 4** Verify that the green SIGNAL and FRAME LEDs are illuminated and the Primary and Secondary Results displays show Results Ok.

**Connecting the 2310  
to the circuit diagram**

Figure 44 is a sample depiction of cable connections from the DSX-1 panel to the inputs on the 2310 for T1 monitoring.




Figure 44 — GR-303 test setup

## Using the ISDN PRI option

The ISDN Primary Rate Option allows the 2310 to test the operational status of ISDN PRI links that use T1, DS3, and STS-1 as the physical interface. Features of the 2310 Primary Rate ISDN option include the following capabilities:

- Supports LUCENT 5ESS, NORTEL DMS 100, and National ISDN-2 Call Control specifications
- Supports different call types which include voice, 56K, 64K, Nx64K, Nx56K, and H0
- Places or receives two simultaneous voice or data calls while emulating a Terminal Equipment (TE) device (e.g., PBX)
- Provides test data services with BERT patterns or test voice services with a microphone and speaker
- Provides history of calls that were placed and terminated, as well as providing their corresponding cause codes
- Monitors physical layer (T1, DS3, and STS-1), and provide decodes of LAPD and Q.931 messages signaling on the D channel when in Monitor mode
- Performs back-up D channel testing and ability to support Network Facility Associated Signaling (NFAS)

### Monitoring ISDN PRI calls

In Monitor mode, the unit allows full duplex, non-intrusive monitoring of a single D channel (which enables interpreting messages going from Terminal Equipment (TE) to Network Termination (NT) as well as messages going from NT to TE. In addition to providing the T1, DS3, and STS-1 results, the option provides full text decodes of the messages on the D channel.

**Configuring the 2310**


To configure the 2310

- 1 On the menu bar, press **MON > Monitor T1/ ISDN PRI** to monitor a T1 circuit.


For all monitor ISDN PRI rate selections, see the following PRI ISDN choices:

| To test...           | Then...  |
|----------------------|--|
| T1                   | On the menu bar, press <b>MON &gt; Monitor T1 &gt; ISDN PRI</b>                        |
| DS3                  | On the menu bar, press <b>MON &gt; Monitor DS3 &gt; Muxed DS3 Drop &gt; ISDN PRI</b>   |
| STS-1 with DS3 muxed | On the menu bar, press <b>MON &gt; Monitor STS-1 &gt; Muxed DS3 Drop &gt; ISDN PRI</b> |
| STS-1 with VT1.5     | On the menu bar, press <b>MON &gt; Monitor STS-1 &gt; VT1.5 Drop &gt; ISDN PRI</b>     |


The 2310 automatically configures to a default setup for the chosen application.



- 2 Press **Setup**. Ensure the characteristics shown in the setup Summary screen match the network characteristics. To change settings, select the desired property sheet tabs in the property setup sheet.
- 3 Select the **Rx Input** tab. Ensure that BRIDGE or DSX-MON is selected. Press **OK**.



- 4 Select **Decodes** in the Result Category under either the Primary or Secondary Result Group. Press **Start Capture**.




Notice how selecting Decodes changes the screen as the 2310 begins to capture frames after Start Capture is pressed.



- 5 View the D channel message decodes. The number of frames captured and the percent of buffer used displays in the status message window.

Pressing **Stop Capture** displays the last captured frame in the display window. If no frames were captured, the text *no frames captured* displays. To traverse through the list of frames that were captured, press any of the four action buttons named **First Frame**, **Last Frame**, **Prev Frame**, and **Next Frame**.



Start Capture becomes Stop Capture when the buffer is full.

- 6 Observe results in the display.

### Connecting the 2310 to the circuit

To connect to a circuit

- 1 Connect a cable from the PRIMARY RX jack to the DSX-1 A-Side MON jack.
- 2 Connect a cable from the SECONDARY RX jack to the DSX-1 Z-Side MON jack.

- 3 Press the **RESTART** permanent softkey to clear alarms and begin the test.



- 4 Verify that the green **SIGNAL** and **FRAME** LEDs are illuminated and the Primary and Secondary Results displays show **Results** **Ok**.

### Connecting the 2310 to the circuit diagram

Figure 45 is a sample depiction of cable connections from the DSX-1 panel to the inputs on the 2310 for T1 monitoring.




Figure 45 — Monitor ISDN PRI test setup

### **Using PRI ISDN in Terminate mode**

The Terminate ISDN PRI test application emulates a TE device such as a PBX. Place Call and Receive Call is an advanced supported feature of Terminate Mode PRI. It enables the processing of up to two simultaneous calls (two terminating, two placing, or generating one call while terminating a second call). One or two calls may be placed on the same T1 or on different T1s.

### **Placing a call**

This test allows you to place calls to and from the network.

**Configuring the 2310**


To configure the 2310 for placing a call

- 1 On the menu bar, press **TERM > Terminate T1 > ISDN PRI**.


For all terminate ISDN PRI rate selections, see the following PRI ISDN choices:

| To test...           | Then...   |
|----------------------|---|
| T1                   | On the menu bar, press <b>TERM &gt; Terminate T1 &gt; ISDN PRI</b>                        |
| DS3                  | On the menu bar, press <b>TERM &gt; Terminate DS3 &gt; Muxed DS3 Drop &gt; ISDN PRI</b>   |
| STS-1 with DS3 muxed | On the menu bar, press <b>TERM &gt; Terminate STS-1 &gt; Muxed DS3 Drop &gt; ISDN PRI</b> |
| STS-1 with VT1.5     | On the menu bar, press <b>TERM &gt; Terminate STS-1 &gt; VT1.5 Drop &gt; ISDN PRI</b>     |


The 2310 automatically configures to a default setup for the chosen application.




- 2 Press **Setup**. Ensure the characteristics shown in the setup Summary screen match the network characteristics. To change settings, select the desired property sheet tabs in the property setup sheet.



- 3 Select the **Rx Input** tab. Ensure that **TERM** is selected. Press **OK**.



- 4 Select the **ISDN** property sheet tab. Choose the Switch type and then Config Prim, D channel test type (Single [Primary Only], NFAS Only, or NFAS/DCBU), and the D channel (s) DS0s.




ISDN tab with 5ESS as the Switch. Here, the primary interface is NFAS/DCBU, and the D channel is 24.

#### NOTE:

The DMS and 5ESS selections are for switches running vendor-proprietary ISDN. For switches running National ISDN, NI-2 should be selected regardless of the switch manufacturer.

- 5 Select the **ISDN Call** property sheet tab. Configure the call(s) by pressing Config Call 1 and/or Config Call 2. Choose the type of call, the B channel to place the call on, and enter the number to be dialed on the Called # keypad. For a data call, enter a callback

number. Of course, this number must be capable of receiving a data call, such as a loop back number.



6 Press **OK**.

### Connecting the 2310 to the circuit

To connect to the circuit

- 1 Connect a cable from the PRIMARY RX jack to the DSX-1 A-Side OUT jack.
- 2 Connect a cable from the PRIMARY TX jack to the DSX-1 Z-Side IN jack.
- 3 Press the **RESTART** permanent softkey to clear alarms and begin the test.




- 4 Verify that the green SIGNAL and FRAME LEDs are illuminated and the Primary and Secondary Results displays show Results Ok.

**NOTE:**

When the 2310 is configured for the correct switch type (Call Control) and the D channel, it establishes the data link and is ready to carry out ISDN call processing. The unit enables BERT and VF analysis of the B channels being used after successful call establishment. In addition to providing the results for the physical interface, the unit also provides statistics collected on the D channel, as well as results based on the analysis of the B channel. The Call Controls supported in this mode include LUCENT 5ESS, NT DMS 100, and NI-2.


- 5 Check the **D Chan Ready** LED under the LED Result Category to verify that the D channel and/or the D channel backup are in service.



Verify the D Chan Ready Category LED is evident before placing a call.



- 6 Press **Enter PRI Call Control**. The PRI CALL CONTROL keypad pops up. Press **Conn** to place the call.



Enter PRI Call Control becomes Exit Call Control when the PRI CALL CONTROL keypad is displayed.

## Receiving a call


When an ISDN call from the network is received by the 2310, you are alerted by a flashing **Enter PRI Call Control** action button, and a message in the status display.

## Configuring the 2310

To configure the 2310 for receiving a call

- 1 Follow procedural steps 1 - 8 in "Placing a call" on page 167.
- 2 Press **Enter PRI Call Control** to open the PRI CALL CONTROL keypad.
- 3 Press **Answer** (or **Reject**) for the incoming call.
- 4 Press **Push 2 Talk** and speak into the microphone to establish a voice path.

- 5 Press **Disc** to disconnect the call.



### Connecting the 2310 to the circuit

To connect to the circuit

- 1 Connect a cable from the PRIMARY RX jack to the DSX-1 A-Side (OUT) jack.
- 2 Connect a cable from the PRIMARY TX jack to the DSX-1 Z-Side (IN) jack.
- 3 Press the **RESTART** permanent softkey to clear alarms and begin the test.



- 4 Verify that the green SIGNAL and FRAME LEDs are illuminated and the Primary and Secondary Results displays show Results Ok.

### Connecting the 2310 to the circuit diagram

Figure 46 is a sample depiction of cable connections from the DSX-1 panel to the inputs on the 2310 for T1 monitoring.




Figure 46 — Terminate ISDN PRI Test Setup

### NFAS and D channel backup testing


The D channel Backup option enables all signaling information to take place on one D channel for both PRI interfaces on the Network Facility Associated Signaling (NFAS). Furthermore, there is a dedicated channel on the non-active D channel interface for the purpose of carrying signaling information in the case of the primary D channel failure.

### Configuring the 2310

To configure the 2310

- 1 Follow procedural steps 1 - 4 in "Placing a call" on page 167.
- 2 Select NFAS or NFAS/DCBU, depending on the PRI line characteristics. For this example, choose NFAS/DCBU on the secondary interface, which supports the signaling information for

two PRI links taking place on the D channel in each T1 (one active, one backup). Because NFAS/DCBU was chosen, Config Sec enables the selection of the DS0 which will carry signaling information.




On Config Prim and Config Sec pop-ups, select 24 on D Chan Select and Interface ID.


#### NOTE:

The Interface ID is most commonly set to 1 for the backup D channel. However, if a non-standard ID is assigned, it must match the switch.


- 3 Set the Interface ID to 1 for the Secondary Interface and 24 on the D Chan Select section.
- 4 Select the **ISDN Stats** Result Category to check this information.



The D Chan In Serv LED is provided under the **LED** Result Category as a convenient means of checking for an in-service D channel. To initiate the D channel to test the switch over of a standby D channel to the in-service D channel, disconnect the in-service T1 or press **Switch D-Chan**.



D Chan Ready in the LED Category locates an in-service and ready D channel.



The backup D channel switch-over feature can test the switch-over of a standby D channel to the in-service D channel.

- 5 Continue with placing and receiving calls as addressed earlier.

- 6 Switch between D channels when testing NFAS/DCBU. Do this several times by pressing **Switch D-Chan.**

Table 13 describes the D channel message displays.

**Table 13** — *D channel states and descriptions*

| <b>D channel States</b> | <b>Descriptions</b>  |
|-------------------------|--|
| In Service              | D channel carries signaling information.   |
| Out of Service          | D channel is not available.  |
| Maintenance Busy        | State is entered automatically when state changes are taking place on the other interface.       |
| Wait                    | D channel is waiting for a response from the network in order to enter the in-service state.     |
| Standby                 | D channel is transitioning to the in-service state in the case of the Primary D channel failure. |

# Test Results

This chapter describes 2310 test results for DS1, DS3, and SONET. The available test results discussed in this chapter include the following:

- “Results Categories” on page 181
- “Summary Category” on page 181
- “LED Category” on page 183
- “Signal Category” on page 188
- “BPV Category” on page 192
- “Frame Category” on page 193
- “Parity Category” on page 197
- “SONET Section Category” on page 199
- “SONET Line Category” on page 200
- “SONET Path Category” on page 204
- “SONET Path Trace Category” on page 206
- “SONET VT Category” on page 207
- “SONET ATM Category” on page 210
- “Channel Category” on page 212

- “Call Signal Category” on page 215
- “Traffic Category” on page 217
- “Logic Category” on page 218
- “Time Category” on page 220
- “GR-303 Category” on page 221
- “PRI ISDN Category” on page 225
- “Quad Results” on page 230



## Results Categories

The following list shows the possible test result categories:

- |               |              |              |
|---------------|--------------|--------------|
| - Summary     | - Section    | - ISDN Stats |
| - LED         | - Line       | - Link Stats |
| - Signal      | - Traffic    | - Call Stats |
| - BPV         | - Time       | - Cell       |
| - Call Signal | - Path       | - Cell Type  |
| - Logic       | - Path Trace | - Stats      |
| - VT          | - Channel    |              |
| - Frame       | - Bridgetap  |              |
| - Parity      | - Multipat   |              |


Many of the categories will be discussed with their test results.

## Summary Category

The Summary Category automatically displays key results that are non-zero or out-of-specification. This allows quick access to the results without having to search through the other categories. When all Summary results are error-free, the message **Results OK** displays. When an error is detected, the appropriate test result appears in the Summary Category window.

### DS1 Summary Category test results

Select **T1 Pri/Sec** from the Result Group and **Summary** from the Result Category for test results.



The results that appear in the Summary Category for DS1 include the following:

- Results OK
- CRC Errors
- Pattern Slips
- Frame Slips
- Signal Losses
- Signal Present
- Excess Zeroes
- BPVs
- Yellow Alarm
- AIS
- B8ZS Detected
- Frame Losses
- Framesync
- Ones Density
- Bit Errors
- Frame Errors
- Rx Frequency
- Pattern Losses

### DS3 Summary Category test results

The results that appear in the Summary Category for DS3 include the following:

- Results OK
- Pattern Slips
- BPV Errors
- FEBEs
- Frame Sync
- Frame Losses
- Frame Errors
- Yellow Alarm
- Parity Slips
- C-Bit Errors
- DS2 Framesync
- Signal Present
- Signal Losses
- Blue Alarm
- RX Frequency
- FEAC Codes
- DS2 Frame Losses
- Bit Errors
- Pattern Losses
- Patternsync

### SONET Summary Category test results


The results that appear in the Summary Category for SONET include the following:

- Results OK
- Line AIS
- Line RDI
- Path AIS
- Path RDI
- Line Unavailable Secs
- Line BIP Errors
- Line FEBEs
- Path Pointer Justifications
- Path Pointer NDFs
- OC-12 RX Frequency
- OC-48 RX Frequency
- VT FEBEs
- VT RDI
- VT Pointer NDFs

- VT AIS
- Frame Word Errors
- Frame Losses
- Framesync
- Severely Errored Frame
- Bit errors
- Section BIP Errors
- Severely Errored Frame Defect
- APS Message Count
- BPVs
- Path Pointer Size
- Path BIP Errors
- Path FEBEs
- Path Pointer Present
- Path Unavailable Secs
- STS-1 RX Frequency
- Pattern Slips
- Pattern Losses
- Pattern Sync
- OC-3 RX Frequency
- VT Pointer Justifications
- VT Pointer Present
- VT Loss of Pointer
- VT Unavailable Secs
- VT BIP Errors
- Signal Present
- Signal History
- Signal Losses
- RX Overload
- VT RDI

## LED Category

For DS1, DS3, and SONET signal testing, green status LEDs provide information about the current condition of the received primary and secondary (optional) signals. The status LEDs are divided into two groups, PRI (Primary) and SEC (Secondary). The PRI status LEDs refer to the signal received through the Primary RECEIVE jack. The PRI status LEDs also indicate the condition of the signal dropped from the payload of a higher signal (for example, the condition of a DS3 signal dropped from an OC-3 signal). The SEC status LEDs refer to the signal received through the Secondary RECEIVE jack. Select **LED** from the Result Category for LED test results.



**DS1 LED Category test results**

As the received signal is recognized, the appropriate Status LEDs illuminate. The DS1 LED Category test results are defined in Table 14.

**Table 14 — DS1 LED test results**

| Displayed Test Result | Description  |
|-----------------------|--|
| Excess Zeros          | Excess Zeros — Illuminates when excess zeros (more than 8 consecutive) are detected in B8ZS coding and more than 15 in AMI coding.   |
| Ones Density          | Ones Density — Illuminates if the T1 signal violates the ones density criteria (when there is at least $n$ ones in $8(n+1)$ bits).   |
| Yellow Alarm          | Yellow Alarm — Illuminates when the Far-End Out-of-Frame (FEOOF) signal is detected. FFOO in FDL for ESF, bit 2 is set to 0 for 255 consecutive DS0 channels for T1-D4.                                |
| AIS                   | Alarm Indication Signal — Illuminates when the unframed pattern is all ones. AIS indicates to downstream equipment that an upstream piece of equipment has detected loss of signal or loss of framing. |
| B8ZS                  | Bipolar with 8-Zero Substitution — Illuminates when B8ZS clear channel coding is detected in the received DS1 signal.  |
| DS1 Idle              | DS1 Idle — Illuminates when the T1 D4 inband (all DS1 channels contain 0001 0111 bit pattern) or T1 ESF out-of-band (FFOO) idle code (Yellow Alarm) is present.  |

### DS3 LED Category test results


As the received signal is recognized, the appropriate status LEDs illuminate. The DS3 LED Category test results are defined in Table 15.

**Table 15** — DS3 LED test results

| Displayed Test Result | Description   |
|-----------------------|---|
| Far End Alarm         | Far-End Alarm — Illuminates when Far-End Alarm and Control (FEAC) messages in the C-bit parity framing format (third C-bit in the M1 subframe) are detected.  |
| Blue Alarm            | Blue Signal Alarm — Illuminates when the Blue Signal (Alarm Indication Signal) is detected (1010 pattern or stuck C bit). AIS indicates to downstream equipment that an upstream piece of equipment has detected loss of signal or loss of framing. |
| Yellow Alarm          | Yellow Alarm — Illuminates when the Far-End Out-of-Frame (FEOOF) signal (X-bits set to zero) is detected.   |
| DS2 Frame Loss        | DS2 Frame Loss — Illuminates when frame synchronization to the DS2 signal is lost.  |
| DS2 Frame Sync        | DS2 Frame Sync — Illuminates when synchronization to the DS2 framing format is present.   |
| C-Bit Frame           | C-Bit Frame — Illuminates when the T-BERD 2310 acquires C-bit frame synchronization.  |
| DS3 Idle              | DS3 Idle — Illuminates when a DS3 signal is received in a 1100 pattern aligned in the payload for one M-frame.  |

## SONET LED test results

As the received signal is recognized, the appropriate status LEDs illuminate. Select **SONET Pri/Sec** from the Result Group for STS-1, OC-3/ OC-12/OC-48 results. Select **LED** from the Result Category for test results.



The SONET LED Category test results are defined in Table 16.

**Table 16 — SONET LED test results**


| Displayed Test Result | Description   |
|-----------------------|---|
| Line AIS              | Line Alarm Indication Signal — Line (AIS) detects a 111 pattern in the Line overhead APS byte (K2), Bits 6 to 8, for five consecutive frames. Line AIS is removed after detecting a pattern other than 111 in Bits 6-8 of byte K2 for five consecutive frames. Line AIS indicates to downstream equipment that an upstream section terminating equipment (STE) has detected loss of signal or loss of framing.                        |
| Line RDI              | Line Remote Defect Indication — (RDI) alarm (also known as far-end receive fail (FERF) alarm) detects a 110 pattern in the Line overhead APS byte (K2), Bits 6 to 8, for five consecutive frames. Line RDI is removed after detecting a pattern other than 110 in Bits 6-8 of byte K2 for five consecutive frames. Line RDI alerts an upstream device of a downstream failure, such as loss of signal, loss of frame, or Line AIS.    |
| Path AIS              | Path Alarm Indication Signal — Path AIS alarm detects an all ones pattern in the Line overhead pointer bytes (H1 and H2) for three consecutive frames. Path AIS is removed when a valid set of pointer bytes and active new data flags (NDFs) are received, or when a valid pointer value is observed in three consecutive frames. Path AIS alerts the downstream path terminating equipment (PTE) that an upstream failure occurred. |

**Table 16** — SONET LED test results (continued)

| Displayed Test Result | Description  |
|-----------------------|--|
| Path LOP              | Path Loss Of Pointer — Path LOP alarm occurs when a valid pointer value cannot be determined from the Line overhead pointer bytes (H1 and H2). Specifically, Path LOP is declared if a valid pointer is not found in eight consecutive frames, if eight consecutive active NDFs are received without the corresponding concatenation indication. The Path LOP alarm is removed when a consistent pointer value or concatenation indication is received for three consecutive frames. |
| Path RDI              | Path Remote Defect Indication — Path RDI alarm (also known as RAI or Yellow Alarm) detects a one in Bit 5 of the Path status byte (G1) for five consecutive frames. STS Path RDI is removed after Bit 5 of byte G1 contains a zero for five consecutive frames. Path RDI indicates to the upstream PTE that a downstream failure has been detected.  |
| VT AIS                | Virtual Tributary Alarm Indication Signal — VT AIS alarm detects an all ones pattern in the VT pointer bytes (V1 and V2) for three consecutive VT superframes. VT Path AIS is removed under two conditions: when a valid VT pointer, valid VT size, and the NDF 1001 flag are detected, or three consecutive VT superframes containing a valid VT pointer, valid VT size, and a normal NDF are detected. VT AIS alerts the downstream VT PTE of an upstream failure.                 |
| VT LOP                | Virtual Tributary Loss Of Pointer — VT LOP alarm detects a valid pointer value cannot be determined from the VT Path overhead bytes (V1 and V2). Specifically, VT Path LOP is declared if a valid pointer is not found in eight consecutive frames, if eight consecutive active NDFs are received. The VT Path LOP alarm is removed when a consistent pointer value is received for three consecutive frames.  |
| VT RDI                | Virtual Tributary Remote Defect Indication — VT RDI alarm (also known as RAI or Yellow Alarm) detects a one in Bit 8 of the VT Path overhead byte (V5) for five consecutive VT superframes. The VT Path RDI alarm is removed when a zero is detected in Bit 8 of byte V5 for five consecutive frames. VT RDI indicates to the upstream VT PTE that a downstream failure has been detected.   |
| Concat Payload        | Concat Payload — A Concatenated pointer value is detected in the first received STS-1 and NDFs with pointer values of 0 in the remaining STS-1s for three frames.  |

# Signal Category

The Signal Category results include signal level, frequency, and loss seconds. The results are accumulated after initial signal detection. Select **T1 Pri/Sec** from the Result Group and **Signal** from the Result Category for Signal Category test results.



## DS1 Signal test results

The DS1 Signal Category test results are defined in Table 17.

Table 17 — DS1 Signal test results

| Displayed Test Result | Description   |
|-----------------------|---|
| Signal Losses         | Signal Losses — The T1 signal is lost or absent (equal to 1 loss in every 100 milliseconds).  |
| Signal Loss Secs      | Signal Loss Seconds — The number of seconds during which the received DS1 signal was lost for all or part of a second since initial signal detection.               |
| RX Frequency          | Receive Frequency — The frequency of the clock recovered from the received DS1.   |
| TX Frequency          | Transmit Frequency — The frequency of the clock as measured from the transmitted data.  |
| Simplex Curr mA       | Simplex Current measured in milliamperes — DS1 electrical signal received in the primary T1 test, the value is displayed as xxx mA in a range from 10 mA to 200 mA. |



**Table 17 — DS1 Signal test results (continued)**

| Displayed Test Result | Description   |
|-----------------------|---|
| RX Level dBdsx        | Receive Level Decibels dsx — DS1 power of signal received in a T1 test. The value is displayed as xxx dBdsx in a range from +6.0 dBdsx to -40.0 dBdsx.  |
| RX Level dBm          | Receive Level Decibels below 1 Milliwatt — DS1 power of signal received in a T1 test. The value is displayed as + xx.x dBm in a range from +23.0 dBdsx to -23.5 dBdm. Will only be valid for unframed ones.   |
| RX Level Vpp          | Receive Level Volts peak-to-peak — DS1 power of signal received in a T1 test. The value is displayed as + xx.x V in a range from +12.0 V to 1.0 V.  |
| Timing Slips          | Timing Slips — The number of bit slips (+/-) and frame slips (absolute value) counted when the DS1 test signal slips from the DS1 reference signal after both signals are present simultaneously. Counts from 0 to + or - 192 and then rolls over to 0. Resets to 0 if signal present is lost on the analyzed T1 or on the reference T1. A positive results indicates that the analyzed T1 is faster than the reference T1. |
| Frame Slips           | Frame Slips — The number of frame slips (absolute value) counted when the DS1 test signal slips from the DS1 reference signal after both signals are present simultaneously.  |

**DS3 Signal test results**

The DS3 Signal Category test results are defined in Table 18.

**Table 18 — DS3 Signal test results**

| Displayed Test Result | Description   |
|-----------------------|---|
| Signal Losses         | Signal Losses — The DS3 signal is lost or absent (equal to 1 loss in every 100 millisecond)s.   |
| Signal Loss Secs      | Signal Loss Seconds — The number of seconds during which the received DS3 signal was lost for all or part of a second since initial signal detection. |

**Table 18 — DS3 Signal test results (continued)**

| Displayed Test Result | Description   |
|-----------------------|---|
| RX Frequency          | Receive Frequency — The frequency of the clock recovered from the received data measured in Hz.   |
| TX Frequency          | Transmit Frequency — The frequency of the clock recovered from the transmitted data measured in Hz.   |
| Level Volts           | Level Volts — The receive level on the incoming STS-1 represented in volts. Accuracy is (+/-) 10% or 20 millivolts, whichever is greater. Range is .00 to 1.99 Vp, and resolution is 0 millivolts.                                  |
| RX Level dBdsx        | Receive Level Decibels dsx — DS3 power of the signal received.  |
| RX Level dBm          | Receive Level Decibels below 1 Milliwatt — DS3 power of signal received in the primary DS3 test. The value is displayed as + xx.x dBm. This is not a true power measurement and is instead derived from the peak level measurement. |

**SONET Signal test results**

The SONET Signal Category test results are defined in Table 19.

**Table 19 — SONET Signal test results**

| Displayed Test Result     | Description   |
|---------------------------|---|
| Signal Losses             | Signal Losses— Occurs during transition from ON to OFF of SONET signal.   |
| Signal Loss Secs          | Signal Loss Seconds — Represents an asynchronous test second in which the appropriate loss of signal was present at least some portion of the second.   |
| RX Frequency (STS-1)      | STS-1 Receive Frequency — Represents the total number of STS-1 cycles received during the last second. The resolution is 4 Hz. If the signal is further than (+/-) 1% from the nominal, a message displays indicating that the signal is not STS-1. |
| RX Frequency (OC-3/12/48) | OC-3/12/48 Receive Frequency — Represents the total number of OC-3/12/48 cycles received during the last second. If the signal is further than (+/-) 1% from the nominal, a message displays indicating that the signal is not OC-3/12/48.          |


**Table 19 — SONET Signal test results (continued)**

| Displayed Test Result         | Description  |
|-------------------------------|--|
| TX Frequency (STS -1)         | STS-1 Transmit Frequency — Represents the total number of STS-1 cycles transmitted during the last second.   |
| TX Frequency (OC-3/12/48)     | OC-3/12/48 Transmit Frequency — Represents the total number of OC-3/12/48 cycles transmitted during the last second.   |
| STS-1 Level Volts             | STS-1 Level Volts — Represents the receive level on the incoming STS-1 in volts. Accuracy is (+/-) 10% or 20 millivolts, whichever is greater. Range is .00 to 1.99 Vp, and resolution is 10 millivolts.   |
| STS-1 Level dBdsx             | STS-1 Level Decibels dsx — Represents the receive level on the incoming STS-1 in dBdsx. If the result is too high, the 2310 indicates the signal is too high and out of range. If the result is 0.00 Volts, it indicates the signal is too low.  |
| STS-1 Power dBm               | Receive Level Decibels below 1 Milliwatt — Represents the receive level on the incoming STS-1 in dBm. This is not a true power measurement and is instead derived from the peak level measurement. If the result is too high, the 2310 indicates the signal is too high and out of range. If the result is 0.00 Volts, it indicates the signal is too low. |
| Optical Power (1310/1550) dBm | Optical Power Decibels below 1 Milliwatt — Represents the receive level on the incoming optical signal (OC-3/12/48) in dBm.  |
| BPVs                          | Bipolar Violations — Represents the number of bipolar violations (BPVs) detected since the beginning of the test.  |
| BPV Rate                      | Bipolar Violation Rate — Represents the ratio of BPVs to received bits since initially acquiring signal presence.  |
| BPV % Err Free Secs           | BPV Percentage of Error-Free Seconds — Represents the percentage of the number of seconds during which no BPVs occurred since the beginning of the test.   |
| Rx Overload                   | Receive Level Overload — Occurs when the received optical power level is greater than -6 dBm. The receiver automatically shuts down and "Rx Overload" appears (only applicable with OC-48 equipped modules).   |
| Temp - Celsius                | Temperature in Celsius degrees — Indicates the internal 2310 temperature.  |

# BPV Category

The BPV Category results include electrical level bi-polar violation measurements.

Select **T1 Pri/Sec** from the Result Group and **BPV** from the Result Category for BPV test results.



**DS1 BPV test results**     The DS1 BPV Category test results are defined in Table 20.

Table 20 — DS1 BPV test results

| Displayed Test Result | Description  |
|-----------------------|--|
| BPVs                  | Bipolar Violations — The number of bipolar violations (BPVs) detected since the beginning of the test. Intentional B8ZS code violations are excluded from the count. |
| BPV Rate              | Bipolar Violation Rate — The ratio of BPVs to received bits since initially acquiring signal presence.   |
| BPV Err Secs          | BPV Errored Seconds — The number of seconds during which one or more BPVs occurred since the beginning of the test.  |


**DS3 BPV test results** The DS3 BPV Category test results are defined in Table 21.

**Table 21** — DS3 BPV test results

| Displayed Test Result | Description  |
|-----------------------|--|
| BPVs                  | Bipolar Violations — The number of bipolar violations (BPVs) detected since the beginning of the test. Intentional B3ZS code violations are excluded from the count. |
| BPV Rate              | Bipolar Violation Rate — The ratio of BPVs to received bits since initially acquiring signal presence.   |
| BPV Err Secs          | BPV Errored Seconds — The number of seconds during which one or more BPVs occurred since the beginning of the test.  |

## Frame Category

Frame errors begin accumulating after initial frame synchronization on the incoming DS1 signal. Select **T1 Pri/Sec** from the Result Group and **Frame** from the Result Category for Frame test results.



**DS1 Frame test results**

The DS1 Frame Category test results are defined in Table 22.

**Table 22 — DS1 Frame test results**

| Displayed Test Result | Description   |
|-----------------------|---|
| Frame Losses          | Frame Losses — A count of discrete losses of frame synchronization since initial frame synchronization or last test restart.  |
| Frame Errors          | Frame Errors — The number of frame errors detected since initial DS1 frame synchronization.   |
| Frame Error Rate      | Frame Error Rate — The ratio of frame errors to received framing bits since initially acquiring frame synchronization.  |
| Frame Erred Secs      | Frame Errored Seconds — The number of seconds during which one or more frame errors occurred since initial DS1 frame synchronization.   |
| Frame Loss Secs       | Frame Loss Seconds — The number of seconds during which one or more frame synchronization losses occurred or during which frame synchronization could not be achieved, since initial DS1 frame synchronization. |
| Frame SES             | Frame Severely Errored Seconds — The number of seconds during which the total number of frame errors equals 12 or more (D4 framing only).   |
| CRC Errors            | Cyclic Redundancy Check Errors — The number of CRC errors detected since initial DS1 frame synchronization. CRC errors are counted only when ESF framing is present in the received T1 data.                    |
| CRC Erred Rate        | Cyclic Redundancy Check Error Rate — The ratio of CRC errors to the number of extended superframes received.  |
| CRC SES               | Cyclic Redundancy Check Severely Errored Seconds — The number of seconds during which the total number of CRC errors and frame synchronization losses equaled 320 or more.                                      |
| CRC Erred Secs        | Cyclic Redundancy Check Errored Seconds — The number of seconds during which one or more CRC errors occurred.   |

**DS3 Frame test results**

The DS3 Frame Category test results are defined in Table 23.

**Table 23 — DS3 Frame test results**

| <b>Displayed Test Result</b> | <b>Description</b>   |
|------------------------------|--|
| Frame Losses                 | DS3 Frame Losses — The detection of frame synchronization lost since the beginning of the test.  |
| DS2 Frame Losses             | DS2 Frame Losses — The number of DS2 frame losses occurring after initial frame synchronization.   |
| Frame Errors                 | Frame Errors — The number of frame errors detected since initial DS3 frame synchronization.  |
| Frame Error Rate             | Frame Error Rate — The ratio of frame errors to received framing bits since initially acquiring frame synchronization.                               |
| Frame Erred Secs             | Frame Errored Seconds — The number of seconds during which one or more frame errors occurred since initial DS3 frame synchronization.                |
| Far-End OOF Sec              | Far-End Out-of-Frame Seconds — The number of seconds during which the received X-bits are zero within the 1 second interval.                         |
| Near-End OOF Sec             | Near-End Out-of-Frame Seconds — The number of seconds during which an out-of-frame condition or an AIS is detected.                                  |
| DS2 Frame Errors             | DS2 Frame Errors — The number of DS2 frame errors detected since initial DS2 frame synchronization.  |
| DS2 Frame Error Rate         | DS2 Frame Error Rate — The ratio of detected DS2 frame errors to the total DS2 framing bits received.  |
| TX X-Bits                    | Transmitted X-bit — The current setting of the transmitted X-bits when in a framed mode.   |
| RX X-Bits                    | Received X-bit — The current status of the received X-bits when in a framed mode. The result is available after receiving DS3 frame synchronization. |


**Table 23** — DS3 Frame test results (continued)

| Displayed Test Result | Description   |
|-----------------------|---|
| FEAC, History         | Far-End Alarm and Control (FEAC) message History — The reception of at least 2 consecutive repetitions of one of the following FEAC messages in the C-bit FEAC channel: |
| Comm Equip Fail NSA:  | DS3 Equipment Failure, Service Affecting (Type 1 equipment failure)   |
| DS3 Idle:             | DS3 Idle Signal Received  |
| DS3 AIS:              | DS3 Alarm Indication Signal Received  |
| DS3 Out of Frame:     | DS3 Out-of-Frame, Loss of DS3 Frame Synchronization   |
| DS3 LOS/HBER:         | DS3 Loss-of-Signal/High Bit Error Ratio   |
| DS3 Equip Fail SA:    | DS3 Equipment Failure, Service Affecting (Type 1 equipment failure)   |
| DS3 Equip Fail NSA:   | DS3 Equipment Failure, Non-Service Affecting (Type 2 equipment failure)   |
| Mult DS1 LOS/HBER:    | Multiple DS1 Loss-of-Signal/High Bit Error Ratio  |
| Single DS1 LOS/HBER:  | Single DS1 Loss-of-Signal/High Bit Error Ratio  |
| DS1 Equip Fail SA:    | DS1 Equipment Failure, Service Affecting (Type 1 equipment failure)   |
| DS1 Equip Fail NSA:   | DS1 Equipment Failure, Non-Service Affecting (Type 2 equipment failure)   |



## Parity Category

Parity errors begin accumulating after initial frame synchronization on the incoming DS3 signal. The DS3 PARITY Category results depend on the current framing mode and the received framing signal. Select **DS3 Pri/Sec** from the Result Group and **Parity** from the Result Category for Parity test results.



### DS3 Parity test results

The DS3 Parity Category test results are defined in Table 24.

Table 24 — DS3 Parity test results


| Displayed Test Result | Description  |
|-----------------------|--|
| Parity Errors         | Parity (P-bit) Errors — An M-Frame that contains a mismatch between either parity bit (P-bits) and the parity calculated from the information bits in the previous M-frame.                              |
| Parity Error Rate     | Parity (P-bit) Error Rate — The ratio of parity errors to the number of bits over which parity was calculated.   |
| Parity Error Secs     | Parity (P-bit) Errored Seconds — The number of seconds during which one or more parity errors occurred since initial DS3 frame synchronization.  |
| C-Bit Errors          | C-bit Parity Errors — An M-Frame that contains a mismatch between the majority rule of the C-Bit path parity bits (CP-bits) and the parity calculated from the information bits in the previous M-frame. |

**Table 24 — DS3 Parity test results (continued)**

| Displayed Test Result | Description  |
|-----------------------|--|
| C-Bit Error Rate      | C-bit Parity Error Rate — The ratio of C-bit parity errors to the number of bits over which C-bit parity was calculated.   |
| C-Bit Error Secs      | C-bit Parity Errored Seconds — The number of seconds during which one or more C-bit parity error occurred since initial DS3 C-bit frame synchronization.                       |
| FEBEs                 | Far-End Block Errors — Far-end block errors (FEBEs) detected since initial DS3 C-bit frame synchronization caused by an M-Frame in which any of the three FEBE bits is a zero. |
| FEBE Rate             | Far-End Block Error Rate — The ratio of FEBEs to the number of bits over which C-bit parity was calculated.  |
| FEBE Errored Seconds  | Far-End Block Errored Seconds — The number of seconds during which at least one FEBE occurred since initial DS3 C-bit frame synchronization.                                   |

## SONET Section Category

SONET Section overhead test results enable the 2310 to analyze the SONET section of a network. The results are only available when a SONET option is installed. Select **SONET Pri/Sec** from the Result Group and **Section** from the Result Group for Section test results.



### SONET Section test results

The SONET Section Category test results are defined in Table 25.

**Table 25** — SONET Section test results


| Displayed Test Result  | Description  |
|------------------------|--|
| Frame Word Errors      | Frame Word Errors — Counts the number of errored frame alignment signal (FAS) subsets (subset of bytes A1 and A2) received since gaining initial frame synchronization.  |
| Section BIP Errors     | Section BIP Errors — Represents an error in the even parity Section BIP-8 (B1) byte when used as a parity check against the preceding STS-n frame. Up to 8 BIP errors may be counted per STS-n frame. Section BIP errors are only defined for the first STS-1 on an STS-n. |
| Section BIP Error Rate | Section BIP Error Rate — Represents the ratio of Section BIP Errors to the total number of received bits.  |
| Section BIP Error Sec  | Section BIP Errored Seconds — Counts the number of seconds in which one or more Section BIP errors occurred since test restart. The errored second interval is not synchronous to the occurrence of the BIP error.   |

**Table 25** — *SONET Section test results (continued)*

| Displayed Test Result | Description  |
|-----------------------|--|
| SEF Defect            | Severely Errored Frame Defects — Occurs when four contiguous errored frame alignment words (A1/A2 pair) are detected.                |
| Sect SES              | Section BIP Severely Errored Seconds — Represents an asynchronous test second in which 2500 or more Section BIP Errors were counted. |
| SEF Secs              | Severely Errored Frame Seconds — Represents an asynchronous test second in which a Severely Errored Frame was counted.               |

SONET Line Category

SONET Line overhead test results enable the 2310 to analyze the SONET Line of a network. The results are only available when a SONET option is installed. Select **SONET Pri/Sec** from the Result Group and **Line** from the Result Category for SONET Line test results.



**SONET Line test results**

The SONET Line Category test results are defined in Table 26.

**Table 26** — *SONET Line test results*

| Displayed Test Result | Description  |         |      |      |  |      |                     |      |                     |      |                         |      |                          |
|-----------------------|--|---------|------|------|--|------|---------------------|------|---------------------|------|-------------------------|------|--------------------------|
| APS Msg Count         | APS Message Count — Counts the number of transitions occurring in the switch priority field of the line overhead byte (K1), Bits1 - 4. This is an indication of protection switch activity; it is not a direct count of protection switches.   |         |      |      |  |      |                     |      |                     |      |                         |      |                          |
| APS Bridged Line      | APS Bridged Line — Provides the number of the channel bridged bits 1-4 onto the protection line. If 0, then no line is bridged to the APS line.  |         |      |      |  |      |                     |      |                     |      |                         |      |                          |
| APS Switch Mode       | APS Switching Mode — Displays the current protection switching mode.   |         |      |      |  |      |                     |      |                     |      |                         |      |                          |
|                       | <table> <tr> <th>K2 Bits</th><th>Mode</th></tr> <tr> <td>5678</td><td></td></tr> <tr> <td>0xxx</td><td>Provisioned for 1+1</td></tr> <tr> <td>1xxx</td><td>Provisioned for 1:n</td></tr> <tr> <td>x101</td><td>Bidirectional switching</td></tr> <tr> <td>x100</td><td>Unidirectional switching</td></tr> </table> | K2 Bits | Mode | 5678 |  | 0xxx | Provisioned for 1+1 | 1xxx | Provisioned for 1:n | x101 | Bidirectional switching | x100 | Unidirectional switching |
| K2 Bits               | Mode   |         |      |      |  |      |                     |      |                     |      |                         |      |                          |
| 5678                  |  |         |      |      |  |      |                     |      |                     |      |                         |      |                          |
| 0xxx                  | Provisioned for 1+1  |         |      |      |  |      |                     |      |                     |      |                         |      |                          |
| 1xxx                  | Provisioned for 1:n  |         |      |      |  |      |                     |      |                     |      |                         |      |                          |
| x101                  | Bidirectional switching  |         |      |      |  |      |                     |      |                     |      |                         |      |                          |
| x100                  | Unidirectional switching   |         |      |      |  |      |                     |      |                     |      |                         |      |                          |

**Table 26 — SONET Line test results (continued)**

| Displayed Test Result | Description   |         |                 |             |  |      |                       |      |               |      |                             |      |                            |      |                                |      |                               |      |            |      |               |      |            |      |                 |      |            |      |          |      |            |      |                 |      |               |      |            |             |                                       |      |              |           |                      |
|-----------------------|---|---------|-----------------|-------------|--|------|-----------------------|------|---------------|------|-----------------------------|------|----------------------------|------|--------------------------------|------|-------------------------------|------|------------|------|---------------|------|------------|------|-----------------|------|------------|------|----------|------|------------|------|-----------------|------|---------------|------|------------|-------------|---------------------------------------|------|--------------|-----------|----------------------|
| APS Request Msg       | <p>APS Request Message — Displays the current protection switch request message and channel as indicated by the line overhead byte (K1). Each message will have a Channel Number Code Assignment and a type of request.</p> <table> <tr> <th>K1 Bits</th><th>Type of Request</th></tr> <tr> <td><b>1234</b></td><td></td></tr> <tr> <td>1111</td><td>Lockout of Protection</td></tr> <tr> <td>1110</td><td>Forced Switch</td></tr> <tr> <td>1101</td><td>Signal Fail — High Priority</td></tr> <tr> <td>1100</td><td>Signal Fail — Low Priority</td></tr> <tr> <td>1011</td><td>Signal Degrade — High Priority</td></tr> <tr> <td>1010</td><td>Signal Degrade — Low Priority</td></tr> <tr> <td>1001</td><td>(not used)</td></tr> <tr> <td>1000</td><td>Manual Switch</td></tr> <tr> <td>0111</td><td>(not used)</td></tr> <tr> <td>0110</td><td>Wait-to-Restore</td></tr> <tr> <td>0101</td><td>(not used)</td></tr> <tr> <td>0100</td><td>Exercise</td></tr> <tr> <td>0011</td><td>(not used)</td></tr> <tr> <td>0010</td><td>Reverse Request</td></tr> <tr> <td>0001</td><td>Do Not Revert</td></tr> <tr> <td>0000</td><td>No Request</td></tr> <tr> <td><b>5678</b></td><td><b>Channel Number Code Assignment</b></td></tr> <tr> <td>0000</td><td>Null Channel</td></tr> <tr> <td>0001-1111</td><td>Actual number (1-15)</td></tr> </table> | K1 Bits | Type of Request | <b>1234</b> |  | 1111 | Lockout of Protection | 1110 | Forced Switch | 1101 | Signal Fail — High Priority | 1100 | Signal Fail — Low Priority | 1011 | Signal Degrade — High Priority | 1010 | Signal Degrade — Low Priority | 1001 | (not used) | 1000 | Manual Switch | 0111 | (not used) | 0110 | Wait-to-Restore | 0101 | (not used) | 0100 | Exercise | 0011 | (not used) | 0010 | Reverse Request | 0001 | Do Not Revert | 0000 | No Request | <b>5678</b> | <b>Channel Number Code Assignment</b> | 0000 | Null Channel | 0001-1111 | Actual number (1-15) |
| K1 Bits               | Type of Request   |         |                 |             |  |      |                       |      |               |      |                             |      |                            |      |                                |      |                               |      |            |      |               |      |            |      |                 |      |            |      |          |      |            |      |                 |      |               |      |            |             |                                       |      |              |           |                      |
| <b>1234</b>           |   |         |                 |             |  |      |                       |      |               |      |                             |      |                            |      |                                |      |                               |      |            |      |               |      |            |      |                 |      |            |      |          |      |            |      |                 |      |               |      |            |             |                                       |      |              |           |                      |
| 1111                  | Lockout of Protection   |         |                 |             |  |      |                       |      |               |      |                             |      |                            |      |                                |      |                               |      |            |      |               |      |            |      |                 |      |            |      |          |      |            |      |                 |      |               |      |            |             |                                       |      |              |           |                      |
| 1110                  | Forced Switch   |         |                 |             |  |      |                       |      |               |      |                             |      |                            |      |                                |      |                               |      |            |      |               |      |            |      |                 |      |            |      |          |      |            |      |                 |      |               |      |            |             |                                       |      |              |           |                      |
| 1101                  | Signal Fail — High Priority   |         |                 |             |  |      |                       |      |               |      |                             |      |                            |      |                                |      |                               |      |            |      |               |      |            |      |                 |      |            |      |          |      |            |      |                 |      |               |      |            |             |                                       |      |              |           |                      |
| 1100                  | Signal Fail — Low Priority  |         |                 |             |  |      |                       |      |               |      |                             |      |                            |      |                                |      |                               |      |            |      |               |      |            |      |                 |      |            |      |          |      |            |      |                 |      |               |      |            |             |                                       |      |              |           |                      |
| 1011                  | Signal Degrade — High Priority  |         |                 |             |  |      |                       |      |               |      |                             |      |                            |      |                                |      |                               |      |            |      |               |      |            |      |                 |      |            |      |          |      |            |      |                 |      |               |      |            |             |                                       |      |              |           |                      |
| 1010                  | Signal Degrade — Low Priority   |         |                 |             |  |      |                       |      |               |      |                             |      |                            |      |                                |      |                               |      |            |      |               |      |            |      |                 |      |            |      |          |      |            |      |                 |      |               |      |            |             |                                       |      |              |           |                      |
| 1001                  | (not used)  |         |                 |             |  |      |                       |      |               |      |                             |      |                            |      |                                |      |                               |      |            |      |               |      |            |      |                 |      |            |      |          |      |            |      |                 |      |               |      |            |             |                                       |      |              |           |                      |
| 1000                  | Manual Switch   |         |                 |             |  |      |                       |      |               |      |                             |      |                            |      |                                |      |                               |      |            |      |               |      |            |      |                 |      |            |      |          |      |            |      |                 |      |               |      |            |             |                                       |      |              |           |                      |
| 0111                  | (not used)  |         |                 |             |  |      |                       |      |               |      |                             |      |                            |      |                                |      |                               |      |            |      |               |      |            |      |                 |      |            |      |          |      |            |      |                 |      |               |      |            |             |                                       |      |              |           |                      |
| 0110                  | Wait-to-Restore   |         |                 |             |  |      |                       |      |               |      |                             |      |                            |      |                                |      |                               |      |            |      |               |      |            |      |                 |      |            |      |          |      |            |      |                 |      |               |      |            |             |                                       |      |              |           |                      |
| 0101                  | (not used)  |         |                 |             |  |      |                       |      |               |      |                             |      |                            |      |                                |      |                               |      |            |      |               |      |            |      |                 |      |            |      |          |      |            |      |                 |      |               |      |            |             |                                       |      |              |           |                      |
| 0100                  | Exercise  |         |                 |             |  |      |                       |      |               |      |                             |      |                            |      |                                |      |                               |      |            |      |               |      |            |      |                 |      |            |      |          |      |            |      |                 |      |               |      |            |             |                                       |      |              |           |                      |
| 0011                  | (not used)  |         |                 |             |  |      |                       |      |               |      |                             |      |                            |      |                                |      |                               |      |            |      |               |      |            |      |                 |      |            |      |          |      |            |      |                 |      |               |      |            |             |                                       |      |              |           |                      |
| 0010                  | Reverse Request   |         |                 |             |  |      |                       |      |               |      |                             |      |                            |      |                                |      |                               |      |            |      |               |      |            |      |                 |      |            |      |          |      |            |      |                 |      |               |      |            |             |                                       |      |              |           |                      |
| 0001                  | Do Not Revert   |         |                 |             |  |      |                       |      |               |      |                             |      |                            |      |                                |      |                               |      |            |      |               |      |            |      |                 |      |            |      |          |      |            |      |                 |      |               |      |            |             |                                       |      |              |           |                      |
| 0000                  | No Request  |         |                 |             |  |      |                       |      |               |      |                             |      |                            |      |                                |      |                               |      |            |      |               |      |            |      |                 |      |            |      |          |      |            |      |                 |      |               |      |            |             |                                       |      |              |           |                      |
| <b>5678</b>           | <b>Channel Number Code Assignment</b>   |         |                 |             |  |      |                       |      |               |      |                             |      |                            |      |                                |      |                               |      |            |      |               |      |            |      |                 |      |            |      |          |      |            |      |                 |      |               |      |            |             |                                       |      |              |           |                      |
| 0000                  | Null Channel  |         |                 |             |  |      |                       |      |               |      |                             |      |                            |      |                                |      |                               |      |            |      |               |      |            |      |                 |      |            |      |          |      |            |      |                 |      |               |      |            |             |                                       |      |              |           |                      |
| 0001-1111             | Actual number (1-15)  |         |                 |             |  |      |                       |      |               |      |                             |      |                            |      |                                |      |                               |      |            |      |               |      |            |      |                 |      |            |      |          |      |            |      |                 |      |               |      |            |             |                                       |      |              |           |                      |
| Line BIP Error Rate   | <p>Line BIP Error Rate — Represents the Line BIP Errors/Total number of received bits in the previous STS-n frame less the SOH. The denominator of the message is the total number of non-section received bits instead of the number of BIPs so that the result is used to approximate overall received bit error rate. This approximation works on the assumption that only 1 bit error occurs per SONET frame per bit position (1-8 or 1-24 for OC-3c/12c/48c).</p>  |         |                 |             |  |      |                       |      |               |      |                             |      |                            |      |                                |      |                               |      |            |      |               |      |            |      |                 |      |            |      |          |      |            |      |                 |      |               |      |            |             |                                       |      |              |           |                      |
| Line BIP Error Secs   | <p>Line BIP Error Seconds — Counts the number of seconds in which one or more Line BIP errors occurred since initial SONET frame synchronization. The errored second interval is not synchronous to the occurrence of the BIP error.</p>  |         |                 |             |  |      |                       |      |               |      |                             |      |                            |      |                                |      |                               |      |            |      |               |      |            |      |                 |      |            |      |          |      |            |      |                 |      |               |      |            |             |                                       |      |              |           |                      |

**Table 26 — SONET Line test results (continued)**


| Displayed Test Result | Description  |
|-----------------------|--|
| Line BIP Errors       | Line BIP Errors — Represents an error in the even parity line BIP-8 (B2) byte when used as a parity check against the preceding STS-1 frame less the SOH. Up to 8 BIP errors may be counted per STS-1 frame. Line BIP errors are defined for all STS-1s on an STS-n. In OC-3c/12c/48c mode, three line BIPs from each STS-1 are treated as one 24 bit BIP, and hence, up to 24 BIP errors may be counted per OC-3c frame.                                      |
| Line SES              | Line BIP Severely Errored Seconds — Counts the number of seconds in which more than 2500 Line BIP errors occurred in 1 second for an STS-1, OC-1, or OC-3 signal; or more than 10,000 errors occurred for an OC-12 signal.   |
| Line Unavailable Secs | Line Unavailable Seconds — Counts the number of seconds in which the line is not available based on counts of consecutive line severely errored seconds, or the presence of an AIS alarm.  |
| Line AIS Seconds      | Line Alarm Indication Signal Seconds — Represents any asynchronous test second in which Line AIS was present for any portion of the test second.   |
| Line FEBEs            | Line Far-End Block Errors — Occurs if a FEBE count is present in the Z2 byte.  |
| Line FEBE Rate        | Line Far-End Block Rate — Represents the ratio of line FEBEs to total number of received bits in the previous STS-n frame, less the SONET overhead.  |
| Path Ptr Just         | Path Pointer Justifications — Counts the number of times the synchronous payload envelope (SPE) pointer changed since initial SONET frame synchronization.   |
| Path Ptr Incs         | Path Pointer Increments — Counts the number of times the pointer bytes (H1 and H2) indicated an increment to the path payload pointer since initial SONET frame synchronization.   |
| Path Ptr Decs         | Path Pointer Decrements — Counts the number of times the pointer bytes (H1 and H2) indicated a decrement to the path payload pointer since initial SONET frame synchronization.  |
| Path Ptr NDFs         | Path Pointer New Data Flags — Counts the number of times the pointer bytes (H1 and H2) indicated an active new data flag (arbitrary change in pointer) since initial SONET frame synchronization. An active NDF occurs during a change in payload content, or after an AIS or some other failure condition. If a change in the pointer is detected for three consecutive frames, the change is counted as an NDF, even if the pointer never has an active NDF. |

Table 26 — SONET Line test results (continued)

| Displayed Test Result | Description  |
|-----------------------|--|
| Path Ptr Value        | Path Pointer Value — Presents the current STS path pointer value from 0 to 782. <i>UNAVAILABLE</i> appears under a number of error conditions, such as line AIS, etc. <i>OUT OF RANGE</i> appears if the pointer value is outside 0 to 782.                      |
| Path Ptr Size         | Path Pointer Size Bits — Indicates the binary setting of the size bits in the SONET H1 byte. The normal setting for the pointer size bits is 00 to indicate a SONET payload. If the received bits are other than 00, the result appears in the SUMMARY category. |

SONET Path Category

Select **SONET Pri/Sec** from the Result Group and **Path** from the Result Category for SONET Path test results.





**SONET Path test results**

The SONET Path Category test results are defined in Table 27.

**Table 27 — SONET Path test results**


| Displayed Test Result | Description  |
|-----------------------|--|
| Path BIP Errors       | Path BIP Errors — An error in the even parity Path BIP-8 (B3) byte when used as a parity check against the preceding STS-1 frame less the SOH and LOH. Up to 8 BIP errors may be counted per STS-1 frame. Path BIP errors are defined for all STS-1s on an STS-n. In OC-3c/12c/48c mode, the 3 Path BIPs from each STS-1 are treated as one 24 bit BIP and hence up to 24 BIP errors may be counted per OC-3c/12c/48c frame. |
| Path BIP Error Rate   | Path BIP Error Rate — Derived from the number of times in which the Path BIP byte (B3) indicates an error in the previous frame since initial SONET frame synchronization. Path BIP Errors are divided by the total number of received bits in the previous STS-n frame less the SOH and LOH.  |
| Path BIP Error Secs   | Path BIP Errored Seconds — Counts the number of seconds in which one or more Path BIP errors occurred since initial SONET frame synchronization. The errored second interval is not synchronous to the occurrence of the BIP error.  |
| Path SES              | Path BIP Severely Errored Seconds — Counts the number of seconds in which 2500 or more Path BIP errors occurred since initial SONET frame synchronization.   |
| Path Unavail Secs     | Path Unavailable Seconds — Counts the number of seconds in which the path is considered unavailable. It is an asynchronous test second in which a Path BIP Severely Errored Second was counted or Path AIS was present for any portion of the test second.   |
| Path AIS Secs         | Path Alarm Indication Signal Seconds — Represents an asynchronous test second in which Path AIS was present for any portion of the test second.  |
| Path AIS/LOP Secs     | Path Alarm Indication Signal/Loss Of Pointer Seconds — Counts the number of seconds in which one or more Path AIS or LOP occurs.   |
| Path LOP Secs         | Path Loss Of Pointer Seconds — Shows asynchronous test seconds in which a Path LOP was present for any portion of the test. ...  |
| Path FEBEs            | Path Far-End Block Errors — Represents the FEBE count present in the Z2 byte. Up to 8 FEBEs errors may be counted per STS-1 frame.   |

Table 27 — SONET Path test results (continued)

| Displayed Test Result | Description   |
|-----------------------|---|
| Path FEBE Rate        | Path Far-End Block Rate — Represents the ratio of FEBEs to (1) the number of bits over which C-bit parity was calculated.   |
| STS-1 Signal Label    | STS Path Signal Label — Presents the payload type being carried in the current position of the current STS. The information is derived from the Path signal label (C2) and VT overhead (V5) bytes. Any C2/V5 combinations which cannot be decoded appear as UNRECOGNIZED. |

SONET Path Trace Category

SONET Path Trace enables one of three default or user-defined messages to be transmitted over the path trace byte (J1) of the inserted STS-1 signal. Select **SONET Pri/Sec** from the Result Group and **Path Trace** from the Result Category for test results.



## SONET Path Trace test results

The SONET Path Trace Category test results are defined in Table 28.

Table 28 — SONET Path Trace test results

| Displayed Test Result | Description   |
|-----------------------|---|
| Path Trace            | Path Trace Message — Displays the 64-byte path trace ASCII message which is carried in the path overhead byte (J1).   |
| STS Path Signal Label | STS Path Signal Label — Presents the payload type being carried in the current position of the current STS. The information is derived from the Path signal label (C2) and VT overhead (V5) bytes. Any C2/V5 combinations which cannot be decoded appear as UNRECOGNIZED. |

## SONET VT Category

The SONET Virtual Tributary overhead test results enable the 2310 to analyze the SONET VT of a network. The results are only available when a SONET option is installed. Select **SONET Pri/Sec** from the Result Group and **VT** from the Result Category for SONET VT test results.

Result  
Group

| SONET Pri | VT         |
|-----------|------------|
| Res       | Summary    |
| Unav      | LED        |
|           | Signal     |
|           | Section    |
|           | Line       |
|           | Path       |
|           | Path Trace |
|           | VT         |
|           | Time       |

Result  
Category

**SONET VT test results**

The SONET VT Category test results are defined in Table 29.

**Table 29 — SONET Virtual Tributary Overhead test results**


| Displayed Test Result | Description   |
|-----------------------|---|
| VT BIP Errors         | Virtual Tributary Bit Interleaved Parity (BIP) Errors — Counts the number of times in which the VT BIP byte (V5, Bits 1 and 2) indicates an error in the received signal. A maximum of two VT BIP errors can be counted in each SONET frame.                    |
| VT BIP Error Rate     | Virtual Tributary BIP Error Rate — Represents the ratio of VT BIP errors to the total of received bits in the previous VT frame.  |
| VT BIP Error Secs     | Virtual Tributary BIP Errored Seconds — Counts the number of seconds in which one or more VT BIP errors, an AIS, or VT LOP occurred.  |
| VT SES                | Virtual Tributary BIP Severely Errored Seconds — Counts the number of seconds in which 600 or more VT BIP errors occurred during a single second.   |
| VT AIS/LOP Secs       | Virtual Tributary Alarm Indication Signal/Loss Of Pointer Seconds — Counts the number of seconds in which one or more VT AIS or LOP occurs.   |
| VT AIS Secs           | Virtual Tributary Alarm Indication Signal Errored Seconds— Counts the number of seconds in which one or more VT AIS occurs.   |
| VT LOP Secs           | Virtual Tributary Loss Of Pointer Errored Seconds — Counts the number of seconds in which one or more VT LOP occurs.  |
| VT Unavail Secs       | Virtual Tributary Unavailable Seconds — Counts the number of seconds in which the VT path is unavailable. It is an asynchronous test second in which a Path BIP Severely Errored Second was counted or Path AIS was present for any portion of the test second. |
| VT FEBE               | Virtual Tributary FEBE — Counts the number of VT BIP errors detected by the downstream PTE. It is calculated by summing the FEBE counter of the path status byte (V5, Bit 3) from each received VT superframe.  |
| VT FEBE Rate          | Virtual Tributary FEBE Rate — Represents the ratio of VT FEBEs to the total number of received bits in the previous VT frame.   |
| VT Ptr Just           | Virtual Tributary Pointer Justifications — Represents the occurrence of a VT pointer increment, a VT pointer decrement, or a VT pointer NDF.  |

**Table 29** — *SONET Virtual Tributary Overhead test results (continued)*

| Displayed Test Result | Description   |
|-----------------------|---|
| VT Ptr Incs           | Virtual Tributary Pointer Increments — Represents an increment of 1 in the SPE pointer that is recognized when a majority vote of the 5 D bits in the V1, V2 bytes indicate an inversion.                                   |
| VT Ptr Decs           | Virtual Tributary Pointer Decrements — Represents a decrement of 1 in the SPE pointer that is recognized when a majority vote of the 5 D bits in the V1, V2 bytes indicate an inversion.                                    |
| VT Ptr NDFs           | Virtual Tributary Pointer New Data Flags — Occurs when the presence of an NDF is recognized by an invert of the 4 N Bits in the V1, V2 bytes, or when the presence of an new SPE pointer persists for 3 consecutive frames. |
| VT Ptr Value          | Virtual Tributary Pointer Value — Presents the current VT pointer value from 0 to 103. Out Of Range appears if the pointer value is outside 0 to 103.   |

## SONET ATM Category

SONET ATM successfully tests the OC-3c/12c ATM circuit by generating an ATM (cell) stream containing test cells and analyzes the received ATM cell stream. Select **ATM** from the Result Group and the appropriate category from the Result Category for SONET VT test results.



### SONET ATM VPI/VCI test results

ATM cell streams have the following ATM test results associated with each VPI/VCI, as defined in Table 30.

Table 30 — ATM VPI/VCI Stats, Cell, and Cell Type Category results

| Displayed Test Results | Description   |
|------------------------|---|
| VPI, VCI % Utilization | Measures percentage of all active (non-idle) cells with selected VPI/VCI combinations.                        |
| VPI, VCI Kbps Util     | Measures approximate bandwidth in kilobits per second of all active cells with selected VPI/VCI combinations. |
| Total % Utilization    | Measures percentage of all active cells.  |
| Total Kbps Util        | Measures approximate bandwidth in kilobits per second of all active cells in the payload.                     |
| HEC Errors             | Counts cells with at least one HEC error, available after cell synchronization.                               |


**Table 30 — ATM VPI/VC1 Stats, Cell, and Cell Type Category results (continued)**

| Displayed Test Results | Description  |
|------------------------|--|
| Dropped Cells          | Counts the dropped test cells. The result is only available when TTC test cells are received (Type 1 or greater).  |
| Out-Of-Seq Cells       | Counts all out-of-sequence cells of TTC ATM cells being received for which the sequence number is out of order. The result is only available when a TTC profile is received. |
| Misinserted Cells      | Counts all cells with the selected VPI/VC1 that do not have the TTC test cell payload. The result is only available when TTC cells are received.                             |
| Correlation Tag        | Indicates the current received TTC test cell correlation tag number. The result is only available when TTC test cells are received.  |
| Cell Type              | Indicates the current type of TTC ATM cells being received. The result is only available when TTC test cells are received.   |
| Mask Cells             | Counts cells received that match Rx Profile selection.   |
| Active Cells           | Counts the not-idle cells in the received ATM cell stream.   |

Channel Category

Results for tone analysis and tone noise analysis measurements are presented below. The VF measurements are categorized into the following result types:

Select the appropriate rate from the Result Group and **Channel** from the Result Category for Channel VF and DDS test results.



Channel VF and DDS test results

The Channel VF and DDS Category test results are defined in Table 31.

Table 31 — Channel VF and DDS Category test results

| Displayed Test Result | Description   |
|-----------------------|---|
| Received Byte         | DDS Received Byte — Displays a sampling of the received 8-bit byte of the selected channel. If the received byte is recognized as a control code, the control code name is displayed in the RCODE result. |
| Frequency Hz          | Voice Frequency — Represents the frequency (Hz) of a VF tone within a selected DS0 channel.   |
| Level dBm             | Voice Frequency Level — Represents the level (dBm) of a VF tone within a selected DS0 channel.  |



**Table 31** — *Channel VF and DDS Category test results (continued)*

| Displayed Test Result | Description  |
|-----------------------|--|
| 3.4K Flat dBrn        | 3.4 kHz Flat Noise — Measures the noise (dBrn) weighted with a 3 kHz flat filter. Used when qualifying data-grade circuits.  |
| 3.4K Notch dBrn       | Notch Noise — Measures the noise (dBrn) against a weighted 3 kHz flat filter. A transmitted 1004 Hz tone is filtered out prior to the measurement for analog data-grade analysis. This measurement includes quantization noise caused by analog/digital conversion in the CODEC. |
| Cmsg dBrnC            | C-Message Noise — Measures the noise (in dBrnC) weighted with a C-Message filter for voice-grade analysis. This measurement determines the noise on an idle channel.   |
| Cnotch dBrnC          | C-Message Notch Noise — Measures the noise (in dBrnC) against a weighted C-message filter. A transmitted 1004 Hz tone is filtered out prior to the measurement for voice-grade analysis.   |
| Snr dB                | Signal-to-Noise Ratio — Represents the signal-to-noise ratio of the received signal, assuming a 1004 Hz tone is inserted from an external source.  |
| Holding Tone Loss     | Holding Tone Loss — Occurs when a transmitted 1004 Hz tone is not detected.  |
| DDS Control Code      | DDS Control Code — Displays the name of the received DS0 code identified in the DDS Receive Byte (see Table 32).   |

## Reportable DS0 Control Codes

The Reportable DS0 Control Codes are defined in Table 32.

**Table 32** — *Reportable DS0 Control Codes*

| Code ID | Control Byte | Description   |
|---------|--------------|---|
| ASC     | x001 1110    | Abnormal Station Code. Generated by the OCU due to a signal loss from the DSU/CSU, the DSU/CSU isn't attached, or a faulty OCU. |
| C IDLE  | x111 1110    | Control Mode Idle. Equivalent to RTS set to OFF. Neither the customer nor the network is using the channel.                     |
| CHAN    | x010 1000    | Alternating Channel (CSU) Loopback.   |
| D IDLE  | x111 1111    | Data Mode Idle. Equivalent to RTS set to ON, but no data is being sent by the computer.   |
| DSU     | x010 1100    | Alternating DSU Loopback.   |
| FEV     | x101 1010    | Far End Voice Byte. Last (Fourth) byte sent in latching loop up sequence.   |
| LBE     | x101 0110    | Loopback Enable. Third byte sent in the latching loop up sequence.  |
| MA      | x111 0010    | MJU Alert Code. Second byte sent during an MJU loop up sequence.  |
| MAP0    | x001 0011    | MAP 0 Confirmation Code (line/T1 side). Sent by the second DS0-DP being looped.   |
| MAP1    | x110 1101    | MAP 1 Confirmation Code (drop/DS0 side). Sent by the first DS0-DP being looped.   |
| MOS     | x001 1010    | Multiplexer Out of Synchronization. Sent by SRMU when it loses subrate frame synchronization.                                   |
| OCU     | x010 1010    | Alternating OCU Loopback.   |
| RELEASE | x111 1000    | MJU Release Code.   |
| TA      | x110 1100    | Test Alert. First byte sent during an MJU loop up sequence.   |
| TEST    | x001 1100    | Test Code. Sent in opposite direction during loop up.   |
| TIP     | x011 1010    | Transition In Progress. First byte sent during a DDS latching loop up sequence. Also sent for DDS latching loop down.           |

**Table 32 — Reportable DS0 Control Codes (continued)**

| Code ID | Control Byte | Description  |
|---------|--------------|--|
| UMC     | x001 1000    | Unassigned Multiplexer Channel. Sent by DS0-DP when no OCU-DP installed in channel bank. |

† x = a substrate framing bit when the byte is transmitted or received as a DS0B signal. Framing bit pattern determined by DS0B data rate.

† x = a *don't care* mode when the byte is received at a DS0A substrate.

† x = a 1 when the byte is transmitted at a DS0A substrate.

† x = a 0 when control codes (except IDLE) are transmitted at DS0A 56 Kb/s rate.


† x = a *don't care* mode when control codes (except IDLE) are received at DS0A 56 kb/s rate.

† x = a 1 when the IDLE code is transmitted or received at DS0A 56 kb/s rate.

## Call Signal Category

Results for the Call Signal Category provide a means to scan signaling bit transitions on all channels of a duplex T1 circuit.

Select the appropriate rate from the Result Group and **Call Sig** from the Result Category for Call Signal test results.



**Call Signal test results**


The Call Signal Category test result types are defined in Table 33.

**Table 33** — *Call Signal Category test results*

| Displayed Test Result | Description   |
|-----------------------|---|
| Signaling Delay       | Measures the delay between the conclusion of the previous signaling event/digit and the start of the current signaling event/digit under examination. This result is applicable to all signaling events/digits in the chronological sequence except the first event/digit in the sequence.  |
| Signaling Duration    | Measures the duration of certain signaling events and all digits in the chronological sequence. This result is applicable for all interpretable digits received, and the signaling events ring, wink, and dial tone. This result is measured in milliseconds. Any result whose value is above 9999 milliseconds (~10 seconds) will be flagged as greater than 10 seconds. |

## Traffic Category

Results for the Traffic Category provide a means to scan signaling bit transitions on all channels of a duplex T1 circuit. Select the appropriate rate from the Result Group and **Traffic** from the Result Category for Traffic test results.



### Traffic Category test results

The Traffic Category test result type is defined in Table 34.


**Table 34** — Traffic Category test results

| Displayed Test Result | Description   |
|-----------------------|---|
| Signaling Bits        | Provides the current ABCD signaling bits for either the Primary or Secondary receivers. This result is available during all T1 signaling tests with T1 frame synchronization. This result is measured as a group. |

# Logic Category

Logic errors are based on discrepancies between the transmitted and received bit stream. The accumulation of logic errors is dependent on frame synchronization (if in a framed mode) and pattern synchronization. Logic errors are not available until initial pattern synchronization is obtained. The results are also not available when sending loop codes. During loss of frame or pattern synchronization, the accumulation of errors is halted.

Select the appropriate rate from the Result Group and **Logic** from the Result Category for Logic test results.



## DS1, DS3, and SONET Logic test results

As the received signal is recognized, the appropriate test result displays in the message window. All three rates (DS1/DS3/SONET) share the same test result messages. Therefore, the Logic Category test results are defined in Table 35.

Table 35 — DS1, DS3, and SONET Logic test results


| Displayed Test Result | Description   |
|-----------------------|---|
| Pattern Losses        | Pattern Losses — The number of times the received pattern is lost relative to the expected (i.e., internally generated) test pattern. |

**Table 35 — DS1, DS3, and SONET Logic test results (continued)**

| Displayed Test Result | Description   |
|-----------------------|---|
| Pattern Slips         | Pattern Slips — The number of times the received pattern becomes skewed relative to the expected (i.e., internally generated) test pattern. When a slip is detected, the 2310 automatically re-synchronizes to the received pattern. However, pattern bit errors are not suppressed during this process. Pattern slips are available only when using pseudorandom patterns. |
| Bit Errors            | Bit Errors — The number of received pattern bits which have a value opposite that of the corresponding transmitted bit pattern since initial pattern synchronization.   |
| Bit Error Rate        | Bit Error Rate — The ratio of pattern bit errors to received pattern bits since initially acquiring pattern synchronization.  |
| Sync Loss Secs        | Out-of-Synchronization Loss Seconds — The number of seconds during which the receiver has lost pattern synchronization, even momentarily, since initial pattern synchronization.  |
| Error Secs            | Errored Seconds — The number of seconds during which one or more pattern bit errors occurred since initial pattern synchronization.   |
| Error-Free Secs       | Error-Free Seconds — The number of seconds during which no pattern bit errors are detected while DS1 pattern synchronization is present.  |
| % Error-Free Secs     | Percentage of Error-Free Seconds — The ratio, expressed as a percentage, of seconds during which no pattern bit errors were detected, to the total number of seconds while pattern synchronization is present.  |

# Time Category

The TIME category lists current date, time, and timed results for DS1, DS3, and SONET. Select the appropriate rate from the Result Group and **Time** from the Result Category for Time test results.



**Time Category test results**      The Time category results are defined in Table 36.

**Table 36** — *Time Category test results*

| Displayed Test Result | Description   |
|-----------------------|---|
| Time                  | Current Time of Day — The current time of day in hours, minutes, and seconds. The time is set through the FILE CABINET Softkey. |
| Date                  | Current Date — The current day and month. The date is set through the FILE CABINET Softkey.                                     |
| Elapsed Time          | Elapsed Time — The elapsed time in hours, minutes, and seconds since the last test restart.                                     |



## GR-303 Category

The GR-303 category Level-2 Protocol Link and Level-3 call-statistical test results are conducted non-intrusively on the protocol link. Set the Result Group to **T1 Pri** and the Category buttons to **Link Stats** on the left and **Call Stats** on the right.

Result  
Group

| T1 Pri  | Link Stats | T1 Pri  | Call Stats |
|---|------------|---|------------|
| Packets<br>117  |            | Call Attempts<br>101                            |            |
| Packets<br>Info Packets<br>RR Packets<br>RNR Packets<br>Reject Packets<br>CRC Err Packets<br>Discarded Packets<br>Packet Error Sec<br>Packet Error Rate |            | Call Attempts<br>Call Connects<br>Call Releases |            |

Result  
Category

### GR-303 Level-2 test results

GR-303 Level-2 Protocol Link test results are defined in Table 37.

**Table 37** — GR-303 Level-2 Protocol Link test results

| Displayed Test Results | Description   |
|------------------------|---|
| Packets                | Packets — Counts all error-free packets with a user-specified SAPI/TEI detected since test restart. If no SAPI/TEI is specified, all packets are counted. |
| CRC Err Packets        | CRC Errored Packets — Counts packets with CRC errors detected since test restart. The 2310 cannot count packets for a specific SAPI/TEI.                  |
| Packet Error Sec       | Packet Errored Seconds — Counts errored seconds with at least one CRC errored packet.   |

**Table 37 — GR-303 Level-2 Protocol Link test results (continued)**

| Displayed Test Results | Description   |
|------------------------|---|
| Packet Error Rate      | Packet CRC Error Rate — Counts CRC errored packets divided by the sum of total valid packets recognized (Packets + Discarded Packets + any others with a valid SAPI/TEI combination for a GR-303 system) + CRC Err Packets detected since test restart.   |
| Discarded Packets      | Discarded Packets — Counts discarded packets since test restart. Discarded packets include packets with seven successive ones (aborts), terminating flag misalignments, sizes that are not a multiple of 8 bits, as well as packets that are too long, too short, or are outside of the bounds of legitimacy.   |
| Info Packets           | Information Packets — Counts error-free Information packets with a user-specified SAPI/TEI detected since test restart. If no SAPI/TEI is specified, all information packets are counted.   |
| RR Packets             | Receiver-Ready Packets — Counts error-free, Receiver-Ready packets with a user-specified SAPI/TEI detected since test restart. If no SAPI/TEI is specified, all RR packets are counted. RR packets act as a “keep-alive” for the protocol link.   |
| RNR Packets            | Receiver-Not-Ready Packets — Counts error-free, Receiver-Not-Ready packets with a user-specified SAPI/TEI detected since test restart. If no SAPI/TEI is specified, all RNR packets are counted.  |
| Reject Packets         | Reject Packets — Counts error-free Reject packets with a user-specified SAPI/TEI detected since test restart. If no SAPI/TEI is specified, all Reject packets are counted.  |
| Link Ready             | Link Ready Status — Indicates the virtual LED link activity (active/not active). The link is considered “ready” if an Unnumbered Acknowledgement (UA) response or a Receiver-Ready (RR) packet is received. The link is considered “not ready” if a Disconnect Mode (DM) response or a Receiver-Not-Ready (RNR) packet is received, or if the carrier signal is lost for that link. |

**GR-303 Level-3 test results**

GR-303 Level-3 call-statistical test results from the TMC/CSC are described in Table 38.

**Table 38 — GR-303 Level-3 call statistical test results**

| Displayed Test Results | Description   |
|------------------------|---|
| Call Attempts          | Counts all call attempts (Setup messages) since test restart. The receipt of each Setup message triggers an increment of one in this count.                             |
| Call Connects          | Counts all calls connected (Connect messages) since test restart. The receipt of each Connect message triggers an increment of one in this count.                       |
| Call Releases          | Counts all calls released since test restart due to a user-specified Cause Value (or ANY, if specified). Each released call triggers an increment of one in this count. |
| % Blocked Calls        | Represents the ratio of released calls, due to a cause value of 34 (Channel Unavailable), to total calls attempted since test restart.                                  |

**GR-303 Cause Codes**

GR-303 Cause Codes are described in Table 39.

**Table 39 — GR-303 Cause Codes**

| Displayed Cause Code | Description                |
|----------------------|----------------------------|
| 16                   | Normal clearing            |
| 27                   | Destination out of service |
| 30                   | Response to STATUS ENQUIRY |
| 34                   | Channel unavailable        |
| 41                   | Temporary failure          |
| 44                   | Line unit unavailable      |
| 47                   | Ring failure               |

**Table 39 — GR-303 Cause Codes**

| Displayed Cause Code | Description                           |
|----------------------|---------------------------------------|
| 81                   | Invalid call reference                |
| 96                   | Mandatory information element missing |
| 97                   | Message unimplemented                 |
| 99                   | Information element unimplemented     |
| 100                  | Invalid information element contents  |
| Default (any)        | Unspecified cause value!              |

## PRI ISDN Category

Test results for the Primary Rate ISDN option are displayed in the Terminate mode. There are two types of ISDN results: Physical Interface (T1, DS3, and STS-1)-Relative and Call-Relative.

### PRI ISDN test results

Table 40 lists the test Results Categories for the Primary Rate ISDN option.

**Table 40** — ISDN PRI category descriptions

| Category   | Description  |
|--|--|
| Summary Category (Primary/<br>Secondary Result Group)  | LAPD Multi-Frame Loss  |
|  | Call Fail Count  |
|  | LAPD Protocol Errors   |
| LED Category   | D channel Ready — Presented as a square LED to indicate the datalink is established and ready for call control. (Pri/Sec)  |
|  | Call Connected — Presented as a square LED to indicate a call connected for PRI Call 1 or PRI Call 2.  |
|  | Call Failure — Presented as a round LED to indicate PRI Call 1 or PRI Call 2 has been cleared with a cause other than "normal." Check Call History.  |
| ISDN Stats<br>Layer 2 Category (Primary/<br>Secondary) | Frame Count — Counts total number of valid LAPD frames received.   |
|  | Errored Frames — Counts valid frames with one or more of the following errored conditions: undefined control fields, "S" or "U" frame with incorrect length, or "I" frame with a long information field. |
|  | Invalid Frames — Counts frames with FCS errors or invalid SAPI.  |
|  | Aborted Frames — Counts aborted LAPD frames detected (excluding Out-of-Frame aborts) count.  |
|  | Reject Frames — Counts LAPD reject frames.   |
|  | Frame Reject Frames — Counts LAPD frame reject frames.   |


**Table 40 — ISDN PRI category descriptions (continued)**

| Category                             | Description   |
|--------------------------------------|---|
| History Category (Call 1 and Call 2) | Call Failure — Stores up to 12 call attempts (including normal and abnormal call clears). |


If a problem with the ISDN PRI line arises, but the physical T1 is working correctly, Cause Codes that are found in these messages become valuable information for understanding where the fault lies. For statistics about the physical T1, select **T1 PRI** or **T1 SEC**. For call specific results, such as frame statistics and LAPD statistics for the D channel, select **PRI Call 1** or **PRI Call 2**.

In the instance where there are problems completing calls or something goes wrong during the transmission, the History Category gives Cause Codes to explain where the problem may lie.

**Associated Signaling**



**NFAS and NFAS/DCBU**



## PRI ISDN Cause Codes

Table 41 provides the information between the Cause Code and the Cause Messages that are displayed in the Message/Status window. The Cause Message is shown when the call placed between the PBX and the Network fails.

**Table 41 — Cause Codes descriptions**

| Cause Code # | Cause Message — Q.931 Cause Codes (1988)              |
|--------------|---|
| 1            | Unassigned number.                                    |
| 2            | No route to specified transit network.                |
| 3            | No route to destination.                              |
| 6            | Channel unacceptable.                                 |
| 7            | Call awarded and delivered in an established channel. |
| 16           | Normal call clearing.                                 |
| 17           | User busy.  |
| 18           | No user responding.                                   |
| 19           | No answer from user (user alerted).                   |
| 21           | Call rejected.  |
| 22           | Number changed.                                       |
| 26           | Non-selected user clearing.                           |
| 27           | Destination out of order.                             |
| 28           | Invalid number format.                                |
| 29           | Facility rejected.                                    |

**Table 41 — Cause Codes descriptions (continued)**

| <b>Cause Code #</b> | <b>Cause Message — Q.931 Cause Codes (1988)</b>      |
|---------------------|--|
| 30                  | Response to STATUS INQUIRY.                          |
| 31                  | Normal, unspecified.                                 |
| 34                  | No circuit/channel available.                        |
| 41                  | Temporary failure.                                   |
| 42                  | Switching equipment congestion.                      |
| 43                  | Access information discarded.                        |
| 44                  | Requested circuit/channel not available.             |
| 47                  | Resources unavailable, unspecified.                  |
| 50                  | Requested facility not subscribed.                   |
| 57                  | Bearer capability not presently authorized.          |
| 58                  | Bearer capability not available.                     |
| 63                  | Service or option not available, unspecified.        |
| 65                  | Bearer capability not implemented.                   |
| 69                  | Requested facility not implemented.                  |
| 79                  | Service or option not implemented, unspecified.      |
| 81                  | Invalid call reference value.                        |
| 88                  | Incompatible destination.                            |
| 96                  | Mandatory information element is missing.            |
| 97                  | Message type non-existent or not implemented.        |
| 99                  | Information element non-existent or not implemented. |



**Table 41 — Cause Codes descriptions (continued)**

| <b>Cause Code #</b> | <b>Cause Message — Q.931 Cause Codes (1988)</b> |
|---------------------|---|
| 100                 | Invalid information element contents.           |
| 101                 | Message not compatible with call state.         |
| 102                 | Recovery on timer expiry.                       |
| 111                 | Protocol error, unspecified.                    |
| 127                 | Internetworking                                 |

### National-specific Cause Codes

Table 42 indicates National-specific cause values.

**Table 42 — National-specific Cause Codes**

| <b>Cause Code #</b> | <b>Cause message — (Defined in TA-NWT-001268)</b> |
|---------------------|---|
| 4                   | Vacant code.                                      |
| 8                   | Prefix 0 dialed in error.                         |
| 9                   | Prefix 1 dialed in error.                         |
| 10                  | Prefix 1 not dialed.                              |
| 11                  | Excessive digits received, Call is proceeding.    |

## Quad Results

Quad Results is a results function that displays up to four embedded signal rates at once in the Results Window of the 2310. For example, by pressing the Quad Results icon, you could monitor a STS-1 signal with a DS3 mapped payload, a T1 signal, and measure the VF tone within a specific DS0, in both the Primary and Secondary directions (if the Dual Rx option is installed).

### Quad customized test results

Quad Results contain a pre-defined list of results called Custom Results. Table 43 lists the Custom Results that apply for each line rate as they appear on the Custom Results property sheets. For definitions on any of the results, look in the appropriate results section of this manual.

**Table 43 — Custom Results for DS0, T1, DS3, and SONET**

| DS0 Rate          | T1 Rate          | DS3 Rate          | SONET Rate      |
|-------------------|------------------|-------------------|-----------------|
| Receive Byte      | Rx Level dBdsx   | Level dBdsx       | STS-1 Rx Freq   |
| VF Level dB       | Rx Level Vpp     | Level dBm         | OC-n Rx Freq    |
| VF Frequency      | Rx Frequency     | Rx Frequency      | Path PTR Just   |
| DDS Control Codes | Timing Slips     | BPV Errors        | Path BIP Errors |
|                   | Error Secs       | BPV Rate          | Sec BIP Errors  |
|                   | Bit Errors       | BPV Err Secs      | Line BIP Errors |
|                   | Bit Error Rate   | Frame Errors      |                 |
|                   | BPVs             | Frame Error Rate  |                 |
|                   | BPV Rate         | Parity Errors     |                 |
|                   | BPV Err Secs     | Parity Error Rate |                 |
|                   | Frame Errors     | DS2 Frame Error   |                 |
|                   | Frame Error Rate | DS2 Fr Err Rate   |                 |

**Table 43** — *Custom Results for DS0, T1, DS3, and SONET (continued)*

| DS0 Rate | T1 Rate         | DS3 Rate         | SONET Rate |
|----------|-----------------|------------------|------------|
|          | Frame Loss Secs | Bit Errors       |            |
|          |                 | Bit Error Rate   |            |
|          |                 | C-Bit Errors     |            |
|          |                 | C-Bit Error Rate |            |
|          |                 | FEBE's           |            |
|          |                 | FEBE Rate        |            |
|          |                 | Err Secs         |            |

**Using Quad results**

The Quad Results icon is applicable in all applications and tests. To engage, first use any of the test procedures described in Chapter 3, Common Applications. After you have selected the type of test and rate, you are now ready to apply the Quad Results feature. Pressing the Quad icon automatically configures the application-specific results for which you are testing to the Quad Results screen.

**Configuring the 2310 for Quad results**

To access Quad results

- 1 On the menu bar, press **Quad**. The Quad Results screen automatically displays (see Figure 47). The results setup is

automatically configured to the application in which you are testing.





Figure 47 — Sample Quad Results screen on 2310

- 2 Press **Setup** to enable the Custom Results tab associated with the applications to display, as shown in Figure 48.



Pressing Setup from the Quad Results Screen prompts the Custom Results property sheet to display.

Figure 48 — Custom Results property sheet

- 3 Select the appropriate **Rate** and **Category** in the Custom Quad Setup Information box. If you press the **Setup** action button here, a selection screen that pertains to that signal rate allows you to enable or disable results.

- 4 Choose the appropriate settings as in the examples shown in Figure 49.

Pressing Setup in the Custom Quad Setup Information box enables detailed parameter sheets to display. Set your parameters for each Rate and Category.




Figure 49 — Custom Results enable/disable property sheets

As stated previously, the available test results depend on the installed options. Categories where all results are unavailable display the message Unavailable.

# Customer Services

This chapter describes the customer services available through Acterna, formerly TTC and WWG. Topics discussed in this chapter include the following:

- “Customer service locations” on page 236
- “Instrument services” on page 237
- “Product Enhancement Group” on page 238
- “Test systems field engineering and installation” on page 238
- “Technical training” on page 239
- “Warranty information” on page 240
- “Equipment return instructions” on page 242

## About our services

Acterna offers unmatched services to support purchased equipment, including a wide range of customer care, technical support, instrument maintenance, and training services. Acterna customer service specialists are fully trained to help customers find the answers they are looking for. Call Customer Services for the following:

- Information on products and services, including upgrades, calibration, training, software enhancement agreements (SEAs), and product maintenance agreements. Our representatives can also provide assistance with product returns and repairs.
- Expert technical support, including help with product configuration, circuit qualification, and complete network trouble sectionalization. Acterna is also available on a contractual basis to provide customized application development, network consulting and management services, software customization, and test procedure development.

All Acterna products are backed by an industry-leading warranty that guarantees mainframe repair or replacement for 3 years and all other parts for 1 year.

## Customer service locations

For questions regarding Acterna products and services, including return authorizations and repairs, technical support, training, and all other available services, contact your local distributor or Acterna Customer Service.



## Instrument services

To maintain your organization's long-term investment, Acterna will structure a service plan to fit your network performance goals and budget. Acterna understands the impact of equipment down time on operations and is staffed to ensure a quick turnaround. Available services include the following:

**Product Repair** — All equipment returned for service is tested to the same rigorous standards as newly manufactured equipment. This ensures products meet all published specifications, including any applicable product updates.

**Calibration** — Acterna's calibration methods are ISO 9001 approved and based on NIST standards. Each calibration comes with a dated certificate, instrument stickers, and a data sheet.

**Factory Upgrades** — Any unit returned for a hardware feature enhancement will also receive applicable product updates and will be thoroughly tested, ensuring peak performance of the complete feature set.

**Software Enhancement Agreements** — These agreements assist in keeping equipment up to date with the latest software features, by providing automatic notification of any new software enhancements and changes for Acterna products.

**Product Maintenance Agreements** — Yearly service and calibration maintenance agreements simplify billing and help ensure the equipment is always operating at optimum levels. Product maintenance agreements can be used to extend a current warranty or provide protection for out-of-warranty units.

**Other Pricing Options** — For out-of-warranty repairs, Acterna offers two additional pricing options: time and material pricing and flat rate pricing. Under time and material pricing, customers are billed for the actual cost of the repair, making this a cost-effective method for minor repairs. Under flat rate pricing, customers pay a fixed service charge to repair unit failures (excluding damage or abuse), resulting in simplified paperwork and easier budgeting.

## Product Enhancement Group

The Product Enhancement Group offers one of the broadest and most experienced resource portfolios in the communications testing industry. This team of professionals offers expertise in software development, test procedure development, and network consulting, as well as years of expert test knowledge. Support is available for all core Acterna product lines:

**Network Consulting and Management** — Provides services such as productivity analysis, test strategy assessment, on-site applications assistance, and specialized training.

**Software Customization** — Develops scripts for remote and automated testing, statistics, and emulation.

**Test Procedure Development** — Creates procedures for automated testing, network testing, and compliance testing.

## Test systems field engineering and installation

Acterna offers a range of support services for our centralized test systems, designed around the needs of the customer's network. These services help preserve the investment over the life of the equipment. Available services include the following:

**Critical Services Program** — Provides technical support at any time, 7 days a week, 24 hours a day. Replacement parts are guaranteed to arrive within 48 hours of contacting Acterna.

**Maintenance Contracts** — Cost-effective management for networks with multiple test systems.

**Out-of-Warranty Service Agreement** — Covers the test system for failures after the warranty expires, including all time and material costs and return shipping costs to the customer site.

**Field Engineering and Installation Service** — Provides a variety of options for implementing the test system into the network, including installation, configuration, upgrades, and on-site technical support.

## Technical training

By providing both experienced instructors and a hands-on atmosphere, Acterna training is designed to optimize test strategies and employee development requirements. Available services include the following:

**Customized Technical Training** — Designed to incorporate real-life challenges technicians face daily, while addressing the customer's training requirements, Acterna provides training at the customer's designated site, so the whole staff is trained at one time. Step-by-step reviews of current technologies and products enable new or experienced technicians to translate theory into practical, hands-on expertise.

**Public Courses** — Regularly scheduled, in-depth, hands-on product and technology courses are offered worldwide. Public courses provide a learning environment that allows individuals from different companies to share their knowledge and experience with their peers.

**Computer-Based Training (CBT)** — Acterna's CBT complements our hands-on technical training. With CBT, customers can learn about emerging communications technologies at their own convenience — at work, at home, or while traveling. Acterna's CBT courses cover technology topics such as ATM, frame relay, ISDN, LAN basics, and more.

**Customized Multimedia Course Development** — Multimedia courseware can be created to customer specifications, making it easier to learn new test instruments or applications. These custom packages provide consistent educational content and training for the entire staff. Students learn at their own pace on their own PC.

**Consulting and Needs Analysis Services** — Acterna can help identify training needs and develop customized training curricula to maximize learning opportunities, all while providing a measurable return on investment.

## Warranty information

The warranties described herein shall apply to all commercially available Acterna products. Any additional or different warranties shall apply only if agreed to by Acterna in writing. These warranties are not transferable without the express written consent of Acterna.

**Hardware Warranty** — Acterna warrants that Hardware Product sold to customer shall, under normal use and service, be free from defects in materials and workmanship. The warranty period shall be three (3) years for mainframes and options (parts and labor), and (1) one year for accessories and field-replaceable batteries. If installation services have been ordered, the warranty period shall begin on the earlier of (1) completion of installation, or (2) thirty (30) days after shipment to Customer. If Installation Services have not been ordered, the warranty period shall begin upon shipment to Customer. Hereafter these periods of time shall be collectively referred to as the “Initial Warranty Period.”

Acterna’s obligation and customer’s sole remedy under this Hardware Warranty is limited to the repair or replacement, at Acterna’s option, of the defective product. Acterna shall have no obligation to remedy any such defect if it can be shown: (a) that the Product was altered, repaired, or reworked by any party other than Acterna without Acterna’s written consent; (b) that such defects were the result of customer’s improper storage, mishandling, abuse, or misuse of Product; (c) that such defects were the result of customer’s use of Product in conjunction with equipment electronically or mechanically incompatible or of an inferior quality; or (d) that the defect was the result of damage by fire, explosion, power failure, or any act of nature.

Acterna warrants that Products returned to Acterna for repair shall be warranted from defective materials and workmanship for one (1) year for the same repair issue, and ninety (90) days for a different repair issue from date of shipment from Acterna to customer, or until the end of the Initial Warranty Period, whichever is longer. Risk of loss or damage to Product returned to Acterna for repair or replacement shall be borne by customer until delivery to Acterna. Upon delivery of such product, Acterna

shall assume the risk of loss or damage until that time that the product being repaired or replaced is returned and delivered to customer. Customer shall pay all transportation costs for equipment or software shipped to Acterna for repair or replacement. Acterna shall pay all transportation costs associated with returning repaired or replaced product to customer.

**Software Warranty** — Acterna warrants that Software Products licensed to Customer shall, under normal use and service, and for a period of ninety (90) days from the date of shipment of the Software to Licensee (the “Warranty Period”), perform in all material respects in accordance with the published specifications for such Software as established by Acterna. However, Acterna does not warrant that the Software will operate uninterrupted or error free, operate in the combination with other software, meet Customer’s requirements, or that its use will be uninterrupted.

Acterna’s obligation and Customer’s sole and exclusive remedy under this Software Warranty is limited to, at Acterna’s option, either (i) correcting the material errors reported to Acterna in writing by Customer during the Warranty Period and which Acterna is able to reproduce, (ii) replacing such defective Software, provided that Acterna received written notice of such defect within the Warranty Period, or (iii) provided that Acterna received written notice of such defect within the Warranty Period, terminating the License and, upon return to Acterna of the Software, Documentation and all other materials provided by Acterna under the applicable License, providing Customer with a refund of all charges paid with respect thereto. Acterna shall have no warranty obligations hereunder if (a) the Software is altered or modified or is merged with other software by Customer or any third party or (b) all or any part of the Software is installed on any computer equipment other than the Designated Server or used with any operating system for which the Software is not designed.

**Services Warranty** — Acterna warrants that the Services provided by Acterna, if any, shall be performed promptly, diligently and in a professional manner in accordance with the commercial standards of the industry. Acterna shall not, however, be responsible for any delays that are not due to Acterna’s fault or

negligence or that could not have reasonably been foreseen or provided against.

**WARRANTY DISCLAIMER** — FOR HARDWARE, SOFTWARE, AND/OR SERVICES FURNISHED BY ACTERNA, THE FOREGOING WARRANTIES ARE IN LIEU OF ALL OTHER WARRANTIES AND CONDITIONS, EXPRESS OR IMPLIED. ACTERNA SPECIFICALLY DISCLAIMS ALL OTHER WARRANTIES, EITHER EXPRESS OR IMPLIED, ON ANY HARDWARE, SOFTWARE, DOCUMENTATION OR SERVICES INCLUDING BUT NOT LIMITED TO WARRANTIES RELATING TO QUALITY, PERFORMANCE, NONINFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, AS WELL AS THOSE ARISING FROM ANY COURSE OF DEALING, USAGE OR TRADE PRACTICE. UNDER NO CIRCUMSTANCES WILL ACTERNA BE LIABLE FOR ANY INDIRECT OR CONSEQUENTIAL DAMAGES RELATED TO BREACH OF THIS WARRANTY.

## Equipment return instructions

For each piece of equipment returned for repair, attach a tag that includes the following information:

- Owner's name, address, and telephone number.
- The serial number, product type, and model.
- Warranty status. (If you are unsure of the warranty status of your instrument, contact Acterna Customer Service.)
- A detailed description of the problem or service requested.
- The name and telephone number of the person to contact regarding questions about the repair.
- The return authorization (RA) number (US customers), or reference number (European Customers).

If possible, return the equipment using the original shipping container and material. If the original container is not available, the unit should be carefully packed so that it will not be damaged in transit; when needed, appropriate packing materials can be obtained by contacting Acterna Customer Services. Acterna is not liable for any damage that may occur during shipping. The customer should clearly mark the

Acterna-issued RA or reference number on the outside of the package and ship it prepaid and insured to Acterna.

# Specifications

This appendix describes the specifications for the 2310 and its options. Topics discussed are as follows:

- “Physical specifications” on page 246
- “Environmental specifications” on page 246
- “Electrical specifications” on page 247
- “DS1 input specifications” on page 248
- “DS1 output specifications” on page 249
- “DS3 and STS-1 input specifications” on page 250
- “DS3 and STS-1 output specifications” on page 251
- “Optical specifications for OC-3/12/48” on page 252
- “ISDN PRI specifications” on page 254
- “ATM specifications” on page 255
- “GR-303 specifications” on page 255



## Physical specifications

The physical characteristics for the 2310 unit are described in Table 44.

**Table 44** — *Physical characteristics for 2310*

| Item   | Description       |
|--------|-------------------|
| Height | 7.5" (19 cm)      |
| Width  | 411.5" (29.2 cm)  |
| Depth  | 2.25" (5.7 cm)    |
| Weight | 5 lb. (11.02 kg.) |

## Environmental specifications

The environmental characteristics for the 2310 unit are described in Table 45.

**Table 45** — *Electrical characteristics for 2310*

| Item                | Description   |
|---------------------|---|
| Temperature         |   |
| Operating           | 32°F to 113°F (0°C to +40°C)  |
| Storage             | -4°F to 158°F (-20°C to +70°C)  |
| Humidity            | 10% to 90% Relative Humidity, non-condensing<br>Relative Humidity, non-condensing |
| Shock and Vibration | Meets IEEE-743  |

## Electrical specifications

The electrical characteristics for the 2310 unit are described in Table 46.

**Table 46** — *Electrical characteristics*

| Item              | Description  |
|-------------------|--|
| Battery           | Rechargeable 10.8 V Nickel-Metal Hydride (NiMH)  |
| Operating Time    | Typically provides up to 1.5 hours of operation performing DS3/DS1 tests.<br>Typically provides up to 30 minutes of operation performing STS-1 and OC-3/12 SONET tests.<br>Typically provides up to 25 minutes of operation for OC-48 SONET tests. |
| Recharging Period | Maximum of 1.5 hours.  |
| AC Adaptor        | 19 VDC, 2.6 amps; 90-240 VAC, 45-65 Hz   |
| Cable             | 75 Ohm RG59 B/U cable, attenuation measured at 22.368 MHz is $5.7 \pm 0.2$ dB per 450 ft. of cable.  |

### NOTE:

The battery life may decrease after 100 charge/discharge cycles.

## DS1 input specifications

The input specifications for DS1 are described in Table 47.

**Table 47** — *Input specifications for DS1*

| Item                          | Description   |
|-------------------------------|---|
| Connector type                | Bantam jack   |
| Frequency                     | 1.544 MHz $\pm$ 50 ppm  |
| Impedance                     |   |
| BRIDGE                        | 1000 ohms minimum   |
| TERM                          | 100 ohms $\pm$ 5%   |
| DSX-MON                       | 100 ohms $\pm$ 5%   |
| Range                         |   |
| BRIDGE                        | +6 to -35.0 dBdsx   |
| TERM                          | +6 to -35.0 dBdsx   |
| DSX-MON                       | -10 to -26.0 dBdsx of resistive loss  |
| Jitter Tolerance              |   |
| Per Reference                 | Bell PUB 62411 - 1990   |
| Accuracy                      |   |
| Receive Level Measurement     | From 6 dBdsx to -15 dBdsx, accuracy of $\pm$ 1 dB<br>From -16 dBdsx to -30 dBdsx, accuracy of $\pm$ 2 dB<br>From -31 dBdsx to -40 dBdsx, accuracy of $\pm$ 3 dB |
| Simplex Current Measurement   | $\pm$ 2% or $\pm$ 2 mA up to 60 mA<br>$\pm$ 3% or $\pm$ 3 mA up to 61 mA to 175 mA  |
| Receive Frequency Measurement | $\pm$ 3 ppm $\pm$ 1 ppm per year  |

## DS1 output specifications

The output specifications for DS1 are described in Table 48.

**Table 48** — *Output specifications for DS1*

| Item              | Description   |
|-------------------|---|
| Connector type    | Bantam jack   |
| LBO Level         | Line build-out of 0, -7.5, -15.0, and -22.5 dB of cable loss at 772 Hz  |
| LBO Tolerance     | $\pm 2$ dB at 772 kHz for -7.5 dB, -15.0 dB, and -22.5 dB<br>$\pm 1$ dB at 772 kHz for 0 dB   |
| Internal Timing   | $\pm 3$ ppm $\pm 1$ ppm per year  |
| Line Codes        | AMI or B8ZS   |
| Error Insert Type | Logic, BPV, or Frame  |
| Pulse Shape       | With output terminated in 100 ohms resistive load and 0 dB line build-out selected, the 2310 meets ITU-T Recommendation G.703; AT&T Publications CB113, CB119, ANSI T1.403-1995, CB132, CB143, and PUB62508; and AT&T PUB62411 pulse shape specifications |

## DS3 and STS-1 input specifications

The input specifications for DS3 and STS-1 are described in Table 49.

**Table 49** — *Input specifications for DS3 and STS-1*

| Item              | Description   |
|-------------------|---|
| Connector type    | Two WECO 560A connectors  |
| Input Level Range |   |
| HIGH              | Accepts a nominal signal level of 1.2 Vp (0 feet of cable attenuation from a HIGH source). With cable attenuation, accepts signal levels from +5dB (-450 feet) of gain to -5 dB (450 feet) of loss from the nominal signal level (1.2 Vp). With resistive attenuation, accepts signal levels from +5 dB of gain to -28 dB of loss from the nominal signal level (1.2Vp).    |
| DSX               | Accepts a nominal signal level of 0.6 Vp (450 feet of cable attenuation from a HIGH source). With cable attenuation, accepts signal levels from +5 dB (-450 feet) of gain to -5dB (450 feet) of loss from the nominal signal level (0.6 Vp). With resistive attenuation, accepts signal levels from +6 dB of gain to -26 dB of loss from the nominal signal level (0.6 Vp). |
| LOW               | Accepts a nominal signal level of 0.3 Vp (900 feet of cable attenuation from a HIGH source). With cable attenuation, accepts signal levels from +5 dB (-450 feet) of gain to -5 dB (450 feet) of loss from the nominal signal level (0.3 Vp). With resistive attenuation, accepts signal levels from +5 dB of gain to -5 dB of loss from the nominal signal level (0.3 Vp). |
| Input Impedance   | 75 ohms nominal, unbalanced to ground.<br>Per applicable specifications   |
| Jitter Tolerance  | Exceeds TR-TSY-000499   |

### **NOTE:**

*The maximum signal that the 2310 can recover without errors is 1.7 Vp. The minimum signal that the it can recover without errors is 0.025 Vp. The maximum input signal level is 2.5 Vp.*

## DS3 and STS-1 output specifications


The output specifications for DS3 and STS-1 are described in Table 50.

**Table 50** — *Output specifications for DS3 and STS-1*

| Item               | Description  |
|--------------------|--|
| Connector type     | One WECO 560A connector  |
| Output level range |  |
| HIGH               | Nominal 1.20 Vp. DS3 Signal meets ANSI T1.102-1993, Table 5, and CCITT Recommendation G.703 for DS3 pulse mask when transmitted through 450 feet of coaxial cable (WECO 728A, RG59B/U, or equivalent). STS-1 pulse mask meets BELL CORE GR-253-CORE-1995 and the DS3 ANSI T1.102-1993. |
| DSX                | Nominal 0.61 Vp. DS3 Signal meets ANSI T1.102-1993, Table 5, and CCITT Recommendation G.703, Section 5. The STS-1 signal meets ANSI T1.102-1993 and BELL CORE GR-253-CORE-1995.  |
| LOW                | Nominal 0.31 Vp. Signal is equivalent to a DSX signal transmitted through 450 feet of coaxial cable (WECO 728A, RG59B/U, or equivalent).   |
| Output impedance   | 75 ohms nominal, unbalanced to ground.<br>Per applicable specifications  |
| Jitter transfer    | Per TR-TSY-000499  |
| Frequency          | DS3 = 44.736 MHz $\pm$ 10 ppm.<br>STS-1 = 51.84 MHz $\pm$ 3 ppm $\pm$ 1 ppm per year.  |

## Optical specifications for OC-3/12/48

The 2310 is a Class 1 Laser product which complies with 21 CFR 1040.10 - 1040.11 laser standards. Cautions must be observed before and during all phases of instrument operation. The following symbol designates a Class 1 Laser product. Please observe the warning to avoid hazardous laser light exposure.



### **WARNING: HAZARDOUS LASER LIGHT EXPOSURE!**

*Do not look directly into the 2310 optical output. The optical source is designed for safe Class I operation. However, it is recommended that you not look directly into the optical output of the unit or at the output of any optical cable connected to the unit. If a fiber optic connection is removed from a transmitting connector, screw the safety cap onto the connector to prevent inadvertent exposure to the laser output. Use of controls, adjustments, or procedures other than those specified herein may result in hazardous laser light exposure.*

The optical specifications for OC-3, OC-12, and OC-48 are described in Table 51. The receiver is a multimode compatible receiver so that it will work with multimode or single mode fiber.

**Table 51 — Optical specifications for OC-3/12/48**

| Item   | Description   |
|--|---|
| Optical connector types <sup>a</sup>                 | OC-3/12/48 Receive — FC, SC, or ST<br>OC-3/12/48 Transmit — FC, SC, or ST |
| Transmit Measurement Range                           | Transmitter works with multimode or single mode fiber                     |
| Uses either 1310 or 1550 wavelengths                 |   |
| Output level for high-power transmit <sup>b, c</sup> | +2 to -4.3 dBm  |
| Output level for low-power transmit                  | - 8.0 to -15 dBm  |
| Eye diagram  | Per BELL CORE; GR-253-CORE-1995   |
| Clock frequency accuracy                             | ± 3 ppm ± 1 ppm per year  |
| Receive Measurement Range                            |   |
| Receive level sensitivity                            | - 8 dBm to -28 dBm  |
| Frequency range for OC-3/12/48 equipped units        | ± 100 ppm year  |
| Frequency range for OC-3 equipped units              | ± 500 ppm year  |
| Frequency range for OC-3/12 equipped units           | ± 500 ppm year  |
| Frequency measurement accuracy                       | ± 3 ppm ± 1 ppm per year  |
| Jitter tolerance                                     | Per BELL CORE; GR-253-CORE-1995   |
| Receiver shutdown <sup>c</sup>                       | -6 dBm  |
| Reflectance for OC-3/12/48 equipped units            | > +20 dBm   |
| Level Measurement                                    |   |
| Range for OC-3/12/48 equipped units                  | - 6 to -28 dBm  |
| Range for OC-3 and OC-3/12 equipped units            | - 5 to -45 dBm  |
| Accuracy   | ± 2 dB  |
| Resolution   | ± 0.1dB   |

- a. Never remove laser connectors to clean the optical fiber. Damage to the optics may occur if this is done. Refer all servicing to qualified Acterna service personnel.
- b. On OC-3 or OC-3/12 equipped units, the only transmitter provided meets the low-power specification. A high-power transmit is only provided with units equipped up to OC-48.
- c. A greater than -8 dbm optical-level signal should not be input into the 2310. Damage to the receiver may occur. Never self-loop the high-power transmitter back to the test set.



## ISDN PRI specifications

### ISDN PRI characteristics

Table 52 lists the specifications for the Primary Rate ISDN option.

**Table 52 — ISDN option characteristics**

| Item                         | Specification                                |
|------------------------------|--|
| Connectors                   | Option utilizes the T1 Interface connectors. |
| Line Termination (resistive) | 100 ohms $\pm 5\%$ .                         |
| TEI Assignment               | 0  |

### ISDN PRI status messages

The status message display window (below the application selection buttons) shows the status of the D channel and the progress of ISDN calls for both incoming and outgoing calls. Table 53 provides the list of messages and their descriptions. The second line of the status message window also provides additional information about call direction.

**Table 53 — ISDN PRI status messages**

| Message      | Description                       |
|--------------|-----------------------------------|
| 1            | Incoming                          |
| 0            | Outgoing                          |
| Call Type    | 64k, 56k, Voice, Nx64k, Nx56k, H0 |
| Called Numb  | Outgoing calls                    |
| Calling Numb | Incoming Calls                    |

## ATM specifications

The specifications for the ATM analysis option are based on the following standards:

- ITU-T I.150-1995 — B-ISDN Asynchronous Transfer Mode functional characteristics
- ITU-T I.356-1996 — B-ISDN ATM layer cell transfer performance
- ITU-T I.361-1999 — B-ISDN ATM Layer specifications
- ITU-T O.191-1997 — Equipment to assess ATM Layer Cell Transfer performance
- ITU-T O.191 Addendum 1-1997 — Equipment to assess ATM Layer Cell Transfer performance

## GR-303 specifications

The specifications for the GR-303 option are based on the following standards:

- Bellcore, TR-NWT-000303-1992 — *Integrated Digital Loop Carrier System Generic Requirements, Objectives, and Interface*, Issue 2
- Bellcore, GR-303-CORE-1996 — *Integrated Digital Loop Carrier System Generic Requirements, Objectives, and Interface*, Issue 1, Revision 2
- ITU-T, Recommendation Q.921-1997 — Digital Subscriber Signaling System No. 1 (DSS 1) - ISDN User-Network Interface – Data Link Specification
- ITU-T, Recommendation Q.931-1993 — Digital Subscriber Signaling System No. 1 (DSS 1) - ISDN User-Network Interface Layer 3 Specification for Basic Call Control, (ITU-T, March 1993)

# Index

## Symbols

% Error-Free Secs  
logic test result, 219

## A

A/B/C/D Signaling Bits  
monitoring, 77

Aborted Frames  
ISDN PRI test results, 225

Action Softkeys  
main screen, 26

Active Port LEDs  
top-panel features, 11

AIS  
DS1 LED test result, 184

Alarm  
LED display for current/history  
signal, 17

Alarm LEDs  
red, 19

Alarms LED  
SONET alarm LED, 19

Analysis  
T1 timing slip, 52

Application Icon Selection  
main screen, 21

Application Icons with Pull-Down  
Lists, 22

Application Setup Property  
Screens, 28

Applications  
common, 41  
DDS option, 67  
DDS drop and insert  
testing, 71  
DDS loopback BER  
testing, 67  
DS3 BER testing, 108  
DS3 option, 105  
monitoring DS3  
performance, 105  
FT1 option, 57  
FT1 drop and insert  
testing, 61  
FT1 loopback BER  
testing, 57  
intelligent repeater span  
option, 99

- OC-3 and OC-12 option, 125
  - monitoring OC-3 and OC-12 performance, 126, 143
  - OC-3 and OC-12 BER testing, 130
  - optical power measurement, 134
- signaling option, 77
  - monitoring A/B/C/D signaling bits, 77
  - PBX/switch emulation (originating a call), 83
  - PBX/switch emulation (terminating a call), 85
  - signaling monitor (call capture), 79
  - T1 drop and insert setup (place call), 87
- STS-1 option, 113
  - monitoring STS-1 performance, 113
  - STS-1 BER testing, 117
  - VT1.5 drop/monitoring from STS-1, 121
- T1 option, 43
  - monitoring T1 performance, 43
  - T1 BERT termination setup, 46
  - T1 loopback BER testing, 49
  - T1 timing slip analysis, 52
- VF option, 91
  - transmitting VF tones, 95
  - VF channel drop/monitor setup, 91
- VT100 emulation option, 137
- APS Bridged Line
  - SONET line test result, 201
- APS Msg Count
  - SONET line test result, 201
- APS Request Msg
  - SONET line test result, 202
- APS Switch Mode
  - SONET line test result, 201
- Available Interface Connectors
  - getting started, 12
- B**
- B8ZS
  - DS1 LED test result, 184
- Basic Test Setup, 36
- Battery
  - access door
    - bottom-panel features, 10
  - recharging the, 39
  - replacement, 40
- Battery Low LED
  - front-panel features, 9
- BER Testing
  - DDS loopback, 67
  - DS3, 108
  - FT1 loopback, 57
  - OC-3 and OC-12, 130
  - simulation of DDS loopback, 70
  - STS-1, 117
  - T1 loopback, 49
  - T1 termination setup, 46
- Bit Error Rate
  - logic test result, 219
- Bit Errors
  - logic test result, 219
- Bits
  - monitoring A/B/C/D signaling, 77
- Blue Alarm
  - DS3 LED test result, 185
- Bottom Vent
  - bottom-panel features, 10
- Bottom-Panel Features
  - getting started, 9
- BPV % Err Free Secs
  - SONET (STS-1) BPV test result, 191
- BPV Category
  - description, 24

- BPV Err Secs
  - DS1 BPV test result, 192
  - DS3 BPV test result, 193
- BPV Rate
  - DS1 BPV test result, 192
  - DS3 BPV test result, 193
  - SONET (STS-1) BPV test result, 191
- BPV Test Results
  - DS1, 192
  - DS3, 193
- BPVs
  - DS1 BPV test result, 192
  - DS3 BPV test result, 193
  - SONET (STS-1) BPV test result, 191
- C**
- Calibration
  - instrument service, 237
- Call 1
  - ISDN PRI result screens, 227
- Call 1 Connected
  - ISDN PRI test results, 225
- Call Capture
  - signaling monitor, 79
- Call Fail Count
  - ISDN PRI test results, 225
- Call Failure
  - ISDN PRI test results, 225, 226
- Call Sig (Call Signal) Category
  - description, 25
- Category
  - DS1 LED, 184
  - DS1 summary, 181
  - DS3 summary, 182
  - errors, 39
  - pull-down list in results, 23
  - SONET LED, 186
  - SONET summary, 182
- C-Bit Error Rate
  - DS3 parity test result, 198
- C-Bit Error Seconds
  - DS3 parity test result, 198
- C-Bit Errors
  - DS3 parity test result, 197
- C-Bit Frame
  - DS3 LED test result, 185
- Changing Between Primary and Secondary Receivers
  - description, 23
- Changing Modules
  - instrument description, 6
- Channel Category
  - description, 25
- Charging LED
  - front-panel features, 9
- Choosing Test Results
  - description, 23
- Codes
  - reportable DS0 control, 214
- Common Applications, 41
- Computer-Based Training (CBT)
  - technical training, 239
- Concat Payload
  - SONET LED test result, 187
- Connection
  - printer, 31
- Connectors
  - available interface, 12
- Consulting and Needs Analysis Services
  - technical training, 239
- Control Codes
  - reportable DS0, 214
- CRC Erred Rate
  - DS1 frame test result, 194

- CRC Erred Secs
  - DS1 frame test result, 194
- CRC Errors
  - DS1 frame test result, 194
- CRC SES
  - DS1 frame test result, 194
- Critical Services Program
  - test systems field engineering and installation, 238
- Custom Results Enable/Disable Property Sheets, 234
- Custom Results Property Sheet, 233
- Customer Service Locations, 236
- Customized Multimedia Course Development
  - technical training, 239
- Customized Technical Training
  - customer services, 239
- D**
- D&I Mode
  - description, 22
- Date
  - time test result, 220
- D-Channel Ready
  - ISDN PRI test results, 225
- DDS Drop and Insert Setup
  - simulation, 76
- DDS Drop and Insert Testing, 71
- DDS Loopback BER Test Setup
  - simulation, 70
- DDS Loopback BER Testing, 67
- DDS Option
  - common applications, 67
- Display Panel
  - LED, 17
- Drop and Insert Setup
  - DDS testing, 71
  - FT1 testing, 61
  - simulation DDS, 76
  - T1 (place call), 87
- Drop/Monitor Setup
  - VF channel, 91
  - VT1.5 from STS-1, 121
- DS0 Control Codes
  - reportable, 214
- DS1
  - input specifications for, 248
- DS1 BPV Test Results, 192
- DS1 Frame Test Results, 194
- DS1 Idle
  - DS1 LED test result, 184
- DS1 LED Category
  - test results, 184
- DS1 Signal Test Results, 188
- DS1 Summary Category
  - test results, 181
- DS1 Timing Slips
  - simulation, 56
- DS1, DS3, and SONET Logic Category
  - test results, 218
- DS1/DS3/STS-1 Primary and Secondary RX & TX Jacks
  - top-panel features, 11
- DS2 Frame Error Rate
  - DS3 frame test result, 195
- DS2 Frame Errors
  - DS3 frame test result, 195
- DS2 Frame Loss
  - DS3 LED test result, 185
- DS2 Frame Losses
  - DS3 frame test result, 195

- DS2 Frame Sync
  - DS3 LED test result, 185
- DS3 and STS-1
  - output specifications for, 251
- DS3 BER Testing
  - common applications, 108
- DS3 BPV Test Results, 193
- DS3 Frame Test Results, 195
- DS3 Idle
  - DS3 LED test result, 185
- DS3 Logic Category
  - test results, 218
- DS3 Option
  - common applications, 105
- DS3 Parity Test Results, 197
- DS3 Performance
  - monitoring, 105
- DS3 Signal Test Results, 189
- DS3 Summary Category
  - test results, 182
- Dual Test Results Display
  - main screen, 27
- Dual Test Results Display (Labeled), 28
- Dual-PCMCIA Card Door/Slot
  - top-panel features, 11
- E**
  - Elapsed Time
    - time test result, 220
  - Emulation (Originating a Call)
    - PBX/switch, 83
  - Emulation (Terminating a Call)
    - PBX/switch, 85
  - Enable/Disable Property Sheets
    - custom results, 234
  - Equipment Return Instructions
    - service and repair information, 242
  - Error Secs
    - logic test result, 219
  - Error/Alarm Insert Test Setup
    - MON/THRU mode, 129
  - Errored Frames
    - ISDN PRI test results, 225
  - Error-Free Secs
    - logic test result, 219
  - Errors Category, 39
  - Events Property Sheet, 34
  - Excess Zeros
    - DS1 LED test result, 184
- F**
  - Factory Upgrades
    - instrument service, 237
  - Far-End OOF Sec
    - DS3 frame test result, 195
  - FEAC, History
    - DS3 frame test result, 196
  - Features
    - bottom-panel, 9
    - front-panel, 8
    - top-panel, 10
  - FEBE Errored Seconds
    - DS3 parity test result, 198
  - FEBE Rate
    - DS3 parity test result, 198
  - FEBEs
    - DS3 parity test result, 198
  - Field Engineering and Installation Service
    - test systems field engineering and installation, 238
  - Frame Category
    - description, 24

- Frame Count
  - ISDN PRI test results, 225
- Frame Erred Secs
  - DS1 frame test result, 194
  - DS3 frame test result, 195
- Frame Error Rate
  - DS1 frame test result, 194
  - DS3 frame test result, 195
- Frame Errors
  - DS1 frame test result, 194
  - DS3 frame test result, 195
- Frame LED
  - DS1 alarm LED, 19
  - DS3 alarm LED, 19
  - SONET alarm LED, 19
  - status LED, 18
- Frame Loss Secs
  - DS1 frame test result, 194
- Frame Losses
  - DS1 frame test result, 194
  - DS3 frame test result, 195
- Frame Reject Frames
  - ISDN PRI test results, 225
- Frame SES
  - DS1 frame test result, 194
- Frame Slips
  - DS1 signal test result, 189
- Frame Test Results
  - DS1, 194
  - DS3, 195
- Frame Word Errors
  - SONET section test result, 199
- Front-Panel Features
  - getting started, 8
- FT1 Drop and Insert Testing, 61
- FT1 Loopback BER Testing, 57
- FT1 Loopback Test Setup
  - simulation, 61
- FT1 Option
  - common applications, 57
- G**
- Green Status LEDs, 18
- I**
- Icons
  - Permanent Softkey, 15, 16
- Information
  - warranty, 240
- Input Specifications
  - DS1, 248
- Installation
  - test systems field engineering and, 238
- Instructions
  - equipment return, 242
- Instrument Service
  - customer services, 237
- Intelligent Repeater Span Option
  - common applications, 99
- Invalid Frames
  - ISDN PRI test results, 225
- ISDN PRI
  - Status Messages, 254
- L**
- LAPD Multi-Frame Loss
  - ISDN PRI test results, 225
- LAPD Protocol Errors
  - ISDN PRI test results, 225
- LCD
  - front-panel features, 9
- LED Category
  - description, 24
  - DS1, 184
  - SONET, 186
- LED Display for Current/History Signal Alarm, 17



- LED Display Panel, 17
  - front-panel features, 9
- LED Test Results
  - DS3, 185
  - SONET, 186
- LEDs
  - green status, 18
  - red alarm, 19
- Level Volts
  - DS3 signal test result, 190
- Line AIS
  - SONET LED test result, 186
- Line AIS Seconds
  - SONET line test result, 203
- Line BIP Error Rate
  - SONET line test result, 202
- Line BIP Error Secs
  - SONET line test result, 202
- Line BIP Errors
  - SONET line test result, 203
- Line Category
  - description, 25
- Line FEBE Rate
  - SONET line test result, 203
- Line FEBEs
  - SONET line test result, 203
- Line RDI
  - SONET LED test result, 186
- Line SES
  - SONET line test result, 203
- Line Unavailable Seconds
  - SONET line test result, 203
- Locations
  - customer service, 236
- Logic Category
  - description, 24
- Loopback BER Testing
  - DDS, 67
  - FT1, 57
  - T1, 49
- Loopback Test Setup
  - simulation of DDS, 70
  - simulation of FT1, 61
  - simulation of T1, 52
- M**
- Main Screen, 21
- Maintenance Contracts
  - test systems field engineering and installation, 238
- Measurement
  - optical power, 134
- Message Display
  - main screen, 28
- Messages
  - ISDN PRI status, 254
- Mon/Thru Mode Error/Alarm Insert Test Setup, 129
- Mon/Thru Modes
  - description, 21
- Monitor (Call Capture)
  - signaling, 79
- Monitoring
  - A/B/C/D signaling bits, 77
  - DS3 performance, 105
  - OC-3 and OC-12
    - performance, 126, 143
  - STS-1 performance, 113
  - T1 performance, 43
- MUX Mode
  - description, 22
- N**
- Near-End OOF Sec
  - DS3 frame test result, 195
- Network Consulting and Management
  - product enhancement group, 238

**O**

- OC-12 Performance
  - monitoring OC-3 and, 126, 143
- OC-3 and OC-12 BER Testing, 130
- OC-3 and OC-12 Option
  - common applications, 125
- OC-3 and OC-12 Performance
  - monitoring, 126, 143
- OC-3 RX Frequency
  - SONET signal test result, 190
- OC-3 TX Frequency
  - SONET signal test result, 191
- Ones Density
  - DS1 LED test result, 184
- Optical Power dBm
  - SONET signal test result, 191
- Optical Power Measurement, 134
- Options
  - DDS
    - common applications, 67
  - DS3
    - common applications, 105
  - FT1
    - common applications, 57
    - intelligent repeater span
      - common applications, 99
  - OC-3 and OC-12
    - common applications, 125
  - signaling
    - common applications, 77
  - STS-1
    - common applications, 113
  - T1
    - common applications, 43
  - VF
    - common applications, 91
  - VT100 emulation
    - common applications, 137
- Other Pricing Options
  - instrument service, 237

- Out-of-Warranty Service Agreement
  - test systems field engineering and installation, 238

- Output Specifications
  - DS3 and STS-1, 251

**P**

- Panel
  - bottom, 9
  - front, 8
  - LED display, 17
  - top, 10
- Parity Category
  - description, 25
- Parity Error Rate
  - DS3 parity test result, 197
- Parity Error Seconds
  - DS3 parity test result, 197
- Parity Errors
  - DS3 parity test result, 197
- Parity Test Results
  - DS3, 197
- Path & VT LED
  - status LED, 18
- Path AIS
  - SONET LED test result, 186
- Path AIS Secs
  - SONET path test result, 205
- Path AIS/LOP Secs
  - SONET path test result, 205
- Path BIP Error Rate
  - SONET path test result, 205
- Path BIP Error Secs
  - SONET path test result, 205
- Path BIP Errors
  - SONET path test result, 205
- Path Category
  - description, 25

- Path FEBE Rate
  - SONET path test result, 206
- Path FEBEs
  - SONET path test result, 205
- Path LOP
  - SONET LED test result, 187
- Path LOP Secs
  - SONET path test result, 205
- Path PTR LED
  - SONET alarm LED, 19
- Path RDI
  - SONET LED test result, 187
- Path SES
  - SONET path test result, 205
- Path Trace
  - SONET path trace test result, 207
- Path Trace Category
  - description, 25
- Path Unavail Secs
  - SONET path test result, 205
- Pattern LED
  - DS1 alarm LED, 19
  - DS3 alarm LED, 19
  - SONET alarm LED, 19
  - status LED, 18
- Pattern Losses
  - logic test result, 218
- Pattern Slips
  - logic test result, 219
- PBX/Switch Emulation
  - originating a call, 83
  - terminating a call, 85
- Performance
  - monitoring DS3, 105
  - monitoring OC-3 and OC-12, 126, 143
  - monitoring STS-1, 113
  - monitoring T1, 43
- Permanent Softkey Icons
  - color display, 15
  - transflective-monochrome display, 16
- Permanent Softkeys
  - main screen, 25
- Place Call
  - T1 drop and insert setup, 87
- Power LED
  - front-panel features, 8
- Power Measurement
  - optical, 134
- Power Switch
  - bottom-panel features, 10
- Preview Screen of Files within Print Buffer, 33
- PRI Status Messages
  - ISDN, 254
- Print Buffer
  - preview screen of files within, 33
- Printer
  - connection, 31
  - settings property sheet, 35
  - setup, 31
- Printer Connector
  - top-panel features, 11
- Printer settings, 31
  - printer settings, 35
- Printout Controls Property Sheets
  - events, 34
  - printer settings, 35
  - printouts, 32
- Product Enhancement Group
  - customer services, 238
- Product Maintenance Agreements
  - instrument service, 237
- Product Repair
  - instrument service, 237

- Property Sheet
  - custom results, 233
  - custom results enable/disable, 234
  - events, 34
  - printout controls, 32, 34, 35
  - printouts, 32
  - setup summary, 29
  - tabs set test parameters, 30
- Property Sheets
  - application setup, 28
- PTR ADJ LED
  - SONET alarm LED, 19
- Public Courses
  - technical training, 239
- Pull-Down List
  - application icons with, 22
  - in results category, 23
- Q**
- Quad Results
  - description, 22
- Quick Configuration Softkeys
  - main screen, 26
- Quick Configuration/Action Buttons Diagram, 26
- R**
- Receive Byte
  - channel VF and DDS test result, 212
- Recharging the Battery, 39
- Red Alarm LEDs, 19
- Reject Frames
  - ISDN PRI test results, 225
- Replacing Battery, 40
- Reportable DS0 Control Codes, 214
- Results
  - DS1 BPV, 192
  - DS1 frame, 194
  - DS1 signal, 188
  - DS1 summary, 181
  - DS3 BPV, 193
  - DS3 frame, 195
  - DS3 LED, 185
  - DS3 parity, 197
  - DS3 signal, 189
  - DS3 summary, 182
  - SONET LEDs, 186
  - SONET section, 199
  - SONET signal, 190
  - SONET summary, 182
  - using quad, 231
- Results Category Display
  - main screen, 23
- Results Display (Labeled)
  - dual test, 28
- Results Enable/Disable Property Sheets
  - custom, 234
- Results Group Display
  - main screen, 23
- Results group selection, 23
- Results Group Selection on Main Menu Screen, 23
- Results Property Sheet
  - custom, 233
- Return Instructions
  - equipment, 242
- RX Frequency
  - DS1 signal test result, 188
  - DS3 signal test result, 190
- RX Level dBdsx
  - DS3 signal test result, 190
- RX Level dBm
  - DS1 signal test result, 189
  - DS3 signal test result, 190
- RX Pulse and TX Laser LEDs
  - top-panel features, 11

RX X-Bits  
DS3 frame test result, 195

## S

Sample Configuration/Action Buttons Usage, 27

Sample Quad Results Screen, 232

### Screen

application setup property, 28  
main, 21  
results group selection on main menu, 23

### Sect SES

SONET section test result, 200

### Section BIP Error Rate

SONET section test result, 199

### Section BIP Error Sec

SONET section test result, 199

### Section BIP Errors

SONET section test result, 199

### Section Category

description, 25  
test results, 199

### SEF Defect

SONET section test result, 200

### SEF Secs

SONET section test result, 200

### Service

instrument, 237

### Service Locations

customer, 236

### Setup

basic test, 36  
MON/THRU mode error/alarm insert test, 129  
printer, 31  
simulation DDS drop and insert, 76  
simulation of DDS loopback BER test, 70

simulation of FT1 loopback test, 61

simulation of T1 loopback test, 52

simulation of T1 termination test, 48

summary property sheet, 29

T1 BERT termination, 46

T1 drop and insert (place call), 87

VF channel drop/monitor, 91

### Sheet

custom results enable/disable property, 234

custom results property, 233

printer settings property, 35

printout controls property, 32, 34, 35

setup summary property, 29

### Signal Alarm

LED display for current/history, 17

### Signal Category

description, 24

### Signal LED

DS1 alarm LED, 19

DS3 alarm LED, 19

SONET alarm LED, 19

status LED, 18

### Signal Loss Count

DS1 signal test result, 188

DS3 signal test result, 189

### Signal Loss Secs

DS1 signal test result, 188

DS3 signal test result, 189

SONET signal test result, 190

### Signal Losses

SONET signal test result, 190

### Signal Test Results

DS1, 188

DS3, 189

SONET, 190

### Signaling Bits

monitoring A/B/C/D, 77

- traffic test result, 217
- Signaling Delay
  - call signal test result, 216
- Signaling Duration
  - call signal test result, 216
- Signaling Monitor (Call Capture), 79
- Signaling Option
  - common applications, 77
- Simplex Curr mA
  - DS1 signal test result, 188
- Simulation
  - DDS drop and insert setup, 76
  - DDS loopback BER test setup, 70
  - DS1 timing slips, 56
  - FT1 loopback test setup, 61
  - T1 loopback test setup, 52
  - T1 termination test setup, 48
- Softkey Icons
  - Permanent, 15, 16
- Software Customization
  - product enhancement group, 238
- Software Enhancement Agreements
  - instrument service, 237
- SONET LED Category
  - test results, 186
- SONET Logic Category
  - test results, 218
- SONET Signal Test Results, 190
- SONET Summary Category
  - test results, 182
- SPE Pointer Justification
  - SONET line test result, 203
- Speaker
  - front-panel features, 8
- Specifications
  - DS1
    - input, 248
  - DS3 and STS-1
    - output, 251
- Status LEDs
  - green, 18
- Status Messages
  - ISDN PRI, 254
- STS Path Signal Label
  - SONET path trace test result, 207
- STS-1 BER Testing, 117
- STS-1 Level dBdsx
  - SONET signal test result, 191
- STS-1 Level Volts
  - SONET signal test result, 191
- STS-1 Option
  - common applications, 113
- STS-1 Performance
  - monitoring, 113
- STS-1 RX Frequency
  - SONET signal test result, 190
- STS-1 TX Frequency
  - SONET signal test result, 191
- STS-Power dBm
  - SONET signal test result, 191
- SUMMARY
  - SONET alarm LED, 19
- Summary Category
  - description, 24
  - DS1 test results, 181
  - DS3 test results, 182
  - SONET test results, 182
- Summary Property Sheet
  - setup, 29
- SYNC FAILURE
  - SONET alarm LED, 20

Sync Loss Secs  
logic test result, 219

## T

T1 BERT Termination Setup, 46

T1 Drop and Insert Setup (Place Call), 87

T1 Loopback BER Testing, 49

T1 Loopback Test Setup  
simulation of, 52

T1 Option  
common applications, 43

T1 Performance  
monitoring, 43

T1 Termination Test Setup  
simulation of, 48

T1 Timing Slip Analysis, 52

Technical Training  
customer services, 239

Term Mode  
description, 22

Terminating a Call  
PBX/switch emulation, 85

Termination Test Setup  
simulation of T1, 48  
T1 BERT, 46

Test Parameters  
property sheet tabs set, 30

Test Procedure Development  
product enhancement group, 238

Test Results  
DS1 BPV, 192  
DS1 frame, 194  
DS1 signal, 188  
DS1 summary, 181  
DS3 BPV, 193  
DS3 frame, 195  
DS3 LED, 185  
DS3 parity, 197

DS3 signal, 189  
DS3 summary, 182  
dual display (Labeled), 28  
SONET LED, 186  
SONET section, 199  
SONET signal, 190  
SONET summary, 182

Test Setup  
basic, 36  
MON/THRU mode error/alarm  
insert, 129  
simulation of DDS loopback  
BER, 70  
simulation of FT1 loopback, 61  
simulation of T1 loopback, 52  
simulation of T1 termination, 48

Test Systems Field Engineering and  
Installation  
customer services, 238

Testing  
DDS drop and insert, 71  
DDS loopback BER, 67  
DS3 BER, 108  
FT1 drop and insert, 61  
FT1 loopback BER, 57  
OC-3 and OC-12 BER, 130  
STS-1 BER, 117  
T1 loopback BER, 49

Thru Mode  
description, 22

Time  
time test result, 220

Time Category  
description, 25

Timing Slip Analysis  
T1, 52

Timing Slips  
DS1 signal test result, 189  
simulation DS1, 56

Tones  
transmitting VF, 95

- Top-Panel Features
  - getting started, 10
- Traffic Category
  - description, 25
- Training
  - technical, 239
- Transmitting VF Tones, 95
- TTC 2000 Test Pad and T-BERD 2310 Module, 7
- TX Frequency
  - DS1 signal test result, 188
  - DS3 signal test result, 190
- TX X-Bits
  - DS3 frame test result, 195
- U**
- Using Quad Results, 231
- V**
- VF Channel Drop/Monitor Setup, 91
- VF Option
  - common applications, 91
- VF Tones
  - transmitting, 95
- Virtual Tributary (VT) Category
  - description, 25
- VT AIS
  - SONET LED test result, 187
- VT AIS/LOP Secs
  - SONET VT test result, 208
- VT BIP Error Rate
  - SONET VT test result, 208
- VT BIP Error Secs
  - SONET VT test result, 208
- VT BIP Errors
  - SONET VT test result, 208
- VT FEBE
  - SONET VT test result, 208
- VT FEBE Rate
  - SONET VT test result, 208
- VT LOP
  - SONET LED test result, 187
- VT PTR Decs
  - SONET VT test result, 209
- VT PTR Incs
  - SONET VT test result, 209
- VT PTR Just
  - SONET VT test result, 208
- VT PTR LED
  - SONET alarm LED, 19
- VT PTR NDFS
  - SONET VT test result, 209
- VT PTR Value
  - SONET VT test result, 209
- VT RDI
  - SONET LED test result, 187
- VT SES
  - SONET VT test result, 208
- VT Unavail Secs
  - SONET VT test result, 208
- VT1.5 Drop/Monitoring From STS-1, 121
- VT100 Emulation Option
  - common applications, 137
- W**
- Warranty Information
  - customer services, 240
- Y**
- Yellow Alarm
  - DS3 LED test result, 185