

Agilent 16196A/B/C/D Parallel Electrode SMD Test Fixture

Operation and Service Manual

Fourth Edition



Agilent Part No. 16196-90040

June 2005

Printed in Japan

Notices

The information contained in this document is subject to change without notice.

This document contains proprietary information that is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent of Agilent Technologies.

© Copyright 1999, 2003, 2005 Agilent Technologies

Manual Printing History

The manual's printing date and part number indicate its current edition. The printing date changes when a new edition is printed. (Minor corrections and updates that are incorporated at reprint do not cause the date to change.) The manual part number changes when extensive technical changes are incorporated.

October 1999	Preliminary
November 1999	First Edition
December 1999	Second Edition
May 2003	Third Edition
June 2005	Fourth Edition

Safety Summary

The following general safety precautions must be observed during all phases of operation, service, and repair of this instrument. Failure to comply with these precautions or with specific WARNINGS elsewhere in this manual may impair the protection provided by the equipment. In addition it violates safety standards of design, manufacture, and intended use of the instrument.

Agilent Technologies assumes no liability for the customer's failure to comply with these requirements.

NOTE

16196A/B/C/D comply with INSTALLATION CATEGORY II and POLLUTION DEGREE 2 in IEC61010-1. 16196A/B/C/D are INDOOR USE product.

- Ground The Instrument
To avoid electric shock hazard, the instrument chassis and cabinet must be connected to a safety earth ground by the supplied power cable with earth blade.
- DO NOT Operate In An Explosive Atmosphere

Do not operate the instrument in the presence of flammable gasses or fumes. Operation of any electrical instrument in such an environment constitutes a definite safety hazard.

- DO NOT Substitute Parts Or Modify Instrument









Because of the danger of introducing additional hazards, do not install substitute parts or perform unauthorized modifications to the instrument. Return the instrument to a Agilent Technologies Sales and Service Office for service and repair to ensure that safety features are maintained.

- Dangerous Procedure Warnings

Warnings, such as the example below, precede potentially dangerous procedures throughout this manual. Instructions contained in the warnings must be followed.

Safety Symbol

General definitions of safety symbols used on the instrument or in manuals are listed below.

-  Instruction Manual symbol: the product is marked with this symbol when it is necessary for the user to refer to the instrument manual.
-  Alternating current.
-  Direct current.
-  On (Supply).
-  Off (Supply).
-  In position of push-button switch.
-  Out position of push-button switch.
-  Frame (or chassis) terminal. A connection to the frame (chassis) of the equipment which normally include all exposed metal structure.

WARNING

This warning sign denotes a hazard. It calls attention to a procedure, practice, condition or the like, which, if not correctly performed or adhered to, could result in injury or death to personnel.

CAUTION

This Caution sign denotes a hazard. It calls attention to a procedure, practice, condition or the like, which, if not correctly performed or adhered to, could result in damage to or destruction of part or all of the product.

NOTE

Note denotes important information. It calls attention to a procedure, practice, condition or the like, which is essential to highlight.

Certification

Agilent Technologies certifies that this product met its published specifications at the time of shipment from the factory. Agilent Technologies further certifies that its calibration measurements are traceable to the United States National Institute of Standards and Technology, to the extent allowed by the Institution's calibration facility or by the calibration facilities of other International Standards Organization members.

Documentation Warranty

The material contained in this document is provided "as is," and is subject to being changed, without notice, in future editions. Further, to the maximum extent permitted by applicable law, Agilent disclaims all warranties, either express or implied with regard to this manual and any information contained herein, including but not limited to the implied warranties of merchantability and fitness for a particular purpose. Agilent shall not be liable for errors or for incidental or consequential damages in connection with the furnishing, use, or performance of this document or any information contained herein. Should Agilent and the user have a separate written agreement with warranty terms covering the material in this document that conflict with these terms, the warranty terms in the separate agreement will control.

Exclusive Remedies

The remedies provided herein are buyer's sole and exclusive remedies. Agilent Technologies shall not be liable for any direct, indirect, special, incidental, or consequential damages, whether based on contract, tort, or any other legal theory.

Assistance

Product maintenance agreements and other customer assistance agreements are available for Agilent Technologies products.

For any assistance, contact your nearest Agilent Technologies Sales and Service Office. Addresses are provided at the back of this manual.

Typeface Conventions

Bold	Boldface type is used when a term is defined. For example: icons are symbols.
<i>Italic</i>	Italic type is used for emphasis and for titles of manuals and other publications.
[Hardkey]	Indicates a hardkey labeled “Hardkey.”
Softkey	Indicates a softkey labeled “Softkey.”
[Hardkey] - Softkey1 - Softkey2	Indicates keystrokes [Hardkey] - Softkey1 - Softkey2 .

1. Installation Guide	
Incoming Inspection	10
Connecting the 16196A/B/C/D to a Measuring Instrument	15
2. Product Overview	
Product Overview	18
Functions	20
Names of Accessories and Functions	21
3. Operation	
Flow of Measurements	24
Selecting and Changing the Insulator Assembly	25
Setting the Electrical Length.	29
Performing Fixture Compensation	30
Measuring Open Compensation Data	30
Measuring Short Compensation Data	32
Connecting and Measuring DUTs	34
Removing the DUT	34
4. User Maintenance	
Overview	38
The Necessity of User Maintenance	38
User Maintenance Flow	39
Cleaning	41
Places Requiring Cleaned	41
Cleaning Methods	42
Wear Check	44
Example of User Limit Values Setting	44
Reference Value Acquisition	46
Measuring Impedance Shift	48
Check Sheet	49
Check Sheet Fill-Out Example	49
Electrode Wear Check	50
Short Plate Wear Check	51
Parts Replacement	52
Procedure for Replacement	52
Check Following Replacement	52
Assembling Check	53
Electrode Check	53
Short Plate Check	56
5. Specifications and Supplemental Performance Characteristics	
Specifications	60
Supplemental Performance Characteristics	61
Additional Error	61
6. Service	
Replaceable Parts	68

Contents

Block Assembly	68
Cap	71
Other Parts	73
Maintenance Kit	74
16196U Maintenance Kit	74
Replacement Procedure	75
Lower Electrode	76
Insulator	78
Upper Electrode	79
Assembling Check	81
Method Using Network Analyzer	81

1 Installation Guide

In this chapter, the procedures required from the time the 16196A/B/C/D Parallel Electrode SMD Test Fixture arrives until its use begins are described.

Incoming Inspection

Inspect the shipping container for damage. If the shipping container or cushioning material is damaged, it should be kept until the contents of the shipment have been checked for completeness and the 16196A/B/C/D has been checked mechanically and electrically.

The shipment should contain everything listed in Table 1-1 to Table 1-4. If the contents are incomplete or if there is mechanical damage or defect, notify the nearest Agilent Technologies office. If the shipping container is damaged or the cushioning material shows signs of unusual stress, notify the carrier as well as the Agilent Technologies office. Keep the shipping materials for the carrier's inspection.

NOTE

When the equipment is used for the first time following purchase, “Wear Check” should be conducted. This “Wear Check” is required for keeping the measurement accuracy. Refer to “Reference Value Acquisition” on page 46 in “Wear Check” for details.

Figure 1-1 16196A/B/C/D Contents




Table 1-1 16196A Package Contents

No.	Description	Agilent Part No.	Qty.
1	16196A Parallel Electrode SMD Test Fixture	-	1
-	Insulator Assembly ϕ 1.34 *1	16196-60112	1
2	Insulator Assembly ϕ 1.14	16196-60113	1
2	Insulator Assembly ϕ 1.08	16196-60114	1
3	Open Plate *2	16196-29002	1
4	Short Plate *2	16196-29026	1
5	Push Ring	16196-24004	1
6	Tweezers *3	8710-2081	1
7	Cleaning Rod	5182-7586	1
8	Wrench	8710-0909	1
9	Magnifying Glass *3	16193-60002	1
10	Carrying Case	16196-60150	1
11	Operation and Service Manual (This manual) *4	16196-90040	1

*1. Mounted in the Test Fixture when shipped from the factory.

*2. The Open Plate and Short Plate are packed in a single case and shipped.

*3. Furnished with Option 710.

*4. Furnished with Option ABA.

Table 1-2 16196B Package Contents

No.	Description	Agilent Part No.	Qty.
1	16196B Parallel Electrode SMD Test Fixture	-	1
-	Insulator Assembly ϕ 0.85 *1	16196-60212	1
2	Insulator Assembly ϕ 0.75	16196-60213	1
2	Insulator Assembly ϕ 0.68	16196-60214	1
3	Open Plate *2	16196-29002	1
4	Short Plate *2	16196-29027	1
5	Push Ring	16196-24004	1
6	Tweezers *3	8710-2081	1
7	Cleaning Rod	5182-7586	1
8	Wrench	8710-0909	1

Table 1-2 16196B Package Contents

No.	Description	Agilent Part No.	Qty.
9	Magnifying Glass *3	16193-60002	1
10	Carrying Case	16196-60250	1
11	Operation and Service Manual (This manual) *4	16196-90040	1

*1. Mounted in the Test Fixture when shipped from the factory.

*2. The Open Plate and Short Plate are packed in a single case and shipped.

*3. Furnished with Option 710.

*4. Furnished with Option ABA.

Table 1-3 16196C Package Contents

No.	Description	Agilent Part No.	Qty.
1	16196C Parallel Electrode SMD Test Fixture	-	1
-	Insulator Assembly $\phi 0.48$ *1	16196-60312	1
3	Open Plate *2	16196-29002	1
4	Short Plate *2	16196-29028	1
5	Push Ring	16196-24004	1
6	Tweezers *3	8710-2081	1
7	Cleaning Rod	5182-7586	1
8	Wrench	8710-0909	1
9	Magnifying Glass *3	16193-60002	1
10	Carrying Case	16196-60350	1
11	Operation and Service Manual (This manual) *4	16196-90040	1

*1. Mounted on the Test Fixture when shipped from the factory.

*2. The Open Plate and Short Plate are packed in a single case and shipped.

*3. Furnished with Option 710.

*4. Furnished with Option ABA.

Table 1-4 16196D Package Contents

No.	Description	Agilent Part No.	Qty.
1	16196D Parallel Electrode SMD Test Fixture	-	1
-	Insulator Assembly $\phi 0.30$ *1	16196-60414	1
2	Insulator Assembly $\phi 0.34$	16196-60412	1
3	Open Plate *2	16196-29002	1

Table 1-4 **16196D Package Contents**

No.	Description	Agilent Part No.	Qty.
4	Short Plate *2	16196-29030*3	1
5	Push Ring	16196-24004	1
6	Tweezers *4	8710-2081	1
7	Cleaning Rod	5182-7586	1
8	Wrench	8710-0909	1
9	Magnifying Glass*4	16193-60002	1
10	Carrying Case	16196-60450	1
11	Operation and Service Manual (This manual)*5	16196-90040	1

*1. Mounted in the Test Fixture when shipped from the factory.

*2. The Open Plate and Short Plate are packed in a single case and shipped.

*3. The part number is different from that of the replacement part. When you order it for user maintenance, refer to Table 6-1 on page 69.

*4. Furnished with Option 710.

*5. Furnished with Option ABA.

Connecting the 16196A/B/C/D to a Measuring Instrument

To connect the 16196A/B/C/D Test Fixture to a measuring instrument, it is necessary to use an adapter that fits the measuring instrument.

The 16196A/B/C/D Test Fixture is suitable for use with a high frequency LCR Meter or Impedance Analyzer. Table 1-4 lists the appropriate combination of measuring instrument and adapter.

Table 1-5 Measuring Instruments and Adapters

Instrument	Adapter
4287A	Test Head + Test Fixture Stand (Furnished with the 4287A)
E4991A	Test Head (Furnished with the E4991A)
4291A/B	Test Station + Test Head (Furnished with the 4291A/B)
4286A	Test Head + Test Fixture Stand (Furnished with the 4286A)
4395A* ¹	43961A Impedance Test Adapter
4396B* ¹	43961A Impedance Test Adapter

*1. "Option 010 Impedance Measuring Function" is required.

16196A/B/C/D Test Fixture can be connected to instruments with the 4-terminal pair configuration.

Table 1-6 Measuring Instruments and Adapters

Instrument	Adapter
4294A	42942A Terminal Adapter
4194A	41941A + 16099A or 41941B + 16099A
4192A, 4194A, 4263B, 4268A, 4278A, 4279A, 4284A, 4285A	16085B Terminal Adapter

Refer to the adapter's manual about the procedure for connecting to the measuring instrument.

NOTE

Some instruments require calibration at the 7-mm connector. Perform calibration at the 7-mm connector before connecting a test fixture. See the operation manual of the instrument for more details.

Connecting the 16196A/B/C/D to a Measuring Instrument


The general procedure for mounting the Test Fixture on the adapter is as shown below. (For details, see the Manual supplied with each adapter.)

- Step 1.** Turn the adapter's 7-mm connector in the counterclockwise direction when viewed from above and screw the connection sleeve in fully.
- Step 2.** Align the test fixture with the adapter's mount post and 7-mm connector and set it gently in place.
- Step 3.** Turn the adapter's 7-mm connector counterclockwise, connecting the bottom of the test fixture with the connector.

NOTE

To make a firm connection with the test fixture, use the torque wrench (size: 3/4 inch, torque: 12 lb-in, Agilent part number: 8710-1766) to fasten the adapter's 7-mm connector.

Figure 1-2 **Installing the Test Fixture**



16196abcqj0101


2 Product Overview

Product Overview

The 16196A, 16196B, 16196C, and 16196D are test fixtures for measuring chip components. They enable chip type capacitors, inductors and other components to be measured with high precision and measurement repeatability. The 16196A/B/C/D also is compatible with measuring frequencies up to 3 GHz. The 16196A is for size 1608 parts ^{*1}, the 16196B is for size 1005 parts ^{*1}, the 16196C is for size 0603parts ^{*1}, and the 16196D is for size 0402 parts ^{*1}.

Figure 2-1

Product Overview (The photograph shows the 16196B.)




The product appearance is the same for the 16196A, 16196B and 16196C. Only the cap shape for the 16196D is different.

^{*1}. These sizes, 1608, 1005, 0603, and 0402, are all nominal sizes in millimeters.

Figure 2-2

Electrode Structure



After passing through the DUT (Device Under Test), the current flows to the outer conductor via the cap electrode and returns to the outer conductor of the 7-mm connector. Through this structure, the ideal shield structure is formed.


2. Product Overview

Functions

The names of each part of the 16196A/B/C/D are shown in Figure 2-3.

Figure 2-3

Names of Parts



16196abcdoe4004

Table 2-1 **Names of Parts and Functions**

No.	Name	Function
1	Cap	This is the LOW side electrode.
2	DUT Insertion Hole	Forms a cylindrical structure made with an insulator and holds the DUT from the sides.
3	Magnifying Glass ^{*1*2}	Enlarges the DUT and the insulator hole area.

*1. Furnished with Option 710.

*2. The magnifying glass is packed separately from the 16196A/B/C/D body. Connect it as shown in Figure 2-3.

Names of Accessories and Functions

Figure 2-4

Accessories




Table 2-2

Names of Accessories and Functions









No.	Name	Function
1	Open Plate	Used when correcting for an open circuit.
2	Short Plate	Used when correcting for a short circuit.
3	Insulator Assembly	Used to change assemblies when measuring DUTs with different shapes.
4	Push Ring	Supplementary tool used when removing DUTs.
5	Cleaning Rod	Cleans the electrodes.
6	Wrench	For removing hex nuts.
7	Tweezers ^{*1}	Used to handle the open plate, short plate, and DUTs, etc.

*1. Fmished with Option 710.

Insulator Assembly

In order to handle DUTs with differing shapes, the 16196A and 16196B each come with 3 types of insulator assembly, the 16196C comes with 1 insulator assembly, and the 16196D comes with two types of insulator assembly. Each of these insulator assemblies has little marks engraved in them to enable identification of each model and hole diameter. There are marks on the back of the insulator assemblies to identify the model and there are marks on the front to identify the hole diameter.

Insulator Assembly identifications

Agilent Model No.	Back	Front
16196A		 <p style="text-align: center;"> ϕ 1.34 ϕ 1.14 ϕ 1.08 </p>
16196B		 <p style="text-align: center;"> ϕ 0.85 ϕ 0.75 ϕ 0.68 </p>
16196C		 <p style="text-align: center;">ϕ 0.48</p>
16196D		 <p style="text-align: center;"> ϕ 0.30 ϕ 0.34 </p>

3 Operation

This chapter describes preparations and fixture compensation when using the 16196A/B/C/D to take measurements as well as DUT connection and measuring methods.

Flow of Measurements

Follow the steps below when performing measurements of DUTs with the 16196A/B/C/D.

1. **Selecting and Changing the Insulator Assembly**
Select an insulator assembly that is appropriate for the shape of the measured DUT and replace the insulator assembly in the fixture.
2. **Setting the Electrical Length**
Set the fixture's electrical length in the measuring instrument you will be using.
3. **Performing Fixture Compensation**
Measure the data for open compensation and measure the data for short compensation. When performing measurements with higher precision, carry out "Fixture compensation for higher precision measurements".
4. **Connecting and Measuring the DUT**
Connect the DUT and perform measurements.

Settings of the electrical length and fixture compensation differ depending on the measuring instrument used. Refer to the Operation Manual for the measuring instrument that you are using.

NOTE

The 16196A/B/C/D requires frequent wear checks to keep the best measurement accuracy. When the equipment is used for the first time following purchase or part replacement, "Wear Check" should be conducted. Refer to "Wear Check" on page 44 for details.

Selecting and Changing the Insulator Assembly

Select an insulator assembly that corresponds to the shape of the DUT being measured and replace the insulator assembly in the fixture..

CAUTION

An exclusive type of insulator assembly is supplied with each model. Do not use an insulator assembly from a different model.

Step 1. Select an insulator assembly that is appropriate for the shape of the DUT to be measured.

To take accurate and repeatable measurements, it is necessary for the DUT to be placed in the DUT insertion hole and be stable. For that reason, the 16196A and 16196B each are provided with 3 types of insulator assembly which have DUT insertion holes with different diameters (the 16196C has only one type of insulator assembly, and the 16196D has two types of insulator assembly). Select an insulator assembly that will create the narrowest gap between the DUT and the DUT insertion hole.

Figure 3-1

DUT and DUT Insertion Hole Diameter




Table 3-1

16196abc0e0311
Insulator Assembly Specifications

	Insulator Assembly	Example of Corresponding Chip (mm)		
		Length (L)	Width (W)	Height (H)
16196A	φ1.34	1.6	0.8	0.8
	φ1.14	1.6	0.8	0.6
	φ1.08	1.6	0.8	0.5

Table 3-1 Insulator Assembly Specifications

	Insulator Assembly	Example of Corresponding Chip (mm)		
		Length (L)	Width (W)	Height (H)
16196B	φ0.85	1.0	0.5	0.5
	φ0.75	1.0	0.5	0.35
	φ0.68	1.0	0.5	0.35
16196C	φ0.48	0.6	0.3	0.3
16196D	φ0.30	0.4	0.2	0.13 or 0.2 ^{*1}
	φ0.34	0.4	0.2	0.2 ^{*1}


*1. When you measure a 0.4 x 0.2 x 0.2 DUT, first check whether it fits in the φ0.30 insulator assembly. Only if it does not, use the φ0.34 insulator assembly.

NOTE The number of the insulator assembly doesn't indicate the maximum diameter of the DUT insertion hole that can insert the cylindrical device.

NOTE If the gap between the DUT and the insulator is large, the measurement accuracy and repeatability decrease. Select an insulator assembly that is appropriate for the shape of the DUT to be measured.

- Step 2.** Replace the insulator assembly in the fixture with the selected insulator assembly. Loosen the 2 screws used to fasten the insulator assembly with the hex wrench and take them out, then remove the insulator assembly.

Figure 3-2 Removing the Insulator Assembly




NOTE If the insulator assembly is difficult to remove, turn the fixture over and remove the insulator assembly by letting it fall out.

CAUTION There is danger of the measuring precision and repeatability being adversely affected, and thus do not touch the lower electrode with your hands or damage it in any way.

- Step 3.** Mount the insulator assembly you have selected, and tighten the screws to secure it. Be sure to contact the insulator assembly with the bottom surface securely before tightening the screws.

Figure 3-3

Installing the Insulator Assembly



- Step 4.** Connect the test fixture to the measuring instrument. Connect the test fixture to the instrument in accordance with “Connecting the 16196A/B/C/D to a Measuring Instrument” on page 15 in Chapter 1.

Setting the Electrical Length

Set the electrical length in the measuring instrument. For the electrical length setting method, see the Operation Manual for the measuring instrument you are using. The electrical lengths for the 16196A/B/C/D are as shown below.

Table 3-2 **Electrical Length**

Model	Electrical Length [mm]
16196A	26.2
16196B	26.9
16196C	27.1
16196D	27.3

Performing Fixture Compensation

In order to perform more accurate measurements, before beginning the measurement procedure, it is necessary to compensate the fixture. For the 16196A/B/C/D, perform measurements of the data for open compensation and of the data for short compensation.

NOTE The 16196A/B/C/D requires frequent wear checks to keep the best measurement accuracy. When the equipment is used for the first time following purchase or part replacement, “Wear Check” should be conducted. Refer to “Wear Check” on page 44 for details.

NOTE If there are temperature fluctuations which exceed a temperature range of $\pm 5^{\circ}\text{C}$ after fixture compensation has been carried out, then perform fixture compensation again.

Measuring Open Compensation Data

Set the fixture in the open state using the open plate supplied.


Step 1. Remove the cap.

CAUTION Make sure there is no dirt or other foreign matter in the DUT insertion hole.

Step 2. Using the Tweezers, place the open plate on top of the insulator assembly. Set the open plate with the protruding surface down.

CAUTION Handle the open plate with Tweezers. If dirt, etc. gets on it, measuring precision and repeatability may be adversely affected.

Figure 3-4 Setting the Open State Using the Open Plate



- Step 3.** Fit the cap in place with the mark toward the front, and turn it to the right until it is locked.
- Step 4.** Take measurements of the data for open compensation in accordance with the Operation Manual for the measuring instrument you are using.

Measuring Short Compensation Data

Set the fixture in the short state using the short plate supplied.

Step 1. Remove the cap. Take out the open plate used to measure the open compensation data.


CAUTION Make sure there is no dirt or other foreign matter in the DUT insertion hole.

CAUTION An exclusive type of short plate is supplied with each model. Do not use a short plate from a different model.

Step 2. Place the short plate on the insulator assembly with tweezers. Place the rod-shaped protrusion of the short plate downward, and insert it into the DUT insertion hole.

CAUTION Handle the short plate with Tweezers. If dirt, etc. gets on it, measuring precision and repeatability may be adversely affected.

Figure 3-5 Setting the Short State Using the Short Plate



Step 3. Fit the cap in place with the mark toward the front, and turn it to the right until it is locked.

Step 4. Take measurements of the data for short compensation in accordance with the Operation Manual for the measuring instrument you are using.

NOTE Residual inductance for the Short Plate is as follows.

Model	Residual Inductance [nH]
16196A	0.43
16196B	0.27
16196C	0.16
16196D	0.11

Connecting and Measuring DUTs

Connect DUTs to the electrodes and take measurements.

CAUTION Do not connect a DUT, which has an incompatible size.


Step 1. Remove the cap.

CAUTION Make sure there is no dirt or other foreign matter in the DUT insertion hole.

Step 2. Insert the DUT into the insulator hole with tweezers.

Use a magnifying glass to check that the DUT is inserted deeply enough into the insulator hole for it to contact the bottom electrode.

Figure 3-6 Connecting a DUT




Step 3. Fit the cap in place with the mark toward the front, and turn it to the right until it is locked.

Step 4. Take measurements in accordance with the Operation Manual for the measuring instrument you are using.

Removing the DUT

Use the push ring when removing the DUT.

Figure 3-7 Removing the DUT Using the Push Ring



Press the insulator assembly down using the push ring. When this is done, the lower electrode will push up the DUT and you will be able to remove it. Measurements can also be taken with the push ring placed as is on the insulator assembly.



4

User Maintenance

Overview

The Necessity of User Maintenance

The measurement performance of the fixture decreases slightly each time measurement is repeated. This is due to contamination of the contacting sections by solder, etc. and mechanical wear and distortion caused by repeated use. Consequently, to maintain satisfactory measurement results, it is important to maintain the contacting sections in good condition and take appropriate measures before wear or distortion occurs. To accomplish this it is necessary to monitor the fixture and perform maintenance of the various items as described in “User Maintenance Flow” on page 39.

Because deterioration of the fixture seriously affects the measurement results when measuring minute values or performing measurements with a high accuracy, proper maintenance of the fixture is particularly important in these cases. Depending on the required measurement performance, it may be necessary to take measures such as establishing more rigorous evaluation standards and perform maintenance more frequently.

The upper and lower electrodes and the short plate are consumable products. These are the fixture construction parts that tend to have the greatest effect on the measurement results. During measurement, solder from the DUT tends to adhere to the upper and lower electrodes, causing gradual deterioration of the electrodes. The short plate part is used for creating a zero-standard during fixture compensation and distortion or contamination of the short plate therefore directly affects the measurement result. Focusing on the upper and lower electrodes and the short plate, this chapter explains the general aspects of user maintenance.

User Maintenance Flow

Figure 4-1 shows the flowchart of the user maintenance. The overview of the each maintenance item is explained below.


Table 4-1

Maintenance Items

Item		Frequency	Item
Cleaning		Several times daily	Cleaning of fixture
Wear Check	Setting the user limit	When the product is received and when you need	Set the user limit to the required measurement accuracy and the measurement condition.
	Measuring reference value	When the product is received and after parts replacement	Measure Ls and Rs of the fixture and set it the reference value
	Measuring impedance shift	daily and before fixture compensation	Measure Ls and Rs of the fixture and calculate the shift from the reference value.
Parts Replacement		When the wear check is failed.	Replacement of worn parts
Assembling Check		After parts replacement	Measure Ls and Rs to confirm that the fixture is assembled correctly.

Figure 4-1

Flowchart of User Maintenance



16196abc0e0403

Cleaning

If the electrodes and insulator assembly become dirty, measuring accuracy and repeatability will decrease. Also, if dirt adheres to the surfaces of the body, it will become impossible to remove the cap smoothly. In order to ensure measurement with high accuracy, be sure to perform cleaning periodically.


Places Requiring Cleaned

Place, which need to be cleaned, are as follows.

- Upper Electrode (Figure 4-2 (1))
- Cap Inside (Figure 4-2 (2))
- Lower Electrode (Figure 4-2 (3))
- Insulator Assembly recessed part (Figure 4-2 (4))
- Body side surfaces (Figure 4-2 (5))
- Short Plate
- Open Plate

Figure 4-2

Places to be Cleaned



16196abcoj0502


Cleaning Methods

Upper Electrode (Figure 4-2 (1)), Insulator Assembly (Figure 4-2 (4)), Open Plate, Short Plate

Use the Cleaning Rod (Agilent parts number 5182-7586) for the cleaning. Use the white rubber part of the cleaning rod to remove dirt from all contacting surfaces of the above-mentioned parts. Be careful not to scratch or damage the parts when removing the dirt.

Figure 4-3

Cleaning Rod



16196abc0j0501

Dirt tends to adhere to the upper electrode and short plate parts in particular. Meticulous cleaning of these parts is recommended.

CAUTION The front of the short plate has a sharp edge, so take adequate precautions when cleaning it.

CAUTION Do not use a file or similar object to remove dirt, as this will affect measurement accuracy and repeatability.

NOTE If the dirt cannot be removed, replace the part. For replacement method, see the sections "Replaceable Parts" and "Replacement Procedure".

Lower Electrode (Figure 4-2 (3))

Use the Cleaning Rod (Agilent parts number 5182-7586) for the cleaning. First use the push ring to press down the insulator assembly. While maintaining this condition, use the white rubber part of the cleaning rod to remove dirt from the contacting parts of the lower electrode. Be careful not to scratch or damage the parts when removing the dirt.

Dirt tends to adhere to the lower electrode parts in particular. Meticulous cleaning of these parts is recommended.

CAUTION Do not use a file or similar object to remove dirt, as this will affect measurement accuracy and repeatability.

NOTE If the dirt cannot be removed, replace the part. For replacement method, see the sections "Replaceable Parts" and "Replacement Procedure".

Cap Inside (Figure 4-2 (2)), Body Side Surfaces (Figure 4-2 (5))

Wipe dirt off using a soft cloth, etc.

NOTE

When removing dirt, always be careful to clean so that the electrodes and insulator assembly are not damaged.

Wear Check

The wear check allows you to obtain an idea about the deterioration of the fixture in order to ensure that the desired measurement accuracy is obtained. This check comprises “User Limit Setting”, “Reference Value Acquisition” and “Measuring Impedance Shift”. Using a desired frequency, the impedance (Rs, Ls) of the fixture itself is measured. It is recommended to use a frequency that is also used under the conditions where the fixture is normally used.

Normally, “User Limit Setting” should be conducted under the following circumstances.

- When the equipment is used for the first time following purchase.
- When the required measurement accuracy is changed.

Normally, “Reference Value Acquisition” should be conducted under the following circumstances.

- When the equipment is used for the first time following purchase.
- Following replacement of parts.

Normally, “Measuring Impedance Shift” should be conducted under the following circumstances.

- Once daily and before fixture compensation is performed.

Example of User Limit Values Setting

It is necessary to decide wear check user limit values suitable for the DUT and the demanded measurement accuracy. An example follows below.

To measure the inductors L: 10 nH and Q: 10 at a frequency (f) of 100 MHz with a measurement accuracy degree of 20%;

L: 10 nH

Q: 10

Frequency: 100 MHz

Demanded Accuracy: 20% for both L and Q

Using the above conditions, the inductor’s reactance X and resistance R are determined in the following manner.

$$X = 2\pi fL = 6 \Omega$$

$$R = X/Q = 0.6 \Omega$$

From $Q = X/R = 2\pi fL/R$ we understand that when R changes 20% (100 mΩ) Q should be approximately 20%, and when L changes 20% (2 nH), L and Q both change 20%. Accordingly, in order to measure both L and Q with a measurement accuracy of 20% or less, at least the error of L and R must be less than 2 nH and 120 mΩ, respectively. While remembering that L and R change together and keeping in mind other error factors than the deterioration of the fixture, the respective values should be set to 25% in this example, i.e., 500 pH and 30 mΩ.

CAUTION Use the same user limit values for “Measuring Impedance Shift”.

NOTE The above is just an example. The methods to determine the user limit vary with the measurement conditions and the DUT, etc.

NOTE In actually testing, a part of the effect of electrode wear is cancelled by the SHORT compensation. It is recommended, however, to set the user limit as shown in this example as the deviation from the reference value can be used to deal with all the things affecting the measured values.

Please enter the user limit values in the “Check Sheet” (page 50, page 51). See “Check Sheet Fill-Out Example” on page 49 for an example of how this is done.

Reference Value Acquisition

The impedance (Rs, Ls) of the fixture itself should be measured before deterioration sets in. It is recommended to use a measurement frequency that is used under the conditions where the fixture is normally used.

Normally, the reference value should be measured under the following circumstances.

- When the product is introduced.
- Following replacement of parts.

Required Tools

- 1.5-mm hex wrench (provided accessory)
- Short plate (provided accessory)
- Impedance measuring instrument (with 7-mm connector and calibrated)

Table 4-2 **Setting of Measuring Instrument**

Measurement Condition	Set Value
Electrical Length	16196A: 26.2 mm 16196B: 26.9 mm 16196C: 27.1 mm 16196D: 27.3 mm
Measurement Parameter	Ls, Rs
OSC Level	500 mV
Point Averaging	32

NOTE To make the same settings as given in the above table, refer to the Operation Manual for the measuring instrument.

CAUTION The measuring instrument's fixture compensation function should be set to OFF.

Acquisition Procedure (Electrode Wear Check Reference Value)

- Step 1.** Remove the cap and ensure that nothing is inserted into the fixture.
- Step 2.** Clean the fixture's upper and lower electrodes as described in "Cleaning" on page 41.
- Step 3.** Connect the fixture to the 7-mm connector.
- Step 4.** Place the cap on the fixture body.
- Step 5.** In order to contact the upper electrode and the lower electrode, use the provided hex wrench to turn the screw at the top of the cap approximately 6 turns to the left.

NOTE In case of the 16196D, please omit the step 5.

- Step 6.** Measure Rs and Ls as described in the Operation Manual for the measuring instrument.

- Step 7.** Record the read values as the reference values in the “Check Sheet” (page 50).
- Step 8.** Calculate the upper limit value and the lower limit value from the previously set user limits and the reference values obtained here. Record these in the "Check Sheet".
- Step 9.** Tighten the screw on top of the cap loosened in Step 5.

NOTE In case of the 16196D, please omit the step 9.

Acquisition Procedure (Short Plate Wear Check Reference Value)

- Step 1.** Clean the short plate as described in “Cleaning” on page 41.
- Step 2.** Remove the cap and place the short plate with the protruding surface down on the insulator assembly.
- Step 3.** Place the cap on the fixture body.
- Step 4.** Measure Rs and Ls as described in the Operation Manual for the measuring instrument.
- Step 5.** Record the read values as the reference values in the “Check Sheet” (page 51).
- Step 6.** Calculate the upper limit value and the lower limit value from the previously set user limits and the reference values obtained here. Record these in the "Check Sheet".

Measuring Impedance Shift

Measuring the impedance of the fixture with the upper and lower electrodes in contact should check the electrode wear.

Normally, this check should be conducted under the following circumstances.

- Once daily and before fixture compensation.

Required Tools

- 1.5-mm hex wrench (provided accessory)
- Impedance measuring instrument (with 7-mm connector and calibrated)

CAUTION

The measuring instrument's fixture compensation function should be set to OFF. Also, other settings should be the same as those used for "Reference Value Acquisition".

Procedure (Electrode Wear Check)

- Step 1.** Clean the electrodes as described in "Cleaning" on page 41.
- Step 2.** Set the measuring instrument and measure in the same way as for "Acquisition Procedure (Electrode Wear Check Reference Value)" on page 46.
- Step 3.** Record the Rs and Ls measured values as pass-fail in the "Check Sheet" (page 50).
- Step 4.** If the result is unacceptable, replace both the upper and the lower electrode.

Procedure (Short Plate Wear Check)

- Step 1.** Clean the short plate as described in "Cleaning" on page 41.
- Step 2.** Set the measuring instrument and measure in the same way as for "Acquisition Procedure (Short Plate Wear Check Reference Value)" on page 47.
- Step 3.** Enter the Rs and Ls measured values as pass-fail in the "Check Sheet" (page 51).
- Step 4.** If the result is unacceptable, replace the short plate.

Check Sheet

Check Sheet Fill-Out Example

The following example shows how the check sheet is filled out following electrode wear check. Fill out the sheet in the same manner for short plate wear check.

Electrode Wear Check Fill-Out Example

Table 4-3 Reference Value and User Limit Values Fill-Out Example

Frequency ^{*1}	Measurement Parameter	Reference Value ^{*2} [a]	User Limit Value ^{*3} [b]	Lower Limit [a-b]	Upper Limit [a+b]
100 MHz	Rs	90 mΩ	30 mΩ	60 mΩ	120 mΩ
	Ls	-290 pH	500 pH	-790 pH	210 pH
800 MHz	Rs	310 mΩ	40 mΩ	270 mΩ	350 mΩ
	Ls	-260 pH	400 pH	-660 pH	140 pH

*1. Set by the user as desired.

*2. Record values obtained at the time of “Reference Value Acquisition” on page 46.

*3. See also “Example of User Limit Values Setting” on page 44.

Table 4-4 Check History Fill-Out Example

Date	Frequency	Measurement parameter	Measured Value	Pass/Fail
Oct./11/1999 9:30	100 MHz	Rs	100 mΩ	Pass
		Ls	-320 pH	Pass
Oct./11/1999 9:35	800 MHz	Rs	345 mΩ	Pass
		Ls	-360 pH	Pass
Oct./12/1999 9:30	100 MHz	Rs	105 mΩ	Pass
		Ls	-340 pH	Pass
Oct./12/1999 9:35	800 MHz	Rs	355 mΩ	Fail ^{*1}
		Ls	-320 pH	Pass

*1. When the result is unacceptable, replace the part.

Electrode Wear Check

Table 4-5 Reference Value and User Limit Values

Frequency	Measurement Parameter	Reference Value [a]	User Limit Value [b]	Lower Limit [a - b]	Upper Limit [a + b]
	Rs	mΩ	mΩ	mΩ	mΩ
	Ls	pH	pH	pH	pH
	Rs	mΩ	mΩ	mΩ	mΩ
	Ls	pH	pH	pH	pH

Table 4-6 Check History

Date	Frequency	Measurement Parameter	Measured Value	Pass/Fail
		Rs	mΩ	
		Ls	pH	
		Rs	mΩ	
		Ls	pH	
		Rs	mΩ	
		Ls	pH	
		Rs	mΩ	
		Ls	pH	
		Rs	mΩ	
		Ls	pH	
		Rs	mΩ	
		Ls	pH	
		Rs	mΩ	
		Ls	pH	
		Rs	mΩ	
		Ls	pH	
		Rs	mΩ	
		Ls	pH	
		Rs	mΩ	
		Ls	pH	
		Rs	mΩ	
		Ls	pH	
		Rs	mΩ	
		Ls	pH	
		Rs	mΩ	
		Ls	pH	
		Rs	mΩ	
		Ls	pH	
		Rs	mΩ	
		Ls	pH	
		Rs	mΩ	
		Ls	pH	

Short Plate Wear Check

Table 4-7 Reference Value and User Limit Values

Frequency	Measurement Parameter	Reference Value [a]	User Limit Value [b]	Lower Limit [a - b]	Upper Limit [a + b]
	Rs	mΩ	mΩ	mΩ	mΩ
	Ls	pH	pH	pH	pH
	Rs	mΩ	mΩ	mΩ	mΩ
	Ls	pH	pH	pH	pH

Table 4-8 Check History

Date	Frequency	Measurement Parameter	Measured Value	Pass/Fail
		Rs	mΩ	
		Ls	pH	
		Rs	mΩ	
		Ls	pH	
		Rs	mΩ	
		Ls	pH	
		Rs	mΩ	
		Ls	pH	
		Rs	mΩ	
		Ls	pH	
		Rs	mΩ	
		Ls	pH	
		Rs	mΩ	
		Ls	pH	
		Rs	mΩ	
		Ls	pH	
		Rs	mΩ	
		Ls	pH	
		Rs	mΩ	
		Ls	pH	
		Rs	mΩ	
		Ls	pH	
		Rs	mΩ	
		Ls	pH	
		Rs	mΩ	
		Ls	pH	
		Rs	mΩ	
		Ls	pH	
		Rs	mΩ	
		Ls	pH	
		Rs	mΩ	
		Ls	pH	

4. User Maintenance

Parts Replacement

The replacement of parts is explained in the following.

Procedure for Replacement

Refer to “Replaceable Parts” on page 68 and “Replacement Procedure” on page 75 when replacing parts.

A maintenance kit containing 5 pieces is available for replacement of upper and lower electrodes and the short plate. For details, see “Maintenance Kit” on page 74.

Check Following Replacement

Following replacement of parts, it is necessary to confirm that the fixture has been correctly assembled. Please conduct the “Assembling Check” on page 53.

Assembling Check

Following replacement of parts, confirm that the fixture has been correctly assembled. The assembling check consists of “Electrode Check” and “Short Plate Check”, Measure the impedance (Rs, Ls) of both at 100 MHz and 1 GHz.

Normally, this check should be conducted under the following circumstances.

- Following replacement of parts.

Electrode Check

It should be checked whether the fixture is correctly assembled by measuring the impedance (Rs, Ls) of the fixture itself with the upper and lower electrodes in contact.

Required Tools

- 1.5-mm hex wrench (provided accessory)
- Impedance measuring instrument (with 7-mm connector and calibrated)

Table 4-9 **Setting of Measuring Instrument**

Measurement Condition	Set Value
Electrical Length	16196A: 26.2 mm 16196B: 26.9 mm 16196C: 27.1 mm 16196D: 27.3 mm
Measurement Parameter	Ls, Rs
OSC Level	500 mV
Point Averaging	32

NOTE

To make the same settings as given in the above table, refer to the Operation Manual for the measuring instrument.

Procedure

- Step 1.** Remove the cap and ensure that nothing is inserted into the fixture.
- Step 2.** Clean the fixture’s upper and lower electrodes as described in “Cleaning” on page 41.
- Step 3.** Connect the fixture to the 7-mm connector.
- Step 4.** Place the cap on the fixture body.
- Step 5.** In order to contact the upper electrode and the lower electrode, use the provided hex wrench to turn the screw on the top of the cap approximately 6 turns to the left.

NOTE In case of the 16196D, please omit the step 5.

Step 6. Measure Rs and Ls at 100 MHz and 1 GHz in this state.

Step 7. Confirm that the Rs and Ls values are within the limits given in the table below. If the results are outside the limit range, first check the attachment of the upper and lower electrode. If these are correctly attached but the results still remain outside the limit range, the fixture main body may be damaged. In this case, please contact a Agilent Technologies Sales or Service office.

Step 8. Tighten the screw on top of the cap loosened in Step 5.

NOTE In case of the 16196D, please omit the step 8.

Table 4-10 Electrode Check and Limits (16196A)

Parameter	Frequency	Limit (Absolute value)
100 MHz	Rs	30 mΩ ~ 150 mΩ
	Ls	-500 pH ~ 0 pH
1 GHz	Rs	100 mΩ ~ 480 mΩ
	Ls	-500 pH ~ 0 pH

Table 4-11 Electrode Check and Limits (16196B)

Parameter	Frequency	Limit (Absolute value)
100 MHz	Rs	40 mΩ ~ 160 mΩ
	Ls	-400 pH ~ 0 pH
1 GHz	Rs	120 mΩ ~ 510 mΩ
	Ls	-400 pH ~ 0 pH

Table 4-12 Electrode Check and Limits (16196C)

Parameter	Frequency	Limit (Absolute value)
100 MHz	Rs	40 mΩ ~ 170 mΩ
	Ls	-300 pH ~ 100 pH
1 GHz	Rs	120 mΩ ~ 540 mΩ
	Ls	-300 pH ~ 100 pH

Table 4-13 Electrode Check and Limits (16196D)

Parameter	Frequency	Limit (Absolute value)
100 MHz	Rs	40 mΩ ~ 250 mΩ
	Ls	-300 pH ~ 350 pH

Table 4-13 **Electrode Check and Limits (16196D)**

Parameter	Frequency	Limit (Absolute value)
1 GHz	Rs	80 mΩ ~ 810 mΩ
	Ls	-300 pH ~ 200 pH

Short Plate Check

Measuring the fixture's impedance with the short plate in place should check the condition of the short plate.

CAUTION

“Short Plate Check” should be performed after the “Electrode Check” has been completed.

Required Tools

- 1.5-mm hex wrench (provided accessory)
- Impedance measuring instrument (with 7-mm connector and calibrated)

Table 4-14 **Setting of Measuring Instrument**

Measurement condition	Set Value
Electrical Length	16196A: 26.2 mm 16196B: 26.9 mm 16196C: 27.1 mm 16196D: 27.3 mm
Measurement Parameter	Ls, Rs
OSC Level	500 mV
Point Averaging	32

NOTE

To make the same settings as given in the above table, refer to the Operation Manual for the measuring instrument.

Procedure

- Step 1.** Clean the short plate as described in “Cleaning” on page 41.
- Step 2.** Remove the cap and place the short plate with the protruding surface down on the insulator assembly.
- Step 3.** Place the cap on the fixture body and fasten it.
- Step 4.** Measure Rs and Ls at 100 MHz and 1 GHz in this condition.
- Step 5.** Confirm that the Rs and Ls values are within the representative values given in the table below. If the results are outside the limit range, please replace the short plate.

Table 4-15 Short Plate Check and Limits (16196A)

Parameter	Frequency	Limit (Absolute value)
100 MHz	Rs	30 mΩ ~ 160 mΩ
	Ls	200 pH ~ 800 pH
1 GHz	Rs	100 mΩ ~ 510 mΩ
	Ls	200 pH ~ 600 pH

Table 4-16 Short Plate Check and Limits (16196B)

Parameter	Frequency	Limit (Absolute value)
100 MHz	Rs	40 mΩ ~ 170 mΩ
	Ls	100 pH ~ 600 pH
1 GHz	Rs	120 mΩ ~ 540 mΩ
	Ls	100 pH ~ 400 pH

Table 4-17 Short Plate Check and Limits (16196C)


Parameter	Frequency	Limit (Absolute value)
100 MHz	Rs	40 mΩ ~ 180 mΩ
	Ls	100 pH ~ 600 pH
1 GHz	Rs	120 mΩ ~ 570 mΩ
	Ls	50 pH ~ 350 pH

Table 4-18 Short Plate Check and Limits (16196D)

Parameter	Frequency	Limit (Absolute value)
100 MHz	Rs	30 mΩ ~ 260 mΩ
	Ls	50 pH ~ 600 pH
1 GHz	Rs	80 mΩ ~ 860 mΩ
	Ls	0 pH ~ 350 pH

User Maintenance
Assembling Check

Specifications

Applicable Instruments	Refer to the Table 1-4,1-5.	
Applicable DUT Type	Surface Mount Device with side electrodes.	
	Model	Length (L) × Width (W) × Height (H)
	16196A	$(1.6 \pm 0.15) \times (0.8 \pm 0.15) \times (0.4 \text{ to } 0.95) \text{ mm}$
	16196B	$(1.0 \pm 0.1) \times (0.5 \pm 0.1) \times (0.3 \text{ to } 0.6) \text{ mm}$
	16196C	$(0.6 \pm 0.03) \times (0.3 \pm 0.03) \times (0.27 \text{ to } 0.33) \text{ mm}$
	16196D	$(0.4 \pm 0.02) \times (0.2 \pm 0.02) \times (0.11 \text{ to } 0.22) \text{ mm}$
Frequency	DC to 3 GHz	
Maximum Voltage	$\pm 40\text{V}$ peak max. (AC+DC)	
Maximum Current	5 A	
Operating Environment	temp.	-55°C to +85°C
	humidity	15% to 95%RH (@ wet bulb temp. < 40°C)
Non Operating Environment	temp.	-55°C to +85°C
	humidity	$\leq 90\%$ RH (@ wet bulb temp. <65°C)
Dimension	78 (D) × 140 (W) × 48 (H) mm (nominal)	
Weight	250g (nominal)	
	Model	(nominal)
	16196A	26.2 mm
	16196B	26.9 mm
	16196C	27.1 mm
	16196D	27.3 mm
Safety Standards	IEC 61010-1:2001 / EN 61010-1:2001 Canada: CAN/CSA C22.2 No. 1010.1-92 Installation/overvoltage category II Pollution degree 2 Indoor use	

Supplemental Performance Characteristics

This section provides useful data on the 16196A/B/C/D. These supplemental performance characteristics should not be considered specifications.

Additional Error

Additional errors are calculated as follows.

|Z| Measurement

Additional error for Impedance Z_e [%] is calculated by substituting the values in the table below into the following equation.

$$Z_e [\%] = \pm \{A + (Z_s/Z_x + Y_o \times Z_x) \times 100\}$$

where

A [%]	Test Fixture's Proportional Error [%]
Y_o [S]	Test Fixture's Open Repeatability [S]
Z_s [Ω]	Test Fixture's Short Repeatability [Ω]
Z_x [Ω]	Measured Impedance Value of DUT [Ω]

Z_s	$(30 + 125 \times f) \times 10^{-3}[\Omega]$
Y_o	$(5 + 40 \times f) \times 10^{-6}[S]$
A	$1 \times f^2 [\%]$

where f is frequency (GHz).

D Measurement

Additional error for Dissipation Factor D_e is calculated by using the additional error for Impedance Z_e [%] as follows.

If $D_x \leq 0.1$:

$$D_e = Z_e / 100$$

If $0.1 < D_x \leq 0.5$:

$$D_e = (Z_e / 100) \times (1 + D_x)$$

where D_x is the measured value of D. It is necessary for Z_e to be below 10 %.

NOTE

D is not expressed as a percentage but as an absolute value.

Rs (ESR) Measurement

Additional error Rse[%] of the Rs measurement is calculated by using the additional error for Impedance Ze [%] as follows.

If $Dx \leq 0.1$:

$$Rse [\%] = Ze / Dx$$

If $0.1 < Dx \leq 0.5$:

$$Rse [\%] = (Ze / Dx) \times \sqrt{(1 + Dx^2)}$$

Dx is the measured value of D and is calculated as follows.

$$Dx = 2 \times \pi \times f \times Csx \times Rsx,$$


where

f : measurement signal frequency

Csx : measured value of Cs

Rsx : measured value of Rs .

Figure 5-1 Additional Error for Impedance



Residual Inductance

Residual inductance for the Short Plate is as follows.

Model	Residual Inductance [nH]
16196A	0.43
16196B	0.27
16196C	0.16
16196D	0.11

Applying loading weight to the DUT

The following table shows the factory default of loading weight on the DUT for each model. For the 16196D, the user can replace a part (washer) inside the cap to change it. For the 16196A/B/C, however the loading weight on the DUT cannot be changed.

Agilent model number	Loading weight to the DUT [gf]
16196A/B/C	400
16196D	300

Changing the loading weight to the DUT for the 16196D

If the factory default loading weight damages the DUT, replace the part (washer) inside the cap, which changes the spring pressure, to adjust the loading weight on the DUT. Replacement washers must be prepared by users themselves.

NOTE

When the washer is replaced, the specifications and performance of this product are not guaranteed.

Information required to create washers is given below.


Table 5-1

Material and size of the washer

Material	Outer diameter [mm]	Inner diameter [mm]
Polyacetal	φ8.0 to φ12.0	φ3.2

Figure 5-2

Shape of the cap washer



16196abcdoe4003

Table 5-2

Relation between washer thickness and loading weight applied to the DUT (design values)

t [mm]	Loading weight to the DUT:G [gf]
1.0	120
1.5	180
2.0	240
2.5	300

The loading weight applied to the DUT, G [gf], is obtained by substituting the values of t [mm] into the following equation.

$$G \text{ [gf]} = 119 \times (3.55 + t) - 420$$


NOTE

If a washer with a thickness (t) of less than 1.0 mm is used, measurement may not be performed accurately.

Replacing the washer inside the cap

The procedure for replacing the washer inside the cap is described below.

Figure 5-3 Exploded view of the cap



16196abcdoj4005

Replacement procedure

1. Locate a replacement washer.
2. Detach the cap from the fixture.
3. Detach [1] then [2] while holding [7].
4. Detach [3] and [4] from [7].
5. Detach [5] from [7], and replace it with the replacement washer.
6. Attach [4] detached in Step 4 to [7].
7. While protruding [7] from [3], attach [2] detached in Step 3, and tighten [1] with a tightening torque of 0.2 Kgf-cm (0.2 in-lb).
8. Clean [7]. (See “User Maintenance” of the Chapter , “Cleaning.”)

NOTE

Be careful not to bolt inside parts out of the cap when detaching/attaching [1] and [2], because the spring [6] is powerful.

6 **Service**

This chapter describes the proper maintenance of the fixture and parts replacement.

Replaceable Parts


Check the part number by the exploded view below. Do not disassemble the fixture beyond what is shown in this exploded view.

To order parts, specify the Agilent part number. If the part, which is causing problems, is a part that cannot be disassembled, please order the part, which the affected part is, a part of. Sales and Service offices of Agilent Technologies also accept products for repairs.

Block Assembly

Figure 6-1

Block Assembly Exploded View



16196abcdoj4006

Table 6-1 Replaceable Parts (Block Assembly)

Ref. Desig.	Agilent Part No.	Qty.	Description
1	16196-60010	1	Cap Assembly (for 16196A/B/C)
	16196-60020	1	Cap Assembly (for 16196D)
2	0515-1044	2	Cap Screw Mach M1.6
3	16196-60112	1	φ1.34 Insulator (for 16196A)
	16196-60113	1	φ1.14 Insulator (for 16196A)
	16196-60114	1	φ1.08 Insulator (for 16196A)
	16196-60212	1	φ0.85 Insulator (for 16196B)
	16196-60213	1	φ0.75 Insulator (for 16196B)
	16196-60214	1	φ0.68 Insulator (for 16196B)
	16196-60312	1	φ0.48 Insulator (for 16196C)
	16196-60412	1	φ0.34 Insulator (for 16196D)
	16196-60414	1	φ0.30 Insulator (for 16196D)
4	N/A	1	Ground Assembly
5*1	16196-60111	1	Lower Electrode (for 16196A)
	16196-60211	1	Lower Electrode (for 16196B)
	16196-60311	1	Lower Electrode (for 16196C)
	16196-60411	1	Lower Electrode (for 16196D)
6	0515-0954	3	Screw M-2.5
7	16196-24001	1	Base
8	0515-0905	3	Screw M-2.5
9	16196-24004	1	Push Ring
10	16196-29002	1	Open Plate
11*1	16196-29026	1	Short Plate (for 16196A)
	16196-29027	1	Short Plate (for 16196B)
	16196-29028	1	Short Plate (for 16196C)
	16196-65101	1	Short Plate (for 16196D)

Table 6-1

Replaceable Parts (Block Assembly)


Ref. Desig.	Agilent Part No.	Qty.	Description
12	16196-00601	1	Plate (for 16196A)
	16196-00611	1	Plate (for 16196B)
	16196-00621	1	Plate (for 16196C)
	16196-00632	1	Plate (for 16196D)

*1. Maintenance Kit consisting of 5 replaceable parts is available. Refer to "Maintenance Kit" on page 74 for details.

Cap

Figure 6-2

Cap Exploded View (for 16196A/B/C)



16196abc0j0504


Table 6-2

Replaceable Parts (Cap)

Ref. Desig.	Agilent Part No.	Qty.	Description
1	0515-1044	1	Screw Mach M1.6
2	16196-24005	1	Stopper
3	N/A	1	Cap
4	1460-2618	1	Spring
5*1	16196-23008	1	Upper Electrode

*1. Maintenance Kit including 5 replaceable parts is available. Refer to “Maintenance Kit” on page 74 for details.

Figure 6-3 Cap Exploded View (for 16196D)



16196abcdoj4005

Table 6-3 Replaceable Parts (Cap)

Ref. Desig.	Agilent Part No.	Qty.	Description
1	0515-1077	1	Screw Mach M2
2	3050-2238	1	Washer
3	N/A	1	Cap
4	3050-2241	1	Washer
5	3050-2239	1	Washer
6	1460-2618	1	Spring
7*1	16196-23043	1	Upper Electrode

*1. Maintenance Kit including 5 replaceable parts is available. Refer to "Maintenance Kit" on page 74 for details.

Other Parts

Table 6-4

Replaceable Parts (Other Parts)

Ref. Desig.	Agilent Part No.	Qty.	Description
1	16196-60150	1	Carrying Case (for 16196A)
	16196-60250	1	Carrying Case (for 16196B)
	16196-60350	1	Carrying Case (for 16196C)
	16196-60450	1	Carrying Case (for 16196D)
2	16193-60002	2	Magnifying Glass
3	5182-7586	1	Cleaning Rod
4	8710-0909	1	Wrench 1.5 mm Hex
5	8710-2081	1	Tweezers
6	1540-0622	1	Case for OPEN and SHORT plate
7	9282-0114	1	Cushion

Maintenance Kit

The 16196U-maintenance kit is available to provide consumable products and replaceable parts for the 16196A/B/C/D.

16196U Maintenance Kit

The 16196A/B/C/D common option and options for each model separately are available.

Table 6-5 **16196A/B/C Common Option**

Opt010	Upper Electrode Set for 16196A/B/C (5 pieces)
--------	---

Table 6-6 **16196A Option**

Opt100	1608(mm) Short Plate Set (5 pieces)
Opt110	1608(mm) Lower Electrode Set (5 pieces)

Table 6-7 **16196B Option**

Opt200	1005(mm) Short Plate Set (5 pieces)
Opt210	1005(mm) Lower Electrode Set (5 pieces)

Table 6-8 **16196C Option**

Opt300	0603(mm) Short Plate Set (5 pieces)
Opt310	0603(mm) Lower Electrode Set (5 pieces)

Table 6-9 **16196D Option**

Opt020	Upper Electrode Set for 16196D (5 pieces)
Opt400	0402(mm) Short Plate Set (5 pieces)
Opt410	0402(mm) Lower Electrode Set (5 pieces)

Replacement Procedure


This section describes the replacement methods for the lower electrode, insulator and upper electrode. After replacing the respective parts, check the operation of the parts with reference to "Operation Check."

To replace the insulator and upper electrode, the 1.5-mm hex wrench (Agilent Part No. 8710-0909), included with the fixture, is required.

Lower Electrode

1. Prepare the replacement center electrode.
2. Take out the 3 screws from the bottom of the fixture and take out the DUT insert.


Figure 6-4 Removing the Bottom of the Fixture



16196abcj0505

3. Remove the lower electrode from the DUT insert.

Figure 6-5 Removing the Lower Electrode



16196abcj0506


4. Insert the replacement lower electrode in the DUT insert.

NOTE

The tip of the lower electrode is thin and easily bent. To prevent the tip of the lower electrode from contacting the inside of the DUT insert and being bent, insert the lower electrode vertically against the DUT's bottom surface.

5. Insert the DUT insert in the bottom of the fixture so that the bottom screws settle into the holes in the bottom of the fixture.

Figure 6-6 **Mounting the DUT Insert**



16196abccj0507

6. Fasten the DUT insert to the bottom of the fixture using the screws.

Insulator

Replace the insulator with reference to “Selecting and Changing the Insulator Assembly” on page 25.

Upper Electrode

1. Prepare the replacement electrode.
2. Remove the cap from the fixture.
3. Take out the screw from the top of the cap and remove the electrode from the cap.


NOTE

In case of the 16196D, take out the screw from the top of the cap while holding the electrode.

4. Take the electrode out of the spring and insert the replacement electrode.
5. Push the electrode in from the bottom of the cap so that the top of the electrode protrudes out of the top of the cap.

Figure 6-7

Electrode Replacement 1



16196abcj0508


Service
Replacement Procedure

- Place the stopper removed in step 3 so that the protrusion in the bottom aligns with the indent in the top of the electrode and tighten the screw.

NOTE

In case of the 16196D, while holding the electrode, attach the washer and tighten the screw. The tightening torque is 0.2 Kgf-cm (0.2 in-lb).

Figure 6-8 **Electrode Replacement 2**



16196abcoj0509

Assembling Check

The assembling check need to be performed following replacement of parts. The impedance measurement instrument or the network analyzer is required for the assembling check. The impedance measurement instrument is more recommendable. Refer to “Assembling Check” on page 53 for the procedure using the impedance measurement instrument.

The assembly check methods with the network analyzer are explained in the following.

NOTE

The network analyzer can be used only for the assembling check. The network analyzer has no function to measure DUT with the 16196A/B/C/D.

Method Using Network Analyzer

Required Tools

- Agilent 8753E
- Open plate
- Short plate

Procedure

Step 1. Conduct S11 full-calibration with the 7-mm connector to be connected to the fixture.

NOTE

For details on the calibration method, see the User’s Guide for the measuring instrument.

Step 2. Connect the fixture to the measuring instrument.

Step 3. Remove the cap and place the open plate on the insulator assembly. Then attach and fasten the cap.

Step 4. Set the measuring instrument as follows.

Measurement Parameter	Primary:Mag, Secondary:Phase
Power	-10 dBm
IF BW	100 Hz
Point Averaging	16
Port Extension	16196A: 26.2 mm 16196B: 26.9 mm 16196C: 27.1 mm 16196D: 27.3 mm

NOTE

For details on the setting and measurement procedures, see the User’s Manual for the

Service
Assembling Check

measuring instrument.

- Step 5.** Take Mag and Phase value readings at 100 MHz and 1 GHz and record the results. Check if the Mag and Phase values are within the typical value ranges shown in the following table.

Table 6-10 Operation Check Typical Values (Open, common for 16196A/B/C/D)

Parameter	Frequency	Typical Value (Absolute value)
Mag	100 MHz	-0.2 ~ 0.2
Mag	1 GHz	-0.2 ~ 0.2
Phase	100 MHz	-0.5° ~ 0.5°
Phase	1 GHz	-2.5° ~ 2.5°

- Step 6.** Remove the open plate, and place the short plate on the insulator assembly. Then attach and fasten the cap.
- Step 7.** Take Mag and Phase value readings at 100 MHz and 1 GHz in this short state and record the results. Check if the Mag and Phase values are within the typical value ranges shown in the following table.

Table 6-11 Operation Check Typical Values (Short, 16196A)

Parameter	Frequency	Typical Value (Absolute value)
Mag	100 MHz	-0.06 ~ -0.01
Mag	1 GHz	-0.18 ~ -0.03
Phase	100 MHz	178° ~ 180°
Phase	1 GHz	171° ~ 178°

Table 6-12 Operation Check Typical Values (Short, 16196B)

Parameter	Frequency	Typical Value (Absolute value)
Mag	100 MHz	-0.06 ~ -0.01
Mag	1 GHz	-0.19 ~ -0.04
Phase	100 MHz	179° ~ 180°
Phase	1 GHz	174° ~ 180°

Table 6-13 Operation Check Typical Values (Short, 16196C)

Parameter	Frequency	Typical Value (Absolute value)
Mag	100 MHz	-0.07 ~ -0.01
Mag	1 GHz	-0.20 ~ -0.04
Phase	100 MHz	179° ~ 180°
Phase	1 GHz	174° ~ 180°

Table 6-14

Operation Check Typical Values (Short, 16196D)

Parameter	Frequency	Typical Value (Absolute value)
Mag	100 MHz	-0.15 ~ 0
Mag	1 GHz	-0.40 ~ 0
Phase	100 MHz	179° ~ 180°
Phase	1 GHz	174° ~ 180°

Service
Assembling Check

Numerics

16196A Option, 74
 16196A/B/C Common Option, 74
 16196B Option, 74
 16196C Option, 74
 16196D Option, 74
 16196U Maintenance Kit, 74
 7-mm connector, 16

A

Accessories, 21
 adapter, 15
 Additional Error, 61
 Assembling Check, 53

B

Body Side Surfaces
 Cleaning Methods, 43

C

Cap
 Cleaning Methods, 43
 Functions, 20
 Places Requiring Cleaning, 41
 Replaceable Parts, 69
 Carrying Case
 16196A Package Contents, 12
 16196B Package Contents, 13
 16196C Package Contents, 13
 16196D Package Contents, 14
 Replaceable Parts, 73
 certification, 4
 Changes The Spring Pressure, 63
 Check Sheet
 Fill-Out Example, 49
 Cleaning
 Methods, 42
 Places Requiring, 41
 Cleaning Rod
 16196A Package Contents, 12
 16196B Package Contents, 12
 16196C Package Contents, 13
 16196D Package Contents, 14
 Functions, 21
 Replaceable Parts, 73

D

Dimension, 60
 Documentation Warranty, 4
 DUT
 Connecting and Measuring, 34
 Removing, 34
 DUT Insertion Hole
 Functions, 20

E

Electrical Length, 29
 Electrode Check, 53
 Electrode Structure, 19
 Electrode Wear Check
 Check Sheet, 50
 Fill-Out Example, 49
 Procedure, 48
 Reference Value Acquisition, 46

F

Fixture Compensation, 30
 Frequency
 Specifications, 60
 Functions, 20

I

Insulator Assembly
 16196A Package Contents, 12
 16196B Package Contents, 12
 16196C Package Contents, 13
 16196D Package Contents, 13
 Cleaning Methods, 42
 Functions, 21
 identifications, 22
 installing, 28
 Places Requiring Cleaning, 41
 Removing, 27
 Replaceable Parts, 69
 Selecting, 25
 Specifications, 25

L

Limit
 Electrode Check, 54
 Limits
 Short Plate Check, 57
 Lower Electrode
 Cleaning Methods, 42
 Places Requiring Cleaning, 41
 Replaceable Parts, 69
 Replacement Procedure, 76
 Ls, 47, 48, 54
 Electrode Check, 54
 Electrode Wear Check, 48
 Performance Check Representative Value, 82
 Short Plate Check, 56
 Short Plate Wear Check, 47, 48

M

Magnifying Glass
 16196A Package Contents, 12
 16196B Package Contents, 13
 16196C Package Contents, 13
 16196D Package Contents, 14

- Functions, 20
- Replaceable Parts, 73
- Maintenance Items, 39
- Maintenance Kit, 74
- Mark, 22
- Maximum Current, 60
- Maximum Voltage, 60

N

- Non Operating Environment, 60

O

- Open Compensation, 30
- Open Plate
 - 16196A Package Contents, 12
 - 16196B Package Contents, 12
 - 16196C Package Contents, 13
 - 16196D Package Contents, 13
 - Cleaning Methods, 42
 - Functions, 21
 - Open Compensation, 31
 - Places Requiring Cleaning, 41
 - Replaceable Parts, 69
- Open Repeatability, 61
- Operating Environment, 60
- Operation and Service Manual
 - 16196A Package Contents, 12
 - 16196B Package Contents, 13
 - 16196C Package Contents, 13
 - 16196D Package Contents, 14
- Opt010
 - 16196A/B/C Common Option, 74
- Opt020
 - 16196D Option, 74
- Opt100
 - 16196A Option, 74
- Opt110
 - 16196A Option, 74
- Opt200
 - 16196B Option, 74
- Opt210
 - 16196B Option, 74
- Opt300
 - 16196C Option, 74
- Opt310
 - 16196C Option, 74
- Opt400
 - 16196D Option, 74
- Opt410
 - 16196D Option, 74
- Option 710
 - 16196A Package Contents, 12
 - 16196B Package Contents, 13
 - 16196C Package Contents, 13
 - 16196D Package Contents, 14

P

- Package Contents
 - 16196A, 12
 - 16196B, 12
 - 16196C, 13
 - 16196D, 13
- Performance Check
 - Method Using Network Analyzer, 81
- Push Ring
 - 16196A Package Contents, 12
 - 16196B Package Contents, 12
 - 16196C Package Contents, 13
 - 16196D Package Contents, 14
 - Functions, 21
 - Removing the DUT, 35
 - Replaceable Parts, 69

R

- Reference Value
 - Electrode Wear Check, 46
- Replaceable Parts
 - Block Assembly, 69
 - Cap, 71, 72
 - Other Parts, 73
- Residual inductance, 33, 63
- Rs, 47, 48, 54
 - Electrode Check, 54
 - Electrode Wear Check, 48
 - Performance Check Representative Value, 82
 - Short Plate Check, 56
 - Short Plate Wear Check, 47, 48

S

- Safety Standards, 60
- Short Compensation, 32
- Short Plate
 - 16196A Package Contents, 12
 - 16196B Package Contents, 12
 - 16196C Package Contents, 13
 - 16196D Package Contents, 14
 - Cleaning Methods, 42
 - Functions, 21
 - Places Requiring Cleaning, 41
 - Replaceable Parts, 69
 - Residual inductance, 33, 63
 - Short Compensation, 32
- Short Plate Check, 56
- Short Plate Wear Check
 - Check Sheet, 51
 - Reference Value Acquisition, 47
- Short Repeatability, 61
- Specifications, 60
- Supplemental Performance Characteristics, 61

T

- Tweezers

16196A Package Contents, 12
16196B Package Contents, 12
16196C Package Contents, 13
16196D Package Contents, 14
Functions, 21
Replaceable Parts, 73

U

Upper Electrode
 Cleaning Methods, 42
 Places Requiring Cleaning, 41
 Replacement Procedure, 79
User Limit Values
 Setting Example, 44

W

Wear Check, 44
Weight, 60
Wrench
 16196A Package Contents, 12
 16196B Package Contents, 12
 16196C Package Contents, 13
 16196D Package Contents, 14
 Functions, 21
 Replaceable Parts, 73