
Caution



Do not exceed the operating input power, voltage, and current level and signal type appropriate for the instrument being used, refer to your instrument's Function Reference.



Electrostatic discharge(ESD) can damage the highly sensitive microcircuits in your instrument. ESD damage is most likely to occur as the test fixtures are being connected or disconnected. Protect them from ESD damage by wearing a grounding strap that provides a high resistance path to ground. Alternatively, ground yourself to discharge any static charge built-up by touching the outer shell of any grounded instrument chassis before touching the test port connectors.

Safety Summary

When you notice any of the unusual conditions listed below, immediately terminate operation and disconnect the power cable.

Contact your local Agilent Technologies sales representative or authorized service company for repair of the instrument. If you continue to operate without repairing the instrument, there is a potential fire or shock hazard for the operator.

- Instrument operates abnormally.
- Instrument emits abnormal noise, smell, smoke or a spark-like light during operation.
- Instrument generates high temperature or electrical shock during operation.
- Power cable, plug, or receptacle on instrument is damaged.
- Foreign substance or liquid has fallen into the instrument.

Herstellerbescheinigung

GERÄUSCHEMISSION

LpA < 70 dB
am Arbeitsplatz
normaler Betrieb
nach DIN 45635 T. 19

Manufacturer's Declaration

ACOUSTIC NOISE EMISSION

LpA < 70 dB
operator position
normal operation
per ISO 7779

DECLARATION OF CONFORMITY

According to ISO/IEC Guide 22 and CEN/CENELEC EN 45014

Manufacturer's Name: Agilent Technologies Japan, Ltd.
Manufacturer's Address: 1-3-2, Murotani, Nishi-ku, Kobe-shi,
Hyogo, 651-2241 Japan

Declares, that the product:

Product Name: Network Analyzer
Model Number: E5070A / E5071A
Product Options: This declaration covers all options of the above product(s)

Conforms with the following product standards:

EMC:	<u>Standard</u>	<u>Limit</u>
	IEC 61326-1:1997 +A1:1998 / EN 61326-1:1997 +A1:1998	
	CISPR 11:1997 / EN 55011:1998 +A1:1999	Group 1, Class A ⁽¹⁾
	IEC 61000-4-2:1995 / EN 61000-4-2:1995 +A1:1998	4 kV CD, 4 kV AD
	IEC 61000-4-3:1995 / EN 61000-4-3:1996 +A1:1998	3 V/m 80% AM 80 - 1000 MHz
	IEC 61000-4-4:1995 / EN 61000-4-4:1995	0.5 kV signal lines, 1 kV power lines
	IEC 61000-4-5:1995 / EN 61000-4-5:1995	0.5 kV line-line, 1 kV line-ground
	IEC 61000-4-6:1996 / EN 61000-4-6:1996	3 V 80% AM 0.15 - 80 MHz
	IEC 61000-4-11:1994 / EN 61000-4-11:1994	1 cycle, 100%
	Australia/New Zealand: AS/NZS 2064.1/2	
	Canada: ICES-001:1998	
Safety:	IEC 61010-1:1990 +A1:1992 +A2:1995 / EN 61010-1:1993 +A2:1995	
	CAN / CSA C22.2 No. 1010.1-92	

Conformity / Supplementary Information:

The product herewith complies with the requirements of the Low Voltage Directive 73/23/EEC and the EMC Directive 89/336/EEC (including 93/68/EEC) and carries the CE-marking accordingly (European Union).

LEDs in this product are Class 1 in accordance with EN 60825-1:1994.

⁽¹⁾ The product was tested in a typical configuration with Agilent Technologies test systems.

Kobe, Japan Oct. 17, 2001
Date


Name Koichi Yanagawa / Quality Engineering Manager

For further information, please contact your local Agilent Technologies sales office, agent or distributor.

Agilent E5070A/E5071A ENA Series RF Network Analyzers

User's Guide

Second Edition

FIRMWARE REVISIONS

This manual applies directly to instruments that have the firmware revision 2.00.

For additional information about firmware revisions, see Appendix A.



Agilent Technologies

Agilent Part No. E5070-90010

April 2002

Printed in Japan

Notices

The information contained in this document is subject to change without notice.

This document contains proprietary information that is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent of Agilent Technologies.

Agilent Technologies Japan, Ltd.

Component Test PGU-Kobe

1-3-2, Murotani, Nishi-ku, Kobe, Hyogo, 651-2241 Japan

© Copyright Agilent Technologies Japan, Ltd. 2001, 2002

Portions © Copyright 1996, Microsoft Corporation. All rights reserved.

Manual Printing History

The manual's printing date and part number indicate its current edition. The printing date changes when a new edition is printed (minor corrections and updates that are incorporated at reprint do not cause the date to change). The manual part number changes when extensive technical changes are incorporated.

December 2001 First Edition (part number: E5070-90000)

April 2002 Second Edition (part number: E5070-90010)

Safety Summary

The following general safety precautions must be observed during all phases of operation, service, and repair of this instrument. Failure to comply with these precautions or with specific WARNINGS elsewhere in this manual may impair the protection provided by the equipment. Such noncompliance would also violate safety standards of design, manufacture, and intended use of the instrument. Agilent Technologies assumes no liability for the customer's failure to comply with these precautions.

NOTE

The E5070A/E5071A complies with INSTALLATION CATEGORY II as well as POLLUTION DEGREE 2 in IEC61010-1. The E5070A/E5071A is an INDOOR USE product.

NOTE

The LEDs in the E5070A/E5071A are Class 1 in accordance with IEC60825-1, CLASS 1 LED PRODUCT








- Ground the Instrument
To avoid electric shock, the instrument chassis and cabinet must be grounded with the supplied power cable's grounding prong.
- DO NOT Operate in an Explosive Atmosphere
Do not operate the instrument in the presence of inflammable gasses or fumes. Operation of any electrical instrument in such an environment clearly constitutes a safety hazard.
- Keep Away from Live Circuits
Operators must not remove instrument covers. Component replacement and internal adjustments must be made by qualified maintenance personnel. Do not replace components with the power cable connected. Under certain conditions, dangerous voltage levels may remain even after the power cable has been disconnected. To avoid injuries, always disconnect the power and discharge circuits before touching them.
- DO NOT Service or Adjust the Instrument Alone
Do not attempt internal service or adjustment unless another person, capable of rendering first aid and resuscitation, is present.
- DO NOT Substitute Parts or Modify the Instrument
To avoid the danger of introducing additional hazards, do not install substitute parts or perform unauthorized modifications to the instrument. Return the instrument to an Agilent Technologies Sales and Service Office for service and repair to ensure that safety features are maintained in operational condition.
- Dangerous Procedure Warnings
Warnings, such as the example below, precede potentially dangerous procedures throughout this manual. Instructions contained in the warnings must be followed.



WARNING

Dangerous voltage levels, capable of causing death, are present in this instrument. Use extreme caution when handling, testing, and adjusting this instrument.

Safety Symbols

General definitions of safety symbols used on the instrument or in manuals are listed below.

-  Instruction Manual symbol: the product is marked with this symbol when it is necessary for the user to refer to the instrument manual.
-  Alternating current.
-  Direct current.
-  On (Supply).
-  Off (Supply).
-  In-position of push-button switch.
-  Out-position of push-button switch.

-  A chassis terminal; a connection to the instrument's chassis, which includes all exposed metal structure.
-  Stand-by.

WARNING This warning sign denotes a hazard. It calls attention to a procedure, practice, or condition that, if not correctly performed or adhered to, could result in injury or death to personnel.

CAUTION This Caution sign denotes a hazard. It calls attention to a procedure, practice, or condition that, if not correctly performed or adhered to, could result in damage to or destruction of part or all of the instrument.

NOTE This Note sign denotes important information. It calls attention to a procedure, practice, or condition that is essential for the user to understand.

Certification

Agilent Technologies certifies that this product met its published specifications at the time of shipment from the factory. Agilent Technologies further certifies that its calibration measurements are traceable to the United States National Institute of Standards and Technology, to the extent allowed by the Institution's calibration facility or by the calibration facilities of other International Standards Organization members.

Warranty

This Agilent Technologies instrument product is warranted against defects in material and workmanship for a period corresponding to the individual warranty periods of its component products. Instruments are warranted for a period of one year. Fixtures and adapters are warranted for a period of 90 days. During the warranty period, Agilent Technologies will, at its option, either repair or replace products that prove to be defective.

For warranty service or repair, this product must be returned to a service facility designated by Agilent Technologies. Buyer shall prepay shipping charges to Agilent Technologies, and Agilent Technologies shall pay shipping charges to return the product to Buyer. However, Buyer shall pay all shipping charges, duties, and taxes for products returned to Agilent Technologies from another country.

Agilent Technologies warrants that its software and firmware designated by Agilent Technologies for use with an instrument will execute its programming instruction when properly installed on that instrument. Agilent Technologies does not warrant that the operation of the instrument, or software, or firmware will be uninterrupted or error free.

Limitation of Warranty

The foregoing warranty shall not apply to defects resulting from improper or inadequate maintenance by Buyer, Buyer-supplied software or interfacing, unauthorized modification or misuse, operation outside the environmental specifications for the product, or improper site preparation or maintenance.

IMPORTANT

No other warranty is expressed or implied. Agilent Technologies specifically disclaims the implied warranties of merchantability and fitness for a particular purpose.

Exclusive Remedies

The remedies provided herein are Buyer's sole and exclusive remedies. Agilent Technologies shall not be liable for any direct, indirect, special, incidental, or consequential damages, whether based on contract, tort, or any other legal theory.

Assistance

Product maintenance agreements and other customer assistance agreements are available for Agilent Technologies products.

For any assistance, contact your nearest Agilent Technologies Sales and Service Office. Addresses are provided at the back of this manual.

Typeface Conventions

Sample (bold)	Boldface type is used when a term is defined or emphasis.
<i>Sample (Italic)</i>	Italic type is used for emphasis.
Sample key	Indicates a hardkey (key on the front panel or external keyboard) labeled “Sample.” “key” may be omitted.
Sample menu/button/box	Indicates a menu/button/box on the screen labeled “Sample” which can be selected/executed by clicking. “menu,” “button,” or “box” may be omitted.
Sample block/toolbar	Indicates a block (group of hardkeys) or a toolbar (setup toolbar) labeled “Sample.”
Sample 1 - Sample 2 - Sample 3	Indicates a sequential operation of Sample 1 , Sample 2 , and Sample 3 (menu, button, or box). “-” may be omitted.

Documentation Map

The following manuals are available for the Agilent E5070A/E5071A.

- ***User's Guide (Part Number E5070-900x0, attached to Option ABA)***

This manual describes most of the basic information needed to use the E5070A/E5071A. It provides a function overview, detailed operation procedure for each function (from preparation for measurement to analysis of measurement results), measurement examples, specifications, and supplemental information. For programming guidance on performing automatic measurement with the E5070A/E5071A, please see the *Programming Manual*.
- ***Installation and Quick Start Guide (Part Number E5070-900x1, attached to Option ABA)***

This manual describes installation of the instrument after it is delivered and the basic procedures for applications and analysis. Refer to this manual when you use the E5070A/E5071A for the first time.
- ***Programmer's Guide (Part Number E5070-900x2, attached to Option ABA)***

This manual provides programming information for performing automatic measurement with the E5070A/E5071A. It includes an outline of remote control, procedures for detecting measurement start (trigger) and end (sweep end), application programming examples, a command reference, and related information.
- ***VBA Programmer's Guide (Part Number E5070-900x3, attached to Option ABA)***

This manual provides programming information for performing automatic measurement with the E5070A/E5071A's internal programming function (VBA). It includes an outline of remote control, procedures for detecting measurement start (trigger) and end (sweep end), application programming examples, a command reference, and related information.

NOTE

The number position shown by "x" in the part numbers above indicates the edition number. This convention is applied to each manual, CD-ROM (for manuals), and sample programs disk issued. Here, "0" indicates the initial edition, and each time a revision is made this number is incremented by 1. The latest edition allows the customer to specify Option ABJ (Japanese) or Option ABA (English) of the product.

Microsoft®, MS-DOS®, Windows®, and Visual Basic® for Applications are registered trademarks of Microsoft Corporation in U.S. and other countries.

1. Precautions	
Software Installed	22
2. Overview of Functions	
Front Panel: Names and Functions of Parts	24
1. Standby Switch	25
2. LCD Screen	25
3. ACTIVE CH/TRACE Block	26
4. RESPONSE Block	27
5. STIMULUS Block	28
6. Floppy Disk Drive	28
7. NAVIGATION Block	29
8. ENTRY Block	30
9. INSTR STATE Block	31
10. MKR/ANALYSIS Block	32
11. Test Port	32
12. Front USB Port	33
13. Ground Terminal	33
Screen Area: Names and Functions of Parts	34
1. Menu Bar	34
2. Data Entry Bar	34
3. Softkey Menu Bar	36
4. Instrument Status Bar	38
5. Channel Window	40
Rear Panel: Names and Functions of Parts	46
1. Power Cable Receptacle (to LINE)	47
2. Line Switch (Always ON)	47
3. Rear USB port	47
4. External Trigger Input Connector (Ext Trig)	47
5. External Monitor Output Terminal (Video)	47
6. GPIB Connector	47
7. High Stability Frequency Reference Output Connector (Ref Oven, Option 1E5 only)	48
8. External Reference Signal Input Connector (Ref In)	48
9. Internal Reference Signal Output Connector (Ref Out)	48
10. Ethernet Port	48
11. Certificate of Authenticity Label	49
12. Printer Parallel Port	49
13. Serial Number Plate	49
14. Mini-DIN Keyboard Port	49
15. Mini-DIN Mouse Port	49
16. Handler I/O Port	49
17. Fan	49
3. Setting Measurement Conditions	
Initializing Parameters	52
Setting Up Channels and Traces	53
Number of Channels and Channel Window Arrangement	56
Active Channel	57



Number of Traces and Arrangement	57
Active Trace	58
Stimulus Settings	59
Setting sweep type	59
Setting the Frequency Range	59
Setting the Power Level	62
Setting the Number of Points	62
Setting the Sweep Time	63
Selecting Measurement Parameters	65
Definition of S-Parameters	65
Setting Up S-Parameters	65
Selecting a Data Format	66
Rectangular Display Formats	66
Polar Format	67
Smith Chart Format	68
Selecting a Data Format	69
Setting the Scales	70
Auto Scale	70
Manual Scale Adjustment on a Rectangular Display Format	70
Manual Scale Adjustment on the Smith Chart/Polar Format	72
Setting the Value of a Reference Line Using the Marker	72
Setting Window Displays	73
Maximizing the Specified Window/Trace Display	73
Turning Off the Display of Graticule Labels	73
Erasing the Frequency Labels	74
Labeling a Window	74
Setting display colors	75
4. Calibration	
Measurement Errors and their Characteristics	78
Drift Errors	78
Random Errors	78
Systematic Errors	79
Calibration Types and Characteristics	83
OPEN/SHORT Response Calibration (Reflection Test)	85
Procedure	86
THRU Response Calibration (Transmission Test)	88
Procedure	88
1-Port Calibration (Reflection Test)	91
Procedure	91
Full 2-Port Calibration	93
Procedure	94
Full 3-Port Calibration	96
Procedure	97
Full 4-Port Calibration	99
Procedure	100
ECal (Electronic Calibration)	102
1-Port Calibration Using a 2-Port ECal Module	102
Full 2-Port Calibration Using the 2-Port ECal Module	103

Full 3-Port and Full 4-Port Calibration Using the 2-Port ECal	105
Operation Method	105
Calibration using 4-port ECal	108
Operational procedure	108
Changing the Calibration Kit Definition	110
Definitions of Terms	110
Defining Parameters for Standards	111
Redefining a Calibration Kit	113
Default Settings of Pre-defined Calibration Kits	116
5. Making Measurements	
Setting Up the Trigger and Making Measurements	122
Trigger Model	122
Sweep Order in Each Channel	123
Trigger Source	123
Trigger Modes	124
Setting Up the Trigger and Making Measurements	124
6. Data Analysis	
Analyzing Data on the Trace Using the Marker	128
About Marker Functions	128
Reading Values on the Trace	128
Reading the Relative Value From the Reference Point on the Trace	130
Reading Only the Actual Measurement Point/Reading the Value Interpolated Between Measurement Points	131
Setting Up Markers for Each Trace/Setting Up Markers for Coupled Operations Between Traces	131
Listing All the Marker Values in All the Channels Displayed	133
Setting Up the Marker Response Value Display in Smith Chart/Polar Data Format	134
Searching for the Maximum and Minimum Measured Values	135
Searching for the Target Value (Target Search)	136
Searching for the Peak	139
Automatically Executing a Search Each Time a Sweep is Done (Search Tracking)	141
Determining the Mean, Standard Deviation, and p-p of the Trace	142
Determining the Bandwidth of the Trace (Bandwidth Search)	143
Comparing Traces/Performing Data Math	145
Performing Data Math Operations	145
Performing parameter conversion of measurement result	147
Operational procedure	147
7. Fixture Simulator	
Overview of Fixture Simulator	150
Functions for single-ended (unbalanced) port	151
Balance-unbalance conversion (option 313, 314, 413, or 414)	151
Functions for balanced port (option 313, 314, 413, or 414)	152
Extending the Calibration Plane Using Network De-embedding	153
Using the Network De-embedding Function	153
Converting the Port Impedance of the Measurement Result	154
Converting the Port Impedance	154

Determining Characteristics After Adding a Matching Circuit	155
Using the Matching Circuit Function	155
Evaluating Balanced Devices (balance-unbalance conversion function).	158
Measurement parameters of balanced devices	160
Steps for Balance-Unbalance Conversion	163
Steps for Measurement Parameter Setups.	164
Converting reference impedance of balanced port	165
Converting port reference impedance in differential mode	166
Converting port reference impedance in common mode	166
Determining the Characteristics that Result from Adding a Matching Circuit to a Differential Port	167
Example of using fixture simulator	169
Measurement circuit example for a DUT with balanced port	169
Evaluation using an actual test fixture	169
Problems in measurement with an actual test fixture	170
DUT evaluation using the E5070A/E5071A's fixture simulator	171
Advantages of balanced DUT evaluation using fixture simulator	173
8. Analysis in Time Domain (Option 010)	
Overview	176
Overview of time domain measurement.	176
Comparison to time domain reflectometry (TDR) measurement	176
Time domain function of E5070A/E5071A	177
Transformation to time domain	178
Flow of measurement	178
Selecting a type.	179
Setting the window	181
Calculating necessary measurement conditions	182
Setting the frequency range and the number of points	186
Setting display range.	186
Enabling transformation function	187
Deleting unnecessary data in time domain (gating)	188
Flow of measurement	188
Setting gate type	188
Setting gate shape	189
Setting gate range	190
Enabling gating function.	191
Characteristics of response in time domain	192
Masking	192
Identifying mismatch type	193
9. Data Output	
Saving and Recalling Instrument State.	196
File Compatibility in Save/Recall Operations	196
Procedure	197
Saving/recalling instrument state for each channel into/from memory	200
Operational procedure.	200
Saving Trace Data to a File	201
Saving Trace Data	201

Saving the Screen Image to a File	202
Saving the Screen Image to a File	202
Organizing Files and Folders	203
To open Windows Explorer	203
To copy a file or folder	203
To move a file or folder	204
To delete a file or folder	204
To rename a file or folder	204
To format a floppy disk	204
Using a Printer to Output the Screen Image	205
Available printers (supported printers)	205
Printed/saved screen image	206
Printing the screen image	206
Registering the printer	210
Installing printer driver	213
10. Limit Test	
Limit Test	216
Concept	216
Defining the Limit Line	220
Turning the Limit Test ON/OFF	224
Initializing the Limit Table	224
Outputting the Test Result	224
11. Optimizing Measurements	
Expanding the Dynamic Range	228
Lowering the Receiver Noise Floor	228
Reducing Trace Noise	230
Turning on Smoothing	230
Improving the Accuracy of Phase Measurements	232
Electrical Delay	232
Port Extension	232
Phase Offset	233
Specifying the Velocity Factor	233
Reduce Measurement Error in High Temperature Environments	234
Procedure	234
Improving the Measurement Throughput	235
Using Fast Sweep Modes	235
Turning Off the Updating of Information Displayed on the LCD Screen	236
Turning Off System Error Correction	236
Performing a Segment-by-Segment Sweep (Segment Sweep)	237
Concept of the Segment Sweep	237
Conditions for Setting Up a Segment Sweep	238
Items that can be set for each segment	238
Sweep Delay Time and Sweep Time in a Segment Sweep	239
Frequency Base Display and Order Base Display	239
Procedure	241

12. Setting and Using the Control and Management Functions	
Setting the GPIB	248
Setting the GPIB	248
Setting the Internal Clock	249
Setting the Date and Time	249
Setting the Date/Time Display ON/OFF	250
Setup for the Mouse	251
Setup Step	251
Enable/Disable the Network Connection Function	254
Operating Step	254
Configuring the Network	255
Configuring the Network	255
Accessing to hard disk of the E5070A/E5071A from an external PC via LAN	258
Enabling access from external PC	258
Accessing to hard disk of E5070A/E5071A from external PC	260
Locking the Front Keys, Keyboard, and/or Mouse (Touch Screen)	261
Locking the Front Keys, Keyboard, and/or Mouse	261
Setting the Beeper (Built-in Speaker)	262
Setting the Operation Complete Beeper	262
Setting the Warning Beeper	262
Turning off the LCD Screen Backlight	263
Turning off the LCD Screen Backlight	263
Checking the product information	264
Checking the serial number	264
Checking the Firmware Revision	264
System Recovery	265
Notes on executing system recovery	265
Procedure to execute system recovery	265
Calibration of the Touch Screen	268
13. Controlling E5091A	
Connecting E5070A/E5071A and E5091A	270
Required devices	270
Connecting E5070A/E5071A and E5091A	270
Powering on	271
Setting E5091A	272
Selecting ID for E5091A	272
Assigning test ports	273
Displaying the E5091A property	273
Setting control line	274
Enabling control of E5091A	275
Calibration	276
Operational procedure	276
Performing Measurement	277
Trigger state and switching the setting of the E5091A	277
Operation	277
Connecting two E5091As	278

14. Measurement Examples

Measuring the SAW Bandpass Filter Using the Segment Sweep	280
Evaluation Steps	280
1. Determine the Segment Sweep Conditions	280
2. Create a Segment Sweep Table	282
3. Select the Segment Sweep as the Sweep Type	284
4. Execute the Calibration	284
5. Connect the DUT	284
6. Execute the Measurement	285
7. Define the Setup for Display	285
Evaluating a Duplexer	287
Evaluation Steps	287
1. Determine the Segment Sweep Conditions	287
2. Create a Segment Sweep Table	288
3. Select the Segment Sweep as the Sweep Type	289
4. Execute the Calibration	289
5. Connect the DUT	292
6. Define the Setup for Display	292
7. Execute the Measurement	293
8. Define the Setup for the Segment Display and Scale	293
9. Analyze the Parameters	294
10. Define the Setup for a Limit Table	296
11. Execute the Limit Test	299
Measuring the Deviation from a Linear Phase	302
Evaluation Steps	302
1. Connect the DUT	302
2. Define the Measurement Conditions	303
3. Execute the Calibration	303
4. Connect the DUT and Execute the Auto Scale	304
5. Specify the Electrical Delay	304
6. Measure the Deviation from a Linear Phase	305
Measuring an Unbalanced and Balanced Bandpass Filter	307
Evaluation Steps	307
1. Connecting the DUT	308
2. Setting the Measuring Conditions	308
3. Performing a Calibration	309
4. Setting a Balance Conversion Topology	310
5. Selecting Measurement Parameters	311
6. Extending the Calibration Plane (removing the cause of error)	312
7. Setting the Port Reference Impedances	313
8. Adding a Matching Circuit	314
Measuring parameters with cable	316
Overview of evaluation procedure	316
1. Setting the measurement conditions	316
2. Executing calibration	316
3. Connecting the DUT	317
4. Auto scale	317
5. Setting the time domain function	318
Evaluating transmission characteristics of a front end module	319

Overview of evaluation procedure	319
1. Determining measurement conditions	320
2. Setting channel window allocation	320
3. Setting the test ports	320
4. Setting control line	321
5. Setting sweep conditions	321
6. Setting balance conversion topology	322
7. Selecting measurement parameter	322
8. Executing calibration	322
9. Connecting DUT	324
10. Executing measurement	324
15. Specifications and Supplemental Information	
Definitions	328
Corrected System Performance	329
Uncorrected System Performance	334
Test Port Output (Source)	335
Test Port Input	337
General Information	341
Measurement Throughput Summary	346
Measurement capabilities	349
Source control	350
Trace functions	350
Data accuracy enhancement	351
Storage	352
System capabilities	352
Automation	353
16. Measurement Accessories	
Test Port Cables	356
N6314A 50 Ω N Type RF Cable (300 kHz ~ 9 GHz)	356
N6315A 50 Ω N Type RF Cable (300 kHz ~ 9 GHz)	356
Calibration Kits	357
For Devices with N Type Connectors	357
For Devices with 3.5 mm (SMA) Connectors	359
Adaptors	362
11853A 50 Ω N Type Accessory Kit	362
11878A N type to 3.5 mm Adaptor Kit	362
11854A 50 Ω BNC Accessory Kit	362
System Accessories	363
System Racks and Cases	363
GP-IB Cables	363
17. Information on Maintenance	
Backing Up the Data	366
Making Backup Files	366
Cleaning this Instrument	367
Cleaning an LCD	367

Maintenance of Test Ports and Other Connectors/Ports	367
Cleaning a Display Other than an LCD	367
Replacement of Parts with Limited Service Life	368
Cautions Applicable to Requesting Repair, Replacement, Regular Calibration, etc.	369
Backing Up Data in the Hard Disk	369
Devices to be Sent Back for Repair or Regular Calibration	369
Recommended Calibration Period	369
A. Manual Changes	
Manual Changes	372
Change 1	373
B. Troubleshooting	
Troubleshooting	376
Troubleshooting during Startup	376
Troubleshooting during Operation	376
Troubleshooting for External Devices	379
Error Messages	380
A	380
B	380
C	380
D	381
E	381
F	382
G	383
H	383
I	383
L	384
M	384
N	384
O	385
P	385
Q	386
R	387
S	387
T	388
U	389
V	389
Warning Message	390
C. List of Default Values	
List of Default Values, Save/Recall Settings, and Backup Settings	392
D. Softkey Functions	
E5070A/E5071A Menu (Top Menu)	404
Analysis Menu	405
Average Menu	413
Calibration Menu	414

Contents

Display Menu	424
Format Menu	428
Macro Setup Menu	429
Marker Menu	430
Marker Function Menu	432
Marker Search Menu	433
Measurement Menu	435
Measurement Menu (Balance Measurement, SE-Bal)	436
Measurement Menu (Balanced Measurement, Bal-Bal)	437
Measurement Menu (Balanced Measurement, SE-SE-Bal)	439
Preset Menu	441
Save/Recall Menu	442
Scale Menu	444
Stimulus Menu	445
Sweep Setup Menu	446
System Menu	448
Trigger Menu	452
E. General Principles of Operation	
System Description	454
Synthesized Source	454
Source Switcher	455
Signal Separator	455
Receiver	455
Data Processing	456
ADC	456
Digital Filter	456
IF Range Correction	457
Ratio Calculation	457
Port Characteristics Correction	457
Sweep Averaging	457
Raw Data Array	457
Error Correction/Error Correction Coefficient Array	457
Port Extension	457
Fixture Simulator	457
Corrected Data Array	457
Corrected Memory Array	458
Data Math	458
Electrical Delay/Phase Offset	458
Data Format/Group Delay	458
Smoothing	458
Formatted Data Array/Formatted Memory Array	458
Offset/Scale	458
Display	458
F. Replacing the 8753ES with the E5070A/E5071A	
Important Functional Differences	460
Channel and Trace Concepts	460

Measurement Parameters	460
Test Port Output Ranges	460
Sweep Function	461
Calibration	462
Trigger System	463
Data Flow	464
Reading/Writing Data	466
Screen Display and Marker Functions	466
Math Operation Functions on Traces	466
Device Test Functions	467
Analytical Functions	467
Save/Recall	467
Test Sequence Program	467
Outputting to a Printer/Plotter	467
GPIB Interface	468
LAN Interface	468
Other Functions	468
Comparing Functions	469

1 Precautions

This chapter describes cautions that must be observed in operating the E5070/E5071A.

Software Installed

The Windows operating system installed in this machine is customized for more effective operation, and has different functions that are not part of the Windows operating system for ordinary PCs (personal computers).

Therefore, do not attempt to use the system in ways other than those described in this manual or to install Windows-based software (including anti-virus software) for ordinary PCs as doing so may cause malfunctions.

Also note the followings.

- Do not update the Windows operating system installed in this machine to the Windows operating system for ordinary PCs. Doing so will cause malfunctions.
- Do not attempt to update VBA (Visual Basic for Applications) software installed in this machine to its equivalent developed for ordinary PCs. Doing so will cause malfunctions.
- Do not allow any computer virus to infect the system. This machine has no virus check function nor anti-virus software installed.

Agilent Technologies will not be held liable for any failure or damage arising from negligence regarding these prohibitions and warnings.

NOTE

If the pre-installed software is damaged somehow, resulting in errant behavior by the machine, perform a system recovery. For further details of system recovery, refer to “System Recovery” on page 265.


2 Overview of Functions

This chapter describes the functions of the E5070/E5071A that can be accessed from the front panel, LCD screen, and rear panel.

Front Panel: Names and Functions of Parts

This section describes the names and functions of parts on the front panel of the E5070/E5071A. For more about the functions displayed on the LCD screen, see “Screen Area: Names and Functions of Parts” on page 34. For more about the functions of softkeys, see Appendix D, “Softkey Functions,” on page 403.

Figure 2-1 Front Panel



e5070aue061

1. Standby Switch

Used for choosing between power-on (|) and standby (⏻) states of the E5070/E5071A.

NOTE

To turn off the power for the E5070/E5071A, be sure to follow the steps described below.

1. First, press this standby switch, or send a shutdown command from the external controller to activate the shutdown process (the processing of software and hardware necessary to turn off the power supply). This will put the E5070/E5071A into the standby state.
2. Next, if necessary, turn off the power supply to the “1. Power Cable Receptacle (to LINE)” on page 47 on the rear panel.

Under normal use, never directly interrupt the power supply to the power cable receptacle on the rear panel when the power supply is on. Always keep the “2. Line Switch (Always ON)” on page 47 at (|). Never turn it off (⏻).

If you directly interrupt the power supply to the power cable receptacle when the power supply is on, or turn off the “2. Line Switch (Always ON)” on page 47, the shutdown process will not work. This could damage the software and hardware of the E5070/E5071A and lead to device failure.

Turning on the power supply after a faulty shutdown may cause the system to start up in a condition called “safe mode”. If this occurs, first shut down the system to put it into the standby state, and then turn on the power supply again and start up the system in normal mode.

For more about turning the power supply on/off and putting it into the standby state, see Chapter 1 “Installation Guide” in the *Installation and Quick Start Guide*.

2. LCD Screen

A 10.4-inch TFT color LCD used for displaying traces, scales, settings, softkeys, etc. Either a standard color LCD or touch screen color LCD (Option 016) are available. The touch screen LCD allows you to manipulate softkeys by touching the LCD screen directly with the finger. For more about the LCD screen, see “Screen Area: Names and Functions of Parts” on page 34.

NOTE

Do not press the surface of the LCD screen (both standard and touch screen types) with a sharp object (e.g., a nail, pen, or screwdriver). Pressing the surface with a sharp-pointed object will damage the LCD screen surface or cause the screen to fail. Be especially careful when using a touch screen LCD.

3. ACTIVE CH/TRACE Block

A group of keys for selecting active channels and traces. For more about the concepts of channels and traces, see “Setting Up Channels and Traces” on page 53.

Channel Next Key

Select the next channel as the active channel. (Each time the key is pressed causes the active channel to step up from the channel with the currently designated number to one with a larger channel number.) An active channel is one for which the frequency range, etc. are defined. To change the settings for a channel, use this key to first make the channel active.

Channel Prev Key

Select the previous channel as the active channel. (Each time the key is pressed causes the active channel to step down from the channel with the currently designated number to one with a smaller channel number.)

Trace Next Key

Select the next trace as the active trace. (Each time the key is pressed causes the active trace to step up from the trace with the currently designated number to one with a larger channel number.) An active trace is one for which the measurement parameters, etc. are defined. To change the settings for a trace, use this key to first make the trace active.

Trace Prev Key

Select the previous trace as the active trace. (Each time the key is pressed causes the active trace to step down from the trace with the currently designated number to one with a smaller trace number.)

4. RESPONSE Block

A group of keys used mainly for setting up response measurements on the E5070/E5071A.

Channel Max Key

Changes between normal and maximum display of the active channel window. In normal display, all the defined channel windows (both active and non-active) are displayed in split views on the screen. In maximum display, only the active channel window is displayed over the entire area, with non-active windows not displayed. To maximize the active channel, double-click the channel window frame. Measurements are also carried out on the non-active channels that are not displayed.

Trace Max Key

Changes between normal and maximum display of the active trace. In normal display, all traces defined on the channel (both active and non-active) are displayed on the screen. In maximum display, only the active trace is displayed over the entire area, with non-active traces not displayed. To maximize the active trace, double-click the area inside the channel window (excluding the frame). Measurements are also carried out on the non-active traces not displayed.

Meas Key

Displays the Measurement softkey menu on the right side of the screen. Manipulating the Measurement menu enables you to specify the measurement parameters (types of S-parameters) for each trace.

Format Key

Displays the Format softkey menu on the right side of the screen. Manipulating the Format menu enables you to specify the data format (data transformation and graph formats) for each trace.

Scale Key

Displays the Scale softkey menu on the right side of the screen. Manipulating the Scale menu enables you to specify the scale for displaying a trace (magnitude per division, value of the reference line, etc.) for each trace. You can also specify the electrical delay and phase offset for each trace.

Display Key

Displays the Display softkey menu on the right side of the screen. Manipulating the Display menu enables you to specify the number of channels and channel window array, the number and arrangement of traces, the setup for data math, etc.

Avg Key










Displays the Average softkey menu on the right side of the screen. Manipulating the Average menu enables you to define the averaging, smoothing, and IF bandwidth.

Cal Key

Displays the Calibration softkey menu on the right side of the screen. Manipulating the Calibration menu enables you to turn the calibration and error correction on/off and change definitions for calibration kits.

5. STIMULUS Block

A group of keys for defining the stimulus values (signal sources and triggers).

 Key	Displays the data entry bar for specifying the sweep start frequency in the upper part of the screen. (It also displays the Stimulus softkey menu for specifying the sweep range on the right side of the screen.)
 Key	Displays the data entry bar for specifying the sweep stop frequency in the upper part of the screen. (It also displays the Stimulus menu in the same way as  .)
 Key	Displays the data entry bar for specifying the sweep center frequency in the upper part of the screen. (It also displays the Stimulus menu in the same way as  .)
 Key	Displays the data entry bar for specifying the frequency span in the upper part of the screen. (It also displays the Stimulus menu in the same way as  .)
 Key	Displays the Sweep Setup softkey menu on the right side of the screen. Manipulating the Sweep Setup menu enables you to specify the signal source power level, sweep time, number of points, sweep type, etc.
 Key	Displays the Trigger Setup softkey menu on the right side of the screen. Manipulating the Trigger menu enables you to specify the trigger mode and trigger source. Specify the trigger mode for each channel.

6. Floppy Disk Drive

A device for storing to and reading from a floppy disk the setup state of the E5070/E5071A, measurement data, calibration data, data on images displayed on the LCD screen, VBA (Visual Basic for Applications) programs, etc. The floppy disk drive is compatible with a 3.5-inch, 1.44 MB, DOS (Disk Operating System) formatted floppy disk.

A floppy disk access lamp is provided at the lower left of the floppy disk drive opening. When the floppy disk drive is accessing a disk (for reading or writing), this lamp will light up green.

A disk eject button is provided at the lower right of the floppy disk drive opening. Pressing this button causes the inserted floppy disk to be ejected.

NOTE

Insert a floppy disk into the floppy disk drive opening **right side up** in the direction of the arrow marked on the disk.

Do not press the disk eject button while the floppy disk access lamp is on. Trying to forcefully pull the floppy disk out while the lamp is on may damage the floppy disk or disk drive.






7. NAVIGATION Block

The keys and knob in the NAVIGATION block are used to navigate between softkey menus, tables (limit table, segment table, etc.), or a selected (highlighted) area in a dialog box, or to change a numeric value in the data entry area by stepping up or down. When selecting one of two or more objects (softkey menus, data entry areas, etc.) to manipulate with the NAVIGATION block keys displayed on the screen, first press the **Focus** key in the “8. ENTRY Block” on page 30 to select the object to be manipulated (focus on the object) and then manipulate the NAVIGATION block keys (knob) to move your selection (highlighted object) or change numeric values.

In the following, you will see how the NAVIGATION block keys work both when the focus is on a softkey menu and when the focus is in the data entry area. For more about manipulating tables and dialog boxes, refer to the manipulation procedure for each of those functions.

When the focus is in a softkey menu (the softkey menu is selected)





When the focus is placed on a softkey menu (the menu title area in the uppermost part is displayed in blue), the NAVIGATION block keys work as described below.

-  Knob (Turn clockwise or counterclockwise.) Moves the softkey selection (highlighted display) up or down.
-  Key Moves the softkey selection (highlighted display) up or down.
-  Key Displays the softkey menu one layer above.
-  Key Displays the softkey menu one layer below.
-  Knob or **Enter** key (to be pressed) Executes the function of the selected softkey.

After pressing the data entry softkey, the focus automatically moves to the data entry area.






When the focus is in the data entry area (the data entry area is selected)

When the focus is placed on the data entry area (the data entry bar is displayed in blue), the NAVIGATION block keys work as described below.

-  Knob (Turn clockwise or counterclockwise.) Increases or decreases the numeric value in the data entry area in small steps.
-  Key Increases or decreases the numeric value in the data entry area in large steps.
-  Key Moves the cursor (|) in the data entry area laterally back and forth. Use it together with the “8. ENTRY Block” keys to change data one character at a time.
-  Knob or **Enter** key (to be pressed) Finishes the entry in the data entry area, and moves the focus to the softkey menu.

8. ENTRY Block





A group of keys used for entering numeric data.



   ...  
Key (Numeric key)


Type numeric characters and a decimal point at the position of the cursor in the data entry area.

 Key


Alternately changes the sign (+, -) of a numeric value in the data entry area.

   
Key

Adds a prefix to the numeric data typed by using the numeric key and  and then enters that data. One of the two prefixes written on the surface of the key is automatically selected depending on the parameter to be entered.  is entered without a prefix being given.

Softkey On/Off
 Key

Turns off the data entry bar if it is displayed. If the dialog box is displayed, cancels the entry and close the dialog box. If the data entry bar and dialog box are not displayed, turns the softkey menu display on/off.

 Key







Deletes a character to the left of the cursor (|) in the data entry area. When two or more characters in the data entry area are selected (highlighted), deletes all the characters selected.

 Key

Changes the selection (focus) between the objects to be manipulated by the NAVIGATION block keys and ENTRY block keys. The objects to be manipulated by the NAVIGATION block keys and ENTRY block keys include softkey menus, data entry areas, tables (e.g., segment tables, limit tables, and marker tables), and dialog boxes. When two or more of these are displayed on the screen and need selecting, use this key to change the selection (focus) between the objects to be manipulated. When a softkey menu is selected, the menu name area at the top of the menu is displayed in blue. When a data entry area is selected, the data entry bar is displayed in blue. When a table is selected, the frame of the table window is displayed in light gray. While a dialog box is displayed, the focus is fixed on the dialog box and cannot be changed.

9. INSTR STATE Block

A group of the keys related to the macro function, store and call function, control/management function, and presetting the E5070/E5071A (returning it to the preset state).

 Key	Displays the VBA Macro softkey menu on the right side of the screen. Manipulating the VBA Macro menu enables you to start up the VBA editor, or create, call, or store a VBA project.
 Key	Executes a VBA procedure called “main” having a VBA module named Module1.
 Key	Stops the VBA procedure being executed.
 Key	Displays the Save/Recall softkey menu on the right side of the screen. Manipulating the Save/Recall menu enables you to store to or read from the internal hard disk or floppy disk the setup conditions, calibration data, and trace data of the analyzer.
 Key	First, temporarily saves the data for the image displayed on the LCD screen the moment this key is pressed ^{*1} to the internal memory (clipboard). Immediately after, displays the System softkey menu on the right side of the screen. Manipulating the System menu enables you to define the setup for and execute the limit test or define the setup concerning the control and management of the analyzer. Using the Dump Screen Image key enables you to store the image data in the clipboard to a file on the internal hard disk or a floppy disk. Also, using the Print key in the System menu enables you to print the image data in the clipboard to a printer.
 Key	Displays the Preset softkey menu on the right side of the screen. Pressing OK in the Preset menu enables you to return the analyzer to the initial setup state, called the preset setup. For the initial setup for each of the functions, see Appendix C, “List of Default Values,” on page 391.

*1. Strictly speaking, the temporary save occurs the moment the System softkey menu is manipulated. Therefore, this also occurs when the menu bar is used to execute **5 Instr State - 5 System**.

10. MKR/ANALYSIS Block

A group of keys used for analyzing the measurement results by using the markers, fixture simulator, etc. For functions of the keys in the MKR/ANALYSIS block, see Chapter 2 “Overview of Functions” in the *User’s Guide*.

Marker Key

Displays the Marker softkey menu on the right side of the screen. Manipulating the Marker menu enables you to turn the markers on/off and move them by entering stimulus values. You can place up to 10 markers on each trace.

Marker Search Key

Displays the Marker Search softkey menu on the right side of the screen. Manipulating the Marker Search menu enables you to move a marker to a specific point (maximum, minimum, peak, and a point with a target value) on a trace. You can also find the bandwidth parameters (up to six) and display them.

Marker Fctn Key

Displays the Marker Function softkey menu on the right side of the screen. Manipulating the Marker Function menu enables you to not only specify the marker sweep range and coupling of markers on a channel but also display statistics data on traces.

Analysis Key

Displays the Analysis softkey menu on the right side of the screen. Manipulating the Analysis menu enables you to use the analytical function called the fixture simulator.

11. Test Port

A port to which the DUT is connected. Option 213 and 214 each has two ports, Option 314 and 314 each has three ports, and Options 413 and 414 each has four ports. While signals are being output from a test port, the yellow LED above the test port lights up.

Connector type: 50 Ω , N-type, female

CAUTION



Do not apply a DC voltage or current to the test port. Applying a DC voltage or current may lead to device failure. In particular, there is a possibility of the capacitor remaining charged. Connect the measurement sample (DUT) to the test port (or the test fixture, cables, etc. connected to the test port) after the analyzer has been completely discharged.

The test ports comply with Installation Category I of IEC 61010-1.

12. Front USB Port

A USB (Universal Serial Bus) port (number of parts: 1) specifically for an ECal (Electronic Calibration) module, a multiport test set or a printer. Connecting a designated ECal module to this port enables ECal measurement to be performed. Connecting a designated printer to this port enables screen information on the E5070/E5071A to be printed to the printer. For more about executing ECal measurements, see Chapter 4, “Calibration,” on page 77, and for printing to a printer, see “Using a Printer to Output the Screen Image” on page 205. The specifications of this port are identical to the “3. Rear USB port” on page 47.

NOTE

We do not support connections to the USB port of devices other than designated printers, ECal modules and multiport test sets.

13. Ground Terminal


Connected to the chassis of the E5070/E5071A. You can connect a banana type plug to this terminal.

Screen Area: Names and Functions of Parts

This section describes the names and functions of parts on the LCD screen of the E5070/E5071A.

Figure 2-2

Screen Display



1. Menu Bar


By using the mouse and keyboard to manipulate the menu bar, you can perform interface operations that are equivalent to those of the keys in the ACTIVE CH/TRACE block, RESPONSE block, STIMULUS block, MKR/ANALYSIS block, and INSTR STATE block on the front panel of the E5070/E5071A. The menus on the menu bar correspond to the key blocks, and their submenus to the hardkeys inside the key blocks.

2. Data Entry Bar

Used to enter numeric data into the E5070/E5071A. Press a hardkey or softkey to enter data, and the data entry bar will appear at the top of the screen. To assign a title to a channel window, an entry bar that allows you to enter letters and symbols by using the front panel keys or mouse is displayed instead.

Figure 2-3

Data Entry Bar



NOTE

To manipulate the data entry bar using the front panel keys, the data entry bar must be selected as the object to be manipulated (with the focus placed on it). When the focus is placed on the data entry bar, the entire bar is displayed in blue. Pressing or clicking **Focus** in the “8. ENTRY Block” on page 30 enables you to move the focus to the desired object.

2-1. Parameter Name

Displays the name of the parameter for which data will be entered.

2-2. Data Entry Area

When the data entry bar is displayed for the first time, the current settings are displayed on it. You can change numeric values by typing from the keyboard or in the ENTRY block on the front panel.

2-3. Step Button (Small)

Increases or decreases the numeric value in the data entry area in small steps. Use the mouse to manipulate this button.

2-4. Step Button (Large)

Increases or decreases the numeric value in the data entry area in large steps. Use the mouse to manipulate this button.

2-5. Enter Button

After typing numeric values in the data entry area by using the keyboard or the numeric keys in the ENTRY block on the front panel, press this button to finish the entry. Use the mouse to manipulate this button.


2-6. Close Button

Closes the data entry area (turns off the display). Use the mouse to manipulate this button.

3. Softkey Menu Bar

A group of keys on the screen called by the hardkeys and menu bars. You can manipulate these keys by using the NAVIGATION block keys on the front panel, the mouse, or the keyboard. When a touch screen LCD (Option 016) is used, you can perform manipulations by directly touching the screen with your finger instead of using a mouse.

Figure 2-4



NOTE

To manipulate a menu bar, it has to be selected as the object to be manipulated (with the focus placed on it). When the focus is placed on a menu bar, the menu title area at the top is displayed in blue. Pressing or clicking on **Focus** of “8. ENTRY Block” on page 30 enables you to move the focus to the desired object.

3-1. Softkey Menu Title

The title of the softkey menu is displayed here. Double-clicking on this part of the menu bar displays the top layer of softkeys.













3-2. Scroll Arrow (Large)

When the softkeys in a menu overflow the screen, using this key enables you to scroll the menu page by page. Both upward and downward scroll arrows are available. Use the mouse to manipulate these buttons.

3-3. Softkeys

These are the actual keys you would use to perform setup. A ► displayed to the right of a softkey indicates that pressing that softkey will display the lower layer of softkeys.

3-4. Highlighted Softkey

Pressing  and  on the front panel or pressing  on the keyboard causes the highlighted (selected) softkey to be executed. You can change which softkey in the menu is highlighted by turning  or pressing   on the front panel, or by pressing   on the keyboard. Pressing the  key on the front panel or the  key on the keyboard brings up the upper level softkey menu and pressing the  key on the front panel or the  key on the keyboard brings up the lower level softkey menu.

3-5. Selection Mark

Shows which softkey function is currently selected.

3-6. Softkey Status Display

Displays the setup status of that softkey.

3-7. Scroll Bar

When the softkeys in a menu overflow the screen, clicking on the blank part of this scroll bar enables you to scroll the softkey menu up or down.

3-8. Scroll Box

You can scroll the softkey menu up or down by using the mouse to select and drag the scroll box (pressing the button on the object to be moved and then releasing the button at the desired location). The length and position of the scroll box represent the ratio and position of the currently displayed part to the length of the entire softkey menu.


3-9. Scroll Arrow (Small)

Using this button, you can scroll the menu one softkey at a time. Both upward and downward scroll arrows are available. Use the mouse to manipulate these buttons.

4. Instrument Status Bar

E5070/E5071A The bar that displays the status of the entire instrument.

Figure 2-5 Instrument Status Bar



4-1. Instrument Message/Warning

Displays instrument messages and warnings. Instrument messages are displayed in gray and warnings in red. For the meanings of the instrument messages and warnings, see Appendix B, “Troubleshooting,” on page 375

4-2. Measurement Status

Displays the measurement status of the E5070/E5071A.

Setup	Setup for measurement in progress
Hold	Measurement on hold (idling)
Init	Measurement being initialized
Man	The trigger source is set to “Manual” and waiting for trigger.
Ext	The trigger source is set to “External” and waiting for trigger.
Bus	The trigger source is set to “Bus” and waiting for trigger.
Meas	A measurement is in progress.

4-3. VBA Status

Displays the state of the execution of the VBA program in the E5070/E5071A.

Run	A VBA program is currently running.
Stop	A VBA program has stopped.

4-4. External Reference Signal Phase Lock

When the frequency reference signal is input to the “8. External Reference Signal Input Connector (Ref In)” on page 48 on the rear panel, and the measurement signal of the

E5070/E5071A is phase-locked to the reference signal, **ExtRef** is displayed in blue.

ExtRef (displayed in blue) Measurement signal is phase-locked to the external reference signal

ExtRef (displayed in gray) Measurement signal is not phase-locked to the external reference signal.

NOTE

Even when the “7. High Stability Frequency Reference Output Connector (Ref Oven, Option 1E5 only)” on page 48 and “8. External Reference Signal Input Connector (Ref In)” on page 48 are connected, phase-locking may not occur immediately after power-on in a low-temperature environment. (The “ExtRef” display remains gray, not turning blue.) In such a case, wait a few minutes until the instrument has warmed up and the “ExtRef” display turns blue.

4-5. Warm-up Status

Ready (displayed in blue) Shows the warm-up in the instrument is completed.

Ready (displayed in gray) Shows the warm-up in the instrument is not completed.

4-6. Service Mode

Indicates the service mode status.

SVC (displayed in blue) The E5070/E5071A is in service mode, which is used for self-diagnosis and repair of the E5070/E5071A. Therefore, measurement performance will not be guaranteed according to the specifications. If, under normal use, the system remains in the service mode and does not return to normal operating mode, there is a possibility that the instrument is out of order.

SVC (displayed in red) An abnormal condition has been detected inside the E5070/E5071A. The unit may be damaged. Contact the Customer Contact listed at the end of this brochure or the distributor from whom the unit was purchased.

SVC (displayed in gray) The E5070/E5071A is in normal mode.

4-7. Date / Time

Displays the date and time generated by the internal clock. The display format is as follows:

YYYY-MM-DD HH:MM **YYYY:** Year (AD)
 MM: Month
 DD: Day
 HH:MM: Time (0:00 to 23:59)


You can turn the date and time display on/off by manipulating the keys: **[System]** - **Clock Setup** - **Show Clock**.

5. Channel Window

Windows for displaying traces. Because a channel corresponds to a window, it is called a channel window. When the outer frame of a channel window is displayed in light gray, the channel is the active channel (the channel for which setup is being performed). In Figure 2-2 on page 34, channel 1 (the upper window) is the active channel. To make a channel active, use **Channel Next** or **Channel Prev**. Clicking inside a channel window will also make a channel active.

Figure 2-6

Channel Window





e5070aue073

5-1. Channel Title Bar

You can assign a title to each channel and have the title displayed on the bar. For more about setting up a channel title bar, see “Labeling a Window” on page 74.

5-2. Trace Name/Measurement Parameter

The names of the traces (Tr1 through Tr9) on the channel and their measurement parameters are displayed here. ► to the right of the trace name indicates the active trace (the trace for which setup is being performed). To make a trace active, use **Trace Next** or **Trace Prev**. Clicking the line where the trace name is placed (the mouse pointer changes from  to ) also makes a trace active.

5-3. Data Format

The data format of each trace is displayed here. For more on setting up data formats, see “Selecting a Data Format” on page 66.

5-4. Scale Settings

The scale setting for each trace is displayed here. This example shows that $10.00\text{dB}/\text{div}$ corresponds to 10 dB per division. “Ref 0.000dB” shows that the value of the reference line is at 0 dB. For more about setting scales, see “Setting the Scales” on page 70.



5-5. Trace Status Area

The setup for each trace is displayed here.

Table 2-1 Trace Status Display

Classification	Contents inside the []	Meaning
Error correction	RO RS RT F1 F2 F3 F4	Error correction: ON (OPEN (n) response calibration) Error correction: ON (SHORT (n) response calibration) Error correction: ON (THRU (n) response calibration) Error correction: ON (1-port calibration) Error correction: ON (Full 2-port calibration) Error correction: ON (Full 3-port calibration) Error correction: ON (Full 4-port calibration)
Turning on/off traces	Nothing M D&M off	Data trace: ON, Memory trace: OFF Data trace: OFF, Memory trace: ON Data trace: ON, Memory trace: ON Data trace: OFF, Memory trace: OFF
Performing data math	D+M (D+M&M) D-M (D-M&M) D*M (D*M&M) D/M (D/M&M)	Execution of Data+Mem math Execution of Data-Mem math Execution of Data*Mem math Execution of Data/Mem math
Electrical delay	Del	A numeric value other than 0 (zero) is specified as the electrical delay or phase offset.
Smoothing	Smo	Smoothing: ON
Parameter conversion	Zr Zt Yr Yt 1/S	Conversion: ON (Impedance: Reflection measurement) Conversion: ON (Impedance: Transmission measurement) Conversion: ON (Admittance: Reflection measurement) Conversion: ON (Admittance: Transmission measurement) Conversion: ON (Inverse S-parameter)

5-6. Reference Line Indicators

The indicators that indicate the position of the reference line for the Y-axis scale in the rectangular display format. One indicator to the right and the other to the left of the scale. (► and ◄). To enter a numeric value for the position of the reference line, open the data entry bar using keys: **[Scale]** - **Reference Position**. You can also move the position of the reference line by placing the mouse pointer on either of the two reference line indicators (the pointer changes from  to ) , moving the indicator vertically with the left mouse button kept pressed, and then releasing the button at the desired location. (This mouse operation is called a drag-and-drop operation).

5-7. Trace Number


In the rectangular display format, the trace number is displayed in the same color as the trace at the right end of each trace.

5-8. Calibration Properties

Displays the status of the calibration between test ports on a channel in a matrix format.

Figure 2-7

Calibration Properties Display



e5070aue079

5-9. Channel Status Bar

The status of each channel is displayed here. (See parts 5-10 through 5-16.)

5-10. Channel Measurement Status

Displays the update status of traces on the channel.

- ! Measurement in progress. When the sweep time exceeds 1.5 seconds, ↑ is displayed at the point on the trace.
- # Invalid traces. The measurement conditions have changed, but the traces on the channel currently displayed have not been updated to match the new conditions.
- (No display) The measurement has not executed.

5-11. Error Calibration Status

Displays the execution status of error correction on the channel.

- Cor** (displayed in blue) Error correction: ON (valid for all traces)
- Cor** (displayed in gray) Error correction: ON (valid for parts of traces)
- Off** (displayed in gray) Error correction: OFF
- (displayed in gray) Error correction: ON (calibration data not available)
- C?** (displayed in blue) Error correction: ON (An interpolation process is in progress, or one or more among the IF bandwidth, the power level, the power range, the sweep time, the sweep delay, the sweep mode (step/swept), the sweep type (linear/segment) does not match that of the calibration.)
- C!** (displayed in blue) Error correction: ON (An extrapolation process is in progress)

5-12. Port Extension Status

Shows whether the port extension is turned ON or OFF.

PExt (displayed in blue)	Port extension: ON
(not displayed)	Port extension: OFF

5-13. Fixture Simulator Status

Shows whether the fixture simulator is turned ON or OFF.

Sim (displayed in blue)	Fixture simulator: ON
(not displayed)	Fixture simulator: OFF

5-14. Averaging Status

Displays the averaging factor and averaging count when averaging is turned on.

n/m (displayed in blue)	Averaging: ON (m: averaging factor; n: averaging count)
(not displayed)	Averaging: OFF

5-15. Sweep Range

Indicates the sweep range by using the start/stop or center/span.



5-16. IF Bandwidth

Indicates the IF bandwidth.

5-17. Channel Number

Indicates the channel number.

5-18. Graticule Labels

Y-axis divisions in the rectangular display format. When traces in the rectangular display format are overlaid, the Y-axis divisions for the active trace are displayed. The value of the reference line (the division line between ► and ◀) is entered numerically by opening the data entry bar using the keys: **Scale** + **Reference Value**. You can change values of the reference line at one division intervals by placing the mouse pointer in the area of the graticule label (the pointer changes from  to ) , moving the pointer vertically with the left mouse button pressed, and then releasing the button at the desired location.

5-19. Bandwidth Parameters

Turning on the bandwidth search function displays the bandwidth parameters here. For more about the bandwidth search function, see “Determining the Bandwidth of the Trace (Bandwidth Search)” on page 143.

5-20. Marker Numbers

The marker values are displayed in a list at positions 5-19, 5-20, and 5-21. Position 5-19 displays the marker numbers. For the active marker (the one for which setup and analysis are being performed), > is displayed to the left of the marker number. For the reference marker, △ is displayed instead of the marker number.

5-21. Marker Stimulus Values


The marker stimulus value for each marker (the frequency at the marker point) is displayed here.


5-22. Marker Response Values

The marker response value for each marker (the measurement value at the marker point) is displayed here. Two (or three) response values are displayed for data in Smith chart or polar display format.

5-23. Markers

The markers used for reading values on a trace. Up to 10 markers can be displayed for each trace.

 Active marker (the one for which setup and analysis are being performed)


 Non-active marker



n denotes a marker number. For the reference marker, however, nothing is displayed at the location of n. Clicking the marker or one of the “5-24. Marker Indicators” makes the marker active.

5-24. Marker Indicators

Indicates the positions of markers on the stimulus axis.

 Active marker indicator

 Non-active marker indicator

You can also move a marker to the desired position by placing the mouse pointer on the marker indicator or position of the marker itself (the pointer changes from  to ), moving the indicator vertically with the left mouse button pressed, and then releasing the button at the desired location.


5-25. Statistics Data

Turning on the statistics data function displays statistics data here. For more about the statistics data function, see “Determining the Mean, Standard Deviation, and p-p of the Trace” on page 142.

Rear Panel: Names and Functions of Parts

This section describes the names and functions of the parts on the rear panel of the E5070/E5071A.

Figure 2-8 Rear Panel



e5070aue062

1. Power Cable Receptacle (to LINE)

The receptacle (outlet) to which the power cable is connected.

NOTE

To feed power, use the included three-prong power cable with a ground conductor.

The plug attached to the power cable (on the power outlet side or device side of the cable) serves as the disconnecting device (device that cuts off power supply) of the E5070/E5071A. When the power supply must be cut off to avoid danger of electric shock or the like, pull out the power cable plug (on the power outlet side or device side of the cable). For the procedure for turning off the mains in normal use, see the description in “1. Standby Switch” on page 25.

For more about the power supply, see Chapter 2 “Installation” in the Installation and Quick Start Guide.

2. Line Switch (Always ON)

Always keep this switch on (I).

CAUTION

Do not use this switch to turn off (O) the mains. Doing so may cause the analyzer to fail. For more information, see the description of the “1. Standby Switch” on page 25.

3. Rear USB port

A USB (Universal Serial Bus) port (number of ports: 1) specifically for an ECal (Electronic Calibration), a multipoint test set or a printer. The specifications of this port are identical to the “12. Front USB Port” on page 33.

4. External Trigger Input Connector (Ext Trig)

A connector to which external trigger signals are input. This connector detects the downward transition from the HIGH state in TTL signals as the trigger signal. To use this connector to generate a trigger, you must set the trigger source to the “external” side. (Key operation: **Trigger** - **Trigger Source** - **External**).

Connector type: BNC connector, female

5. External Monitor Output Terminal (Video)

A terminal to which the external color monitor (display device) is connected. By connecting the color monitor to this terminal, the same information shown on the LCD screen of the main body can be displayed on an external color monitor.

Connector type: 15-pin VGA connector, female

6. GPIB Connector

General Purpose Interface Bus (GPIB). The connection of an external controller and other devices through this connector allows an automatic measurement system to be structured. For more about the automatic measurement system using the GPIB, see the Programmer’s Guide.

7. High Stability Frequency Reference Output Connector (Ref Oven, Option 1E5 only)

When Option 1E5 (High stability frequency reference) is installed, the reference signal is output from this connector.

Connector type: BNC connector, female
Output signal (Nominal): 10 MHz, +2 dBm

NOTE

When Option 1E5 (High stability frequency reference) is installed, connect this connector to the “8. External Reference Signal Input Connector (Ref In)” on page 48 by using the BNC(m)-BNC(m) cable included with the option.

8. External Reference Signal Input Connector (Ref In)

The reference signal input connector for phase-locking the measurement signal from the E5070/E5071A to the external frequency reference signal. Inputting the reference signal to this connector improves the accuracy and stability of the frequency of the measurement signal from the E5070/E5071A.

Connector type: BNC connector, female
Input signal (Nominal): 10 MHz \pm 10 ppm, 0 to +6 dBm

NOTE

When the frequency reference signal is input to this connector, the measurement signal from the E5070/E5071A is automatically phase-locked to the reference signal. When an input signal is not present, the frequency reference signal inside the E5070/E5071A is automatically used. The **ExtRef** on the instrument status bar is displayed in blue when the system is phase-locked to the external reference signal and in gray when not phase-locked.

When using Option 1E5 (High stability frequency reference), connect this connector to the “7. High Stability Frequency Reference Output Connector (Ref Oven, Option 1E5 only)” on page 48 by using the BNC(m)-BNC(m) cable included with the option.

9. Internal Reference Signal Output Connector (Ref Out)

A connector for outputting the internal frequency reference signal from the E5070/E5071A. By connecting this output connector to the external reference signal input connector of another device, the device can be phase-locked to the internal reference signal of the E5070/E5071A and used under this condition.

Connector type: BNC connector, female
Output signal (Nominal): 10 MHz, +2 dBm
Output impedance (Nominal): 50 Ω

10. Ethernet Port

A terminal for connecting the E5070/E5071A to a LAN (Local Area Network). Connecting this instrument to a LAN enables you to access the hard disk drive of this instrument from an external PC or to control this instrument by using telnet.

Connector type: 8-pin RJ-45 connector
Base standard: 10Base-T/100Base-TX Ethernet (automatic data rate selection)

11. Certificate of Authenticity Label

The label showing information of the “Certificate of Authenticity.”

12. Printer Parallel Port

The 25-pin parallel port for printer connection. Connecting a designated printer to this port allows screen information on the E5070/E5071A to be printed to a printer. For more about printing to a printer, see “Using a Printer to Output the Screen Image” on page 205.

13. Serial Number Plate

The seal showing the serial number of the product.

14. Mini-DIN Keyboard Port

The port to which a mini-DIN type keyboard is connected. The keyboard can be used to edit VBA programs inside the E5070/E5071A or to enter file names. Since the arrow keys and numeric keys on the keyboard work in the same way as the arrow keys and numeric keys on the front panel of the E5070/E5071A, you can use it instead of the front panel operation.

NOTE

Be sure to only use a keyboard designated for use with this instrument. Using a keyboard other than those designated may cause wrong actions to occur.

15. Mini-DIN Mouse Port

The port to which a mini-DIN type mouse is connected. Using a mouse enables you to more efficiently perform the operations of menu bars, softkeys, and dialog boxes as well as selecting an active channel or an active trace. The mouse also enables you to move a marker or the scale reference line using drag-and-drop operations.

NOTE

Be sure to only use a mouse designated for use with this instrument. Using a mouse other than those designated may cause wrong actions to occur.

16. Handler I/O Port

The terminal to which an automatic machine (handler) used on a production line is connected. For more about using the handler I/O port, see the Programmer’s Guide.

Connector type: 36-pin D-sub connector

17. Fan

The cooling fan for limiting the temperature rise inside the E5070/E5071A. This fan exhausts heated air from inside the analyzer to the outside.

Overview of Functions

Rear Panel: Names and Functions of Parts

3 Setting Measurement Conditions

This chapter describes how to set up the measurement conditions for the Agilent E5070/E5071A Network Analyzer.

Initializing Parameters

The E5070/E5071A has three different initial settings as shown in Table 3-1 below.

Table 3-1

E5070/E5071A Initial Settings and Methods for Restoring Them

Initial setting	Restore Method
Preset state	<ul style="list-style-type: none">• Press Preset - OK on the front panelor,• Execute SCPI commands :SYST:PRES.
*RST state	Execute the *RST command.
Factory default setting	(The way the E5070/E5071A is set up prior to shipment from the factory)


For further details of each setting, refer to Appendix C, “List of Default Values,” on page 391. To restore initial settings using commands, refer to the Programmer’s Guide and VBA Programmer’s Guide.

Setting Up Channels and Traces

Up to nine channels can be set up with the E5070/E5071A. In each channel, up to nine traces can be drawn. Thus, up to 81 traces can be drawn on the screen. Each channel has its own channel window, and the traces appear in the channel windows (each channel has a 1-to-1 relationship with a channel window).

Figure 3-1

Channels and Traces



e5070aue036

NOTE

Executing measurement of a channel does not depend on the channel's display status. You can even perform measurement of a channel with no display. See Chapter 5, "Making Measurements," on page 121 for details on the setup of measurement execution by each channel.

The traces actually measured are set by the number of traces in each channel. See "Number of Traces and Arrangement" on page 57 for how to set up the traces.

Setting Measurement Conditions
Setting Up Channels and Traces

Table 3-3 describes the setup items (analyzer, channel, or trace) and the effect that each parameter has on them.

Table 3-2 Parameters and Setup Items (Controlled Items)

Parameter	Setup Items (Controlled Items)			Setup Key(s)
	Analyzer	Channel	Trace	
Stimulus Settings				
Frequency range		√		<input type="button" value="Start"/> <input type="button" value="Stop"/> <input type="button" value="Center"/> <input type="button" value="Span"/>
Power		√		<input type="button" value="Sweep Setup"/> - Power/Power Ranges
Sweep time/Sweep delay time		√		<input type="button" value="Sweep Setup"/> - Sweep Time/Sweep Delay
Number of points		√		<input type="button" value="Sweep Setup"/> - Points
Segment sweep		√		<input type="button" value="Sweep Setup"/> - Sweep Type /Edit Segment Table/Segment Display
Sweep mode		√		<input type="button" value="Sweep Setup"/> - Sweep Mode
Trigger	√			<input type="button" value="Trigger"/> - Trigger Source/Restart/Trigger
Trigger mode		√(*1)		<input type="button" value="Trigger"/> - Hold/Hold All Channels /Single /Continuous/Continuous Disp Channels
Response Settings				
Measurement parameter			√	<input type="button" value="Meas"/>
Data format			√	<input type="button" value="Format"/>
Scale, Electrical delay, Phase offset			√(*2)	<input type="button" value="Scale"/>
Memory trace and data math			√	<input type="button" value="Display"/> - Display /Data → Mem /Data Math
Window title		√		<input type="button" value="Display"/> - Edit Title Label /Title Label (ON/OFF)
Graticule label in rectangular form		√		<input type="button" value="Display"/> - Graticule Label (ON/OFF)
Color inversion	√			<input type="button" value="Display"/> - Invert Color
Frequency display ON/OFF	√			<input type="button" value="Display"/> - Frequency (ON/OFF)
Display update ON/OFF	√			<input type="button" value="Display"/> - Update (ON/OFF)
Averaging		√		<input type="button" value="Avg"/> - Averaging Restart /Avg Factor/Averaging (ON/OFF)
Smoothing			√	<input type="button" value="Avg"/> - Smo Aperture /Smoothing (ON/OFF)
IF bandwidth		√		<input type="button" value="Avg"/> - IF Bandwidth
Calibration		√		<input type="button" value="Cal"/>

Table 3-2 Parameters and Setup Items (Controlled Items)

Parameter	Setup Items (Controlled Items)			Setup Key(s)
	Analyzer	Channel	Trace	
Marker			√(*3)	Marker Marker Search Marker Fctn
Analysis				
Fixture simulator		√(*4)		Analysis - Fixture Simulator
Limit test			√	Analysis - Limit Test
Time domain			√	Analysis - Gating Analysis - Transform
Parameter conversion			√	Analysis - Conversion
Saving and recalling data	√			Save/Recall
Macro	√			Macro Setup Macro Run Macro Break
System				
Printing/Saving display screen/Beeper/GRIB settings/Network settings/Date & Time/Key lock/Backlight/Firmware revision/Service menu	√			System
Preset	√			Preset

- *1. Hold **All Channels** for the analyzer.
- *2. **Auto Scale All** and scale **Divisions** must be set up in rectangular form for each channel.
- *3. Turning the marker table display on or off applies to the entire analyzer. On the other hand, the sweep range setting of the marker must be performed for each channel. In the preset conditions, marker coupling is enabled and marker settings and movements are effective for all traces on a channel.
- *4. The balanced-unbalanced conversion function (**BalUn ON/OFF**) must be turned on or off for each trace.

Number of Channels and Channel Window Arrangement

The number of channels to be displayed (up to nine channels) is automatically determined by selecting the arrangement of channel windows on the screen. There are fourteen patterns to select from (see Figure 3-2).


NOTE

The execution of measurements does not depend on the display status of each channel (measurements can be performed on channels that are not displayed). The user can set up each channel for measurements (by selecting the sweep mode and the trigger source) from the Chapter 5, “Making Measurements,” on page 121.

Selecting the Number of Channels & Channel Window Arrangement

- Step 1.** Press **Display**.
- Step 2.** Press **Allocate Channels**.
- Step 3.** Press the softkey that corresponds to the desired number of channels and channel window arrangement.

Figure 3-2 Channel Window Arrangements



e5070auj194

Active Channel

The channel whose settings are being changed is called the active channel. The active channel is displayed on the screen by highlighting its channel window. In order to change settings unique to a particular channel, it is necessary to make the channel “active.”

Use the following keys to select the active channel:

Hardkey	Function
<input type="button" value="Channel Next"/>	Selects the next channel by incrementing the channel number.
<input type="button" value="Channel Prev"/>	Selects the previous channel by decrementing the channel number.

Number of Traces and Arrangement

Up to nine traces can be drawn for each channel. You can select an arrangement of graphs within a channel window from the pre-defined patterns shown in Figure 3-3.

Traces are displayed based on the order determined from the graph arrangement currently being used.

NOTE


If the number of traces is less than the number of graphs, nothing will be displayed in the extra area(s). If the number of traces is more than the number of graphs, the remaining traces will be displayed by going back to the first graph, overlapping existing traces. For example, if is selected from the graph arrangement shown in Figure 3-3 and there are five traces to display, then Trace 1 and Trace 4 share Graph **Gr1**, and Trace 2 and Trace 5 share Graph **Gr2**. Graph **Gr3** displays only Trace 3.

Selecting the Number of Traces and Graph Arrangement

- Step 1.** Press or to select the channel in which the number of traces and arrangement will be set.
- Step 2.** Press .
- Step 3.** Press **Number of Traces**.
- Step 4.** Select the number of traces from **1** to **9**.
- Step 5.** Press **Allocate Traces**.
- Step 6.** Press the softkey that corresponds to the desired graph arrangement. (See Figure 3-3.)

Figure 3-3

Graph Arrangements



e5070auj195

Active Trace

The trace whose settings are being changed is called the active trace. The active trace is indicated on the screen by the ► to the left of its name (e.g., Tr3). In order to change the settings unique to a particular trace, the trace needs to be “active.”

Use the following keys to select the active trace:

Hardkey	Function
Trace Next	Selects the next trace by incrementing the trace number.
Trace Prev	Selects the previous trace by decrementing the trace number.

Stimulus Settings

Setting sweep type

The procedure to select the sweep type is as follows:

- Step 1.** Press **Channel Next** or **Channel Prev** to select the channel for which you want to set the number of points.
- Step 2.** Press **Sweep Setup**.
- Step 3.** Press **Sweep Type**.
- Step 4.** Press the desired softkey to select the sweep type.


Softkey	Function
Lin Freq	Selects the linear sweep.
Log Freq	Selects the logarithmic sweep.
Segment	Selects the linear sweep. For information on how to use the segment sweep, refer to “Performing a Segment-by-Segment Sweep (Segment Sweep)” on page 237.

Setting the Frequency Range

The E5070A and E5071A each allow the user to set the sweep frequency range from 300 kHz to 3 GHz and from 300 kHz to 8.5 GHz, respectively. The smallest unit of increment is 1 Hz in all frequency ranges. There are two ways to set the frequency range: by specifying the lowest and the highest values and by specifying the center value and a span. Once the frequency range is set, it is possible to change the range by substituting the lowest frequency, the highest frequency, or the center frequency with a value (stimulus value) represented by a marker on the trace. The frequency range is set independently for each channel.

Figure 3-4

Setting the Frequency Range



e5070aue120

Setting Measurement Conditions

Stimulus Settings

Setting the Range with the Lowest and Highest Values

- Step 1.** Press **Channel Next** or **Channel Prev** to select the channel for which the frequency range will be set.
- Step 2.** Press **Start**.
- Step 3.** Using the ENTRY block keys on the front panel, input the lowest frequency.
- Step 4.** Press **Stop**.
- Step 5.** Using the ENTRY block keys on the front panel, input the highest frequency.

Setting the Range with the Center Value and a Span

- Step 1.** Press **Channel Next** or **Channel Prev** to select the channel for which the frequency range will be set.
- Step 2.** Press **Center**.
- Step 3.** Using the ENTRY block keys on the front panel, input the center frequency.
- Step 4.** Press **Span**.
- Step 5.** Using the ENTRY block keys on the front panel, input a frequency span.

Setting the Frequency Range Using the Marker


- Step 1.** In the channel window whose range must be set, place the active marker on the active trace to a position that corresponds to the new range (to the lowest, highest, or center frequency).
- Step 2.** Press **Marker Fctn**.
- Step 3.** Press the softkey that corresponds to each frequency.

Softkey	Function
Marker → Start	Sets the lowest frequency to the stimulus value of the active marker on the currently active trace.
Marker → Stop	Sets the highest frequency to the stimulus value of the active marker on the currently active trace.
Marker → Center	Sets the center frequency to the stimulus value of the active marker on the currently active trace.

NOTE

If the reference marker is on and the stimulus value of the active marker is expressed by a value relative to the reference marker, the absolute stimulus value will be used to set the new frequency range.

Figure 3-5 Setting the Frequency Range Using the Marker



e5070aue118

3. Setting Measurement
Conditions

Setting the Power Level

The power level can be set to any value from –15 dBm to 0 dBm (–50 dBm to 0 dBm for models with Option 214, 314, or 414) with a minimum increment of 0.05 dB.

Setting the Power Level

- Step 1.** Press **Channel Next** or **Channel Prev** to select the channel for which the power level will be set.
- Step 2.** Press **Sweep Setup**.
- Step 3.** If Option 214, 314, or 414 is installed, follow the procedure below:
- Press **Power Ranges**.
 - Press the softkey that corresponds to the desired power range.

Softkey	Function
–15 to 0	Sets the power range to –15 dBm to 0 dBm.
–20 to –5	Sets the power range to –20 dBm to –5 dBm.
–25 to –10	Sets the power range to –25 dBm to –10 dBm.
–30 to –15	Sets the power range to –30 dBm to –15 dBm.
–35 to –20	Sets the power range to –35 dBm to –20 dBm.
–40 to –25	Sets the power range to –40 dBm to –25 dBm.
–45 to –30	Sets the power range to –45 dBm to –30 dBm.
–50 to –35	Sets the power range to –50 dBm to –35 dBm.

- Step 4.** Press **Power**.
- Step 5.** Using the ENTRY block keys on the front panel, input the power level.

Setting the Number of Points

The number of points is the number of data items collected in one sweep. It can be set to any number from 2 to 1601 for each channel independently.

- To obtain a higher trace resolution against the stimulus value, choose a larger number of points.
- To obtain higher throughput, keep the number of points to a smaller value within an allowable trace resolution.
- To obtain higher measurement accuracy after calibration, perform calibration using the same number of points as in actual measurements.

Setting the Number of Points

- Step 1.** Press **Channel Next** or **Channel Prev** to select the channel for which the number of points will be set.
- Step 2.** Press **Sweep Setup**.
- Step 3.** Press **Points**.
- Step 4.** Using the ENTRY block keys on the front panel, input the desired number of points.

Setting the Sweep Time

Sweep time is the time it takes to complete a sweep for each stimulus (source) port. Two modes are available for setting the sweep time: manual sweep time mode and automatic sweep time mode.

Manual Sweep Time Mode


In this mode, the sweep time is set manually. Once the sweep time is set, changes in measurement conditions will not affect the sweep time as long as it is within the analyzer's capability. If the sweep time becomes lower than the analyzer's lower sweep time limit, the sweep time will be reset to the shortest time within the conditions. If the sweep time exceeds the analyzer's upper sweep time limit, the sweep time will be reset to the longest time within the conditions.

Automatic Sweep Time Mode

The sweep time is always kept to the shortest time possible with the current measurement conditions.

Figure 3-6 shows the definitions of the sweep time and the sweep delay time.

Figure 3-6 Sweep Time and Sweep Delay Time



e5070aue119

Sweep delay is time before starting a sweep for each stimulus (source) port

Setting Measurement Conditions

Stimulus Settings

Setting Up the Sweep Time (Manual Sweep Time Mode)

- Step 1.** Press or to select the channel for which sweep time will be set.
- Step 2.** Press .
- Step 3.** Press **Sweep Time**.
- Step 4.** Using the ENTRY block keys on the front panel, input the desired sweep time (in seconds).

If the previous operation mode was automatic sweep time mode, entering a new sweep time forces the machine to switch to manual sweep time mode.

Switching to Automatic Sweep Time Mode

- Step 1.** Press or to select the channel which will be switched to automatic sweep time mode.
- Step 2.** Press .
- Step 3.** Press **Sweep Time**.
- Step 4.** Press . (By entering zero (seconds), automatic sweep time becomes effective.)

Selecting Measurement Parameters

The E5070/E5071A allows users to evaluate the DUT (device under test) characteristics using the following measurement parameters.

- S-parameters
- Mixed mode S-parameters

This section describes the definition of S-parameters and how to choose their values. For the definition and use of mixed mode S-parameters, refer to “Evaluating Balanced Devices (balance-unbalance conversion function)” on page 158.

Definition of S-Parameters

S-parameters (scattering parameters) are used to evaluate how signals are reflected by and transferred through the DUT. An S-parameter is defined by the ratio of two complex numbers and contains information about magnitude and phase of the signal. S-parameters are typically expressed as follows.

$S_{out\ in}$

out: port number of the DUT from which the signal is output

in: port number of the DUT to which the signal is input

For example, S-parameter S_{21} is the ratio of the output signal of port 2 on the DUT with the input signal of port 1 on the DUT, both expressed in complex numbers.

Setting Up S-Parameters

Step 1. Press **Channel Next** (or **Channel Prev**) and **Trace Next** (or **Trace Prev**) to select the trace for which measurement parameters will be set up.

Step 2. Press **Meas**.

Step 3. Press a softkey that corresponds to the desired S-parameter.

S-parameters on the softkeys are expressed as follows.

$S_{out\ in}$

out: test port number of the E5070/E5071A to which the DUT’s output signal is input

in: test port number of the E5070/E5071A from which the signal is applied to the DUT

Selecting a Data Format

The E5070/E5071A allows you to display measured S-parameters using the following data formats:


- Rectangular display formats
 - Log magnitude format
 - Phase format
 - Expanded phase format
 - Positive phase format
 - Group delay format
 - Linear magnitude format
 - SWR format
 - Real format
 - Imaginary format
- Polar format
- Smith chart format

Rectangular Display Formats

Rectangular display format draws traces by assigning stimulus values (sweep frequency on a linear scale) to the X-axis and response values to the Y-axis (see Figure 3-7). Eight different formats are available depending on the selection of data for the Y-axis (see Table 3-3).

Figure 3-7

Rectangular Display Format



e5070aue029

Table 3-3 Eight Types of Rectangular Display Formats

Type	Y-axis Data Type	Y-axis Unit	Application Examples
Log magnitude format	Magnitude	dB	<ul style="list-style-type: none"> •Return loss measurement •Insertion loss measurement (or gain measurement)
Phase format	Phase (displayed in the range from -180° to $+180^\circ$)	Degrees ($^\circ$)	•Measurement of the deviation from the linear phase
Expanded phase format	Phase (it is possible to display above $+180^\circ$ and below -180°)	Degrees ($^\circ$)	•Measurement of the deviation from the linear phase
Positive phase format	Phase (displayed in the range from 0° to $+360^\circ$)	Degrees ($^\circ$)	•Measurement of the deviation from the linear phase
Group delay format	Signal transfer delays within the DUT	Seconds (s)	•Group delay measurement
Linear magnitude format	Magnitude	(Abstract number)	•Reflection coefficient measurement
SWR format	$\frac{1 + \rho}{1 - \rho}$ (ρ : reflection coefficient)	(Abstract number)	•Measurement of the standing wave ratio
Real format	Real part of the measured complex parameter	(Abstract number)	
Imaginary format	Imaginary part of the measured complex parameter	(Abstract number)	


Polar Format

In the polar format, traces are drawn by expressing the magnitude as a displacement from the origin (linear) and phase in an angle counterclockwise from the positive X-axis. This data format does not have the frequency (stimulus) axis so, frequencies must be read using the marker. Also, the polar format allows users to select one of the following three data groups for displaying the marker response values.

- Linear magnitude and phase ($^\circ$)
- Log magnitude and phase ($^\circ$)
- Real and imaginary parts

Figure 3-8

Polar Format



e5070aue030


Smith Chart Format

The Smith chart format is used to display impedances based on reflection measurement data on the DUT. In this format, traces are plotted on the same spots as in the polar format. The Smith chart format allows users to select one of the following five data groups for displaying the marker response values.

- Linear magnitude and phase (°)
- Log magnitude and phase (°)
- Real and imaginary parts
- Resistance (Ω), reactance (Ω), and inductance (H) or capacitance (F)
- Conductance (S), susceptance (S), and capacitance (F) or inductance (H)

Figure 3-9

Smith Chart Format



Selecting a Data Format

Use the following procedure to select a data format.

- Step 1.** Press **Channel Next** (or **Channel Prev**) and **Trace Next** (or **Trace Prev**) to select the trace for which the data format will be set.
- Step 2.** Press **Format**.
- Step 3.** Press the softkey that corresponds to the desired data format.

Softkey	Function
Log Mag	Selects the log magnitude format.
Phase	Selects the phase format.
Group Delay	Selects the group delay format.
Smith - Lin / Phase	Selects the Smith chart format (with linear magnitude and phase as the marker response values).
Smith - Log / Phase	Selects the Smith chart format (with log magnitude and phase as the marker response values).
Smith - Real / Imag	Selects the Smith chart format (with the real and imaginary parts as the marker response values).
Smith - R + jX	Selects the Smith chart format (with resistance and reactance as the marker response values).
Smith - G + jB	Selects the Smith chart format (with conductance and susceptance as the marker response values).
Polar - Lin / Phase	Selects the polar format (with linear magnitude and phase as the marker response values).
Polar - Log / Phase	Selects the polar format (with log magnitude and phase as the marker response values).
Polar - Real / Imag	Selects the polar format (with the real and imaginary parts as the marker response values).
Lin Mag	Selects the linear magnitude format
SWR	Selects the SWR (standing wave ratio) format.
Real	Selects the real format
Imaginary	Selects the imaginary format
Expand Phase	Selects the expanded phase format
Positive Phase	Selects the positive phase format

Setting the Scales

Auto Scale

The auto scale function is used to tailor each scale (scale/division and the reference line value) automatically in such a way that traces will appear in the proper sizes on the screen for easy observation.

Single Trace Auto Scale

Follow the procedure below to perform the auto scale function only on a specific trace.

- Step 1.** Press **Channel Next** (or **Channel Prev**) and **Trace Next** (or **Trace Prev**) to select the trace for which the auto scale function will be performed.
- Step 2.** Press **Scale**.
- Step 3.** Press **Auto Scale**.

Auto Scale on All Traces Within a Channel

- Step 1.** Press **Channel Next** (or **Channel Prev**) to select the channel for which the auto scale function will be performed.
- Step 2.** Press **Scale**.
- Step 3.** Press **Auto Scale All**.

Manual Scale Adjustment on a Rectangular Display Format

For a rectangular display format, four parameters are used to manually adjust the scales. (See Table 3-3 and Figure 3-10.)


Table 3-4

Adjustable Scale Features on a Rectangular Display Format

Adjustable Feature	Description
Divisions (Divisions)	Defines the number of divisions on the Y-axis. An even number from 4 to 30 must be used. Once set, it is commonly applied to all traces displayed in any rectangular format within that channel.
Scale/Division (Scale/Div)	Defines the number of increments per division on the Y-axis. The value applies only to the active trace.
Reference position (Reference Position)	Defines the position of the reference line. The position must be specified using the number assigned to each division on the Y-axis starting at 0 (the least significant) running up to the number of divisions being used (the most significant). The position applies only to the active trace.
Reference line value (Reference Value)	Defines the value corresponding to the reference line. It must be set using the unit on the Y-axis. The reference line value applies only to the active trace.

Figure 3-10

Manual Scale Setup on a Rectangular Display Format



e5070aue032

Manually Setting Scales on a Rectangular Display Format

- Step 1.** Press **Channel Next** (or **Channel Prev**) and **Trace Next** (or **Trace Prev**) to select the trace for which scale features will be adjusted.
- Step 2.** Press **Scale**.
- Step 3.** Press the softkey that corresponds to the particular feature that needs to be adjusted.

Softkey	Function
Divisions	Defines the number of divisions on the Y-axis.
Scale/Div	Defines the number of increments per division on the Y-axis.
Reference Position	Defines the position of the reference line.
Reference Value	Defines the value corresponding to the reference line.

NOTE It is also possible to turn off the display of graticule labels. For details, refer to “Turning Off the Display of Graticule Labels” on page 73.


3. Setting Measurement Conditions

Manual Scale Adjustment on the Smith Chart/Polar Format

Manual scale adjustment on the Smith chart format or the polar format is done using the displacement (Scale/Div of the outermost circle. (See Figure 3-11.)

Figure 3-11

Manual Scale Setup on the Smith Chart/Polar Format



Manually Setting Scales on the Smith Chart/Polar Format

- Step 1.** Press **Channel Next** (or **Channel Prev**) and **Trace Next** (or **Trace Prev**) to select the trace for which the scale will be adjusted.
- Step 2.** Press **Scale**.
- Step 3.** Press **Scale/Div**.
- Step 4.** Using the ENTRY block keys on the front panel, input the displacement of the outermost circle.

Setting the Value of a Reference Line Using the Marker

When using a rectangular display format, it is possible to change the reference line value to be equal to the response value of the active marker on the active trace.

Setting the Reference Line Value Using the Marker

- Step 1.** Place the active marker on the active trace on the position that corresponds to the new reference line value.
- Step 2.** Press **Scale** or **Marker Fctn**.
- Step 3.** Press **Marker** → **Reference** to change the reference line value to the marker response value.

NOTE

If the reference marker is on and the stimulus value of the active marker is expressed using a value relative to the reference marker, the absolute stimulus value will be used to set the new reference line value.

Setting Window Displays

Maximizing the Specified Window/Trace Display

When using multiple channels, it is possible to maximize a specific channel window on the screen. When multiple traces are displayed in a channel window, it is also possible to maximize a specific trace display within that channel window.

Maximizing a Window

Step 1. Press **Channel Next** (or **Channel Prev**) to select the channel whose window will be maximized.

Step 2. Press **Channel Max** to maximize the channel window.

Press **Channel Max** one more time to reduce the window to its previous size.

Maximizing a Trace Display

Step 1. Press **Channel Next** (or **Channel Prev**) to select the channel to which the trace belongs.

Step 2. Press **Trace Next** (or **Trace Prev**) to select the trace whose display will be maximized.

Step 3. Press **Trace Max** to maximize the trace display.

Press **Trace Max** one more time to reduce the display to its previous size.

Turning Off the Display of Graticule Labels

When using a rectangular display format, the graph area can be expanded to the left by turning off the display of graticule labels.

Turning Off Graticule Label Display

Step 1. Press **Channel Next** (or **Channel Prev**) to select the channel for which graticule label display will be turned on or off.

Step 2. Press **Graticule Label** to turn graticule label display on or off.

Erasing the Frequency Labels

It is possible to set the analyzer so it does not show the frequency labels on the screen. When using this function, the frequency information cannot be read without manipulating the analyzer. Thus, this function provides an effective means of security.

Erasing the Frequency Labels

- Step 1.** Press **Display**.
- Step 2.** Press **Frequency** to turn off the frequency display.

NOTE

Turning off the frequency display using the **Frequency** key does not erase the frequency display within the Stimulus softkey, which is turned on by pressing **Start**, **Stop**, **Center**, and **Span**. The display of the softkey bar itself can be switched on or off by pressing **Softkey On/Off**.

Labeling a Window

It is possible to assign a unique name to a channel and display it on the screen. This feature is useful in saving and/or printing measurement result for future reference.

Labeling a Window

- Step 1.** Press **Channel Next** or **Channel Prev** to select the channel to be labeled.
- Step 2.** Press **Display**.
- Step 3.** Press **Edit Title Label**.

The title label input dialog box (see Figure 3-12) appears.

Figure 3-12

Title Label Input Dialog Box




- Step 4.** Using keys that appear in the dialog box, type a label and press **Enter**.
- Step 5.** Press **Title Label** to turn on the title display.

The title will appear within a frame at the top of the channel window (title bar). (See Figure 3-13.)

Figure 3-13

Title Display



Setting display colors

Selecting display mode

You can select the display mode of the LCD display from 2 modes: normal display (background: black) or inverted display (background: white). In normal display, the colors of items are preset so that you can recognize them easily on the display of the instrument. On the other hand, in inverted display, they are preset to colors obtained by almost inverting the default settings of the normal display so that you can use data easily when storing it into a graphic file.

The selection procedure is as follows:

- Step 1.** Press **[Display]**.
- Step 2.** Press **Invert Color** to select the display color. OFF indicates the normal display; ON the inverted display.

Setting display color for each item

You can set the display color to the normal display or the inverted display separately for each of the following items.

- Data/memory trace
- Labels and lines of graphs
- File display of the limit test and limit lines
- Background

You set the color of each item by specifying the amounts of red (R), green (G), and blue (B) contained in the color. You can specify each of R, G, and B in 6 steps (0 to 5). Therefore, 216 colors in total are available by combining them. The below table shows the R, G, and B values for main colors for reference purposes.

	R	G	B		R	G	B		R	G	B
White	5	5	5	Gray	2	2	2	Black	0	0	0
Light red	5	3	3	Red	5	0	0	Dark red	2	0	0
Light yellow	5	5	3	Yellow	5	5	0	Dark yellow	2	2	0
Light green	3	5	3	Green	0	5	0	Dark green	0	2	0
Light cyan	3	5	5	Cyan	0	5	5	Dark cyan	0	2	2
Light blue	0	0	5	Blue	0	0	5	Dark blue	0	0	2
Light magenta	5	3	5	Magenta	5	0	5	Dark magenta	2	0	2

The setting procedure is as follows:

- Step 1.** Press **[System]**.
- Step 2.** Press **Misc Setup**.
- Step 3.** Press **Color Setup**.
- Step 4.** Press **Normal** (for normal display) or **Invert** (for inverted display).

Setting Measurement Conditions

Setting Window Displays

Step 5. Press the softkey corresponding to the item for which you want to set the display color.

Softkey	Function
Data Trace 1 to 9	Specifies the data trace of traces 1 to 9.
Mem Trace 1 to 9	Specifies the memory trace of traces 1 to 9.
Graticule Main	Specifies the graticule label and the outer lines of graphs.
Graticule Sub	Specifies the grid of graphs.
Limit Fail	Specifies the fail display in the limit test result.
Limit Line	Specifies the limit line.
Background	Specifies the background.

Step 6. Press **Red**.

Step 7. Select the amount of red (R) from **0** to **5**.

Step 8. Press **Green**.

Step 9. Select the amount of green (G) from **0** to **5**.

Step 10. Press **Blue**.

Step 11. Select the amount of blue (B) from **0** to **5**.

Resetting the display colors to the factory state

You can reset the display colors in normal display and inverted display to the preset factory state.

The selection procedure is as follows:

Step 1. Press **[System]**.

Step 2. Press **Misc Setup**.

Step 3. Press **Color Setup**.

Step 4. Press **Normal** (for normal display) or **Invert** (for inverted display).

Step 5. Press **Reset Color**.

Step 6. Press **OK**.

4 Calibration

This chapter describes the calibration process to use with the Agilent E5070A/E5071A.

Measurement Errors and their Characteristics

It is important to understand factors contributing to measurement errors in order to determine the appropriate measures that should be taken to improve accuracy.

Measurement errors are classified into three categories:

- Drift errors
- Random errors
- Systematic errors

Drift Errors

Drift errors are caused by deviations in performance of the measuring instrument (measurement system) that occur after the calibration. Major causes are the thermal expansion of connecting cables and the thermal drift of the frequency converter within the measuring instrument. These errors may be reduced by carrying out frequent calibrations as the ambient temperature changes or by maintaining a stable ambient temperature during the course of a measurement.

Random Errors

Random errors occur irregularly along the time line. Since random errors are unpredictable, they cannot be eliminated in a calibration. These errors are further classified into the following sub-categories depending on their causes.

- Instrument noise errors
- Switch repeatability errors
- Connector repeatability errors

Instrument Noise Errors

Instrument noise errors are caused by electric fluctuations within components used in the measuring instrument. These errors may be reduced by increasing the power of signal supplied to the DUT, narrowing the IF bandwidth, and enabling sweep averaging.

Switch Repeatability Errors

Switch repeatability errors occur due to the fact that electrical characteristics of the mechanical RF switch used in the measuring instrument change every time it is switched on. These errors may be reduced by carrying out measurements under conditions in which no switching operation takes place.

You can ignore those errors since the E5070A/E5071A does not have mechanical RF switches.

Connector Repeatability Errors

Connector repeatability errors are caused by fluctuations in the electrical characteristics of connectors due to wear. These errors may be reduced by handling connectors with care.

Systematic Errors

Systematic errors are caused by imperfections in the measuring instrument and the test setup (cables, connectors, fixtures, etc.). Assuming that these errors are repeatable (i.e., predictable) and their characteristics do not change relative to time, then it is possible to eliminate these errors mathematically at the time of measurement by determining the characteristics of these errors in a calibration. There are six types of systematic errors, as follows.

Errors caused by signal leaks in the measuring system:

- Directivity
- Isolation (cross-talk)

Errors caused by reflections in the measuring system:


- Source match
- Load match

Errors caused by the frequency response of the receiver within the measuring instrument:

- Reflection tracking
- Transmission tracking

The E5070A/E5071A has 2 receivers for each test port, the reference receiver and the test receiver (transmission measurement or reflection measurement) and allows you to perform measurements using these receivers at the same time. Figure 4-1 shows the architecture of the test ports of the E5070A/E5071A and systematic errors.

Figure 4-1 E5070A/E5071A Port Architecture and Systematic Errors



Directivity error (Ed)

Directivity errors are caused by the fact that, in a reflection measurement, signals other than the reflection signal from the DUT are received by receiver T1 (see Figure 4-1) through the directivity coupler. When a certain port is a stimulus port, this error can be defined as a constant value for each stimulus port because the state of the termination at the other ports does not change. The number of directivity errors of the E5070A/E5071A is the number of stimulus ports you use.

Ed1	Directivity error of port 1
Ed2	Directivity error of port 2
Ed3 ^{*1}	Directivity error of port 3
Ed4 ^{*2}	Directivity error of port 4

*1. Options 313, 314, 413, and 414 only

*2. Options 413 and 414 only

Isolation error (Ex)

An isolation error (crosstalk error) is caused because signals other than the transmission signal of the DUT leak to the test receiver of the transmission measurement port in transmission measurement. When a certain port is a stimulus port, an isolation error is defined for each of the other ports. Therefore, the number of isolation errors of the E5070A/E5071A is the total number of the combinations of stimulus ports and response ports.

Ex21, Ex31 ^{*1} , and Ex41 ^{*2}	Isolation error when port 1 is a stimulus port.
Ex12, Ex32 ^{*1} , and Ex42 ^{*2}	Isolation error when port 2 is a stimulus port.
Ex13 ^{*1} , Ex23 ^{*1} , and Ex43 ^{*2}	Isolation error when port 3 is a stimulus port.
Ex14 ^{*2} , Ex24 ^{*2} , and Ex34 ^{*2}	Isolation error when port 4 is a stimulus port.

*1. Options 313, 314, 413, and 414 only

*2. Options 413 and 414 only

Source match error (Es)

A source match error is caused because the reflection signal of the DUT reflects at the signal source and enters into the DUT again. When a certain port is a stimulus port, this error can be defined as a constant value for each stimulus port because the state of the signal source switch does not change. The number of source match errors of the E5070A/E5071A is the number of stimulus ports you use.

Es1	Source match error of port 1
Es2	Source match error of port 2
Es3*1	Source match error of port 3
Es4*2	Source match error of port 4

*1. Options 313, 314, 413, and 414 only

*2. Options 413 and 414 only

Load match error (EI)

A load match error is caused because part of the signal transmitted in the DUT reflects at a response port and all of the signal is not measured by the receiver of the response port . When a certain port is a stimulus port, a load match error is defined for each of the other ports. Therefore, the number of load match errors of the E5070A/E5071A is the total number of the combinations of stimulus ports and response ports.

EI21, EI31*1, and EI41*2	Load match error when port 1 is a stimulus port.
EI12, EI32*1, and EI42*2	Load match error when port 2 is a stimulus port.
EI13*1, EI23*1, and EI43*2	Load match error when port 3 is a stimulus port.
EI14*2, EI24*2, and EI34*2	Load match error when port 4 is a stimulus port.

*1. Options 313, 314, 413, and 414 only

*2. Options 413 and 414 only

Reflection tracking error (Er)

A reflection tracking error is caused because the difference in frequency response between the test receiver and the reference receiver of a stimulus port in reflection measurement. This error can be defined as a constant value for each stimulus port because the combination of the test receiver and the reference receiver of a stimulus port is always the same. The number of reflection tracking errors of the E5070A/E5071A is the number of stimulus ports you use.

Er1	Reflection tracking error of port 1
Er2	Reflection tracking error of port 2
Er3*1	Reflection tracking error of port 3
Er4*2	Reflection tracking error of port 4

*1. Options 313, 314, 413, and 414 only

*2. Options 413 and 414 only

Transmission tracking error (Et)

A transmission tracking error is caused because the difference in frequency response between the test receiver of a response port and the reference receiver of a stimulus port in transmission measurement. When a certain port is a stimulus port, a transmission tracking error is defined for each of the other ports. Therefore, the number of transmission tracking errors of the E5070A/E5071A is the total number of the combinations of stimulus ports and response ports.

Et21, Et31^{*1}, and Et41^{*2} Transmission tracking error when port 1 is a stimulus port.

Et12, Et32^{*1}, and Et42^{*2} Transmission tracking error when port 2 is a stimulus port.

Et13^{*1}, Et23^{*1}, and Et43^{*2} Transmission tracking error when port 3 is a stimulus port.

Et14^{*2}, Et24^{*2}, and Et34^{*2} Transmission tracking error when port 4 is a stimulus port.

*1. Options 313, 314, 413, and 414 only

*2. Options 413 and 414 only

Calibration Types and Characteristics

Table 4-1 shows the different types of calibrations and the features of each method.

Table 4-1 Calibration Types and Characteristics

Calibration Method	Standard(s) Used	Corrected Error Factor	Measurement Parameters	Characteristics
No calibration	None	None	All parameters	<ul style="list-style-type: none"> • Low accuracy • Calibration not required
Response Calibration *1	<ul style="list-style-type: none"> •OPEN or SHORT*2 •LOAD*3 	Following 2 error terms: <ul style="list-style-type: none"> •Reflection Tracking (Er) •Directivity (Ed)*3 	S11 (Reflection characteristics at 1 port)	<ul style="list-style-type: none"> •Medium accuracy •Quick calibration •An isolation calibration improves the accuracy in a reflection measurement of the DUT that has high return loss
	<ul style="list-style-type: none"> •THRU •LOAD*3 	Following 2 error terms: <ul style="list-style-type: none"> •Transmission Tracking (Et) •Isolation (Ex)*3 	S21 (1 direction transmission characteristics at 2 ports)	<ul style="list-style-type: none"> •Medium accuracy •Quick calibration •An isolation calibration improves the accuracy in a transmission measurement of a device that has high insertion loss
1-Port Calibration	ECal module (2-port/4-port)	Following 3 error terms: <ul style="list-style-type: none"> •Directivity (Ed) •Source Match (Es) •Reflection Tracking (Er) 	S11 (Reflection characteristics at 1 port)	<ul style="list-style-type: none"> •Highly accurate 1-port measurement •Quick calibration with low chance of operator errors
	<ul style="list-style-type: none"> •OPEN •SHORT •LOAD 			<ul style="list-style-type: none"> •Highly accurate 1-port measurement (more accurate than the ECal)
Full 2-Port Calibration *1	ECal module (2-port/4-port)	Following 12 error terms: <ul style="list-style-type: none"> •Directivity (Ed1,Ed2) •Isolation (Ex21,Ex12)*3 •Source Match (Es1,Es2) •Load Match (El1,El2) •Transmission Tracking (Et21,Et12) •Reflection Tracking (Er1,Er2) 	S11,S21,S12,S22 (All S-parameters at 2 ports)	<ul style="list-style-type: none"> •Highly accurate 2-port measurement •Quick calibration with low chance of operator errors
	<ul style="list-style-type: none"> •OPEN •SHORT •LOAD •THRU 			<ul style="list-style-type: none"> •A 2-port measurement with the highest degree of accuracy
Full 3-Port Calibration *4*1	ECal module (2-port*5/4-port)	Following 2 error terms: <ul style="list-style-type: none"> •Directivity (Ed1,Ed2,Ed3) •Isolation (Ex21,Ex31,Ex12,Ex32,Ex13,Ex23)*3 •Source Match (Es1,Es2,Es3) •Load Match (El21,El31,El12,El32,El13,El23) •Transmission Tracking (Et21,Et31,Et12,Et32,Et13,Et23) •Reflection Tracking (Er1,Er2,Er3) 	S11,S21,S31,S12,S22,S32,S13,S23,S33 (All S-parameters at 3 ports)	<ul style="list-style-type: none"> •Highly accurate 3-port measurement •Quick calibration with low chance of operator errors
	<ul style="list-style-type: none"> •OPEN •SHORT •LOAD •THRU 			<ul style="list-style-type: none"> •A 3-port measurement with the highest degree of accuracy

Calibration
Calibration Types and Characteristics

Table 4-1 Calibration Types and Characteristics

Calibration Method	Standard(s) Used	Corrected Error Factor	Measurement Parameters	Characteristics
Full 4-Port Calibration *6*1	ECal module (2-port *5/ 4-port)	Following 2 error terms: <ul style="list-style-type: none"> •Directivity (Ed1,Ed2,Ed3,Ed4) •Isolation (Ex21,Ex31,Ex41,Ex12,Ex32,Ex42,Ex13,Ex23,Ex43,Ex14,Ex24,Ex34) *3 •Source Match (Es1,Es2,Es3,Es4) •Load Match (El1,El2,El3,El4) 	S11,S21,S31,S41,S12,S22,S32,S42,S13,S23,S33,S43,S14,S24,S34,S44 (All S-parameters at 4 ports)	<ul style="list-style-type: none"> •Highly accurate 4-port measurement •Quick calibration with low chance of operator errors compared with the full 4-port calibration using OPEN, SHORT LOAD, and THRU standards
	<ul style="list-style-type: none"> •OPEN •SHORT •LOAD •THRU 	<ul style="list-style-type: none"> •Transmission Tracking (Et21,Et31,Et41,Et12,Et32,Et42,Et13,Et23,Et43,Et14,Et24,Et34) •Reflection Tracking (Er1,Er2,Er3,Er4) 		<ul style="list-style-type: none"> •A 4-port measurement with the highest degree of accuracy


- *1. The user may select whether or not to carry out an isolation calibration.
- *2. A general principle is to use an open standard if the impedance of the device is larger than 50 Ω and a short standard if it is less.
- *3. Only when an isolation calibration is carried out. Isolation calibration is not performed when the 2 port ECal module and ECal Assistant VBA macro are used.
- *4. Only for options 313, 314, 413, and 414.
- *5. Used with the EcalAssistant VBA macro pre-installed in the E5070A/E5071A.
- *6. Only for options 413 and 414

OPEN/SHORT Response Calibration (Reflection Test)

In OPEN or SHORT response calibration, calibration data are measured by connecting an OPEN or SHORT standard, respectively, to the desired test port. For frequency response, these calibrations effectively eliminate the reflection tracking error from the test setup in a reflection test using that port (Figure 4-2). It is also possible to carry out isolation calibration with a LOAD standard during OPEN/SHORT response calibration. An isolation calibration will eliminate the directivity error from the test setup in a reflection test using that port (Figure 4-3).

Figure 4-2


1-Port Error Model (OPEN/SHORT Response)



e5070aue148

Figure 4-3

1-Port Error Model (OPEN/SHORT Response + Isolation)



e5070aue149

Calibration
OPEN/SHORT Response Calibration (Reflection Test)

Procedure

- Step 1.** Press .
- Step 2.** Press **Calibrate**.
- Step 3.** Select OPEN or SHORT response calibration.


Softkey	Function
Response (Open)	Displays softkeys for performing an open response calibration (response calibration with an OPEN standard).
Response (Short)	Displays softkeys for performing a SHORT response calibration (response calibration with a SHORT standard).

- Step 4.** Press **Select Port**.
- Step 5.** Select a test port upon which an OPEN/SHORT response calibration will be performed.

Softkey	Function
1	Selects port 1.
2	Selects port 2.
3	Selects port 3.
4	Selects port 4.

- Step 6.** According to the selection made in Step 3, connect an OPEN or SHORT calibration standard to the test port (connector to which the DUT will be connected) selected in Step 5.


Figure 4-4 Connecting the standard at OPEN/SHORT Response Calibration



e5070aue153

- Step 7.** Press **Open** or **Short** to start the calibration measurement.
- Step 8.** If an isolation calibration must be performed using a LOAD standard, follow the procedure below.
- Connect a LOAD standard to the test port (connector to which the DUT will be connected) selected in Step 5.

Figure 4-5 Connecting the Load Standard



e5070aue154

- Press **Load (Optional)** to start the measurement on the LOAD standard.
- Step 9.** Press **Done** to terminate the response calibration (and the LOAD isolation calibration) process. Upon pressing the key, calibration coefficients will be calculated and saved. The error correction function will also be automatically enabled.

NOTE


By pressing **Done**, previously saved calibration coefficients will be overwritten with new calibration coefficients. To cancel the calibration without saving the new calibration coefficients, press **Cancel - OK** successively.

THRU Response Calibration (Transmission Test)

In THRU response calibration, calibration data are measured by connecting a THRU standard to the desired test port. This calibration effectively eliminates the frequency response transmission tracking error from the test setup in a transmission test using that port (Figure 4-6). It is also possible to carry out an isolation calibration using a LOAD standard in the process of THRU response calibration. An isolation calibration will eliminate isolation error (crosstalk error) from the test setup in a transmission test using that port.

Figure 4-6


2-Port Error Model (Thru Response)



e5070aue150

Figure 4-7

2-Port Error Model (Thru Response + Isolation)



e5070aue151

Procedure

- Step 1. Press .
- Step 2. Press **Calibrate**.
- Step 3. Press **Response (Thru)**.
- Step 4. Press **Select Ports**.
- Step 5. Select the test ports (and corresponding S parameters) upon which a THRU response calibration will be performed.


Softkey	Function
2-1 (S21)	Selects test port 2 (input) and test port 1 (output). Corresponds to the determination of S ₂₁ .
3-1 (S31)	Selects test port 3 (input) and test port 1 (output). Corresponds to the determination of S ₃₁ .

Softkey	Function
4-1 (S41)	Selects test port 4 (input) and test port 1 (output). Corresponds to the determination of S_{41} .
1-2 (S12)	Selects test port 1 (input) and test port 2 (output). Corresponds to the determination of S_{12} .
3-2 (S32)	Selects test port 3 (input) and test port 2 (output). Corresponds to the determination of S_{32} .
4-2 (S42)	Selects test port 4 (input) and test port 2 (output). Corresponds to the determination of S_{42} .
1-3 (S13)	Selects test port 1 (input) and test port 3 (output). Corresponds to the determination of S_{13} .
2-3 (S23)	Selects test port 2 (input) and test port 3 (output). Corresponds to the determination of S_{23} .
4-3 (S43)	Selects test port 4 (input) and test port 3 (output). Corresponds to the determination of S_{43} .
1-4 (S14)	Selects test port 1 (input) and test port 4 (output). Corresponds to the determination of S_{14} .
2-4 (S24)	Selects test port 2 (input) and test port 4 (output). Corresponds to the determination of S_{24} .
3-4 (S34)	Selects test port 3 (input) and test port 4 (output). Corresponds to the determination of S_{34} .

Step 6. Make a THRU connection between the test ports (between the connectors to which the DUT will be connected) selected in Step 5.

Figure 4-8

Connecting at Thru Response Calibration




e5070aue155

Step 7. Press **Thru** to start the calibration measurement.

- Step 8.** If an isolation calibration must be performed using a LOAD standard, follow the procedure below.
- a. Connect a LOAD standard to each of the two test ports (connectors to which the DUT will be connected) selected in Step 5.

Figure 4-9 Connecting the Load Standard



e5070aue156

- b. Press **Isolation (Optional)** to start the calibration measurement.
- Step 9.** Press **Done** to terminate the response calibration (and the load isolation calibration) process. Upon pressing the key, calibration coefficients will be calculated and saved. The error correction function will also be automatically enabled.

NOTE


By pressing **Done**, previously saved calibration coefficients will be overwritten with new calibration coefficients. To cancel the calibration without saving the new calibration coefficients, press **Cancel - OK** successively.

1-Port Calibration (Reflection Test)

In 1-port calibration, calibration data are measured by connecting an OPEN standard, a SHORT standard, and a LOAD standard to the desired test port. This calibration effectively eliminates the frequency response reflection tracking error, directivity error, and source match error from the test setup in a reflection test using that port (Figure 4-10).

Figure 4-10

1-Port Error Model (1-Port Calibration)




e5070aue152

Procedure

Figure 4-11

Connecting the Standard at 1-Port Calibration



e5070aue157

Calibration
1-Port Calibration (Reflection Test)

- Step 1.** Press **Cal**.
- Step 2.** Press **Calibrate**.
- Step 3.** Press **1-Port Cal**.
- Step 4.** Press **Select Port**.
- Step 5.** Select a test port (and corresponding S parameter) on which a 1-port calibration will be performed.

Softkey	Function
1	Selects port 1.
2	Selects port 2.
3	Selects port 3.
4	Selects port 4.

- Step 6.** Connect an OPEN calibration standard to the test port (connector to which the DUT will be connected) selected in Step 5.
- Step 7.** Press **Open** to start the calibration measurement.
- Step 8.** Connect a SHORT calibration standard to the test port (connector to which the DUT will be connected) selected in Step 5.
- Step 9.** Press **Short** to start the calibration measurement.
- Step 10.** Connect a LOAD calibration standard to the test port (connector to which the DUT will be connected) selected in Step 5.
- Step 11.** Press **Load** to start the calibration measurement.
- Step 12.** Press **Done** to terminate the 1-port calibration process. Upon pressing the key, calibration coefficients will be calculated and saved. The error correction function will also be automatically enabled.


NOTE

By pressing **Done**, previously saved calibration coefficients will be overwritten with new calibration coefficients. To cancel the calibration without saving the new calibration coefficients, press **Cancel - OK** successively.

Full 2-Port Calibration

In full 2-port calibration, calibration data are measured by connecting an OPEN standard, a SHORT standard, or a LOAD standard to two desired test ports (or a THRU standard between two ports). This calibration effectively eliminates the directivity error, crosstalk, source match error, frequency response reflection tracking error, and frequency response transmission tracking error from the test setup in a transmission or reflection test using those ports (Figure 4-12). This calibration makes it possible to perform measurements with the highest possible accuracy. A total of twelve error terms, six each in the forward direction and the reverse direction, are used in a calibration.


Figure 4-12 Full 2-Port Error Model (Forward)



e5070aue144

Procedure

Figure 4-13 Connecting the Standard at Full 2-Port Calibration



e5070aue158

- Step 1. Press **Cal**.
- Step 2. Press **Calibrate**.
- Step 3. Press **2-Port Cal**.
- Step 4. Press **Select Ports**.
- Step 5. Select the test ports on which a full 2-port calibration will be performed.

Softkey	Function
1-2	Selects test ports 1 and 2.
1-3	Selects test ports 1 and 3.
1-4	Selects test ports 1 and 4.
2-3	Selects test ports 2 and 3.
2-4	Selects test ports 2 and 4.
3-4	Selects test ports 3 and 4.

NOTE In the procedure below, the selected test ports are denoted as x and y.

- Step 6. Press **Reflection**.
- Step 7. Connect an OPEN calibration standard to test port x (the connector to which the DUT will be connected) selected in Step 5.

- Step 8.** Press **Port x Open** to start the calibration measurement (**x** denotes the test port to which the standard is connected).
- Step 9.** Disconnect the OPEN calibration standard that was connected in Step 7 and replace it with a SHORT calibration standard.
- Step 10.** Press **Port x Short** to start the calibration measurement (**x** denotes the test port to which the standard is connected).
- Step 11.** Disconnect the SHORT calibration standard that was connected in Step 7 and replace it with a LOAD standard.
- Step 12.** Press **Port x Load** to start the calibration measurement (**x** denotes the test port to which the standard is connected).
- Step 13.** Repeat Step 7 to Step 12 for port y.
- Step 14.** Press **Return**.
- Step 15.** Press **Transmission**.
- Step 16.** Make a THRU connection between ports x and y (between the connectors to which the DUT will be connected) selected in Step 5.
- Step 17.** Press **Port x-y Thru** to start the calibration measurement (**x** and **y** denote the test ports between which the THRU connection is being made).
- Step 18.** Press **Return**.
- Step 19.** If an isolation calibration must be performed using a LOAD standard, follow the procedure below.
- a. Press **Isolation (Optional)**.
 - b. Connect a LOAD standard to each of the two test ports (connectors to which the DUT will be connected) selected in Step 5.
 - c. Press **Port x-y Isol** to start the calibration measurement (**x** and **y** denote the port numbers to which the LOAD standard is connected).
- Step 20.** Press **Return**.
- Step 21.** Press **Done** to terminate the full 2-port calibration process. Upon pressing the key, calibration coefficients will be calculated and saved. The error correction function will also be automatically enabled.


NOTE

By pressing **Done**, previously saved calibration coefficients will be overwritten with new calibration coefficients. To cancel the calibration without saving the new calibration coefficients, press **Cancel - OK** successively.

Full 3-Port Calibration

In full 3-port calibration, calibration data are measured by connecting an OPEN standard, a SHORT standard, or a LOAD standard to three desired test ports (or a THRU standard between three ports). This calibration effectively eliminates the directivity error, crosstalk, source match error, load match error, frequency response reflection tracking error, and frequency response transmission tracking error from the test setup in a transmission or reflection test using those ports (Figure 4-14). As in full 2-port calibration, this calibration method also makes it possible to perform measurements with the highest possible accuracy. There are unique error terms for directivity, source match, and reflection tracking for each stimulus test port (3×3 ports = 9). As for isolation, load match, and transmission tracking errors, there are unique terms for each combination between a stimulus port and a response port (3×6 combinations = 18). Therefore, in total, 27 error terms are involved in a full 3-port calibration.


Figure 4-14 Full 3-Port Error Model (Option 313, 314, 413, and 414)



e5070aue145

Procedure

Figure 4-15 Connecting the Standard at Full 3-Port Calibration



e5070aue159

- Step 1.** Press **Cal**.
- Step 2.** Press **Calibrate**.
- Step 3.** Press **3-Port Cal**.
- Step 4.** Press **Select Ports**.
- Step 5.** Select the test ports on which a full 3-port calibration will be performed.

Softkey	Function
1-2-3	Selects test ports 1, 2, and 3.
1-2-4	Selects test ports 1, 2, and 4.
1-3-4	Selects test ports 1, 3, and 4.
2-3-4	Selects test ports 2, 3, and 4.

NOTE In the procedure below, the selected test ports are denoted as x, y, and z.

- Step 6.** Press **Reflection**.
- Step 7.** Connect an OPEN calibration standard to test port x (the connector to which the DUT will be connected) selected in Step 5.

Calibration

Full 3-Port Calibration

- Step 8.** Press **Port x Open** to start the calibration measurement (**x** denotes the test port to which the standard is connected).
- Step 9.** Disconnect the OPEN calibration standard that was connected in Step 7 and replace it with a SHORT calibration standard.
- Step 10.** Press **Port x Short** to start the calibration measurement (**x** denotes the test port to which the standard is connected).
- Step 11.** Disconnect the SHORT calibration standard that was connected in Step 7 and replace it with a LOAD standard.
- Step 12.** Press **Port x Load** to start the calibration measurement (**x** denotes the test port to which the standard is connected).
- Step 13.** Repeat Step 7 to Step 12 on port y.
- Step 14.** Repeat Step 7 to Step 12 on port z.
- Step 15.** Press **Return**.
- Step 16.** Press **Transmission**.
- Step 17.** Make a THRU connection between ports x and y (between the connectors to which the DUT will be connected) selected in Step 5.
- Step 18.** Press **Port x-y Thru** to start the calibration measurement (**x** and **y** denote the test ports between which a THRU connection is being made).
- Step 19.** Repeat Step 17 and Step 18 on ports x and z.
- Step 20.** Repeat Step 17 and Step 18 on ports y and z.
- Step 21.** Press **Return**.
- Step 22.** If an isolation calibration must be performed using a LOAD standard, follow the procedure below.
- Press **Isolation (Optional)**.
 - Connect a LOAD standard to each of the three test ports x, y, and z (the connectors to which the DUT will be connected) selected in Step 5.
 - Press **Port x-y Isol** to start the calibration measurement.
 - Press **Port x-z Isol** to start the calibration measurement.
 - Press **Port y-z Isol** to start the calibration measurement.
- Step 23.** Press **Return**.
- Step 24.** Press **Done** to terminate the full 3-port calibration process. Upon pressing the key, calibration coefficients will be calculated and saved. The error correction function will also be automatically enabled.


NOTE

By pressing **Done**, previously saved calibration coefficients will be overwritten with new calibration coefficients. To cancel the calibration without saving the new calibration coefficients, press **Cancel - OK** successively.

Full 4-Port Calibration

In full 4-port calibration, calibration data are measured by connecting an OPEN standard, a SHORT standard, or a LOAD standard to the four test ports (or a THRU standard between the four ports). This calibration effectively eliminates the directivity error, crosstalk, source match error, load match error, frequency response reflection tracking error, and frequency response transmission tracking error from the test setup in a transmission or reflection test using those ports (Figure 4-16). As in full 2-port calibration, this calibration method also makes it possible to perform measurements with the highest possible accuracy. There are unique error terms for directivity, source match, and reflection tracking for each stimulus test port (3×4 ports = 12). As for isolation, load match, and transmission tracking errors, there are unique terms for each combination between a stimulus port and a response port (3×12 combinations = 36). Therefore, in total, 48 error terms are involved in a full 4-port calibration.


Figure 4-16 Full 4-Port Error Model (Option 413 and 414)



e5070aue146

Procedure

Figure 4-17 Connecting the Standard at Full 4-Port Calibration



e5070aue160

- Step 1.** Press **Cal**.
- Step 2.** Press **Calibrate**.
- Step 3.** Press **4-Port Cal**.
- Step 4.** Press **Reflection**.
- Step 5.** Connect an OPEN calibration standard to test port 1 (the connector to which the DUT will be connected).
- Step 6.** Press **Port 1 Open** to start the calibration measurement.
- Step 7.** Disconnect the OPEN calibration standard connected in Step 5 and replace it with a SHORT calibration standard.
- Step 8.** Press **Port 1 Short** to start the calibration measurement.
- Step 9.** Disconnect the SHORT calibration standard connected in Step 7 and replace it with a LOAD calibration standard.
- Step 10.** Press **Port 1 Load** to start the calibration measurement.
- Step 11.** Repeat Step 5 to Step 10 on test port 2.
- Step 12.** Repeat Step 5 to Step 10 on test port 3.
- Step 13.** Repeat Step 5 to Step 10 on test port 4.

- Step 14.** Press **Return**.
- Step 15.** Press **Transmission**.
- Step 16.** Make a THRU connection between ports 1 and 2 (between the connectors to which the DUT will be connected).
- Step 17.** Press **Port 1-2 Thru** to start the calibration measurement.
- Step 18.** Repeat Step 16 and Step 17 on ports 1 and 3.
- Step 19.** Repeat Step 16 and Step 17 on ports 1 and 4.
- Step 20.** Repeat Step 16 and Step 17 on ports 2 and 3.
- Step 21.** Repeat Step 16 and Step 17 on ports 2 and 4.
- Step 22.** Repeat Step 16 and Step 17 on ports 3 and 4.
- Step 23.** Press **Return**.
- Step 24.** If an isolation calibration must be performed using a LOAD standard, follow the procedure below.
- a. Press **Isolation (Optional)**.
 - b. Connect a LOAD standard to each of the four test ports (connectors to which the DUT will be connected).
 - c. Press **Port 1-2 Isol** to start the calibration measurement.
 - d. Press **Port 1-3 Isol** to start the calibration measurement.
 - e. Press **Port 1-4 Isol** to start the calibration measurement.
 - f. Press **Port 2-3 Isol** to start the calibration measurement.
 - g. Press **Port 2-4 Isol** to start the calibration measurement.
 - h. Press **Port 3-4 Isol** to start the calibration measurement.
- Step 25.** Press **Return**.
- Step 26.** Press **Done** to terminate the full 4-port calibration process. Upon pressing the key, calibration coefficients will be calculated and saved. The error correction function will also be automatically enabled.

NOTE

By pressing **Done**, previously saved calibration coefficients will be overwritten with new calibration coefficients. To cancel the calibration without saving the new calibration coefficients, press **Cancel - OK** successively.

ECal (Electronic Calibration)

ECal is a calibration method that uses solid state circuit technology. ECal has following advantages:

- Simplifies the calibration process.
- Shortens the time required for calibration.
- Reduces the chances for erroneous manipulation.
- Prevents inferior performance due to wear because the ECal module employs PIN diodes and FET switches.

1-Port Calibration Using a 2-Port ECal Module

Follow the procedure below to perform a 1-port calibration using the 2-port ECal module.


- Step 1.** Connect the USB port on the ECal module with the USB port on the E5070A/E5071A using a USB cable. This connection may be done with the E5070A/E5071A power on.
- Step 2.** Connect port on the ECal module to the test port that needs to be calibrated.

NOTE

You can connect the ports of the ECal and the test ports of the E5070A/E5071A arbitrarily. The connected ports are detected before data measurement.

Figure 4-18

Connecting the ECal Module (1-Port Calibration)



Step 3. Press .

Step 4. Press **ECal**.

Step 5. Press **1 Port ECal**.

Step 6. Perform a 1-port calibration.

Softkey	Function
Port 1	Performs a 1-port calibration on test port 1.
Port 2	Performs a 1-port calibration on test port 2.
Port 3 ^{*1}	Performs a 1-port calibration on test port 3.
Port 4 ^{*2}	Performs a 1-port calibration on test port 4.

*1. Only with Options 313, 314, 413, and 414.

*2. Only with Options 413 and 414.


Full 2-Port Calibration Using the 2-Port ECal Module

Follow the procedure below to perform a full 2-port calibration using the 2-port ECal module.

- Step 1.** Connect the USB port on the ECal module with the USB port on the E5070A/E5071A using a USB cable. This connection may be done with the E5070A/E5071A power on.
- Step 2.** Connect port A and port B on the ECal module to the test ports that need to be calibrated.

Figure 4-19

Connecting the ECal Module (Full 2-Port Calibration)



e5070aue117

Step 3. Press **Cal**.

Step 4. Press **ECal**.

Step 5. To enable isolation calibration, press **Isolation** and confirm that the display turns **ON**.

Step 6. Press **2 Port ECal**. When using a 2-port E5070A/E5071A (Option 213 or 214), pressing this key performs a 2-port ECal (proceed to Step 5).

Calibration
ECal (Electronic Calibration)

Step 7. When using a 3-port or 4-port E5070A/E5071A (Option 313, 314, 413, or 414), press one of the softkeys below to start a full 2-port calibration.

Softkey	Function
Port 1-2	Performs a full 2-port calibration between test ports 1 and 2.
Port 1-3	Performs a full 2-port calibration between test ports 1 and 3.
Port 1-4 ^{*1}	Performs a full 2-port calibration between test ports 1 and 4.
Port 2-3	Performs a full 2-port calibration between test ports 2 and 3.
Port 2-4 ^{*1}	Performs a full 2-port calibration between test ports 2 and 4.
Port 3-4 ^{*1}	Performs a full 2-port calibration between test ports 3 and 4.

*1. Only with Options 413 and 414.

Full 3-Port and Full 4-Port Calibration Using the 2-Port ECal

A VBA macro (ECal Assistant) is pre-installed in the E5070A/E5071A to carry out a full 3-port or a full 4-port calibration using the 2-port ECal.

NOTE ECal Assistant does not perform the isolation calibration.


Operation Method

- Step 1.** Connect the USB port of the ECal module and the USB port on the E5070A/E5071A with a USB cable. The connection may be made with the E5070A/E5071A powered on.
- Step 2.** Press **Macro Setup**.
- Step 3.** Press **Load Project**.
- Step 4.** From the Open dialog box, select the VBA project file “D:\Agilent\ECalAssistant.VBA” and press the **Open** button.
- Step 5.** Press **Macro Run**.

A dialog box as shown in Figure 4-20 appears.

Figure 4-20

ECalAssistant (Start) Dialog Box




- Step 6.** Press the **Next** button.

A dialog box as shown in Figure 4-21 appears.

Figure 4-21

ECalAssistant (Port/Channel Selection) Dialog Box



- Step 7.** In the Select Ports area, click and select the **3-Port** (for a full 3-port calibration) or the

Calibration

Full 3-Port and Full 4-Port Calibration Using the 2-Port ECal

4-Port (for a full 4-port calibration) radio button.

Step 8. When a full 3-port calibration is carried out on an E5070A/E5071A with option 413 or 414, select the test ports to be calibrated on the drop down list box below the **3-Port** button (either **1-2-3**, **1-2-4**, **1-3-4**, or **2-3-4**).


Step 9. In the Select Channel area, select the channel to be calibrated (one of the channels **1 ~ 9**).

Step 10. Press the **Next** button.

A dialog box as shown in Figure 4-22 appears.

Figure 4-22

ECalAssistant (Connection) Dialog Box



Step 11. Following the connection diagram shown in the dialog box (Figure 4-22), connect port A and B of the ECal module to test ports on the E5070A/E5071A.


Note that the connection diagram shown in each dialog box that appears in each step depends on the number of test ports on the E5070A/E5071A (option 313/314 or 413/414), and the test port selection made in Step 8.

Step 12. Press the **Measure** button to start the measurement of calibration data.

Upon completion of the measurement, a dialog box as shown in Figure 4-23 will be displayed.

Figure 4-23

ECalAssistant (Measurement Complete) Dialog Box




Step 13. Press the **Next** button.

A dialog box as shown in Figure 4-24 appears.

Figure 4-24


ECalAssistant (Connection) Dialog Box



- Step 14. Re-connect the ECal module following the instructions given in each dialog box and continue the calibration process.
- Step 15. When all calibration data have been collected, a dialog box with the *Complete!* sign appears as shown in Figure 4-25. Press the **Done** button to finish the calibration. If you wish to cancel the calibration, press the **Cancel** button.

Figure 4-25

EcalAssistant (Finish) Dialog Box



Calibration using 4-port ECal

The E5070A/E5071A allows you to perform calibration using the 4-port ECal module. It provides much simpler operation than when using the 2-port ECal. Especially when using a multi-port test set, calibration time and operator's mistakes can be reduced significantly.


Operational procedure

To execute full 2-port calibration using the 4-port ECal module, follow these steps.

- Step 1.** Connect the USB cable between the USB port of the 4-port ECal module and the USB port of the E5070A/E5071A. You can make this connection with the E5070A/E5071A ON.
- Step 2.** Connect the ports of the 4-port ECal module to the test ports you want to calibrate.

Figure 4-26

Connecting 4-port ECal module (for full 4-port calibration)



e5070aue200

NOTE

You can connect the ports of the 4-port ECal and the test ports of the E5070A/E5071A arbitrarily. The connected ports are detected before data measurement.

- Step 1.** Press .
- Step 2.** Press **ECal**.
- Step 3.** When you want to turn ON the isolation calibration, press **Isolation** (set to **ON**).
- Step 4.** Select the calibration type.

Softkey	Function
1-Port ECal	Full 1-port calibration.

Softkey	Function
2-Port ECal	Full 2-port calibration.
3-Port ECal ^{*1}	Full 3-port calibration.
4-Port ECal ^{*2}	Full 4-port calibration.
Thru ECal	Thru calibration.

*1. Options 313, 314, 413, and 414 only

*2. Options 413 and 414 only

Step 5. If you must select a port, the softkey to select a port is displayed. Select a port and start calibration. If you do not have to, this step is skipped.

Step 6. The E5070A/E5071A detects the test ports connected to the ECal and then measurement starts.

NOTE

If a test port to be calibrated is not connected to the ECal module, an error occurs.

Changing the Calibration Kit Definition

In most measurements, the user can use pre-defined calibration kits as they are. However, it may be necessary to change the definition of a calibration kit (or create a new one) when a special standard is used or a high degree of accuracy is demanded. When it is necessary to change the definition of a calibration kit that contains a calibration device but no calibration kit model, the user must fully understand error correction and the system error model.

A user-defined calibration kit may be used in the following circumstances.

- When the user wants to use connectors other than those pre-defined in the calibration kits for the E5070A/E5071A (e.g., a SMA connector).
- When the user wants to use different standards in place of one or more standards pre-defined in the E5070A/E5071A. For example, when three offset SHORT standards are used instead of OPEN, SHORT, and LOAD standards.
- When the user wants to modify the standard model of a pre-defined calibration kit and turn it into a more accurate model. It is possible to perform better calibration if the performance of the actual standard is reflected in the standard model better. For example, define the 7 mm load standard as 50.4 Ω instead of 50.0 Ω .

Definitions of Terms

The terms used in this section are defined as follows:


Standard	An accurate physical device, for which the model is clearly defined, and is used to determine system errors. With the E5070A/E5071A, the user may define up to 21 standards per calibration kit. Each standard is numbered, from 1 through 21. For example, standard 1 for the 85033E 3.5 mm calibration kit is a SHORT standard.
Standard type	The type of standard used to classify a standard model based on its form and construction. Five standard types are available: SHORT, OPEN, LOAD, delay/THRU, and arbitrary impedance.
Standard coefficient	The numeric characteristics of the standard used in the selected model. For example, the offset delay (32 ps) of the SHORT standard in the 3.5 mm calibration kit is a standard coefficient.
Standard class	A group of standards used in a calibration process. For each class, the user must select the standards to use from the 21 available standards.

Defining Parameters for Standards

Figure 4-27 and Figure 4-28 show the parameters used in defining standards.

Figure 4-27


Reflection Standard Model (SHORT, OPEN, or LOAD)



e5070aue004

Figure 4-28

Transmission Standard Model (THRU)



e5070aue005

Z0

The offset impedance between the standard to be defined and the actual measurement plane. Normally, this is set to the characteristic impedance of the system.

Delay

The delay occurs depending on the length of the transmission line between the standard to be defined and the actual measurement plane. In an OPEN, SHOT, or LOAD standard, the delay is defined as one-way propagation time (sec.) from the measurement plane to the standard. In a THRU standard, it is defined as one-way propagation time (sec.) from one measurement plane to the other. The delay can be

determined through measurement or by dividing the exact physical length of the standard by the velocity coefficient.

Loss

This is used to determine the energy loss caused by the skin effect for the length (one-way) of the coaxial cable. Loss is defined using the unit of Ω/s at 1 GHz. In many applications, using the value $i0i$ for the loss should not result in significant errors. The loss of a standard is determined by measuring the delay (sec.) and the loss at 1 GHz and then substituting them in the formula below.

$$Loss\left(\frac{\Omega}{s}\right) = \frac{loss(dB) \times Z_0(\Omega)}{4.3429(dB) \times delay(s)}$$

C0, C1, C2, C3

It is extremely rare for an OPEN standard to have perfect reflection characteristics at high frequencies. This is because the fringe capacitance of the standard causes a phase shift that varies along with the frequency. For internal calculation of the analyzer, an OPEN capacitance model is used. This model is described as a function of frequency, which is a polynomial of the third degree. Coefficients in the polynomial may be defined by the user. The formula for the capacitance model is shown below.

$$C = (C0) + (C1 \times F) + (C2 \times F^2) + (C3 \times F^3)$$

F: measurement frequency

C0 unit: (Farads) (constant in the polynomial)

C1 unit: (Farads/Hz)

C2 unit: (Farads/Hz²)

C3 unit: (Farads/Hz³)

L0, L1, L2, L3

It is extremely rare for a SHORT standard to have perfect reflection characteristics at high frequencies. This is because the residual inductance of the standard causes a phase shift that varies along with the frequency. It is not possible to eliminate this effect. For internal calculation of the analyzer, a short-circuit inductance model is used. The model is described as a function of frequency, which is a polynomial of the third degree. Coefficients in the polynomial may be defined by the user. The formula for the inductance model is shown below.

$$L = (L0) + (L1 \times F) + (L2 \times F^2) + (L3 \times F^3)$$

F: Measurement frequency

L0 unit: [Farads] (the constant in the polynomial)

L1 unit: [Farads/Hz]

L2 unit: [Farads/Hz²]

L3 unit: [Farads/Hz³]

In most existing calibration kits, THRU standards are defined as “zero-length THRU,” i.e., the delay and loss are both “0”. Such a THRU standard does not exist, however. Calibration must be done with two test ports interconnected directly.

NOTE

The measurement accuracy depends on the conformity of the calibration standard to its definition. If the calibration standard has been damaged or worn out, the accuracy will decrease.

Redefining a Calibration Kit

To change the definition of a calibration kit, follow the procedure below.

1. Select a calibration kit to be redefined.
2. Define the type of standard. Select one from among the OPEN, SHORT, LOAD, delay/THRU, and arbitrary impedance standards.
3. Define the standard coefficient.
4. Designate a standard class for the standard.
5. Save the data for the calibration kit that has been redefined.

Redefining a Calibration Kit

Step 1. Press **Cal**.

Step 2. Press **Cal Kit**.

Step 3. Select the calibration kit to be redefined.

Softkey	Function
85033E	Selects the “85033E” calibration kit.
85033D	Selects the “85033D” calibration kit.
85052D	Selects the “85052D” calibration kit.
85032F	Selects the “85032F” calibration kit.
85032B	Selects the “85032B” calibration kit.
User	Selects a user-defined calibration kit.
User	Selects a user-defined calibration kit.
User	Selects a user-defined calibration kit.
User	Selects a user-defined calibration kit.
User	Selects a user-defined calibration kit.

NOTE

If the names (labels) of calibration kits were changed prior to operation, the new names will appear as respective softkeys.

Step 4. Press **Modify Kit**.

Step 5. Press **Define STDs**.

Step 6. Select the standard to be redefined from among standards numbered 1 through 21.

Step 7. Press **STD Type**.

Calibration

Changing the Calibration Kit Definition

Step 8. Select a type of standard.

Softkey	Function
Open	Selects the OPEN standard.
Short	Selects the SHORT standard.
Load	Selects the LOAD standard.
Delay/Thru	Selects the delay/THRU standard.
Arbitrary	Selects the arbitrary impedance.
None	Selects no standard type.

Step 9. Set the standard coefficient.

Softkey	Function
C0	Sets C0.
C1	Sets C1.
C2	Sets C2.
C3	Sets C3.
L0	Sets L0.
L1	Sets L1.
L2	Sets L2.
L3	Sets L3.
Offset Delay	Sets the offset delay.
Offset Z0	Sets the offset Z0.
Offset Loss	Sets the offset loss.
Arb. Impedance	Sets an arbitrary impedance.

Step 10. Press **Label** and input a new label for the standard using the keypad displayed on the screen.

Step 11. Press **Return**.

Step 12. Repeat Step 6 to Step 11 to redefine all standards for which changes are necessary.

Step 13. Press **Return**.

Step 14. Press **Specify CLSs**.

Step 15. Select the class to be redefined.

Softkey	Function
Open	Selects the OPEN class.
Short	Selects the SHORT class.
Load	Selects the LOAD class.
Thru	Selects the THRU class.

Step 16. Select a test port.

Softkey	Function
Port 1	Selects port 1.
Port 2	Selects port 2.
Port 3	Selects port 3.
Port 4	Selects port 4.

NOTE

Select **Set All** to use the same standards for all test ports.

- Step 17.** Select the standards to be registered in the class from among standards numbered 1 through 21.
- Step 18.** Repeat Step 16 and Step 17 until classes are defined for all test ports that need to be redefined.
- Step 19.** Press **Return**.
- Step 20.** Repeat Step 15 to Step 19 to redefine all classes that need to be modified.
- Step 21.** Press **Return**.
- Step 22.** Press **Label Kit** and input a new label for the calibration kit using the keypad displayed on the screen.

Default Settings of Pre-defined Calibration Kits

Calibration kits 85033E, 85033D, 85052D, 85032F, and 85032B are pre-defined with default settings.

85033E

	1. Short	2. Open	3. Broadband	4. Thru
Label	Short	Open	Broadband	Thru
STD Type	Short	Open	Load	Delay/Thru
C0 [$\times 10^{-15}$ F]	0	49.43	0	0
C1 [$\times 10^{-27}$ F/Hz]	0	-310.13	0	0
C2 [$\times 10^{-36}$ F/Hz ²]	0	23.17	0	0
C3 [$\times 10^{-45}$ F/Hz ³]	0	-0.16	0	0
L0 [$\times 10^{-12}$ H]	2.0765	0	0	0
L1 [$\times 10^{-24}$ H/Hz]	-108.54	0	0	0
L2 [$\times 10^{-33}$ H/Hz ²]	2.1705	0	0	0
L3 [$\times 10^{-42}$ H/Hz ³]	0.01	0	0	0
Offset Delay [s]	31.808 p	29.243 p	0	0
Offset Z0 [Ω]	50	50	50	50
Offset Loss [Ω /s]	2.36 G	2.2 G	2.2 G	2.2 G
Arb. Impedance [Ω]	50	50	50	50

85033D

	1. Short	2. Open	3. Broadband	4. Thru
Label	Short	Open	Broadband	Thru
STD Type	Short	Open	Load	Delay/Thru
C0 [$\times 10^{-15}$ F]	0	49.43	0	0
C1 [$\times 10^{-27}$ F/Hz]	0	-310.13	0	0
C2 [$\times 10^{-36}$ F/Hz ²]	0	23.17	0	0
C3 [$\times 10^{-45}$ F/Hz ³]	0	-0.16	0	0
L0 [$\times 10^{-12}$ H]	2.0765	0	0	0
L1 [$\times 10^{-24}$ H/Hz]	-108.54	0	0	0
L2 [$\times 10^{-33}$ H/Hz ²]	2.1705	0	0	0
L3 [$\times 10^{-42}$ H/Hz ³]	0.01	0	0	0
Offset Delay [s]	31.808 p	29.243 p	0	0
Offset Z0 [Ω]	50	50	50	50
Offset Loss [Ω /s]	2.36 G	2.2 G	2.2 G	2.2 G
Arb. Impedance [Ω]	50	50	50	50

85052D

	1. Short	2. Open	5. 3.5/2.92	6. 3.5/SMA	7. 2.92/SMA
Label	Short	Open	3.5/2.92	3.5/SMA	3.5/SMA
STD Type	Short	Open	Open	Open	Open
C0 [$\times 10^{-15}$ F]	0	49.433	6.9558	5.9588	13.4203
C1 [$\times 10^{-27}$ F/Hz]	0	-310.131	-1.0259	-11.195	-1.9452
C2 [$\times 10^{-36}$ F/Hz²]	0	23.1682	-0.01435	0.5076	0.5459
C3 [$\times 10^{-45}$ F/Hz³]	0	-0.15966	0.0028	-0.00243	0.01594
L0 [$\times 10^{-12}$ H]	2.0765	0	0	0	0
L1 [$\times 10^{-24}$ H/Hz]	-108.54	0	0	0	0
L2 [$\times 10^{-33}$ H/Hz²]	2.1705	0	0	0	0
L3 [$\times 10^{-42}$ H/Hz³]	0.01	0	0	0	0
Offset Delay [s]	31.785 p	29.243 p	0	0	0
Offset Z0 [Ω]	50	50	50	50	50
Offset Loss [Ω/s]	2.36 G	2.2 G	0	0	0
Arb. Impedance [Ω]	50	50	50	50	50
	8. 2.4/1.85	9. Broadband	11. Thru	13. Adapter	
Label	2.4/1.85	Broadband	Thru	Adapter	
STD Type	Open	Load	Delay/Thru	Delay/Thru	
C0 [$\times 10^{-15}$ F]	8.9843	0	0	0	
C1 [$\times 10^{-27}$ F/Hz]	-13.9923	0	0	0	
C2 [$\times 10^{-36}$ F/Hz²]	0.3242	0	0	0	
C3 [$\times 10^{-45}$ F/Hz³]	-0.00112	0	0	0	
L0 [$\times 10^{-12}$ H]	0	0	0	0	
L1 [$\times 10^{-24}$ H/Hz]	0	0	0	0	
L2 [$\times 10^{-33}$ H/Hz²]	0	0	0	0	
L3 [$\times 10^{-42}$ H/Hz³]	0	0	0	0	
Offset Delay [s]	0	0	0	94.75 p	
Offset Z0 [Ω]	50	50	50	50	
Offset Loss [Ω/s]	0	0	0	2.51 G	
Arb. Impedance [Ω]	50	50	50	50	

Calibration
 Changing the Calibration Kit Definition

85032F

	1. Short(m)	2. Open(m)	7. Short(f)	8. Open(f)
Label	Short(m)	Open(m)	Short(f)	Open(f)
STD Type	Short	Open	Short	Open
C0 [$\times 10^{-15}$ F]	0	89.939	0	89.939
C1 [$\times 10^{-27}$ F/Hz]	0	2536.8	0	2536.8
C2 [$\times 10^{-36}$ F/Hz ²]	0	-264.99	0	-264.99
C3 [$\times 10^{-45}$ F/Hz ³]	0	13.4	0	13.4
L0 [$\times 10^{-12}$ H]	3.3998	0	3.3998	0
L1 [$\times 10^{-24}$ H/Hz]	-496.4808	0	-496.4808	0
L2 [$\times 10^{-33}$ H/Hz ²]	34.8314	0	34.8314	0
L3 [$\times 10^{-42}$ H/Hz ³]	-0.7847	0	-0.7847	0
Offset Delay [s]	45.955 p	41.19 p	45.955 p	40.8688 p
Offset Z0 [Ω]	49.99	50	49.99	50
Offset Loss [Ω /s]	1.087 G	930 M	1.087 G	930 M
Arb. Impedance [Ω]	50	50	50	50
	9. Broadband	11. Thru	13. (f/f)Adapter	14. (m/m)Adapter
Label	Broadband	Thru	(f/f)Adapter	(m/m)Adapter
STD Type	Load	Delay/Thru	Delay/Thru	Delay/Thru
C0 [$\times 10^{-15}$ F]	0	0	0	0
C1 [$\times 10^{-27}$ F/Hz]	0	0	0	0
C2 [$\times 10^{-36}$ F/Hz ²]	0	0	0	0
C3 [$\times 10^{-45}$ F/Hz ³]	0	0	0	0
L0 [$\times 10^{-12}$ H]	0	0	0	0
L1 [$\times 10^{-24}$ H/Hz]	0	0	0	0
L2 [$\times 10^{-33}$ H/Hz ²]	0	0	0	0
L3 [$\times 10^{-42}$ H/Hz ³]	0	0	0	0
Offset Delay [s]	0	0	339 p	339 p
Offset Z0 [Ω]	50	50	50	50
Offset Loss [Ω /s]	0	0	2.2 G	2.2 G
Arb. Impedance [Ω]	50	50	50	50

85032B

	1. Short(m)	2. Open(m)	3. Broadband	4. Thru
Label	Short(m)	Open(m)	Broadband	Thru
STD Type	Short	Open	Load	Delay/Thru
C0 [$\times 10^{-15}$ F]	0	119.09	0	0
C1 [$\times 10^{-27}$ F/Hz]	0	-36.955	0	0
C2 [$\times 10^{-36}$ F/Hz ²]	0	26.258	0	0
C3 [$\times 10^{-45}$ F/Hz ³]	0	5.5136	0	0
L0 [$\times 10^{-12}$ H]	0	0	0	0
L1 [$\times 10^{-24}$ H/Hz]	0	0	0	0
L2 [$\times 10^{-33}$ H/Hz ²]	0	0	0	0
L3 [$\times 10^{-42}$ H/Hz ³]	0	0	0	0
Offset Delay [s]	93 f	0	0	0
Offset Z0 [Ω]	49.992	50	50	50
Offset Loss [Ω /s]	700 M	700 M	700 M	700 M
Arb. Impedance [Ω]	50	50	50	50
	7. Short(f)	8. Open(f)		
Label	Short(f)	Open(f)		
STD Type	Short	Open		
C0 [$\times 10^{-15}$ F]	0	62.14		
C1 [$\times 10^{-27}$ F/Hz]	0	-143.07		
C2 [$\times 10^{-36}$ F/Hz ²]	0	82.92		
C3 [$\times 10^{-45}$ F/Hz ³]	0	0.76		
L0 [$\times 10^{-12}$ H]	0	0		
L1 [$\times 10^{-24}$ H/Hz]	0	0		
L2 [$\times 10^{-33}$ H/Hz ²]	0	0		
L3 [$\times 10^{-42}$ H/Hz ³]	0	0		
Offset Delay [s]	17.817 p	17.411 p		
Offset Z0 [Ω]	50.209	50		
Offset Loss [Ω /s]	2.1002 G	700 M		
Arb. Impedance [Ω]	50	50		

5

Making Measurements

This chapter describes how to carry out measurements with the Agilent E5070A/E5071A by using the trigger function.


Setting Up the Trigger and Making Measurements

Trigger Model

Figure 5-1 shows the trigger model used in the E5070/E5071A.

Figure 5-1

Trigger Model Used in the E5070/E5071A



e5070auj035

The E5070/E5071A has one trigger source. The trigger signal generated by this trigger source will be sent to channels 1 through 9 in order. The trigger mode is set independently for each channel. If the trigger mode is set to “Hold,” sending a trigger will not prompt a sweep.

NOTE

Executing measurement of a channel does not depend on the channel’s display status. You can even perform measurement of a channel with no display.

The traces actually measured are set by the number of traces in each channel.

Sweep Order in Each Channel

In a channel, each test port is set to stimulus port in the order of port number and updates each trace (Table 5-1).

Table 5-1 Sweep Order in Each Channel

Sweep Order	Stimulus Port	Updated Trace
↓	Port 1	S ₁₁ , S ₂₁ , S ₃₁ ^{*1} , S ₄₁ ^{*2}
	Port 2	S ₁₂ , S ₂₂ , S ₃₂ ^{*1} , S ₄₂ ^{*2}
	Port 3 ^{*1}	S ₁₃ ^{*1} , S ₂₃ ^{*1} , S ₃₃ ^{*1} , S ₄₃ ^{*2}
	Port 4 ^{*2}	S ₁₄ ^{*2} , S ₂₄ ^{*2} , S ₃₄ ^{*2} , S ₄₄ ^{*2}

*1. Option 313, 314, 413, or 414 only

*2. Option 413 or 414 only

NOTE

If full 2, 3, or 4 port error correction is valid, any traces related to the calibrated ports are not updated before the last calibrated port is swept as a stimulus port.

Sweep is not executed for the stimulus port which is not required for updating traces.

Trigger Source

The trigger source generates a cue signal that initiates a measurement process. Four types of trigger sources are available as shown in Table 5-2.

Table 5-2 Trigger Sources and Their Functions

Trigger Sources	Function
Internal (Internal)	Uses a consecutive signal generated by the firmware as a trigger source. Triggers are sent immediately following the completion of each measurement.
External (External)	Uses the external trigger input terminal (BNC) as a trigger source.
Manual (Manual)	A trigger will be generated by pressing Trigger - Trigger .
Bus (Bus)	A trigger will be generated by executing a *TRG command.

Trigger Modes

Different trigger modes may be set for different channels independently.

Table 5-3**Trigger Modes**

Trigger Mode	Function
Hold sweep (Hold)	Disables the sweep. Sending a trigger does not prompt a sweep.
Single sweep (Single)	Executes one complete sweep when a trigger is received. After completion, the analyzer will be reset to “Hold” mode.
Continuous sweep (Continuous)	Executes one complete sweep each time a trigger is received.

Setting Up the Trigger and Making Measurements**1. Selecting a Trigger Source**

Follow the procedure below to select a trigger source.

Step 1. Press **Trigger**

Step 2. Press **Trigger Source**

Step 3. Press the softkey that corresponds to the desired trigger source.

Softkey	Function
Internal	Selects the internal trigger source.
External	Selects the external trigger source.
Manual	Selects the manual trigger source.
Bus	Selects the bus trigger source.

2. Selecting a Trigger Mode

Follow the procedure below to select a trigger mode.

Step 1. Press **Channel Next** (or **Channel Prev**) to select a channel for which the trigger mode will be set.

Step 2. Press **Trigger**.

Step 3. Press the softkey that corresponds to the desired trigger mode.

Softkey	Function
Hold	Sets the active channel trigger mode to the hold sweep mode
Single	Sets the active channel trigger mode to the single sweep mode.
Continuous	Sets the active channel trigger mode to the continuous sweep mode.
Hold All Channels	Sets all channel trigger modes to the hold sweep mode.
Continuous Disp Channels	Sets trigger modes of all displayed channels (Display - Display) to the continuous sweep mode.

Step 4. Repeat Step 1 to Step 3 until all channels are set for the respective trigger mode.

3. Generating the Trigger

Next, it is necessary to generate a trigger using the trigger source selected in “1. Selecting a Trigger Source” on page 124.

NOTE

Once the internal trigger source is selected, a series of triggers will be continuously generated as soon as the setting becomes effective.

Pressing **Trigger** - **Restart** during a sweep forces the analyzer to abort the sweep.

Making Measurements

Setting Up the Trigger and Making Measurements

6 **Data Analysis**

This chapter explains how to use the analytical functions of the Agilent E5070A/E5071A.

Analyzing Data on the Trace Using the Marker

About Marker Functions

The marker can be used in the following ways:

- Reading a measured value as numerical data (as an absolute value or a relative value from the reference point)
- Moving the marker to a specific point on the trace (marker search)
- Analyzing trace data to determine a specific parameter
- Using the value of the marker to change the stimulus (frequency range) and scale (value of the reference line)

For the procedure to change the frequency range and scale by using the marker, refer to “Setting the Frequency Range Using the Marker” on page 60 and “Setting the Value of a Reference Line Using the Marker” on page 72.

The E5070A/E5071A is capable of displaying up to 10 markers on each trace. Each marker has a stimulus value (the value on the X-axis in rectangular display format) and a response value (the value on the Y-axis in rectangular display format). The Smith chart and polar formats each have two marker response values (log amplitude and phase).

NOTE

A partial search cannot be performed by manual operation.

Reading Values on the Trace

Follow the steps below to read the value of a marker displayed on the trace.

Reading a Value on the Trace

- Step 1.** Press **Channel Next** or **Channel Prev** to activate the channel on which a marker is used.
- Step 2.** Press **Trace Next** or **Trace Prev** to activate the channel on which a marker is used.
- Step 3.** Press **Marker**.

NOTE

At this point in time, marker 1 is turned on and becomes active (you can operate the marker). When using marker 1, you can omit Step 4.

- Step 4.** Select a marker and turn it on. The softkey used to turn on a marker is used to activate that marker.

Softkey	Function
Marker 1	Turn on marker 1, which has been turned off; activate marker 1.
Marker 2	Turn on marker 2, which has been turned off; activate marker 2.






Softkey	Function
Marker 3	Turn on marker 3, which has been turned off; activate marker 3.
Marker 4	Turn on marker 4, which has been turned off; activate marker 4.
More Markers - Marker 5	Turn on marker 5, which has been turned off; activate marker 5.
More Markers - Marker 6	Turn on marker 6, which has been turned off; activate marker 6.
More Markers - Marker 7	Turn on marker 7, which has been turned off; activate marker 7.
More Markers - Marker 8	Turn on marker 8, which has been turned off; activate marker 8.
More Markers - Marker 9	Turn on marker 9, which has been turned off; activate marker 9.
Ref Marker	Turn on the reference marker, which has been turned off; activate the reference marker.



Step 5. Change the marker stimulus value in the entry area. This operation enables you to move the marker to a point on the desired trace.

The value in the entry area can be changed by one of the following methods.

NOTE

To change the value in the entry area, the figure in the box should be highlighted. If the figure is not highlighted, press the softkey for the marker you are using (**marker 1** to **marker 9**, **Ref Marker**), or **Focus** to highlight the figure.

- Enter a numeric value using the ENTRY block key on the front panel.
- Turn the rotary knob () on the front panel.
- Press the up or down arrow key ( ) on the front panel.
- Using the mouse, click one of the buttons ( ) on the right side of the entry area.

You can move the marker by dragging and dropping either one of the marker position pointers above and below the graph ( ) (pressing the button on the object to be moved and releasing the button on the destination). In rectangular display format, you can move a marker itself by dragging and dropping it.

Step 6. When using other markers, repeat Step 4 and Step 5.

Step 7. Read the marker stimulus value and marker response value displayed in the upper-left part of the trace screen.

Step 8. To turn off marker(s), press the **Clear Marker Menu** and then press one of the softkeys as

Data Analysis

Analyzing Data on the Trace Using the Marker

follows:

Softkey	Function
All OFF	Turns off all of the markers on the active trace.
Marker 1 to Marker 9	Turns off one of the markers 1 through 9 on the active trace.
Ref Marker	Turns off the reference markers on the active trace.


NOTE

In the preset configuration, the marker settings on traces in a channel are coupled (Marker Couple is turned on). For marker coupling, refer to “Setting Up Markers for Each Trace/Setting Up Markers for Coupled Operations Between Traces” on page 131.

Reading the Relative Value From the Reference Point on the Trace

You can convert the marker reading into a relative value from the reference point.

Figure 6-1 Delta marker mode



e5070aue121

Converting From a Reference Point to a Relative Value

- Step 1.** Following Step 1 to Step 5 in “Reading Values on the Trace” on page 128, place the reference marker on the point to be used as the reference.
- Step 2.** Press **Ref Marker Mode** to turn on the reference mode.
With the reference mode turned on, the stimulus values and response values are indicated in relative values referred to by the position of the reference marker.
- Step 3.** Following Step 4 to Step 5 in “Reading Values on the Trace” on page 128, place markers 1 through 9 on the desired points to read the values.

NOTE Pressing **Marker** → **Ref Marker** enables you to place the reference marker at the position of the currently active marker. The reference mode will then turn on automatically.

Reading Only the Actual Measurement Point/Reading the Value Interpolated Between Measurement Points


The point on the trace on which a marker can be placed differs depending on how the discrete marker mode is set up.

Turning on discrete mode (Discrete ON) A marker moves only between actual measurement points. When a specific marker stimulus value is specified as a numerical value, the marker is placed at the measurement point closest to the specified value. A marker that is placed between interpolated points with the discrete mode off automatically moves to the nearest measurement point when the discrete mode turns on.

Turning off discrete mode (Discrete OFF) The marker can move from one actual measurement point to another. Because it is interpolated, it can also move in the space between measurement points.

Figure 6-2

Marker Discrete Mode



Turning Discrete Mode On or Off


- Step 1.** Press **Channel Next** (or **Channel Prev**) and **Trace Next** (or **Trace Prev**) to activate the trace on which the discrete mode is set up.
- Step 2.** Press **Marker Fctn**.
- Step 3.** Press **Discrete** to turn the discrete mode on or off.

Setting Up Markers for Each Trace/Setting Up Markers for Coupled Operations Between Traces

The setting up and moving of markers can be performed either in coupled operation for all traces in a channel or independently for each trace.

Figure 6-3

Marker Coupling



e5070aue049

Marker Couple is on.
(Coupling ON)

The setting up and moving of markers is performed in coupled operation on all traces in a channel.

Marker Couple is off.
(Coupling OFF)

The setting up and moving of markers is performed independently for each trace.

Turning Marker Coupling On or Off

- Step 1.** Press **Channel Next** (or **Channel Prev**) to activate the channel on which the marker couple will be set.
- Step 2.** Press **Marker Fctn**.
- Step 3.** Press **Couple** to turn the marker coupling on or off.

Listing All the Marker Values in All the Channels Displayed


You can list all the marker values in all the displayed channels on the screen.

Turning On the Marker Table Display

- Step 1. Press **Marker Fctn**.
- Step 2. Press **Marker Table** to turn on the marker table display.

The marker table appears in the lower part of the screen. (See Figure 6-4.)

Figure 6-4



Setting Up the Marker Response Value Display in Smith Chart/Polar Data Format

In rectangular display format, the marker response value is always in the same data format as that of the Y-axis. On the contrary, one format for the marker response values (two values: main and auxiliary) can be selected from among several types. The selection is performed in the data format.

Table 6-1

Marker Response Values for Smith Chart/Polar Data Formats

Softkey for selecting the data format	Marker response value	
	Main	Auxiliary
Smith - Lin / Phase	Linear amplitude	Phase
Smith - Log / Phase	Log amplitude	Phase
Smith - Real / Imag	Real component	Imaginary component
Smith - R + jX	Resistance	Reactance ^{*1}
Smith - G + jX	Conductance	Susceptance ^{*1}
Polar - Lin / Phase	Linear amplitude	Phase
Polar - Log / Phase	Log amplitude	Phase
Polar - Real / Imag	Real component	Imaginary component

*1. The inductance or capacitance is also displayed.


For setting up data formats, refer to “Selecting a Data Format” on page 66.

Searching for the Maximum and Minimum Measured Values

You can search for the maximum or minimum measured value on the trace and move a marker to that point. (See Figure 6-5.)

Figure 6-5

Searching for the Maximum and Minimum Measured Values



e5070aue047

Search for the maximum (Max) Move the active marker to the point on the trace where the measured value is greatest.

Search for the minimum (Min) Move the active marker to the point on the trace where the measured value is lowest.

Searching for Maximum and Minimum Values

Step 1. Following Step 1 to Step 4 in “Reading Values on the Trace” on page 128, activate the marker you are using to search for the maximum and minimum values.

Step 2. Press **Marker Search**.

Step 3. Press the corresponding softkey to move the marker to the maximum or minimum measured value.

Softkey	Function
Max	Perform a search for the maximum value.
Min	Perform a search for the minimum value.

NOTE

When the data format is in Smith chart or polar format, execute the search for the main response value of the two marker response values.

Searching for the Target Value (Target Search)

The target search function enables you to move the marker to the point having the target measured value.


Target and Transition Types

A target is a point that has a specific measured value on the trace. Targets can be divided into the two groups shown below depending on their transition type.

Transition type: Positive (Positive)	When the value of the target is larger than the measured value that immediately precedes (on the left)
Transition type: Negative (Negative)	When the value of the target is smaller than the measured value that precedes immediately (on the left)

Figure 6-6

Target and Transition Types



e5070aue050

About the target search function


The target search is a function that searches for a target that matches the pre-defined target value and transition type(s) (positive, negative, or both positive and negative) and then moves the marker to the target being searched.

The following three methods are available for executing the target search:

Target search (Search Peak)	The marker will move to the peak with maximum response value if the peak polarity is Positive or Both or to the peak with minimum response value if the peak polarity is Negative .
Search Left (Search Left)	Execute the search from the current marker position to the smaller stimulus values, and move the marker to the first target encountered.
Search Right (Search Right)	Execute the search from the current marker position to the larger stimulus values, and move the marker to the first target encountered.

Figure 6-7

Target Search (when transition type is set to “both positive and negative”)



e5070aue048

Executing a Target Search

Step 1. Following Step 1 to Step 4 in “Reading Values on the Trace” on page 128, activate the marker you are using for the target search.

Step 2. Press **Marker Search**.

Step 3. Press **Target**.

This causes the target search to be executed based on the definitions of the currently set target value and transition type.

Step 4. Press **Target Value**, and enter the target value in the entry area that appears.

This causes the target search to be executed based on the definitions of the currently set target value and transition type.

Step 5. Press **Target Transition**.

Step 6. Select a transition type.

Softkey	Function
Positive	Select Positive as the transition type.
Negative	Select Negative as the transition type.
Both	Select both Positive and Negative as the transition type.

This causes the target search to be executed based on the definitions of the currently set target value and transition type.

Step 7. Press the corresponding softkey to move the marker to the target.

Softkey	Function
Search Target	Execute the target search.
Search Left	Execute the left search.

Data Analysis

Analyzing Data on the Trace Using the Marker

Softkey	Function
Search Right	Execute the right search.

NOTE

When the data format is in Smith chart or polar format, execute the search for the main response value of the two marker response values.

Searching for the Peak

The peak search function enables you to move the marker to the peak (inflection point) on the trace.

Definition of the Peak


A peak is a measurement point whose value is greater or smaller than the adjoining measurement points on its right and left sides. Peaks are classified into the following two types depending on the difference in magnitude from the measurement points on either side of it.

Positive peak (Positive)	A peak whose measured value is greater than those of the measurement points on either side of it (peak polarity: positive).
Negative peak (Negative)	A peak whose measured value is smaller than those of the measuring points on either side of it (peak polarity: negative).

The smaller of the differences in measured values from the adjoining peaks of the opposite polarity is called peak deviation.

Figure 6-8

Positive Peak/Negative Peak and Peak Deviation



About the Peak Search Function


The peak search is a function that searches for a peak that matches a pre-defined peak deviation and peak polarity (positive or negative) and then moves the marker to the peak being searched.

The following three methods are available for executing the peak search:

Peak search (Search Peak)	Move the marker from the current marker position to the peak that is closest based on the stimulus values.
Left search (Search Left)	Execute the search from the current marker position to the smaller stimulus values, and move the marker to the first peak encountered.
Right search (Search Right)	Execute the search from the current marker position to the larger stimulus values, and move the marker to the first peak encountered.

Figure 6-9

Peak Search (when peak polarity is positive)



Executing a Peak Search

Step 1. Following Step 1 to Step 4 in “Reading Values on the Trace” on page 128, activate the marker you are using for the peak search.

Step 2. Press **Marker Search**.

Step 3. Press **Peak**.

This causes the target search to be executed based on the definitions of the currently set peak deviation and peak polarity.

Step 4. Press **Peak Excursion**, and enter the peak deviation in the entry area that appears.

This causes the target search to be executed based on the definitions of the newly set peak deviation and currently set peak polarity.

Step 5. Press **Peak Polarity**.

Step 6. Select a peak polarity.

Softkey	Function
Positive	Select Positive as the peak polarity.
Negative	Select Negative as the peak polarity.
Both	Select both Positive and Negative as the peak polarity.

This causes the target search to be executed based on the definitions of the currently set peak deviation and newly set peak polarity.

Step 7. Press the corresponding softkey to move the marker to the target.

Softkey	Function
Search Peak	Execute the peak search.
Search Left	Execute the left search.

Softkey	Function
Search Right	Execute the right search.

NOTE

When the data format is in Smith chart or polar format, execute the search for the main response value of the two marker response values.

Automatically Executing a Search Each Time a Sweep is Done (Search Tracking)

Search tracking is a function that causes a search to be repeated every time a sweep is done even if the execution key for the search (maximum, minimum, peak, and target) is not pressed. This function facilitates that measurement dispersion be observed, such as the maximum value of traces (e.g., the insertion loss of a bandpass filter).

Performing Search Tracking


- Step 1.** Press **Channel Next** (or **Channel Prev**) and **Trace Next** (or **Trace Prev**) to activate the trace on which search tracking is set up.
- Step 2.** Press **Marker Search**.
- Step 3.** Press **Tracking**, and turn the search tracking function on or off.

Determining the Mean, Standard Deviation, and p-p of the Trace

You can easily determine the statistics data for a trace (mean, standard deviation, and peak-to-peak). Figure 6-10 and Table 6-2 show the definitions for the statistics data elements.

Figure 6-10

Parameters Used for Calculating Statistics Data



e5070aue053

Table 6-2

Definitions of Statistics Data

Statistics data element	Definition
Mean (mean)	$\frac{\sum_{i=1}^n x_i}{n}$ <p>(n: number of points; x_i: i measured value at the ith measurement point)</p>
Standard deviation (s. dev)	$\sqrt{\frac{\sum_{i=1}^n (x_i - \text{mean})^2}{n - 1}}$ <p>(n: number of points; x_i: F i measured value at the ith measurement point mean: Mean)</p>
Peak-to-peak (p - p)	$\text{Max} - \text{Min}$ <p>(Max: greatest measured value; Min: smallest measured value)</p>

Displaying Statistics Data


- Step 1.** Press **Channel Next** (or **Channel Prev**) and **Trace Next** (or **Trace Prev**) to activate the trace for which statistics data is required.
- Step 2.** Press **Marker Fctn**.
- Step 3.** Press **Statistics** to turn on the display of statistics data.

Determining the Bandwidth of the Trace (Bandwidth Search)

The bandwidth search is a function for determining the bandwidth of the trace, center frequency, cut-off points (on the higher frequency and the lower frequency sides), Q, and insertion loss, based on the position of the active marker. The definitions of the parameters determined through the bandwidth search are shown in Figure 6-5 and Table 6-3. The user specifies the defined bandwidth value in Figure 6-11.

Figure 6-11

Bandwidth Parameters



e5070aue054

Table 6-3

Definitions of Bandwidth Parameters

Bandwidth Parameter	Definition
Insertion loss (loss)	The measured value of the position of the active marker at the time the bandwidth search is executed.
Lower frequency cut-off point (low)	Frequency at one of two measurement points, both separated by the defined bandwidth value from the active marker position, which corresponds to the lower of the two frequencies.
Higher frequency cut-off point (high)	Frequency at one of two measurement points, both separated by the defined bandwidth value from the active marker position, which corresponds to the higher of the two frequencies.
Center frequency (cent)	Frequency at the midpoint between the lower frequency cut-off and higher frequency cut-off points. $(\frac{high + low}{2})$.
Bandwidth (BW)	The difference in frequency between the higher frequency cut-off and lower frequency cut-off points ($high - low$).
Q	Value obtained by dividing the center frequency by the bandwidth $(\frac{cent}{BW})$.

Executing a Bandwidth Search

- Step 1.** Place the active marker on the desired point on the trace on which the bandwidth search is executed. The response value of this active marker itself is the insertion loss in the

Data Analysis

Analyzing Data on the Trace Using the Marker

bandwidth search (**loss**).


Step 2. Press **Marker Search**.

Step 3. Press **Bandwidth Value** and enter the defined bandwidth value in the entry area that appears.

Step 4. Press **Bandwidth** to turn on the bandwidth search. In the upper left of the trace display, six bandwidth parameters are displayed. (See Figure 6-12.)

Figure 6-12

Bandwidth Search Results (defined bandwidth = -3 dB)



Comparing Traces/Performing Data Math

Each of the traces for which measured data is displayed is provided with an additional trace, called a memory trace, that temporarily stores measured data. You can use the memory trace to compare traces on the screen or to perform complex data math between it and measured data.

The following data math operations are available:

Data / Memory	Divides the measured data by the data in the memory trace. This function can be used to evaluate the ratio of two traces (e.g., evaluating gain or attenuation).
Data * Memory	Multiplies the measured data by a memory trace.
Data – Memory	Subtracts a memory trace from the measured data. This function can be used, for example, to subtract a vector error that has been measured and stored (e.g., directivity) from later data measured on a device.
Data + Memory	Adds the measured data and the data in the memory trace.

Performing Data Math Operations

- Step 1.** Press **Channel Next** (or **Channel Prev**) and **Trace Next** (or **Trace Prev**) to activate the trace to be stored in memory.
- Step 2.** Press **Display**.
- Step 3.** Press **Data** → **Mem** to store the measured data in memory.
- Step 4.** Press **Data Math**.
- Step 5.** Select the data math operation to perform.

Softkey	Function
OFF	Turns off data math functions (Do not perform data math.).
Data / Mem	Divide the measured data by the memory trace and store the result in the data trace.
Data * Mem	Multiply the data trace by the memory trace and store the result in the data trace.
Data – Mem	Subtract the memory trace from the data trace and store the result in the data trace.
Data + Mem	Add the data trace and memory trace and store the result in the data trace.

- Step 6.** Press **Display**.

Data Analysis
Comparing Traces/Performing Data Math

Step 7. Select the type of data to display on the screen.

Softkey	Function
Data	Display only the data trace on the screen.
Mem	Display only the memory trace stored by the operation Data → Mem on the screen.
Data & Mem	Display the data trace and memory trace on the screen. You can now easily compare the data trace and memory trace on the screen.
Off	Do not display the trace.

Step 8. Apply the trigger to make measurements.

Performing parameter conversion of measurement result

You can use the parameter conversion function to convert the measurement result of the S-parameter (S_{ab}) to the following parameters.

- ❑ Equivalent impedance (Z_r) and equivalent admittance (Y_r) in reflection measurement

$$Z_r = Z_{0a} \times \frac{1 + S_{ab}}{1 - S_{ab}}, Y_r = \frac{1}{Z_r}$$

- ❑ Equivalent impedance (Z_t) and equivalent admittance (Y_t) in transmission measurement

$$Z_t = \frac{2 \times \sqrt{Z_{0a} \times Z_{0b}}}{S_{ab}} - (Z_{0a} + Z_{0b}), Y_t = \frac{1}{Z_t}$$

- ❑ Inverse S-parameter ($\frac{1}{S_{ab}}$)

Where,

Z_{0a} Characteristic impedance of port a*1

Z_{0b} Characteristic impedance of port b*1

Operational procedure

ON/OFF

- Step 1.** Press **Channel Next** or **Channel Prev** to activate a channel on which you want to use the marker.
- Step 2.** Press **Trace Next** or **Trace Prev** to activate a trace on which you want to use the marker.
- Step 3.** Press **Analysis**.
- Step 4.** Press **Conversion**.
- Step 5.** Press **Conversion** to turn ON the conversion function.

*1. When the fixture simulator function is ON and the port impedance function is ON, the value set in the port impedance conversion is used. In other cases, 50Ω is always used.

Selecting conversion target parameter

Step 1. Press **Channel Next** or **Channel Prev** to activate a channel on which you want to use the marker.

Step 2. Press **Trace Next** or **Trace Prev** to activate a trace on which you want to use the marker.

Step 3. Press **Analysis**.

Step 4. Press **Conversion**.

Step 5. Press **Function**.

Step 6. Press the softkey corresponding to the parameter to which you want to convert.

When the conversion function is ON, the selected parameter is displayed in the “5-5. Trace Status Area” on page 42.

7**Fixture Simulator**

This chapter explains how to use the fixture simulator functions of the Agilent E5070A/E5071A.


Overview of Fixture Simulator

The fixture simulator is a function that uses software in the E5070A/E5071A to simulate various measurement conditions based on the measurement results. The six functions are as follows.

- Network de-embedding
- Port reference impedance conversion
- Matching circuit embedding
- Balance-unbalance conversion^{*1}
- Differential/Common port reference impedance conversion^{*1}
- Differential matching circuit embedding^{*1}

Figure 7-1 shows the data processing flow diagram of the fixture simulator.

Figure 7-1 Data Processing Flow Diagram of Fixture Simulator



e5070aue143

Port extension is an independent function from the fixture simulator, but if the fixture simulator function is on, data processing is automatically executed as a part of fixture simulator to improve the data processing efficiency. (Measurement result is the same as

*1. Option 313, 314, 413, or 414 only.

when the fixture simulator is turned off.) Port extension moves the calibration reference location by setting an electrical delay for a single-ended port. Port extension can eliminate only electrical delay (phase shift) for each single-ended port. Loss or mismatch cannot be eliminated by this function.

Functions for single-ended (unbalanced) port

The following three functions are applied to single-ended ports (unbalanced ports). Balance-unbalance conversion can additionally be applied to such single-ended ports.

Network de-embedding

A function that uses software to remove an arbitrary network (50 Ω system) defined by a two-port Touchstone data file from each test port (single-ended) and to extend the calibration plane. This makes it possible to remove networks that create error elements between the calibration plane and the DUT, thereby enabling a more realistic evaluation of the DUT.

For the setup procedure of network de-embedding function, see “Extending the Calibration Plane Using Network De-embedding” on page 153.

Port reference impedance conversion

A function that uses software to convert an S-parameter measured with a 50 Ω port reference impedance into a value measured with an arbitrary impedance.

For the setup procedure of port reference impedance conversion, see “Converting the Port Impedance of the Measurement Result” on page 154.

Matching circuit embedding

A function for converting an original measurement result into a characteristic determined under the condition of inserting a matching circuit between the DUT and the test port (single-ended). The matching circuit to be inserted is either selected from the five predetermined circuit models or provided by a designated arbitrary circuit defined in a two-port Touchstone file.

For the setup procedure of matching circuit embedding, see “Determining Characteristics After Adding a Matching Circuit” on page 155.

Balance-unbalance conversion (option 313, 314, 413, or 414)

A function that uses software to convert the measurement results in an unbalanced DUT state, which are obtained by connecting the DUT to the test port of the E5070A/E5071A, into measurement results in a balanced state. Two test ports of the E5070A/E5071A are connected to one balanced port of the DUT.

For the setup procedure of balance-unbalance conversion, see “Evaluating Balanced Devices (balance-unbalance conversion function)” on page 158.

Functions for balanced port (option 313, 314, 413, or 414)

The following two functions are applied to a balanced (differential) port converted by balance-unbalance conversion.

Differential port impedance conversion

A function for converting the differential mode port impedance of a balanced port after an balance-unbalance conversion. Balance-unbalance conversion automatically converts the differential mode port impedance at the balanced port into $2Z_0$ and the common mode port impedance into $Z_0/2$, compared with the two pre-conversion port impedances of Z_0 . Differential port impedance conversion further converts a differential port impedance after balance-unbalance conversion into an arbitrary port impedance.

For the setup procedure of differential port impedance conversion, see “Converting reference impedance of balanced port” on page 165.

Differential matching circuit embedding

A function for converting the measurement results obtained from balance-unbalance conversion into a characteristic under the condition of inserting a matching circuit in the balanced port.


For setup procedure of differential matching circuit embedding, see “Determining the Characteristics that Result from Adding a Matching Circuit to a Differential Port” on page 167.

Extending the Calibration Plane Using Network De-embedding

Network de-embedding is a function for performing measurements, test port by test port, by removing the characteristics of an arbitrary network defined by a Touchstone data file. By removing the characteristics of the cable, test fixtures, etc. between the actual calibration plane and the DUT, the calibration plane can be correspondingly extended. The network de-embedding function can be used together with the port extension function (see Figure 7-2).

Figure 7-2

Port Extension and Calibration Plane Extension Using Network De-embedding



Using the Network De-embedding Function


- Step 1.** Prepare a two-port Touchstone data file (.s2p format) corresponding to the network to be removed.
- Step 2.** Press **Analysis** - **Fixture Simulator** - **De-Embedding**.
- Step 3.** Press **Select Port**.
- Step 4.** Press **1**, **2**, **3**, or **4** to select the test port from which the network de-embedding is performed.
- Step 5.** Press **User File**.
- Step 6.** Using the dialog box that appears, select the Touchstone data file defining the characteristics of the network to be removed. Once the file is selected, the selection of **Select Type** automatically changes to **User**. To cancel a user-defined file that has been set up, press **Select Type - None**.
- Step 7.** Repeat Step 3 to Step 6 to set up the Touchstone data file for each port from which a network is to be removed.
- Step 8.** Press **De-Embedding** to turn the network de-embedding function **ON**.
- Step 9.** Press **Return**.
- Step 10.** If **Fixture Simulator** is **OFF**, press the key again to turn it **ON**.

Converting the Port Impedance of the Measurement Result

The measured value obtained by using a port impedance of $50\ \Omega$ can be converted into a measured value at an arbitrary port impedance.

Figure 7-3

Port Impedance Conversion Function



Converting the Port Impedance


- Step 1.** Press **[Analysis]** - **Fixture Simulator** - **Port Z Conversion**.
- Step 2.** Press **Port 1 Z0**, **Port 2 Z0**, **Port 3 Z0**, or **Port 4 Z0** to select the port whose impedance will be changed.
- Step 3.** Enter the port impedance as a numeric value.
- Step 4.** Repeat Step 2 and Step 3 to specify the port impedance for each port changed.
- Step 5.** Press **Port Z Conversion** to change the port impedance conversion function to the **ON** state.
- Step 6.** Press **Return**.
- Step 7.** If **Fixture Simulator** is **OFF**, press the key again to turn it **ON**.

Determining Characteristics After Adding a Matching Circuit

Using the matching circuit embedding function, you can easily obtain the resulting characteristics after adding a matching circuit for each test port (see Figure 7-4).

Figure 7-4

Matching Circuit Function



e5070aue008

Define the matching circuit to be added by one of the following methods:

- Select one from the five predetermined circuit models and specify the values for the elements in the circuit model.
- Use a user file (in two-port Touchstone data format) that defines the matching circuit to be added.

The circuit models used for defining matching circuits are shown in Figure 7-5.

Using the Matching Circuit Function

Step 1. Press **Analysis** - **Fixture Simulator - Port Matching**.

Step 2. Press **Select Port**.

Step 3. Press **1**, **2**, **3**, or **4** to select the port to which a matching circuit is to be added.

Step 4. To add a matching circuit defined in a user file, execute the following operations:


a. Press **User File**.

b. In the dialog box that appears, select the two-port Touchstone data file (.s2p format) for the matching circuit to be added.

Once a user file is specified, the selection of **Select Circuit** automatically changes to **User**. In this case, you do not need to execute Step 5 and Step 6.

Figure 7-5

Circuit Models for Defining Matching Circuits



e5070aue009

NOTE

If the user file (in two-port Touchstone data format) is defined in a normalized impedance other than the 50 Ω system, data is automatically converted into the 50 Ω system when the E5070A/E5071A receives the file.

For a network defined in the user file, it is assumed that port 1 is connected to the test port and port 2 is connected to the DUT.

Step 5. Press **Select Circuit**.

Step 6. Select a matching circuit model (see Figure 7-5).

Softkey	Function
None	No matching circuit is added.
Series L - Shunt C	Select a circuit model consisting of a series inductor and a shunt capacitor.
Shunt C - Series L	Select a circuit model consisting of a shunt capacitor and a series inductor.
Shunt L - Series C	Select a circuit model consisting of a shunt inductor and a series capacitor.
Series C - Shunt L	Select a circuit model consisting of a series capacitor and a shunt inductor.
Shunt L - Shunt C	Select a circuit model consisting of a shunt inductor and a shunt capacitor.
User	Select the circuit model defined in the user file imported by performing Step 4.

Step 7. Specify the values of the elements in the selected circuit model.

Softkey	Function
C	Specifies the capacitance [F].
G	Specifies the conductance [S].
L	Specifies the inductance [H].
R	Specifies the resistance [Ω].

Step 8. Repeat Step 3 to Step 7 to set up the matching circuit for each port used.

Step 9. Press **Port Matching** to turn the matching circuit function **ON**.

Step 10. Press **Return**.


Step 11. If **Fixture Simulator** is **OFF**, press the key again to turn it **ON**.

Evaluating Balanced Devices (balance-unbalance conversion function)

The balance-unbalance conversion function simulates a measurement under a balanced state based on measurement results obtained in an unbalanced state (Figure 7-6). This function enables you to evaluate devices with balanced ports.

Figure 7-6

Balance-unbalance conversion



e5070aue170

The types of devices that can be evaluated using the E5070A/E5071A are shown in Figure 7-7.


NOTE

To evaluate a balanced device, an E5070A/E5071A with at least three test ports (option 313, 314, 413, or 414) is required.

Evaluating Balanced Devices (balance-unbalance conversion function)

Figure 7-7

Type of balanced devices that can be evaluated with E5070A/E5071A



e5070aue010

In the terminology of the E5070A/E5071A, ports after the balance conversion are called logical ports (or DUT ports).

You can assign the test ports of the E5070A/E5071A to logical ports (a to d in Figure 7-7) freely.

7. Fixture Simulator

Measurement parameters of balanced devices

Turn on the balance-unbalance conversion function to measure the following parameters.

- Mixed mode S-parameter
- Imbalance parameter
- CMRR (Common Mode Rejection Ratio)

Mixed mode S-parameter

By turning on the balance-unbalance conversion function, you can obtain the S-parameter of the balanced port separately for 2 modes, the differential mode and the common mode. Figure 7-8 shows the notation of the S-parameter in balance measurement (mixed mode S-parameter).

Figure 7-8

Notation of mixed mode S-parameter





Figure 7-9 to Figure 7-11 show the mixed mode S-parameter when measuring each balanced device.

Evaluating Balanced Devices (balance-unbalance conversion function)

Figure 7-9


Mixed mode S-parameter when measuring a single-ended - balanced device



e5070aue184

Figure 7-10


Mixed mode S-parameter when measuring a balanced - balanced device



e5070aue183

Figure 7-11

Mixed mode S-parameter when measuring a single-ended - single-ended - balanced device



e5070aue185

Imbalance parameter

By turning on the balance-unbalance conversion function, you can select the imbalance parameter of the balanced port as the measurement parameter. Figure 7-12 to Figure 7-14 show the imbalance parameter you can select when measuring each balanced device.

Figure 7-12

Parameter when measuring a single-ended - balanced device (Imbalance)




Figure 7-13

Parameter when measuring a balanced - balanced device (Imbalance1, Imbalance2)





Figure 7-14

Parameter when measuring a single-ended - single-ended - balanced device (Imbalance1, Imbalance2)



CMRR (Common Mode Rejection Ratio)

By turning on the balance-unbalance conversion function, you can select CMRR (ratio between the transmission characteristic in the differential mode and that in the common mode) of the balanced port as the measurement parameter. The table below shows the CMRR parameter you can select when measuring each balanced device.

Single-ended - balanced device	$\frac{S_{ds21}}{S_{cs21}}$
Balanced - balanced device	$\frac{S_{dd21}}{S_{cc21}}$
Single-ended - single-ended - balanced device	$\frac{S_{ds31}}{S_{cs31}}$ and $\frac{S_{ds32}}{S_{cs32}}$

Steps for Balance-Unbalance Conversion

NOTE

When using three test ports, perform a full three-port calibration on the test ports to be used. When using four test ports, perform a full four-port calibration.

Extend the calibration plane, if necessary, by using the port extension function or network de-embedding function. For more on the port extension and network de-embedding functions, see “Extending the Calibration Plane Using Network De-embedding” on page 153.

- Step 1.** Press **Analysis**.
- Step 2.** Press **Fixture Simulator**.
- Step 3.** Press **Topology**.
- Step 4.** Press **Device**.
- Step 5.** Select the balanced/unbalanced topology.

Softkey	Function
SE-Bal	Establish port 1 on the DUT as an unbalanced port and port 2 as a balanced port.
Bal-Bal	Establish both port 1 and port 2 on the DUT as balanced ports.
SE-SE-Bal	Establish port 1 and port 2 on the DUT as unbalanced ports and port 3 as a balanced port.

- Step 6.** Select each port on the analyzer to which a port on the DUT is connected.

· When you have selected **SE-Bal** in Step 5:

Softkey	Function
Port 1 (se)	Select a port on the analyzer from among 1, 2, 3, and 4 for connection to logical 1 (Port a in Figure 7-7).
Port 2 (bal)	Select two ports on the analyzer from among 1-2, 1-3, 1-4, 2-3, 2-4, and 3-4 for connection to logical port 2 (Port b and Port c in Figure 7-7).

· When you have selected **Bal-Bal** in Step 5:

Softkey	Function
Port 1 (bal)	Select two ports on the analyzer from among 1-2, 1-3, 1-4, 2-3, 2-4, and 3-4 for connection to logical port 1 (Port a and Port b in Figure 7-7).
Port 2 (bal)	Select two ports on the analyzer from among 1-2, 1-3, 1-4, 2-3, 2-4, and 3-4 for connection to logical port 2 (Port c and Port d in Figure 7-7).

7. Fixture Simulator

· When you have selected **SE-SE-Bal** in Step 5:

Softkey	Function
Port 1 (se)	Select a port on the analyzer from among 1, 2, 3, and 4 for connection to logical 1 (Port a in Figure 7-7).
Port 2 (se)	Select a port on the analyzer from among 1, 2, 3, and 4 for connection to logical 2 (Port b in Figure 7-7).
Port 3 (bal)	Select two ports on the analyzer from among 1-2, 1-3, 1-4, 2-3, 2-4, and 3-4 for connection to logical port 3 (Port c and Port d in Figure 7-7).

Step 7. Press **Return**.

Step 8. Press **BalUn** to turn on the balanced/unbalanced state conversion function.

Step 9. Press **Fixture Simulator** to turn on the fixture simulator function.

Steps for Measurement Parameter Setups

Performing balance-unbalance conversion enables you to make measurements with mixed mode S-parameters, imbalance parameters and CMRR. Parameters that can be used differ depending on the balance-unbalance topology specified in Step 5 in “Steps for Balance-Unbalance Conversion” on page 163.

Step 1. Press **Meas** (or **Analysis**) - **Fixture Simulator - Measurement**).


Step 2. Select the measurement parameter.

Converting reference impedance of balanced port

By using the port impedance conversion function, you can specify the impedance of each test port. As a result of this conversion, the impedance of the balanced port in differential mode is set to a value twice as large as the impedance of the two unbalanced ports before conversion, and in common mode to a value one-half as large (see Figure 7-15).

Figure 7-15

Port Impedance After a Balance-Unbalance Conversion



Be sure to set the impedances of the two unbalanced ports equal to each other. For more details on setting up port impedance for unbalanced ports, refer to “Converting the Port Impedance of the Measurement Result” on page 154.

7. Fixture Simulator

Converting port reference impedance in differential mode

If you turn on the differential port impedance conversion function, the port reference impedance in the differential mode is converted to an arbitrary value specified with this function instead of the value in Figure 7-15.

Procedure to turn on/off differential port reference impedance conversion function

- Step 1. **[Analysis]** - Press **Fixture Simulator - Diff Z Conversion**.
- Step 2. Press **Diff Z Conversion** to set the differential impedance conversion function to **ON**.

You can only turn on or off Differential Port Impedance Conversion for all the balanced ports, but not for each port individually. If you want to turn off a specific port only, set the reference impedance of the port to the value in Figure 7-15 .

Procedure to set differential port reference impedance

- Step 1. **[Analysis]** - Press **Fixture Simulator - Diff Z Conversion**.
- Step 2. Press **Port 1 (bal)**, **Port 2 (bal)**, or **Port 3 (bal)** to select the balanced port.
- Step 3. Enter a value of the port reference impedance in the differential mode.

Converting port reference impedance in common mode

If you turn on the common port impedance conversion function, the port reference impedance in the common mode is converted to an arbitrary value specified with this function instead of the value in Figure 7-15.

Procedure to turn on/off common port reference impedance conversion

- Step 1. **[Analysis]** - Press **Fixture Simulator - Cmn Z Conversion**.
- Step 2. Press **Cmn Z Conversion** to set the differential impedance conversion function to **ON**.

You can only turn on or off Common Port Impedance Conversion for all the ports, but not for each port individually. If you want to turn off a specific port only, set the impedance of the port to the value in Figure 7-15 .

Procedure to set common port reference impedance

- Step 1. **[Analysis]** - Press **Fixture Simulator - Cmn Z Conversion**.
- Step 2. Press **Port 1 (bal)**, **Port 2 (bal)**, or **Port 3 (bal)** to select the balanced port.
- Step 3. Enter a value of the port reference impedance in the common mode.


Determining the Characteristics that Result from Adding a Matching Circuit to a Differential Port

You can obtain the characteristics resulting from the pseudo addition of a balance matching circuit to a balanced port created by balance-unbalance conversion.

By using the matching circuit function, you can obtain the characteristics resulting from the addition of an arbitrary matching circuit for each test port (see Figure 7-16).

Figure 7-16

Balance Matching Circuit Function



e5070aue012


Define the matching circuit to be added by one of the following methods:

- Use a predetermined circuit model and specify the values for the elements in the circuit model.
- Use a user file (in two-port Touchstone format) to define the matching circuit to be added.

Figure 7-17 shows the circuit models used in defining a balance matching circuit.

Figure 7-17

Circuit Models Used to Define Balance Matching Circuit



e5070aue15

NOTE

For a network defined in a user file, it is assumed that port 1 is connected to the test port and port 2 is connected to the DUT.

The setup steps are shown below.

Step 1. Press **[Analysis]** - **Fixture Simulator - Diff. Matching**.

Step 2. Press **Select Port**.

Step 3. Press **1**, **2**, or **3** to select the port on the DUT to which a differential matching circuit will be added.

Step 4. To add a matching circuit defined in a user file, perform the following operations:

- a. Press **User File**.
- b. Using the dialog box that appears, select the 2-port Touchstone data file (.s2p format) for the matching circuit to be added.

Once you have specified the user file, the selection of **Select Circuit** automatically changes to **User**. In this case, you do not have to execute Step 5 and Step 6.

Step 5. Press **Select Circuit**.

Step 6. Select a differential matching circuit model (see Figure 7-17).

Softkey	Function
None	The matching circuit is not added.
Shunt L - Shunt C	Selects a circuit model consisting of a shunt inductor and a shunt capacitor.
User	Selects the circuit model defined in the user file imported in Step 4.

Step 7. Specify the values for the elements in the circuit model selected.

Softkey	Function
C	Specifies the capacitance [F].
G	Specifies the conductance [S].
L	Specifies the inductance [H].
R	Specifies the resistance [Ω].

Step 8. Repeat Step 3 to Step 7 to set up the differential matching circuit to be added to the selected ports on the DUT.

Step 9. Press **Diff. Matching** to turn the differential matching circuit **ON**.

Step 10. Press **Return**.

Step 11. If **Fixture Simulator** is **OFF**, press the key again to turn it **ON**.

Example of using fixture simulator


In this section, the fixture simulation function is explained based on an evaluation example for a DUT (balanced SAW filter) with a balanced port.

Measurement circuit example for a DUT with balanced port

Figure 7-18 shows an example of a measurement circuit used to evaluate a balanced SAW filter. DUT port 1 is an unbalanced port connected to source impedance R_s and input matching circuit L_1 . DUT port 2 is a balanced port connected to an output matching circuit (C_1 , C_2 , and L_2) and load resistance R_L .

Figure 7-18

Measurement circuit of balance SAW filter




Evaluation using an actual test fixture

Generally, a test fixture as shown in Figure 7-19 is fabricated for evaluating the characteristics of a DUT in a measurement circuit by using a network analyzer.

Generally, a network analyzer performs measurements at a 50Ω port reference impedance and in a single-ended (unbalanced) state. Therefore, DUT port 1 can be connected directly to the test port of the network analyzer. On the other hand, DUT port 2 is a balanced port that cannot be connected directly to the test port of the network analyzer. Usually, a balun (BALance-UNbalance transformer) is used to convert the DUT's balanced port to an unbalanced port and to connect the converted port to the test port of the network analyzer. Matching circuits are mounted in the test fixture as shown in the figure.

Figure 7-19 DUT evaluation using an actual test fixture



Problems in measurement with an actual test fixture

Evaluating a balanced device with an actual test fixture has the following problems:

- Calibration cannot be performed at the DUT's terminals. (A DUT's terminals are in the test fixture and calibration standards cannot be connected to them. In addition, it is very difficult to obtain calibration standards that can be used to calibrate a balanced port.) As a result, calibration is performed at appropriate connectors connected to the test fixture, and the network between the calibration reference plane and the DUT's terminals induces measurement errors.
- Different test fixtures must be fabricated for evaluating different types of DUTs because they require different characteristic impedances and matching circuits.
- An actual balun does not have an ideal characteristics. Measurement error cannot be avoided. Furthermore, a common mode signal evaluation cannot be performed when an actual balun is used.

DUT evaluation using the E5070A/E5071A's fixture simulator

The E5070A/E5071A's fixture simulator function simulates a test fixture by using internal software instead of using an actual test fixture for evaluating DUTs.

Figure 7-20 shows an example connection for evaluating a DUT with the E5070A/E5071A's fixture simulator function. The unbalanced port of the DUT should be directly connected to a test port of the E5070A/E5071A and the balanced port of the DUT should be connected to two other test ports of the E5070A/E5071A. The actual measurement by the E5070A/E5071A is performed at single-ended ports with a 50 Ω port reference impedance.

Figure 7-20

DUT connection when fixture simulator is used





Figure 7-21 shows the measurement circuit simulated by the fixture simulator based on actual measurement with the test fixture shown in Figure 7-20.

Figure 7-21 Measurement circuit simulated by fixture simulator



e5070aue168

First, the effect of an undesired network can be eliminated by port extension and/or network de-embedding. In Figure 7-20, since calibration standards cannot be connected to the DUT terminals to perform calibration, calibration should be performed at the connectors to the test fixture. Using port extension and/or network de-embedding enables you to remove an undesired network by using data processing and moving the calibration reference plane to the DUT's side equivalently. This function is performed for a single-ended port even if balance-unbalance conversion is applied to the port.

Port reference impedance conversion converts measured S-parameters to those at arbitrary port reference impedance. In Figure 7-20, since the single-ended port of the DUT is connected to the E5070A/E5071A's test port (50 Ω, single-ended), port reference impedance conversion is not required. This function is performed for a single-ended port even if balance-unbalance conversion is applied to the port.

Matching circuit embedding converts measured S-parameters to those when a matching circuit is added to the DUT's terminal. This function is performed for a single-ended port even if balance-unbalance conversion is applied to the port.

Balance-unbalance conversion converts S-parameters measured at an unbalanced state to mixed-mode S-parameters measured at a balanced state. The balanced port signal can be evaluated by using differential mode and common mode signals.

Differential matching circuit embedding converts measured S-parameters to those when a matching circuit is added to the DUT's differential mode port.

Differential port reference impedance conversion converts a differential port reference impedance to a arbitrary impedance. Port reference impedance Z [Ω] at the two single-ended ports before balance conversion is automatically converted to $2Z$ [Ω] for differential mode port and $Z/2$ [Ω] for common mode port after balance conversion. Accordingly, if port reference impedance conversion is not performed for the two single-ended ports before balance conversion, differential mode port reference impedance Z_d becomes $50\ \Omega \times 2 = 100\ \Omega$, and common mode port reference impedance Z_c becomes $50\ \Omega / 2 = 25\ \Omega$. Since the differential port is terminated with 200 Ω in Figure 7-18, differential port reference impedance Z_d should be set to 200 Ω.

Advantages of balanced DUT evaluation using fixture simulator

Balanced device evaluation using the fixture simulator has the following advantages:

- Calibration reference plane can be easily moved to the DUT's terminal after calibration is performed at the connectors where calibration standards can be connected. Undesired network can be removed to eliminate measurement errors (port extension, network de-embedding).
- Characteristics of a DUT, including desired matching circuits, can be obtained easily (matching circuit embedding, differential matching circuit embedding). Port reference impedance can be set freely (port reference impedance conversion, differential port reference impedance conversion).
- Differential mode and common mode signal evaluation (mixed-mode S-parameter evaluation) can be performed easily (balance-unbalance conversion).

Fixture Simulator
Example of using fixture simulator

8

Analysis in Time Domain (Option 010)

This chapter describes how to deal responses in time domain using the time domain function (Option 010).

Overview


Overview of time domain measurement

The E5070A/E5071A Option 010 provides the time domain function. The time domain function is a function to mathematically transform waveforms in frequency domain that can be measured with a general network analyzer to waveforms in time domain.

Figure 8-1 shows the waveforms in frequency domain and in time domain for the same cable. The waveform in frequency domain shows ripples due to mismatches, but it is difficult to estimate their locations. On the other hand, from the waveform in time domain, you can find out the locations and magnitudes of mismatches.

Figure 8-1

Example of measurement in time domain and in frequency domain



Comparison to time domain reflectometry (TDR) measurement

The time domain function of the E5070A/E5071A is similar to the time domain reflectometry (TDR) measurement in it displays the response in time domain.

In the TDR measurement, a pulse or step signal is inputted to the DUT and the change of the reflected wave over time is measured.

On the other hand, the time domain function of the E5070A/E5071A changes the frequency of the input signal to the DUT, performs measurement in frequency domain, and transforms the result to the response in time domain using the inverse Fourier transform.

Time domain function of E5070A/E5071A

The time domain function of the E5070A/E5071A is divided into the following 2 types of functions. You can use them at the same time.

- Transformation function
Transforms measurement data in frequency domain to data in time domain. For more information, refer to “Transformation to time domain” on page 178.
- Gating function
Deletes unnecessary data in time domain from original data in time domain. For more information, refer to “Deleting unnecessary data in time domain (gating)” on page 188.

Transformation to time domain

The transformation function lets you transform the response in frequency domain to the response in time domain.

Flow of measurement

Table 8-1 shows the flow of measurement.

Table 8-1 Flow of transformation to time domain

Item	Description
“Selecting a type” on page 179	Select the transformation type from the following. <ul style="list-style-type: none">• Band pass mode You can set the sweep range arbitrarily. This is suitable for devices through which signals within a certain frequency range pass such as filters.• Low pass mode Simulates the TDR measurement. This mode is suitable for devices through which dc current or signals of many frequencies pass such as cables. The low pass mode provides 2 types of modes: low pass step and low pass impulse.
“Setting the window” on page 181	To reduce a phenomenon (ringing) in which a waveform waves caused because the frequency domain is finite, set the window.
“Calculating necessary measurement conditions” on page 182	To obtain the necessary resolution and measurement range in time domain, calculate the following values. <ul style="list-style-type: none">• Sweep range• Number of points• Window width
“Setting the frequency range and the number of points” on page 186	Set the sweep range and the number of points to the values calculated above.
“Setting display range” on page 186	Set the range displayed on the graph.
“Enabling transformation function” on page 187	Enables the transformation function.

Selecting a type

There are 2 types of transformation to time domain: band pass and low pass. The appropriate transformation type differs depending on the DUT.

Comparison between the band pass mode and the low pass mode

Item	Band pass	Low pass
Appropriate DUT	DUTs that do not operate with dc current such as band pass filters.	DUTs that operate with dc current such as cables.
Input signal	You can simulate the response to the impulse signal.	You can simulate the TDR measurement. You can simulate the response to both the impulse signal and step signal.
Selection of the sweep range	You can select the sweep range arbitrarily.	Because dc data is estimated from the first several points, the frequencies of measurement points must be multiples of the start frequency.
Transmission/reflection measurement	You can perform both transmission and reflection measurements.	You can perform both transmission and reflection measurements.
Identification of mismatches	You can identify the locations of mismatches.	You can identify the locations of mismatches and the type of impedance (capacitive or inductive).
Resolution		The resolution in time domain improves two times compared to the band pass mode.
Available data format	<input type="checkbox"/> Liner magnitude format <ul style="list-style-type: none"> • In the reflection measurement, it indicates the mean of the reflection coefficient within the frequency sweep range. • In the transmission measurement, it indicates the mean of the transmission coefficient within the frequency sweep range. <input type="checkbox"/> Log magnitude format <ul style="list-style-type: none"> • In the reflection measurement, it indicates the mean of the return loss within the frequency sweep range. • In the transmission measurement, it indicates the mean of the transmission gain within the frequency sweep range. <input type="checkbox"/> SWR format <ul style="list-style-type: none"> • In the reflection measurement, it indicates the mean of SWR (standing wave ratio) within the frequency sweep range. 	<input type="checkbox"/> Real format <ul style="list-style-type: none"> • In the low pass mode, the real format is useful because the time axis data does not have phase information.

Impulse signal and step signal


The E5070A/E5071A lets you simulate the response from the DUT to 2 types of signals: impulse signal and step signal. The impulse signal is a pulse-shape signal in which the voltage rises from 0 to a certain value and returns to 0 again. The pulse width depends on the frequency sweep range. The step signal is a signal in which the voltage rises from 0 to a certain value. The rise time depends on the maximum frequency within the frequency sweep range.

NOTE

For more information on how the frequency span setting affects the pulse width and the rise time, refer to "Calculating necessary measurement conditions" on page 182.

Figure 8-2

Step signal and impulse signal



Operation

- Step 1.** Press **Channel Next** (or **Channel Prev**) and **Trace Next** (or **Trace Prev**) to activate a trace for which you want to set the transformation type.
- Step 2.** **Analysis** - Press **Transform** to display the "Transform" menu.
- Press
- Step 3.** **Type** and then press one of the following softkeys to specify the type.

Softkey	Function
Bandpass	Sets the transformation type to "band pass."
Lowpass Step	Sets the transformation type to "lowpass step."
Lowpass Imp.	Sets the transformation type to "lowpass impulse."

- Step 4.** Press **Format** to display the "Format" menu and then select the data format.

Setting the window

Because the E5070A/E5071A transforms data within a finite frequency domain to data in time domain, unnatural change of data at the end points within the frequency domain occurs. For this reason, the following phenomena occur.

- The width of the impulse signal and the rise time of the step signal
The time width occurs in the impulse signal and the rise time occurs in the step signal.
- Sidelobe
Sidelobes (small peaks around the maximum peak) occur in the impulse signal and the step signal. Ringing occurs on the trace due to sidelobes, which reduces the dynamic range.

By using the window function, you can lower the level of sidelobes. However, the width of the impulse and the rise time of the step become larger as a penalty. You can select from 3 types of windows: maximum, normal, and minimum. Table 8-1 shows the relation between the window and the sidelobe/impulse width.


Table 8-2 Characteristics of window

Window	Sidelobe level of the impulse signal	Width of the impulse (50% in low pass mode ^{*1})	Sidelobe level of the step signal	Rise time of the step signal (10 – 90 %)
Maximum	-13 dB	0.60/frequency span	-21 dB	0.45/frequency span
Normal	-44 dB	0.98/frequency span	-60 dB	0.99/frequency span
Minimum	-75 dB	1.39/frequency span	-70 dB	1.48/frequency span

*1. The value in the band pass mode is 2 times the value in the low pass mode.

The window function is available only when the response in time domain is displayed. It does not have any effect when the response in frequency domain is displayed. Figure 8-3 shows the effect of the window when measuring the reflection of a short circuit in time domain.

Figure 8-3 Effect of window on response from a short circuit in time domain



e5070aue216

Analysis in Time Domain (Option 010)

Transformation to time domain

Operation

Step 1. Press **Channel Next** (or **Channel Prev**) and **Trace Next** (or **Trace Prev**) to activate a trace for which you want to set the window.

Step 2. Press **Analysis** - Press **Transform** to display the "Transform" menu.

Step 3. Window and then select a window type.

Softkey	Function
Maximum	Sets the window type to maximum. β of the Kaiser Bessel function is set to 13.
Normal	Sets the window type to normal. β of the Kaiser Bessel function is set to 6.
Minimum	Sets the window type to minimum. β of the Kaiser Bessel function is set to 0.
Rise Time	Sets the window by specifying the impulse width or the step rise time. The lower limit you can set is the value when the window is the minimum; the upper limit when the window is the maximum.
Kaiser Beta	Sets the window by specifying the β value of the Kaiser Bessel function. The Kaiser Bessel function is a function to determine the shape of the window. The allowable setting range is 0 to 13.

NOTE

By specifying **Kaiser Beta**, **Impulse Width**, or **Rise Time**, you can specify a window that is not classified into the 3 window types. When you specify a window type, these values are set automatically.

Calculating necessary measurement conditions

To use the transformation function efficiently, you need to make the following 2 settings appropriately.

- Resolution of the response
- Measurement range
- Sidelobe


This section describes the settings of these conditions.

Effect of frequency sweep range on response resolution

Figure 8-3 shows an example when measuring the same cable while changing the sweep span. When measured in a narrower sweep range, the overlap between 2 peaks is larger than when measured in a wider sweep range. By performing measurement in a wider sweep range, adjacent peaks can be clearly separated, which means that the response resolution is smaller.

Figure 8-4

Effect of frequency sweep range on resolution




The sweep range affects the width of the impulse signal and the rise time of the step signal. The width of the impulse signal and the rise time of the step signal are inversely proportional to the sweep range. Therefore, the wider the sweep range is, the shorter these times are.

The resolution is equal to the width defined at the point of 50% of the impulse signal or the rise time defined at the points of 10% and 90% of the step signal. (Figure 8-5)

Figure 8-5

Definition of the impulse width and the step rise time



e5070aue215

8. Analysis in Time Domain (Option 010)

Effect of the window function on the response resolution


Lowering the sidelobe level with the window function elongates the width of the impulse signal and the rise time of the step signal. As described in “Effect of frequency sweep range on response resolution” on page 183, because the response resolution is equal to the width of the impulse signal and the rise time of the step signal, lowering the sidelobe level enlarges the response resolution. Table 8-1 shows the relation between the response resolution and the window setting.

Table 8-3 The shape of window and response resolution

Window	Low pass step	Low pass impulse	Band pass
Maximum	0.45/frequency span	0.60/frequency span	1.20/frequency span
Normal	0.99/frequency span	0.98/frequency span	1.95/frequency span
Minimum	1.48/frequency span	1.39/frequency span	2.77/frequency span

Figure 8-6 shows how the response changes when changing the window shape. You can see that, if the magnitudes of adjacent peaks are comparable, you need to make the resolution higher and, if they differ significantly, you need to set the window so that smaller peaks with lower sidelobes appear.

Figure 8-6 Effect of window on response resolution



Effect of the transformation type on the response resolution

Although both transformation types, band pass and low pass impulse, simulate the response of the impulse signal, the impulse width in the low pass impulse mode is half the width in the band pass mode as shown in Table 8-1. Therefore, the resolution is better in the low pass mode. If the DUT can be measured in the low pass mode, response data with better resolution is obtained in the low pass mode.

Measurement range

In the time domain function, the measurement range means the range within which the response can be measured without repetition. The repetition of the response occurs because measurement in frequency domain is performed discretely instead of continuously. The measurement range is inversely proportional to the frequency difference between adjacent measurement points. The frequency difference between measurement points ΔF is expressed as follows using the span of the sweep frequency F_{span} and the number of points N_{meas} .

$$\Delta F = \frac{F_{span}}{N_{meas} - 1}$$

Therefore, the measurement range is proportional to (the number of points– 1) and inversely proportional to the span of the sweep range. To enlarge the measurement range, use one of the following methods:

- Increase the number of points.
- Narrow the span of the sweep range.

NOTE

When you change the above settings after performing calibration, you need to perform calibration again.

The sweep range is expressed as time or distance. The time of the measurement range T_{span} is as follows:

$$T_{span} = \frac{1}{\Delta F}$$

The distance of the measurement range L_{span} is expressed as follows using the velocity factor V and the speed of light in a vacuum c (3×10^8 m/s).

$$L_{span} = \frac{Vc}{\Delta F}$$

NOTE

The maximum length of the DUT that can be measured in the transmission measurement is L_{span} . On the other hand, in the reflection measurement, because the signal goes and returns, it is 1/2 of L_{span} .

The velocity factor varies depending on the material through which the signal propagates. For polyethylene, it is 0.66; for Teflon, 0.7.

The change of the setting and the change of the response

Table 8-1 shows the effect of the change of the measurement conditions on the response resolution and the measurement range.

Table 8-4 Effect of setting changes

Change of setting	Response resolution	Measurement range	Sidelobe
Widen the sweep range.	Becomes smaller.	Becomes narrower.	Does not change.
Sets the window type to maximum.	Becomes larger.	Does not change.	Becomes lower.
Increase the number of points.	Does not change.	Becomes wider.	Does not change.

Setting the frequency range and the number of points

Operation

Step 1. Press **Channel Next** (or **Channel Prev**) to activate a channel you want to set.

NOTE The frequency range and the number of points are common to all the traces in the channel. If you want to use different settings, make them on another channel.

Step 2. **Sweep Setup** - Press **Sweep Type - Lin Freq** to set the sweep type to "linear sweep."

NOTE When the sweep type is set to other than the "linear sweep," the time domain function is not available.

Step 3. Use the following keys to set the sweep range.

Key stroke	Function
Start	Sets the start frequency.
Stop	Sets the stop frequency.
Center	Sets the center frequency.
Span	Sets the frequency span.

Step 4. **Sweep Setup** - Press **Points** and then enter the number of points.

Step 5. When performing measurement in the low pass mode, press **Analysis** - **Transform - Set Freq Low Pass** to adjust the frequency range so that it is appropriate for the low pass mode. The frequency changes depending on the stop frequency as shown below.

Condition of the stop frequency	Frequency setting
$> 300 \text{ kHz} \times \text{the number of points}$	Start frequency = stop frequency/number of points
$< 300 \text{ kHz} \times \text{the number of points}$	Start frequency: 300 kHz Stop frequency = 300 kHz \times number of points

When frequency settings satisfy the conditions as shown above, the **Set Freq Low Pass** key displayed in gray.

Setting display range

The E5070A/E5071A has the following limitations on the display range you can set.

Lower limit $-T_{span}^{*1}$

*1. T_{span} is the measurement range expressed in time obtained in "Measurement range" on page 185.

Upper limit $T_{span} * 1$

The number of response points displayed on the graph is the same as the number of points regardless of the response resolution.

Operation

- Step 1.** Press **Channel Next** (or **Channel Prev**) and **Trace Next** (or **Trace Prev**) to activate a trace for which you want to set the display range.
- Step 2.** **Analysis** - Press **Transform** to display the "Transform" menu.
- Step 3.** Press each of the following softkeys and then specify the display range. At the side of the set value in the data entry bar, the distance corresponding to the set time is displayed (Figure 8-7). The displayed distance is a value taking the velocity factor into consideration.


Softkey	Function
Start	Sets the start value of the display range in time.
Stop	Sets the stop value of the display range in time.
Center	Sets the center value of the display range in time.
Span	Sets the span of the display range in time.

NOTE

You cannot use hardkeys to set the display. The hardkeys are dedicated to specifying the sweep range.

Figure 8-7

Data entry bar



e5070auj206

Enabling transformation function

Operation

- Step 1.** Press **Channel Next** (or **Channel Prev**) and **Trace Next** (or **Trace Prev**) to activate a trace for which you want to use the transformation type.
- Step 2.** **Analysis** - Press **Transform** to display the "Transform" menu.
- Step 3.** Press **Transform** to enable (**ON**) the transformation function.

NOTE

The following requirement must be met to enable the transformation function.

- The sweep mode is the linear sweep.
- The measurement points is three or more.

Deleting unnecessary data in time domain (gating)


Flow of measurement

Table 8-1 shows the flow of measurement. Figure 8-8 shows the change of the waveform in each flow.

Table 8-5 Measurement flow

Item	Description
1. Measurement in frequency domain	Execute measurement in frequency domain.
2. Transformation to time domain	Enable the transformation function and transform measurement data to data in time domain.
3. Setting the gate	To select a necessary domain, make the following settings of the gate. <ul style="list-style-type: none"> • Gate type • Gate shape • Gate range
4. Transforming the data back to data in frequency domain	Disable the transformation function and display the response in frequency domain corresponding to the data selected with the gate.

Figure 8-8 Measurement flow



e5070aue211

Setting gate type

The E5070A/E5071A lets you choose from the following 2 gate types:

Gate type	Description
Band pass	Deletes the response outside the gate range.
Notch	Deletes the response inside the gate range.


Operational procedure

- Step 1.** Press **Channel Next** (or **Channel Prev**) and **Trace Next** (or **Trace Prev**) to activate a trace for which you want to set the gate type.
- Step 2.** **Analysis** - Press **Gating** to display the "Gating" menu.
- Step 3.** Press **Type** to toggle between band pass (**Bandpass**) and notch (**Notch**).

Setting gate shape

The gate is a filter whose shape looks like a band pass filter. There are several parameters that indicate the gate shape. Figure 8-9 shows the definitions of them.

Figure 8-9 Parameters of gate shape



e5070aue213

Table 8-1 shows the comparison of the characteristics depending on the gate shape. When the shape is "minimum," the cutoff time is shorter and the response is deleted abruptly, but the sidelobe level and band pass ripples become larger. When it is "maximum," cutoff is gentler, but the sidelobe level and the band pass ripple become smaller. The minimum gate span in Table 8-1 is the minimum gate range you can set. This value is defined as the minimum gate span necessary for the existence of the pass band and is equal to 2 times the cutoff time.

Table 8-6 Comparison of characteristics of gate

Gate shape	Passband ripple	Sidelobe level	Cutoff time	Minimum gate span
Minimum	±0.13 dB	-48 dB	1.4/frequency span	2.8/frequency span
Normal	±0.01 dB	-68 dB	2.8/frequency span	5.6/frequency span
Wide	±0.01 dB	-57 dB	4.4/frequency span	8.8/frequency span
Maximum	±0.01 dB	-70 dB	12.7/frequency span	25.4/frequency span

Analysis in Time Domain (Option 010)
Deleting unnecessary data in time domain (gating)

Operational procedure

- Step 1.** Press **Channel Next** (or **Channel Prev**) and **Trace Next** (or **Trace Prev**) to activate a trace for which you want to set the gate shape.
- Step 2.** **Analysis** - Press **Gating** to display the "Gating" menu.
- Step 3.** Press **Shape** and then select the gate shape from the following.

Softkey	Function
Maximum	Sets the gate shape to "maximum."
Normal	Sets the gate shape to "normal."
Wide	Sets the gate shape to "wide."
Minimum	Sets the gate shape to "minimum."

Setting gate range

Specify the gate range in time. The ends of the range are defined as the -6 dB attenuation points shown in Figure 8-9. You can set the gate range by specifying the start and stop times or the center and span. The E5070A/E5071A has the following limitations on the gate range you can set.

Lower limit	$-T_{span}^{*1}$
Upper limit	T_{span}^{*1}

Operational procedure

- Step 1.** Press **Channel Next** (or **Channel Prev**) and **Trace Next** (or **Trace Prev**) to activate a trace for which you want to set the gate range.
- Step 2.** **Analysis** - Press **Gating** to display the "Gating" menu.
- Step 3.** Press each of the following softkeys to specify the gate range. At the side of the set value in the data entry bar, the distance corresponding to the set time is displayed as shown in Figure 8-7. The displayed distance is a value taking the velocity factor into consideration.

Softkey	Function
Start	Sets the start time.
Stop	Sets the stop time.
Center	Sets the center of the gate in time.
Span	Sets the gate span in time.

NOTE No Hardkey is provided for this setting. The hardkeys are dedicated to setting the sweep range.

*1. T_{span} is the measurement range expressed in time obtained in "Measurement range" on page 185.


NOTE You can set the center and span by dragging and dropping flags indicating the gate range (Figure 8-10).

Enabling gating function

When you enables the gating function, data within the specified range is deleted. When the transformation function is enabled, the flags indicating the gate range is displayed as shown in Figure 8-10.

NOTE In Figure 8-10, the gate type is set to band pass. When it is set to notch, the directions of the flags indicating the ends of the gate range are reversed.

Figure 8-10 Screen when transformation function and gate function are enabled



Operational procedure

- Step 1.** Press **Channel Next** (or **Channel Prev**) and **Trace Next** (or **Trace Prev**) to activate a trace for which you want to use the gate function.
- Step 2.** **Analysis** - Press **Gating** to display the "Gating" menu.
- Step 3.** Use **Gating** to enable (**ON**) the gate function.

Characteristics of response in time domain

This section describes masking and the identification of the mismatch type that are important for analyzing the response in time domain.

Masking

Masking is a phenomenon in which a mismatch at a location near the calibration surface affects the response at the next mismatch location. This occurs because energy reflected by a mismatch at a location nearest to the calibration surface does not reach the next mismatch location. For example, when you measure the reflection of a cable that has 2 mismatch locations reflecting 50% of the input voltage, the first mismatch reflects 50% of the measurement signal. The remaining 50% reaches the next mismatch and its 50%, which is 25% of the entire measurement signal, is reflected. Therefore, in the response in time domain, the 2nd mismatch looks smaller.


NOTE

In this example, the transmission line is assumed to have no loss. However, because there is loss in fact, the signal is attenuated as the distance from the calibration surface becomes greater.

Figure 8-11 shows an example of masking due to loss. It compares masking when a short termination is directly connected to the calibration surface and masking when a 6-dB attenuator is inserted. In either case, total reflection occurs at the short termination. In the latter case, the signal is attenuated in both ways, the return loss looks -12 dB.

Figure 8-11

Example of masking















Identifying mismatch type

The transformation in the low pass mode simulates the response in the TDR measurement. In addition to mismatch locations, the response includes information on the mismatch type.

Figure 8-12 shows each mismatch type and the response waveform corresponding to it. In the low pass mode, you can simulate the response of the step signal and the impulse signal. From the viewpoint of mathematics, the response of the impulse signal is the waveform obtained by differentiating the response of the step signal.

Figure 8-12

Mismatch type and response in low pass mode

	Step response	Impulse Response
Open	 Unity Reflection	 Unity Reflection
Short	 Unity Reflection, -180°	 Unity Reflection, -180°
Resistor $R > Z_0$		
Resistor $R < Z_0$		
Inductor		
Capacitor		

e5070aue212

Analysis in Time Domain (Option 010)
Characteristics of response in time domain

9 Data Output

This chapter explains the concepts behind saving/recalling internal data and printing the information that is displayed on the screen. Procedures for performing these tasks with the Agilent E5070A/E5071A are also given.

Saving and Recalling Instrument State

Using the Save/Recall functions, it is possible to save instrument state from the E5070A/E5071A to a storage medium (e.g., hard disk or floppy disk) for future use. Table 9-1 lists the available save contents.

Table 9-1

Save Contents

Save type	Save contents and purposes
Save settings (State Only)	Saves the settings* ¹ on the E5070A/E5071A. By recalling the saved settings, you can later restore the operating environment of the E5070A/E5071A.
Save settings and calibration data (State & Cal)	Saves the settings* ¹ of E5070A/E5071A and calibration data (calibration coefficient array* ²). By recalling the saved settings, you can later restore the operating environment of the E5070A/E5071A. This option also allows the user to make error corrections using the recalled calibration data.
Save settings and traces (State & Trace)	Saves the settings* ¹ E5070A/E5071A and traces (corrected data array* ² and corrected memory array* ²). By recalling the saved settings, you can later restore the operating environment of the E5070A/E5071A. Saved traces are also recalled together with the settings and displayed on the screen.
Save settings, calibration data, and traces (All)	Saves the settings* ¹ of E5070A/E5071A, calibration data, and traces. By recalling the saved settings, you can restore the operating environment of the E5070A/E5071A. Saved calibration data and traces are also recalled together with the settings.

*1. See Appendix C, “List of Default Values,” for settings to be saved.

*2. See “Data Processing” on page 456 for details about arrays.

File Compatibility in Save/Recall Operations

Unlike saving/recalling data from the same unit of E5070A/E5071A, following compatibility issues must be considered when transferring data between multiple E5070A/E5071A units.

1. Exchanging files between different models

It is not possible to exchange files between different models, e.g., a file saved by the E5070 cannot be loaded into the E5071A.

2. Exchanging files between units with different options

“State Only” files:

- A unit equipped with more ports can load a file saved from a unit with less ports. However, the reverse is not possible.
- A unit with a source attenuator can load a file saved from a unit with no source attenuator. However, the reverse is not possible.

File types other than “State Only”:

- File exchange is not possible if the number of ports and the presence of a source attenuator does not match between the units.

NOTE

Recalling an incompatible file will result in an error and the settings will be reset.

Procedure

Selecting Contents

Follow the procedure below to save internal data from the E5070A/E5071A.

NOTE

This setting takes the effect both when saving the entire instrument state into a file and when saving the instrument state for each channel into memory.

Step 1. Press **Save/Recall**.

Step 2. Press **Save Type**.

Step 3. Press the softkey corresponding to contents you wish to save or recall.

Softkey	Function
State Only	Selects E5070A/E5071A settings only.
State & Cal	Selects E5070A/E5071A settings and calibration data.
State & Trace	Selects E5070A/E5071A settings and traces.
All	Selects E5070A/E5071A settings, calibration data, and traces.

Saving Instrument State

Follow the procedure below to save internal data from the E5070A/E5071A.

Step 1. Press **Save/Recall**.

Step 2. Press **Save State**.

Step 3. When you want to use a pre-defined file name (State01.sta - State08.sta, Autorec.sta)

Press **State01 - State08** or **Autorec**.

NOTE

If “A:\Autorec.sta” or “D:\Autorec.sta” is found on the system at startup, the E5070A/E5071A is automatically configured using the saved settings. When both files are found, “A:\Autorec.sta” is recalled. To disable the auto recall function, delete the Autorec.sta files.

NOTE


When the files already exist, the * symbol is displayed to the right of their softkey label. If you specify one of them, the existing file is copied as “backup.sta” and then it is overwritten.

When you want to use other file name or a file name on the floppy disk

1. Press **File Dialog...** to open the Save As dialog box. Figure 9-1 explains the Save As dialog box.
2. Select the folder and input a file name using the external keyboard and mouse.
3. Click **Save**

Figure 9-1

Save As Dialog Box



e5070aue059

On the E5070A/E5071A, the following drives are available for saving/recalling files. Select the appropriate drive from the **Save In** pull-down menu shown in Figure 9-1

Drive	Description
3 1/2 Floppy [A:]	Select this drive when saving or recalling a file to/from a floppy disk* ¹ .
[D:]	Select this drive when saving or recalling a file to/from the hard disk drive (D drive).

*1. When using the built-in floppy disk drive on the E5070A/E5071A, insert a 1.44 MB floppy disk formatted in DOS format.

NOTE Do not modify any files and folders in drives other than drive A: and drive D:. Doing so will cause malfunctions.

NOTE Do not press the disk eject button while the floppy disk access lamp is on. Trying to forcefully pull the floppy disk out while the lamp is on may damage the floppy disk or disk drive.

Recalling Instrument State

Follow the procedure below to recall internal data from the E5070A/E5071A.

Step 1. Press **Save/Recall**.

Step 2. Press **Recall State**.


Step 3. When you want to recall State01.sta - State08.sta, Autorec.sta

Press **State01 - State08** or **Autorec**.

When you want to recall other files

1. Press **File Dialog...** to open the Open dialog box. Figure 9-2 describes the Open dialog box
2. Select the folder and the file using the external keyboard and mouse.
3. Click **Open**.

Figure 9-2 Open Dialog Box



NOTE

Do not press the disk eject button while the floppy disk access lamp is on. Trying to forcefully pull the floppy disk out while the lamp is on may damage the floppy disk or disk drive.

NOTE

When a user file is used in “Extending the Calibration Plane Using Network De-embedding” on page 153, “Determining Characteristics After Adding a Matching Circuit” on page 155, or “Determining the Characteristics that Result from Adding a Matching Circuit to a Differential Port” on page 167 and the setup status is saved, the recall error will occur if the user file is not located in the previous folder when the state is saved.

Saving/recalling instrument state for each channel into/from memory

The E5070A/E5071A allows you to save/recall the instrument state for each channel only. This function lets you save the instrument state of the active channel only that is specified independently for each channel into one of registers A to D (volatile memory) and recall the instrument state saved in one of registers A to D to restore it as the state of the active channel. Like when saving the entire state of the instrument into a file, you can select items to be saved from 4 kinds (refer to Table 9-2).

Because you can call the instrument state for each channel saved with this function from a channel different from the channel used when it was saved, you can use this function to copy an instrument state between channels.

NOTE

Unlike when saving the entire instrument state, the instrument state for each channel is saved into volatile memory instead of a file and therefore, if you turn off the power, it is lost.

Operational procedure

Saving instrument state for each channel

- Step 1.** Press **Channel Next** or **Channel Prev** to activate a channel whose state you want to save.
- Step 2.** Press **Save/Recall**.
- Step 3.** Press **Save Channel**.
- Step 4.** Press one of **State A** to **State D** to save the instrument state of the active channel to the specified register.

NOTE

For registers having saved data, the * symbol is displayed to the right of their softkey label. If you specify one of them, it is overwritten.

Recalling instrument state for each channel

- Step 1.** Press **Channel Next** or **Channel Prev** to activate a channel whose state you want to recall and restore.
- Step 2.** Press **Save/Recall**.
- Step 3.** Press **Recall Channel**.
- Step 4.** Press the softkey of the register in which the state you want to restore is saved. The instrument state for the channel is recalled to the active channel.

Deleting the saved instrument states (clearing all the registers)

- Step 1.** Press **Save/Recall**.
- Step 2.** Press **Save Channel**.
- Step 3.** Press **Clear States**. The contents of all the registers are deleted.

Saving Trace Data to a File

The E5070A/E5071A allows the user to save data for the active trace on the active channel as a CSV file (file extension *.csv) and load the data into PC application software for further processing.

Trace data will be saved in the format shown below.

Example 9-1

Example of Saved Trace Data

```
"# Channel 1"
"# Trace 1"
Frequency,          Formatted Data,      Formatted Data
+3.00000000000E+005, +1.41837599227E-002, +1.43446459328E-006
+4.27985000000E+007, +1.41275293412E-002, +2.02407834551E-004
+8.52970000000E+007, +1.41334093048E-002, +4.00643331604E-004
+1.27795500000E+008, +1.41240661092E-002, +6.09250514670E-004
+1.70294000000E+008, +1.41402155348E-002, +8.05620003993E-004
```

The first line shows the number of the active channel at the time the data was saved.

The second line shows the number of the active trace at the time the data was saved.

The third line is a header line indicating the contents of each trace data written on the fourth line onward.

The fourth line onward show the trace data. The amount of data is determined by the number of points (frequency) assigned to the trace.

Saving Trace Data

Follow the procedure below to save trace data from the E5070A/E5071A.

- Step 1.** Press or to select the channel that contains the trace to be saved.
- Step 2.** Press or to select the trace to be saved.
- Step 3.** Press to open the Save/Recall menu.
- Step 4.** Press **Save Trace Data** to open the Save As dialog box. When the dialog box appears, use the external keyboard and mouse to complete the task. For more information on the Save As dialog box, see Figure 9-1, “Save As Dialog Box,” on page 198. Note that “CSV Files (*.csv)” will already be selected as the file type when the dialog box first opens.
- Step 5.** Select the destination folder and input a file name. Press **Save** to save the file.

NOTE

Do not press the disk eject button while the floppy disk access lamp is on. Trying to forcefully pull the floppy disk out while the lamp is on may damage the floppy disk or disk drive.

Saving the Screen Image to a File

Along with printing, the E5070A/E5071A allows the user to save screen images as bitmap (.bmp) or portable network graphics (.png) files. Saved files can be loaded into PC application software for further processing.

Saving the Screen Image to a File

Follow the procedure below to save a screen image to a file.

Step 1. Display the screen to be saved as a file.

NOTE If you want to save the screen with white background, set the display mode to inverted display before you save the screen. For details about display mode, see “Selecting display mode” on page 75.

Step 2. Press **System** to display the System menu. Use the softkey listed below.

Softkey	Function
Dump Screen Image	Saves the screen image to a file.

NOTE The screen image at the time **System**^{Capture} is pressed is the image that will be saved. For details, see “Printed/saved screen image” on page 206.

Step 3. Press **Dump Screen Image** to open the Save As dialog box. For more information on the Save As dialog box, see the descriptions associated with Figure 9-1, “Save As Dialog Box,” on page 198. Note that “Bitmap Files (*.bmp)” or “Portable Network Graphics (*.png)” is selected as the file type when the dialog box first opens.

Step 4. Select the file type.


Step 5. Select the destination folder and type a file name. Press **Save** to save the screen image of E5070A/E5071A to a file.

Organizing Files and Folders

You can organize files and folders (copy, move, delete, rename, or format a floppy disk) with Windows® Explorer®.

Figure 9-3

Windows Explorer



NOTE

Do not modify any files and folders in drives other than drive A: and drive D:. Doing so will cause malfunctions.

To open Windows Explorer

Step 1. Press **Save/Recall**.

Step 2. Press **Explorer...**

To copy a file or folder

Step 1. Select a source file or folder on the Windows Explorer.

Step 2. Select **Edit - Copy** from the menu bar.

Step 3. Open the destination folder.

Step 4. Select **Edit - Paste** from the menu bar.

To move a file or folder

- Step 1.** Select a source file or folder on the Windows Explorer.
- Step 2.** Select **Edit - Cut** from the menu bar.
- Step 3.** Open the destination folder.
- Step 4.** Select **Edit - Paste** from the menu bar.

To delete a file or folder

- Step 1.** Select a file or folder you want to delete on the Windows Explorer.
- Step 2.** Select **Edit - Delete** from the menu bar.

To rename a file or folder

- Step 1.** Select a file or folder you want to rename on the Windows Explorer.
- Step 2.** Select **File - Rename** from the menu bar.
- Step 3.** Type the new name of the file or folder, and then press .

To format a floppy disk

NOTE All files and folders in the floppy disk are erased by formatting.

- Step 1.** Put a floppy disk into the floppy disk drive that you want to format.
- Step 2.** Use the right mouse button to click the A drive in the Windows Explorer.
- Step 3.** Click **Format...** in the shortcut menu.
- Step 4.** Follow the instructions in the dialog box to format the floppy disk.

Using a Printer to Output the Screen Image

By connecting the printer to the printer parallel port or the USB port of the E5070A/E5071A, you can print the screen information of the E5070A/E5071A.

NOTE

When you want to use the printer by connecting it to the USB port, you need to register the printer first. For more information, refer to “Registering the printer” on page 210.

Available printers (supported printers)

Table 9-2 shows the models of the available printers (supported printers) for the E5070A/E5071A, the printer drivers you need to use, and the available ports of the E5070A/E5071A as of April 2002.

For the latest information of the supported printers for the E5070A/E5071A, contact Agilent Technologies. When contacting us, see the list of our customer centers at the end of this manual.

Table 9-2 Supported printers (as of April 2002)



Manufacturer	Model name	Printer driver you need to use ^{*1}	Available port
Hewlett-Packard	DeskJet 930C	HP Deskjet 930C	Printer parallel port and USB port
Hewlett-Packard	DeskJet 940C	HP Deskjet 940C	Printer parallel port and USB port
Hewlett-Packard	DeskJet 948C	HP Deskjet 948C	Printer parallel port and USB port

*1. The drivers for all supported printers at the time of shipment are installed in the E5070A/E5071A. If you use a printer newly supported after purchasing the product, you need to install the printer driver for the printer in the E5070A/E5071A. For more information on installation, refer to “Installing printer driver” on page 213.

Printed/saved screen image

The screen image memorized in the volatile memory (clipboard) is printed/saved. Notice that, if no image is memorized in the clipboard, the screen image at the execution is printed/saved.

Memorizing the screen image to the clipboard

 captures the screen, i.e., the screen image at the time  is pressed is memorized to the clipboard.


Printing the screen image

Follow the procedure below to print the screen image.

- Step 1.** Connect a printer to the parallel port of E5070A/E5071A or USB port while the E5070A/E5071A is on. Turn on the printer.

NOTE

Do not connect printers other than those supported by the E5070A/E5071A. An incorrect connection may cause the Add New Hardware wizard to be displayed on the screen. If this happens, terminate the Add New Hardware wizard by clicking the **Cancel** button.


- Step 2.** Display the window to be printed.
- Step 3.** Press  to open the System menu. Use the softkeys displayed to complete the printing.

Softkey	Function
Print	Starts printing.
Abort Printing	Aborts printing.
Printer Setup	Allows the user to select and set up a printer.
Invert Image	Allows the user to print either with colors closest to the screen display [OFF] or with inverted colors [ON].

- Step 4.** Press **Printer Setup** to open the Print dialog box as shown in Figure 9-4. When the dialog box appears, use the external keyboard and mouse to complete the printing.

Figure 9-4

Print Setup Dialog Box



- Step 5.** Select the destination printer in the **Name** box in the **Printer** area.

NOTE

The user may select the pre-installed printer or another printer that corresponds to a new printer driver installed according to “Installing printer driver” on page 213.


Data Output
Using a Printer to Output the Screen Image

Step 6. Follow the instructions below to set up the printer.

Table 9-3 Using the Print Setup Dialog Box

Setup Item	Operation
Paper setup	Select the paper size in the Paper Settings area. Also select the orientation of the paper in the Orientation area.
Printer properties setup	For setting printer properties other than the paper setup, click Properties in the Printer area to open a dialog box. Make the necessary changes in the dialog box (Figure 9-5 shows the dialog box for the HP DeskJet 930C printer driver).

Figure 9-5 HP DeskJet 930C Series Dialog Box



Step 7. Press **Invert Image** to print either in colors closest to the screen display [OFF] or in inverted colors [ON], as necessary.

Step 8. Press **Print** to start printing. To cancel the printing in progress, press **Abort Printing**.

NOTE

Issuing the Print instruction when the printer is not ready (e.g., the power is not on) may result in displaying the Printers Folder dialog box shown in Figure 9-6. If this happens, first close the Printers Folder dialog box by clicking **Cancel**, ready the printer, and then restart the printing.

Figure 9-6**Printers Folder Dialog Box**

Registering the printer

From the Print dialog box (refer to Figure 9-10 on page 212), you can select from the registered printers only. Therefore, when you use the printer for the first time, you need to register the printer first. When you use a printer supported at the time of shipment with the parallel port, it is already registered at the factory and therefore you need not to register it yourself.

NOTE

In the case of the USB port, the ID of the printer is also registered. Therefore, when you use a printer different from one used for the registration, even if it is of the same model, you need to register the printer again. When using the parallel port, you need not to register the printer again as long as you use a printer of the same model.

The registration procedure is as follows:

NOTE


You need the mouse and the keyboard for this operation.

Step 1. Restart the E5070A/E5071A in the service mode

- i. Press **System**.
- ii. Press **Service Menu - Restart Menu**. The Password dialog box (Figure 9-7) opens.

Figure 9-7

Password dialog box.




e5070auj136

- iii. Enter the password **e507xa** in the **Password** box and click the **OK** button.
- iv. Press **Restart as Service**. The instrument is restarted and the Windows screen appears.

Step 2. Connect the printer

Turn on the printer and connect it to the E5070A/E5071A.


- Step 3.** Move the mouse pointer to the lower left part of the screen of the E5070A/E5071A and click **Start - Settings - Printers** (see the below figure) to open the Printers window.



e5070auj173

- Step 4.** Double-click the Add Printer icon in the Printers window to start Add Printer Wizard.

- Step 5.** On the first screen of Add Printer Wizard, click **Next**. When the screen shown in the below figure, check that "Local printer" is selected and click **Next**.



e5070auj176


- Step 6.** The screen to select the manufacturer and model name of the printer appears. Select the manufacturer (1 in Figure 9-8) and the model name (2 in Figure 9-8) and then click **Next**.

CAUTION

Do not select other than supported printers because doing so may give serious damage to the E5070A/E5071A.


Figure 9-8

Selecting manufacturer and model name (example for Hewlett Packard Deskjet 930C)



e5070auj177

- Step 7.** If the screen that asks you whether you want to keep the existing printer driver, select "Keep existing driver[recommended]" as shown below and click **Next**.




e5070auj178

Data Output

Using a Printer to Output the Screen Image


Step 8. The screen to select the connection port appears. Select the port to which you connect the printer (LPT1 or USB...) and click **Next**.

Figure 9-9 Selecting connection port (when selecting the USB port)



Step 9. The screen to enter the printer name appears. Enter the printer name (1 in Figure 9-10), select whether to set it to the default printer (2 in Figure 9-10), and click **Finish**. Use the printer name you have specified here when selecting the printer in the Print dialog box (see Figure 9-10 on page 212).

Figure 9-10 Entering printer name



Step 10. Restart the E5070A/E5071A in the instrument mode

Double-click the Restart as Inst icon on the desktop (see Figure 9-11). The confirmation message appears. Click **OK**. The E5070A/E5071A is restarted and starts up as the instrument.

Figure 9-11 Restart as Inst icon



Installing printer driver

If you use a printer newly supported after purchasing the product, you need to install the printer driver for the printer in the E5070A/E5071A.

Installation procedure

NOTE

You need the mouse and the keyboard for this operation.

Step 1. Prepare the printer driver

i. Obtaining the printer driver

Obtain the printer driver for the E5070A/E5071A specific to the printer you want to use.

Generally, you can download the printer driver from our product information web site of the Agilent Technologies E5070A/E5071A.

For how to obtain the printer driver, contact Agilent Technologies. To contact us, see the list of our customer centers at the end of this manual or Online assistance homepage (<http://www.agilent.com/find/assist>).

CAUTION

Installing a printer driver other than specified by Agilent Technologies may give serious damage to the E5070A/E5071A.

- Never install the printer driver for printers that Agilent Technologies does not support.
- Except when instructed from Agilent Technologies, never install general printer drivers that printer manufactures provide. When installing a general printer driver according to the instruction from Agilent Technologies, be sure to install the driver of the specified revision.

ii. Copy the printer driver you obtained onto a disk

When installing the printer driver from a floppy disk, copy the printer driver file you obtained in a 3.5-inch floppy disk.

When installing the printer driver from the hard disk drive (D drive), network (mount) the D drive of the E5070A/E5071A from the external computer and then, from the external computer, copy the printer driver file you obtained in the D drive of the E5070A/E5071A. For information on how to network the D drive, refer to “Accessing to hard disk of the E5070A/E5071A from an external PC via LAN” on page 258.

Data Output
Using a Printer to Output the Screen Image

Step 2. Restart the E5070A/E5071A in the service mode

- i. Press **System**.
- ii. Press **Service Menu - Restart Menu**.
- iii. Enter the password **e507xa** in the **Password** box of the Password dialog box (Figure 9-7) and click the **OK** button.
- iv. Press **Restart as Service**. The instrument is restarted and the Windows screen appears.

Step 3. Connect the printer

Turn on the printer and connect it to the E5070A/E5071A.

NOTE

At this time, the Add New Hardware Wizard may appear. In this case, click **Cancel** to finish the Add New Hardware Wizard.

Step 4. Install the printer driver

Install the printer driver following the attached procedure document.

Step 5. Restart the E5070A/E5071A in the instrument mode

Double-click the Restart as Inst icon on the desktop (see Figure 9-11). The confirmation message appears. Click **OK**. The E5070A/E5071A is restarted and starts up as the instrument.

10 **Limit Test**

This chapter describes the concepts behind the limit test and how to perform it using the Agilent E5070/E5071A.

Limit Test

The limit test function enables you to define a limit line for each trace and evaluate measurement data on a pass/fail basis.

Concept

What is a Limit Value?

The Limit Value for the frequency of each point (Stimulus) is determined by using Equation 10-1. The line connecting the limit values will be displayed on the screen as the limit line.

Equation 10-1

Limit Value


$$LimitValue = BeginResponse + \frac{Stimulus - BeginStimulus}{EndStimulus - BeginStimulus} \times (EndResponse - BeginResponse)$$

To calculate the above equation, the Begin Stimulus and Begin Response, and the End Stimulus and End Response are specified in the limit table.

The concept of the limit line is described in Figure 10-1 below.

Figure 10-1

Concept of a Segment



e5070aue065

Determine whether or not to use the limit line as the minimum (MIN) or as the maximum (MAX) in the pass/fail evaluation for the limit test. You can also define a segment not to be used in the limit test by setting the type to OFF in the same way as segment 5 in Figure 10-1 is set to OFF.

NOTE

You can define a limit line that is able to freely overlap with the frequency of another limit line.

Defining one limit line having the same type as a second limit line whose frequency overlaps with the first one results in two or more limit values at the same frequency point. In this case, the limit value to be used in the limit test is defined as follows:

- When two or more limit values whose type is set to maximum (MAX) exist, the smallest one is used as the maximum.
 - When two or more limit values whose type is set to minimum (MIN) exist, the largest one is used as the minimum.
-

Display of the Limit Test Evaluation Result


During execution of the limit test, the magnitude of the measurement value and limit value are compared with one another at all points in the limit line frequency range. Based on whether points outside the limit value exist or not, the result of the evaluation on a Pass/Fail basis is displayed on the screen.

Examples of the evaluation result are shown below.

Example 10-1

Acceptable Measurement Result


If all measurement values are within the limit value, as shown below, “Pass” is displayed on the screen.



e5070aue066

Example 10-2 Unacceptable Measurement Result

Even if only a few measurement values are outside the limit value, as shown below, “Fail” is displayed on the screen. In this case, the points whose measurement values are outside the limit value are displayed in red.



e5070aue067

Defining the Limit Line

To use the limit test, you must first define the limit line. You can define a limit table for each trace, and you can define up to 100 limit lines (segments) in a limit table.

Defining a Segment

The following steps describe how to define a segment.

- Step 1.** Press **Channel Next** or **Channel Prev** to activate the channel on which the limit test function will be used.
- Step 2.** Press **Trace Next** or **Trace Prev** to activate the trace on which the limit test function will be used.
- Step 3.** Press **Analysis** to display the Analysis menu.
- Step 4.** Press **Limit Test** to display the softkeys associated with the limit test.
- Step 5.** Press **Edit Limit Line** to display the limit table shown in Figure 10-2. Using the limit table, create/edit a segment. Initially, no segments are entered in the limit table.

Figure 10-2

Limit Table

The screenshot shows a table with 6 rows and 6 columns. Labels with arrows point to specific parts of the table:

- Segment number:** Points to the first column (row 1).
- Type of limit line:** Points to the second column (row 1).
- Beginning point of stimulus value:** Points to the third column (row 1).
- End point of stimulus value:** Points to the fourth column (row 1).
- Beginning point of response value:** Points to the fifth column (row 1).
- End point of response value:** Points to the sixth column (row 1).

Segment number	Type of limit line	Beginning point of stimulus value	End point of stimulus value	Beginning point of response value	End point of response value
1	MAX	1.000000000 MHz	3.000000000 MHz	-10 dB	-20 dB
2	MAX	4.000000000 MHz	5.000000000 MHz	-30 dB	-30 dB
3	MIN	4.000000000 MHz	5.000000000 MHz	-50 dB	-50 dB
4	MAX	6.000000000 MHz	8.000000000 MHz	-20 dB	-10 dB
5	OFF	8.000000000 MHz	10.000000000 MHz	-10 dB	-10 dB
6					

e5070aue064

At the same time, the Edit Limit Line menu used to create/edit the limit table is displayed. The following lists the functions that correspond to the softkeys shown.

Softkey	Function
Delete	Deletes the segment containing the selected cell from the limit table.
Add	Adds a segment before the segment containing the selected cell to the limit table.
Clear Limit Table	Clears all the limit table data.
Export to CSV File	Exports the limit table to a file in CSV (comma-separated value) format. For more information, see “Saving/Calling the Limit Table” on page 223.
Import from CSV File	Imports a limit table saved in CSV (separated-separated value) format. For more information, see “Saving/Calling the Limit Table” on page 223.
Return	Exits the Edit Limit Line menu and closes the limit table display.

Step 6. Press **Add** to add a segment to the limit table, and then specify the segment parameter values shown below.

Segment Parameter	Description						
Type	Select the type of segment from the following: <table style="width: 100%; border: none;"> <tr> <td style="width: 10%;">OFF</td> <td>Segment not used for the limit test</td> </tr> <tr> <td>MIN</td> <td>The segment at which the minimum is specified</td> </tr> <tr> <td>MAX</td> <td>The segment at which the maximum is specified</td> </tr> </table>	OFF	Segment not used for the limit test	MIN	The segment at which the minimum is specified	MAX	The segment at which the maximum is specified
OFF	Segment not used for the limit test						
MIN	The segment at which the minimum is specified						
MAX	The segment at which the maximum is specified						
Begin Stimulus ^{*1*2}	Specify the starting point for the stimulus value (frequency) on the limit line.						
End Stimulus ^{*1*2}	Specify the ending point for the stimulus value (frequency) on the limit line.						
Begin Response ^{*3*4}	Specify the starting point for the response value on the limit line.						
End Response ^{*3*4}	Specify the ending point for the response value on the limit line.						

*1. The range in which stimulus values can be specified; the resolution is the same as the frequency range and resolution set for the E5070/E5071A. When a value outside the specification is entered, a suitable value that meets the specification is specified.
*2. Once the stimulus value is specified, changing the frequency range of the E5070/E5071A does not affect the stimulus value.

Limit Test

Limit Test

- *3. The range in which stimulus values can be specified is from -500 MHz to +500 MHz.
When a value outside the range is entered, a suitable value within the range is specified.
- *4. After the response value is specified, changing formats results in changing the units but not the value.

NOTE

When the frequency is set at zero span, the limit test is performed with reference to the frequency, not to the time. Even if the frequency on the E5070/E5071A is set at zero span, enter the two parameters, Begin Stimulus and End Stimulus.

NOTE

When two or more response values are returned as a result of using the Smith or polar chart format, the first response value of the marker provides the object of the limit test.

Saving/Calling the Limit Table

You can save the limit table to a file, which you can then freely bring up on the screen later and use. You can import a file saved in CSV format (extension: *.csv) into spreadsheet software on a PC for later use. (A numerical value will be saved as strings including its unit).

The limit table is saved in the following format.

Example 10-3

Limit Table Saved in CSV Format

```
"# Channel 1"  
"# Trace 1"  
Type, Begin Stimulus, End Stimulus, Begin Response, End Response  
MAX, 200.0000000 MHz, 400.0000000 MHz, -100 dB, -100 dB  
MAX, 490.0000000 MHz, 510.0000000 MHz, -10 dB, -10 dB  
MIN, 490.0000000 MHz, 510.0000000 MHz, -20 dB, -20 dB  
MIN, 600.0000000 MHz, 800.0000000 MHz, -100 dB, -100 dB
```

On the first line, the channel number of the active channel that was valid when the file was saved is output.

On the second line, the trace number of the active trace that was valid when the file was saved is output.

The third line provides the header showing the items for the segments to be output on the fourth and later lines.

Data on segments are output on the fourth and later lines.

Saving/Calling the Limit Table

The following steps describe how to save/call the limit table. Use the external keyboard and mouse for the operations described below.

- Step 1.** Display the limit table.
- Step 2.** In the Edit Limit Line menu, press **Export to CSV File** to open the Save As dialog box. For more information on the Save As dialog box, refer to the description provided in Figure 9-1, "Save As Dialog Box," on page 198. In this step, CSV Files (extension: *.csv) are selected as the file type.
- Step 3.** Specify the folder in which to save the file, and enter the file name. Press **Save** to save the limit table displayed on the screen to the file.
- Step 4.** Conversely, to recall a saved limit table, press **Import from CSV File** in the Edit Limit Line menu to display the Open dialog box. For a description of parts of the Open dialog box, see Figure 9-2, "Open Dialog Box," on page 199. In this step, CSV Files (extension: *.csv) are selected as the file type.
- Step 5.** After specifying the folder containing the file, select the file. Press **Open** to display the limit table on the screen.

NOTE

You can recall a limit table from a trace on any channel independently of the channel and trace that were active when the limit table was saved to the file.

Limit Test

Limit Test

Turning the Limit Test ON/OFF

You can set the limit test ON/OFF for each trace individually.

Setting the Limit Test ON/OFF

The following steps describe how to set the limit test ON/OFF.

- Step 1.** Press **Channel Next** or **Channel Prev** to activate the channel on which the limit test function will be used.
- Step 2.** Press **Trace Next** or **Trace Prev** to activate the trace on which the limit test function will be used.
- Step 3.** Press **Analysis** to display the Analysis menu.
- Step 4.** Press **Limit Test** to display the Limit Test menu.

Softkey	Function
Limit Test	Sets the limit test ON/OFF.
Limit Line	Sets the limit line display ON/OFF.
Edit Limit Line	Opens the limit table for editing the limit line.*1

*1. To use the limit test function, you must first define the limit line. For more on how to define the limit line, see “Defining the Limit Line” on page 220.

- Step 5.** Press **Limit Test** to turn the limit test ON. To display the limit line on the screen, press **Limit Line**.

Initializing the Limit Table

The following operations initialize the limit table.

- At power-on
- When presetting
- When calling a limit table with zero segments
- When **Clear Limit Table - OK** is pressed in the Edit Limit Line menu

Outputting the Test Result

The test result is displayed on the screen as a pass or fail. At the same time, the following methods are ways you can learn whether or not the limit test failed.

- A point that is outside the limit line (that failed the limit test) is displayed in red on the screen.
- You can make a beep sound.
- The result is provided in the register. (For more information, refer to the Programmer’s Guide.)
- Turning **ON** the **Analysis** - **Limit Test - Fail Sign** in the Limit Test menu will bring up a

sign as shown in Figure 10-3 in the case of a failure in the test.

Figure 10-3 Fail Sign Display



Limit Test
Limit Test

11 Optimizing Measurements

This chapter describes how to optimize your measurements when using the Agilent E5070A/E5071A.

Expanding the Dynamic Range

The dynamic range is the finite difference between the maximum input power level and the minimum measurement power level (noise floor) of the analyzer. In evaluating a characteristic accompanied by a large change in the amplitude (the pass band and stop band of a filter, for example), it is important to increase the dynamic range.

Lowering the Receiver Noise Floor

Lowering the noise floor of the receiver enables you to enlarge the dynamic range. The following methods can be used to lower the receiver noise floor.


- “Narrowing the IF Bandwidth” on page 228
- “Turning on Sweep Averaging” on page 229

Narrowing the IF Bandwidth

Narrowing the receiver IF bandwidth enables you to reduce the effect of random noise on measurements. Narrowing the IF bandwidth to 1/10 the original bandwidth causes the receiver noise floor to decrease by 10 dB.

Figure 11-1

Effects of Narrowing the IF Bandwidth



To specify the IF bandwidth, follow the steps described below.

- Step 1.** Press **Channel Next** or **Channel Prev** to select a channel on which to specify the IF bandwidth.
- Step 2.** Press **Avg**.
- Step 3.** Press **IF Bandwidth**.
- Step 4.** Change the IF bandwidth in the data entry area.

Turning on Sweep Averaging

Using sweep averaging also enables you to reduce the effects of random noise on measurements.

Sweep averaging averages data from each point (vector quantity) based on the exponential average of a continuous sweep weighted by the averaging factor specified by the user. Sweep averaging is expressed in Equation 11-1.

Equation 11-1**Sweep Averaging**


$$A_n = \frac{S_n}{F} + \left(1 - \frac{1}{F}\right) \times A_{n-1}$$

where:

An = Result of the calculation of sweep averaging for the nth sweep operation at the point in question (a vector quantity).

Sn = Measurement value obtained at the nth sweep operation at the point in question (a vector quantity).

F = Sweep averaging factor (an integer between 1 and 999)

Figure 11-2**Effects of Sweep Averaging**

Define the sweep averaging by following the steps below.

- Step 1.** Press **Channel Next** or **Channel Prev** to select a channel on which the sweep averaging will be defined.
- Step 2.** Press **Avg**.
- Step 3.** Press **Avg Factor**.
- Step 4.** Change the averaging factor in the data entry area.
- Step 5.** Press **Averaging** to turn **ON** the averaging.

NOTE

Pressing **Averaging Restart** resets n to 1 in Equation 11-1 on page 229.

Reducing Trace Noise

Any of the following methods can be used to lower the trace noise.

- Turning on sweep averaging
- Turning on smoothing
- Narrowing the IF bandwidth


For more about sweep averaging and the IF bandwidth, see “Turning on Sweep Averaging” on page 229 and “Narrowing the IF Bandwidth” on page 228.

Turning on Smoothing

Smoothing can be used to reduce noise having relatively small peaks. By turning on smoothing, the value of each point on a trace is represented by the moving average over the values of several nearby points. The smoothing aperture (percentage of sweep span) defines the range of points to be included in the calculation of the moving average.

NOTE You can define the smoothing trace by trace.


Figure 11-3 Effects of Smoothing (Log Magnitude Format)



e5070auj107

Figure 11-4

Effects of Smoothing (Group Delay Format)



Setting Up Smoothing

Setup the smoothing operation by following the steps below.

- Step 1.** Press **Channel Next** (or **Channel Prev**) and **Trace Next** (or **Trace Prev**) to activate the trace on which smoothing will be defined.
- Step 2.** Press **Avg**.
- Step 3.** Press **Smo Aperture**.
- Step 4.** Change the smoothing aperture (%) in the data entry area.
- Step 5.** Press **Smoothing** to turn **ON** the smoothing.

Improving the Accuracy of Phase Measurements

This section describes the following functions that can be used to improve phase measurement accuracy.

- “Electrical Delay” on page 232
- “Port Extension” on page 232
- “Phase Offset” on page 233

Electrical Delay

Electrical Delay is a function that adds or removes a pseudo-lossless transmission line with a variable length against the receiver input. Using this function enables you to improve the resolution in phase measurement and thereby measure deviation from the linear phase. You can specify the electrical delay trace by trace.

Using the Electrical Delay Function

- Step 1.** Press **Channel Next** (or **Channel Prev**) and **Trace Next** (or **Trace Prev**) to activate the phase trace for which the electrical delay will be specified.
- Step 2.** Press **Scale**.
- Step 3.** Press **Electrical Delay**.
- Step 4.** Change the electrical delay (in seconds) in the data entry area.

For how to determine the deviation from a linear phase, see “Measuring the Deviation from a Linear Phase” on page 302.

Port Extension

Port Extension is a function for moving the calibration reference plane by specifying the electrical delay. This function is useful, for example, when you cannot perform calibration at the DUT terminal directly because the DUT is inside the test fixture. In such a case, this function enables you to first perform calibration at the test fixture terminal and then move the calibration plane to the DUT terminal by extending the port.

Port extension corrects the electrical delay of each test port (phase shift) only. It cannot remove errors caused by the loss in and wrong matching of cables, adapters, or test fixtures.

NOTE

You can define port extension channel by channel. Even if you set port extension for a channel, it does not affect to the other channels.

Using the Port Extension Function

- Step 1.** Press **Channel Next** or **Channel Prev** to activate the channel for which port extension will be specified.
- Step 2.** Press **Cal**.
- Step 3.** Press **Port Extensions**.

Step 4. Specify the port extension for each test port.

Softkey	Function
Extension Port 1	Specify the port extension (in seconds) for test port 1.
Extension Port 2	Specify the port extension (in seconds) for test port 2.
Extension Port 3 *1	Specify the port extension (in seconds) for test port 3.
Extension Port 4 *2	Specify the port extension (in seconds) for test port 4.

*1. Only with Options 313, 314, 413, and 414.

*2. Only with Options 413 and 414.

Phase Offset

Phase Offset is a function used to add or subtract a predetermined value relative to the frequency to and from the trace. Using this function enables you to simulate the phase offset occurring as a result of, say, adding a cable.

The phase offset can be specified from -360° to $+360^\circ$.

Using the Phase Offset Function

- Step 1.** Press **Channel Next** (or **Channel Prev**) and **Trace Next** (or **Trace Prev**) to activate the trace for which the phase offset will be specified.
- Step 2.** Press **Scale**.
- Step 3.** Press **Phase Offset**.
- Step 4.** Enter the phase offset ($^\circ$) in the data entry area.

Specifying the Velocity Factor

The velocity factor is the ratio of the propagation velocity of a signal in a coaxial cable to the propagation velocity of that signal in free space. The velocity factor for a common cable is about 0.66. The propagation velocity depends on the dielectric constant (ϵ_r) of the dielectric substance in the cable.

$$\text{Velocity factor} = \frac{1}{\sqrt{\epsilon_r}}$$

By specifying the velocity factor, you can match the equivalent length (in meters) appearing in the data entry area to the actual physical length when using the “Electrical Delay” on page 232 or “Port Extension” on page 232 to specify the electrical delay (in seconds).

The velocity factor is common to all channels.

Using the Velocity Factor

- Step 1.** Press **Cal**.
- Step 2.** Press **Velocity Factor**.
- Step 3.** Enter the velocity factor in the data entry area.

Reduce Measurement Error in High Temperature Environments

The E5070A/E5071A is designed to obtain the best measurement accuracy at the ambient temperature range of $23^{\circ}\text{C} \pm 5^{\circ}\text{C}$. The high temperature measurement mode of the E5070A/E5071A reduces measurement error (drift error) at an ambient temperature of 28°C to 33°C .

NOTE

The high temperature measurement mode must be turned off when the analyzer is used at an ambient temperature below 28°C . Otherwise, the measurement accuracy may be degraded.

Procedure

- Step 1.** Press **System**.
- Step 2.** Press **Service Menu**.
- Step 3.** Press **High Temperature** to turn **ON/OFF** the high temperature measurement mode.

Improving the Measurement Throughput

This section explains the following two methods to improve the measurement throughput.


- “Using Fast Sweep Modes” on page 235
- “Turning Off the Updating of Information Displayed on the LCD Screen” on page 236

Using Fast Sweep Modes

There are 4 sweep modes. "Stepped mode" and "swept mode." And, "fast stepped mode" and "fast swept mode" that are the speeded-up versions of them realized by shortening wait time during sweep and so on.

Figure 11-5

Sweep Mode



Operational procedure

- Step 1.** Press **Sweep Setup**.
- Step 2.** Press **Sweep Mode**.
- Step 3.** Press the softkey corresponding to a proper sweep mode.

Softkey	Function
Std Stepped	Selects the stepped mode.
Std Swept	Selects the swept mode.
Fast Stepped	Selects the fast stepped mode.
Fast Swept	Selects the fast swept mode.

Turning Off the Updating of Information Displayed on the LCD Screen

Turning off the updating of information displayed on the LCD screen causes the processing time required to update displays within the analyzer to be omitted, improving measurement throughput. If it is not necessary to check displayed information during measurements, turning off real-time updating is an effective means of improving throughput.

The updating of information displayed on the LCD screen can be switched using the following procedure:

Turning Off the Updating of Information

- Step 1.** Press **Display**.
- Step 2.** Press **Update** to switch the updating of displayed information on the LCD screen on/off.

When the LCD screen update is turned off, **Update Off** appears on “4. Instrument Status Bar” on page 38.

Turning Off System Error Correction

The E5070A/E5071A executes “IF Range Correction” on page 457 and “Port Characteristics Correction” on page 457 in the data processing flow shown in Figure E-2, “Data Processing Flowchart,” on page 456 by using the system calibration data set at the factory. This system error correction process is not required if the user performs proper calibration by using the **Cal** and subsequently appearing softkeys, which automatically turns on error correction.

By turning off system error correction, you can reduce the data processing time during measurement and thus improve measurement throughput.


NOTE When you turn ON/OFF system error correction, all calibration data set by user calibration is deleted.

Procedure

- Step 1.** Press **System**.
- Step 2.** Press **Service Menu**.
- Step 3.** Press **System Correction**. Figure 11-6 appears.

Figure 11-6

Dialog Box for System Error Correction Change



e5070auj162

- Step 4.** Press **OK** to turn ON/OFF system error correction.

Performing a Segment-by-Segment Sweep (Segment Sweep)

This section describes the concept of the segment sweep and how to perform it.

Concept of the Segment Sweep


To perform a segment sweep, you must define two or more frequency ranges called segments, and then specify the number of points, IF bandwidth, power level, sweep mode, sweep delay time, and sweep time for each segment. All segments are swept sequentially as if swept in one sweep operation.

- By skipping the frequency range, which does not need to be measured, you can sweep and measure only the portions you need.
- You can define the optimum measurement conditions for each of the segments you designate. For example, you can specify as many points as possible in a segment requiring high trace resolution and as few points as possible in a segment not requiring high resolution. This shortens the measurement time, enabling you to enhance the overall measurement throughput without the entire measurement operation being drawn into the measurement conditions at a particular frequency range.

To evaluate a bandpass filter having the transmission characteristics shown in Figure 11-7, for example, you can select the frequency ranges you need from A through G and determine the measurement conditions shown in the Table . This enables you to measure them simultaneously in one sweep operation.

Figure 11-7

Characteristics of a DUT on which a Segment Sweep Will be Performed



e5070aue097

Table 11-1

Frequency Ranges (Segments) From Figure 11-7 and Their Measurement Conditions

	Start Frequency	Stop Frequency	Number of Points	IF Bandwidth	Sweep Mode
A	440 MHz	915 MHz	50	50 kHz	Stepped
B	915 MHz	980 MHz	130	70 kHz	Fast Stepped
C	980 MHz	1.035 GHz	60	50 kHz	Stepped
E	1.07 GHz	2 GHz	100	70 kHz	Fast Swept
G	2.6 GHz	3 GHz	40	70 kHz	Fast Swept

Conditions for Setting Up a Segment Sweep

The following conditions apply when setting up a segment sweep.

- The frequency range of a segment must not overlap with that of another segment. (The start frequency of a segment must be higher than the stop frequency of the immediately preceding segment.)
- The start frequency of segment 1 must be greater than 300 kHz and the stop frequency of the last segment less than 3 GHz (E5070A) or 8.5 GHz (E5071A).
- When the start frequency and stop frequency of a segment are not the same, you can define from 2 to 1601 points in a segment.
- When the start frequency and stop frequency of a segment are the same, you can define from 1 to 1601 points in a segment.
- You can set the total number of points in the segment table from 2 to 1601.
- You can set the number of points in the segment table to between 1 and 201.

Items that can be set for each segment

For the segment sweep, you can set the sweep range, the number of points, IF bandwidth, power level, sweep delay time, sweep mode, and sweep time for each segment.


You can set the items in the following table to ON/OFF for each segment. If you enable the segment-by-segment setting, you can make the setting for each segment in the segment table; if you disable it, the setting in the following table is used.

Item	When segment-by-segment setting is disabled
IF bandwidth	For all the segments, the IF bandwidth for the linear/log sweep (set with <input type="text" value="Avg"/> - IF Bandwidth) is set.
Power level	For all the segments, the power level for the linear/log sweep (set with <input type="text" value="Sweep Setup"/> - Power) is set.
Sweep delay time	For all the segments, 0 is set.
Sweep mode	For all the segments, the sweep mode for the linear/log sweep (set with <input type="text" value="Sweep Setup"/> - Sweep Mode) is set.
Sweep time	For all the segments, the auto sweep time mode is set.

Sweep Delay Time and Sweep Time in a Segment Sweep

The definitions for both sweep delay time and sweep time, which you can specify in the segment sweep, are shown in Figure 11-8.

Figure 11-8 Sweep delay time and sweep time in segment sweep




e5070aue098

Frequency Base Display and Order Base Display

You can choose between frequency base and order base as the method of displaying traces when executing the segment sweep.


Figure 11-9 Concept of Segment Display



e5070aue105

Optimizing Measurements
Performing a Segment-by-Segment Sweep (Segment Sweep)

Figure 11-10 Comparing Methods of Displaying Segments



e5070aue103

Performing a Segment-by-Segment Sweep (Segment Sweep)

Procedure

Creating a Segment Table

Step 1. Press **Channel Next** or **Channel Prev** to select the channel for which you want to create the segment table.

Step 2. Press **Sweep Setup**.

Step 3. Press **Edit Segment Table**.

The segment table appears in the lower part of the screen.

Step 4. To change the frequency range setting mode or to set the IF bandwidth, power level, sweep delay time, sweep mode, and sweep time for each segment, use the following softkeys.

NOTE




When setting the segment table using the front panel keys or keyboard, you need to place focus on (select) the operation target (segment table of softkey) first. You can change the focus by pressing **Focus** in the ENTRY block. When the focus is placed on the segment table, the selected cell is enclosed with the thick line box. When the focus is placed on the softkey menu, the softkey menu title area is displayed in blue.

Softkey	Function
Freq Mode	Switches the frequency range setting mode (start/stop or center/span).
List IFBW	Toggles ON/OFF the IF bandwidth setting for each segment. Only when this setting is ON, the row (IFBW) for setting appears in the segment table.
List Power	Toggles ON/OFF the power level setting for each segment. Only when this setting is ON, the row (Power) for setting appears in the segment table.
List Delay	Toggles ON/OFF the sweep delay time setting for each segment. Only when this setting is ON, the row (Delay) for setting appears in the segment table.
List Sweep Mode	Toggles ON/OFF the sweep mode setting for each segment. Only when this setting is ON, the row (Sweep Mode) for setting appears in the segment table.
List Time	Toggles ON/OFF the sweep time setting for each segment. Only when this setting is ON, the row (Time) for setting appears in the segment table.

Step 5. Repeat entering each item in the following table and adding a segment (line) to create the segment table.

Start	Set the start value of the sweep range.
Stop	Set the stop value of the sweep range.
Center	Set the stop value of the sweep range.
Span	Set the span value of the sweep range.
Points	Set the number of points.
IFBW	Set the IF bandwidth.
Power	Set the power level. The power range is common to the setting for the linear/log sweep ([Sweep Setup] - Power Ranges).
Delay	Set the sweep delay time.
Sweep Mode	Set the sweep mode. Select one of the following items. STD STEPPED Stepped mode STD SWEPT Swept mode FAST STEPPED Fast stepped mode FAST SWEPT Fast swept mode
Time	Set the sweep time. To specify the auto setting (AUTO), enter 0 as the sweep time.


To create the segment table, use the following keys.

Hardkey	Function
	If you select a cell and then press this key, you enter into the mode in which you can edit the cell character by character. If you change a value and then press this key, the value is entered into the cell.
	Move up and down in the cell selected in the segment table. In the character-by-character edit mode, you can select an item or perform the step change of data.
	Move right and left in the cell selected in the segment table.

Softkey	Function
Delete	Deletes the line in which the selected cell is included.
Add	Adds a new line above the line in which the selected cell is included.
Clear Segment Table - OK	Resets the segment table. As a result, segment 1 that is initialized remains.

Figure 11-11

Example of creating segment table



Useful functions when using a mouse

By right-clicking on the selected cell, you can use the following shortcut menu.

Shortcut	Function
Copy	Copies the value in the selected cell into the clipboard (internal temporary storage memory).
Paste	Pastes the value data in the clipboard to a newly selected cell.
Insert	Adds a new line above the selected cell.
Delete	Deletes the line in which the selected cell is included.

In the character-by-character edit mode, you can use the following shortcut menu also.

Shortcut	Function
Undo	Undoes the change and restore the value before the change.
Cut	Cuts the selected string and store it into the clipboard (temporary memory).
Copy	Copies the selected string into the clipboard.
Paste	Pastes the string in the clipboard to a newly selected cell.
Delete	Deletes the selected string.
Select All	Selects the entire string in the cell.

Executing Segment Sweep

To execute a segment sweep by using the segment table you have created, you must specify the sweep type for that sweep operation by following the steps described below.

- Step 1.** Press **Channel Next** or **Channel Prev** to select the channel on which you will execute the segment sweep operation.
- Step 2.** Press **Sweep Setup**.
- Step 3.** Press **Sweep Type**.
- Step 4.** Press **Segment**.

Setting Up the Segment Display

Define the method of displaying traces when the segment sweep is executed by following the steps described below.

- Step 1.** Press **Channel Next** or **Channel Prev** to select the channel on which you will define the segment display.
- Step 2.** Press **Sweep Setup**.
- Step 3.** Press **Segment Display**.
- Step 4.** Select segment display.

Softkey	Function
Freq Base	Displays the X-axis as the axis for linear frequencies (frequency base display).
Order Base	Displays the X-axis as the axis for the points (order base display).

Performing a Segment-by-Segment Sweep (Segment Sweep)

Saving a Newly Created Segment Table in CSV Format

As discussed in “Creating a Segment Table” on page 241, you can export the newly created segment table as a CSV (comma-separated value) formatted file (so it can be used easily in software that requires a different format).

- Step 1.** Press **Sweep Setup**.
- Step 2.** Press **Edit Segment Table**.
- Step 3.** Press **Export to CSV File** to open the Save As dialog box. For more information on the Save As dialog box, see Figure 9-1, “Save As Dialog Box,” on page 198. Note that “CSV Files (*.csv)” will already be selected as the file type when the dialog box first opens.
- Step 4.** Type the file name in the **File Name** area, and press **Save** to save the segment table.

Calling a Segment Table Saved in CSV Format

By importing a segment table created following the steps described in “Saving a Newly Created Segment Table in CSV Format” on page 245 (inputting a file in a different software format), you can set up the segment table.

NOTE It is possible to recall a file from a different channel where it was saved.

- Step 1.** Press **Sweep Setup**.
- Step 2.** Press **Edit Segment Table**.
- Step 3.** Press **Import from CSV File** to open the Open dialog box. For more information on the Open dialog box, see Figure 9-2, “Open Dialog Box,” on page 199. Note that “CSV Files (*.csv)” will already be selected as the file type when the dialog box first opens.
- Step 4.** Select the CSV format file to be imported, and press **Open** to call up the segment table.

NOTE You cannot import a CSV-formatted file created/edited in spreadsheet software into the E5070A/E5071A. Furthermore, you cannot import a CSV format file exported following the steps described in “Saving a Newly Created Segment Table in CSV Format” on page 245 if a change has been made to that file.

12 **Setting and Using the Control and Management Functions**

This chapter describes how to set and use the control and management functions not directly linked with measurement or analysis.

Setting the GPIB

This section describes how to set up the interface required to use the GPIB (General Purpose Interface Bus) on the E5070A/E5071A. For more about performing automatic measurements using the GPIB and specific methods of achieving such measurements, see the Programmer's Guide.

To use the E5070A/E5071A in a GPIB system, you must choose whether to use the E5070A/E5071A as a system controller or in talker/listener mode. One system controller can exist in an automatic measurement system and serves to control the entire system. When the instrument is set in talker/listener mode, however, an address specified for the E5070A/E5071A can be used for control by another device. Therefore, depending on which mode is used, you need to set the address in either system controller mode or talker/listener mode.

Setting the GPIB

- Step 1.** Press **System**.
- Step 2.** Press **Misc Setup**.
- Step 3.** Press **GPIB Configuration**.
- Step 4.** Press the corresponding softkey to set the control mode.

Softkey	Function
Talker/Listener	Puts the instrument into talker/listener mode.
System Controller	Puts the instrument into system controller mode.

- Step 5.** Press the corresponding softkey to set the address.

Softkey	Function
Talker/Listener Address	Sets the address in talker/listener mode.
System Controller Address	Sets the address in system controller mode.

- Step 6.** Press the standby switch to shut down the E5070A/E5071A.
- Step 7.** Press the standby switch again to turn on the E5070A/E5071A power.

NOTE The modified control mode and address will not take effect until you shut down the E5070A/E5071A and turn on its power.

Setting the Internal Clock

The E5070A/E5071A has the built-in clock that keeps track of the date and time. This clock is used for the following functions.

- To display the current date and time in the instrument status bar at the lower part of the screen
- To write date and time information when saving internal data or a VBA program


Setting the Date and Time

- Step 1.** Press **System**.
- Step 2.** Press **Misc Setup**.
- Step 3.** Press **Clock Setup**.
- Step 4.** Press **Set Date and Time**.

The dialog box in Figure 12-1 appears.

Figure 12-1

Date/Time Properties Dialog Box (“Date & Time” Tab)



- Step 5.** Set the date in the **Date** area, and set the time in the **Time** area.
- Step 6.** Press the **Time Zone** tab.

The dialog box in Figure 12-2 appears.

Figure 12-2

Date/Time Properties Dialog Box (“Time Zone” Tab)



Step 7. In the drop-down list box select a time zone.

Step 8. To make the summertime setting automatically, check **Automatically adjust clock for daylight saving changes** to assign the check mark (√) to it.

Step 9. Press the **OK** button.

Setting the Date/Time Display ON/OFF

The date/time display in the instrument status bar can be switched on/off using the following procedure.

Step 1. Press **System**.

Step 2. Press **Misc Setup**.

Step 3. Press **Clock Setup**.

Step 4. Press **Show Clock** to switch the date/time display on/off.

Setup for the Mouse


The user can change the setup for the mouse connected to the E5070A/E5071A and the movement of the pointer.

Setup Step

NOTE Be sure to use a mouse and a keyboard for mouse setup operations.


- Step 1.** Press **System**.
- Step 2.** Press **Misc Setup**.
- Step 3.** Click **Service Menu - Restart Menu** on the menu bar, and the Password dialog box (Figure 12-3) will open.

Figure 12-3 Password Dialog Box



e5070auj136

- Step 4.** Enter the password, **e507xa**, into the **Password** box.
- Step 5.** Click **Restart as Service** on the menu bar, and the instrument will be restarted.
- Step 6.** Move the mouse pointer to the lower-left corner of the E5070A/E5071A screen and click **Start - Settings - Control Panel** to open the Control Panel window.



e5070auj180


- Step 7.** Double-click the **Mouse** icon in the Control Panel window.

Setting and Using the Control and Management Functions Setup for the Mouse

Step 8. The Mouse Properties dialog box (Figure 12-4) is displayed.


Define the setup for a right-handed/left-handed person in the **Buttons configuration** area. Define also the setup for double-click speed in the **Double-click speed** area.

Figure 12-4 Mouse Properties Dialog Box (Buttons tab)



Step 9. Click the **Pointers** tab (Figure 12-5).

Figure 12-5 Mouse Properties Dialog Box (Pointers tab)




Step 10. Enter a registration name into the **Scheme** box and specify the shapes of pointers for the registration name in the box below.

To create a registration name, click the **Save As...** button. Enter the registration name into the **Save Scheme** dialog box that appears, and click the **OK** button.

Step 11. Click the **Motion** tab (Figure 12-6).

Figure 12-6

Mouse Properties Dialog Box (Motion tab)



Step 12. Specify the pointer speed in the **Pointer speed** area and the pointer trail in the **Pointer trail** area.

Step 13. Click the **OK** button.

Step 14. Double-click the **Restart as Inst** icon (Figure 12-7) on the screen. A dialog box will appear that confirms to restart the instrument or not, press **OK** to restart.

The E5070A/E5071A is restarted, and measurement screen will appear.

Figure 12-7

Restart as Inst icon



Enable/Disable the Network Connection Function.

You can enable or disable the network connection function of the E5070A/E5071A.

Operating Step

- Step 1.** Press **System**.
- Step 2.** Press **Misc Setup**.
- Step 3.** Press **Network Setup**.
- Step 4.** Press **Network Device** to **ENABLE** or **DISABLE** the network connection function.
- Step 5.** A dialog box will appear that confirms to reboot the instrument or not, press **OK** to reboot.

Configuring the Network

This section describes how to make the settings required to connect the E5070A/E5071A to a LAN (local area network). For details of how to use a LAN, see the Programmer's Guide.

NOTE


When connecting the E5070A/E5071A to a LAN, consult the network administrator about the proper LAN settings.

Configuring the Network

- Step 1.** Use the LAN cable to connect the E5070A/E5071A to the LAN.
- Step 2.** Press **System**.
- Step 3.** Press **Misc Setup**.
- Step 4.** Press **Network Setup**.
- Step 5.** Press **Network Configuration**.
- Step 6.** The Network dialog box (Figure 12-8) will appear. In the **Configuration** tab, select **TCP/IP** (display it in reverse video) and press the **Properties** button.

Figure 12-8

Network Dialog Box ("Configuration" Tab)



Setting and Using the Control and Management Functions Configuring the Network


Step 7. The dialog box in Figure 12-9 appears.

To assign a specific IP address and subnet mask, select the **Specify an IP address** option button within the **IP Address** tab and enter an IP address into the **IP Address** box and a subnet mask into the **Subnet Mask** box (write them over the initial values).

If an IP address can be obtained automatically (i.e., you can use the DHCP server), click and select **Obtain an IP address automatically**. In this case, it is not necessary to set a gateway address in Step 8.

Figure 12-9


TCP/IP Properties Dialog Box (“IP Address” Tab)



Step 8. Select the **Gateway** tab. The dialog box in Figure 12-10 appears, enter a correct gateway address in the **New gateway** box and press the **Add** button.


Figure 12-10

TCP/IP Properties Dialog Box (“Gateway” Tab)




- Step 9.** In the Network dialog box, select **Identification** tab. The dialog box in Figure 12-11 appears. If another computer name is required other than **E507X**, set in the **Computer Name** box.

Figure 12-11 Network Dialog Box (“Identification” Tab)



- Step 10.** If another network configuration is required, follow the same procedure to configure a network on a Windows 98® PC.
- Step 11.** Press the **OK** button to close the TCP/IP Properties dialog box.
- Step 12.** Press the **OK** button to close the Network dialog box.
- Step 13.** The System Settings Change dialog box (Figure 12-12) now appears, press the **Yes** button to shut down the E5070A/E5071A.

Figure 12-12 System Settings Change Dialog Box



NOTE

The modified network configuration will not take effect until you shut down and restart the E5070A/E5071A.

Accessing to hard disk of the E5070A/E5071A from an external PC via LAN


If you connect the E5070A/E5071A to LAN, you can access the hard disk (D drive) in the E5070A/E5071A as a network drive from an external PC connected to the same LAN.

NOTE

Accessing the hard disk of the external PC connected to the same LAN from the E5070A/E5071A is not supported.

Figure 12-13

Accessing to drive D of E5070A/E5071A from external PC



Enabling access from external PC

NOTE


You need to make the setting to enable the connection to LAN in advance. For more information, refer to “Configuring the Network” on page 255.

- Step 1.** Press **System**.
- Step 2.** Press **Network Configuration**.

- Step 3.** The Network dialog box as shown in Figure 12-14 appears. Click the **File and Print Sharing...** button.

Figure 12-14


Network dialog box



- Step 4.** The File and Print Sharing dialog box as shown in Figure 12-15 appears. Check **I want to be able to give others access to my files** and click the **OK** button.

Figure 12-15

File and Print Sharing dialog box




- Step 5.** Click the **OK** button in the Network dialog box (see Figure 12-14).

- Step 6.** The System Setting Change dialog box as shown in Figure 12-16 appears. Click the **Yes** button to restart.

Figure 12-16

System Settings Change dialog box




Accessing to hard disk of E5070A/E5071A from external PC

This section describes the procedure to connect to the hard disk (drive D) in the E5070A/E5071A from the external PC, taking Windows 98 ® as an example. For information on connection, see your PC's operation manual.

- Step 1.** From the Start menu, click Programs - Windows Explorer to start the Explorer.
- Step 2.** From the Explorer's menu, click **Tools - Map Network Drive...**
- Step 3.** The Map Network Drive dialog box appears. Select an appropriate drive (1 in Figure 12-17), enter **\\e507x\user\$** as the network path (2 in Figure 12-17), and then click the **OK** button.

Figure 12-17 Map Network Drive dialog box




NOTE **e507x** in the network path is the computer name of the E5070A/E5071A. If you changed the computer name when setting the network, use the computer name you changed instead of **e507x**.

NOTE If you use another OS such as Windows NT®, you may be prompted to enter the user name but you can leave it blank.

- Step 4.** The Enter Network Password dialog box appears. Enter the password, **e507xa**, and then click the **OK** button. The D drive of the E5070A/E5071A is connected to the PC.

Figure 12-18 Enter Network Password dialog box



Locking the Front Keys, Keyboard, and/or Mouse (Touch Screen)

You can lock (disable) the front keys, keyboard, and/or mouse (touch screen). This feature prevents erroneous operation caused by inadvertently touching any of these devices.

Locking the Front Keys, Keyboard, and/or Mouse

- Step 1.** Press **System**.
- Step 2.** Press **Misc Setup**.
- Step 3.** Press **Key Lock**.
- Step 4.** Press the corresponding key to switch the lock on/off.

Softkey	Function
Front Panel & Keyboard Lock	Switches the lock for the front panel keys and keyboard on/off.
Touch Screen & Mouse Lock	Switches the lock for the touch screen and mouse on/off.

NOTE

You cannot use a locked device to unlock that same device. To unlock the front panel keys, keyboard, touch screen and mouse that have been locked, press the Standby switch to turn off the power supply and then turn it on again. When setting at power-on, the front panel keys, keyboard, touch screen and mouse are all in an unlocked condition.

Setting the Beeper (Built-in Speaker)

The E5070A/E5071A has a built-in speaker that sounds a beep tone. The beeper allows you to make two types of settings shown in Table 12-1.

Table 12-1

Beeper Functions

Type	Function
Operation complete beeper	Sounds a beep tone to inform the user that operations have completed. <ul style="list-style-type: none">• When calibration data measurements are done• When data storage has completed
Warning beeper	Sounds a beep tone to prompt the user to use caution. <ul style="list-style-type: none">• When an instrument error occurs (An error message appears at the same time.)• When a limit test fails

The warning beeper sounds slightly longer than the operation complete beeper.

Setting the Operation Complete Beeper

Step 1. Press **[System]**.

Step 2. Press **Misc Setup**.

Step 3. Press **Beeper**.

Step 4. Press **Beep Complete** to switch the operation complete beeper on/off.

Pressing **Test Beep Complete** allows you to hear and check the beep tone of the operation complete beeper.

Setting the Warning Beeper

Step 1. Press **[System]**.

Step 2. Press **Misc Setup**.

Step 3. Press **Beeper**.

Step 4. Press **Beep Warning** to switch the warning beeper on/off.

Pressing **Test Beep Warning** allows you to hear and check the beep tone of the warning beeper.

Turning off the LCD Screen Backlight

You can switch off the backlight (illumination) of the LCD screen of the E5070A/E5071A. This extends the life of the backlight when using it continuously over a long period.

Turning off the LCD Screen Backlight

Step 1. Press **System**.

Step 2. Press **Backlight** to switch the backlight on/off.

Switching off the backlight causes indications on the LCD screen to be almost invisible.

The backlight that has been switched off can be turned on again by pressing **Preset**. When the LCD backlight is off, **Preset** works as a key for switching the backlight back on.

Checking the product information

Checking the serial number

The revision number of the firmware installed in the E5070A/E5071A can be checked using the following procedure.

Checking the serial number

- Step 1.** Press **System**.
- Step 2.** Press **Service Functions**.
- Step 3.** Press **Enable Options**.

The serial number is displayed in the softkey menu bar.

Checking the Firmware Revision

The revision number of the firmware installed in the E5070A/E5071A can be checked using the following procedure.


Checking the Firmware Revision

- Step 1.** Press **System**.
- Step 2.** Press **Firmware Revision**.

The Firmware Revision dialog box (Figure 12-19) appears.

Figure 12-19

Firmware Revision Dialog Box



- Step 3.** Press **OK** to close the dialog box.

System Recovery

By executing system recovery, you can return the Windows operating system and the firmware of the E5070A/E5071A to the state when you purchased it*¹.

Notes on executing system recovery

Executing system recovery causes the following:

- The following settings of the E5070A/E5071A are initialized.
 - Network setting
 - GPIB setting
 - Printer setting
- If the firmware has been updated after purchasing the E5070A/E5071A, the firmware when you purchased the product*¹ is recovered.
- The driver for the supported printer you installed is deleted.


Files you created using the save function (files in the D drive) are not affected, but we recommend backing them up before executing system recovery for precautionary purposes. For more information on backup, refer to “Making Backup Files” on page 366.

Procedure to execute system recovery

NOTE

You need the keyboard and the mouse for this operation.

- Step 1.** Shut down the E5070A/E5071A.
- Step 2.** Connect the keyboard and the mouse to the E5070A/E5071A.
- Step 3.** Press the standby switch of the E5070A/E5071A to turn it on.
- Step 4.** When the message in the figure below appears on the screen following the Agilent's logo screen (white screen), immediately press **[R]** on the keyboard.



NOTE

After several seconds, the next screen appears automatically even if you do not press any key, so do not miss it.

If the above message does not appear, the instrument is at fault; contact your local Agilent customer center listed at the end of this manual or distributor.

*1. If the hard disk failed and has been replaced after purchase, the state when the replacement was performed is recovered.

Setting and Using the Control and Management Functions

System Recovery

Step 5. When "Recover Hard disk (C drive) [Y, N]?" is displayed, press on the keyboard. If you want to quit the system recovery, press to start up the E5070A/E5071A as usual.

Step 6. The following message appears. This is the final confirmation message asking whether you want to start the system recover. Press on the keyboard to start the system recovery. If you want to quit the system recovery, press to start up the E5070A/E5071A as usual.

```
=====
SYSTEM RECOVERY
=====

This process will recover the system drive (C:) of this
instrument to the factory-shipment state. It takes about 30 minutes.
Please refer to the Operation Manual for more information.

This is the last chance to quit the recovery process

Continue [Y,N]?
```

Step 7. The system recovery will be complete in about 15 minutes. The following message is displayed during the system recovery.

```
=====
SYSTEM RECOVERY IN PROGRESS....
=====

System recovery in progress. It takes about 30 minutes.
Please DO NOT TURN THE POWER OFF DURING THIS TIME.
```


CAUTION

Never turn off the power during the system recovery because doing so may cause serious damage to the E5070A/E5071A.

Step 8. After the completion of the system recovery, the System Setting Change dialog box as shown in Figure 12-16 appears. Click the **Yes** button to restart.


Figure 12-20

System Setting Change dialog box



- Step 9.** After restart, the Enter Network Password dialog box as shown in Figure 12-21 appears. **Enter nothing** and click the **OK** button.

Figure 12-21 Enter Network Password dialog box




NOTE

If you enter the password here, each time you start the instrument, the Enter Network Password dialog box appears and asks you to enter the password. If you click the **Cancel** button, the Enter Network Password dialog box will appear again at the next startup.

- Step 10.** The System Setup Complete dialog box appears. Click the **OK** button to restart.

Note that, if the system calibration data file has a problem, the Recovery Failed dialog box as shown in Figure 12-22 appears instead of the System Setup Complete dialog box, and then the System Setup **Incomplete** dialog box appears.

Figure 12-22 Recovery Failed dialog box



NOTE

If the Recovery Failed dialog box and the System Setup Incomplete dialog box appear or if the problem persists even if you executing the system recovery, the instrument is at fault. Contact your local Agilent Technologies customer center listed at the end of this manual or distributor.

- Step 11.** For the E5070A/E5071A equipped with the Option 016 touch screen, execute the calibration of the touch screen. For information on the execution procedure, refer to “Calibration of the Touch Screen” on page 268.

Now the system recovery of the E5070A/E5071A is complete.

Calibration of the Touch Screen


When you have executed system recovery on a E5070A/E5071A equipped with an Option 016 touch screen, you have to calibrate the touch screen. Follow the procedure described below to calibrate the touch screen.

- Step 1.** Press **System**.
- Step 2.** Press **Service Menu**.
- Step 3.** Press **Test Menu**.
- Step 4.** Press **Adjust Touch Screen**.

The touch screen calibration screen (Figure 12-23) appears.

Figure 12-23

Touch Panel Calibration Screen



- Step 5.** Touch the x mark on the upper left with your finger. The mark x appears also on the lower left, upper right, and lower right. Touch the x marks in that order with your finger.

Touching the four locations described above with your finger automatically concludes the touch screen calibration.

NOTE

With no operation on the touch screen calibration screen for a preset time, it automatically closes and the previous measurement screen reappears.

13 Controlling E5091A

This chapter describes how to control the E5091A multiport test set.

Connecting E5070A/E5071A and E5091A

Required devices

The required devices to connect between the E5070A/E5071A and the E5091A are listed below.


- E5070A/E5071A
- E5091A
- N-type to N-type cable (attached to the E5091A, Agilent part number: 8120-4782)
- USB cable (attached to the E5091A, Agilent part number: 8121-0770)

Connecting E5070A/E5071A and E5091A

As shown in Figure 13-1, connect the USB cable between the rear panel of the E5070A/E5071A and that of the E5091A.

Figure 13-1

Connection between the E5070A/E5071A and the E5091A (rear view)




NOTE

Don't switch on/off devices connected using USB ports (both front and rear panels) and connect/disconnect devices to the USB ports, while the E5070A/E5071A measures with the E5091A.

As shown in Figure 13-2, connect the N-type cable between the front panel of the E5070A/E5071A and that of the E5091A. Make the connection so that the numbers of the test ports of the E5070A/E5071A and those of the interconnection ports of the E5091A match.

Figure 13-2 Connection between E5070A/E5071A and E5091A (front view)



Powering on

After connecting the E5070A/E5071A and the E5091A, follow these steps to power them on.

- Step 1.** Turn on the E5070A/E5071A and the E5091A.
- Step 2.** Immediately after power-on, all the port connection indicator LEDs of the E5091A go on. Then, after the E5070A/E5071A detects the E5091A, 4 LEDs that indicate the connected test ports stay on. As the initial setting of the E5070A/E5071A, the port connection indicators, A, T1, R1+, and R1-, stay on.

NOTE

If the E5070A/E5071A is not powered on or if the E5070A/E5071A and the E5091A are not connected with the USB cable, all the LEDs stay on.

Setting E5091A

This section describes the setting of the E5091A. Table 13-1 shows the flow of the setting.

Table 13-1 Setting flow for E5091A

Item	Description
“Selecting ID for E5091A” on page 272	Select the ID of the E5091A you want to set.
“Assigning test ports” on page 273	Assign between the test ports of the E5070A/E5071A and those of the E5091A.
“Displaying the E5091A property” on page 273	Display the E5091A property to check the port setting.
“Setting control line” on page 274	Make the setting of the control line to control the DUT.
“Enabling control of E5091A” on page 275	Enables the functions of the E5091A.


Selecting ID for E5091A

Set the set target ID to the ID of the connected E5091A.

- Step 1.** Press **[System]** - **E5091A Setup** to display the E5091A setup menu.
- Step 2.** Press **Select ID** and then select the ID of the E5091A. The ID is set with the bit switch on the rear panel of the E5091A. (Figure 13-3)

NOTE Change the ID bit switch setting when the E5070A/E5071A is turned off.

Figure 13-3 ID bit switch of E5091A



e5091a0e004

Assigning test ports

Before calibration and measurement, you need to assign the test ports of the E5091A. You can set the connection ports for each channel and perform measurement switching the connection for each channel.

Operational procedure

- Step 1.** Press **System** - **E5091A Setup** to display the E5091A setup menu.
- Step 2.** Press **Channel Next** or **Channel Prev** to activate a channel for which you want to set the connection ports.
- Step 3.** Use the corresponding softkey to assign between the test ports of the E5091A and the interconnection ports.

Softkey	Function
Port1	Selects a test port of the E5091A to which you want to connect port 1 of the E5070A/E5071A. You can select the port from A or T1 ^{*1} .
Port2	Selects a test port of the E5091A to which you want to connect port 2 of the E5070A/E5071A. You can select the port from T1 ^{*1} or T2 .
Port3	Selects a test port of the E5091A to which you want to connect port 3 of the E5070A/E5071A. You can select the port from R1+ , R2+ , or R3+ ^{*2} .
Port4	Selects a test port of the E5091A to which you want to connect port 4 of the E5070A/E5071A. You can select the port from R1- , R2- , or R3- ^{*2} .

*1. If port T1 has been already assigned to port 2 when you try to assign port T1 to port 1, port T2 is automatically assigned to port 2. If port T1 has been already assigned to port 1 when you try to assign port T1 to port 2, port A is automatically assigned to port 1.

*2. When the E5091A Option 007 is connected, the connection is made to R2+ if **R3+** has been set; the connection is made R2- to if **R3-** has been set.

- Step 4.** Execute Step. 2 through Step. 3 for all channels for which you want to perform sweep.


Displaying the E5091A property

By displaying the E5091A property shown in Figure 13-4, you can obtain the assignment information of the test ports for each channel. It is useful when you need to check the test port assignment, for example, when you perform calibration.

Controlling E5091A Setting E5091A

Figure 13-4

E5091A property



Operational procedure

- Step 1.** Press **System** - **E5091A Setup** to display the E5091A setup menu.
- Step 2.** Press **Select ID** and then select the ID whose E5091A property you want to display. The ID is set with the bit switch on the rear panel of the E5091A. (Figure 13-3)
- Step 3.** Press **E5091A Property** to enable it (**ON**) to display the E5091 property.

NOTE


The enable (**ON**)/disable (**OFF**) setting of the E5091A property display is executed for all channels.

Setting control line

The E5070A/E5071A can control the output from the control line (Figure 13-5) of the E5091A and control the DUT (for example, switching the frequency band of the front end module). The procedure is shown below. For the specifications of the DUT control line, refer to *E5091A Users & Service Guide*.

Figure 13-5

Control line



Operational procedure

- Step 1.** Press **System** - **E5091A Setup** to display the E5091A setup menu.
- Step 2.** Press **Channel Next** or **Channel Prev** to activate a channel for which you want to set the control line.
- Step 3.** Press **Select ID** and then select the ID of the E5091A. The ID is set with the bit switch on the real panel of the E5091A. (Figure 13-3 on page 272)
- Step 4.** Press **Control Lines** to the setting menu of the DUT control line.
- Step 5.** Use the corresponding softkey to set the control line of the E5091A.

Softkey	Function
Line 0, Line 1, Line 2, Line 3, Line 4, Line 5, Line 6, Line 7	Set High/Low of each line of the control line.

- Step 6.** Execute Step. 3 through Step. 5 for all channels for which you want to perform sweep.

Enabling control of E5091A

If you enable the control of the E5091A, switching the measurement path and the output function of the control line of the E5091A during measurement become available.

NOTE

The E5070A/E5071A needs about 3 ms to control the E5091A when you enable the control of the E5091A. Notice that, if the E5091A is not connected to the E5070A/E5071A, the E5070A/E5071A does not need any additional time to control the E5091A regardless of this setting.

When you disable the control of the E5091A, the E5070A/E5071A does not need any additional time to control the E5091A regardless of connecting the E5091A to the E5070A/E5071A.

Operational procedure

- Step 1.** Press **System** - **E5091A Setup** to display the E5091A setup menu.
- Step 2.** Press **E5091A Control** to enable (**ON**) the control of the E5091A.

NOTE

The enable (**ON**)/disable (**OFF**) setting of the control function of the E5091A is executed for all channels.

Calibration

For calibration with the E5091A connected, because the setting of the E5091 can be performed for each channel, you need to change the ports to which the standard is connected for the channel even for the same measurement parameter.

Operational procedure

- Step 1.** Press `Channel Next` or `Channel Prev` to set the channel for which you want to perform calibration to the active channel.
- Step 2.** Follow “Displaying the E5091A property” on page 273 to display the E5091A property.
- Step 3.** According to Chapter 4, “Calibration,” on page 77, perform calibration. Check the connected test ports shown in the calibration property as the port names of the E5070A/E5071A on the calibration menu, connect the calibration standard to the corresponding test ports of the E5091A, and perform calibration.

Performing Measurement

Trigger state and switching the setting of the E5091A

The following table shows how the setting in the E5091A is switched from when the trigger state is the stop state. For more information on the trigger state, refer to *E5070A/E5071A Programmers Guide*.

Trigger state	Switching the setting the E5091A
Stop	The setting is not switched.
Trigger wait	The setting of the internal switch and the output of the control line are switched according to the setting of the channel swept first. The connection of the test ports and the output of the control line are switched according to the setting of the channel swept first.
Measurement	Measurement is performed following the procedure below. Execute a sweep for the first channel. ↓ Set the connection of the test ports and the output of control line according to the setting of the channel swept second. ↓ Execute a sweep for the second channel. ↓ ⋮ ↓ Set the connection of the test ports and the output of control line according to the setting of the channel swept last. ↓ Execute a sweep for the last channel.
Stop or trigger wait	The setting is not switched for the stop state; it is switched for the trigger wait state.

Operation

Perform operation, referring to Chapter 5, “Making Measurements,” on page 121.

Connecting two E5091As

Give attention to the following items when you make measurement with two E5091As.

- Set their ID to different values. The instrument don't work correctly if they are same.
- Connect calibration standards and DUT with after confirming the connection and the port assignment of the E5071As.

14 Measurement Examples

This chapter introduces examples of actual device measurements using the Agilent E5070A/E5071A.

Measuring the SAW Bandpass Filter Using the Segment Sweep

This section illustrates how to use the segment sweep function to evaluate a SAW bandpass filter with a center frequency of 947.5 MHz.

Evaluation Steps

Here, the DUT is evaluated by following the steps described in Table 14-1.

Table 14-1 Evaluating the DUT Using the Segment Sweep


Step	Description
“1. Determine the Segment Sweep Conditions” on page 280	The segment sweep conditions are determined considering the characteristics of the DUT.
“2. Create a Segment Sweep Table” on page 282	The segment sweep conditions are entered in the E5070A/E5071A.
“3. Select the Segment Sweep as the Sweep Type” on page 284	The segment sweep is selected as the sweep type.
“4. Execute the Calibration” on page 284	A 2-port ECal is performed between the test ports connecting the DUT.
“5. Connect the DUT” on page 284	The DUT is connected.
“6. Execute the Measurement” on page 285	A trigger is applied to perform the measurement.
“7. Define the Setup for Display” on page 285	A choice is made between frequency base and order base as the method of displaying segments.

1. Determine the Segment Sweep Conditions

Figure 14-1 shows the result of evaluating the transmission characteristics of the SAW bandpass filter in the range of 440 MHz to 3 GHz by using the linear sweep.

Figure 14-1

Transmission Characteristics of a SAW Bandpass Filter (440 MHz to 3 GHz, linear sweep)



The measurement conditions are determined for each frequency range. Here, the segment sweep is performed following the sweep conditions shown in Table 14-2.

Table 14-2

Determining the Sweep Conditions (Using markers shown in Figure 14-1).

Frequency Range		Measurement Conditions	
Start	Stop	Number of Points	IF Bandwidth
440 MHz	915 MHz (Marker 1)	47	70 kHz
915 MHz (Marker 1)	980 MHz (Marker 2)	130	100 kHz
980 MHz (Marker 2)	1.035 GHz (Marker 3)	55	70 kHz
1.07 GHz (Marker 4)	2 GHz (Marker 5)	93	70 kHz
2.6 GHz (Marker 6)	3 GHz	41	70 kHz

14. Measurement Examples

2. Create a Segment Sweep Table

Follow the steps below to make entries in the segment sweep table.

Step 1. Display the segment table.

Setup Description	Key Operation
Presetting	Preset - OK
Displaying the segment table	Sweep Setup - Edit Segment Table

Step 2. Display the IF bandwidth setting column on the segment table.

Setup Description	Key Operation
Moving the focus to the softkey menu	Focus
Display of the IF bandwidth setting column: ON	List IFBW (Turn it ON .)

NOTE

When setup items (power level, delay time, and sweep time in this case) are not displayed in the segment table, the setting for the channel in use applies to all segments.

Step 3. Enter the setup data into the segment table.

Setup Description	Key Operation
Moving the focus to the segment table	Focus
Segment 1	
Start frequency: 440 MHz	4 4 0 M/μ
Stop frequency: 915 MHz	9 1 5 M/μ
Number of points: 47	4 7 x1
IF bandwidth: 70 kHz	7 0 k/m
Segment 2	
Start frequency: 915 MHz	9 1 5 M/μ
Stop frequency: 980 MHz	9 8 0 M/μ
Number of points: 130	1 3 0 x1
IF bandwidth: 100 kHz	1 0 0 k/m
Segment 3	
Start frequency: 980 MHz	9 8 0 M/μ
Stop frequency: 1.035 GHz	1 . 0 3 5 G/n

Setup Description

Key Operation

Number of points: 55

5 **5** **x1**

IF bandwidth: 70 kHz

7 **0** **k/m**

Segment 4

Start frequency: 1.07 GHz

1 **.** **0** **7** **G/n**

Stop frequency: 2 GHz

2 **G/n**

Number of points: 93

9 **3** **x1**

IF bandwidth: 70 kHz

7 **0** **k/m**

Segment 5

Start frequency: 2.6 GHz

2 **.** **6** **G/n**

Stop frequency: 3 GHz

3 **G/n**

Number of points: 41


4 **1** **x1**

IF bandwidth: 70 kHz

7 **0** **k/m**

Figure 14-2

Completed Segment Table



3. Select the Segment Sweep as the Sweep Type

The segment sweep is selected as the sweep type.


Setup Description	Key Operation
Sweep type: Segment sweep	 - Sweep Type - Segment

4. Execute the Calibration


In this step, a 2-port ECal is executed on the two ports to be used.

Step 1. Connect the ECal module across test ports 1 and 2.

Figure 14-3 Connecting the ECal Module



Step 2. Execute the 2-port ECal.


Setup Description	Key Operation
Executing a 2-port ECal between test ports 1 and 2	 - ECal - 2 Port ECal - 1-2

5. Connect the DUT

The DUT is connected across test ports 1 and 2.

Figure 14-4

Connecting the DUT



e5070auj082

6. Execute the Measurement

A trigger is applied to perform the measurement.

Setup Description	Key Operation
Sweep mode: Single	Trigger - Single (Or Continuous)

7. Define the Setup for Display

A choice is made between frequency base and order base as the segment display mode.

Setup Description	Key Operation
Segment display: Frequency base or order base	Sweep Setup - Segment Display - Frequency Base Order Base

14. Measurement Examples

Figure 14-5

Segment Display: Frequency Base





Figure 14-6

Segment Display: Order Base



Evaluating a Duplexer

This section illustrates how to evaluate a duplexer (Tx center frequency: 1.88 GHz, Rx center frequency: 1.96 GHz).

Evaluation Steps

Here, the DUT is evaluated by following the steps described in Table 14-3.

Table 14-3 Evaluating the DUT Using the Segment Sweep

Step	Description
“1. Determine the Segment Sweep Conditions” on page 287	Segment sweep conditions are determined by considering the characteristics of the DUT.
“2. Create a Segment Sweep Table” on page 288	The segment sweep conditions are entered in the E5070A/E5071A.
“3. Select the Segment Sweep as the Sweep Type” on page 289	The segment sweep is selected as the sweep type.
“4. Execute the Calibration” on page 289	A full 3-port calibration is executed by using the 2-port ECal module.
“5. Connect the DUT” on page 292	The DUT is connected.
“6. Define the Setup for Display” on page 292	The number of traces to be displayed, split display, and measurement parameters are specified.
“7. Execute the Measurement” on page 293	A trigger is applied to execute the measurement.
“8. Define the Setup for the Segment Display and Scale” on page 293	The setup for segment display and for the scale are defined.
“9. Analyze the Parameters” on page 294	The evaluation parameters for the duplexer are determined.
“10. Define the Setup for a Limit Table” on page 296	The setup for the limit table is defined.
“11. Execute the Limit Test” on page 299	The limit test is executed.

1. Determine the Segment Sweep Conditions

A segment sweep is performed following the sweep conditions shown in Table 14-4.

Table 14-4 Sweep Conditions

Start	Stop	Number of Points
1.73 GHz	1.83 GHz	50
1.83 GHz	2.03 GHz	400
2.03 GHz	2.13 GHz	50
3.65 GHz	4.03 GHz	38
5.5 GHz	6.02 GHz	52

2. Create a Segment Sweep Table

Entries are made into the segment sweep table following the steps described below.

Step 1. Display the segment table.

Setup Description	Key Operation
Presetting	Preset - OK
Displaying the segment table	Sweep Setup - Edit Segment Table

Step 2. Enter the setup data into the segment table.

NOTE

In this step, the IF Bandwidth, power level, delay time, and sweep time are not entered segment by segment. By turning off the display of those parameters on the segment table, you can use, in each segment without making a change, the IF Bandwidth (preset value: 70 kHz) of the channel specified by using **Avg** - **IF Bandwidth**; Power level (preset value: 0 dBm) of the channel specified by using **Sweep Setup** - **Power**; Sweep delay time (preset value: 0 second) of the channel specified by using **Sweep Setup** - **Sweep Delay**; Sweep mode (preset value: Stepped mode) of the channel specified by using **Sweep Setup** - **Sweep Mode**; and Sweep time (preset value: Automatic) of the channel specified by using **Sweep Setup** - **Sweep Time**.

Setup Description	Key Operation
Segment 1	
Start frequency: 1.73 GHz	1 . 7 3 G/n
Stop frequency: 1.83 GHz	1 . 8 3 G/n
Number of points: 50	5 0 x1
Segment 2	
Start frequency: 1.83 GHz	1 . 8 3 G/n
Stop frequency: 2.03 GHz	2 . 0 3 G/n
Number of points: 400	4 0 0 x1
Segment 3	
Start frequency: 2.03 GHz	2 . 0 3 G/n
Stop frequency: 2.13 GHz	2 . 1 3 G/n
Number of points: 50	5 0 x1
Segment 4	
Start frequency: 3.65 GHz	3 . 6 5 G/n
Stop frequency: 4.03 GHz	4 . 0 3 G/n

Setup Description

Number of points: 38

3 **8** **x1**

Segment 5

Start frequency: 5.5 GHz

5 **.** **5** **G/n**

Stop frequency: 6.02 GHz


6 **.** **0** **2** **G/n**

Number of points: 52

5 **2** **x1**

Figure 14-7

Completed Segment Table



3. Select the Segment Sweep as the Sweep Type

The segment sweep is selected as the sweep type.

Setup Description

Sweep type: Segment sweep

Key Operation

Focus (Moves the focus to the softkey menu)
- Return - Sweep Type - Segment
 (or **Sweep Setup** - Sweep Type - Segment)

4. Execute the Calibration

In this step, a 2-port ECal module and 3-/4-port module contained in the E5070A/E5071A are used to execute the calibration on the three ports to be used in the measurement.

- Step 1.** First, connect the USB port of the 2-port ECal module and the USB port of the E5070A/E5071A with a USB cable. The connection may be made while the unit is powered.

Measurement Examples

Evaluating a Duplexer

Step 2. Load and execute the 3-/4-port ECal programs.

Setup Description	Key Operation
Opening the VBA Project Open dialog box	Macro Setup - Load Project
Loading “ECalAssistant.VBA”	Select “D:\Agilent\ECalAssistant.VBA” and press the Open button.
Executing the program	Macro Run

Step 3. The EcalAssistant (Start) dialog box appears (Figure 14-8).

Figure 14-8


EcalAssistant (Start) Dialog Box



Step 4. Pressing the **Next** button to display the EcalAssistant (Port/Channel Selection) dialog box (Figure 14-9).

Figure 14-9

EcalAssistant (Port/Channel Selection) Dialog Box




Step 5. Following the instructions in the dialog box, select the type of ECal, test ports, and a channel.

Setup Description	Key Operation
Select Ports	
ECal type: Full 3-port calibration	3 Port
Test ports to be used for ECal: 1, 2, and 3	1, 2, 3
Select Channel	
Channel on which ECal is to be executed: Channel 1	Channel: 1

Step 6. Press the **Next** button. The EcalAssistant (Connection) dialog box (Figure 14-10) will appear.

Figure 14-10

EcalAssistant (Connection) Dialog Box




Step 7. Connect the ECal module to the test ports according to the instruction in the dialog box and then press **Measure**.

Setup Description	Key Operation
Executing calibration between ports 1 and 2	(After making the connections shown in Figure 14-3 (a)), press Measure - Next .
Executing calibration between ports 1 and 3	(After making the connections shown in Figure 14-3 (b)), press Measure - Next .
Executing calibration between ports 2 and 3	(After making the connections shown in Figure 14-3 (c)), press Measure - Next .

Figure 14-11

Connecting the ECal Module




e5070aue089

Step 8. The EcalAssistant (Complete) dialog box (Figure 14-12) will appear. Press the **Done** button to terminate the calibration.

Figure 14-12

ECalAssistant (Complete) Dialog Box




5. Connect the DUT

The DUT is connected to test ports 1, 2, and 3.

Figure 14-13

Connecting the DUT



6. Define the Setup for Display

The setup for display is defined.

Setup Description	Key Operation
Number of traces to be displayed: 5	[Display] - Number of Traces - 5
Trace placement: Trisected	Allocate Traces - <input type="text" value="x3"/>
Measurement Parameter	
Trace 1: S ₁₃	[Meas] - S13
Trace 2: S ₂₁	[Trace Next] - [Meas] - S21
Trace 3: S ₂₃	[Trace Next] - [Meas] - S23

Setup Description

Key Operation

Trace 4: S₃₃

Trace Next - **Meas** - **S33**

Trace 5: S₁₁

Trace Next - **Meas** - **S11**

7. Execute the Measurement

A trigger is applied to execute the measurement.

Setup Description

Key Operation

Sweep mode: Single (or continuous)

Trigger - **Single** (or **Continuous**)

8. Define the Setup for the Segment Display and Scale

The setup for the scale is defined.

Setup Description

Key Operation

Segment display: Order base

Sweep Setup - **Segment Display** - **Order Base**

Reference Line Position

Trace 1: 10

Trace Next - **Scale** - **Reference Position** - **1** **0** **x1**

Trace 2: 10

Trace Next - **Reference Position** - **1** **0** **x1**

Trace 3: 10

Trace Next - **Reference Position** - **1** **0** **x1**

Trace 4: 9


Trace Next - **Reference Position** - **9** **x1**

Trace 5: 9

Trace Next - **Reference Position** - **9** **x1**

Figure 14-14

Measurement Result (Segment Display: Order Base)



9. Analyze the Parameters

The parameters for the duplexer are determined.

Step 1. Determine the insertion loss and 3 dB bandwidth for Tx.

Setup Description	Key Operation
Marker coupling: OFF	Marker Fctn - Couple (Turn it OFF)
Activating Trace 1	Trace Next
Marker 1: ON	Marker
Search/Tracking: ON	Marker Search - Tracking (Turn it ON)
Moving the marker to the trace maximum	Max
Bandwidth search: ON	Bandwidth (Turn it ON .)
Maximizing the display of Trace 1	Bandwidth (Turn it ON .)

In the example shown in Figure 14-15, the insertion loss (**loss**) is 1.243 dB and the 3 dB bandwidth (**BW**) is 85.53 MHz.

Step 2. Determine the insertion loss and 3 dB bandwidth for the Rx.

Setup Description	Key Operation
Activating Trace 2	Trace Next
Marker 1: ON	Marker

Setup Description	Key Operation
Search/Tracking: ON	Marker Search - Tracking (Turn it ON .)
Moving Marker 1 to the trace maximum	Max
Bandwidth search: ON	Bandwidth (Turn it ON)

In the example shown in Figure 14-15, the insertion loss (**loss**) is 1.627 dB and the 3 dB bandwidth (**BW**) is 71.04 MHz.

Step 3. Determine the isolation between Tx and Rx.

Setup Description	Key Operation
Activating Trace 3	Trace Next
Marker 1: ON	Marker
Search/Tracking: ON	Marker Search - Tracking (Turn it ON)
Moving Marker 1 to the peak near 1.92 GHz	Peak - Search Left or Search Right (Press as many times as necessary.)

In the example shown in Figure 14-15, the isolation (response value of marker 1) is 6.612 dB.

Step 4. Determine the return loss of Tx.

Setup Description	Key Operation
Activating Trace 4	Trace Next
Marker 1: ON	Marker
Search/Tracking: ON	Marker Search - Tracking (Turn it ON)
Moving Marker 1 to the peak in the pass band	Peak - Search Left or Search Right (Press as many times as necessary.)* ¹

*1. If you cannot move the marker to the desired peak, use **Peak Excursion** to change the peak deviation and then execute the search again. (Example: **Peak Excursion** -

0 **.** **1** **x1**).

In the example shown in Figure 14-15, the return loss (response value of Marker 1) is 12.65 dB.

Step 5. Determine the return loss of Rx.

Setup Description	Key Operation
Activating Trace 5	Trace Next
Marker 1: ON	Marker

Measurement Examples Evaluating a Duplexer

Setup Description

Search/Tracking: ON

Moving Marker 1 to the peak in the pass band

Key Operation

Marker Search - **Tracking** (Turn it ON)

Peak - Search Left|Search Right (Press as many times as necessary.)*1

*1. If you cannot move the marker to the desired peak, use **Peak Excursion** to change the peak deviation and then execute the search again. (Example: **Peak Excursion -**

0 **.** **1** **x1**).

In the example shown in Figure 14-15, the return loss (response value of Marker 1) is 13.80 dB.

Step 6. Turn on the marker table display.

Setup Description


Marker table display: ON

Key Operation

Marker Fctn - **Marker Table** (Turn it ON)

Figure 14-15

Analyzing Duplexer Parameters



10. Define the Setup for a Limit Table

Follow the steps below to make entries into the limit table.

Step 1. Define a limit table for Trace 1 (S₁₃).

Setup Description

Activating Trace 1

Key Operation

Trace Next

Setup Description

Displaying a limit table

Segment 1

Type: Upper limit

Begin Stimulus value: 1.73 GHz

End Stimulus value: 1.94 GHz

Begin Response value: 0 dB

End Response value: 0 dB

Segment 2

Type: Lower limit

Begin Stimulus value: 1.85 GHz

End Stimulus value: 1.91 GHz

Begin Response value: -4 dB

End Response value: -4 dB

Segment 3

Type: Upper limit

Begin Stimulus value: 1.93 GHz

End Stimulus value: 1.99 GHz

Begin Response value: -40 dB

End Response value: -40 dB

Segment 4

Type: Upper limit

Begin Stimulus value: 1.99 GHz

End Stimulus value: 2.13 GHz

Begin Response value: -40 dB



End Response value: -40 dB


Segment 5

Type: Upper limit

Key Operation

System - **Limit Test** - **Edit Limit Line**

Enter   (Select **Max**) - **Enter**


 **1** **.** **7** **3** **G/n**

1 **.** **9** **4** **G/n**

0 **x1**

0 **x1**



Enter    (Select **Min**) - **Enter**


 **1** **.** **8** **5** **G/n**

1 **.** **9** **1** **G/n**

+/- **4** **x1**

+/- **4** **x1**



Enter   (Select **Max**) - **Enter**


 **1** **.** **9** **3** **G/n**

1 **.** **9** **9** **G/n**

+/- **4** **0** **x1**

+/- **4** **0** **x1**



Enter   (Select **Max**) - **Enter**

 **1** **.** **9** **9** **G/n**

2 **.** **1** **3** **G/n**

+/- **4** **0** **x1**

+/- **4** **0** **x1**

Enter   (Select **Max**) - **Enter**

Measurement Examples Evaluating a Duplexer

Setup Description

Begin Stimulus value: 2.13 GHz

End Stimulus value: 6.02 GHz

Begin Response value: -25 dB

End Response value: -25 dB

Key Operation

2 . 1 3 G/n

6 . 0 2 G/n

+/- 2 5 x1

+/- 2 5 x1

Figure 14-16

Completed Limit Table for Trace 1

	Type	Begin Stimulus	End Stimulus	Begin Response	End Response
1	MAX	1.730000000 GHz	1.940000000 GHz	0 dB	0 dB
2	MIN	1.850000000 GHz	1.910000000 GHz	-4 dB	-4 dB
3	MAX	1.930000000 GHz	1.990000000 GHz	-40 dB	-40 dB
4	MAX	1.990000000 GHz	2.130000000 GHz	-40 dB	-40 dB
5	MAX	2.130000000 GHz	6.020000000 GHz	-25 dB	-25 dB
6					

e5070auj091

Step 2. Define the setup of the limit table for Trace 2 (S_{21}).

Setup Description

Activating Trace 2

Key Operation

Trace Next

Segment 1

Type: Upper limit

Enter (Select Max) - Enter

Begin Stimulus value: 1.73 GHz

1 . 7 3 G/n

End Stimulus value: 1.85 GHz

1 . 8 5 G/n

Begin Response value: -40 dB

+/- 4 0 x1

End Response value: -40 dB

+/- 4 0 x1

Segment 2

Type: Upper limit

Enter (Select Max) - Enter

Begin Stimulus value: 1.85 GHz

1 . 8 5 G/n

End Stimulus value: 1.91 GHz

1 . 9 1 G/n

Begin Response value: -45 dB

+/- 4 5 x1

End Response value: -45 dB

+/- 4 5 x1

Segment 3

Setup Description	Key Operation
Type: Upper limit	(Select Max) -
Begin Stimulus value: 1.91 GHz	
End Stimulus value: 6.02 GHz	
Begin Response value: 0 dB	
End Response value: 0 dB	
Segment 4	
Type: Lower limit	(Select Min) -
Begin Stimulus value: 1.93 GHz	
End Stimulus value: 1.99 GHz	
Begin Response value: -5 dB	
End Response value: -5 dB	

Figure 14-17

Completed Limit Table for Trace 2

	Type	Begin Stimulus	End Stimulus	Begin Response	End Response
1	MAX	1.730000000 GHz	1.850000000 GHz	-40 dB	-40 dB
2	MAX	1.850000000 GHz	1.910000000 GHz	-45 dB	-45 dB
3	MAX	1.910000000 GHz	6.020000000 GHz	0 dB	0 dB
4	MIN	1.930000000 GHz	1.990000000 GHz	-5 dB	-5 dB
5					

e5070auj092

11. Execute the Limit Test

The limit test is executed.

Step 1. Turn on the limit line and limit test for Trace 1.

Setup Description	Key Operation
Activating Trace 1	
Limit Line: ON	- Limit Test - Limit Line (Turn it ON)
Limit Test: ON	Limit Test (Turn it ON)

Measurement Examples Evaluating a Duplexer

Step 2. Turn on the limit line and limit test for Trace 2.


Setup Description	Key Operation
Activating Trace 2	Trace Next
Limit Line: ON	Limit Line (Turn it ON)
Limit Test: ON	Limit Test (Turn it ON)

Step 3. Apply a trigger to execute the measurement.

Setup Description	Key Operation
Sweep Mode: Single	Trigger - Single (or Continuous)

Figure 14-18


Limit Test Results



Step 4. Maximize the screen display of Trace 1 to examine its details.

Setup Description	Key Operation
Activating Trace 1	Trace Prev
Maximizing the display of Trace 1	Trace Max

Figure 14-19 Enlarged Display of Trace 1



Step 5. Maximize the screen display of Trace 2 to examine its details.


Setup Description

Key Operation

Activating Trace 2

Trace Prev (The display of Trace 2 is maximized.)

Figure 14-20 Enlarged Display of Trace 2



Measuring the Deviation from a Linear Phase

This section illustrates how to determine the deviation from a linear phase in the pass band of a 1.09 GHz bandpass filter.

Evaluation Steps

Here, the DUT is evaluated by following the steps described in Table 14-5.

Table 14-5 Evaluating the Deviation from a Linear Phase


Step	Description
“1. Connect the DUT” on page 302	The DUT is connected.
“2. Define the Measurement Conditions” on page 303	The measurement conditions are defined.
“3. Execute the Calibration” on page 303	The calibration is executed.
“4. Connect the DUT and Execute the Auto Scale” on page 304	The DUT is connected again to execute the auto scale function.
“5. Specify the Electrical Delay” on page 304	The electrical delay is specified.
“6. Measure the Deviation from a Linear Phase” on page 305	The statistics data function (peak-to-peak) is used to determine the deviation from a linear phase.

1. Connect the DUT

Connect the DUT as shown in Figure 14-21.

Figure 14-21

Connecting the DUT



e5070auj112

2. Define the Measurement Conditions

The measurement conditions are defined by following the steps described below.

Setup Description	Key Operation
Presetting	Preset - OK
Center frequency: 1.09 GHz	Center 1 . 0 9 G/n
Frequency span: 20 MHz	Span 2 0 M/μ
Measurement parameter: S_{21}	Meas - S_{21}
Data format: Expand Phase	Format - Expand Phase
Executing the Auto Scale	Scale - Auto Scale

3. Execute the Calibration

The THRU response calibration is executed.

Setup Description	Key Operation
Executing the THRU response	(A THRU standard is connected instead of a DUT) Cal - Calibrate - Response (Thru) - Thru - Done


Measurement Examples
Measuring the Deviation from a Linear Phase

4. Connect the DUT and Execute the Auto Scale

The DUT is connected again as shown in Figure 14-21 to execute the auto scale.

Setup Description	Key Operation
Executing the auto scale	Scale - Auto Scale

Figure 14-22




5. Specify the Electrical Delay

The electrical delay is entered to flatten the phase trace.

Setup Description	Key Operation
Entering the electrical delay	Scale - Electrical Delay - (Flattening a trace)

Figure 14-23

Entering the Electrical Delay



6. Measure the Deviation from a Linear Phase


The statistics data is used to read the deviation from a linear phase (peak-to-peak) (Figure 14-24).

Setup Description	Key Operation
Executing the auto scale	Scale - Auto Scale
Displaying the statistics data	Marker Fctn - Statistics (Turn it ON.)

Measurement Examples
Measuring the Deviation from a Linear Phase

Figure 14-24


Measuring the Deviation from a Linear Phase



Measuring an Unbalanced and Balanced Bandpass Filter

This section introduces an example of actually evaluating the unbalanced and balanced SAW bandpass filter with a center frequency of 942.5 MHz. Figure 14-25 shows the measurement circuit in a condition for evaluating the DUT.

Figure 14-25 Measurement Circuit



Evaluation Steps

Here, the DUT is evaluated by following the steps described in Table 14-6.

Table 14-6 Evaluating the Deviation from a Linear Phase

Step	Description
“1. Connecting the DUT” on page 308	The DUT is connected.
“2. Setting the Measuring Conditions” on page 308	The measurement conditions are defined.
“3. Performing a Calibration” on page 309	The full 3 port calibration is executed.
“4. Setting a Balance Conversion Topology” on page 310	The balance conversion topology is specified.
“5. Selecting Measurement Parameters” on page 311	The mixed-mode S-parameters are selected.
“6. Extending the Calibration Plane (removing the cause of error)” on page 312	The calibration reference plane is extended.
“7. Setting the Port Reference Impedances” on page 313	The port reference impedances are specified.


Table 14-6 Evaluating the Deviation from a Linear Phase

Step	Description
“8. Adding a Matching Circuit” on page 314	A matching circuit is added.

1. Connecting the DUT

Connect the DUT to the E5070A/E5071A using the three test ports on the instrument (Figure 14-26).

Figure 14-26 Connecting the DUT



e5070auj017

2. Setting the Measuring Conditions


Follow the procedure below to set the measurement conditions. The measurement parameters for balanced measurements should be set after unbalanced-balanced conversion. Here, set the measurement parameters for observing the characteristics achieved during unbalanced measurements.

Setting Description	Keystroke
Preset for setting	Preset - OK
Center frequency: 940 MHz	Center 9 4 0 M/μ
Frequency span: 200 MHz	Span 2 0 0 M/μ
Number of traces: 2	Display - Num of Traces - 2
Trace-1 measurement parameter: S_{21}	Meas - S21

Setting Description	Keystroke
Trace-2 measurement parameter: S_{31}	Trace Next Meas - S31
Allocate a trace to upper and lower displays.	Display - Allocate Traces - <input type="checkbox"/> × 2 <input type="checkbox"/>
Auto-scale all traces.	Scale - Auto Scale All

Figure 14-27

Results of Unbalanced Measurements



3. Performing a Calibration

Perform a full three-port calibration for the three ports to be used.

Step 1. Set the type and conditions of the calibration.

Setting Description	Keystroke
Calibration kit to use: 85033D	Cal - Cal Kit - 85033D
Type of calibration: Full three-port calibration	Calibrate - 3-Port Cal
Test ports to calibrate: 1, 2, 3	Select Ports - 1-2-3 (check only)

Step 2. Perform a reflection calibration.

Setting Description	Keystroke
Select reflection calibration.	Reflection
Perform Port 1 calibration.	(With the OPEN connected) Port 1 OPEN (With the SHORT connected) Port 1 SHORT

14. Measurement Examples

Setting Description	Keystroke
Perform Port 2 calibration.	(With the LOAD connected) Port 1 LOAD
	(With the OPEN connected) Port 2 OPEN
	(With the SHORT connected) Port 2 SHORT
Perform Port 3 calibration.	(With the LOAD connected) Port 2 LOAD
	(With the OPEN connected) Port 3 OPEN
	(With the SHORT connected) Port 3 SHORT
	(With the LOAD connected) Port 3 LOAD

Step 3. Perform a transmission calibration.

Setting Description	Keystroke
Select transmission calibration.	Return - Reflection
Perform a Port 1-to-Port 2 calibration.	(With thru connection) Port 1-2 Thru
Perform a Port 1-to-Port 3 calibration.	(With thru connection) Port 1-3 Thru
Perform a Port 2-to-Port 3 calibration.	(With thru connection) Port 2-3 Thru

Step 4. Finish the calibration.

Setting Description	Keystroke
Complete the calibration and then calculate and store calibration coefficients.	Return - Done (This causes Correction to turn ON .)
Calibration property display: ON	Return - Return - Property (Turns it ON .)

4. Setting a Balance Conversion Topology

Follow the procedure below to set the balanced conversion topology.

Table 14-7

Setting Description	Keystroke
Set port 1 on the DUT to unbalanced and port 2 on the DUT to balanced.	[Analysis] - Fixture Simulator - Topology - Device - SE-Bal (check only)
Set the connecting destination of port 1 on the DUT (unbalanced) to test port 1 of the analyzer.	Port 1 (se) - 1 (check only)
Set the connecting destination of port 2 on the DUT (balanced) to test ports 2 and 3 of the analyzer.	Port 2 (bal) - 2-3 (check only)

5. Selecting Measurement Parameters

Step 1. Display four traces.

Setting Description	Keystroke
Number of traces: 4	Display - Number of Traces - 4
Trace allocation: 4-part split	Allocate Traces - <input type="text" value="x 4"/> <input type="text" value=""/>

Step 2. Set the measurement parameter (mixed mode S-parameter) and data format for trace 1.

Setting Description	Keystroke
Fixture simulator: ON	Analysis - Fixture Simulator - Fixture Simulator (Turns it ON.)
Unbalanced-balanced conversion of trace 1: ON	BalUn (Turns it ON.)
Measurement parameter: S_{ds21}	Meas - Sds21

Step 3. Set the measurement parameter (mixed mode S-parameter) and data format for trace 2.

Setting Description	Keystroke
Unbalanced-balanced conversion of trace 2: ON	Trace Next - Analysis - Fixture Simulator - BalUn (Turns it ON.)
Measurement parameter: S_{cs21}	Meas - Scs21

Step 4. Set the measurement parameter (mixed mode S-parameter) and data format for trace 3.

Setting Description	Keystroke
Unbalanced-balanced conversion of trace 3: ON	Trace Next - Analysis - Fixture Simulator - BalUn (Turns it ON.)
Measurement parameter: S_{ss11}	Meas - Sss11
Data format: Smith chart (marker display: R+jX)	Format - Smith - R + jX

Step 5. Set the measurement parameter (mixed mode S-parameter) and data format for trace 4.

Setting Description	Keystroke
Unbalanced-balanced conversion of trace 4: ON	Trace Next - Analysis - Fixture Simulator - BalUn (Turns it ON.)
Measurement parameter: S_{dd22}	Meas - Sdd22
Data format: Smith chart (marker display: R+jX)	Format - Smith - R + jX


Measurement Examples

Measuring an Unbalanced and Balanced Bandpass Filter

Figure 14-28 shows the setting results for each parameter.

Figure 14-28

Measurement Results After Unbalanced-Balanced Conversion



6. Extending the Calibration Plane (removing the cause of error)

In this section you will use the port extension function to remove an electrical delay caused by cables or fixtures located between the calibration reference plane and the DUT to be evaluated. If you can provide a two-port Touchstone data file representing the characteristics of the network to be removed, the network removal function allows you to remove the network and extend the calibration reference plane.


Follow the procedure below to set port extension for each test port.

Setting Description	Keystroke
Port extension of test port 1: 260 ps	Cal - Port Extensions - Extension Port 1 - 2 6 G/n
Port extension of test port 2: 260 ps	Extension Port 2 - 2 6 G/n
Port extension of test port 3: 260 ps	Extension Port 3 - 2 6 G/n
Port extension: ON	Extensions (Turns it ON .)

Figure 14-29 shows the results of extension of the calibration reference plane.

Figure 14-29

Results of Extending the Calibration Reference Plane



7. Setting the Port Reference Impedances

With the reference impedances of two test ports in unbalanced measurements set to Z_0 , conversion of those ports into balanced ports causes the impedance of the balanced ports' common mode to be automatically set to $Z_{0/2}$ and the impedance of their differential mode to be automatically set to $2Z_0$.

Step 1. Set the port reference impedance of port 1 on the DUT (unbalanced) to 50 Ω .

Setting Description	Keystroke
Reference impedance of test port 1: 50 Ω	Analysis - Fixture Simulator - Port Z conversion - Port 1 Z0 - <input type="text" value="5"/> <input type="text" value="0"/> <input type="text" value="x1"/>

Step 2. In order to set the impedance of the differential mode of port 2 on the DUT (balanced) to 200 Ω , set the impedances of two unbalanced ports before conversion each to 100 Ω .

Setting Description	Keystroke
Reference impedance of test port 2: 100 Ω	Port 2 Z0 - <input type="text" value="1"/> <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="x1"/>
Reference impedance of test port 3: 100 Ω	Port 3 Z0 - <input type="text" value="1"/> <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="x1"/>

NOTE

Always set the reference impedances of the two test ports before balanced conversion to the same value.

Measurement Examples

Measuring an Unbalanced and Balanced Bandpass Filter

Step 3. Turn on the port reference impedance conversion function.


Setting Description	Keystroke
Port reference impedance conversion: ON	Port Z Conversion (Turns it ON.)

The reference impedance of the command mode of port 2 on the DUT is set to 50 Ω. The impedance of the differential mode of that port may be set and modified independent of setting the two port reference impedances before balanced conversion. For more information, see “Converting reference impedance of balanced port” on page 165.

Figure 14-30 shows the results of port reference impedance conversion.

Figure 14-30

Results of Port Reference Impedance Conversion



8. Adding a Matching Circuit


Add an inductance of 47 nH in parallel to port 2 on the DUT (balanced). It is also possible to add a matching circuit to the port before unbalanced-balanced conversion. For more information, see “Determining the Characteristics that Result from Adding a Matching Circuit to a Differential Port” on page 167.

Setting Description	Keystroke
Selecting a matching circuit: Shunt L - Shunt C	Return (or Analysis) - Fixture Simulator - Diff. Matching - Select Circuit - Shunt L-Shunt C
Inductance: 47 nH	L - 4 7 G/n
C=0, G=0, R=0	(checks that C , G , and R have been set to 0.)
Differential matching circuit function: ON	Diff. Matching (Turns it ON.)

Figure 14-31 shows the results of adding a matching circuit.

Figure 14-31

Results of Adding a Matching Circuit (47 nH)



Measuring parameters with cable

This section introduces an example of how to detect the location of a mismatch that occurs in a cable using the time domain function.

Overview of evaluation procedure

In this example, a DUT is evaluated according to the procedure shown in Table 14-8.

Table 14-8 Evaluation procedure for deviation from linear phase

Procedure	Description
“1. Setting the measurement conditions” on page 316	Set the measurement conditions.
“2. Executing calibration” on page 316	Execute calibration.
“3. Connecting the DUT” on page 317	Connect the DUT.
“4. Auto scale” on page 317	Execute auto scale.
“5. Setting the time domain function” on page 318	Set the time domain function.

1. Setting the measurement conditions

Follow these steps to set the measurement conditions:

Description of setting	Key stroke
Presetting	Preset - OK
Stop frequency: 3 GHz	Start 3 G/n
Number of points: 201	Sweep Setup - Points - 2 0 1 x1
Specifying the low pass mode sweep condition	Analysis - Transform - Set Freq Low Pass
Measurement parameter: S11	Meas - S11

2. Executing calibration


According to “1-Port Calibration (Reflection Test)” on page 91, execute full 1-port calibration on port 1.

3. Connecting the DUT

Connect the DUT as shown in Figure 14-32.

Figure 14-32

Connecting the DUT



e5070aue210

4. Auto scale

Execute auto scale.

Description of setting


Key stroke

Executing auto scale

Scale - Auto Scale

Figure 14-33

Response in frequency domain



e5070auj203

14. Measurement Examples


5. Setting the time domain function

Set the conversion function to display the response in time domain. If you enable this setting, the response in time domain is displayed as shown in Figure 14-34. A peak indicating a small mismatch appears at the location of the connector.

Description of setting	Key stroke
Data format: real	Format - Real
Setting the transformation type to low pass impulse	Analysis - Transform - Lowpass Imp.
Setting the window type to maximum.	Window - Maximum
Setting the display range to from 0 s to 10 ns	Start - 0 x1 Stop - 2 0 G/n
Enabling the transformation function	Transform (set to ON)
Executing auto scale	Scale - Auto Scale

Figure 14-34

Response in time domain




Evaluating transmission characteristics of a front end module

This example shows how to measure the transmission characteristics of a 6-port front end module shown in Figure 14-35 using the E5070A/E5071A and the E5091A.

Figure 14-35

Front end module



e5070auj199

Overview of evaluation procedure

In this example, a DUT is evaluated according to the procedure shown in Table 14-9.

Table 14-9

Evaluation procedure for 6-port front end module

Procedure	Description
“1. Determining measurement conditions” on page 320	Determine the measurement conditions such as the sweep conditions and measurement ports.
“2. Setting channel window allocation” on page 320	Set the allocation of the channel windows on the screen.
“3. Setting the test ports” on page 320	Determine the test port assignment for each channel.
“4. Setting control line” on page 321	Set the E5091A's control line.
“5. Setting sweep conditions” on page 321	Set the sweep range and the number of points.
“6. Setting balance conversion topology” on page 322	Set the balance port and unbalance port assignment.
“7. Selecting measurement parameter” on page 322	Set the measurement parameter.

Table 14-9 Evaluation procedure for 6-port front end module

Procedure	Description
“8. Executing calibration” on page 322	Perform calibration using 4-port ECal.
“9. Connecting DUT” on page 324	Connect the DUT.
“10. Executing measurement” on page 324	Execute the measurement and perform the auto scale.

1. Determining measurement conditions




In this example, perform measurement under the measurement conditions in Table 14-9.

Table 14-10 Sweep conditions

Channel	Start frequency	Stop frequency	NOP	Test port assignment	Control line	Meas. parameter	Calibration	
							Type	Port
1	400 MHz	1.4 GHz	201	Port 1 - Port A Port 2 - Port T1	Line 1: Low Line 2: High	S12	Full 2-Port	1,2
2	880 MHz	1 GHz	101	Port 3 - Port R1+ Port 4 - Port R1-	Line 1: Low Line 2: Low	Sds21	Full 3-Port	1,3,4
3	1.34 GHz	2.34 GHz	201	Port 1 - Port A Port 2 - Port T2	Line 1: High Line 2: Low	S12	Full 2-Port	1,2
4	1.665 GHz	2.015 GHz	101	Port 3 - Port R2+ Port 4 - Port R1-	Line 1: Low Line 2: Low	S31	Full 2-Port	1,3


2. Setting channel window allocation

Make the setting to split the screen into 2 lines and 2 columns to assign channel windows after preset.

Description of setting	Key stroke
Executing preset	 - OK
Allocating channel windows	 - Allocate Channels - 

3. Setting the test ports

Step 1. Display the E5091A setup menu and display the E5091A property.

Description of setting	Key stroke
Displaying the E5091A setup menu	 - E5091A Setup
Displaying the E5091A property	E5091A Property

Step 2. Select the test ports assigned to ports 1 to 4 for channel 1.

Description of setting	Key stroke
Select the ID of the E5091A	Select ID - 1
Assign test port A to port 1.	Port1 - A
Assign test port T1 to port 2.	Port2 - T1
Assign test port R1+ to port 3.	Port3 - R1+
Assign test port R1- to port 4.	Port4 - R1-

Step 3. Assign test ports for channels 2, 3, and 4. Press the Channel Next key to switch the active channel and then make the setting in the same way as Step 2.

Step 4. Enable the control of the E5091A.

Description of setting	Key stroke
Enable the control of the E5091A.	E5091A Control (Set it to ON .)

4. Setting control line

Step 1. Set the bits of the control line for channel 1.

Description of setting	Key stroke
Set channel 1 to the active channel.	Channel Next
Line 1: Low	Control Line (check only)
Line 2: High	Control Line - Line 1 (Set it to High .)

Step 2. Set the control line for channels 2, 3, and 4 also according to the same procedure as in Step 1.

5. Setting sweep conditions

Step 1. Set the sweep conditions for channel 1.

Description of setting	Key stroke
Set channel 1 to the active channel.	Channel Next
Start frequency: 400 MHz	Start 4 0 0 M/μ
Stop frequency: 1.4 GHz	Stop 1 . 4 G/n
Number of points: 201	Sweep Setup - Pooint - 2 0 1 x1

Step 2. Set the sweep conditions for channels 2, 3, and 4 also according to the same procedure as in Step 1.

6. Setting balance conversion topology

For channel 2, set the balance conversion topology in order to perform measurement including the balanced port.

Description of setting	Key stroke
Set channel 2 to the active channel.	Channel Next (Press it until channel 2 is activated.)
Set DUT port 1 to unbalance and DUT port 2 to balance.	Analysis - Fixture Simulator - Topology - Device - SE-Bal
Set the destination to which DUT port 1 (unbalance) is connected to test port 1 of the analyzer.	Port 1 (se) - 1
Set the destination to which DUT port 2 (balance) is connected to test ports 3 and 4 of the analyzer.	Port 2 (bal) - 3-4
Unbalance-balance conversion for trace 1: ON	BalUn (Set it to ON .)
Fixture simulator: ON	Fixture Simulator (Set it to ON .)

7. Selecting measurement parameter

Set the measurement parameter for channel 1.

Step 1. Select the measurement parameter for trace 1 of channel 1.

Description of setting	Key stroke
Set channel 1 to the active channel.	Channel Next (Press it until channel 1 is activated.)
Measurement parameter for trace 1: S12	Meas - S12

NOTE

The subscript of the measurement parameter means the test port of the E5070A/E5071A. Check the test port assignment and select the measurement parameter.

Step 2. Set the measurement parameter for channels 2, 3, and 4 according to the same procedure as in Step 1.

8. Executing calibration

Step 1. Display the ECal menu.


Description of setting	Key stroke
Display the ECal menu.	Cal - ECal

Step 2. Set channel 1 to the active channel.

Description of setting	Key stroke
Switch the active channel.	Channel Next

Step 3. Check the test ports assigned to ports 1 to 4 in the E5091A property and connect the 4-port ECal module to those ports.

Figure 14-36 **Connecting the 4-port ECal**



Step 4. Execute the calibration.

Description of setting	Key stroke
Select the full 2-port calibration.	2-Port ECal
Select the port and execute the calibration.	1-2

Step 5. Perform the calibration for channels 2, 3, and 4 according to the same procedure as in Step 2 to Step 4.

NOTE


Because the test port assignment setting for channels 1 and 2 and that for channels 3 and 4 are the same, you need not to change the connection of ECal.

9. Connecting DUT

Connect the DUT as shown in Figure 14-37.

Figure 14-37

Connecting 6-port front end module



e5070aue197

10. Executing measurement

Step 1. Display the trigger menu.

Description of setting

Key stroke

Display the trigger menu.

Trigger

Step 2. Set the trigger source to "manual."

Description of setting	Key stroke
Set the trigger source to "manual."	Trigger Source - Manual

Step 3. Set the trigger mode for channel 1 to "continuous."

Description of setting	Key stroke
Set channel 1 to the active channel.	<input type="button" value="Channel Next"/>
Set the trigger mode to "continuous."	Continuous

Step 4. Set the trigger mode for channels 2, 3, and 4 to "continuous" according to the same procedure as in Step 3.

Step 5. Execute the measurement.

Description of setting	Key stroke
Generate a trigger event.	Trigger

Step 6. Repeat the following procedure to execute the auto scale for all the channels.


Description of setting	Key stroke
Set the active channel.	<input type="button" value="Channel Next"/>
Execute the auto scale.	<input type="button" value="Scale"/> - Auto Scale

Step 7. After all the procedures are complete, the screen as shown in Figure 14-38 appears.

Measurement Examples
Evaluating transmission characteristics of a front end module

Figure 14-38

Example of measuring a front end module



e5070auj201

15

Specifications and Supplemental Information

This chapter provides specifications and supplemental information for the Agilent E5070A/E5071A Network Analyzer.

Definitions

All specifications apply over a 5°C to 40°C range (unless otherwise stated) and 90 minutes after the instrument has been turned on.

Specification (spec.): Warranted performance. Specifications include guardbands to account for the expected statistical performance distribution, measurement uncertainties, and changes in performance due to environmental conditions.

Supplemental information is intended to provide information that is helpful for using the instrument but that is not guaranteed by the product warranty. This information is denoted as either typical or nominal.

Typical (typ.): Expected performance of an average unit that does not include guardbands. It is not guaranteed by the product warranty.

Nominal (nom.): A general, descriptive term that does not imply a level of performance. It is not guaranteed by the product warranty.

Corrected System Performance

The specifications in this section apply for measurements made with the Agilent E5070A/E5071A Network Analyzer under the following conditions:

- No averaging applied to data
- Environmental temperature of 23°C ±5°C, with less than 1°C deviation from the calibration temperature
- Response and isolation calibration not omitted

Table 15-1 System Dynamic Range

Description	Specification	Supplemental Information	
System Dynamic Range ^{*1*2}			
300 kHz to 3 MHz	IF bandwidth = 3 kHz	85 dB	
3 MHz to 1.5 GHz		95 dB	98 dB
1.5 GHz to 4 GHz		97 dB	100 dB
4 GHz to 6 GHz		95 dB	97 dB
6 GHz to 7.5 GHz		92 dB	95 dB
7.5 GHz to 8.5 GHz		85 dB	88 dB
300 kHz to 3 MHz	IF bandwidth = 10 Hz	110 dB	
3 MHz to 1.5 GHz		120 dB	123 dB
1.5 GHz to 4 GHz		122 dB	125 dB
4 GHz to 6 GHz		120 dB	122 dB
6 GHz to 7.5 GHz		117 dB	120 dB
7.5 GHz to 8.5 GHz		110 dB	113 dB

*1. The test port dynamic range is calculated as the difference between the test port rms noise floor and the source maximum output power. The effective dynamic range must take measurement uncertainty and interfering signals into account.

*2. May be limited to 90 dB at particular frequencies below 350MHz or above 4.2GHz due to spurious receiver residuals.

Table 15-2 Corrected System Performance With Type-N Device Connectors, 85032F Calibration Kit

Network analyzer: E5070A/E5071A, Calibration kit: 85032F (Type-N, 50 Ω), Calibration: full 2-port			
IF bandwidth = 10 Hz, No averaging applied to data, Environmental temperature = 23°C \pm 5°C with <1°C deviation from calibration temperature, Isolation calibration not omitted			
Description	Specification (dB)		
	3 MHz to 3 GHz	3 GHz to 6 GHz	6 GHz to 8.5 GHz
Directivity	49	40	38
Source Match	41	36	35
Load Match	49	40	38
Reflection Tracking	± 0.011	± 0.032	± 0.054
Transmission Tracking	± 0.016	± 0.062	± 0.073

Transmission Uncertainty (Specification)	
<p>Magnitude</p>	<p>Phase</p>

Reflection Uncertainty (Specification)	
<p>Magnitude</p>	<p>Phase</p>





Table 15-3 Corrected System Performance With Type-N Device Connectors, 85092C Electronic Calibration Module

Network analyzer: E5070A/E5071A, Calibration module: 85092C (Type-N, 50 Ω) electronic calibration (ECal) module, Calibration: full 2-port			
IF bandwidth = 10 Hz, No averaging applied to data, Environmental temperature = 23°C±5°C with <1°C deviation from calibration temperature, Isolation calibration not omitted			
Description	Specification (dB)		
	3 MHz to 3 GHz	3 GHz to 6 GHz	6 GHz to 8.5 GHz
Directivity	52	52	47
Source Match	45	41	36
Load Match	47	44	39
Reflection Tracking	±0.040	±0.060	±0.070
Transmission Tracking	±0.039	±0.069	±0.136
Transmission Uncertainty (Specification)			
Reflection Uncertainty (Specification)			

Table 15-4 Corrected System Performance With 3.5 mm Device Connector Type, 85033E Calibration Kit

Network analyzer: E5070A/E5071A, Calibration kit: 85033E (3.5 mm, 50 Ω), Calibration: full 2-port			
IF bandwidth = 10 Hz, No averaging applied to data, Environmental temperature = 23°C±5°C with <1°C deviation from calibration temperature, Isolation calibration not omitted			
Description	Specification (dB)		
	3 MHz to 3 GHz	3 GHz to 6 GHz	6 GHz to 8.5 GHz
Directivity	46	38	38
Source Match	43	37	36
Load Match	46	38	38
Reflection Tracking	±0.006	±0.009	±0.010
Transmission Tracking	±0.016	±0.065	±0.069
Transmission Uncertainty (Specification)			
Reflection Uncertainty (Specification)			

Table 15-5 Corrected System Performance With 3.5 mm Device Connector Type, 85093C Electronic Calibration Module

Network analyzer: E5070A/E5071A, Calibration module: 85093C (3.5 mm, 50 Ω) electronic calibration (ECal) module, Calibration: full 2-port			
IF bandwidth = 10 Hz, No averaging applied to data, Environmental temperature = 23°C±5°C with <1°C deviation from calibration temperature, Isolation calibration not omitted			
Description	Specification (dB)		
	3 MHz to 3 GHz	3 GHz to 6 GHz	6 GHz to 8.5 GHz
Directivity	52	51	47
Source Match	44	39	34
Load Match	47	44	40
Reflection Tracking	±0.030	±0.050	±0.070
Transmission Tracking	±0.039	±0.069	±0.117
Transmission Uncertainty (Specification)			
 <p>Magnitude Uncertainty [dB] Transmission Coefficient [dB] S11=S22=0 Source Power = -10 dBm</p>		 <p>Phase Uncertainty [degrees] Transmission Coefficient [dB] S11=S22=0 Source Power = -10 dBm</p>	
Reflection Uncertainty (Specification)			
 <p>Magnitude Uncertainty [linear] Reflection Coefficient [linear] S21=S12=0 Source Power = -10 dBm</p>		 <p>Phase Uncertainty [degrees] Reflection Coefficient [linear] S21=S12=0 Source Power = -10 dBm</p>	

Uncorrected System Performance

Table 15-6 **Uncorrected System Performance**

Description	Specification		
	3 MHz to 3 GHz	3 GHz to 6 GHz	6 GHz to 8.5 GHz
Directivity	10 dB	6 dB	4 dB
Source Match	15 dB	10 dB	10 dB
Load Match	17 dB	12 dB	12 dB
Transmission Tracking	± 3.0 dB, typical	± 2.0 dB, typical	± 4.0 dB, typical
Reflection Tracking	± 3.0 dB, typical	± 2.0 dB, typical	± 4.0 dB, typical

Test Port Output (Source)

Table 15-7 Test Port Output Frequency

Description	Specification	Supplemental Information
Range E5070A E5071A	300 kHz to 3 GHz 300 kHz to 8.5 GHz	
Resolution	1 Hz	
Source Stability Standard Option 1E5		±5 ppm (5°C to 40°C, typical) ±0.05 ppm (23°C±5°C, typical) ±0.5 ppm/year (typical)
CW Accuracy Standard Option 1E5	±5 ppm, 23°C±5°C ±1 ppm, 23°C±5°C	

Table 15-8 Test Port Output Power*¹

Description	Specification	Supplemental Information
Level Accuracy (at 23°C±5°C) 300 kHz to 10 MHz 10 MHz to 8.5 GHz Level Accuracy (high temperature mode: ON) 300 kHz to 8.5 GHz Level Accuracy (swept mode: ON) 300 kHz to 4.2 GHz 4.2 GHz to 8.5 GHz	±0.650 dB (at 0 dBm, 50 MHz absolute) ±1.0 dB (at 0 dBm, relative to 50 MHz reference)	±1.0 dB (at 0 dBm, relative to 50 MHz reference) ±0.8 dB (at 0 dBm, 50 MHz absolute) ±1.5 dB (at 0 dBm, relative to 50 MHz reference) ±2.5 dB (at 0 dBm, relative to 50 MHz reference) ±3.5 dB (at 0 dBm, relative to 50 MHz reference)
Level Linearity (23°C±5°C) 10 MHz to 4.2 GHz 4.2 GHz to 8.5 GHz Level Linearity (high temperature mode: ON) 300 kHz to 4.2 GHz 4.2 GHz to 8.5 GHz	±0.75 dB (at -15 dBm to 0 dBm) ±1.5 dB (at -10 dBm to 0 dBm) ±3 dB (at -15 dBm to 0 dBm)	±1.5 dB (at -15 dBm to 0 dBm) ±1.5 dB (at -15 dBm to 0 dBm) ±2.0 dB (at -10 dBm to 0 dBm) ±3.5 dB (at -15 dBm to 0 dBm)

Specifications and Supplemental Information
Test Port Output (Source)

Table 15-8 Test Port Output Power^{*1}

Description	Specification	Supplemental Information
Level Linearity (swept mode: ON) 300 kHz to 4.2 GHz 4.2 GHz to 8.5 GHz		±1.5 dB (at -15 dBm to 0 dBm) ±3 dB (at -5 dBm to 0 dBm) ±5 dB (at -10 dBm to 0 dBm) ±8 dB (at -15 dBm to 0 dBm)
Range Standard Extended Power Range (with option 214, 314, 414)	-15 dBm to 0 dBm	-50 dBm to 0 dBm (non-harmonics spurious may limit power range)
Level Resolution	0.05 dB	

*1. Source output performance on port 1 only. Other port output performance is typical.

Table 15-9 Test Port Output Signal Purity

Description	Specification	Supplemental Information
Harmonics (2nd or 3rd) 10 MHz to 2 GHz 2 GHz to 3 GHz 3 GHz to 8.5 GHz		< -25 dBc (at -5 dBm, typical) < -15 dBc (at -5 dBm, typical) < -10 dBc (at -5 dBm, typical)
Non-Harmonic Spurious 10 MHz to 3 GHz 3 GHz to 8.5 GHz		< -25 dBc (at -5 dBm, typical) < -10 dBc (at -5 dBm, typical)

Test Port Input

Table 15-10 Test Port Input Levels

Description	Specification	Supplemental Information
Maximum Test Port Input Level		
300 kHz to 8.5 GHz	+0 dBm max.	
Damage Level		
300 kHz to 8.5 GHz		+20 dBm, ±25 VDC, typical
Crosstalk*¹		
3 MHz to 3 GHz	-120 dB	
3 GHz to 6 GHz	-110 dB	
6 GHz to 7.5 GHz	-100 dB	
7.5 GHz to 8.5 GHz	-90 dB	

*1. Response calibration not omitted.

Table 15-11 Test Port Input (Trace Noise)

Description	Specification	Supplemental Information
Trace Noise*¹ Magnitude		
300 kHz to 3 MHz		5 mdB rms (at IFBW = 3 kHz, typical) 8 mdB rms (at IFBW = 3 kHz, high temperature mode: ON, typical)
3 MHz to 4.2 GHz	1 mdB rms (at IFBW = 3 kHz)	4 mdB rms (at IFBW = 3 kHz, high temperature mode: ON, typical)
4.2 GHz to 7.5 GHz	3 mdB rms (at IFBW = 3 kHz)	6 mdB rms (at IFBW = 3 kHz, high temperature mode: ON, typical)
7.5 GHz to 8.5 GHz	5 mdB rms (at IFBW = 3 kHz)	8 mdB rms (at IFBW = 3 kHz, high temperature mode: ON, typical)

Table 15-11 Test Port Input (Trace Noise)

Description	Specification	Supplemental Information
Trace Noise ^{*1} Phase		
300 kHz to 3 MHz		0.035 ° rms (at IFBW = 3 kHz, typical) 0.05 ° rms (at IFBW = 3 kHz, high temperature mode: ON, typical)
3 MHz to 4.2 GHz		0.007 ° rms (at IFBW = 3 kHz, typical) 0.02 ° rms (at IFBW = 3 kHz, high temperature mode: ON, typical)
4.2 GHz to 7.5 GHz		0.021 ° rms (at IFBW = 3 kHz, typical) 0.035 ° rms (at IFBW = 3 kHz, high temperature mode: ON, typical)
7.5 GHz to 8.5 GHz		0.035 ° rms (at IFBW = 3 kHz, typical) 0.05 ° rms (at IFBW = 3 kHz, high temperature mode: ON, typical)

*1. Trace noise is defined as a ratio measurement of a through, with the source set to 0 dBm.

Table 15-12 Test Port Input (Stability)

Description	Specification	Supplemental Information
Stability Magnitude^{*1}		
3 MHz to 3 GHz		0.005 dB/°C (at 23 °C±5°C, typical)
3 GHz to 6 GHz		0.01 dB/°C (at 23 °C±5°C, typical)
6 GHz to 8.5 GHz		0.04 dB/°C (at 23 °C±5°C, typical)
Stability Phase^{*1}		
3 MHz to 3 GHz		0.1 °/°C (at 23 °C±5°C, typical)
3 GHz to 6 GHz		0.2 °/°C (at 23 °C±5°C, typical)
6 GHz to 8.5 GHz		0.8 °/°C (at 23 °C±5°C, typical)

*1. Stability is defined as a ratio measurement at the test port.


Table 15-13 Test Port Input (Dynamic Accuracy)

Accuracy of the test port input power reading is relative to -20 dBm reference input power level.	
Specification	Supplemental Information
<p>Magnitude</p> <p>Mag [dB]</p> <p>Test Port Power [dBm]</p>	<p>Phase</p> <p>Phase [deg]</p> <p>Test Port Power [dBm]</p>

Table 15-14 Test Port Input (Group Delay)^{*1}

Description	Specification	Supplemental Information
Aperture (selectable)	(frequency span)/(number of points – 1)	
Maximum Aperture	25% of frequency span	
Minimum Delay		Limited to measuring no more than 180° of phase change within the minimum aperture.
Accuracy		See graph below, typical

The following graph shows group delay accuracy with type-N full 2-port calibration and a 10 Hz IF bandwidth. Insertion loss is assumed to be < 2 dB.



In general, the following formula can be used to determine the accuracy, in seconds, of specific group delay measurement:

$$\pm \text{Phase Accuracy (deg)} / [360 \times \text{Aperture (Hz)}]$$

*1. Group delay is computed by measuring the phase change within a specified step (determined by the frequency span and the number of points per sweep).

General Information

Table 15-15 System Bandwidths

Description	Supplemental Information
IF Bandwidth Settings	
Range	10 Hz to 100 kHz Nominal settings are: 10, 15, 20, 30, 40, 50, 70, 100, 150, 200, 300, 400, 500, 700, 1k, 1.5k, 2k, 3k, 4k, 5k, 7k, 10k, 15k, 20k, 30k, 40k, 50k, 70k, 100kHz

Table 15-16 Front Panel Information

Description	Supplemental Information
RF Connectors	
Type	Type-N, female, 50 Ω (nominal)
Display	
Size	10.4 in TFT color LCD
Resolution	VGA (640 \times 480)

Table 15-17 Rear Panel Information

Description	Supplemental Information
External Trigger Connector	
Type	BNC, female
Input level	LOW threshold voltage: 0.5 V HIGH threshold voltage: 2.1 V Input level range: 0 to + 5 V
Pulse width	≥ 2 μsec, typical
Polarity	Negative (downward) only
External Reference Signal Input Connector	
Type	BNC, female
Input Frequency	10 MHz ± 10 ppm, typical
Input Level	0 dBm ± 3 dB, typical
Internal Reference Signal Output Connector	
Type	BNC, female
Output Frequency	10 MHz ± 10 ppm, typical
Signal Type	Sine Wave, typical
Output Level	0 dBm ± 3 dB into 50 Ω, typical
Output Impedance	50 Ω, nominal
VGA Video Output	15-pin mini D-Sub; female; drives VGA compatible monitors
GPIO	24-pin D-Sub (Type D-24), female; compatible with IEEE-488
Parallel Port	36-pin D-Sub (Type 1284-C), female; provides connection to printers
USB Port	
Contact 1	Universal Serial Bus jack, Type A configuration (4 contacts inline, contact 1 on left); female; provides connection to printer, ECal module or multiport test set Vcc: 4.75 to 5.25 VDC, 500 mA, maximum -Data +Data Ground
Contact 2	
Contact 3	
Contact 4	
LAN	10/100BaseT Ethernet, 8-pin configuration; auto selects between the two data rates
Handler I/O Port	36-pin D-sub, female; provides connection to handler system

Table 15-17 Rear Panel Information

Description	Supplemental Information
Line Power *1	
Frequency	47 Hz to 63 Hz
Voltage	90 to 132 VAC, or 198 to 264 VAC (automatically switched)
VA Max	350 VA max.

*1. A third-wire ground is required.

Table 15-18 EMC and Safety





Description	Supplemental Information
EMC	
 ISM 1-A	European Council Directive 89/336/EEC EN / IEC 61326-1:1997+A1:1998 CISPR 11:1997+A1:1999 / EN 55011:1998+A1:1999 Group 1, Class A IEC 61000-4-2:1995 / EN 61000-4-2:1995 +A1:1998 4 kV CD / 4 kV AD IEC 61000-4-3:1995 / EN 61000-4-3:1996 +A1:1998 3 V/m, 80-1000 MHz, 80% AM IEC 61000-4-4:1995 / EN 61000-4-4:1995 1 kV power / 0.5 kV Signal IEC 61000-4-5:1995 / EN 61000-4-5:1995 0.5 kV Normal / 1 kV Common IEC 61000-4-6:1996 / EN 61000-4-6:1996 3 V, 0.15-80 MHz, 80% AM IEC 61000-4-11:1994 / EN 61000-4-11:1994 100% 1cycle Canada ICES001:1998 Note: The performance of EUT will be within the specification over the RF immunity tests according to EN 61000-4-3 or EN 61000-4-6 except under the coincidence of measurement frequency and interference frequency.
ICES/NMB-001	This ISM device complies with Canadian ICES-001. Cet appareil ISM est conforme à la norme NMB-001 du Canada.
 N10149	AS/NZS 2064.1/2 Group 1, Class A
Safety	
 ISM 1-A	European Council Directive 73/23/EEC IEC 61010-1:1990+A1+A2 / EN 61010-1:1993+A2 INSTALLATION CATEGORY II, POLLUTION DEGREE 2 INDOOR USE IEC60825-1:1994 CLASS 1 LED PRODUCT
 LR95111C	CAN/CSA C22.2 No. 1010.1-92

Table 15-19 Analyzer Environment and Dimensions

Description	Supplemental Information
Operating Environment	
Temperature	+5 °C to +40 °C
Error-Corrected Temperature Range	23 °C ± 5 °C with < 1°C deviation from calibration temperature
Humidity	< 90% at +40 °C (non-condensing)
Altitude	0 to 2,000 m (0 to 6,561 feet)
Vibration	0.5 G maximum, 5 Hz to 500 Hz
Non-Operating Storage Environment	
Temperature	-25 °C to +65 °C
Humidity	< 95% at +65 °C (non-condensing)
Altitude	0 to 4,572 m (0 to 15,000 feet)
Vibration	0.5 G maximum, 5 Hz to 500 Hz
Dimensions	See Figure 15-1 through Figure 15-3.
Weight	
Net	16 kg (Option 213/214, nominal) 18 kg (Option 413/414, nominal)

Figure 15-1 Dimensions (front view, with Option 413, in millimeters, nominal)





Figure 15-2


Dimensions (rear view, with Option 1E5, in millimeters, nominal)



e5070aue002

Figure 15-3

Dimensions (side view, in millimeters, nominal)



e5070aue003

Measurement Throughput Summary

Table 15-20 Typical Cycle Time for Measurement Completion ^{*1*2} (ms)

	Number of Points			
	51	201	401	1601
Start 1 GHz, Stop 1.2 GHz, 100 kHz IF bandwidth				
Uncorrected	4	5	7	18
2-port cal	5	8	13	42
Start 300 kHz, Stop 3 GHz, 100 kHz IF bandwidth				
Uncorrected	11	12	13	22
2-port cal	19	22	24	46
Start 300 kHz, Stop 8.5 GHz, 100 kHz IF bandwidth				
Uncorrected	19	23	24	24
2-port cal	37	45	46	49

*1. Typical performance.

*2. Sweep mode: Fast swept. Analyzer display turned off with :DISP:ENAB OFF. Number of traces = 1. System error correction: OFF.

Table 15-21 Typical Cycle Time for Measurement Completion ^{*1*2} (ms)

	Number of Points			
	51	201	401	1601
Start 1 GHz, Stop 1.2 GHz, 100 kHz IF bandwidth				
Uncorrected	4	6	7	21
2-port cal	5	9	15	54
Start 300 kHz, Stop 3 GHz, 100 kHz IF bandwidth				
Uncorrected	11	12	13	23
2-port cal	19	22	24	54
Start 300 kHz, Stop 8.5 GHz, 100 kHz IF bandwidth				
Uncorrected	19	24	24	25
2-port cal	37	45	46	56

*1. Typical performance.

*2. Sweep mode: Fast swept. Analyzer display turned off with :DISP:ENAB OFF. Number of traces = 1. System error correction: ON.

Table 15-22 Typical Cycle Time for Measurement Completion^{*1*2} (ms)

	Number of Points			
	51	201	401	1601
Start 1 GHz, Stop 1.2 GHz, 100 kHz IF bandwidth				
Uncorrected	7	17	29	90
2-port cal	12	32	55	178
Start 300 kHz, Stop 3 GHz, 100 kHz IF bandwidth				
Uncorrected	13	26	42	129
2-port cal	25	49	82	257
Start 300 kHz, Stop 8.5 GHz, 100 kHz IF bandwidth				
Uncorrected	15	29	49	146
2-port cal	28	56	95	289

*1. Typical performance.

*2. Sweep mode: Std Stepped. Analyzer display turned off with :DISP:ENAB OFF. Number of traces = 1. System error correction: ON

Table 15-23 Cycle Time (ms)^{*1*2} vs. Number of Points

Number of Points	Sweep mode: Fast Swept System error correction: OFF	Sweep mode: Fast Swept System error correction: ON	Sweep mode: Std Stepped System error correction: ON
3	4	4	4
11	4	4	4
51	4	4	7
101	4	5	11
201	5	6	17
401	8	7	29
801	11	12	52
1601	18	21	90

*1. Typical performance.

*2. Start 1 GHz, Stop 1.2 GHz, 100 kHz IF bandwidth, Error correction: OFF, Display update: OFF, Number of traces = 1.

Table 15-24 Data Transfer Time^{*1} (ms)

	Number of Points			
	51	201	401	1601
SCPI over GPIB (program executed on external PC)^{*2}				
64-bit floating point	7	20	40	150
ASCII	20	75	149	587
SCPI over 100 Mbps LAN (program executed on external PC)^{*2}				
REAL 64	2	2	3	5
ASCII	37	140	274	1066
COM (program executed in the analyzer)^{*3}				
Variant type	1	1	1	1

*1. Typical performance.

*2. Measured using a VEE 5.0 program running on a 733 MHz Pentium III HP Kayak, Transferred complex S_{11} data, using :CALC:DATA?SDATA.

*3. Measured using an E5070A/E5071A VBA macro running inside the analyzer. Transferred complex S_{11} data.

Measurement capabilities

Number of measurement channels	Up to 9 independent measurement channels. A measurement channel is coupled to stimulus response settings including frequency, IF bandwidth, power level, and number of points.
Number of display windows	Each measurement channel has a display window. Up to 9 display windows (channels) can be displayed.
Number of traces	Up to 9 data traces and 9 memory traces per channel. 81 total traces and 81 memory traces can be displayed.
Measurement choices	Opt. 213/214: S_{11} , S_{21} , S_{12} , S_{22} Opt. 313/314: S_{11} , S_{21} , S_{31} , S_{12} , S_{22} , S_{32} , S_{13} , S_{23} , S_{33} , Mixed-mode S-parameters, Balance parameters, CMRR Opt. 413/414: S_{11} , S_{21} , S_{31} , S_{41} , S_{12} , S_{22} , S_{32} , S_{42} , S_{13} , S_{23} , S_{33} , S_{43} , S_{14} , S_{24} , S_{34} , S_{44} , Mixed mode S-parameters, Balance parameters, CMRR
Measurement parameter conversion	Available to convert S-parameters into reflection impedance, transmission impedance, reflection admittance, transmission admittance, and 1/S.
Data formats	Log magnitude, linear magnitude, phase, extended phase, positive phase, group delay, SWR, real, imaginary, Smith chart, polar.
Data markers	10 independent markers per trace. Reference marker available for delta marker operation. Smith chart format includes 5 marker formats: linear magnitude/phase, log magnitude/phase, real/imaginary, $R + jX$, and $G + jB$. Polar chart format includes 3 marker formats: linear magnitude/phase, log magnitude/phase, and real/imaginary.
Marker functions	
Marker search	Max value, Min value, peak, peak left, peak right, target, target left, target right, bandwidth parameters with user-defined bandwidth values.
Marker-to functions	Set start, stop, center to active marker stimulus value; set reference to active marker response value.
Tracking	Performs marker search continuously or on demand.
Time domain functions	
Transformation	Selectable transformation type from bandpass, lowpass impulse, lowpass step. Selectable window from maximum, normal and minimum.
Gated functions	Selectable gated filter type from bandpass, notch. Selectable gate shape from maximum, normal and wide.

Source control

Measured number of points per sweep	User definable from 2 to 1601.
Sweep mode	Normal stepped, normal swept, fast stepped and fast swept.
Sweep type	Linear sweep, segment sweep and log sweep.
Segment sweep	Define independent sweep segments. Set number of points, test port power levels, IF bandwidth, delay time, sweep time and sweep mode independently for each segment.
Sweep trigger	Set to continuous, hold, or single, sweep with internal, external, manual, or bus trigger.
Power	Set source power from -15 dBm (-50 dBm for option 214/314/414) to 0 dBm.

Trace functions

Display data	Display current measurement data, memory data, or current measurement and memory data simultaneously.
Trace math	Vector addition, subtraction, multiplication or division of measured complex values and memory data.
Title	Add custom title to each channel window. Titles are printed on hardcopies of displayed measurements.
Autoscale	Automatically selects scale resolution and reference value to vertically center the trace.
Electrical delay	Offset measured phase or group delay by a defined amount of electrical delay, in seconds.
Phase Offset	Offset measured phase or group delay by a defined amount in degrees.
Statistics	Calculates and displays mean, standard deviation and peak-to-peak deviation of the data trace.

Data accuracy enhancement

Measurement calibration	Measurement calibration significantly reduces measurement uncertainty due to errors caused by system directivity, source and load match, tracking and crosstalk. Full 2-port, 3-port, or 4-port calibration removes all the systematic errors for the related test ports to obtain the most accurate measurements.
Calibration types available	
Response	Simultaneous magnitude and phase correction of frequency response errors for either reflection or transmission measurements.
Response and isolation	Compensates for frequency response and crosstalk errors of transmission measurements.
One-port calibration	Available on test port 1, port 2, port 3, or port 4 to correct for directivity, frequency response and source match errors.
Full 2-port/3-port/4-port calibration TRL calibration	Compensates for directivity, source match, reflection tracking, load match, transmission tracking and crosstalk. Crosstalk calibration can be omitted.
Interpolated error correction	With any type of accuracy enhancement applied, interpolated mode recalculates the error coefficients when the test frequencies are changed. The number of points can be increased or decreased and the start/stop frequencies can be changed.
Velocity factor	Enter the velocity factor to calculate the equivalent physical length.
Reference port extension	Redefine the measurement plane from the plane where the calibration was done.

Storage

Internal hard disk drive	Store and recall instrument states, calibration data, and trace data on 3 GB, minimum, internal hard drive. Trace data can be saved in CSV (comma separated value) format. All files are MS-DOS® -compatible. Instrument states include control settings, limit lines, segment sweep tables, and memory trace data.
File sharing	Internal hard disk drive (D:) can be accessed from an external Windows® PC through LAN.
Disk drive	Instrument states, calibration data, and trace data can be stored on an internal 3.5 inch 1.4MB floppy disk in MS-DOS® -compatible format.
Screen hardcopy	Printouts of instrument display are directly produced on a printer. The analyzer provides USB and parallel interfaces.

System capabilities

Familiar graphical user interface	The ENA Series analyzer employs a graphical user interface based on the Windows® operating system. There are three ways to operate the instrument manually: you can use a hardkey interface, a touch screen interface (Opt. 016), or a mouse interface.
Limit lines	Define the test limit lines that appear on the display for pass/fail testing. Defined limits may be any combination of horizontal/sloping lines and discrete data points.
Fixture Simulator	
Balanced-unbalanced conversion	Convert data from single-ended measurement to balanced measurement parameters (mixed-mode S-parameters), balance parameter or CMRR by using internal software.
Network De-embedding	De-embed an arbitrary circuit defined by a two-port Touchstone data file (50 Ω system) for each test port. This function eliminates error factors between the calibration plane and DUT and expands the calibration plane for each test port. This function can be used with the port extension function.
Port reference impedance conversion	Convert S-parameters measured in 50 Ω reference impedance to data in other reference impedance levels by using internal software. This conversion can be performed for both single-ended (unbalanced) measurement ports and converted balanced measurement ports.
Matching circuit	Add one of the predefined matching circuits or a circuit defined by a two-port Touchstone data file to each single-ended test port or converted balanced (differential) test port by using internal software.

Automation

Methods	
Internal analyzer execution	Applications can be developed in a built-in VBA® (Visual Basic for Applications) language. Applications can be executed from within the analyzer via COM (component object model) or using SCPI.
Controlling via GPIB	The GPIB interface operates to IEEE 488.2 and SCPI protocols. The analyzer can either be the system controller, or talker/listener.
LAN	
Standard conformity	10 Base-T or 100 Base-TX (automatically switched), Ethernet, RJ45 connector
Protocol	TCP/IP
Function	Telnet

16 Measurement Accessories

This chapter introduces the accessories that can be used with the Agilent E5070A/E5071A for various measurements.

Test Port Cables

The following cables are used to connect the DUT and the network analyzer.

N6314A 50 Ω N Type RF Cable (300 kHz ~ 9 GHz)

An RF cable 610 mm in length with male N type connectors on both ends.

N6315A 50 Ω N Type RF Cable (300 kHz ~ 9 GHz)

An RF cable 610 mm in length with a male and a female N type connector on each end.

Calibration Kits

Calibration kits are used to improve the accuracy of the analyzer in various measurements.

Two types of calibration kit – the coaxial mechanical calibration kit and coaxial electronic calibration kit – are available. Each kit comes with N type connectors or 3.5 mm (SMA) connectors.

The electronic type reduces the time required for calibration, mis-connections, and wear on connectors since it requires fewer changes of connection than the mechanical type.

Specifications for calibration kits and the availability of particular calibration kits are subject to change without prior notice. Contact the nearest Agilent Technology sales office or the supplier of your analyzer for more information before placing an order.

For Devices with N Type Connectors

Coaxial Mechanical Calibration Kits

85032F Mechanical Calibration Kit N Type 50 Ω (30 kHz ~ 9 GHz)

The 85032F kit includes the following items.

Agilent Cat. No.	Description
85032-60017	50 Ω N type (m), terminated
85032-60018	50 Ω N type (f), terminated
85032-60013	50 Ω N type (m), open
85032-60014	50 Ω N type (f), open
85032-60016	50 Ω N type (m), short
85032-60015	50 Ω N type (f), short

Also, the following options are available for the 85032F.

Option	Agilent Cat. No.	Description
Option 100	85032-60021	With a 50 Ω N type (f)-(f) adaptor.
Option 200	85032-60019	With a 50 Ω N type (m)-(m) adaptor.
Option 300	85032-60020	With a N type (m)-(f) adaptor.
Option 500	85054-60001	With two 50 Ω N type (f) to 7 mm adaptors.
	85054-60009	With two 50 Ω N type (m) to 7 mm adaptors.

85054D Economy Mechanical Calibration Kit N Type (45 MHz ~ 18 GHz)

Measurement Accessories

Calibration Kits

The 85054D includes the followings.

Agilent Cat. No.	Description
85054-60025	N type (m), short
85054-60026	N type (f), short
85054-60027	N type (m), open
85054-60028	N type (f), open
85054-60031	N type (f) to 7 mm adaptor
85054-60032	N type (m) to 7 mm adaptor
85054-60037	N type (f)-(f) adaptor
85054-60038	N type (m)-(m) adaptor
85054-60046	N type (m), terminated
85054-60047	N type (f), terminated

Coaxial Electronic Calibration Kits

85092C RF Two-Port ECal Module (300 kHz ~ 9 GHz)

Option	Description
Option M0F	Module with 50 Ω N type (m)/N type (f) connectors
Option 00M	Module with 50 Ω N type (m)/N type (m) connectors
Option 00F	Module with 50 Ω N type (f)/N type (f) connectors

N4431A RF Four-Port ECal Module (300 kHz ~ 9 GHz)

Option	Description
Option 020	Module with four 50 Ω N type (f) connectors

For Devices with 3.5 mm (SMA) Connectors

Coaxial Mechanical Calibration Kits

85033E Mechanical Calibration Kit 3.5 mm 50 Ω (30 kHz ~ 9 GHz)

The 85033E kit includes the following items.

Agilent Cat. No.	Description
85033-60016	3.5 mm (m), terminated
85033-60017	3.5 mm (f), terminated
85033-60018	3.5 mm (m), open
85033-60019	3.5 mm (f), open
85033-60020	3.5 mm (m), short
85033-60021	3.5 mm (f), short
8710-1761	Torque wrench

Also, the following options are available for the 85033E.

Option	Agilent Cat. No.	Description
Option 100	85027-60005	With a 3.5 mm (f)-(f) adaptor.
Option 200	85027-60007	With a 3.5 mm (m)-(m) adaptor.
Option 300	85027-60006	With a 3.5 mm (m)-(f) adaptor.
Option 400	1250-1744	With a 3.5 mm (f) to N type 50 Ω (m) adaptor.
	1250-1743	With a 3.5 mm (m) to N type 50 Ω (m) adaptor.
	1250-1745	With a 3.5 mm (f) to N type 50 Ω (f) adaptor.
Option 500	1250-1750	With a 3.5 mm (m) to N type 50 Ω (f) adaptor.
	1250-1746	With two 3.5 mm (m) to 7 mm adaptors.
	1250-1747	With two 3.5 mm (f) to 7 mm adaptors.

Measurement Accessories
Calibration Kits

85052C Mechanical Calibration Kit 3.5 mm (45 MHz ~ 26.5 GHz)

The 85052C kit includes the following items.

Agilent Cat. No.	Description
00902-60003	3.5 mm (m), terminated
00902-60004	3.5 mm (f), terminated
85052-60006	3.5 mm (m), short
85052-60007	3.5 mm (f), short
85052-60008	3.5 mm (m), open
85052-60009	3.5 mm (f), open
85052-60032	3.5 mm (f)-(f) adaptor
85052-60033	3.5 mm (m)-(m) adaptor
85052-60034	3.5 mm (f)-(m) adaptor
85052-60035	3.5 mm high-precision short airline
85052-60036	3.5 mm high-precision long airline

85052D Economy Mechanical Calibration Kit 3.5 mm (45 MHz to 26.5 GHz)

The 85052D kit includes the following items.

Agilent Cat. No.	Description
00902-60003	3.5 mm (m), terminated
00902-60004	3.5 mm (f), terminated
85052-60006	3.5 mm (m), short
85052-60007	3.5 mm (f), short
85052-60008	3.5 mm (m), open
85052-60009	3.5 mm (f), open
85052-60012	3.5 mm (f)-(f) adaptor
85052-60013	3.5 mm (f)-(m) adaptor
85052-60014	3.5 mm (m)-(m) adaptor

Coaxial Electronic Calibration Kits

85093C RF Two-Port ECal Module (300 kHz ~ 9 GHz)

Option	Description
Option M0F	Module with 3.5 mm (m)/3.5 mm (f) connectors
Option 00M	Module with 3.5 mm (m)/3.5 mm (m) connectors
Option 00F	Module with 3.5 mm (f)/3.5 mm (f) connectors

N4431A RF Four-Port ECal Module (300 kHz ~ 9 GHz)

Option	Description
Option 010	Module with four 3.5 mm (f) connectors

Adaptors

11853A 50 Ω N Type Accessory Kit

The 11853A kit includes the following items.

Agilent Cat. No.	Description
1250-1472	N type (f)-(f) adaptor kit (two adaptors)
1250-1475	N type (m)-(m) adaptor kit (two adaptors)
11511A	N type (f), short
11512A	N type (m), short

11878A N type to 3.5 mm Adaptor Kit

The 11878A kit includes the following items.

Agilent Cat. No.	Description
1250-1744	3.5 mm (f) to N type 50 Ω (m) adaptor
1250-1743	3.5 mm (m) to N type 50 Ω (m) adaptor
1250-1745	3.5 mm (f) to N type 50 Ω (f) adaptor
1250-1750	3.5 mm (m) to N type 50 Ω (f) adaptor

11854A 50 Ω BNC Accessory Kit

The 11854A kit includes the following items.

Agilent Cat. No.	Description
1250-0929	BNC (m), short
1250-1473	BNC (m) to N type (m) adaptor kit (two adaptors)
1250-1474	BNC (f) to N type (f) adaptor kit (two adaptors)
1250-1476	BNC (f) to N type (m) adaptor kit (two adaptors)
1250-1477	BNC (m) to N type (f) adaptor kit (two adaptors)

System Accessories

System Racks and Cases

Option	Agilent Cat. No.	Description
Option 1CN	5063-9229	Handle kit (two handles)
Option 1CM	5063-9216	Rack mount kit (without handles)
Option 1CP	5063-9223	Rack mount/handle kit (for customers already supplied with handles)
	E3663AC	Rack mount rail kit (with a rack mount kit and a handle kit)
	9211-2658	Transit case

GP-IB Cables

The following GPIB cables can be used to connect the analyzer with an external device such as a computer.

10833A GPIB cable	1.0 m (3.3 ft)
10833B GPIB cable	2.0 m (6.6 ft)
10833C GPIB cable	3.0 m (9.9 ft)
10833D GPIB cable	0.5 m (1.6 ft)

17 Information on Maintenance

This chapter explains the measures you should take to maintain the Agilent E5070/E5071A.

Backing Up the Data

Be sure to back up regularly your important data (including program) files in this instrument to a CD-R or other backup medium. Agilent Technologies shall not be liable for any data damages caused by troubles of this instrument.

Making Backup Files

Making backup files on a floppy disk

You can make backup files on a floppy disk using the copy function. See “Organizing Files and Folders” on page 203 for making a copy.

Making backup files on the hard disk of an external PC

You can make backup files on the hard disk of an external PC using following methods.

- You can access to drive D: of the E5070/E5071A from an external PC via LAN, and copy your important data files on the drive D: to the external PC. See “Accessing to hard disk of the E5070A/E5071A from an external PC via LAN” on page 258 for details.
- You can transfer your important data files on the drive D: of the E5070/E5071A to the external PC using :MMEM:TRAN command via GPIB. See *Programmer's Guide* for details.

NOTE

Do not modify any files and folders in drives other than drive A: and drive D:. Doing so will cause malfunctions.

Cleaning this Instrument

This section describes how to clean the instrument.

WARNING

To protect yourself from electrical shock, be sure to unplug the power cable from the outlet before cleaning the instrument.

Never clean the internal components of the instrument.

Cleaning an LCD

Use one of the following methods to clean the display surface regularly.

- For normal cleaning, rub the surface gently with a dry, soft cloth.
- When stains are difficult to remove, gently wipe the surface with cloth damped with a small amount of ethanol or isopropyl alcohol.
You can clean the standard type LCD (no touch screen function) with a cloth dipped in water and then wrung tightly.

NOTE

Do not use chemicals other than ethanol and isopropyl alcohol to wet the cleaning cloth.

To clean a touch screen type LCD (Option 016), do not wet the cloth with water.

Maintenance of Test Ports and Other Connectors/Ports

Test ports on the front panel of the E5070/E5071A are fitted with N Type connectors (f). Stains or other damage to these connectors would significantly affect the accuracy in measurements in the RF range. Always pay attention to the following precautions.

- Always keep the connectors free from stains and dust.
- Do not touch the contact surface on the connectors.
- Do not plug damaged or scratched connectors into the test ports.
- Use compressed air for cleaning connectors. Do not use abrasives under any circumstance.

The above precautions must also be observed in maintaining connectors and ports other than these test ports.

Cleaning a Display Other than an LCD

To remove stains on parts other than the LCD, test ports, and other connectors/ports of the instrument, wipe them gently with a soft cloth that is dry or wetted with a small amount of water and wrung tightly.

Replacement of Parts with Limited Service Life

This instrument incorporates parts with limited service life as shown in Table 17-1. Using the recommended replacement time shown in Table 17-1 as a guide, request the Company's Service Center to replace these parts. However, a part may need to be replaced at an earlier time than that listed in the table, depending on such conditions as location, frequency of use, and where it is stored.

NOTE

Each service life and recommended replacement time listed below is for reference only and does not imply a guarantee of the part's service life.

Table 17-1 **Parts with Limited Service Life**

Part Name	Service Life (Parts supplier reference value)	Recommended replacement time
Hard Disk Drive* ¹	5 years or 20,000 operating hours, whichever comes earlier	3 years
Floppy disk drive* ²	5 years or 30,000 operating hours, whichever comes earlier	4 years
Main fan* ²	50,000 operating hours	5 years
CPU fan* ²	50,000 operating hours	5 years
Power supply* ²	50,000 operating hours (Depends on the service life of the power supply cooling fan)	5 years
LCD screen backlight* ³	50,000 operating hours	5 years
Touch screen (function)	One million times (dotting life)	5 years

*1. Exchanging hard disk drives causes the contents written after shipment from the factory (LAN setup, etc.) to be initialized to the state at the time of shipment. The programs and data stored in Drive D (user directory) are erased.

*2. The service life may be significantly shorter when used in a dusty and dirty environment.

*3. When the unit is used for automatic measurements in a production line and the on-screen information is not required, the life of the LCD backlight can be saved by turning it off. As for the method of turning the backlight off, refer to "Turning off the LCD Screen Backlight" on page 263.

Cautions Applicable to Requesting Repair, Replacement, Regular Calibration, etc.

Backing Up Data in the Hard Disk

The user is requested to back up the stored programs and data into external media by using the instrument's storing function before requesting the Company's Service Center to repair the instrument or replace hard disks.

See "Making Backup Files" on page 366 for how to make backup files.

Please take note that the Company will not be held liable to any extent for potential erasure or change of stored programs or data due to the repair or replacement of hard disks performed by the Company. When a hard disk itself fails, the programs and data stored in it cannot be recovered.

Devices to be Sent Back for Repair or Regular Calibration

If it is necessary to send the unit to the Service Center of Agilent Technologies for repair or regular calibration, please follow the instructions below.

Equipment to be Sent

When requesting repair or regular calibration of the unit by our Service Center, send only the E5070/E5071A main unit without any installed option you may have ordered. Unless specifically instructed, it is not necessary to send accessories and calibration kits.

Packing

Use the original package and shock absorbers, or equivalent antistatic packing materials, when sending the unit.

Shipping Address

For the location of the nearest Agilent Technologies Service Center, contact the Customer Contact listed at the end of this brochure.

Recommended Calibration Period

The recommended calibration period for this instrument is one year. The user is recommended to request the Company's Service Center to perform regular calibration every year.

Information on Maintenance

Cautions Applicable to Requesting Repair, Replacement, Regular Calibration, etc.

A **Manual Changes**

This appendix contains the information required to adapt this manual to versions or configurations of the E5070A/E5071A manufactured earlier than the current printing date of this manual. The information in this manual applies directly to E5070A/E5071A units having the serial number printed on the title page of this manual.

Manual Changes

To adapt this manual to your E5070A/E5071A, refer to Table A-1 and Table A-2.

Table A-1 Manual Changes by Serial Number

Serial Prefix or Number	Make Manual Changes

Table A-2 Manual Changes by Firmware Version

Version	Make Manual Changes
1.xx	Change 1

Agilent Technologies uses a two-part, ten-character serial number that is stamped on the serial number plate (Figure A-1). The first five characters are the serial prefix and the last five digits are the suffix.

Figure A-1 Serial Number Plate



e5070auj034

Change 1

The firmware revision 1.xx does not support the following functions. Please delete the descriptions about these functions in this manual

- Sweep
 - Log sweep
 - Fast Stepped/Swept mode
 - Sweep mode setting for each segment
- Save/Recall
 - Saving/recalling instrument state for each channel
 - Saving screen images as portable network graphics (.png) file
 - Backing up when State01 to State08 are overwritten.
- Fixture simulator
 - Imbalance parameter
 - CMRR
 - Common port reference impedance conversion
- Parameter conversion
- Time domain
- Positive phase format
- Changing display color
- Controlling the E5091A
- ECal (Electronic Calibration)
 - 4 port ECal
 - Response calibration (Thru)

Manual Changes
Manual Changes

B Troubleshooting

This Chapter describes the steps to take in troubleshooting when your Agilent E5070A/E5071A appears to be operating improperly. Explanations are also given for the error warning messages displayed on the screen.

Troubleshooting

This section describes the steps you should take when you believe the Agilent E5070A/E5071A is operating improperly. The results of these simple investigative procedures may help you avoid the down-time and inconvenience of repair service. The troubleshooting instructions are divided into three categories:

- “Troubleshooting during Startup” on page 376
- “Troubleshooting during Operation” on page 376
- “Troubleshooting for External Devices” on page 379

Troubleshooting during Startup

The System Does Not Start Up.

- Turning on (I) the standby switch does not start up the system.
 - ▶ Confirm that the power cable is properly plugged in.
 - ▶ Confirm that the line switch on the rear panel is turned on (O). For the information on the line switch on the rear panel, see “2. Line Switch (Always ON)” on page 47.

When taking all the above measures does not result in normal operation, there is a possibility of a failure. Unplug the power cable immediately, and contact Agilent Technology’s Customer Contact listed at the end of this guide or the company from which you bought the device.

The system starts up, but the normal measurement screen does not appear.

- The system starts up, but it automatically shuts down immediately.
- The system starts up, but it enters the service mode (The instrument status bar in the lower right part of the screen displays **SVC** in red).
- The measurement screen appears after startup, but the date and time displayed on the instrument status bar in the lower right part of the screen differ greatly from the previous settings.
- The measurement screen appears after startup, but the power-on test is failed, with Error Message 241 appearing against a red background in the instrument message/warning area in the lower left part of the screen.

There is a possibility of a failure. Contact Agilent Technology’s Customer Contact listed at the end of this guide or the company from which you bought the device.

Troubleshooting during Operation

The Sweep Action Stops during Measurement or Is Not Executed.

- The sweep action stops during measurement or is not executed, but the front keys and softkeys are operational.

There is a possibility of a failure. Contact Agilent Technology’s Customer Contact listed at the end of this guide or the company from which you bought the device.

The Error Message “Port N receiver overload” (N denotes a port number) is Displayed.

- During the measurement of an amplifier, Error Messages 221 through 224 “Port N receiver overload” (N denotes a port number) on page 385 are displayed.
 This error occurs when the input to a test port exceeds the maximum input level in the measurement of an amplifier. The measurement value obtained in such a case is not correct. In the worst case, a failure (damage to the receiver) may occur.

- ▶ Change the measurement condition so that the input to the test port does not exceed the maximum input level.

When this message is displayed with nothing connected to the test port, there is a possibility of a failure of the instrument. Contact Agilent Technology’s Customer Contact listed at the end of this guide or the company from which you bought the device.

A Clearly Abnormal Measurement Value

- The measurement value is not reproducible, or clearly abnormal.
 - ▶ Confirm that the DUT, connection cables, and other parts are connected correctly.
 - ▶ Confirm that the connectors and cables used to connect the DUT are free from damage and poor contact.
 - ▶ Confirm that the calibration has been executed correctly. If you have not acquired a correct error correction factor, you cannot obtain a correct measurement value.
 - ▶ Confirm that the calibration kit was selected correctly.
 - ▶ Confirm that the calibration kit is defined correctly.

When taking all these measures does not result in a correct measurement value, there is a possibility of a failure. Contact Agilent Technology’s Customer Contact listed at the end of this guide or the company from which you bought the device.

The System Cannot be Operated Manually (Front Panel Keys, Keyboard, and Mouse)

- The keyboard or mouse becomes inoperable.
 - ▶ Confirm that the keyboard or mouse is connected correctly. When it is connected correctly, turn off the power once, and restart the system.
- The front panel key or keyboard becomes inoperable.
 - ▶ Using the mouse, turn **System – Key Lock – Front Panel & Keyboard Lock OFF**.
- The mouse becomes inoperable.
 - ▶ Using the front panel keys or keyboard, turn **System – Key Lock – Front Panel & Keyboard Lock OFF**.
- All of the front panel keys, keyboard, and mouse become inoperable.
 - ▶ Confirm that the keyboard or mouse is connected correctly. When it is connected correctly, turn off the power once, and restart the system.
- The keyboard and mouse have been connected after power-on.

Troubleshooting

Troubleshooting

- ▶ Turn off the power once, and restart the system.

When taking all these measures does not recover operability, there is a possibility of a failure. Contact Agilent Technology's Customer Contact listed at the end of this guide or the company from which you bought the device.

The Screen Freezes and All Operations Become Impossible.

- The measurement in progress or screen update is stalled and all of the front panel keys, keyboard, mouse, and touch screen (Option 016) are inoperable.
 - ▶ Press the standby switch to turn off the power once, and restart the system.

When a similar symptom reappears, there is a possibility of a failure. Contact Agilent Technology's Customer Contact listed at the end of this guide or the company from which you bought the device.

The System Freezes while in Operation.

- The system freezes while in operation.
 - ▶ Press the standby switch to turn off the power once, and restart the system.

The Cooling Fan Does Not Operate.

- The rear cooling fan does not operate.

There is a possibility of a failure. Contact Agilent Technology's Customer Contact listed at the end of this guide or the company from which you bought the device.

You Cannot Save a File in a Floppy Disk.

- You cannot save a file in a floppy disk.
 - ▶ Confirm that the floppy disk is initialized. If not, initialize it.
 - ▶ Confirm that the floppy disk is inserted correctly. Insert a floppy disk until the eject button pops up fully.
 - ▶ Confirm that the floppy disk is not write-protected. If it is, unprotect the disk.
 - ▶ Confirm that the floppy disk has free space. If it does not, delete unnecessary files or use a new floppy disk.

When taking all these measures does not make it possible to save a file, there is a possibility of a failure. Contact Agilent Technology's Customer Contact listed at the end of this guide or the company from which you bought the device.

You Cannot Read a File from a Floppy Disk.

- You cannot read a file from a floppy disk.
 - ▶ Confirm that the floppy disk is inserted correctly. Insert the floppy disk until the eject button pops up fully.
 - ▶ A stored file may be damaged by a magnetic field. Confirm that the file can be read on a PC.

When taking all these measures does not make it possible to read the file, there is a possibility of a failure. Contact Agilent Technology's Customer Contact listed at the end of

this guide or the company from which you bought the device.

An Error or Warning Message Appears.

When an error or warning message is displayed on the instrument message/warning area in the lower part of the screen, refer to Error Messages on page 380 and Warning Messages on page 390.

Troubleshooting for External Devices

Cannot Output to a Printer

- Cannot output a measurement screen or data to a printer.
- Attempting to output to a printer causes Error Messages 120 and 121 on page 386 to appear.
 - ▶ Confirm that the power to the printer is on and that the line cable is connected correctly.
 - ▶ Confirm that the connector cable of the printer is connected correctly.
 - ▶ Confirm that the printer is online.
 - ▶ Confirm that the printer has not run out of paper.
 - ▶ Confirm that the printer has not run out of ink.

When taking all these measures does not result in printer output, there is a possibility of a failure. Contact Agilent Technology’s Customer Contact listed at the end of this guide or the company from which you bought the device.

Does Not Respond to an External Controller/Fails to Function Normally

- A GPIB device does not respond to the external controller, or fails to function normally.
 - ▶ Confirm that the GPIB address is defined correctly.
 - ▶ Confirm that the GPIB cable is connected.
 - ▶ Confirm that another instrument connected by the GPIB cable has the same GPIB address.
 - ▶ Confirm that the GPIB cable connection forms a loop.

When taking all these measures does not result in correct operation of the GPIB devices, there is a possibility of a failure. Contact Agilent Technology’s Customer Contact listed at the end of this guide or the company from which you bought the device.

Error Messages

An error message is displayed against a red background in the instrument message/warning area in the lower left part of the screen. Pushing a front panel key or executing :DISP:CCL command clears the error message. Errors caused by the operation of a front panel key simply appear on the display. They are not stored in the error queue with some exceptions.

An error with a positive error number is one uniquely defined for this instrument. On the other hand, an error with a negative error number is basically one defined for common GPIB devices in IEEE488.2

A

20

Additional standard needed

The GPIB command that turns ON the calibration function has been sent before all of the data measurements needed to calculate the calibration factor have been completed. For instance, the "SENS:CORR:COLL:SAVE" command is sent to calculate calibration coefficients and turn on error correction for 1-Port Calibration when open and short calibration are completed but load calibration is not completed. Be sure to measure all necessary calibration data before sending commands. This error is not generated by front key operations.

B

-168

Block data not allowed

A block-data element has been received at a position where this instrument does not accept one.

C

240

Calibration data lost

This error occurs when a file containing the system calibration data is not found or in a damaged state at time of the startup of this instrument, indicating a failure of this instrument. Contact an Agilent Technology sales office or the company from which you bought the instrument.

22

Calibration method not selected

This error occurs when the command for validating the calibration, SENS:CORR:COLL:SAVE, is executed before the command for selecting a calibration type, SENS:CORR:COLL:METH:xxxx, is executed. This error is not generated by front key operations.

-148

Character data not allowed

A character data element (not violating the standard) has been received at a position where this instrument does not accept one. Double quotes (") are omitted where it is necessary to place a parameter in double quotes ("), for example.

- 100 **Command error**
- A comprehensive syntax error has occurred showing that this instrument cannot detect a more detailed error. This code simply shows that a command error defined in 11.5.1.1.4, IEEE488.2 has occurred.
- 60 **Cont switching may damage source attenuator**
- This error occurs when different source attenuator (power range) settings are present during measurement on two or more channels. Performing such measurement for a long time is not recommended because of the possibility of the source attenuator being damaged. The measurement value is normal. This error occurs only on models with the extended power output (Option 214, 314, and 414).
- D**
- 222 **Data out of range**
- A data element (not violating the standard) outside the range defined by this instrument has been received. This error occurs when an integer-based command for which the parameter can be rounded exceeds the range of -65536 to +65536 or when a real-number-based command for which the parameter can be rounded exceeds the range of -9.9e37 to +9.9e37, for example.
- This error occurs also when a numeric value other than a specified one is entered into a command in which the “port number” and “CalKit number” are specified as parameters and hence the parameters are not rounded. Such commands are, for example, CALC:FSIM:BAL:TOP:BBAL:PPOR, SENS:CORR:COLL:ACQ:OPEN, SENS:CORR:COLL:ECAL:SOLT3, SENS:CORR:COLL:CKIT:ORD:LOAD, etc.
- 104 **Data type error**
- The parser has recognized a data element that must not exist. Block data has been sent instead of numeric value data or character string data that had been expected, for example.
- E**
- 32 **Ecal module not in appropriate RF path**
- This error occurs when an ECal command, SENS:CORR:COLL:ECAL:SOLTn, is executed with the port on the ECal module not connected correctly to the instrument.
- 200 **Execution error**
- An error associated with execution has been generated for which this instrument cannot specify the error message. This code shows that an error associated with execution defined in 11.5.1.1.5, IEEE488.2 has occurred. This error occurs also when a calibration measurement is aborted.
- 123 **Exponent too large**
- The absolute value of the exponent exceeds 32,000 (see 7.7.2.4.1, IEEE488.2).
- 178 **Expression data not allowed**
- An expression-data element has been received at a position where this instrument does not accept one.

- 170 **Expression error**
When the expression data is put to syntactic analysis, an error not corresponding to one of Error Numbers -171 through -179 occurs.
- F**
- 31 **Failed to configure ECal module**
This error occurs when the control of the ECal module fails at time of executing an ECal command, SENS:CORR:COLL:ECAL:SOLTn. The failure results from the failure to connect the ECal module to the USB port, failure of the ECal module, etc.
- 102 **Failed to copy file**
This error occurs when copying a file (MMEM:COPY command) fails.
- 104 **Failed to create directory**
This error occurs when creating a directory (MMEM:MDIR command) fails.
- 103 **Failed to delete file**
This error occurs when deleting a file (MMEM:DEL command) fails.
- 100 **Failed to read file**
This error occurs when a 2-port touchstone file (CALC:FSIM:SEND:PMC:PORT:USER:FIL command), the formatted data array (MMEM:LOAD:FDAT command) and limit table (MMEM:STOR:LIM command) for the active trace on the active channel, segment sweep table (MMEM:LOAD:SEGM command) for the active channel, a VBA project file (MMEM:LOAD:PROG command), etc. cannot be read normally.
- 101 **Failed to write file**
This error occurs when the formatted data array (MMEM:STOR:FDATcommand) and limit table (MMEM:STOR:LIM command) for the active trace on the active channel, segment sweep table (MMEM:STOR:SEGM command) for the active channel, display image (MMEM:STOR:IMAG command) for the LCD screen, a VBA project file (MMEM:STOR:PROG command), etc. cannot be written normally.
- 257 **File name error**
A file name error. This message appears when an error exists in the file name and hence a command is not executed correctly. This error occurs when you try to copy to an unsuitable file name, for example.
- 256 **File name not found**
The file name specified is not found and hence the command is not executed correctly. This error occurs when you try to read a file that does not exist in a disk or a disk is not correctly inserted into the drive to read or write a file, for example.
- 107 **File transfer failed**
This error occurs when writing data into or reading data from a file (MMEM:TRAN command) fails.

G

-105 **GET not allowed**

A group execution trigger (GET) has been received in the program message (see 7.7, IEEE488.2).

H

-114 **Header suffix out of range**

The unit of the header is outside the range. The header is invalid in the unit for numeric parameters following a SCPI command.

I

53 **Log sweep requires 2 octave minimum span**

The span of sweep range is not satisfied the requirement for logarithmic sweep. The sweep type is automatically changed to linear sweep when this error occurs.

For example, this error occurs when, with the start and stop frequency are set 1 MHz and 2 MHz respectively, the sweep type is changed to logarithmic sweep.

Set the stop frequency to more than four times as many as the start frequency. And then select logarithmic sweep.

-224 **Illegal parameter value**

The parameter value is not suitable. This error occurs when the CALC:PAR:DEF command is used to specify an S-parameter that does not exist in the model (S44 in the case of a 2-port model), for example.

-282 **Illegal program name**

This error occurs when a nonexistent VBA program name is specified by the PROG:SEL:NAME command.

-213 **Init ignored**

Because another measurement is in progress, the request for initiating a measurement ("INIT" command) is ignored.

-161 **Invalid block data**

Block data has been expected, but the block data that appears is invalid for some reason (see 7.7.6.2, IEEE488.2). The END message is received before the length of block data has been filled, for example.

-101 **Invalid character**

An invalid character exists in the program message character string.

-141 **Invalid character data**

An invalid character is found in the character data element, or the parameter received is not valid.

- 121 **Invalid character in number**
A character that is invalid for the data type subject to syntactic analysis has been received. For example, a letter is found in a decimal numeric value or a numeric character “9” in octal data.
- 171 **Invalid expression**
The expression-data element is invalid (see 7.7.7.2, IEEE488.2). Parentheses are not paired, or illegal characters are used, for example.
- 103 **Invalid separator**
The parser (a syntactic analysis program) had been expecting a delimiter, but a character that is not a delimiter has been sent.
- 151 **Invalid string data**
Character string data has been expected, but the character string data that appears is invalid for some reason (see 7.7.5.2, IEEE488.2). The END message is received before the ending quotation mark character appears, for example.
- 131 **Invalid suffix**
The suffix does not comply with the syntax defined in 7.7.3.2, IEEE488.2. Or it does not suit 4294A.

L

- 53 **Log sweep requires 2 octave minimum span**
The span of sweep range is not satisfied the requirement for logarithmic sweep. The sweep type is automatically changed to linear sweep when this error occurs.
For example, this error occurs when, with the start and stop frequency are set 1 MHz and 2 MHz respectively, the sweep type is changed to logarithmic sweep.
Set the stop frequency to more than four times as many as the start frequency. And then select logarithmic sweep.

M

- 109 **Missing parameter**
The number of parameters is less than that required for the command, or the parameter has not been entered. For example, the command SENS {1 - 6} :SWE:POIN requires one more parameter.
Therefore, when a message “SENS1:SWE:POIN” is sent to a correct program message “SENS1:SWE:POIN 201” this instrument receives the former message as an invalid one because all parameters have not been entered. Enter command parameters correctly.

N

- 120 **Numeric data error**
An error resulting from the numeric value data (including numeric value data having no decimal point representation) has occurred. A numeric value error other than Errors -121 through -129 has occurred.

- 128 **Numeric data not allowed**
An numeric-value-data element (not violating the standard) has been received at a position where this instrument does not accept one.
- O**
- 200 **Option not installed**
The command received has been ignored because of the mismatch between the contents of an option for this instrument and the command.
For example, this error occurs when the source attenuator (power range) is set at a value other than zero (SOUR:POW:ATT command) in a model not having the extended power output option.
This error is not generated by front key operations.
- 225 **Out of memory**
Insufficient memory is available in this instrument to perform the required operation.
- P**
- 220 **Parameter error**
When a parameter-related error other than Errors -221 through -229 occurs, that error is displayed.
- 108 **Parameter not allowed**
The number of parameters exceeds that required for the command.
For instance, when a program message “:SENS1:SWE:TYPE LIN, SEGM” is sent instead of a correct program message with a command “:SENS1:SWE:TYPE LIN” which requires a parameter, the instrument receives the message as the number of parameters is invalid. See the command reference to confirm the required number of parameters.
- 41 **Peak not found**
This error occurs when, after specifying a peak and executing the CALC:MARK:FUNC:EXEC and CALC:FUNC:EXEC commands, the specified peak is not found in the marker search analysis.
- 220 **Phase lock loop unlocked**
This error occurs when the PLL circuit of this instrument becomes unlocked while the measurement is in progress. The measurement value is not correct. This error may occur when an external reference out of specification is connected to this instrument. Should an error occur with an external reference not connected, this instrument is faulty. Contact an Agilent Technology sales office or the company from which you bought the instrument.
- 221 **Port 1 receiver overload**
The input to Test Port 1 exceeds the maximum input level. The measurement value is not correct. When a DUT is an amplifier or the like, this error may occur, damaging the receiver in the worst case. Should this error occur with a passive part used as the DUT or with nothing connected to the test port, this instrument is faulty. Contact an Agilent Technology sales office or the company from which you bought the instrument.

- 222 **Port 2 receiver overload**
- The input to Test Port 2 exceeds the maximum input level. The measurement value is not correct. When a DUT is an amplifier or the like, this error may occur, damaging the receiver in the worst case. Should this error occur with a passive part used as the DUT or with nothing connected to the test port, this instrument is faulty. Contact an Agilent Technology sales office or the company from which you bought the instrument.
- 223 **Port 3 receiver overload (for Options 313, 314, 413, and 414 only)**
- The input to Test Port 3 exceeds the maximum input level. The measurement value is not correct. When a DUT is an amplifier or the like, this error may occur, damaging the receiver in the worst case. Should this error occur with a passive part used as the DUT or with nothing connected to the test port, this instrument is faulty. Contact an Agilent Technology sales office or the company from which you bought the instrument.
- 224 **Port 4 receiver overload (For Options 413 and 414 only)**
- The input to Test Port 4 exceeds the maximum input level. The measurement value is not correct. When a DUT is an amplifier or the like, this error may occur, damaging the receiver in the worst case. Should this error occur with a passive part used as the DUT or with nothing connected to the test port, this instrument is faulty. Contact an Agilent Technology sales office or the company from which you bought the instrument.
- 241 **Power on test failed**
- This error occurs when the power-on test fails, indicating a failure of this instrument. Contact an Agilent Technology sales office or the company from which you bought the instrument.
- 120 **Printer error**
- This error occurs when the previous printing is still in progress or the printer fails (offline, short of paper, etc.) at time of outputting the display image on the LCD screen to the printer (HCOP:IMM command).
- 121 **Print failed**
- This error occurs when printing fails for reasons other than Error 120, Printer error.
- 284 **Program currently running**
- This error occurs when the PROG:SEL:STAT RUN command is executed with the VBA program in the Run state.
- 112 **Program mnemonic too long**
- The length of the header exceeds 12 characters (see 7.6.1.4.1, IEEE488.2).
- 286 **Program runtime error**
- An error occurring when VBA is executed.
- Q**
- 430 **Query DEADLOCKED**
- The state that generates a “DEADLOCKED” Query error (see 6.3.1.7, IEEE488.2). This error occurs when both input and output buffers have become full, preventing the instrument from continuing processing, for example.

- 400 **Query error**
A comprehensive query error has occurred showing that this instrument cannot detect a more detailed error. This code simply shows that a query error defined in 11.5.1.1.7 and 6.3, IEEE488.2 has occurred.
- 410 **Query INTERRUPTED**
The state that generates a “INTERRUPTED” Query error (see 6.3.2.3, IEEE488.1). This error occurs when data bytes (DAB) or GET are received before the transmission of the response after a query has not been completed, for example.
- 420 **Query UNTERMINATED**
The state that generates an “UNTERMINATED” Query error (see 6.3.2, IEEE488.2). This error occurs when this instrument is designated as the talker and an incomplete program message is received, for example.
- 440 **Query UNTERMINATED after indefinite response**
After a query asking for an indefinite response has been run, another query is received in the same program message (See 6.5.7.5.7, IEEE488.2).
- R**
- 105 **Recall failed**
This error occurs when reading an instrument status file (State01.sta, etc.) (MMEM:LOAD:STAT command) fails.
- S**
- 106 **Save failed**
This error occurs when writing an instrument status file (State01.sta, etc.) (MMEM:STOR:STAT command) fails.
- 50 **Specified channel hidden**
This error occurs when an attempt is made to activate a channel not on display using the DISP:WIND:ACT command. This error is not generated by front key operations.
- 21 **Specified ports overlapped**
This error occurs when a port number is duplicated in a command requiring two or more port numbers as parameters. Such commands are, for example, CALC:FSIM:BAL:TOP:SSB:PPOR 1,2,3,3. Specify port setup correctly to avoid duplication of ports. This error is not generated by front key operations.
- 150 **String data error**
When a character-string-data element is put to syntactic analysis, an error not corresponding to one of Error Numbers -151 through -159 occurs.
- 158 **String data not allowed**
A character-string-data element has been received at a position where this instrument does not accept one.

- 138 **Suffix not allowed**
A suffix is attached to a numeric value element to which a suffix is not allowed to be attached.
- 134 **Suffix too long**
The unit is too long.
The unit is expressed in 12 or more characters (see 7.7.3.4, IEEE488.2).
- 102 **Syntax error**
A command or data type that is not recognized exists.
- 310 **System error**
One of the errors designated as “system errors” in this instrument has occurred.
- T**
- 40 **Target value not found**
This error occurs when the target is not found during the marker search analysis after specifying the target and executing the CALC:MARK:FUNC:EXEC and CALC:FUNC:EXEC commands. This error occurs also when the bandwidth is not found after executing the bandwidth marker command, CALC:MARK:BWID:DATA?
- 124 **Too many digits**
The number of digits of the argument of the decimal numeric-value-data element exceeds 255 with the preceding 0 removed (see 7.7.2.4.1, IEEE488.2).
- 223 **Too much data**
The block-, expression-, or character-string-type program data that has been received conforms with the standard. But it exceeds the amount that can be processed under the condition of the memory or conditions specific to memory-related devices. In this instrument, this error occurs when the number of characters exceeds 254 in a character-string parameter.
- 54 **Transform, Gate not allowed**
This error occurs when number of points is set 2 or sweep type is set logarithmic/segment sweep, the gating or transform function of time domain function is turned on.
Set number of points to more than 3, the sweep type to linear sweep. And then, turn on the gating or transform function of time domain function.
- 211 **Trigger ignored**
This instrument receives and detects a trigger command (“TRIG”) or an external trigger signal. But it is ignored due to the timing condition (This instrument is not in the wait-for-trigger state, for example). Change the setup so that a trigger command or an external trigger signal can be sent after the instrument has entered the wait-for- trigger state.

U

-113

Undefined header

A command not defined in this instrument, though not illegal in the syntactic structure, has been received. For example, when a message “:DISP:WIND1:TABL:MEM ON” is sent to a correct program message “:DISP:WIND1:TRAC1:MEM ON,” the message sent is received as an undefined command by this instrument. See the command reference and use correct commands.

This error occurs also when a port not existing on this model is specified in a command specifying a port number as an index. Such commands are CALC:FSIM:SEND:DEEM:PORTn:xxxx, CALC:FSIM:SEND:PMC:PORTn:xxxx, CALC:FSIM:SEND:ZCON:PORTn:Z0:R, and SENS:CORR:EXT:PORTn:TIME; they include PORTn as a part.

V

30

Valid Ecal module not found

This error occurs when the number of ports of the ECal module connected is less than the necessary number of ports. This error occurs, for example, when a 4-port Cal executing command, SENS:CORR:COLL:ECAL:SOLT4, is executed with a 2-port ECal module connected. This error is not generated by front key operations.

Warning Message

A warning message is displayed in the instrument message/Warning area in the lower left part of the display against a gray background. Pushing a front panel key or executing :DISP:CCL command clears the message.

This message simply appears on the display, being not known to a remote environment such as a GPIB. This message is not displayed when another error (against a red background) has already been displayed in the instrument message/Warning area.

The warning messages for this instrument are as follows:

Peak not found

This warning message is displayed when, with the tracking turned on, the peak specified by the marker search has not been found by the time the sweep is finished (with the tracking executed).

Segment table changed

This warning message is displayed when the setting specified segment by segment in the segment table is automatically changed by a change in the other setting.

For example, this warning message is displayed when, with the power specified segment by segment in the segment table, the power setting for a segment is adjusted by a change in the power range setting.

Target value not found

This warning message is displayed when, with the tracking turned on, the target specified by the marker search has not been found by the time the sweep is finished (with the tracking executed).

This warning message is displayed also when, with the bandwidth marker displayed, the setting for the bandwidth marker is changed at the end of the sweep, or when, with the active marker changed or moved, the bandwidth is not found.

Transform, Gate not allowed

This warning message is displayed when the gating/transform function of time domain function is turned on, number of points is set 2 or sweep type is set logarithmic/segment sweep.

The gating function and transform function are automatically turned off when this warning message is displayed.

C **List of Default Values**

This appendix gives the default values, settings for Save/Recall of an object, and settings for backing up an object when using the Agilent E5070A/E5071A.

List of Default Values, Save/Recall Settings, and Backup Settings

The table below shows the following settings for the Agilent E5070A/E5071A.

- Factory-shipped settings
- Settings valid when you press **Preset** (Or when you execute the **:SYST:PRES** command)
- Settings valid when you execute the ***RST** command
- Settings that permit Save/Recall of a setup state

In the table, states that can be saved/recalled are denoted in the following manner:

√: Save/Recall can be performed

Blank: Save/Recall cannot be performed

- Settings that are backed up (set state not affected by turning power ON/OFF)

In the table, a setting that is automatically backed up is denoted in the following manner:

√: Backup operation performed

Blank: Backup operation not performed

- Available means of defining a setting

In the table, the following symbols are used to denote the method(s) that can be used to define a setting.

K: Using the front panel key (including the mouse and keyboard)

C: Using the SCPI or COM command

NOTE

In the table, the ← symbol shows that the setup is the same as that in the box to the left.

List of Default Values
List of Default Values, Save/Recall Settings, and Backup Settings

Key Operation	Factory-shipped Setting	Default Value		Save/ Recall	Backup	Available Means of Defining a Setting
		Preset	*RST			
Meas	S11	←	←	√		K/C
	Sss11 (When Fixture Simulator is set on, set Topology at SE-Bal, and, BalUn on in Analysis mode)	←	←	√		K/C
	Sdd11 (When Fixture Simulator is set on, set Topology at Bal-Bal, and BalUn on in Analysis mode)	←	←	√		K/C
	Sss11 (When Fixture Simulator is set on, set Topology at SE-SE-Bal, and BalUn on in Analysis mode)	←	←	√		K/C
Format	Log Mag	←	←	√		K/C
Scale						
Divisions	10	←	←	√		K/C
Scale/Div	10.000 dB/div	←	←	√		K/C
Reference Position	5 Div	←	←	√		K/C
Reference Value	0.0000 dB	←	←	√		K/C
Electrical Delay	0.0000 s	←	←	√		K/C
Phase Offset	0.0000 °	←	←	√		K/C
Display						
Allocate Channels	<input type="text" value="x 1"/>	←	←	√		K/C
Number of Traces	1	←	←	√		K/C
Allocate Traces	<input type="text" value="x 1"/>	←	←	√		K/C
Display	Data	←	←	√		K/C
Data Math	OFF	←	←	√		K/C
Title Label	OFF	←	←	√		K/C
Graticule Label	ON	←	←	√		K/C
Invert Color	OFF	←	←	√		K/C
Frequency	ON	←	←	√		K/C
Update	ON	←	←	√		K/C
Avg						

List of Default Values

List of Default Values, Save/Recall Settings, and Backup Settings

Key Operation	Factory-shipped Setting	Default Value		Save/Recall	Backup	Available Means of Defining a Setting
		Preset	*RST			
Avg Factor	16	←	←	√		K/C
Averaging	OFF	←	←	√		K/C
SMO Aperture	1.5000%	←	←	√		K/C
Smoothing	OFF	←	←	√		K/C
IF Bandwidth	70 kHz	←	←	√		K/C
Cal						
Correction	OFF	←	←	√		K/C
Calibrate						
Response (Open)						
Select Port	1	←	←			K/C
Response (Short)						
Select Port	1	←	←			K/C
Response (Thru)						
Select Ports	2-1 (S21)	←	←			K/C
1-Port Cal						
Select Port	1	←	←			K/C
2-Port Cal						
Select Ports	1-2	←	←			K/C
3-Port Cal						
Select Ports	1-2-3	←	←			K/C
ECal						
Isolation	OFF	←	←	√		K/C
Property	OFF	←	←	√		K/C
Cal Kit	85033E	←	←	√		K/C
Modify Cal Kit						
Define STDs	Define STDs	←	←	√		K
Specify CLSs						
Open	Open	←	←	√		K
Port Extensions						
Extension Port1	OFF	←	←	√		K/C
Extension Port2	OFF	←	←	√		K/C

List of Default Values
List of Default Values, Save/Recall Settings, and Backup Settings

Key Operation	Factory-shipped Setting	Default Value		Save/ Recall	Backup	Available Means of Defining a Setting
		Preset	*RST			
Extension Port3	OFF	←	←	√		K/C
	OFF	←	←	√		K/C
Velocity Factor	1.0000	←	←	√		K/C
Start	300.00 kHz	←	←	√		K/C
Stop	3.0000 GHz (E5070A) 8.5000 GHz (E5071A)	←	←	√		K/C
Center	1.50015 GHz (E5070A) 4.25015 GHz (E5071A)	←	←	√		K/C
Span	2.9997 GHz (E5070A) 8.4997 GHz (E5071A)	←	←	√		K/C
Sweep Setup						
Power	0 dBm	←	←	√		K/C
Power Ranges	-15 to 0	←	←	√		K/C
Sweep Time	AUTO	←	←	√		K/C
Sweep Delay	0.0000 s	←	←	√		K/C
Sweep Mode	Std Stepped	←	←	√		K/C
Points	201	←	←	√		K/C
Sweep Type	Linear	←	←	√		K/C
Edit Segment Table						
Freq Mode	Start/Stop	←	←	√		K/C
List IFBW	OFF	←	←	√		K/C
List Power	OFF	←	←	√		K/C
List Delay	OFF	←	←	√		K/C
List Sweep Mode	OFF	←	←	√		K/C
List Time	OFF	←	←	√		K/C
Segment Display	Order Base	←	←	√		K/C
Trigger						
Continuous	Continuous (Ch1) Hold (Ch2 to 9)	←	Hold (all channels)	√		K/C
Trigger Source	Internal	←	←	√		K/C
Marker						

List of Default Values

List of Default Values, Save/Recall Settings, and Backup Settings

Key Operation	Factory-shipped Setting	Default Value		Save/ Recall	Backup	Available Means of Defining a Setting
		Preset	*RST			
Marker 1	Marker 1 is turned on immediately after the marker softkey menu is displayed.	←	←	√		K/C
Ref Marker Mode	OFF	←	←	√		K/C
Marker Search						
Max	Max	←	←	√		K/C
Peak						
Peak Excursion	3.0000 dB	←	←	√		K/C
Peak Polarity	Positive	←	←	√		K/C
Target						
Target Value	0.0000 dB (When Target is selected)	←	←	√		K/C
Target Transition	Both (When Target is selected)	←	←	√		K/C
Tracking	OFF	←	←	√		K/C
Bandwidth	OFF	←	←	√		K/C
Bandwidth Value	-3.0000 dB (When one of the marker is on)	←	←	√		K/C
Marker Fctn						
Discrete	OFF	←	←	√		K/C
Couple	ON	←	←	√		K/C
Marker Table	OFF	←	←	√		K/C
Statistics	OFF	←	←	√		K/C
Analysis						
Fixture Simulator						
Fixture Simulator	OFF	←	←	√		K/C
Topology						
Device	SE-BAL	←	←	√		K/C
Port1 (se)	1 (When SE-Bal is selected as the device) (When SE-SE-Bal is selected as the device)	←	←	√		K/C
Port1 (bal)	1-2 (When Bal-Bal is selected as the device)	←	←	√		K/C

List of Default Values
List of Default Values, Save/Recall Settings, and Backup Settings

Key Operation	Factory-shipped Setting	Default Value		Save/ Recall	Backup	Available Means of Defining a Setting
		Preset	*RST			
Port2 (bal)	2-3 (SE-Bal is selected as the device) 3-4 (Bal-Bal is selected as the device)	←	←	√		K/C
Port2 (se)	2 (When SE-SE-Bal is selected as the device)	←	←	√		K/C
Port3 (bal)	3-4 (When SE-SE-Bal is selected as the device)	←	←	√		K/C
BalUn	OFF	←	←	√		K/C
Port Matching						
Port Matching	OFF	←	←	√		K/C
Select Port	1	←	←	√		K/C
Select Circuit	None	←	←	√		K/C
C	0.000e-12 F	←	←	√		K/C
G	0.0000 S	←	←	√		K/C
L	0.000e-9 H	←	←	√		K/C
R	0.0000 Ω	←	←	√		K/C
Port ZConversion						
Port ZConversion	OFF	←	←	√		K/C
Port1 Z0	50.000 Ω	←	←	√		K/C
Port2 Z0	50.000 Ω	←	←	√		K/C
Port3 Z0	50.000 Ω	←	←	√		K/C
Port4 Z0	50.000 Ω	←	←	√		K/C
De-Embedding						
De-Embedding	OFF	←	←	√		K/C
Select Port	1	←	←	√		K/C
Select Type	None	←	←	√		K/C
Diff Matching						
Diff Matching	OFF	←	←	√		K/C
Select Bal Port	2	←	←	√		K/C
Select Circuit	None	←	←	√		K/C

List of Default Values

List of Default Values, Save/Recall Settings, and Backup Settings

Key Operation	Factory-shipped Setting	Default Value		Save/Recall	Backup	Available Means of Defining a Setting
		Preset	*RST			
C	0.000e-12 F	←	←	√		K/C
G	0.0000 S	←	←	√		K/C
L	0.000e-9 H	←	←	√		K/C
R	0.0000 Ω	←	←	√		K/C
Diff ZConversion						
Diff ZConversion	OFF	←	←	√		K/C
Port2 (bal)	100.00 Ω	←	←	√		K/C
Cmn ZConversion						
Cmn Z Conversion	OFF	←	←	√		K/C
Port2 (bal)	25.000 Ω	←	←	√		K/C
Gating						
Gating	OFF	←	←	√		K/C
Start	-10.000ns	←	←	√		K/C
Stop	10.000ns	←	←	√		K/C
Center	0.0000s	←	←	√		K/C
Span	20.000ns	←	←	√		K/C
Type	Bandpass	←	←	√		K/C
Shape	Normal	←	←	√		K/C
Transform						
Transform	OFF	←	←	√		K/C
Start	-10.000ns	←	←	√		K/C
Stop	10.000ns	←	←	√		K/C
Center	0.0000s	←	←	√		K/C
Span	20.000ns	←	←	√		K/C
Type	Bandpass	←	←	√		K/C
Window	Normal	←	←	√		K/C
Impulse Width	229.55ps	←	←	√		K/C
Kaiser Beta	6.0000	←	←	√		K/C
Conversion						
Conversion	OFF	←	←	√		K/C

List of Default Values
List of Default Values, Save/Recall Settings, and Backup Settings

Key Operation	Factory-shipped Setting	Default Value		Save/ Recall	Backup	Available Means of Defining a Setting
		Preset	*RST			
Function	Z:Reflection	←	←	√		K/C
Limit Test						
Limit Test	OFF	←	←	√		K/C
Limit Line	OFF	←	←	√		K/C
Fail Sign	ON	←	←	√		K/C
Macro Setup						
Echo Window	OFF	←	←	√		K/C
Save/Recall						
Save Type	State&Cal	←	←	√		K/C
System						
Invert Image	ON	←	←	√		K/C
E5091A Setup						
Select ID	1	←	←	√		K
Port 1	A	←	←	√		K/C
Port 2	T1	←	←	√		K/C
Port 3	R1+	←	←	√		K/C
Port 4	R1-	←	←	√		K/C
Control Lines						
Line 1 ... Line 8	LOW	←	←	√		K/C
E5091A Property	OFF	←	←	√		K/C
E5091A Control	OFF	←	←	√		K/C
Misc Setup						
Beeper						
Beep Complete	ON	←	←	√		K/C
Beep Warning	ON	←	←	√		K/C
GPIB Setup						
GPIB Configuration	Talker/Listener	Non-changing	←		√	K
Talker/Listener Address	17	Non-changing	←		√	K

List of Default Values

List of Default Values, Save/Recall Settings, and Backup Settings

Key Operation	Factory-shipped Setting	Default Value		Save/Recall	Backup	Available Means of Defining a Setting
		Preset	*RST			
System Controller Address	21	Non-changing	←		√	K
Network Setup						
Telnet Server	OFF	Non-changing	←		√	K
Network Device	ENABLE	Non-changing	←		√	K
Clock Setup						
Show Clock	ON	←	←	√		K/C
Key Lock						
Front Panel & Keyboard Lock	OFF	←	←			K/C
Mouse Lock	OFF	←	←			K/C
Color Setup						
Normal						
Data Trace 1	Red:5 Green:5 Blue:0	←	←	√		K/C
Data Trace 2	Red:0 Green:5 Blue:5	←	←	√		K/C
Data Trace 3	Red:5 Green:0 Blue:5	←	←	√		K/C
Data Trace 4	Red:0 Green:5 Blue:0	←	←	√		K/C
Data Trace 5	Red:5 Green:4 Blue:0	←	←	√		K/C
Data Trace 6	Red:5 Green:3 Blue:3	←	←	√		K/C
Data Trace 7	Red:3 Green:4 Blue:5	←	←	√		K/C
Data Trace 8	Red:5 Green:4 Blue:4	←	←	√		K/C
Data Trace 9	Red:3 Green:4 Blue:3	←	←	√		K/C
Mem Trace 1	Red:3 Green:3 Blue:0	←	←	√		K/C
Mem Trace 2	Red:0 Green:3 Blue:3	←	←	√		K/C

List of Default Values
List of Default Values, Save/Recall Settings, and Backup Settings

Key Operation	Factory-shipped Setting	Default Value		Save/ Recall	Backup	Available Means of Defining a Setting
		Preset	*RST			
Mem Trace 3	Red:3 Green:0 Blue:3	←	←	√		K/C
Mem Trace 4	Red:0 Green:3 Blue:0	←	←	√		K/C
Mem Trace 5	Red:3 Green:2 Blue:0	←	←	√		K/C
Mem Trace 6	Red:3 Green:1 Blue:1	←	←	√		K/C
Mem Trace 7	Red:1 Green:2 Blue:3	←	←	√		K/C
Mem Trace 8	Red:3 Green:2 Blue:2	←	←	√		K/C
Mem Trace 9	Red:1 Green:2 Blue:1	←	←	√		K/C
Graticule Main	Red:3 Green:3 Blue:3	←	←	√		K/C
Graticule Sub	Red:1 Green:1 Blue:1	←	←	√		K/C
Limit Fail	Red:5 Green:0 Blue:0	←	←	√		K/C
Limit Line	Red:3 Green:0 Blue:0	←	←	√		K/C
Background	Red:0 Green:0 Blue:0	←	←	√		K/C
Backlight	ON	←	←			K/C
Service Menu						
System Correction	ON	←	←	√		K/C
Avoid Spurious	ON	←	←	√		K/C
High Temperature	OFF	←	←	√		K/C

List of Default Values

List of Default Values, Save/Recall Settings, and Backup Settings

D **Softkey Functions**

This appendix explains the functions of softkeys and hardkeys supplied on the Agilent E5070A/E5071A.

E5070A/E5071A Menu (Top Menu)

Key Operation	Function
Double-click on each softkey menu title	Displays the top menu of each menu item below. A preset operation will not cancel the menu display.
Measurement	Same as Meas . See “Measurement Menu” on page 435.
Format	Same as Format . See “Format Menu” on page 428.
Scale	Same as Scale . See “Scale Menu” on page 444.
Display	Same as Display . See “Display Menu” on page 424.
Average	Same as Avg . See “Average Menu” on page 413.
Calibration	Same as Cal . See “Calibration Menu” on page 414.
Stimulus	Displays the same softkey for setting up the sweep range that appears when Start , Stop , Center , or Span is pressed. See “Stimulus Menu” on page 445.
Sweep Setup	Same as Sweep Setup . See “Sweep Setup Menu” on page 446.
Trigger	Same as Trigger . See “Trigger Menu” on page 452.
Marker	Same as Marker . See “Marker Menu” on page 430.
Marker Search	Same as Marker Search . See “Marker Search Menu” on page 433.
Marker Function	Same as Marker Fctn . See “Marker Function Menu” on page 432.
Analysis	Same as Analysis . See “Analysis Menu” on page 405.
Macro Setup	Same as Macro Setup . See “Macro Setup Menu” on page 429.
Save/Recall	Same as Save/Recall . See “Save/Recall Menu” on page 442.
System	Same as System . See “System Menu” on page 448.
Preset	Same as Preset . See “Preset Menu” on page 441.

Analysis Menu

Key Operation	Function	SCPI Command
Analysis	Displays softkeys for performing analysis functions.	
Fixture Simulator	Displays softkeys for setting up fixture simulator functions. The fixture simulator is software that uses measurement results to simulate various measurement conditions. The fixture simulator consists of the following six functions: balanced/unbalanced conversion (use Topology and BalUn to set up), matching circuit (use Port Matching), port impedance conversion (use Port Z Conversion), network de-embedding (use De-Embedding), differential matching circuit (use Diff. Matching), and differential impedance conversion (use Diff. Z Conversion). To use each of the above functions, each must be enabled at the same time you enable the fixture simulator using the Fixture Simulator key below.	
Fixture Simulator *1	Enables or disables the fixture simulator function. When using one or more of the six functions provided with the fixture simulator, the fixture simulator function must be enabled using this key along with all desired functions.	:CALC{1-9};FSIM:STAT
Topology *1	Displays softkeys for setting the balanced measurement topology (the types of DUT ports and the connecting method to test the ports).	
Device	Displays softkeys for selecting the types of DUT ports in a balanced measurement.	
SE-Bal	Evaluates mixed mode S parameters between a single-end (unbalanced) port and balanced port on the DUT. In the succeeding procedure, the single-end port and the balanced port will be treated as port 1 on the DUT (logical port 1) and port 2 on the DUT (logical port 2), respectively.	:CALC{1-9};FSIM:BAL:DEV SBAL
Bal-Bal *2	Evaluates mixed mode S parameters between two balanced ports on the DUT. In the succeeding procedure, the two balanced ports will be treated as port 1 on the DUT (logical port 1) and port 2 on the DUT (logical port 2).	:CALC{1-9};FSIM:BAL:DEV BBAL
SE-SE-Bal *2	Evaluates mixed mode S parameters between two single-end (unbalanced) ports and balanced port on the DUT. In the succeeding procedure, the two single-end ports will be treated as port 1 on the DUT (logical port 1) and port 2 on the DUT (logical port 2), and the balanced port as port 3 on the DUT (logical port 3).	:CALC{1-9};FSIM:BAL:DEV SSB
Cancel	Returns to the softkey display screen one level higher.	
Port1 (se)	Displays softkeys for selecting the analyzer port (test port) to which (single-end) port 1 on the DUT will be connected. This key will be displayed only when SE-Bal or SE-SE-Bal in the Device menu is selected.	
1	Selects test port 1 on the analyzer for connection with (single-end) port 1 on the DUT.	:CALC{1-9};FSIM:BAL:TOP:SBAL :CALC{1-9};FSIM:BAL:TOP:SSB
2	Selects test port 2 on the analyzer for connection with (single-end) port 1 on the DUT.	:CALC{1-9};FSIM:BAL:TOP:SBAL :CALC{1-9};FSIM:BAL:TOP:SSB
3	Selects test port 3 on the analyzer for connection with (single-end) port 1 on the DUT.	:CALC{1-9};FSIM:BAL:TOP:SBAL :CALC{1-9};FSIM:BAL:TOP:SSB
4 *2	Selects test port 4 on the analyzer for connection with (single-end) port 1 on the DUT.	:CALC{1-9};FSIM:BAL:TOP:SBAL :CALC{1-9};FSIM:BAL:TOP:SSB
Cancel	Returns to the softkey display screen one level higher.	
Port1 (bal) *2	Displays softkeys for selecting the analyzer ports (test ports) to which (balanced) port 1 on the DUT will be connected. This key will be displayed only when Bal-Bal in the Device menu is selected.	
1-2	Selects test ports 1 and 2 on the analyzer for connection with (balanced) port 1 on the DUT.	:CALC{1-9};FSIM:BAL:TOP:BBAL
1-3	Selects test ports 1 and 3 on the analyzer for connection with (balanced) port 1 on the DUT.	:CALC{1-9};FSIM:BAL:TOP:BBAL
1-4	Selects test ports 1 and 4 on the analyzer for connection with (balanced) port 1 on the DUT.	:CALC{1-9};FSIM:BAL:TOP:BBAL

Softkey Functions
Analysis Menu

Key Operation	Function	SCPI Command
Analysis	(Continued)	
Fixture Simulator		
Topology * ¹		
Port1 (bal) * ²		
2-3	Selects test ports 2 and 3 on the analyzer for connection with (balanced) port 1 on the DUT.	:CALC{1-9}:FSIM:BAL:TOP:BBAL
2-4	Selects test ports 2 and 4 on the analyzer for connection with (balanced) port 1 on the DUT.	:CALC{1-9}:FSIM:BAL:TOP:BBAL
3-4	Selects test ports 3 and 4 on the analyzer for connection with (balanced) port 1 on the DUT.	:CALC{1-9}:FSIM:BAL:TOP:BBAL
Cancel	Returns to the softkey display screen one level higher.	
Port2 (bal)	Displays softkeys for selecting the analyzer ports (test ports) to which (balanced) port 2 on the DUT will be connected. This key will be displayed only when SE-Bal or Bal-Bal in the Device menu is selected.	
1-2	Selects test ports 1 and 2 on the analyzer for connection with (balanced) port 2 on the DUT.	:CALC{1-9}:FSIM:BAL:TOP:BBAL :CALC{1-9}:FSIM:BAL:TOP:SBAL
1-3	Selects test ports 1 and 3 on the analyzer for connection with (balanced) port 2 on the DUT.	:CALC{1-9}:FSIM:BAL:TOP:BBAL :CALC{1-9}:FSIM:BAL:TOP:SBAL
1-4 * ²	Selects test ports 1 and 4 on the analyzer for connection with (balanced) port 2 on the DUT.	:CALC{1-9}:FSIM:BAL:TOP:BBAL :CALC{1-9}:FSIM:BAL:TOP:SBAL
2-3	Selects test ports 2 and 3 on the analyzer for connection with (balanced) port 2 on the DUT.	:CALC{1-9}:FSIM:BAL:TOP:BBAL :CALC{1-9}:FSIM:BAL:TOP:SBAL
2-4 * ²	Selects test ports 2 and 4 on the analyzer for connection with (balanced) port 2 on the DUT.	:CALC{1-9}:FSIM:BAL:TOP:BBAL :CALC{1-9}:FSIM:BAL:TOP:SBAL
3-4 * ²	Selects test ports 3 and 4 on the analyzer for connection with (balanced) port 2 on the DUT.	:CALC{1-9}:FSIM:BAL:TOP:BBAL :CALC{1-9}:FSIM:BAL:TOP:SBAL
Cancel	Returns to the softkey display screen one level higher.	
Port2 (se) * ²	Displays softkeys for selecting the analyzer port (test port) to which (single-end) port 2 on the DUT will be connected. This key will be displayed only when SE-SE-Bal in the Device menu is selected.	
1	Selects test port 1 on the analyzer for connection with (single-end) port 2 on the DUT.	:CALC{1-9}:FSIM:BAL:TOP:SSB
2	Selects test port 2 on the analyzer for connection with (single-end) port 2 on the DUT.	:CALC{1-9}:FSIM:BAL:TOP:SSB
3	Selects test port 3 on the analyzer for connection with (single-end) port 2 on the DUT.	:CALC{1-9}:FSIM:BAL:TOP:SSB
4	Selects test port 4 on the analyzer for connection with (single-end) port 2 on the DUT.	:CALC{1-9}:FSIM:BAL:TOP:SSB
Cancel	Returns to the softkey display screen one level higher.	
Port3 (bal) * ²	Displays softkeys for selecting the analyzer ports (test ports) to which (balanced) port 3 on the DUT will be connected. This key will be displayed only when SE-SE-Bal in the Device menu is selected.	
1-2	Selects test ports 1 and 2 on the analyzer for connection with (balanced) port 3 on the DUT.	:CALC{1-9}:FSIM:BAL:TOP:SSB
1-3	Selects test ports 1 and 3 on the analyzer for connection with (balanced) port 3 on the DUT.	:CALC{1-9}:FSIM:BAL:TOP:SSB
1-4	Selects test ports 1 and 4 on the analyzer for connection with (balanced) port 3 on the DUT.	:CALC{1-9}:FSIM:BAL:TOP:SSB
2-3	Selects test ports 2 and 3 on the analyzer for connection with (balanced) port 3 on the DUT.	:CALC{1-9}:FSIM:BAL:TOP:SSB

Key Operation	Function	SCPI Command
Analysis	(Continued)	
Fixture Simulator		
Topology ^{*1}		
Port1 (bal) ^{*2}		
2-4	Selects test ports 2 and 4 on the analyzer for connection with (balanced) port 3 on the DUT.	:CALC{1-9}:FSIM:BAL:TOP:SSB
3-4	Selects test ports 3 and 4 on the analyzer for connection with (balanced) port 3 on the DUT.	:CALC{1-9}:FSIM:BAL:TOP:SSB
Cancel	Returns to the softkey display screen one level higher.	
Return	Returns to the softkey display screen one level higher.	
BalUn ^{*1}	Enables or disables the balanced/unbalanced conversion function of active trace. This function uses internal software to convert the results obtained from an unbalanced test port on the E5070A/E5071A into characteristics of a balanced port. The port converted into a balanced port will be characterized by a common mode signal and a differential mode signal. Measurement parameters are expressed as mixed mode S parameters. Use the Topology to select the type of DUT port and the connection method to test the ports.	:CALC{1-9}:FSIM:BAL:STAT
Balun OFF All Traces ^{*1}	Disables the balanced/unbalanced conversion function of all displayed traces.	None
Balun ON All Traces ^{*1}	Enables the balanced/unbalanced conversion function of all displayed traces.	None
Measurement	Same as Meas . See “Measurement Menu” on page 435.	
Port Matching	Displays softkeys for setting up the matching circuit function. Based on the measurement results, the matching circuit function uses internal software to determine characteristics with a matching circuit inserted between the DUT and the test ports.	
Port Matching	Enables or disables the matching circuit function.	:CALC{1-9}:FSIM:SEND:PMC:STAT
Select Port	Displays softkeys for selecting the test port to which a matching circuit is added.	
1	Selects test port 1 for adding a matching circuit.	:CALC{1-9}:FSIM:SEND:PMC:PORT1
2	Selects test port 2 for adding a matching circuit.	:CALC{1-9}:FSIM:SEND:PMC:PORT2
3 ^{*1}	Selects test port 3 for adding a matching circuit.	:CALC{1-9}:FSIM:SEND:PMC:PORT3
4 ^{*2}	Selects test port 4 for adding a matching circuit.	:CALC{1-9}:FSIM:SEND:PMC:PORT4
Cancel	Returns to the softkey display screen one level higher.	
Select Circuit	Displays softkeys for selecting the type of matching circuit to be added.	
None	Does not add any matching circuit to the port selected in the Select Port menu.	:CALC{1-9}:FSIM:SEND:PMC:PORT{1-4} NONE
SeriesL - ShuntC	Adds a series L - shunt C type matching circuit to the port selected in the Select Port menu.	:CALC{1-9}:FSIM:SEND:PMC:PORT{1-4} SLPC
ShuntC - SeriesL	Adds a shunt C - series L type matching circuit to the port selected in the Select Port menu.	:CALC{1-9}:FSIM:SEND:PMC:PORT{1-4} PCSL
ShuntL - SeriesC	Adds a shunt L - series C type matching circuit to the port selected in the Select Port menu.	:CALC{1-9}:FSIM:SEND:PMC:PORT{1-4} PLSC
SeriesC - ShuntL	Adds a series C - shunt L type matching circuit to the port selected in the Select Port menu.	:CALC{1-9}:FSIM:SEND:PMC:PORT{1-4} SCPL
ShuntL - ShuntC	Adds a shunt L - shunt C type matching circuit to the port selected in the Select Port menu.	:CALC{1-9}:FSIM:SEND:PMC:PORT{1-4} PLPC

Softkey Functions Analysis Menu

Key Operation	Function	SCPI Command
Analysis	(Continued)	
Fixture Simulator		
Port Matching		
Select Circuit		
User	Adds a user-defined matching circuit to the port selected in the Select Port menu. The user-defined matching circuit must be prepared in the 2-port Touchstone data format and loaded onto the E5070A/E5071A from the User File menu.	:CALC{1-9}:FSIM:SEND:PMC:PORT{1-4} USER
Cancel	Returns to the softkey display screen one level higher.	
C	Sets the value of C for the matching circuit selected in the Select Circuit menu for addition to the port selected in the Select Port menu.	:CALC{1-9}:FSIM:SEND:PMC:PORT{1-4}:PAR:C
G	Sets the value of G for the matching circuit selected in the Select Circuit menu for addition to the port selected in the Select Port menu.	:CALC{1-9}:FSIM:SEND:PMC:PORT{1-4}:PAR:G
L	Sets the value of L for the matching circuit selected in the Select Circuit menu for addition to the port selected in the Select Port menu.	:CALC{1-9}:FSIM:SEND:PMC:PORT{1-4}:PAR:L
R	Sets the value of R for the matching circuit selected in the Select Circuit menu for addition to the port selected in the Select Port menu.	:CALC{1-9}:FSIM:SEND:PMC:PORT{1-4}:PAR:R
User File	Opens a dialog box for loading a user-defined 2-port Touchstone data file. The loaded matching circuit can be added to ports by selecting User in the Select Circuit menu.	:CALC{1-9}:FSIM:SEND:PMC:PORT{1-4}:USER:FIL
Return	Returns to the softkey display screen one level higher.	
Port ZConversion	Displays softkeys for setting up the port impedance conversion function. This function is included in internal software that converts S parameters determined with a 50 Ω reference port impedance to S parameters for arbitrary port impedance.	
Port ZConversion	Enables or disables the port impedance conversion function.	:CALC{1-9}:FSIM:SEND:ZCON: STAT
Port 1 Z0	Sets the reference impedance of port 1.	:CALC{1-9}:FSIM:SEND:ZCON:PORT1:Z0
Port 2 Z0	Sets the reference impedance of port 2.	:CALC{1-9}:FSIM:SEND:ZCON:PORT2:Z0
Port 3 Z0* ¹	Sets the reference impedance of port 3.	:CALC{1-9}:FSIM:SEND:ZCON:PORT3:Z0
Port 4 Z0* ²	Sets the reference impedance of port 4.	:CALC{1-9}:FSIM:SEND:ZCON:PORT4:Z0
Return	Returns to the softkey display screen one level higher.	
De-Embedding	Displays softkeys for setting up the network de-embedding function. Network de-embedding is a function used to eliminate any user-defined network (with a reference impedance of 50 Ω) supplied in a 2-port Touchstone data file, from desired test ports to extend the calibration plane.	
De-Embedding	Enables or disables the network de-embedding function.	:CALC{1-9}:FSIM:SEND:DEEM:STAT
Select Port	Displays softkeys for selecting test ports for which network de-embedding will be performed.	
1	Selects test port 1 for performing network de-embedding.	:CALC{1-9}:FSIM:SEND:DEEM:PORT1
2	Selects test port 2 for performing network de-embedding.	:CALC{1-9}:FSIM:SEND:DEEM:PORT2
3* ¹	Selects test port 3 for performing network de-embedding.	:CALC{1-9}:FSIM:SEND:DEEM:PORT3
4* ²	Selects test port 4 for performing network de-embedding.	:CALC{1-9}:FSIM:SEND:DEEM:PORT4
Cancel	Returns to the softkey display screen one level higher.	

Key Operation	Function	SCPI Command
Analysis	(Continued)	
Fixture Simulator		
De-Embedding		
Select Type	Displays softkeys for selecting the type of network de-embedding to be performed on the test port selected in the Select Port menu.	
None	Does not allow network de-embedding on the test port selected in the Select Port menu.	:CALC{1-9};FSIM:SEND:DEEM:PORT{1-4} NONE
User	De-embeds a user-defined network from the test port selected in the Select Port menu. The user-defined network should be prepared in the 2-port Touchstone data format and loaded onto the E5070A/E5071A from the User File menu.	:CALC{1-9};FSIM:SEND:DEEM:PORT{1-4} USER
Cancel	Returns to the softkey display screen one level higher.	
User File	Opens a dialog box for reading a 2-port Touchstone data file prepared by the user. Selecting User in the Select Type menu will de-embed the loaded network.	:CALC{1-9};FSIM:SEND:DEEM:PORT{1-4}:USER:FILE
Return	Returns to the softkey display screen one level higher.	
Diff Matching*1	Displays softkeys for setting up the differential matching circuit function. This function uses internal software to convert the characteristics of a balanced port to those with an inserted differential matching circuit.	
Diff. Matching	Enables or disables the differential matching circuit function.	:CALC{1-9};FSIM:BAL:DMC:STAT
Select Bal Port	Displays softkeys for selecting a balanced port to which a differential matching circuit will be added.	
1*2	Selects port 1 on the DUT for adding a differential matching circuit.	:CALC{1-9};FSIM:BAL:DMC:BPOR1
2	Selects port 2 on the DUT for adding a differential matching circuit.	:CALC{1-9};FSIM:BAL:DMC:BPOR{1-2}
3*2	Selects port 3 on the DUT for adding a differential matching circuit.	:CALC{1-9};FSIM:BAL:DMC:BPOR1
Cancel	Returns to the softkey display screen one level higher.	
Select Circuit	Displays softkeys for selecting the type of differential matching circuit.	
None	Does not allow a differential matching circuit to be added to the balanced port selected in the Select Bal Port menu.	:CALC{1-9};FSIM:BAL:DMC:BPOR{1-2} NONE
ShuntL - ShuntC	Adds a shunt L - shunt C type differential matching circuit to the port selected in the Select Bal Port menu.	:CALC{1-9};FSIM:BAL:DMC:BPOR{1-2} PLPC
User	Adds a user-defined differential matching circuit to the port selected in the Select Bal Port menu. The user-defined differential matching circuit should be provided in the 2-port Touchstone data format and loaded onto the E5070A/E5071A from the User File menu.	:CALC{1-9};FSIM:BAL:DMC:BPOR{1-2} USER
Cancel	Returns to the softkey display screen one level higher.	
C	Sets the value of C for the shunt L - shunt C differential matching circuit to be added to the balanced port selected in the Select Bal Port menu.	:CALC{1-9};FSIM:BAL:DMC:BPOR{1-2}:PAR:C
G	Sets the value of G for the shunt L - shunt C differential matching circuit to be added to the balanced port selected in the Select Bal Port menu.	:CALC{1-9};FSIM:BAL:DMC:BPOR{1-2}:PAR:G
L	Sets the value of L for the shunt L - shunt C differential matching circuit to be added to the balanced port selected in the Select Bal Port menu.	:CALC{1-9};FSIM:BAL:DMC:BPOR{1-2}:PAR:L
R	Sets the value of R for the shunt L - shunt C differential matching circuit to be added to the balanced port selected in the Select Bal Port menu.	:CALC{1-9};FSIM:BAL:DMC:BPOR{1-2}:PAR:R
User File	Opens a dialog box for reading a 2-port Touchstone data file prepared by the user. Selecting User in the Select Circuit menu adds the loaded differential matching circuit.	:CALC{1-9};FSIM:BAL:DMC:BPOR{1-2}:USER:FILE
Return	Returns to the softkey display screen one level higher.	

Softkey Functions
Analysis Menu

Key Operation	Function	SCPI Command
Analysis	(Continued)	
Fixture Simulator		
Diff ZConversion *1	Displays softkeys for setting up the differential impedance conversion function. When the reference impedance of two unbalanced ports is expressed as Z_0 , an automatic conversion sets the differential mode reference impedance of the converted balanced port to $2Z_0$ and the common mode reference impedance to $Z_0/2$. Differential impedance conversion is a function that further converts $2Z_0$ into another reference impedance.	
Diff ZConversion	Enables or disables the differential impedance conversion function.	:CALC{1-9}:FSIM:BAL:DZC:STAT
Port1 (bal) *2	Sets the differential reference impedance of balanced port 1.	:CALC{1-9}:FSIM:BAL:DZC:BPOR1:Z0
Port2 (bal)	Sets the differential reference impedance of balanced port 2.	:CALC{1-9}:FSIM:BAL:DZC:BPOR{1-2}:Z0
Port3 (bal) *2	Sets the differential reference impedance of balanced port 3.	:CALC{1-9}:FSIM:BAL:DZC:BPOR1:Z0
Return	Returns to the softkey display screen one level higher.	
Return	Returns to the softkey display screen one level higher.	
Cmn ZConversion *1	Displays softkeys for setting up the common impedance conversion function. When the reference impedance of two unbalanced ports is expressed as Z_0 , an automatic conversion sets the differential mode reference impedance of the converted balanced port to $2Z_0$ and the common mode reference impedance to $Z_0/2$. Common impedance conversion is a function that further converts $Z_0/2$ into another reference impedance.	
Cmn ZConversion	Enables or disables the common impedance conversion function.	:CALC{1-9}:FSIM:BAL:CZC:STAT
Port1 (bal) *2	Sets the common reference impedance of balanced port 1.	:CALC{1-9}:FSIM:BAL:CZC:BPOR1:Z0
Port2 (bal)	Sets the common reference impedance of balanced port 2.	:CALC{1-9}:FSIM:BAL:CZC:BPOR{1-2}:Z0
Port3 (bal) *2	Sets the common reference impedance of balanced port 3.	:CALC{1-9}:FSIM:BAL:CZC:BPOR1:Z0
Return	Returns to the softkey display screen one level higher.	
Return	Returns to the softkey display screen one level higher.	
Gating	Displays softkeys for setting up the gating function of the time domain function.	
Gating	Enables or disables the gating function.	:CALC{1-9}:FILT:TIME:STAT
Start	Sets the start value of the gate.	:CALC{1-9}:FILT:TIME:STAR
Stop	Sets the stop value of the gate.	:CALC{1-9}:FILT:TIME:STOP
Center	Sets the center value of the gate.	:CALC{1-9}:FILT:TIME:CENT
Span	Sets the span value of the gate.	:CALC{1-9}:FILT:TIME:SPAN
Type	Sets a type of the gate (bandpass/notch).	:CALC{1-9}:FILT:TIME:SPAN
Shape	Displays softkeys for selecting a shape of the gate.	
Maximum	Selects the maximum shape.	:CALC{1-9}:FILT:TIME:SHAP MAX
Wide	Selects the wide shape.	:CALC{1-9}:FILT:TIME:SHAP WIDE
Normal	Selects the normal shape.	:CALC{1-9}:FILT:TIME:SHAP NORM
Minimum	Selects the minimum shape.	:CALC{1-9}:FILT:TIME:SHAP MIN
Cancel	Returns to the softkey display screen one level higher.	
Return	Returns to the softkey display screen one level higher.	
Transform	Displays softkeys for setting up the transform function of the time domain function.	
Transform	Enables or disables the transform function.	:CALC{1-9}:TRAN:TIME:STAT
Start	Sets the start value.	:CALC{1-9}:TRAN:TIME:STAR
Stop	Sets the stop value.	:CALC{1-9}:TRAN:TIME:STOP

Key Operation	Function	SCPI Command
Analysis	(Continued)	
Transform		
Center	Sets the center value.	:CALC{1-9};TRAN:TIME:CENT
Span	Sets the span value.	:CALC{1-9};TRAN:TIME:SPAN
Set Freq Low Pass	???.	:CALC{1-9};TRAN:TIME:LPFR
Type	Displays softkeys for selecting a type of the transform.	
Bandpass	Selects the bandpass mode.	:CALC{1-9};TRAN:TIME BPAS
Lowpass Step	Selects the lowpass step mode.	:CALC{1-9};TRAN:TIME LPAS :CALC{1-9};TRAN:TIME:STIM STEP
Lowpass Imp	Selects the lowpass impulse mode.	:CALC{1-9};TRAN:TIME LPAS :CALC{1-9};TRAN:TIME:STIM STEP
Cancel	Returns to the softkey display screen one level higher.	
Window	Displays softkeys for selecting a type of the window.	
Maximum	Selects the maximum type.	:CALC{1-9};TRAN:TIME KBES 13
Normal	Selects the normal type.	:CALC{1-9};TRAN:TIME KBES 6
Minimum	Selects the minimum type.	:CALC{1-9};TRAN:TIME KBES 0
User	Displays softkeys for setting up the user window shape.	
Impulse Width	Sets the impulse width value.	:CALC{1-9};TRAN:TIME IMP:WIDT
Rise Time	Sets the rise time of the step signal.	:CALC{1-9};TRAN:TIME STEP:RTIM
Kaiser Beta	Sets the β value of Kaiser Bessel window.	:CALC{1-9};TRAN:TIME KBES
Return	Returns to the softkey display screen one level higher.	
Return	Returns to the softkey display screen one level higher.	
Return	Returns to the softkey display screen one level higher.	
Conversion	Displays softkeys for setting up the conversion function.	
Conversion	Enables or disables the conversion function.	:CALC{1-9};CONV
Function	Displays softkeys for selecting a converted parameter.	
Z:Reflection	???.	:CALC{1-9};CONV:FUNC ZREF
Z:Transmission	???.	:CALC{1-9};CONV:FUNC ZTR
Y:Reflection	???.	:CALC{1-9};CONV:FUNC YREF
Y:Transmission	???.	:CALC{1-9};CONV:FUNC YTR
1/S	???.	:CALC{1-9};CONV:FUNC INV
Cancel	Returns to the softkey display screen one level higher.	
Return	Returns to the softkey display screen one level higher.	
Limit Test	Displays softkeys for setting up the limit test function.	
Limit Test	Enables or disables the limit test function.	:CALC{1-9};LIM
Limit Line	Enables or disables the limit line display.	:CALC{1-9};LIM:DISP
Edit Limit Line	Displays softkeys for editing the limit line.	
Delete	Deletes the line at the cursor from the limit table.	:CALC{1-9};LIM:DATA
Add	Adds a new segment to the limit table under the line on which the cursor is located.	:CALC{1-9};LIM:DATA
Clear Limit Table	Displays softkeys for clearing the contents of the limit table.	:CALC{1-9};LIM:DATA
OK	Deletes all segments in the limit table.	:CALC{1-9};LIM:DATA
Cancel	Returns to the softkey display screen one level higher.	

Softkey Functions Analysis Menu

Key Operation	Function	SCPI Command
Analysis	(Continued)	
Transform		
Edit Limit Line		
Export to CSV File	Exports (saves the data in formats used by other software) the limit table to a CSV (comma-separated value) file.	:MMEM:STOR:LIM
Import from CSV File	Imports (loads the data from files in different formats) a CSV (comma-separated value) file to the limit table.	:MMEM:LOAD:LIM
Return	Returns to the softkey display screen one level higher.	
Fail Sign	Turns on/off the display of the limit test fail sign.	:DISP:FSIG
Return	Returns to the softkey display screen one level higher.	
Return	Returns to the “E5070A/E5071A Menu (Top Menu)” on page 404.	

*1. Only with Options 313, 314, 413, and 414.

*2. Only with Options 413 and 414.

Average Menu

Key Operation	Function	SCPI Command
Avg	Displays softkeys for setting averaging options.	
Averaging Restart	Resets the counter and restarts from “1”.	:SENS{1-9}:AVER:CLE
Avg Factor	Sets the averaging factor. The averaging factor must be defined as an integer from 1 to 999.	:SENS{1-9}:AVER:COUN
Averaging	Enables or disables averaging execution	:SENS{1-9}:AVER
Smo Aperture	Sets the smoothing aperture using a percentage against the sweep span	:CALC{1-9}:SMO:APER
Smoothing	Enables or disables the smoothing function. When enabled, the letters “Smo” will appear in the trace status area.	:CALC{1-9}:SMO:STAT
IF Bandwidth	Sets the IF bandwidth. For more about the effective range of the IF bandwidth, refer to “Specifications and Reference Data”. If an input value is out of the range, it will automatically be modified to the closest value in the effective range. A narrow IF bandwidth slows down the sweep speed, but improves the S/N ratio.	:SENS{1-9}:BAND or :SENS{1-9}:BWID
Return	Returns to the “E5070A/E5071A Menu (Top Menu)” on page 404.	

Calibration Menu

Key Operation	Function	SCPI Command
Cal	Displays softkeys for setting and executing calibrations.	
Correction	Enables or disables error correction.	:SENS{1-9}:CORR:STAT
Calibrate	Displays softkeys for selecting calibration options.	
Response (Open)	Displays softkeys for selecting options for response calibration using the OPEN standard.	
Select Port	Displays softkeys for selecting a test port.	
1	Selects test port 1.	:SENS{1-9}:CORR:COLL:METH:OPEN 1
2	Selects test port 2.	:SENS{1-9}:CORR:COLL:METH:OPEN 2
3^{*1}	Selects test port 3.	:SENS{1-9}:CORR:COLL:METH:OPEN 3
4^{*2}	Selects test port 4.	:SENS{1-9}:CORR:COLL:METH:OPEN 4
Cancel	Returns to the softkey display screen one level higher.	
Open	Executes a response calibration using the OPEN standard on the test port selected in the Select Port menu. This calibration is effective for eliminating response tracking errors.	:SENS{1-9}:CORR:COLL:OPEN
Load (Optional)	Executes an isolation calibration using the LOAD standard on the test port selected in the Select Port menu. This calibration is effective for eliminating directivity errors.	:SENS{1-9}:CORR:COLL:LOAD
Done	Terminates a calibration process and calculates the calibration coefficients.	:SENS{1-9}:CORR:COLL:SAVE
Cancel	Displays softkeys for canceling a calibration.	
OK	Cancels the calibration in progress.	None
Cancel	Returns to the softkey display screen one level higher.	
Return	Returns to the softkey display screen one level higher.	
Response (Short)	Displays softkeys for selecting options for a response calibration using the SHORT standard.	
Select Port	Displays softkeys for selecting a test port.	
1	Selects test port 1.	:SENS{1-9}:CORR:COLL:METH:SHOR 1
2	Selects test port 2.	:SENS{1-9}:CORR:COLL:METH:SHOR 2
3^{*1}	Selects test port 3.	:SENS{1-9}:CORR:COLL:METH:SHOR 3
4^{*2}	Selects test port 4.	:SENS{1-9}:CORR:COLL:METH:SHOR 4
Cancel	Returns to the softkey display screen one level higher.	
Short	Executes a SHORT calibration on the test port selected in the Select Port menu. This calibration is effective for eliminating reflection tracking errors.	:SENS{1-9}:CORR:COLL:SHOR
Load (Optional)	Executes an isolation calibration using the LOAD standard on the test port selected in the Select Port menu. This calibration is effective for eliminating directivity errors.	:SENS{1-9}:CORR:COLL:LOAD
Done	Terminates a calibration process and calculates the calibration coefficients.	:SENS{1-9}:CORR:COLL:SAVE
Cancel	Displays softkeys for canceling a calibration.	
OK	Cancels the calibration in progress.	None
Cancel	Returns to the softkey display screen one level higher.	
Return	Returns to the softkey display screen one level higher.	

Key Operation	Function	SCPI Command
Cal	(Continued)	
Calibrate		
Response (Thru)	Displays softkeys for selecting options for response calibrations using the THRU standard.	
Select Ports	Displays softkeys for selecting test ports.	
2-1 (S21)	Selects the transmission test (measurement of S_{21}) for test port 1→2.	:SENS{1-9}:CORR:COLL:METH:THRU 2,1
3-1 (S31) ^{*1}	Selects the transmission test (measurement of S_{31}) for test port 1→3.	:SENS{1-9}:CORR:COLL:METH:THRU 3,1
4-1 (S41) ^{*2}	Selects the transmission test (measurement of S_{41}) for test port 1→4.	:SENS{1-9}:CORR:COLL:METH:THRU 4,1
1-2 (S12)	Selects the transmission test (measurement of S_{12}) for test port 2→1.	:SENS{1-9}:CORR:COLL:METH:THRU 1,2
3-2 (S32) ^{*1}	Selects the transmission test (measurement of S_{32}) for test port 2→3.	:SENS{1-9}:CORR:COLL:METH:THRU 3,2
4-2 (S42) ^{*2}	Selects the transmission test (measurement of S_{42}) for test port 2→4.	:SENS{1-9}:CORR:COLL:METH:THRU 4,2
1-3 (S13) ^{*1}	Selects the transmission test (measurement of S_{13}) for test port 3→1.	:SENS{1-9}:CORR:COLL:METH:THRU 1,3
2-3 (S23) ^{*1}	Selects the transmission test (measurement of S_{23}) for test port 3→2.	:SENS{1-9}:CORR:COLL:METH:THRU 2,3
4-3 (S43) ^{*2}	Selects the transmission test (measurement of S_{43}) for test port 3→4.	:SENS{1-9}:CORR:COLL:METH:THRU 4,3
1-4 (S14) ^{*2}	Selects the transmission test (measurement of S_{14}) for test port 4→1.	:SENS{1-9}:CORR:COLL:METH:THRU 1,4
2-4 (S24) ^{*2}	Selects the transmission test (measurement of S_{24}) for test port 4→2.	:SENS{1-9}:CORR:COLL:METH:THRU 2,4
3-4 (S34) ^{*2}	Selects the transmission test (measurement of S_{34}) for test port 4→3.	:SENS{1-9}:CORR:COLL:METH:THRU 3,4
Cancel	Returns to the softkey display screen one level higher.	
Thru	Executes a THRU response calibration on the test ports selected in the Select Ports menu. This calibration is effective for eliminating transmission tracking errors.	:SENS{1-9}:CORR:COLL:THRU
Isolation (Optional)	Executes an isolation calibration on the test ports selected in the Select Ports menu. This calibration is effective for eliminating isolation errors.	:SENS{1-9}:CORR:COLL:ISOL
Done	Terminates a calibration process and calculates the calibration coefficients.	:SENS{1-9}:CORR:COLL:SAVE
Cancel	Displays softkeys for canceling a calibration.	
OK	Cancels the calibration in progress.	None
Cancel	Returns to the softkey display screen one level higher.	
Return	Returns to the softkey display screen one level higher.	
1-Port Cal	Displays softkeys for executing 1-port calibrations.	
Select Port	Displays softkeys for selecting a test port.	
1	Selects test port 1.	:SENS{1-9}:CORR:COLL:METH:SOLT1 1
2	Selects test port 2.	:SENS{1-9}:CORR:COLL:METH:SOLT1 2
3 ^{*1}	Selects test port 3.	:SENS{1-9}:CORR:COLL:METH:SOLT1 3
4 ^{*2}	Selects test port 4.	:SENS{1-9}:CORR:COLL:METH:SOLT1 4

Softkey Functions Calibration Menu

Key Operation	Function	SCPI Command
Cal	(Continued)	
Calibrate		
1-Port Cal		
Select Port		
Cancel	Returns to the softkey display screen one level higher.	
Open	Executes an OPEN calibration on the test port selected in the Select Port menu.	:SENS{1-9}:CORR:COLL:OPEN
Short	Executes a SHORT calibration on the test port selected in the Select Port menu.	:SENS{1-9}:CORR:COLL:SHOR
Load	Executes a LOAD calibration on the test port selected in the Select Port menu.	:SENS{1-9}:CORR:COLL:LOAD
Done	Terminates a calibration process and calculates the calibration coefficients.	:SENS{1-9}:CORR:COLL:SAVE
Cancel	Displays softkeys for canceling a calibration.	
OK	Cancels the calibration in progress.	None
Cancel	Returns to the softkey display screen one level higher.	
Return	Returns to the softkey display screen one level higher.	
2-Port Cal	Displays softkeys for executing a full 2-port calibration.	
Select Ports *1	Displays softkeys for selecting test ports.	
1-2	Selects test ports 1 and 2.	:SENS{1-9}:CORR:COLL:METH:SOLT2 1,2
1-3	Selects test ports 1 and 3.	:SENS{1-9}:CORR:COLL:METH:SOLT2 1,3
1-4 *2	Selects test ports 1 and 4.	:SENS{1-9}:CORR:COLL:METH:SOLT2 1,4
2-3	Selects test ports 2 and 3.	:SENS{1-9}:CORR:COLL:METH:SOLT2 2,3
2-4 *2	Selects test ports 2 and 4.	:SENS{1-9}:CORR:COLL:METH:SOLT2 2,4
3-4 *2	Selects test ports 3 and 4.	:SENS{1-9}:CORR:COLL:METH:SOLT2 3,4
Cancel	Returns to the softkey display screen one level higher.	
Reflection	Displays softkeys for executing reflection calibrations. Symbols x and y refer to the two test ports selected in the Select Ports menu (x and y are always 1 and 2, respectively, for models with Option 213 or 214).	
Port x Open	Executes an OPEN reflection calibration on test port x.	:SENS{1-9}:CORR:COLL:OPEN x
Port x Short	Executes a SHORT reflection calibration on test port x.	:SENS{1-9}:CORR:COLL:SHOR x
Port x Load	Executes a LOAD reflection calibration on test port x.	:SENS{1-9}:CORR:COLL:LOAD x
Port y Open	Executes an OPEN reflection calibration on test port y.	:SENS{1-9}:CORR:COLL:OPEN y
Port y Short	Executes a SHORT reflection calibration on test port y.	:SENS{1-9}:CORR:COLL:SHOR y
Port y Load	Executes a LOAD reflection calibration on test port y.	:SENS{1-9}:CORR:COLL:LOAD y
Return	Returns to the softkey display screen one level higher.	
Transmission	Displays softkeys for executing transmission calibrations. Symbols x and y refer to the two test ports selected in the Select Ports menu (x and y are always 1 and 2, respectively, for models with Option 213 or 214).	
Port x-y Thru	Executes a THRU calibration on test ports x and y.	:SENS{1-9}:CORR:COLL:THRU x,y :SENS{1-9}:CORR:COLL:THRU y,x
Return	Returns to the softkey display screen one level higher.	
Isolation (Optional)	Displays softkeys for executing isolation calibrations. Symbols x and y refer to the two test ports selected in the Select Ports menu (x and y are always 1 and 2, respectively, for models with Option 213 or 214).	
Port x-y Isol	Executes an isolation calibration on test ports x and y.	:SENS{1-9}:CORR:COLL:ISOL x,y :SENS{1-9}:CORR:COLL:ISOL y,x
Return	Returns to the softkey display screen one level higher.	

Key Operation	Function	SCPI Command
Cal	(Continued)	
Calibrate		
2-Port Cal		
Done	Terminates a calibration process and calculates the calibration coefficients.	:SENS{1-9}:CORR:COLL:SAVE
Cancel	Displays softkeys for canceling a calibration.	
OK	Cancels the calibration in progress.	None
Cancel	Returns to the softkey display screen one level higher.	
Return	Returns to the softkey display screen one level higher.	
3-Port Cal ^{*1}	Displays softkeys for executing full 3-port calibrations.	
Select Ports ^{*2}	Displays softkeys for selecting test ports.	
1-2-3	Selects test ports 1, 2, and 3.	:SENS{1-9}:CORR:COLL:METH:SOLT3 1,2,3
1-2-4	Selects test ports 1, 2, and 4.	:SENS{1-9}:CORR:COLL:METH:SOLT3 1,2,4
1-3-4	Selects test ports 1, 3, and 4.	:SENS{1-9}:CORR:COLL:METH:SOLT3 1,3,4
2-3-4	Selects test ports 2, 3, and 4.	:SENS{1-9}:CORR:COLL:METH:SOLT3 2,3,4
Cancel	Returns to the softkey display screen one level higher.	
Reflection	Displays softkeys for executing reflection calibrations. Symbols x, y, and z refer to the three test ports selected in the Select Ports menu (x, y, and z are always 1, 2, and 3, respectively, for models with Option 313 or 314).	
Port x Open	Executes an OPEN reflection calibration on test port x.	:SENS{1-9}:CORR:COLL:OPEN x
Port x Short	Executes a SHORT reflection calibration on test port x.	:SENS{1-9}:CORR:COLL:SHOR x
Port x Load	Executes a LOAD reflection calibration on test port x.	:SENS{1-9}:CORR:COLL:LOAD x
Port y Open	Executes an OPEN reflection calibration on test port y.	:SENS{1-9}:CORR:COLL:OPEN y
Port y Short	Executes a SHORT reflection calibration on test port y.	:SENS{1-9}:CORR:COLL:SHOR y
Port y Load	Executes a LOAD reflection calibration on test port y.	:SENS{1-9}:CORR:COLL:LOAD y
Port z Open	Executes an OPEN reflection calibration on test port z.	:SENS{1-9}:CORR:COLL:OPEN z
Port z Short	Executes a SHORT reflection calibration on test port z.	:SENS{1-9}:CORR:COLL:SHOR z
Port z Load	Executes a LOAD reflection calibration on test port z.	:SENS{1-9}:CORR:COLL:LOAD z
Return	Returns to the softkey display screen one level higher.	
Transmission	Displays softkeys for executing transmission calibrations. Symbols x, y, and z refer to the three test ports selected in the Select Ports menu (x, y, and z are always 1, 2, and 3, respectively, for models with Option 313 or 314).	
Port x-y Thru	Executes a THRU calibration on test ports x and y.	:SENS{1-9}:CORR:COLL:THRU x,y :SENS{1-9}:CORR:COLL:THRU y,x
Port x-z Thru	Executes a THRU calibration on test ports x and z.	:SENS{1-9}:CORR:COLL:THRU x,z :SENS{1-9}:CORR:COLL:THRU z,x
Port y-z Thru	Executes a THRU calibration on test ports y and z.	:SENS{1-9}:CORR:COLL:THRU y,z :SENS{1-9}:CORR:COLL:THRU z,y
Return	Returns to the softkey display screen one level higher.	
Isolation (Optional)	Displays softkeys for executing isolation calibrations. Symbols x, y, and z refer to the three test ports selected in the Select Ports menu (x, y, and z are always 1, 2, and 3, respectively, for models with Option 313 or 314).	
Port x-y Isol	Executes an isolation test on test ports x and y.	:SENS{1-9}:CORR:COLL:ISOL x,y :SENS{1-9}:CORR:COLL:ISOL y,x
Port x-z Isol	Executes an isolation test on test ports x and z.	:SENS{1-9}:CORR:COLL:ISOL x,z :SENS{1-9}:CORR:COLL:ISOL z,x
Port y-z Isol	Executes an isolation test on test ports y and z.	:SENS{1-9}:CORR:COLL:ISOL y,z :SENS{1-9}:CORR:COLL:ISOL z,y
Return	Returns to the softkey display screen one level higher.	

Softkey Functions Calibration Menu

Key Operation	Function	SCPI Command
Cal	(Continued)	
Calibrate		
3-Port Cal* ¹		
Done	Terminates a calibration process and calculates the calibration coefficients.	:SENS{1-9}:CORR:COLL:SAVE
Cancel	Displays softkeys for canceling a calibration.	
OK	Cancels the calibration in progress.	None
Cancel	Returns to the softkey display screen one level higher.	
Return	Returns to the softkey display screen one level higher.	
4-Port Cal* ²	Displays softkeys for executing full 4-port calibrations.	
Reflection	Displays softkeys for executing reflection calibrations.	
Port 1 Open	Executes an OPEN calibration on test port 1.	:SENS{1-9}:CORR:COLL:OPEN 1
Port 1 Short	Executes a SHORT calibration on test port 1.	:SENS{1-9}:CORR:COLL:SHOR 1
Port 1 Load	Executes a LOAD calibration on test port 1.	:SENS{1-9}:CORR:COLL:LOAD 1
Port 2 Open	Executes an OPEN calibration on test port 2.	:SENS{1-9}:CORR:COLL:OPEN 2
Port 2 Short	Executes a SHORT calibration on test port 2.	:SENS{1-9}:CORR:COLL:SHOR 2
Port 2 Load	Executes a LOAD calibration on test port 2.	:SENS{1-9}:CORR:COLL:LOAD 2
Port 3 Open	Executes an OPEN calibration on test port 3.	:SENS{1-9}:CORR:COLL:OPEN 3
Port 3 Short	Executes a SHORT calibration on test port 3.	:SENS{1-9}:CORR:COLL:SHOR 3
Port 3 Load	Executes a LOAD calibration on test port 3.	:SENS{1-9}:CORR:COLL:LOAD 3
Port 4 Open	Executes an OPEN calibration on test port 4.	:SENS{1-9}:CORR:COLL:OPEN 4
Port 4 Short	Executes a SHORT calibration on test port 4.	:SENS{1-9}:CORR:COLL:SHOR 4
Port 4 Load	Executes a LOAD calibration on test port 4.	:SENS{1-9}:CORR:COLL:LOAD 4
Return	Returns to the softkey display screen one level higher.	
Transmission	Displays softkeys for executing transmission calibrations.	
Port 1-2 Thru	Executes a THRU calibration between test ports 1 and 2.	:SENS{1-9}:CORR:COLL:THRU 1,2 :SENS{1-9}:CORR:COLL:THRU 2,1
Port 1-3 Thru	Executes a THRU calibration between test ports 1 and 3.	:SENS{1-9}:CORR:COLL:THRU 1,3 :SENS{1-9}:CORR:COLL:THRU 3,1
Port 1-4 Thru	Executes a THRU calibration between test ports 1 and 4.	:SENS{1-9}:CORR:COLL:THRU 1,4 :SENS{1-9}:CORR:COLL:THRU 4,1
Port 2-3 Thru	Executes a THRU calibration between test ports 2 and 3.	:SENS{1-9}:CORR:COLL:THRU 2,3 :SENS{1-9}:CORR:COLL:THRU 3,2
Port 2-4 Thru	Executes a THRU calibration between test ports 2 and 4.	:SENS{1-9}:CORR:COLL:THRU 2,4 :SENS{1-9}:CORR:COLL:THRU 4,2
Port 3-4 Thru	Executes a THRU calibration between test ports 3 and 4.	:SENS{1-9}:CORR:COLL:THRU 3,4 :SENS{1-9}:CORR:COLL:THRU 4,3
Return	Returns to the softkey display screen one level higher.	
Isolation (Optional)	Displays softkeys for executing isolation calibrations.	
Port 1-2 Isol	Executes an isolation calibration on test ports 1 and 2.	:SENS{1-9}:CORR:COLL:ISOL 1,2 :SENS{1-9}:CORR:COLL:ISOL 2,1
Port 1-3 Isol	Executes an isolation calibration on test ports 1 and 3.	:SENS{1-9}:CORR:COLL:ISOL 1,3 :SENS{1-9}:CORR:COLL:ISOL 3,1
Port 1-4 Isol	Executes an isolation calibration on test ports 1 and 4.	:SENS{1-9}:CORR:COLL:ISOL 1,4 :SENS{1-9}:CORR:COLL:ISOL 4,1
Port 2-3 Isol	Executes an isolation calibration on test ports 2 and 3.	:SENS{1-9}:CORR:COLL:ISOL 2,3 :SENS{1-9}:CORR:COLL:ISOL 3,2

Key Operation	Function	SCPI Command
Cal	(Continued)	
Calibrate		
4-Port Cal ^{*2}		
Isolation (Optional)		
Port 2-4 Isol	Executes an isolation calibration on test ports 2 and 4.	:SENS{1-9}:CORR:COLL:ISOL 2,4 :SENS{1-9}:CORR:COLL:ISOL 4,2
Port 3-4 Isol	Executes an isolation calibration on test ports 3 and 4.	:SENS{1-9}:CORR:COLL:ISOL 3,4 :SENS{1-9}:CORR:COLL:ISOL 4,3
Return	Returns to the softkey display screen one level higher.	
Done	Terminates a calibration process and calculates the calibration coefficients.	:SENS{1-9}:CORR:COLL:SAVE
Cancel	Displays softkeys for canceling a calibration.	
OK	Cancels the calibration in progress.	None
Cancel	Returns to the softkey display screen one level higher.	
Return	Returns to the softkey display screen one level higher.	
Return	Returns to the softkey display screen one level higher.	
ECal	Displays softkeys for executing ECal (Electronic Calibrations).	:CALC{1-9}:SEL:FORM GDEL
1-Port ECal	Displays softkeys for executing 1-port ECal	
Port 1	Executes a 1-port ECal on test port 1.	:SENS{1-9}:CORR:COLL:ECAL:SOLT1 1
Port 2	Executes a 1-port ECal on test port 2.	:SENS{1-9}:CORR:COLL:ECAL:SOLT1 2
Port 3 ^{*1}	Executes a 1-port ECal on test port 3.	:SENS{1-9}:CORR:COLL:ECAL:SOLT1 3
Port 4 ^{*2}	Executes a 1-port ECal on test port 4.	:SENS{1-9}:CORR:COLL:ECAL:SOLT1 4
Return	Returns to the softkey display screen one level higher.	
2-Port ECal	Options 213 and 214: Execute a 2-port ECal. Options 313, 314, 413, and 414: Display softkeys for executing a 2-port ECal.	
Port 1-2 ^{*1}	Executes a 2-port ECal on test ports 1 and 2.	:SENS{1-9}:CORR:COLL:ECAL:SOLT2 1,2
Port 1-3 ^{*1}	Executes a 2-port ECal on test ports 1 and 3.	:SENS{1-9}:CORR:COLL:ECAL:SOLT2 1,3
Port 1-4 ^{*2}	Executes a 2-port ECal on test ports 1 and 4.	:SENS{1-9}:CORR:COLL:ECAL:SOLT2 1,4
Port 2-3 ^{*1}	Executes a 2-port ECal on test ports 2 and 3.	:SENS{1-9}:CORR:COLL:ECAL:SOLT2 2,3
Port 2-4 ^{*2}	Executes a 2-port ECal on test ports 2 and 4.	:SENS{1-9}:CORR:COLL:ECAL:SOLT2 2,4
Port 3-4 ^{*2}	Executes a 2-port ECal on test ports 3 and 4.	:SENS{1-9}:CORR:COLL:ECAL:SOLT2 3,4
Return ^{*1}	Returns to the softkey display screen one level higher.	
3-Port ECal	Options 313 and 314: Execute a 3-port ECal. Options 413 and 414: Display softkeys for executing a 3-port ECal.	
Port 1-2-3 ^{*2}	Executes a 3-port ECal on test ports 1, 2, and 3.	:SENS{1-9}:CORR:COLL:ECAL:SOLT3 1,2,3
Port 1-2-4 ^{*2}	Executes a 3-port ECal on test ports 1, 2, and 4.	:SENS{1-9}:CORR:COLL:ECAL:SOLT3 1,2,4
Port 1-3-4 ^{*2}	Executes a 3-port ECal on test ports 1, 3, and 4.	:SENS{1-9}:CORR:COLL:ECAL:SOLT3 1,3,4
Port 2-3-4 ^{*2}	Executes a 3-port ECal on test ports 2, 3, and 4.	:SENS{1-9}:CORR:COLL:ECAL:SOLT3 2,3,4
Return ^{*2}	Returns to the softkey display screen one level higher.	
4-Port ECal ^{*2}	Executes a 4-port ECal.	:SENS{1-9}:CORR:COLL:ECAL:SOLT4 1,2,3,4

Softkey Functions Calibration Menu

Key Operation	Function	SCPI Command
Cal	(Continued)	
ECal		
Thru ECal	Display softkeys for executing a THRU ECal.	
2-1 (S21)	Executes a THRU ECal for test port 1→2.	:SENS{1-9}:CORR:COLL:ECAL:THRU 2,1
3-1 (S31)* ¹	Executes a THRU ECal for test port 1→3.	:SENS{1-9}:CORR:COLL:ECAL:THRU 3,1
4-1 (S41)* ²	Executes a THRU ECal for test port 1→4.	:SENS{1-9}:CORR:COLL:ECAL:THRU 4,1
1-2 (S12)	Executes a THRU ECal for test port 2→1.	:SENS{1-9}:CORR:COLL:ECAL:THRU 1,2
3-2 (S32)* ¹	Executes a THRU ECal for test port 2→3.	:SENS{1-9}:CORR:COLL:ECAL:THRU 3,2
4-2 (S42)* ²	Executes a THRU ECal for test port 2→4.	:SENS{1-9}:CORR:COLL:ECAL:THRU 4,2
1-3 (S13)* ¹	Executes a THRU ECal for test port 3→1.	:SENS{1-9}:CORR:COLL:ECAL:THRU 1,3
2-3 (S23)* ¹	Executes a THRU ECal for test port 3→2.	:SENS{1-9}:CORR:COLL:ECAL:THRU 2,3
4-3 (S43)* ²	Executes a THRU ECal for test port 3→4.	:SENS{1-9}:CORR:COLL:ECAL:THRU 4,3
1-4 (S14)* ²	Executes a THRU ECal for test port 4→1.	:SENS{1-9}:CORR:COLL:ECAL:THRU 1,4
2-4 (S24)* ²	Executes a THRU ECal for test port 4→2.	:SENS{1-9}:CORR:COLL:ECAL:THRU 2,4
3-4 (S34)* ²	Executes a THRU ECal for test port 4→3.	:SENS{1-9}:CORR:COLL:ECAL:THRU 3,4
Return	Returns to the softkey display screen one level higher.	
Isolation	Enables or disables isolation calibration.	:SENS{1-9}:CORR:COLL:ECAL:ISOL
Return	Returns to the softkey display screen one level higher.	
Property	Enables or disables the display of calibration properties. When enabled, calibration status information between test ports will be displayed in a matrix format in the lower-right corner of the channel window.	:SENS{1-9}:CORR:PROP
Cal Kit	Displays softkeys for selecting calibration kits. Up to ten calibration kits may be defined. Calibration kits 85033E, 85033D, 85052D, 85032F, and 85032B are pre-defined with default settings.	
85033E	Selects calibration kit 85033E.	:SENS{1-9}:CORR:COLL:CKIT 1
85033D	Selects calibration kit 85033D.	:SENS{1-9}:CORR:COLL:CKIT 2
85052D	Selects calibration kit 85052D.	:SENS{1-9}:CORR:COLL:CKIT 3
85032F	Selects calibration kit 85032F.	:SENS{1-9}:CORR:COLL:CKIT 4
85032B	Selects calibration kit 85032B.	:SENS{1-9}:CORR:COLL:CKIT 5
User	Selects a user-defined calibration kit.	:SENS{1-9}:CORR:COLL:CKIT 6
User	Selects a user-defined calibration kit.	:SENS{1-9}:CORR:COLL:CKIT 7
User	Selects a user-defined calibration kit.	:SENS{1-9}:CORR:COLL:CKIT 8
User	Selects a user-defined calibration kit.	:SENS{1-9}:CORR:COLL:CKIT 9
User	Selects a user-defined calibration kit.	:SENS{1-9}:CORR:COLL:CKIT 10
Cancel	Returns to the softkey display screen one level higher.	
Modify Cal Kit	Displays softkeys for changing the definition of the calibration kit selected in the Cal Kit menu.	CALC{1-9}:SEL:FORM SCOM
Define STDs	Displays softkeys for defining the standard for a calibration kit. The label (Std Name) on each softkey represents the name of each standard. As a default setting, undefined standards are tagged with a No Name label. Up to 21 standards may be defined.	
1. (Std Name)	Displays softkeys for changing the definition of 1. (Std Name).	
Label	Defines the name of the standard No.1. Once named, the new name will appear as a label for the corresponding softkey, which is represented as (Std Name) in this manual.	:SENS{1-9}:CORR:COLL:CKIT:STAN1:LAB

Key Operation	Function	SCPI Command
Cal	(Continued)	
Modify Cal Kit		
Define STDs		
1. (Std Name)		
STD Type	Displays softkeys for setting the types of standards. A standard type is a classification of a standard based on its form and construction. There are five standard types: OPEN, SHORT, LOAD, delay/THRU, and arbitrary impedance.	
Open	Selects "OPEN" as the standard type.	:SENS{1-9}:CORR:COLL:CKIT:STAN1:TYPE OPEN
Short	Selects "SHORT" as the standard type.	:SENS{1-9}:CORR:COLL:CKIT:STAN1:TYPE SHOR
Load	Selects "LOAD" as the standard type.	:SENS{1-9}:CORR:COLL:CKIT:STAN1:TYPE LOAD
Delay/ Thru	Selects "delay/THRU" as the standard type.	:SENS{1-9}:CORR:COLL:CKIT:STAN1:TYPE THRU
Arbitrary	Selects "arbitrary impedance" as the standard type.	:SENS{1-9}:CORR:COLL:CKIT:STAN1:TYPE ARBI
None	Does not select any standard type.	:SENS{1-9}:CORR:COLL:CKIT:STAN1:TYPE NONE
Cancel	Returns to the softkey display screen one level higher.	
C0	Sets the value of C0 (F) for the standard. The fringe capacitance (F) of a standard is determined by the following formula: $C = (C0) + (C1 \times F) + (C2 \times F^2) + (C3 \times F^3)$ (F: measurement frequency [Hz])	:SENS{1-9}:CORR:COLL:CKIT:STAN1:C0
C1	Sets the value of C1 (F/Hz) for the standard.	:SENS{1-9}:CORR:COLL:CKIT:STAN1:C1
C2	Sets the value of C2 (F/Hz ²) for the standard.	:SENS{1-9}:CORR:COLL:CKIT:STAN1:C2
C3	Sets the value of C3 (F/Hz ³) for the standard.	:SENS{1-9}:CORR:COLL:CKIT:STAN1:C3
L0	Sets the value of L0 (H) for the standard. The residual inductance (H) of a standard is determined by the following formula: $L = (L0) + (L1 \times F) + (L2 \times F^2) + (L3 \times F^3)$ (F: measurement frequency [Hz])	:SENS{1-9}:CORR:COLL:CKIT:STAN1:L0
L1	Sets the value of L1 (H/Hz) for the standard.	:SENS{1-9}:CORR:COLL:CKIT:STAN1:L1
L2	Sets the value of L2 (H/Hz ²) for the standard.	:SENS{1-9}:CORR:COLL:CKIT:STAN1:L2
L3	Sets the value of L3 (H/Hz ³) for the standard.	:SENS{1-9}:CORR:COLL:CKIT:STAN1:L3
Offset Delay	Sets the offset delay (sec.) for the standard. The offset delay is a delay caused by the length of the transmission line between the standard to be defined and the actual measurement plane. For the OPEN, SHORT, and LOAD standards, input the one-way transmission time (sec.) from the measurement plane to the standard. For the THRU standard, input the one-way transmission time (sec.) from one measurement plane to the other. The offset delay can be obtained either by measuring it or by dividing the exact physical length of the standard by the velocity factor.	:SENS{1-9}:CORR:COLL:CKIT:STAN1:DEL
Offset Z0	Sets the impedance Z0 between the measurement plane and the standard being defined. Normally, this value is set to the characteristic impedance of the system.	:SENS{1-9}:CORR:COLL:CKIT:STAN1:Z0

Softkey Functions Calibration Menu


















Key Operation	Function	SCPI Command
Cal	(Continued)	
Modify Cal Kit		
Define STDs		
1. (Std Name)		
Offset Loss	Sets the offset loss for the standard. The offset loss is an energy loss due to skin effect on the length of single coaxial cable. Input the energy loss at 1 GHz using the unit Ω /sec. In most applications, setting the offset loss to "0" should not affect the result. The offset loss of a standard can be determined by measuring the offset delay and the loss at 1 GHz and then substituting them in the following formula: $\text{Loss}(\Omega/\text{s}) = \frac{\text{loss}(\text{dB}) \times Z_0(\Omega)}{4.3429(\text{dB}) \times \text{delay}(\text{s})}$:SENS{1-9}:CORR:COLL:CKIT:STAN1:LOSS
Arb. Impedance	Sets the value for the LOAD standard. Use this option to input an arbitrary impedance that is different from the system impedance.	:SENS{1-9}:CORR:COLL:CKIT:STAN1:ARB
Return	Returns to the softkey display screen one level higher.	
2. (Std Name)	Displays softkeys for changing the definition of 2. (Std Name) . The lower-level softkeys displayed are the same as those for 1. (Std Name) .	
.	.	
21. (Std Name)	Displays softkeys for changing the definition of 21. (Std Name) . The lower-level softkeys displayed are the same as those for 1. (Std Name) .	
Return	Returns to the softkey display screen one level higher.	
Specify CLSs	Displays softkeys for setting the classes of standards. A standard class refers to a set of standards that are used in the process of calibration. For each class of OPEN, SHORT, LOAD, and THRU, designate standards to be used from among the 21 standards.	
Open	Displays softkeys for selecting standards for the OPEN standard class.	
Set All	Displays softkeys for selecting standards for the OPEN standard class that applies to all test ports.	
1. (Std Name)	Includes 1. (Std Name) in the OPEN standard class.	:SENS{1-9}:CORR:COLL:CKIT:ORD:OPEN x,1
2. (Std Name)	Includes 2. (Std Name) in the OPEN standard class.	:SENS{1-9}:CORR:COLL:CKIT:ORD:OPEN x,2
.	.	
21. (Std Name)	Includes 21. (Std Name) in the OPEN standard class.	:SENS{1-9}:CORR:COLL:CKIT:ORD:OPEN x,21
Cancel	Returns to the softkey display screen one level higher.	
Port 1	Displays softkeys for selecting standards for the OPEN standard class that applies only to test port 1. The lower-level softkeys are the same as those for Set All .	
Port 2	Displays softkeys for selecting standards for the OPEN standard class that applies only to test port 2. The lower-level softkeys are the same as those for Set All .	
Port 3 ^{*1}	Displays softkeys for selecting standards for the OPEN standard class that applies only to test port 3. The lower-level softkeys are the same as those for Set All .	
Port 4 ^{*2}	Displays softkeys for selecting standards for the OPEN standard class that applies only to test port 4. The lower-level softkeys are the same as those for Set All .	
Return	Returns to the softkey display screen one level higher.	













Key Operation	Function	SCPI Command
Cal	(Continued)	
Modify Cal Kit		
Specify CLSs		
Short	Displays softkeys for selecting standards for the SHORT standard class. The lower-level softkeys displayed are the same as those for Open .	:SENS{1-9}:CORR:COLL:CKIT:ORD:SHOR
Load	Displays softkeys for selecting standards for the LOAD standard class. The lower-level softkeys displayed are the same as those for Open .	:SENS{1-9}:CORR:COLL:CKIT:ORD:LOAD
Thru	Displays softkeys for selecting standards for the THRU standard class. The lower-level softkeys displayed are the same as those for Open .	:SENS{1-9}:CORR:COLL:CKIT:ORD:THRU
Return	Returns to the softkey display screen one level higher.	
Label Kit	Allows the user to label the calibration kit.	:SENS{1-9}:CORR:COLL:CKIT:LAB
Restore Cal Kit	Displays softkeys for initializing the definition of calibration kit.	
OK	Restores the definition of the calibration kit selected by Cal Kit to factory default settings.	:SENS{1-9}:CORR:COLL:CKIT:RES
Cancel	Returns to the softkey display screen one level higher.	
Return	Returns to the softkey display screen one level higher.	
Port Extensions	Displays softkeys for extending ports.	
Extensions	Enables or disables the port extension function.	:SENS{1-9}:CORR:EXT
Extension Port 1	Sets the value for test port 1 extension (sec.).	:SENS{1-9}:CORR:EXT:PORT 1
Extension Port 2	Sets the value for test port 2 extension (sec.).	:SENS{1-9}:CORR:EXT:PORT 2
Extension Port 3 ^{*1}	Sets the value for test port 3 extension (sec.).	:SENS{1-9}:CORR:EXT:PORT 3
Extension Port 4 ^{*2}	Sets the value for test port 4 extension (sec.).	:SENS{1-9}:CORR:EXT:PORT 4
Return	Returns to the softkey display screen one level higher.	
Velocity Factor	Sets the velocity factor.	:SENS{1-9}:CORR:RVEL:COAX
Return	Returns to the "E5070A/E5071A Menu (Top Menu)" on page 404.	

*1. Only with Options 313, 314, 413, and 414.










*2. Only with Options 413 and 414.

Display Menu

Key Operation	Function	SCPI Command
Display	Displays softkeys for setting up display options.	
Allocate Channels	Displays softkeys for setting the number of channels to be displayed and the channel window arrangement. The execution of measurements does not depend on the display status of each channel (measurements can be performed on channels that are not displayed). The user can set up each channel for measurements (by selecting the sweep mode and the trigger source) from the "Trigger Menu" on page 452.	
	Displays channel 1 using the entire display screen.	:DISP:SPL D1
	Displays channel windows by bisecting the screen horizontally with channel 1 on the left and channel 2 on the right.	:DISP:SPL D12
	Displays channel windows by bisecting the screen vertically, with channel 1 displayed above channel 2.	:DISP:SPL D1_2
	Displays channel windows by splitting the screen vertically (with the left window occupying 2/3 of the screen), with channel 1 on the left and channel 2 on the right.	:DISP:SPL D112
	Displays channel windows by splitting the screen vertically (with the upper window occupying 2/3 of the screen), and channel 1 displayed above channel 2.	:DISP:SPL D1_1_2
	Displays channel windows by trisecting the screen horizontally, with channels 1, 2, and 3 displayed from left to right.	:DISP:SPL D123
	Displays channel windows by trisecting the screen vertically with channels 1, 2, and 3 arranged from top to bottom.	:DISP:SPL D1_2_3
	Displays channel windows by bisecting the screen vertically and then bisecting the upper window horizontally with channels 1, 2, and 3 displayed, respectively, in the upper-left corner, upper-right corner, and bottom.	:DISP:SPL D12_33
	Displays channel windows by bisecting the screen vertically and then bisecting the lower window horizontally with channels 1, 2, and 3 displayed, respectively, in the top, lower-left corner, and lower-right corner.	:DISP:SPL D11_23
	Displays channel windows by bisecting the screen horizontally and then bisecting the left window vertically, with channels 1, 2, and 3 displayed, respectively, in the upper-left corner, lower-left corner, and on the right.	:DISP:SPL D13_23
	Displays channel windows by bisecting the screen horizontally and then bisecting the right window vertically, with channels 1, 2, and 3 displayed, respectively, on the left, in the upper-right corner, and lower-right corner.	:DISP:SPL D12_13
	Displays channel windows by splitting the screen horizontally into four equal parts, with channels 1, 2, 3, and 4 displayed from left to right.	:DISP:SPL D1234
	Displays channel windows by splitting the screen vertically into four equal parts, with channels 1, 2, 3, and 4 displayed from top to bottom.	:DISP:SPL D1_2_3_4
	Displays channel windows by bisecting the screen both vertically and horizontally with channels 1, 2, 3, and 4 in the upper-left, upper-right, lower-left corner, and lower-right corners, respectively.	:DISP:SPL D12_34
	Displays channel windows by trisecting the screen horizontally and then bisecting each window vertically, with channels 1, 2, 3, 4, 5, and 6 displayed.	:DISP:SPL D123_456
	Displays channel windows by bisecting the screen horizontally and trisecting each window vertically, with channels 1, 2, 3, 4, 5, and 6 displayed.	:DISP:SPL D12_34_56
	Displays channel windows by splitting the screen horizontally into four equal parts and then bisecting each window vertically, with channels 1, 2, 3, and 4 displayed in upper windows from left to right, and channels 5, 6, 7, and 8 displayed in lower windows from left to right.	:DISP:SPL D1234_5678

Key Operation	Function	SCPI Command
Display	(Continued)	
Allocate Channels		
 × 8	Displays channel windows by splitting the screen vertically into four equal parts and then bisecting each window horizontally, with channels 1, 3, 5, and 7 displayed in left windows from top to bottom, and channels 2, 4, 6, and 8 displayed in right windows from top to bottom.	:DISP:SPL D12_34_56_78
 × 9	Displays channel windows by trisecting the screen both vertically and horizontally (i.e., nine total windows), with channels 1, 2, and 3 displayed in upper windows from left to right, channels 4, 5, and 6 displayed in middle windows from left to right, and channels 7, 8, and 9 displayed in lower windows from left to right.	:DISP:SPL D123_456_789
Cancel	Returns to the softkey display screen one level higher.	
Number of Traces	Displays softkeys for setting the number of traces.	
1	Sets the number of traces to one for the active channel.	:CALC{1-9}:PAR:COUN 1
2	Sets the number of traces to two for the active channel.	:CALC{1-9}:PAR:COUN 2
3	Sets the number of traces to three for the active channel.	:CALC{1-9}:PAR:COUN 3
4	Sets the number of traces to four for the active channel.	:CALC{1-9}:PAR:COUN 4
5	Sets the number of traces to five for the active channel.	:CALC{1-9}:PAR:COUN 5
6	Sets the number of traces to six for the active channel.	:CALC{1-9}:PAR:COUN 6
7	Sets the number of traces to seven for the active channel.	:CALC{1-9}:PAR:COUN 7
8	Sets the number of traces to eight for the active channel.	:CALC{1-9}:PAR:COUN 8
9	Sets the number of traces to nine for the active channel.	:CALC{1-9}:PAR:COUN 9
Cancel	Returns to the softkey display screen one level higher.	
Allocate Traces	Displays softkeys for setting up the trace display arrangement. Traces are displayed based on the order determined from the graph arrangement currently being used. If the number of traces is less than the number of graphs, nothing will be displayed in the extra area(s). If the number of traces is more than the number of graphs, the remaining traces will be displayed by going back to the first graph, overlapping existing traces.	
 × 1	Displays channel 1 using the entire channel window.	:DISP:WIND{1-9}:SPL D1
 × 2	Displays graphs by bisecting the screen horizontally with graph 1 on the left and graph 2 on the right.	:DISP:WIND{1-9}:SPL D1_2
 × 2	Displays graphs by bisecting the screen vertically, with graph 1 displayed above graph 2.	:DISP:WIND{1-9}:SPL D12
 × 2	Displays graphs by splitting the screen vertically (with the left window occupying 2/3 of the screen), with graph 1 on the left and graph 2 on the right.	:DISP:WIND{1-9}:SPL D112
 × 2	Displays graphs by splitting the screen vertically (with the upper window occupying 2/3 of the screen), and graph 1 displayed above graph 2.	:DISP:WIND{1-9}:SPL D1_1_2
 × 3	Displays graphs by trisecting the screen horizontally, with graphs 1, 2, and 3 displayed from left to right.	:DISP:WIND{1-9}:SPL D123
 × 3	Displays graphs by trisecting the screen vertically with graphs 1, 2, and 3 arranged from top to bottom.	:DISP:WIND{1-9}:SPL D1_2_3
 × 3	Displays graphs by bisecting the screen vertically and then bisecting the upper window horizontally with graphs 1, 2, and 3 displayed, respectively, in the upper-left corner, upper-right corner, and bottom.	:DISP:WIND{1-9}:SPL D12_33
 × 3	Displays graphs by bisecting the screen vertically and then bisecting the lower window horizontally with graphs 1, 2, and 3 displayed, respectively, in the top, lower-left corner, and lower-right corner.	:DISP:WIND{1-9}:SPL D11_23
 × 3	Displays graphs by bisecting the screen horizontally and then bisecting the left window vertically, with graphs 1, 2, and 3 displayed, respectively, in the upper-left corner, lower-left corner, and on the right.	:DISP:WIND{1-9}:SPL D13_23

Softkey Functions Display Menu

Key Operation	Function	SCPI Command
Display	(Continued)	
Allocate Traces		
 ×3	Displays graphs by bisecting the screen horizontally and then bisecting the right window vertically, with graphs 1, 2, and 3 displayed, respectively, on the left, in the upper-right corner, and lower-right corner.	:DISP:WIND{1-9}:SPL D12_13
 ×4	Displays graphs by splitting the screen horizontally into four equal parts, with graphs 1, 2, 3, and 4 displayed from left to right.	:DISP:WIND{1-9}:SPL D1234
 ×4	Displays graphs by splitting the screen vertically into four equal parts, with graphs 1, 2, 3, and 4 displayed from top to bottom.	:DISP:WIND{1-9}:SPL D1_2_3_4
 ×4	Displays graphs by bisecting the screen both vertically and horizontally with graphs 1, 2, 3, and 4 in the upper-left, upper-right, lower-left corner, and lower-right corners, respectively.	:DISP:WIND{1-9}:SPL D12_34
 ×6	Displays graphs by trisecting the screen horizontally and then bisecting each window vertically, with graphs 1, 2, 3, 4, 5, and 6 displayed.	:DISP:WIND{1-9}:SPL D123_456
 ×6	Displays graphs by bisecting the screen horizontally and trisecting each window vertically, with graphs 1, 2, 3, 4, 5, and 6 displayed.	:DISP:WIND{1-9}:SPL D12_34_56
 ×8	Displays graphs by splitting the screen horizontally into four equal parts and then bisecting each window vertically, with graphs 1, 2, 3, and 4 displayed in upper windows from left to right, and graphs 5, 6, 7, and 8 displayed in lower windows from left to right.	:DISP:WIND{1-9}:SPL D1234_5678
 ×8	Displays graphs by splitting the screen vertically into four equal parts and then bisecting each window horizontally, with graphs 1, 3, 5, and 7 displayed in left windows from top to bottom, and graphs 2, 4, 6, and 8 displayed in right windows from top to bottom.	:DISP:WIND{1-9}:SPL D12_34_56_78
 ×9	Displays graphs by trisecting the screen both vertically and horizontally (i.e., nine total windows), with graphs 1, 2, and 3 displayed in upper windows from left to right, graphs 4, 5, and 6 displayed in middle windows from left to right, and graphs 7, 8, and 9 displayed in lower windows from left to right.	:DISP:WIND{1-9}:SPL D123_456_789
Return	Returns to the softkey display screen one level higher.	
Display	Displays softkeys for selecting between data trace and memory trace for on-screen display.	
Data	Selects data trace for on-screen display. If the data math option was enabled in the Data Math menu, the computation results will also be displayed.	:DISP:WIND{1-9}:TRAC{1-9}:STAT
Mem	Selects memory trace for on-screen display. To store data for a memory trace, go back to the previous menu and press Data → Mem .	:DISP:WIND{1-9}:TRAC{1-9}:MEM
Data & Mem	Selects both data trace and memory trace for on-screen display. By storing data obtained under certain conditions, it is possible to compare them to new measurement results (data trace) obtained under different conditions. To store data for a memory trace, go back to the previous menu and press Data → Mem .	:DISP:WIND{1-9}:TRAC{1-9}:MEM :DISP:WIND{1-9}:TRAC{1-9}:STAT
OFF	Turns off both the data trace and memory trace.	:DISP:WIND{1-9}:TRAC{1-9}:MEM :DISP:WIND{1-9}:TRAC{1-9}:STAT
Cancel	Returns to the softkey display screen one level higher.	
Data → Mem	Stores the measured data for the current active trace in memory. Stored data can be displayed using the memory trace option. To enable/disable the memory trace, go to the Display menu.	:CALC{1-9}:MATH:MEM
Data Math	Displays softkeys for selecting the types of data processing to be performed.	
OFF	Disables the data processing function. Raw measurement data will be stored as a data trace.	:CALC{1-9}:MATH:FUNC NORM
Data / Mem	Divides the measured data by the memory trace data (normalization) and stores the results as a data trace. This function is used to evaluate the ratio between two traces (e.g., to evaluate gains and attenuations).	:CALC{1-9}:MATH:FUNC DIV

Key Operation	Function	SCPI Command
Display	(Continued)	
Data Math		
Data * Mem	Multiplies the measured data by the memory trace data and stores the result as a data trace.	:CALC{1-9}:MATH:FUNC MULT
Data - Mem	Subtracts the memory trace data from the measured data (vector operation) and stores the results as a data trace. This function is useful in determining vector errors (e.g., directivity) and storing them for data compensation for future measurements.	:CALC{1-9}:MATH:FUNC SUBT
Data + Mem	Adds the measured data to the memory trace data and stores the result as a data trace.	:CALC{1-9}:MATH:FUNC ADD
Cancel	Returns to the softkey display screen one level higher.	
Edit Title Label	Displays the input bar for editing title labels. Each channel is allowed to have a title label up to 100 characters in length. However, the entire title bar may not be displayed depending on the width of the channel window.	:DISP:WIND{1-9}:TITL:DATA
Title Label	Enables or disables the title label display. Once a title label is assigned, it can be displayed within the title bar at the top of a channel window by enabling the title label display. Title labels are useful for adding extra information to saved data and printouts.	:DISP:WIND{1-9}:TITL
Graticule Label	Enables or disables the graticule label display for the Y-axis in a rectangular display format. Disabling the graticule label display will result in expanded graph areas.	:DISP:WIND{1-9}:LAB
Invert Color	Inverts the display colors for all channel windows. Inverting colors from the normal display will create white backgrounds.	:DISP:IMAG
Frequency	Enables or disables the frequency display on the screen. This function is useful for protecting critical information by making it impossible to obtain frequencies used in measurements just by glancing at the screen.	:DISP:ANN:FREQ:STAT
Update	Enables or disables screen updates. When disabled, the analyzer can save time required for screen updates and thus improve measurement throughput. If it is not necessary to confirm results on the screen, this is an effective way to improve throughput.	:DISP:ENAB
Return	Returns to the "E5070A/E5071A Menu (Top Menu)" on page 404.	

Format Menu

Key Operation	Function	SCPI Command
Format	Displays softkeys for setting up data formats.	
Log Mag	Displays traces in a rectangular display format with log magnitude (dB) on the Y-axis and frequencies on the X-axis (log magnitude format).	:CALC{1-9}:SEL:FORM MLOG
Phase	Displays traces in a rectangular display format with phase (-180° to +180°) on the Y-axis and frequencies on the X-axis (phase format).	:CALC{1-9}:SEL:FORM PHAS
Group Delay	Displays traces in a rectangular display format with group delay (s) on the Y-axis and frequencies on the X-axis (group delay format).	:CALC{1-9}:SEL:FORM GDEL
Smith	Displays softkeys for setting up smith chart.	
Lin / Phase	Displays traces in Smith chart format. The marker response values are linear magnitude and phase (°).	:CALC{1-9}:SEL:FORM SLIN
Log / Phase	Displays traces in Smith chart format. The marker response values are log magnitude (dB) and phase (°).	:CALC{1-9}:SEL:FORM SLOG
Real / Imag	Displays traces in Smith chart format. The marker response values are the real and imaginary parts.	:CALC{1-9}:SEL:FORM SCOM
R + jX	Displays traces in Smith chart format. The marker response values are resistance (Ω) and reactance (Ω).	:CALC{1-9}:SEL:FORM SMIT
G + jB	Displays traces in Smith chart format. The marker response values are conductance (S) and susceptance (S).	:CALC{1-9}:SEL:FORM SMGB
Cancel	Returns to the softkey display screen one level higher.	
Ploar	Displays softkeys for setting up polar format.	
Lin / Phase	Displays traces in polar format. The marker response values are linear magnitude and phase (°).	:CALC{1-9}:SEL:FORM PLIN
Log / Phase	Displays traces in polar format. The marker response values are log magnitude (dB) and phase (°).	:CALC{1-9}:SEL:FORM PLOG
Real / Imag	Displays traces in polar format. The marker response values are the real and imaginary parts.	:CALC{1-9}:SEL:FORM POL
Cancel	Returns to the softkey display screen one level higher.	
Lin Mag	Displays traces in a rectangular display format with linear magnitude on the Y-axis and frequencies on the X-axis (linear magnitude format).	:CALC{1-9}:SEL:FORM MLIN
SWR	Displays traces in a rectangular display format with SWR (standing wave ratio) on the Y-axis and frequencies on the X-axis (SWR format).	:CALC{1-9}:SEL:FORM SWR
Real	Displays traces in a rectangular display format with the real part on the Y-axis and frequencies on the X-axis (real format).	:CALC{1-9}:SEL:FORM REAL
Imaginary	Displays traces in a rectangular display format with the imaginary part on the Y-axis and frequencies on the X-axis (imaginary format).	:CALC{1-9}:SEL:FORM IMAG
Expand Phase	Displays traces in a rectangular display format with expanded phase (°) on the Y-axis and frequencies on the X-axis (expanded phase format).	:CALC{1-9}:SEL:FORM UPH
Positive Phase	Displays traces in a rectangular display format with phase (0° to +360°) on the Y-axis and frequencies on the X-axis (positive phase format).	:CALC{1-9}:SEL:FORM PPH
Return	Returns to the “E5070A/E5071A Menu (Top Menu)” on page 404.	

Macro Setup Menu

Key Operation	Function	SCPI Command
Macro Setup	Displays the macro setup menu.	
VBA Editor	Starts the VBA editor. A keyboard and mouse are necessary to use this editor.	None
New Project	Creates a new VBA project.	None
Load Project	Opens a dialog box for loading a saved VBA project.	:MMEM:LOAD:PROG
Save Project	Opens a dialog box for saving a VBA project.	:MMEM:STOR:PROG
Close Editor	Closes the currently open VBA editor.	None
Select Macro	Displays a list of all macros in the form of softkeys from which they can be executed.	
(macro name)	Executes the macro that corresponds to the softkey.	:PROG:NAME
:	:	:PROG:STAT
(macro name)	Executes the macro that corresponds to the softkey.	
Cancel	Returns to the softkey display screen one level higher.	
Stop	Stops execution of a program after executing the line of code being executed at the time the Stop key is pressed.	:PROG:STAT
Continue	Resumes execution of a program that has been stopped.	:PROG:STAT
Echo Window	Enables or disables the echo window display at the bottom of the screen.	:DISP:TABL :DISP:TABL:TYPE
Clear Echo	Clears text displayed in the echo window.	:DISP:ECHO:CLE
User Menu	Displays user menu softkeys.	
Button 1	Executes the procedure assigned to Button 1 . Softkey label can be modified using a command.	None
Button 2	Executes the procedure assigned to Button 2 . Softkey label can be modified using a command.	None
Button 3	Executes the procedure assigned to Button 3 . Softkey label can be modified using a command.	None
Button 4	Executes the procedure assigned to Button 4 . Softkey label can be modified using a command.	None
Button 5	Executes the procedure assigned to Button 5 . Softkey label can be modified using a command.	None
Button 6	Executes the procedure assigned to Button 6 . Softkey label can be modified using a command.	None
Button 7	Executes the procedure assigned to Button 7 . Softkey label can be modified using a command.	None
Button 8	Executes the procedure assigned to Button 8 . Softkey label can be modified using a command.	None
Button 9	Executes the procedure assigned to Button 9 . Softkey label can be modified using a command.	None
Button 10	Executes the procedure assigned to Button 10 . Softkey label can be modified using a command.	None
Return	Returns to the softkey display screen one level higher.	
Preset User Menu	Returns the softkey labels of user menu to the initial settings.	None
Return	Returns to the “E5070A/E5071A Menu (Top Menu)” on page 404.	

Marker Menu

Key Operation	Function	SCPI Command
Marker	Activates marker 1 and displays an input dialog box for setting the stimulus value for marker 1. Also displays softkeys for setting and moving each marker.	
Marker 1	Enables marker 1 if it is disabled. Also activates marker 1 and displays an input dialog box for setting the stimulus value.	:CALC{1-9}:MARK1 :CALC{1-9}:MARK1:ACT :CALC{1-9}:MARK1:X
Marker 2	Enables marker 2 if it is disabled. Also activates marker 2 and displays an input dialog box for setting the stimulus value.	:CALC{1-9}:MARK2 :CALC{1-9}:MARK2:ACT :CALC{1-9}:MARK2:X
Marker 3	Enables marker 3 if it is disabled. Also activates marker 3 and displays an input dialog box for setting the stimulus value.	:CALC{1-9}:MARK3 :CALC{1-9}:MARK3:ACT :CALC{1-9}:MARK3:X
Marker 4	Enables marker 4 if it is disabled. Also activates marker 4 and displays an input dialog box for setting the stimulus value.	:CALC{1-9}:MARK4 :CALC{1-9}:MARK4:ACT :CALC{1-9}:MARK4:X
More Markers	Displays softkeys for setting markers 5 to 9.	
Marker 5	Enables marker 5 if it is disabled. Also activates marker 5 and displays an input dialog box for setting the stimulus value.	:CALC{1-9}:MARK5 :CALC{1-9}:MARK5:ACT :CALC{1-9}:MARK5:X
Marker 6	Enables marker 6 if it is disabled. Also activates marker 6 and displays an input dialog box for setting the stimulus value.	:CALC{1-9}:MARK6 :CALC{1-9}:MARK6:ACT :CALC{1-9}:MARK6:X
Marker 7	Enables marker 7 if it is disabled. Also activates marker 7 and displays an input dialog box for setting the stimulus value.	:CALC{1-9}:MARK7 :CALC{1-9}:MARK7:ACT :CALC{1-9}:MARK7:X
Marker 8	Enables marker 8 if it is disabled. Also activates marker 8 and displays an input dialog box for setting the stimulus value.	:CALC{1-9}:MARK8 :CALC{1-9}:MARK8:ACT :CALC{1-9}:MARK8:X
Marker 9	Enables marker 9 if it is disabled. Also activates marker 9 and displays an input dialog box for setting the stimulus value.	:CALC{1-9}:MARK9 :CALC{1-9}:MARK9:ACT :CALC{1-9}:MARK9:X
Return	Returns to the softkey display screen one level higher.	
Ref Marker	Enables the reference marker if it is disabled (the reference marker mode [Ref Marker Mode] is enabled at the same time). Also activates the reference marker and displays an input dialog box for setting the stimulus value.	:CALC{1-9}:MARK10 :CALC{1-9}:MARK10:ACT :CALC{1-9}:MARK10:X
Clear Marker Menu	Displays softkeys for turning off each marker.	
All OFF	Turns off all markers on the active trace.	None
Marker 1	Turns off marker 1 on the active trace.	:CALC{1-9}:MARK1
Marker 2	Turns off marker 2 on the active trace.	:CALC{1-9}:MARK2
Marker 3	Turns off marker 3 on the active trace.	:CALC{1-9}:MARK3
Marker 4	Turns off marker 4 on the active trace.	:CALC{1-9}:MARK4
Marker 5	Turns off marker 5 on the active trace.	:CALC{1-9}:MARK5
Marker 6	Turns off marker 6 on the active trace.	:CALC{1-9}:MARK6
Marker 7	Turns off marker 7 on the active trace.	:CALC{1-9}:MARK7
Marker 8	Turns off marker 8 on the active trace.	:CALC{1-9}:MARK8
Marker 9	Turns off marker 9 on the active trace.	:CALC{1-9}:MARK9
Ref Marker	Turns off the reference marker on the active trace.	:CALC{1-9}:MARK10
Return	Returns to the softkey display screen one level higher.	
Marker → Ref Marker	Replaces the stimulus value of the reference marker with that of the active marker. As a result, the reference marker will be placed at the same position as the active marker.	None

Key Operation	Function	SCPI Command
Marker	(Continued)	
Ref Marker Mode	Enables or disables the reference marker mode. When enabled, stimulus values and response values of markers 1 to 9 will be displayed using values relative to the reference marker. When disabled, the reference marker will not appear on the screen.	:CALC{1-9};MARK{1-10};REF
Return	Returns to the “E5070A/E5071A Menu (Top Menu)” on page 404.	

Marker Function Menu

Key Operation	Function	SCPI Command
Marker Fctn	Displays softkeys for setting the sweep range using markers and other marker options.	
Marker → Start	Sets the starting frequency to the stimulus value of the active marker on the active trace. Even if the reference marker is enabled and a relative stimulus value is displayed, the absolute value will be used.	:CALC{1-9}:MARK{1-10}:SET STAR
Marker → Stop	Sets the ending frequency to the stimulus value of the active marker on the active trace. Even if the reference marker is enabled and a relative stimulus value is displayed, the absolute value will be used.	:CALC{1-9}:MARK{1-10}:SET STOP
Marker → Center	Sets the center frequency to the stimulus value of the active marker on the active trace. Even if the reference marker is enabled and a relative stimulus value is displayed, the absolute value will be used.	:CALC{1-9}:MARK{1-10}:SET CENT
Marker → Reference	Sets the value of the reference line to the response value of the active marker on the active trace. A softkey having the same function is also provided in “Scale Menu” on page 444.	:CALC{1-9}:MARK{1-10}:SET RLEV
Discrete	Enables or disables the discrete marker function. When enabled, the marker will be placed at the nearest measurement point from the specified marker stimulus value. When disabled, the marker will be placed at the point corresponding to the specified marker stimulus value (by interpolating gaps between measurement points).	:CALC{1-9}:MARK{1-10}:DISC
Couple	Enables or disables marker coupling. When enabled, marker settings and movements become effective for all traces on a channel. When disabled, marker settings and movements are done independently on each trace.	:CALC{1-9}:MARK{1-10}:COUP
Marker Table	Enables or disables the marker table display. The marker table lists the values of markers for all traces defined on a channel using the bottom third of the screen. If a channel holds too many markers to be displayed in the display area, use the scroll bar on the right to view the entire table.	:DISP:TABL :DISP:TABL:TYPE MARK
Statistics	Enables or disables the display of statistics. When enabled, the following three statistical data items (Mean value, Standard deviation, Peak-to-peak) will be displayed on the screen. For details, see “Determining the Mean, Standard Deviation, and p-p of the Trace” on page 142.	:CALC{1-9}:MST
Return	Returns to the “E5070A/E5071A Menu (Top Menu)” on page 404.	

Marker Search Menu

Key Operation	Function	SCPI Command
Marker Search	Displays softkeys for performing searches using markers.	
Max	Moves the active marker to a position on the trace that represents the maximum response value.	:CALC{1-9}:MARK{1-10}:FUNC:EXEC :CALC{1-9}:MARK{1-10}:FUNC:TYPE MAX
Min	Moves the active marker to a position on the trace that represents the minimum response value.	:CALC{1-9}:MARK{1-10}:FUNC:EXEC :CALC{1-9}:MARK{1-10}:FUNC:TYPE MIN
Peak	Displays softkeys for setting and performing a peak search. A peak refers to a point where the response value is larger (positive peak) or smaller (negative peak) than those of adjacent measurement points on either side in a rectangular display format. A peak search picks up points that satisfy definitions given by Peak Excursion and Peak Polarity among all the peaks. If the Smith chart format or polar format is used, the main response value, among the two response values, will be used to perform searches (e.g., resistance in the Smith (R+jX) format).	
Search Peak	In the rectangular display format, the active marker will move to the peak with maximum response value among the peaks that match the definition if the peak polarity is Positive or Both , or to the peak with minimum response value if the peak polarity is Negative . The search is performed based on conditions defined by Peak Excursion and Peak Polarity .	:CALC{1-9}:MARK{1-10}:FUNC:EXEC :CALC{1-9}:MARK{1-10}:FUNC:TYPE PEAK
Search Left	In a rectangular display format, moves the active marker to the peak on its left under the given conditions. The search is performed based on conditions defined by Peak Excursion and Peak Polarity .	:CALC{1-9}:MARK{1-10}:FUNC:EXEC :CALC{1-9}:MARK{1-10}:FUNC:TYPE LPE
Search Right	In a rectangular display format, moves the active marker to the peak on its right under the given conditions. The search is performed based on conditions defined by Peak Excursion and Peak Polarity .	:CALC{1-9}:MARK{1-10}:FUNC:EXEC :CALC{1-9}:MARK{1-10}:FUNC:TYPE RPE
Peak Excursion	Sets the peak offset (and performs Search Peak at the same time). Peak offset is the difference between the response value of a peak and those of adjacent peaks of opposite polarity (the vertical interval between the tip and the base of a slope, one each on the left and right) in a rectangular display format. The smaller of the two will be used. The peak search will detect peaks with an offset larger than the set value.	:CALC{1-9}:MARK{1-10}:FUNC:PEXC
Peak Polarity	Displays softkeys for selecting the polarity of peaks. A peak search will detect peaks having the matching polarity.	
Positive	Selects positive polarity (and performs Search Peak at the same time). A positive peak is a point whose measured value is larger than the values of the two adjacent points on its left and right.	:CALC{1-9}:MARK{1-10}:FUNC:PPOL POS
Negative	Selects negative polarity (and performs Search Peak at the same time). A negative peak is a point whose measured value is smaller than the values of the two adjacent points on its left and right.	:CALC{1-9}:MARK{1-10}:FUNC:PPOL NEG
Both	Selects both positive and negative polarity (and performs Search Peak at the same time).	:CALC{1-9}:MARK{1-10}:FUNC:PPOL BOTH
Cancel	Returns to the softkey display screen one level higher.	
Return	Returns to the softkey display screen one level higher.	
Target	Displays softkeys for setting and performing target searches. A target refers to a point on a trace that has a unique response value (target value) in a rectangular display format. A target search picks up points that have matching characteristics defined by Target Value and Target Transition . If the Smith chart format or polar format is used, the main response value, among the two response values, will be used to perform searches (e.g., resistance in the Smith (R+jX) format).	

Softkey Functions
Marker Search Menu

Key Operation	Function	SCPI Command
Marker Search	(Continued)	
Target		
Search Target	In a rectangular display format, moves the active marker to the nearest target (i.e., the closest stimulus value on the X-axis) that matches the definition (having a unique response value - the target value). The conditions for a target search must be defined using Target Value and Target Transition .	:CALC{1-9}:MARK{1-10}:FUNC:EXEC :CALC{1-9}:MARK{1-10}:FUNC:TYPE TARG
Search Left	In a rectangular display format, moves the active marker to the target that is nearest on its left and that matches the definition (having a unique response value - the target value). The conditions for a target search must be defined using Target Value and Target Transition .	:CALC{1-9}:MARK{1-10}:FUNC:EXEC :CALC{1-9}:MARK{1-10}:FUNC:TYPE LTAR
Search Right	In a rectangular display format, moves the active marker to the target that is nearest on its right and that matches the definition (having a unique response value - the target value). The conditions for a target search must be defined using Target Value and Target Transition .	:CALC{1-9}:MARK{1-10}:FUNC:EXEC :CALC{1-9}:MARK{1-10}:FUNC:TYPE RTAR
Target Value	Sets the target value (desired response value). (Also performs Search Target at the same time.) A target search uses the target value to look for a point on a trace.	:CALC{1-9}:MARK{1-10}:FUNC:TARG
Target Transition	Displays softkeys for defining the transition direction.	
Positive	Selects positive transition for a target search (and performs Search Target at the same time). Targets with positive transition refer to points whose response value is larger than the value of the adjacent point on its left in a rectangular display format.	:CALC{1-9}:MARK{1-10}:FUNC:TTR POS
Negative	Selects negative transition for a target search (and performs Search Target at the same time). Targets with negative transition refer to points whose response value is larger than the value of the adjacent point on its left in a rectangular display format.	:CALC{1-9}:MARK{1-10}:FUNC:TTR NEG
Both	Selects both positive and negative transition for a target search (and performs Search Target at the same time).	:CALC{1-9}:MARK{1-10}:FUNC:TTR BOTH
Cancel	Returns to the softkey display screen one level higher.	
Return	Returns to the softkey display screen one level higher.	
Tracking	Enables or disables search tracking. When enabled, the currently selected search operation will be performed each time a sweep is completed. If disabled, you can initiate a search by pressing a key for a particular search.	:CALC{1-9}:MARK{1-10}:FUNC:TRAC
Bandwidth	Enables or disables bandwidth searching. When enabled, bandwidth parameters (Insertion loss, Low cutoff point, High cutoff point, Center frequency, Bandwidth and Q) will be displayed on the screen. If the Smith chart format or polar format is used, the main response value, among the two response values, will be used to perform searches (e.g., resistance in the Smith (R+jX) format). For details, see "Determining the Bandwidth of the Trace (Bandwidth Search)" on page 143.	:CALC{1-9}:MARK{1-10}:BWID
Bandwidth Value	Sets the bandwidth. The bandwidth in a bandwidth search is defined by specifying the displacement from the active marker to the cutoff point using the response value (the value assigned to the Y-axis in a rectangular display format).	:CALC{1-9}:MARK{1-10}:BWID:THR
Return	Returns to the "E5070A/E5071A Menu (Top Menu)" on page 404.	

Measurement Menu

Key Operation	Function	SCPI Command
Meas	Displays softkeys for setting measurement parameters. These softkeys will not be displayed unless either the balanced/unbalanced conversion function or the fixture simulator function is turned off (BalUn OFF or Fixture Simulator OFF) in the “Analysis Menu” on page 405 on the E5070A/E5071A.	
S11	Selects parameter S ₁₁ .	:CALC{1-9};PAR{1-9};DEF S11
S21	Selects parameter S ₂₁ .	:CALC{1-9};PAR{1-9};DEF S21
S31 ^{*1}	Selects parameter S ₃₁ .	:CALC{1-9};PAR{1-9};DEF S31
S41 ^{*2}	Selects parameter S ₄₁ .	:CALC{1-9};PAR{1-9};DEF S41
S12	Selects parameter S ₁₂ .	:CALC{1-9};PAR{1-9};DEF S12
S22	Selects parameter S ₂₂ .	:CALC{1-9};PAR{1-9};DEF S22
S32 ^{*1}	Selects parameter S ₃₂ .	:CALC{1-9};PAR{1-9};DEF S32
S42 ^{*2}	Selects parameter S ₄₂ .	:CALC{1-9};PAR{1-9};DEF S42
S13 ^{*1}	Selects parameter S ₁₃ .	:CALC{1-9};PAR{1-9};DEF S13
S23 ^{*1}	Selects parameter S ₂₃ .	:CALC{1-9};PAR{1-9};DEF S23
S33 ^{*1}	Selects parameter S ₃₃ .	:CALC{1-9};PAR{1-9};DEF S33
S43 ^{*2}	Selects parameter S ₄₃ .	:CALC{1-9};PAR{1-9};DEF S43
S14 ^{*2}	Selects parameter S ₁₄ .	:CALC{1-9};PAR{1-9};DEF S14
S24 ^{*2}	Selects parameter S ₂₄ .	:CALC{1-9};PAR{1-9};DEF S24
S34 ^{*2}	Selects parameter S ₃₄ .	:CALC{1-9};PAR{1-9};DEF S34
S44 ^{*2}	Selects parameter S ₄₄ .	:CALC{1-9};PAR{1-9};DEF S44
Return	Returns to the “E5070A/E5071A Menu (Top Menu)” on page 404.	

*1. Only with Options 313, 314, 413, and 414.

*2. Only with Options 413 and 414.

Measurement Menu (Balance Measurement, SE-Bal)

Key Operation	Function	SCPI Command
Meas	Displays softkeys for setting measurement parameters (only for models with Option 313, 314, 413, or 414). To display these softkeys, the balanced/unbalanced conversion topology must be set to unbalanced-balanced (SE-Bal), the balanced/unbalanced conversion function must be on (BalUn ON), and the fixture simulator function must be on (Fixture Simulator ON) in the “Analysis Menu” on page 405.	
Sss11	Selects parameter S_{ss11} . S_{ss11} defines the way an unbalanced signal input to (unbalanced) port 1 on the DUT is reflected as an unbalanced signal.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:SBAL SSS11
Sds21	Selects parameter S_{ds21} . S_{ds21} defines the way an unbalanced signal input to (unbalanced) port 1 on the DUT is transmitted to (balanced) port 2 on the DUT as a differential signal.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:SBAL SDS21
Ssd12	Selects parameter S_{sd12} . S_{sd12} defines the way a differential signal input to (balanced) port 2 on the DUT is transmitted to (unbalanced) port 1 on the DUT as an unbalanced signal.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:SBAL SSD12
Scs21	Selects parameter S_{cs21} . S_{cs21} defines the way an unbalanced signal input to (unbalanced) port 1 on the DUT is transmitted to (balanced) port 2 on the DUT as a common mode signal.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:SBAL SCS21
Ssc12	Selects parameter S_{sc12} . S_{sc12} defines the way a common mode signal input to (balanced) port 2 on the DUT is transmitted to (unbalanced) port 1 on the DUT as an unbalanced signal.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:SBAL SSC12
Sdd22	Selects parameter S_{dd22} . S_{dd22} defines the way a differential signal input to (balanced) port 2 on the DUT is reflected as a differential signal.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:SBAL SDD22
Scd22	Selects parameter S_{cd22} . S_{cd22} defines the way a differential signal input to (balanced) port 2 on the DUT is reflected as a common mode signal.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:SBAL SCD22
Sdc22	Selects parameter S_{dc22} . S_{dc22} defines the way a common mode signal input to (balanced) port 2 on the DUT is reflected as a differential signal.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:SBAL SDC22
Sc22	Selects parameter S_{cc22} . S_{cc22} defines the way a common mode signal input to (balanced) port 2 on the DUT is reflected as a common mode signal.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:SBAL SCC22
Imbalance	Selects parameter Imbalance.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:SBAL IMB
CMRR	Selects parameter CMRR.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:SBAL CMRR
Return	Returns to the “E5070A/E5071A Menu (Top Menu)” on page 404.	

Measurement Menu (Balanced Measurement, Bal-Bal)

Key Operation	Function	SCPI Command
Meas	Displays softkeys for setting up measurement parameters (only for models with Option 412 or 414). To display these softkeys, the balanced/unbalanced conversion topology must be set to balanced-balanced (Bal-Bal), the balanced/unbalanced conversion function must be on (BalUn ON), and the fixture simulator function must be on (Fixture Simulator ON) in the “Analysis Menu” on page 405.	
Sdd11	Selects parameter S_{dd11} . S_{dd11} defines the way a differential signal input to (balanced) port 1 on the DUT is reflected as a differential signal.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:BBAL SDD11
Sdd21	Selects parameter S_{dd21} . S_{dd21} defines the way a differential signal input to (balanced) port 1 on the DUT is transmitted to (balanced) port 2 on the DUT as a differential signal.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:BBAL SDD21
Sdd12	Selects parameter S_{dd12} . S_{dd12} defines the way a differential signal input to (balanced) port 2 on the DUT is transmitted to (balanced) port 1 on the DUT as a differential signal.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:BBAL SDD12
Sdd22	Selects parameter S_{dd22} . S_{dd22} defines the way a differential signal input to (balanced) port 2 on the DUT is reflected as a differential signal.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:BBAL SDD22
Scd11	Selects parameter S_{cd11} . S_{cd11} defines the way a differential signal input to (balanced) port 1 on the DUT is reflected as a common mode signal.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:BBAL SCD11
Scd21	Selects parameter S_{cd21} . S_{cd21} defines the way a differential signal input to (balanced) port 1 on the DUT is transmitted to (balanced) port 2 on the DUT as a common mode signal.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:BBAL SCD21
Scd12	Selects parameter S_{cd12} . S_{cd12} defines the way a differential signal input to (balanced) port 2 on the DUT is transmitted to (balanced) port 1 on the DUT as a common mode signal.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:BBAL SCD12
Scd22	Selects parameter S_{cd22} . S_{cd22} defines the way a differential signal input to (balanced) port 2 on the DUT is reflected as a common mode signal.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:BBAL SCD22
Sdc11	Selects parameter S_{dc11} . S_{dc11} defines the way a common mode signal input to (balanced) port 1 on the DUT is reflected as a differential signal.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:BBAL SDC11
Sdc21	Selects parameter S_{dc21} . S_{dc21} defines the way a common mode signal input to (balanced) port 1 on the DUT is transmitted to (balanced) port 2 on the DUT as a differential signal.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:BBAL SDC21
Sdc12	Selects parameter S_{dc12} . S_{dc12} defines the way a common mode signal input to (balanced) port 2 on the DUT is transmitted to (balanced) port 1 on the DUT as a differential signal.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:BBAL SDC12
Sdc22	Selects parameter S_{dc22} . S_{dc22} defines the way a common mode signal input to (balanced) port 2 on the DUT is reflected as a differential signal.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:BBAL SDC22
Scd11	Selects parameter S_{cc11} . S_{cc11} defines the way a common mode signal input to (balanced) port 1 on the DUT is reflected as a common mode signal.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:BBAL SCC11
Scd21	Selects parameter S_{cc21} . S_{cc21} defines the way a common mode signal input to (balanced) port 1 on the DUT is transmitted to (balanced) port 2 on the DUT as a common mode signal.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:BBAL SCC21
Scd12	Selects parameter S_{cc12} . S_{cc12} defines the way a common mode signal input to (balanced) port 2 on the DUT is transmitted to (balanced) port 1 on the DUT as a common mode signal.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:BBAL SCC12

Softkey Functions
Measurement Menu (Balanced Measurement, Bal-Bal)

Key Operation	Function	SCPI Command
Meas	(Continued)	
Scc22	Selects parameter S_{cc22} . S_{cc22} defines the way a common mode signal input to (balanced) port 2 on the DUT is reflected as a common mode signal.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:BBAL SCC22
Imbalance1	Selects parameter Imbalance1.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:BBAL IMB1
Imbalance2	Selects parameter Imbalance2.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:BBAL IMB2
Sdd21/Scc21	Selects parameter CMRR.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:BBAL CMRR
Return	Returns to the “E5070A/E5071A Menu (Top Menu)” on page 404.	

Measurement Menu (Balanced Measurement, SE-SE-Bal)

Key Operation	Function	SCPI Command
Meas	Displays softkeys for setting measurement parameters (only for models with Option 413 or 414). To display these softkeys, the balanced/unbalanced conversion topology must be set to unbalanced-unbalanced-balanced SE-SE-Bal , the balanced/unbalanced conversion function must be on (BalUn ON), and the fixture simulator function must be on (Fixture Simulator ON) in the “Analysis Menu” on page 405.	
Sss11	Selects parameter S_{ss11} . S_{ss11} defines the way an unbalanced signal input to (unbalanced) port 1 on the DUT is reflected as an unbalanced signal.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:SSB SSS11
Sss21	Selects parameter S_{ss21} . S_{ss21} defines the way an unbalanced signal input to (unbalanced) port 1 on the DUT is transmitted to (unbalanced) port 2 on the DUT as an unbalanced signal.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:SSB SSS21
Sss12	Selects parameter S_{ss12} . S_{ss12} defines the way an unbalanced signal input to (unbalanced) port 2 on the DUT is transmitted to (unbalanced) port 1 on the DUT as an unbalanced signal.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:SSB SSS12
Sss22	Selects parameter S_{ss22} . S_{ss22} defines the way an unbalanced signal input to (unbalanced) port 2 on the DUT is reflected as an unbalanced signal.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:SSB SSS22
Sds31	Selects parameter S_{ds31} . S_{ds31} defines the way an unbalanced signal input to (unbalanced) port 1 on the DUT is transmitted to (balanced) port 3 on the DUT as a differential signal.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:SSB SDS31
Sds32	Selects parameter S_{ds32} . S_{ds32} defines the way an unbalanced signal input to (unbalanced) port 2 on the DUT is transmitted to (balanced) port 3 on the DUT as a differential signal.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:SSB SDS32
Ssd13	Selects parameter S_{sd13} . S_{sd13} defines the way a differential signal input to (balanced) port 3 on the DUT is transmitted to (unbalanced) port 1 on the DUT as an unbalanced signal.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:SSB SSD13
Ssd23	Selects parameter S_{sd23} . S_{sd23} defines the way a differential signal input to (balanced) port 3 on the DUT is transmitted to (unbalanced) port 2 on the DUT as an unbalanced signal.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:SSB SSD23
Scs31	Selects parameter S_{cs31} . S_{cs31} defines the way an unbalanced signal input to (unbalanced) port 1 on the DUT is transmitted to (balanced) port 3 on the DUT as a common mode signal.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:SSB SCS31
Scs32	Selects parameter S_{cs32} . S_{cs32} defines the way an unbalanced signal input to (unbalanced) port 2 on the DUT is transmitted to (balanced) port 3 on the DUT as a common mode signal.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:SSB SCS32
Ssc13	Selects parameter S_{sc13} . S_{sc13} defines the way a common mode signal input to (balanced) port 3 on the DUT is transmitted to (unbalanced) port 1 on the DUT as an unbalanced signal.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:SSB SSC13
Ssc23	Selects parameter S_{sc23} . S_{sc23} defines the way a common mode signal input to (balanced) port 3 on the DUT is transmitted to (unbalanced) port 2 on the DUT as an unbalanced signal.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:SSB SSC23
Sdd33	Selects parameter S_{dd33} . S_{dd33} defines the way a differential signal input to (balanced) port 3 on the DUT is reflected as a differential signal.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:SSB SDD33
Scd33	Selects parameter S_{cd33} . S_{cd33} defines the way a differential signal input to (balanced) port 3 on the DUT is reflected as a common mode signal.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:SSB SCD33
Sdc33	Selects parameter S_{dc33} . S_{dc33} defines the way a common mode signal input to (balanced) port 3 on the DUT is reflected as a differential signal.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:SSB SDC33

Softkey Functions

Measurement Menu (Balanced Measurement, SE-SE-Bal)

Key Operation	Function	SCPI Command
Meas	(Continued)	
Scc33	Selects parameter S_{cc33} . S_{cc33} defines the way a common mode signal input to (balanced) port 3 on the DUT is reflected as a common mode signal.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:SSB SCC33
Imbalance1	Selects parameter Imbalance1.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:SSB IMB1
Imbalance2	Selects parameter Imbalance2.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:SSB IMB2
Sds31/Scs31	Selects parameter CMRR1.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:SSB CMRR1
Sds32/Scs32	Selects parameter CMRR2.	:CALC{1-9}:FSIM:BAL:PAR{1-9}:SSB CMRR2
Return	Returns to the “E5070A/E5071A Menu (Top Menu)” on page 404.	

Preset Menu

Key Operation	Function	SCPI Command
Preset	Displays softkeys for restoring the preset conditions.	
OK	Restores the preset conditions.	:SYST:PRES
Cancel	Returns to the “E5070A/E5071A Menu (Top Menu)” on page 404.	

Save/Recall Menu

Key Operation	Function	SCPI Command
Save/Recall	Displays softkeys for saving and recalling data.	
Save State	Displays softkeys for saving settings.	
State01	Saves the current settings on the internal hard disk drive (D:) and names it State01.sta.	:MMEM:STOR "State01.sta"
State02	Saves the current settings on the internal hard disk drive (D:) and names it State02.sta.	:MMEM:STOR "State02.sta"
State03	Saves the current settings on the internal hard disk drive (D:) and names it State03.sta.	:MMEM:STOR "State03.sta"
State04	Saves the current settings on the internal hard disk drive (D:) and names it State04.sta.	:MMEM:STOR "State04.sta"
State05	Saves the current settings on the internal hard disk drive (D:) and names it State05.sta.	:MMEM:STOR "State05.sta"
State06	Saves the current settings on the internal hard disk drive (D:) and names it State06.sta.	:MMEM:STOR "State06.sta"
State07	Saves the current settings on the internal hard disk drive (D:) and names it State07.sta.	:MMEM:STOR "State07.sta"
State08	Saves the current settings on the internal hard disk drive (D:) and names it State08.sta.	:MMEM:STOR "State08.sta"
Autorec	Saves the current settings on the internal hard disk drive (D:) and names it Autorec.sta. This file will be automatically loaded during the startup process and the analyzer settings will be restored.	:MMEM:STOR "Autorec.sta"
File Dialog...	Opens a dialog box for saving settings. This dialog box allows the user to save settings with an arbitrary name. This key is also used to save settings to a floppy disk.	:MMEM:STOR
Return	Returns to the softkey display screen one level higher.	
Recall State	Displays softkeys for recalling settings.	
State01	Recalls from the internal hard disk drive (D:) the settings saved as State01.sta.	:MMEM:LOAD "State01.sta"
State02	Recalls from the internal hard disk drive (D:) the settings saved as State02.sta.	:MMEM:LOAD "State02.sta"
State03	Recalls from the internal hard disk drive (D:) the settings saved as State03.sta.	:MMEM:LOAD "State03.sta"
State04	Recalls from the internal hard disk drive (D:) the settings saved as State04.sta.	:MMEM:LOAD "State04.sta"
State05	Recalls from the internal hard disk drive (D:) the settings saved as State05.sta.	:MMEM:LOAD "State05.sta"
State06	Recalls from the internal hard disk drive (D:) the settings saved as State06.sta.	:MMEM:LOAD "State06.sta"
State07	Recalls from the internal hard disk drive (D:) the settings saved as State07.sta.	:MMEM:LOAD "State07.sta"
State08	Recalls from the internal hard disk drive (D:) the settings saved as State08.sta.	:MMEM:LOAD "State08.sta"
Autorec	Recalls from the internal hard disk drive (D:) the settings saved as Autorec.sta.	:MMEM:LOAD "Autorec.sta"
File Dialog...	Opens a dialog box for recalling settings. This dialog box allows the user to recall settings saved under arbitrary names. This key is also used to recall a file saved on a floppy disk.	:MMEM:LOAD
Return	Returns to the softkey display screen one level higher.	
Save Channel	Displays softkeys for ???.	
State A	Saves the current settings ???.	:MMEM:STOR:CHAN A
State B	Saves the current settings ???.	:MMEM:STOR:CHAN B
State C	Saves the current settings ???.	:MMEM:STOR:CHAN C
State D	Saves the current settings ???.	:MMEM:STOR:CHAN D

Key Operation	Function	SCPI Command
Save/Recall	(Continued)	
Save Channel		
Clear States	Displays softkeys for clearing registers.	
OK	Clears all registers (A - D).	:MMEM:STOR:CHAN:CLE
Cancel	Returns to the softkey display screen one level higher.	
Return	Returns to the softkey display screen one level higher.	
Recall Channel	Displays softkeys for ???.	
State A	Saves the current settings ???.	:MMEM:LOAD:CHAN A
State B	Saves the current settings ???.	:MMEM:LOAD:CHAN B
State C	Saves the current settings ???.	:MMEM:LOAD:CHAN C
State D	Saves the current settings ???.	:MMEM:LOAD:CHAN D
Return	Returns to the softkey display screen one level higher.	
Save Type	Displays softkeys for selecting the types of data to be saved.	
State Only	Saves settings only.	:MMEM:STOR:STYP STAT
State & Cal	Saves settings and calibration data.	:MMEM:STOR:STYP CST
State & Trace	Saves settings and trace data.	:MMEM:STOR:STYP DST
All	Saves settings, calibration data, and trace data.	:MMEM:STOR:STYP CDST
Cancel	Returns to the softkey display screen one level higher.	
Save Trace Data	Opens a dialog box for saving trace data as a CSV (comma-separated value) file. A CSV file can be opened in spreadsheet software such as Microsoft® Excel®.	:MMEM:STOR:FDAT
Exploler...	Opens Windows Exploler for organizing (cut, copy, paste, delete, rename, format) files and folders. The operation is same as Windows 98 computers. Users can modify files and folders in drive A: (floppy disk drive) and drive D: (user directory). Be sure not to modify any files and folders in drives other than drive A: and drive D:. Doing so will cause malfunctions.	:MMEM:MDIR :MMEM:COPY :MMEM:DEL
Cancel	Returns to the “E5070A/E5071A Menu (Top Menu)” on page 404.	

Scale Menu

Key Operation	Function	SCPI Command
Scale	Displays softkeys for adjusting scales.	
Auto Scale	Automatically adjusts scales for the active trace.	:DISP:WIND{1-9}:TRAC{1-9}:Y:AUTO
Auto Scale All	Automatically adjusts scales for all traces within the active channel.	None
Divisions	Defines the number of divisions on the Y-axis of a rectangular display format. An even number from 4 to 30 must be used. Once set, it is then applied to all traces displayed in any rectangular display format within that channel.	:DISP:WIND{1-9}:TRAC{1-9}:Y:DIV
Scale/Div	In a rectangular format, defines the number of increments per division on the Y-axis. In the Smith chart format or polar format, defines the range (the displacement of the outermost circle). The setting applies to the active trace only.	:DISP:WIND{1-9}:TRAC{1-9}:Y:PDIV
Reference Position	Defines the position of the reference line on a rectangular display format. The position must be defined by using numbers assigned to the Y-axis between 0 (the origin, the X-axis) and the number of divisions (the highest scale). This setting applies only to the active trace. The reference line can also be moved by performing a drag-and-drop operation (pressing the mouse button on the object to be moved and releasing the button after dragging it to the desired position) on one of the reference line pointers (▶ and ◀).	:DISP:WIND{1-9}:TRAC{1-9}:Y:RPOS
Reference Value	Defines the value corresponding to the reference line on a rectangular display format. The setting applies only to the active trace.	:DISP:WIND{1-9}:TRAC{1-9}:Y:RLEV
Marker → Reference	Changes the value of the reference line to the response value of the active marker. The same function is also accessible from the “Marker Function Menu” on page 432.	:CALC{1-9}:MARK{1-10}:SET
Electrical Delay	Sets an electrical delay to the active trace. This function simulates the addition or deletion of a variable length lossless transfer line against the input of a receiver. It can be used to compensate for the electrical length of cables inside the DUT. Although the unit used is seconds, the length (meters) will be displayed in parentheses next to the input box based on the velocity coefficient used at the time.	:CALC{1-9}:CORR:EDEL:TIME
Phase Offset	Sets the values to be added or subtracted in phase measurement (phase offset) (°).	:CALC{1-9}:CORR:OFFS:PHAS
Return	Returns to the “E5070A/E5071A Menu (Top Menu)” on page 404.	

Stimulus Menu

Key Operation	Function	SCPI Command
Start	Sets the lowest frequency for sweeps. Also displays a menu (Stimulus Menu) for defining the sweep range.	:SENS{1-9}:FREQ:STAR
Start	Sets the starting frequency for sweeps.	:SENS{1-9}:FREQ:STAR
Stop	Sets the ending frequency for sweeps.	:SENS{1-9}:FREQ:STOP
Center	Sets the center frequency of the sweep range.	:SENS{1-9}:FREQ:CENT
Span	Sets the frequency span for sweeps.	:SENS{1-9}:FREQ:SPAN
Return	Returns to the “E5070A/E5071A Menu (Top Menu)” on page 404.	
Stop	Sets the ending frequency for sweeps. Also displays the Stimulus Menu same as Start .	:SENS{1-9}:FREQ:STOP
Center	Sets the center frequency of the sweep range. Also displays the Stimulus Menu same as Start .	:SENS{1-9}:FREQ:CENT
Span	Sets the frequency span for sweeps. Also displays the Stimulus Menu same as Start .	:SENS{1-9}:FREQ:SPAN

Sweep Setup Menu

Key Operation	Function	SCPI Command
Sweep Setup	Sets the output power level of the internal signal source of the analyzer. Also displays softkeys for setting up sweeps.	:SOUR{1-9}:POW
Power	Sets the output power level of the internal signal source of the analyzer.	:SOUR{1-9}:POW
Power Ranges ^{*1}	Displays softkeys for selecting the power range.	
–15 to 0	Sets the power range to –15 dBm to 0 dBm.	:SOUR{1-9}:POW:ATT 0
–20 to –5	Sets the power range to –20 dBm to –5 dBm.	:SOUR{1-9}:POW:ATT 5
–25 to –10	Sets the power range to –25 dBm to –10 dBm.	:SOUR{1-9}:POW:ATT 10
–30 to –15	Sets the power range to –30 dBm to –15 dBm.	:SOUR{1-9}:POW:ATT 15
–35 to –20	Sets the power range to –35 dBm to –20 dBm.	:SOUR{1-9}:POW:ATT 20
–40 to –25	Sets the power range to –40 dBm to –25 dBm.	:SOUR{1-9}:POW:ATT 25
–45 to –30	Sets the power range to –45 dBm to –30 dBm.	:SOUR{1-9}:POW:ATT 30
–50 to –35	Sets the power range to –50 dBm to –35 dBm.	:SOUR{1-9}:POW:ATT 35
Cancel	Returns to the softkey display screen one level higher.	
Sweep Time	Sets the sweep time for each source port. Sweep time mode can be either manual or automatic. Inputting the sweep time from the keyboard forces the analyzer to go into manual mode. In the manual sweep time mode, input values will be maintained even when measurement conditions change, as long as the analyzer can handle it. If the sweep time becomes lower than the analyzer’s lower sweep time limit, the sweep time will be reset to the shortest time within the conditions. If the sweep time exceeds the analyzer’s upper sweep time limit, the sweep time will be reset to the longest time within the conditions. Inputting the value “0” as the sweep time causes the analyzer to go into automatic sweep time mode. In this mode, the sweep time is set to the shortest possible time depending on the measurement conditions.	:SENS{1-9}:SWE:TIME
Sweep Delay	Sets the wait time (sweep delay) before starting a sweep for each source port.	:SENS{1-9}:SWE:DEL
Sweep Mode	Displays softkeys for selecting the sweep mode.	
Std Stepped	Selects the stepped mode.	:SENS{1-9}:SWE:GEN STEP
Std Swept	Selects the swept mode.	:SENS{1-9}:SWE:GEN ANAL
Fast Stepped	Selects the fast stepped mode.	:SENS{1-9}:SWE:GEN FST
Fast Swept	Selects the fast swept mode.	:SENS{1-9}:SWE:GEN FAN
Cancel	Returns to the softkey display screen one level higher.	
Points	Sets the number of points per sweep. The number of points should be from 2 to 1601.	:SENS{1-9}:SWE:POIN
Sweep Type	Displays softkeys for selecting the sweep type.	
Lin Freq	Selects linear frequency sweep.	:SENS{1-9}:SWE:TYPE LIN
Log Freq	Selects logarithmic frequency sweep.	:SENS{1-9}:SWE:TYPE LOG
Segment	Selects segment sweep. Segment sweep is a function in which the user can define a multiple number of frequency ranges, called segments, each with a unique number of points, IF bandwidth, power level, delay, sweep mode and sweep time, and with all segments covered in a single sweep. This function lets the user skip unnecessary frequency ranges and define optimal measurement conditions for each segment so that measurement throughput can be improved.	:SENS{1-9}:SWE:TYPE SEG
Cancel	Returns to the softkey display screen one level higher.	

Key Operation	Function	SCPI Command
Sweep Setup	(Continued)	
Edit Segment Table	Displays the segment sweep setup table as well as softkeys for editing the segment table.	
Freq Mode	Alternates the setup mode for the sweep range between two methods: one using the starting and ending frequencies (Start/Stop), and the other using the center frequency and a frequency span (Center/Span).	:SENS{1-9};SEGM:DATA
List IFBW	Enables or disables the IF bandwidth display in the segment table.	:SENS{1-9};SEGM:DATA
List Power	Enables or disables the power level display in the segment table.	:SENS{1-9};SEGM:DATA
List Delay	Enables or disables the segment delay display in the segment table.	:SENS{1-9};SEGM:DATA
List Sweep Mode	Enables or disables the segment sweep mode display in the segment table.	:SENS{1-9};SEGM:DATA
List Time	Enables or disables the segment sweep time display in the segment table.	:SENS{1-9};SEGM:DATA
Delete	Deletes from the segment table the segment upon which the cursor is currently located. If the cursor is not displayed, the segment on the bottom will be deleted.	:SENS{1-9};SEGM:DATA
Add	Adds a new segment immediately above the segment upon which the cursor is currently located. If the cursor is not displayed, a new segment will be added to the bottom of the table.	:SENS{1-9};SEGM:DATA
Clear Segment Table	Displays softkeys for clearing elements of the segment table.	
OK	Deletes all segments in the segment table.	None
Cancel	Returns to the softkey display screen one level higher.	
Export to CSV File	Exports (saves data in file formats used by other software) the segment table as a CSV (comma-separated value) file.	:MMEM:STOR:SEGM
Import from CSV File	Imports (loads a file that is written in a format used by other software) a CSV (comma-separated value) file to the segment table of E5070A/E5071A.	:MMEM:LOAD:SEGM
Return	Returns to the softkey display screen one level higher.	
Segment Display	Selects linear frequency (Freq Base) or selects the order of measurements (1, 2, ..., N; where N refers to the number of points) (Order Base) for drawing the X-axis of a rectangular display format in a segment sweep.	:DISP:WIND{1-9};X:SPAC LIN :DISP:WIND{1-9};X:SPAC OBAS
Return	Returns to the "E5070A/E5071A Menu (Top Menu)" on page 404.	

*1. Only with Options 214, 314, and 414.

System Menu

Key Operation	Function	SCPI Command
System	Displays softkeys for performing limit tests and accessing control and management functions on the analyzer.	
Print	Outputs the current screen to a printer.	:HCOP
Abort Printing	Aborts printing.	:HCOP:ABOR
Printer Setup	Opens a dialog box for setting up the printer.	None
Invert Image	Inverts the colors of the screen display.	:HCOP:IMAG
Dump Screen Image	Opens a dialog box for saving the screen image in BMP (Windows or OS/2 bitmap) format.	:MMEM:STOR:IMAG
E5091A Setup	Displays softkeys for setting up the E5091A.	
Select ID	Displays softkeys for selecting the E5091A's ID.	
1	Selects 1.	None
2	Selects 2.	None
Cancel	Returns to the softkey display screen one level higher.	
Port 1	Displays softkeys for selecting a test port of the E5091A ???.	
A	Selects A.	:SENS{1-9}:MULT{1-2}:TEST9:PORT1 A
T1	Selects T1.	:SENS{1-9}:MULT{1-2}:TEST9:PORT1 T1
Cancel	Returns to the softkey display screen one level higher.	
Port 2	Displays softkeys for selecting a test port of the E5091A ???.	
T1	Selects T1.	:SENS{1-9}:MULT{1-2}:TEST9:PORT2 T1
T2	Selects T2.	:SENS{1-9}:MULT{1-2}:TEST9:PORT2 T2
Cancel	Returns to the softkey display screen one level higher.	
Port 3	Displays softkeys for selecting a test port of the E5091A ???.	
R1+	Selects R1+.	:SENS{1-9}:MULT{1-2}:TEST9:PORT3 R1
R2+	Selects R2+.	:SENS{1-9}:MULT{1-2}:TEST9:PORT3 R2
R3+	Selects R3+.	:SENS{1-9}:MULT{1-2}:TEST9:PORT3 R3
Cancel	Returns to the softkey display screen one level higher.	
Port 4	Displays softkeys for selecting a test port of the E5091A ???.	
R1-	Selects R1- .	:SENS{1-9}:MULT{1-2}:TEST9:PORT4 R1
R2-	Selects R2- .	:SENS{1-9}:MULT{1-2}:TEST9:PORT4 R2
R3-	Selects R3- .	:SENS{1-9}:MULT{1-2}:TEST9:PORT4 R3
Cancel	Returns to the softkey display screen one level higher.	
Control Lines	Displays softkeys for setting up HIGH/LOW of control lines.	
Line 1	Sets HIGH/LOW of line 1.	:SENS{1-9}:MULT{1-2}:TEST9:OUTP
Line 2	Sets HIGH/LOW of line 2.	:SENS{1-9}:MULT{1-2}:TEST9:OUTP
Line 3	Sets HIGH/LOW of line 3.	:SENS{1-9}:MULT{1-2}:TEST9:OUTP
Line 4	Sets HIGH/LOW of line 4.	:SENS{1-9}:MULT{1-2}:TEST9:OUTP
Line 5	Sets HIGH/LOW of line 5.	:SENS{1-9}:MULT{1-2}:TEST9:OUTP
Line 6	Sets HIGH/LOW of line 6.	:SENS{1-9}:MULT{1-2}:TEST9:OUTP
Line 7	Sets HIGH/LOW of line 7.	:SENS{1-9}:MULT{1-2}:TEST9:OUTP
Line 8	Sets HIGH/LOW of line 8.	:SENS{1-9}:MULT{1-2}:TEST9:OUTP
Cancel	Returns to the softkey display screen one level higher.	
E5091A Property	Enables or disables the display of the E5091A properties.	:SENS:MULT{1-2}:DISP

Key Operation	Function	SCPI Command
System	(Continued)	
E5091A Setup		
E5091A Control	Enables or disables control of the E5091A.	:SENS:MULT{1-2}:STAT
Return	Returns to the softkey display screen one level higher.	
Misc Setup	Displays softkeys for setting up the beeper function, GPIB, Network, internal clock, key lock function and color of display image.	
Beeper	Displays softkeys for setting up the beeper function.	
Beep Complete	Enables or disables beeps at the end of processes. When enabled, the user will be notified with a beep when a measurement has completed or settings have been saved.	:SYST:BEEP:COMP:STAT
Test Beep Complete	Tests the beeping sound.	:SYST:BEEP:COMP:IMM
Beep Warning	Enables or disables warning beeps. When enabled, all warning messages will be accompanied by beeps.	:SYST:BEEP:WARN:STAT
Test Beep Warning	Tests the beeping sound for warnings.	:SYST:BEEP:WARN:IMM
Return	Returns to the softkey display screen one level higher.	
GPIB Setup	Displays softkeys for setting up the GPIB.	
GPIB Configuration	Toggles the GPIB configuration (between talker/listener mode and system controller mode).	None
Talker/Listener Address	Sets the GPIB address for controlling the analyzer from a controller.	None
System Controller Address	Sets an address for using the analyzer as a system controller.	None
Return	Returns to the softkey display screen one level higher.	
Network Setup	Displays softkeys for configuring network settings.	
Telnet Server	Enables or disables the telnet server function.	None
Network Configuration	Opens a dialog box for configuring network settings.	None
Network Device	Enables or disables the network device function.	None
Return	Returns to the softkey display screen one level higher.	
Clock Setup	Displays softkeys for setting the internal clock.	
Set Date and Time	Opens a dialog box for setting the date and time of the internal clock.	:SYST:DATE :SYST:TIME
Show Clock	Enables or disables the time and date display inside the status bar.	:DISP:CLOC
Return	Returns to the softkey display screen one level higher.	
Key Lock	Displays softkeys for locking the keyboard and the mouse.	
Front Panel & Keyboard Lock	Locks the front panel keys and the keyboard (key operations disabled).	:SYST:KLOC:KBD
Touch Screen & Mouse Lock	Locks the touch screen ^{*1} and the mouse (mouse operations disabled).	:SYST:KLOC:MOUS
Return	Returns to the softkey display screen one level higher.	

Softkey Functions System Menu

Key Operation	Function	SCPI Command
System	(Continued)	
Misc Setup		
Color Setup	Displays softkeys for setting up the color of display image.	
Normal	Displays softkeys for setting up the color of the normal display.	
Data Trace 1	Displays softkeys for setting up the color of the data trace of Trace 1.	
Red	Displays softkeys for setting up the amount of red in a color.	
0	Sets 0.	:DISP:COL{1-2}:TRAC1:DATA
1	Sets 1.	:DISP:COL{1-2}:TRAC1:DATA
:	:	:
5	Sets 5.	:DISP:COL{1-2}:TRAC1:DATA
Cancel	Returns to the softkey display screen one level higher.	
Green	Displays softkeys for setting up the amount of green in a color. The lower-level softkeys are the same as those for Red .	
Blue	Displays softkeys for setting up the amount of blue in a color. The lower-level softkeys are the same as those for Red .	
Return	Returns to the softkey display screen one level higher.	
Data Trace 2	Displays softkeys for setting up the color of the data trace of Trace 2. The lower-level softkeys are the same as those for Data Trace 1 .	:DISP:COL{1-2}:TRAC2:DATA
:	:	:
Data Trace 9	Displays softkeys for setting up the color of the data trace of Trace 9. The lower-level softkeys are the same as those for Data Trace 1 .	:DISP:COL{1-2}:TRAC9:DATA
Mem Trace 1	Displays softkeys for setting up the color of the memory trace of Trace 1. The lower-level softkeys are the same as those for Data Trace 1 .	:DISP:COL{1-2}:TRAC1:MEM
:	:	:
Mem Trace 9	Displays softkeys for setting up the color of the memory trace of Trace 9. The lower-level softkeys are the same as those for Data Trace 1 .	:DISP:COL{1-2}:TRAC9:MEM
Graticule Main	Displays softkeys for setting up the color of the graticule labels and the outer frame of graphs. The lower-level softkeys are the same as those for Data Trace 1 .	:DISP:COL{1-2}:GRAT1
Graticule Sub	Displays softkeys for setting up the color of the graticule lines in graphs. The lower-level softkeys are the same as those for Data Trace 1 .	:DISP:COL{1-2}:GRAT2
Limit Fail	Displays softkeys for setting up the color of the fail label of the limit test. The lower-level softkeys are the same as those for Data Trace 1 .	:DISP:COL{1-2}:LIM1
Limit Line	Displays softkeys for setting up the color of the limit line of the limit test. The lower-level softkeys are the same as those for Data Trace 1 .	:DISP:COL{1-2}:LIM2
Background	Displays softkeys for setting up the color of the background. The lower-level softkeys are the same as those for Data Trace 1 .	:DISP:COL{1-2}:BACK
Reset Color	Resets the color to the factory setting state.	:DISP:COL{1-2}:RES
Return	Returns to the softkey display screen one level higher.	
Invert	Displays softkeys for setting up the color of the inverted display. The lower-level softkeys are the same as those for Normal .	
Return	Returns to the softkey display screen one level higher.	
Return	Returns to the softkey display screen one level higher.	
Backlight	Turns the backlight for the LCD screen on/off.	:SYST:BACK
Firmware Revision	Displays the firmware revision information in a dialog box.	*IDN?

Key Operation	Function	SCPI Command
System	(Continued)	
Service Menu	Displays softkeys for maintenance services.	
Test Menu	Displays softkeys for self diagnosis functions.	
Power On Test	Executes an internal test.	None
Display	Executes a display test.	None
Front Panel	Tests the front panel keys (hardkeys).	None
Adjust Touch Screen	Executes calibration of the touch screen.	None
Return	Returns to the softkey display screen one level higher.	
System Correction	Turns ON/OFF error correction, which uses system calibration data. If user calibration using [Cal] is executed properly and the error correction is valid, you can turn off system error correction and reduce measurement time.	:SYST:CORR
Avoid Spurious	Turns ON/OFF the avoid spurious mode.	:SENS{1-9}:SWE:ASP
High Temperature	Turns ON/OFF the high temperature measurement mode. When the high temperature measurement mode is turned on, drift error can be reduced in the ambient temperature range of 28°C to 33°C. If you use the analyzer within the range of 23°C ± 5°C, you must turn off this function.	:SYST:TEMP:HIGH
Enable Options	Displays softkeys for other options.	
Restart Menu	Displays softkeys for rebooting the analyzer.	
Service Functions	Displays softkeys for performing service functions. This option is not open to average users.	
Return	Returns to the softkey display screen one level higher.	
Return	Returns to the "E5070A/E5071A Menu (Top Menu)" on page 404.	

*1. Only with Options 016.

Trigger Menu

Key Operation	Function	SCPI Command
Trigger	Displays following seven softkeys for setting the trigger. Once the trigger mode is set, measurements are executed according to the trigger mode even when the channel is no longer on display due to reduction of the number of channels to be displayed from the “Display Menu” on page 424.	
Hold	Sets the active channel trigger mode to “hold”. A trigger sent from the trigger source to that channel will not prompt a sweep.	:INIT{1-9}:CONT
Single	Sets the active channel trigger mode to “single”. A trigger sent from the trigger source to that channel prompts a single sweep and then the sweep mode changes to “hold.”	:INIT{1-9}
Continuous	Sets the active channel trigger mode to “continuous”. Each trigger sent from the trigger source to that channel prompts a single sweep.	:INIT{1-9}:CONT
Hold All Channels	Sets all channel trigger modes to “hold”.	None
Continuous Disp Channels	Sets all displayed channel trigger modes to “continuous”. See “Number of Channels and Channel Window Arrangement” on page 56 for details about displayed channels.	None
Trigger Source	Displays softkeys for selecting the trigger source.	
Internal	Selects the “internal” trigger source of the analyzer. The analyzer will generate a series of trigger signals. A trigger, once generated, is sent to all channels in order no matter how many channels are displayed.	:TRIG:SOUR INT
External	Selects the “external” trigger source. A signal input to the external trigger input terminal (BNC(f) connector) on the rear panel will be used as the trigger source. A trigger, once generated, is sent to all channels in order no matter how many channels are displayed.	:TRIG:SOUR EXT
Manual	Sets the trigger source to “manual”. Pressing the Trigger key in the Trigger Menu generates a trigger. A trigger, once generated, is sent to all channels in order no matter how many channels are displayed.	:TRIG:SOUR MAN
Bus	Sets the analyzer trigger source to “bus”. A trigger is generated by sending a trigger command through the GPIB or a LAN. A trigger, once generated, is sent to all channels in order no matter how many channels are displayed.	:TRIG:SOUR BUS
Cancel	Returns to the softkey display screen one level higher.	
Restart	Aborts a sweep.	:ABOR
Trigger	When the trigger source is set to “manual”, generates a trigger.	:TRIG
Return	Returns to the “E5070A/E5071A Menu (Top Menu)” on page 404.	


E **General Principles of Operation**

This chapter explains the general principles of operation for the Agilent E5070A/E5071A.

System Description

A network analyzer supplies a sweep signal to a DUT, measures its transmission and reflection, and displays the results as ratios against the input signal from the signal source. The E5070A/E5071A network analyzer consists of the circuit modules shown in Figure E-1.

Figure E-1 System Diagram for the E5070A/E5071A Network Analyzer



e5070aue124

Synthesized Source

The synthesized source generates an RF sweep signal in the following frequency range.

- E5070A: 300 kHz ~ 3 GHz
- E5071A: 300 kHz ~ 8.5 GHz

The signal source is phase-locked to a highly reliable quartz crystal oscillator to maintain a high level of accuracy in its frequency as well as to achieve precise phase measurements. The level of RF output power is controlled within the range of -15 dBm ~ 0 dBm by the internal ALC (automatic leveling control) circuit. The E5070A/E5071A with option 214, 314, or 414 comes with a source-stepping attenuator which allows the user to set the power level in the range of -50 dBm ~ 0 dBm.

Source Switcher

The source switcher is used to switch test ports to which the RF signal is supplied from the source.

Signal Separator

The signal separator consists of directivity couplers that detect input and output signals at the test ports. On a test port to which a signal is output, the output signal and the reflection from the DUT are detected as the reference signal (R) and the test signal (T), respectively. On the other ports, the signal that is transmitted through the DUT is detected as the test signal (T). All signals are then sent to the receiver.


Receiver

Each signal that is sent to the receiver is first converted into an IF signal by a mixer and then converted into a digital signal by an ADC (analog to digital converter). These processes are applied to each signal independently. The digital data is then analyzed by a micro processor and measurement results will be displayed on the screen.

Data Processing

The internal data processing flowchart for the E5070A/E5071A is shown in Figure E-2.

Figure E-2 Data Processing Flowchart



e5070aue125

ADC

The ADCs (analog-to-digital converters) convert analog signals fed to the receiver and converted into IF signals (R_1, R_2, \dots, R_n and T_1, T_2, \dots, T_n) into digital signals. One ADC is available for each signal and the conversion takes place simultaneously.

Digital Filter

The digital filter performs a discrete Fourier transformation (DFT) and picks up IF signals. Each IF signal is then converted into a complex number that has a real part and an imaginary part. The IF bandwidth of the analyzer is equivalent to the bandwidth of the DFT filter. The IF bandwidth can be set in the range of 10 Hz ~ 100 kHz.

IF Range Correction

Input signals that went through ranging at the receiver are reverted (corrected) to previous values before the ranging.

Ratio Calculation

The ratio between two signals is determined by performing divisions on complex numbers.

Port Characteristics Correction

The equivalent source match error, the directivity error, and the tracking error of each test port bridge are corrected.

Sweep Averaging

The average of complex indices is determined based on data obtained from multiple sweep measurements. Sweep averaging is effective in reducing random noise in measurements.

Raw Data Array

The results from all data processing done up to this point are stored in this array as raw data. All prior data processing is performed as each sweep takes place. When the full N-port error correction (N=2 to 4) is enabled, all $4 \times N$ S parameters are stored in the raw data array and used in error correction. The user is not allowed to access (read/write) this raw data array.

Error Correction/Error Correction Coefficient Array

When error correction is enabled, the process eliminates the system errors that are reproducible and stored in the error correction coefficient array (calibration coefficient array). It accommodates everything from the simple vector normalization to the full 12-term error correction. The user is not allowed to access (read/write) this error correction coefficient array.

Port Extension

This process carries out a simulation of adding or eliminating a variable length no-loss transmission path on each test port so that the reference plane of calibration is moved. The port extension is defined by an electrical delay (sec).

Fixture Simulator

A data conversion by the fixture simulator function is executed. The fixture simulator function is a collective term for six different functions: balanced-unbalanced conversion, addition of matching circuits, port reference impedance conversion, network elimination, addition of differential matching circuits, and differential reference impedance conversion.

Corrected Data Array

Unlike the raw data array, this array stores the results obtained after error corrections, port extensions, or the fixture simulator functions are applied. The user is allowed only to read

General Principles of Operation

Data Processing

data from the corrected data array.

Corrected Memory Array

By pressing **Display** - Data → Mem, the contents of the corrected data array will be copied to this array. The user is allowed only to read data from the corrected memory array.

Data Math

Data processing is carried out using the corrected data array and the corrected memory array. Four types of data processing – addition, subtraction, multiplication, and division – are available.

Electrical Delay/Phase Offset

An electrical delay and a phase offset are applied to each trace. By setting an electrical delay, a linear phase that is proportional to the frequency will be added or subtracted. On the other hand, setting a phase offset adds or subtracts a phase that is constant throughout the frequency range. Incidentally, data processing performed from this point on in the flowchart is applied to both the data array and the memory array.

Data Format/Group Delay

Complex data consisting of the real parts and the imaginary parts are converted into scalar data according to the data format of user's choice. Group delays are also calculated here.

Smoothing

By enabling the smoothing function, each point in a sweep measurement will be replaced by a moving average of several measurement points nearby. The number of points used in calculating a moving average is determined by the smoothing aperture set by the user. The smoothing aperture is defined by a percentage against the sweep span.

Formatted Data Array/Formatted Memory Array

All results from data processing are stored in the formatted data array and the formatted memory array. The marker functions are applied to these arrays. The limit test is applied to the formatted data array. The user is allowed to read/write data from/to these arrays.

Offset/Scale

Each set of data is processed so that traces can be drawn on the screen. Particular scaling depending on the data format is applied using the position of the reference line, the value of the reference line, and the scale/graticule settings.

Display

The results obtained after data processing are displayed on the screen as traces.

F Replacing the 8753ES with the E5070A/E5071A

This chapter describes the information necessary to replace Agilent 8753ES with the Agilent E5070A/E5071A.

Important Functional Differences

This section describes the key differences between the Agilent 8753ES and Agilent E5070A/E5071A.

Channel and Trace Concepts

In the 8753ES, channels 1 and 2 are independent from each other and have auxiliary channels, channels 3 and 4, respectively. Channels 3 and 4 can be displayed as additions to channels 1 and 2, respectively. This allows up to four channels to be displayed for up to four traces on the screen simultaneously. Channels 1 and 3 and channels 2 and 4 are always coupled, while channels 1 and 2 are independent from each other. This enables you to specify different sweep conditions on each of channels 1 and 2. The E5070A/E5071A has nine independent channels, each of which allows sweep conditions to be defined different from those on other channels. On the screen you can open up nine windows, each of which allows up to nine traces to be defined.

Measurement Parameters

In the 8753ES, S-parameters as well as measurement parameters such as A, B, R, A/R, B/R, and A/B are supported to enable you to measure values such as the absolute value of the power input to a port. The E5070A/E5071A, however, allows only S-parameters to be measured.

Test Port Output Ranges

The 8753ES comes standard with test sets for two ports, while the E5070A/E5071A comes optionally with test sets for two ports (Options 213 and 214), three ports (Options 313 and 314), and four ports (Options 413 and 414). Furthermore, the 8753ES comes optionally with a 75 Ω test set (Option 075), while the E5070A/E5071A does not.

For more about the measurement frequency ranges of the 8753ES and E5070A/E5071A, see Table F-1.

Table F-1 Measurement Frequency Ranges

Function	8753ES	E5070A/E5071A
Measurement frequency range	30 kHz to 3 GHz (std.)	300 kHz to 3 GHz (E5070A)
	30 kHz to 6 GHz (Option 006)	300 kHz to 8.5 GHz (E5071A)

For more about the output power levels and output power ranges of the 8753ES and E5070A/E5071A, see Table F-2. As is seen in this table, the output power level ranges of the E5070A/E5071A are narrower than those of the 8753ES.

Table F-2 Test Port Output Power Levels

Function	8753ES	E5070A/E5071A
Output power levels	-85 dBm to 10 dBm (std.) -85 dBm to 8 dBm (Options 014 and 075)	-15 dBm to 0 dBm (Options 213, 313, and 413) -50 dBm to 0 dBm (Options 214, 314, and 414)
Output power ranges	-15 dBm to 10 dBm (std.) or -15 dBm to 8 dBm (Options 014 and 075), -25 dBm to 0 dBm, -35 dBm to -10 dBm, -45 dBm to -20 dBm, -55 dBm to -30 dBm, -65 dBm to -40 dBm, -75 dBm to -50 dBm, -85 dBm to -60 dBm	-15 dBm to 0 dBm only (Options 213, 313, and 413) -15 dBm to 0 dBm, -20 dBm to -5 dBm, -25 dBm to -10 dBm, -30 dBm to -15 dBm, -35 dBm to -20 dBm, -45 dBm to -30 dBm, -50 dBm to -35 dBm (Options 214, 314, and 414)

Sweep Function

The list(segment) sweep function enables you to perform measurements corresponding to two or more sweep conditions in one sweep operation and is supported both on the 8753ES and E5070A/E5071A. While the 8753ES allows only up to 30 segments per table to be defined, the E5070A/E5071A allows up to 201 segments to be defined. Furthermore, while two or more commands are needed to create a table using GPIB (SCPI) commands on the 8753ES, only one command does the same function on the E5070A/E5071A.

The 8753ES supports an IF bandwidth up to 6 kHz, but the E5070A/E5071A supports an IF bandwidth up to 100 kHz, enabling faster sweep operations than with the 8753ES.

While the power sweep function is supported on the 8753ES, it is not supported on the E5070A/E5071A. Furthermore, while the 8753ES supports automatically selecting the output power range, the E5070A/E5071A supports only manual selection.

On the 8753ES, which supports frequency offset sweeps, frequency conversion devices such as mixers can be measured. The E5070A/E5071A, however, does not support this function.

Replacing the 8753ES with the E5070A/E5071A
Important Functional Differences

Calibration

The types of calibration kits supported by the 8753ES and E5070A/E5071A are shown in Table F-3.

Table F-3 Supported Calibration Kits

Type of calibration kit	8753ES	E5070A/E5071A
7 mm	85031B	N/A
3.5 mm	85033C/D/E	85033D/E, 85032D
N type	50 Ω: 85032B/E/F 75 Ω: 85036B/E	50 Ω: 85032B/F
2.4 mm	85056/D	N/A
TRL 3.5 mm	85052C	N/A
Others	User-defined calibration kit	User-defined calibration kit

The 8753ES allows only one type of user-defined calibration kit to be saved in the internal memory. Up to 15 classes can be set up when defining calibration kits, including 12 classes (isolation included) to be used for full 2-port calibration and three calibration classes (THRU, reflect, and line/match for TRL*/LRM* calibration. A maximum of seven standards can be defined for each calibration class.

In contrast, the E5070A/E5071A allows ten types of user-defined calibration kits to be saved in the internal memory, which include the five calibration kits registered beforehand. When setting up calibration classes, OPEN, SHORT, and LOAD can be set up on each port and THRU between ports. Only one standard is allowed for each calibration class.

On the 8753ES, supported calibration types include not only measurement port calibration but also receiver calibration and power meter calibration used in power sweeps. On the E5070A/E5071A, however, only response calibration, 1-port calibration, and full 2-port calibration are supported. For three or more ports, full 3-port calibration (Options 313, 314, 413, and 414) and full 4-port calibration (Options 413 and 414) are supported.

ECal

The 8753ES needs a PC interface unit to perform calibration using the ECal module, while the E5070A/E5071A needs only the main body of the instrument and the ECal module to perform the same function.

Both the 8753ES and E5070A/E5071A support ECal measurement. However, each supports slightly different functions. The 8753ES supports enhanced response calibration, 1-port calibration for S11 and S22, and full 2-port calibration. Although the E5070A/E5071A does not support enhanced response calibration, it does support full 3-port calibration (Options 313, 314, 413, 414) and full 4-port calibration (Options 413, 414), making multi-port calibration possible.

While the 8753ES allows the manual measurement for the THRU standard, the E5070A/E5071A does not. Furthermore, the 8753ES allows a frequency array or module information to be read, but these functions are not supported on the E5070A/E5071A.

Trigger System

The trigger system detects the signal for starting a measurement (trigger) and controls decisions on whether to measure or not measure.

On the 8753ES, the trigger state is available for the pair of a main channel and an auxiliary channel (two pairs: channels 1 and 3 and channels 2 and 4). For each pair, three states are available: Hold, Waiting for Trigger, and Measurement. When a trigger event occurs, one pair of channels in the Waiting for Trigger state are put into a sweep operation. If the other pair is also Waiting for Trigger, then the next trigger event puts it into sweep operation as well. When the sweep condition coupling channels is turned on, the Hold, Waiting for Trigger, and Measurement states are common to all channels. In this case, when a trigger event occurs in the Waiting for Trigger state, all channels are put into sweep operation. For example, when you set channel 1 and 2 to uncouple and sweep each channel, you need to set each channel to Hold state and make trigger events to each channel.

On the E5070A/E5071A, the trigger system involves states of the entire system and those of each of the channels. Since a trigger event is common to all channels, three system-wide states exist: Hold, Waiting for Trigger, and Measurement. On the other hand, two states exist for each channel: Idle and Startup. For a channel in an Idle state, measurement is not performed at all, while for a channel in Startup state, measurements are started in sequence after an event occurs. When all channels are in an Idle state, the E5070A/E5071A is in Hold state when viewed as an entire system. If even one Startup state channel exists, the E5070A/E5071A enters the Waiting for Trigger or Measurement state. Upon a transition from the Waiting for Trigger to the Measurement state, measurement is performed on channels put into Startup state starting with the channel with the smallest channel number.

While the 8753ES allows either High or Low input signals from the external trigger line to be selected, the E5070A/E5071A allows only Low input signals to be selected.

Replacing the 8753ES with the E5070A/E5071A Important Functional Differences

Data Flow

The data flow in the 8753ES is shown in Figure F-1 while the flow in the E5070A/E5071A is shown in Figure F-2. As described in “Reading/Writing Data” on page 466, the types of data you can read/write using the 8753ES differ from those you can read/write using the E5070A/E5071A.

Figure F-1

8753ES Data Flow





Figure F-2

E5070A/E5071A Data Flow



F. Replacing the 8753ES
 with the E5070A/E5071A

Replacing the 8753ES with the E5070A/E5071A
Important Functional Differences

Reading/Writing Data

Types of data that can be handled by the 8753ES and E5070A/E5071A are listed in Table 3-4.

Table F-4 Reading/Writing Data

Function	8753ES	E5070A/E5071A
Data transfer format	Intra-device binary IEEE 32-bit floating point IEEE 64-bit floating point ASCII PC-DOS 32-bit floating point	IEEE 64-bit floating point ASCII
Reading/Writing data	Raw data array Calibration coefficient array (before interpolation) Corrected data array Formatted memory array Memory trace Calibration kit array data Power meter calibration coefficient array (before interpolation)	Formatted data array Formatted memory array
Reading data	Pre-raw data (in Take4 mode) Calibration coefficient array (after interpolation) Power meter calibration coefficient array (after interpolation) Entry area display All lists in list format	Corrected data array Corrected memory array

Screen Display and Marker Functions

The 8753ES allows up to four channels to be displayed on the screen. Up to five markers can be displayed on each channel. Also, one of the displayed markers can be designated as the reference marker. Each channel also supports a fixed marker that can be established at a fixed position.

In contrast, the E5070A/E5071A enables you to have all nine channels displayed by opening up nine separate windows on the screen. Nine traces can be displayed for each channel, and up to nine markers can be displayed for each trace. In addition to the markers displayed, you can also designate one marker as the reference marker. The E5070A/E5071A, however, does not support fixed markers.

The 8753ES supports the Maximum, Minimum, Target value, and Bandwidth marker functions. The E5070A/E5071A supports all these in addition to a Peak Search function. Using this function, you can determine whether or not to search for a positive or negative peak. In addition, the 8753ES has an additional function to search for the maximum or minimum bandwidth. While the 8753ES allows a target value or search tracking to be established only on the active marker, the E5070A/E5071A allows a target value or search tracking to be established on all markers.

Math Operation Functions on Traces

On the 8753ES, each channel is provided with a memory trace. For this reason, math operations between the data trace and memory trace are supported: “Data / Memory” and “Data – Memory”. On the E5070A/E5071A, however, “Data × Memory” and “Data +

Memory” are supported along with the division and subtraction operations described above.

The trace displays supported on the 8753ES are: “Data trace only”, “Memory trace only”, “Both memory trace and data trace”, and “Data math only”. The E5070A/E5071A supports these functions in addition to “Both data math and memory trace”.

Device Test Functions

The 8753ES supports the limit test, ripple test, and bandwidth test, while the E5070A/E5071A supports only the limit test. For the limit test on the 8753ES, a limit test table is provided for each channel with up to 18 segments are allowed in each table. In contrast, the E5070A/E5071A allows a limit test table to be defined for each trace and up to 100 segments to be defined per table.

Among the items read from the test results, the 8753ES supports a pass/fail for each channel, segment, and point, plus maximum/minimum values for each segment. In contrast, the E5070A/E5071A supports only a pass/fail of the active trace on each channel.

Analytical Functions

Although the 8753ES does not support the fixture simulator function, the E5070A/E5071A does. The fixture simulator supported by the E5070A/E5071A include the balanced-unbalanced transformation function for analyzing balanced devices, and the matching circuit function.

Save/Recall

For storing data, the 8753ES is provided with an internal register, internal disk drive (floppy disk), and external disk drive (connected through the GPIB). In contrast, the E5070A/E5071A provides an internal hard disk drive, and an internal disk drive (floppy disk). While the 8753ES can save or recall the device setup, screen color settings, and test sequences, the E5070A/E5071A is able to save or recall the instrument setup, segment sweep table, and limit line table as well as VBA projects. The 8753ES saves display data in JPEG format while the E5070A/E5071A supports the Windows® Bitmap (BMP) and Portable Network Graphics (PNG) format.

Test Sequence Program

Although the 8753ES supports the test sequence program, the E5070A/E5071A provides an environment for developing VBA programs for automatic measurement.

Outputting to a Printer/Plotter

The 8753ES enables you to establish the print area covering an entire sheet or just a 1/4 sheet, and to define traces, the reference line, and colors of warning messages. In contrast, the E5070A/E5071A supports only full-sheet output, and an on/off setting for highlighting the entire screen in connection with color setup.

The 8753ES supports parallel ports, serial ports, and GPIB as printer ports, although the E5070A/E5071A supports only parallel- and USB-connected printers.

Replacing the 8753ES with the E5070A/E5071A

Important Functional Differences

GPIB Interface

While the 8753ES uses pass control to pass the controller information to an external PC or instrument, the E5070A/E5071A does not support this function.

LAN Interface

Although the 8753ES does not support a LAN interface, support for LANs is standard on the E5070A/E5071A. The LAN interface automatically changes between 10BaseT and 100BaseTX, supporting both TCP/IP and telnet as well.

Other Functions

The 8753ES is provided with Take4 mode, mixer measurement function, and harmonics measurement function (Option 002), but the E5070A/E5071A is not provided with these functions.

Comparing Functions

Table F-5 Functions of the 8753ES vs. the E5070A/E5071A

Function		8753ES	E5070A/E5071A	
Measurement	Reset	Can be executed by using the front panel and the GPIB command.	Can be executed by using the front panel, the GPIB command, and telnet.	
	Channel	Number of channels	4 channels	9 channels
		Coupling between channels	Channels 3 and 4 are auxiliary channels for channels 1 and 2 and subject to the same sweep conditions, etc. applicable to channels 1 and 2. Couple/Uncouple between channels 1 and 2 can be set up.	Channels are independent of each other.
	Trace	A trace for each channel	Each channel can accommodate up to nine traces.	
	Measurement parameter	S-parameters, A, B, R, A/R, B/R, A/B, and analog bus	S-parameters	
	S-parameter conversion	Impedance (reflection and transmission), admittance (reflection and transmission), and I/S	←	
	Display format(Data format)	log magnitude, linear magnitude, phase, group delay, Smith chart, polar format, SWR, real, imaginary	log magnitude, linear magnitude, phase, expanded phase, positive phase, group delay, Smith chart, polar format, SWR, real, imaginari	
	Test port output	Number of ports	2 ports	2 ports (Opts. 213/214) 3 ports (Opts. 313/314) 4 ports (Opts. 413/414)
		Frequency	30 kHz to 3 GHz (Std.) 30 kHz to 6 GHz (Opt. 006)	300 kHz to 3 GHz (E5070A) 300 kHz to 8.5 GHz (E5071A)
		Power level	-85 to +10 dBm (Std.) -85 to +8 dBm (Opts. 014/075)	-15 to 0 dBm (Opts. 213, 313, 413) -50 to 0 dBm (Opts. 214, 314, 414)
		Characteristic Impedance	50 Ω(Std.) 75 Ω(Opt. 075)	50 Ω
		Coupled/Uncoupled power levels	You can define Couple/Uncouple between channels and between ports.	Traces are coupled on the same channel, not between channels.
		Power slope function	Available	Not available
		Turning the output On/Off	Allowed	Not allowed
		Power range	Items to be set up	Per port and per channel
	Automatic setting		On/Off setting capability	Manual setting
	Setting range		Range setting with 10 dBm resolution is definable from between -15 and +10 dBm down to between -85 and -60 dBm.	Range setting with 5 dBm resolution is definable from between -15 and 0 dBm down to between -50 and -35 dBm

F. Replacing the 8753ES
with the E5070A/E5071A

Replacing the 8753ES with the E5070A/E5071A
Comparing Functions

Table F-5 Functions of the 8753ES vs. the E5070A/E5071A

Function		8753ES	E5070A/E5071A	
Measurement (cont'd.)	Sweep conditions	Number of points (except for the list frequency sweep operation)	3, 11, 21, 26, 51, 101, 201, 401, 801, 1601	Arbitrary value from 2 to 1601
		Sweep type	linear sweep, log sweep, list sweep, power sweep, and CW time sweep	linear sweep, log sweep, and segment sweep
	List frequency sweep	Number of list tables	One for channels 1 and 3 and one for channels 2 and 4, two in total	One for each channel (nine in total)
		Number of segments per table	Up to 30	Up to 201
		Creation of a table using GPIB(SCPI) command	Creating a table using more than one command	Creating a table using a single command
		Number of points	1 to 1601 points per segment Up to 1601 points in total	2 to 1601 points per segment Up to 1601 points in total
		Stepped/swept mode	stepped mode and swept mod. Selectable only when list frequency sweep is performed	stepped mode, swept mode, fast stepped mode, and fast swept mode. Selectable also when list frequency sweep is not performed.
		Sweep of designated segments.	Allowed	Not allowed (Always sweeps all segments.)
		Sweep time	Automatic, Manual (definable from the shortest time to 24 hours)	Automatic, Manual (range of definable sweep depends on sweep condition)
	IF bandwidth	10 Hz, 30 Hz, 100 Hz, 300 Hz, 1 KHz, 3 kHz, 3.7 kHz, 6 kHz	10 Hz, 15 Hz, 20 Hz, 30 Hz, 40 Hz, 50 Hz, 70 Hz, 100 Hz, 150 Hz, 200 Hz, 300 Hz, 400 Hz, 500 Hz, 700 Hz, 1 kHz, 1.5 kHz, 2 kHz, 3 kHz, 4 kHz, 5 kHz, 7 kHz, 10 kHz, 15 kHz, 20 kHz, 30 kHz, 40 kHz, 50 kHz, 70 kHz, 100 kHz	
	Averaging	Can be set from 1 to 999.	Can be set from 1 to 999.	
	Smoothing		The smoothing aperture can be set from 0.05% to 20%.	The smoothing aperture can be set from 1% to 25%.
	Electrical delay	Transmission line	Compatible with coaxial cables and waveguides	Compatible with coaxial cables only
		Value	Any value from 0 to 10 seconds	Any value from -10 to +10 seconds
	Phase offset		Any value from -360° to +360°.	Any value from -360° to 360°.
Setting sweep conditions for Couple/Uncouple		Channels 1 and 3 and channels 2 and 4 are always coupled. Channels 1 and 2 can be set either at Couple or Uncouple.	Traces in the same channel are coupled; traces in different channels are not coupled.	
Trigger mode		Continuous, single, hold, specified number of sweeps	Continuous, single, hold	

Table F-5 Functions of the 8753ES vs. the E5070A/E5071A

Function		8753ES	E5070A/E5071A	
Measurement (cont'd.)	Trigger source	Internal, external (per sweep, per point), manual (per point)	Internal, external (per sweep), bus, manual (per sweep)	
	External trigger line	Can be set to High or Low	Low	
Display	Memory trace	Number	One per channel	
		Data math	Data / Memory Data – Memory	
		Display	Data trace only Memory trace only Simultaneous display of memory traces and data traces Data math only	
	Frequency display	On/Off setting is definable for all channels.	On/off setting is definable channel by channel.	
	Graph layout	Up to four graphs can be displayed.	Windows are assigned to each channel; up to nine windows can be displayed. Up to nine graphs can be displayed in each window.	
	Math between data traces	The results for channel 1/channel 2 can be displayed on the trace for channel 2.	Not available	
	Scale	Autoscale	Available	←
		Reference line	Both value and position can be specified.	←
		Scales per division	Definable	←
		Number of divisions	Fixed at 10	Can be set in increments of 2 from 4 to 30.
	Turning the softkey area On/Off	Available	←	
	List display	Available	Not available	
	List display of Instrument State	Available	Not available	
	Color settings	Available	←	
	Screen brightness setting	Available	Not available	
Turning the LCD On/Off	Available	←		
Turning the update On/Off	Always updates.	Available		

F. Replacing the 8753ES
with the E5070A/E5071A

Replacing the 8753ES with the E5070A/E5071A
Comparing Functions

Table F-5 Functions of the 8753ES vs. the E5070A/E5071A

Function		8753ES	E5070A/E5071A	
Calibration	Calibration kit	Available calibration kits: 7 mm: 85031B 3.5 mm: 85033C/D/E N type (50 Ω): 85032B/E/F N type (75 Ω): 85036B/E 2.4 mm: 85056A/D TRL 3.5 mm: 85052C User defined calibration kit	3.5 mm:85033D/E, 85052D N type (50 Ω): 85032B/F Up to six user defined calibration kits can be registered.	
	Calibration type	Not more than two ports	Response calibration Response and isolation calibration Enhanced response calibration S11 1-port calibration S22 1-port calibration Full 2-port calibration TRL*/LRM* Calibration Receiver calibration Power meter calibration	Response calibration (OPEN,SHORT, THRU) Full 1-port calibration Full 2-port calibration TRL*/LRM* Calibration (VBA) The response calibration includes isolation measurement as an option.
		Not less than three ports	Not available	Full 3-port calibration (Opts. 313, 314, 413, and 414 only) Full 4-port calibration(Opts. 413 and 414 only)
	Omission of the isolation measurement		Possible (Can be omitted by designating it using the softkeys on the front panel or sending a GPIB command from the front panel)	Possible (Isolation measurement is performed as an option accompanying a response calibration and 2-, 3-, and 4-port calibration.)
	Velocity factor		Definable	←
	Characteristic impedance of the measurement system		Definable	Definable with fixture simulator
	Port extensionr		Definable for ports 1 and 2 and inputs A and B	Definable for each port per channel
	Adapter removal		Available	Not available
	Selection between chop sweep and alternate sweep		Can be changed over.	Chop sweep for traces in a channel and alternate sweep between channels
	Error correction		On/Off setting is definable.	←
Interpolating the calibration coefficient		On/Off setting is definable.	Always On.	

Table F-5 Functions of the 8753ES vs. the E5070A/E5071A

Function		8753ES	E5070A/E5071A	
Calibration (cont'd.)	Defining the calibration kit	Calibration class	S11A (OPEN) S11B (SHORT) S11C (LOAD) S22A (OPEN) S22B (SHORT) S22C (LOAD) Forward Transmission Forward Match Reverse Transmission Reverse Match Response Response & Isolation TRL Thru TRL Reflect TRL Line/Match	OPEN SHORT LOAD THRU (OPEN, SHORT, and LOAD are set for each port; THRU is set between ports)
		Class indication label	Editable	Not editable
		Number of standards that can be registered in calibration classes	Up to seven types	One type
		Type of standard	OPEN, SHORT, LOAD, and THRU Arbitrary Impedance	OPENOPEN, SHORT, LOAD, and THRU Arbitrary Impedance, None
		Standard parameters	Common to standards	Offset delay Offset loss Offset characteristic impedance Frequency range Offset type (coaxial, waveguide)
	Unique to OPEN		C0, C1, C2, C3	←
	Unique to SHORT		Not available	L0, L1, L2, L3
	Unique to LOAD		Type of standard (fixed, sliding, offset)	Not available (the type of standard is treated as fixed load.)
	Unique to THRU		Not available	←
	Arbitrary Impedance		Type of standard (fixed, sliding) Arbitrary Impedance	Arbitrary Impedance
	Standard label		Editable	←
	ECal	Type of calibration	Enhanced response calibration S11 1-port calibration S22 1-port calibration Full 2-port calibration	Response (thru) calibration Full 1-port calibration Full 2-port calibration Full 3-port calibration (Opts. 313/314/413/414) Full 4-port calibration (Opts. 413/414)
		Omission of isolation	Allowed	←
		Manual THRU measurement	Allowed	Not allowed
		Reading the frequency array	Allowed	Not allowed
Reading the module information		Allowed	Not allowed	

F. Replacing the 8753ES with the E5070A/E5071A

Replacing the 8753ES with the E5070A/E5071A
Comparing Functions

Table F-5 Functions of the 8753ES vs. the E5070A/E5071A

Function		8753ES	E5070A/E5071A
Reading/Writing data	Transfer format	Intra-device binary IEEE 32-bit floating point IEEE 64-bit floating point ASCII PC-DOS 32-bit floating point	IEEE 64-bit floating point ASCII
	Object to be read/written	Raw data array Calibration coefficient array (before interpolating) Corrected data array Formatted memory array Memory trace Calibration kit array data Power meter calibration coefficient array (before interpolating)	Formatted data array Formatted memory array
	Object to be read only	Pre-raw data (in Take4 mode) Calibration coefficient array (after interpolating) Power meter calibration coefficient array (after interpolating)	Corrected data array Corrected memory array
	Reading data for a designated point or scope	Allowed only for data traces	Not allowed
Marker	Number of markers	Up to five markers per channel	Nine markers per tracer (exclude reference marker)
	Active marker	One marker per channel	One marker per trace
	Delta marker(Reference marker)	Designates the marker displayed as the reference marker.	You can designate the reference marker independently from the markers displayed.
	Marker coupling	Setting of Couple/Uncouple definable	Setting of Couple/Uncouple definable (coupling available only between markers on the same channel)
	Marker move mode	Continuous/discrete (definable channel by channel)	Continuous/discrete (definable trace by trace)
	Fixed marker	One marker definable per channel	Not available
	Marker value display	On/Off setting for the marker value display definable per channel	All marker values for active traces are displayed on each channel. Display/No Display setting for the marker table displaying all marker values definable

Table F-5 Functions of the 8753ES vs. the E5070A/E5071A

Function			8753ES	E5070A/E5071A
Markers (cont'd.)	Marker search	Search function	Maximum, minimum, target value, bandwidth	Maximum, minimum, target value, peak
		Object of search	Active marker	Arbitrary marker (during remote control) Active marker (when manipulating the front panel)
		Parameters for bandwidth search	Bandwidth, bandwidth center frequency Q factor, loss	Bandwidth, bandwidth center frequency Upper and lower frequency of the bandwidth Q factor, loss
		Target value	Definable for an active marker	Definable for each marker
		Target transition type	Not definable	Setting of Positive/Negative transition definable (per marker)
		Search tracking	On/Off setting definable for the active marker (Markers other than the active marker are always turned off.)	On/Off setting definable for each marker
		Marker reading set at a parameter	Values of the start, stop, center, span, CW frequency, and reference line in the sweep range	Values of the start, stop, center, span, and reference line in the sweep range
	Reading the marker value (for remote control)		Possible for the active marker	Possible for any marker
Device test	Limit test	Limit test table	One per channel Number of segments: Up to 18 per table	One per trace Number of segments: Up to 100 per table
		Offset	Definable	Not definable
		Creating a table by using the GPIB command	Create a table by using two or more commands	Create a table by using one command
		Reading the results	Per channel, Per segment Pass/fail at each point, Number of points per segment that failed the maximum/minimum, Stimulus value at a failed point	Pass/Fail of the active trace on each channel Number of failed points Stimulus value at a failed point
	Ripple test		Available	Not available
	Bandwidth test		Available	Not available (Marker search function can be used for the bandwidth search.)
Analysis	Fixture simulator		Not available	Available

F: Replacing the 8753ES
with the E5070A/E5071A

Replacing the 8753ES with the E5070A/E5071A
Comparing Functions

Table F-5 Functions of the 8753ES vs. the E5070A/E5071A

Function		8753ES	E5070A/E5071A
Status report	Register types	Status byte register Service request enable register Standard event status register Standard event status register B and enable register	Status byte register Service request validation register Standard event status register Operation status register and validation register Questionable status register and validation register
	For limit test	Included in the standard event status register B and validation register	Questionable limit status register Questionable limit status channel register
Save/Recall	Storage	Internal registers Internal disk (floppy disk) External disk (connected through GPIB)	Internal hard disk Floppy disk
	Storage initialization	Possible	Available with mouse
	Save only	LCD screen image	Formatted data array LCD screen image
	Object to be saved/recalled	Instrument State (You can simultaneously save formatted data array for the active trace, raw data array, corrected data array, and LCD images.) Color settings Test sequence	Instrument State (You can simultaneously save formatted data array for the active trace and calibration data.) Segment sweep table Limit line table VBA project
	File formats	Binary form, ASCII form	Binary form
	Format for saving the screen display	JPEG format	Windows® Bitmap format, PNG format
	File manipulation	Reading file information Deleting a file	Reading file information Deleting a file or folder Creating a folder Copying a file
Macros	Creating macros	Uses a test sequence.	Uses VBA.
	Automatic execution	Will execute if "AUTO" is given as the name of the sequence 6.	Only auto loading is possible.
System	Self-test	Can be executed by using the front panel and SCPI commands.	Can be executed by using the front panel.
	Internal clock	Available	Available
	Beep sound	On/Off setting definable for completion of actions, warnings, and limit test failures	On/Off setting definable for completion of actions and warnings
	Measuring instrument mode	Can be selected from a standard network analyzer, external signal source (automatic), external signal source (manual), and tuned receiver.	Always a network analyzer

Table F-5 Functions of the 8753ES vs. the E5070A/E5071A

Function		8753ES	E5070A/E5071A	
Printer / Plotter output	Print range	Entire sheet, 1/4 of a sheet	Entire sheet	
	Color settings	Settings definable for the colors of a trace, reference line, text, and warning messages	Highlighting/No highlighting of all elements	
	Line settings	Possible	Always a solid line.	
	Printer port	Parallel port Serial port GPIB	Parallel port USB(Setting up must be executed on Windows)	
Others	Time domain transformation		Available	Not available
	Take4 mode		Available	Not available
	Mixer measurement function		Available	Not available
	Harmonics measurement		Available (Opt. 002)	Not available
	Key manipulation-related GPIB command		GPIB commands that perform the same processing as do the front panel key and softkey manipulation.	Not available
	LAN	interface	Not available	10 Base-T and 100 Base-TX
		protocol	Not available	TCP/IP
		function	Not available	Telnet
	GPIB	Debug mode	Can be turned On/Off	Not available
		pass control	Available	Not available
		GPIB address setup	The addresses of the main body, controller, external disk, LO control, power meter, printer, and plotter can be specified by using the GPIB command and from the front panel.	The address of the controller can be specified from the front panel.
Parallel port		Can be used as a printer or GPIO connector.	For printer use	

F. Replacing the 8753ES
with the E5070A/E5071A

Replacing the 8753ES with the E5070A/E5071A
Comparing Functions

Symbols

- .bmp
 - Saving the screen image, 202
- .csv
 - Saving/Recalling files, 196
- CSV file
 - Saving trace data, 201
- .sta
 - Saving/Recalling files, 196

Numerics

- 1-Port Calibration, 91
 - procedure, 91
 - Using a 2-Port ECal Module, 102
- 4-port ECal, 108

A

- absolute value measurement, 460
- Accessories, 355
- ACTIVE CH/TRACE Block
 - names and functions of parts, 26
- Active Channel
 - selecting, 57
- active marker
 - marker reading set at a parameter, 475
 - number, 474
 - reading marker value, 475
- Active Trace
 - selecting, 58
- Adaptors
 - Accessories, 362
- ADC
 - Data Processing, 456
- Admittance, 147
- analysis, 475
- Analysis Menu
 - Softkey Functions, 405
- Analyzer Environment
 - specification, 344
- assistance, 6
- Auto Recall function
 - Settings, 197
- Auto Scale
 - settings, 70
- Automatic Sweep Time Mode
 - switching, 64
- autoscale, 471
- Available printers, 205
- Average Menu
 - Softkey Functions, 413
- Averaging
 - Sweep-to-sweep
 - Equation, 229
- averaging, 470

B

- balanced port
 - function, 152
- Balance-Unbalance Conversion
 - setting, 163
- Balance-unbalance conversion function, 158
- Bandwidth Search, 143
- bandwidth search
 - bandwidth, 475
 - bandwidth center frequency, 475
 - loss, 475
 - Q factor, 475
- bandwidth test, 467, 475
- beep sound, 476
- Beep(n)
 - Failed the limit test, 224
- Beeper
 - setting, 262
- Bitmap file
 - Screen image, 202

C

- Calibration
 - Types and Characteristics, 83
 - Using the 4-port ECal module, 108
- calibration, 462, 472
- calibration class
 - number of calibration classes, 462
- calibration coefficient array
 - interpolation, 472
 - reading/writing, 466, 474
- calibration kit
 - definition, 473
 - supported calibration kit, 462, 472
- calibration kit array data
 - reading/writing, 466, 474
- Calibration Kit Definition
 - Changing, 110
- Calibration Kits
 - Accessories, 357
- Calibration Menu
 - Softkey Functions, 414
- calibration type, 462, 472
- certification, 4
- channel
 - auxiliary channel, 460
 - couple, 469
 - number of channels, 469
- Channel Window
 - arrangement, 56
 - names and functions, 40
- Channel Window Arrangement
 - selecting, 56
- Channels
 - setting up, 53
- characteristic impedance
 - measurement system, 472

- chop/alternate, 472
 - Cleaning, 367
 - Color, 75
 - color setting, 471
 - Connector Repeatability Errors, 78
 - Connectors
 - Maintenance, 367
 - continuous sweep, 470
 - Conversion, 147
 - Corrected Data Array
 - Data Processing, 457
 - corrected data array
 - reading/writing, 466, 474
 - save/recall, 476
 - Corrected Memory Array
 - Data Processing, 458
 - corrected memory array
 - reading/writing, 466, 474
 - Corrected System Performance
 - specification, 329
 - couple/uncouple of sweep condition, 469, 470
 - CSV file
 - Limit table, 223

 - D**
 - Data Entry Bar
 - names and functions, 34
 - data flow, 464
 - Data Format
 - Data Processing, 458
 - selecting, 69
 - data format, 469
 - Data Math
 - Data Processing, 458
 - Performing, 145
 - data math, 466, 471
 - Data Transfer Time
 - specification, 348
 - Date and Time
 - Display ON/OFF, 250
 - setting, 249
 - Default Values, 391
 - Deviation from a Linear Phase
 - Measureing Examples, 302
 - Differential matching circuit embedding, 152
 - Differential Port
 - Determining the Characteristics that Result from Adding a Matching Circuit, 167
 - Reference Impedance Conversion, 165
 - Differential port impedance conversion, 152
 - Digital Filter
 - Data Processing, 456
 - Dimensions
 - specification, 344
 - Directivity Errors, 80
 - Display
 - Data Processing, 458
 - display
 - update, 471
 - display format, 469
 - Display Menu
 - Softkey Functions, 424
 - Display mode, 75
 - documentation map, 7
 - Drift Errors, 78
 - Duplexer
 - Measureing Examples, 287
 - Dynamic Range
 - Expanding, 228

 - E**
 - E5091A
 - assigning test port, 273
 - connection, 270
 - control line, 274
 - displaying property, 273
 - selecting ID, 272
 - ECal, 102, 462, 473
 - ECal4-port, 108
 - Electrical Delay
 - Data Processing, 458
 - electrical delay, 470
 - Electronic Calibration, 102
 - EMC
 - specification, 342
 - enhanced response calibration, 472
 - ENTRY Block
 - names and functions of parts, 30
 - Error Correction
 - Data Processing, 457
 - Error Correction Coefficient Array
 - Data Processing, 457
 - Error Messages, 380
 - Ethernet Port
 - names and functions, 48
 - exclusive remedies, 5
 - expanded phase format, 469
 - Ext Trig
 - names and functions, 47
 - External Monitor Output Terminal
 - names and functions, 47
 - External PC
 - Connecting via LAN, 258
 - External Reference Signal Input Connector
 - names and functions, 48
 - external trigger, 471
 - External Trigger Input Connector
 - names and functions, 47
 - external trigger line, 471
-
- F**
- Fail
 - Limit test result, 219
- Fan

- names and functions, 49
 - File
 - Copy, 198
 - Delete, 198
 - Rename a file, 198
 - Firmware Revision
 - Checking, 264
 - Manual Changes, 372
 - fixed marker
 - number, 474
 - Fixture Simulator
 - Data Processing, 457
 - Example, 169
 - overview, 150
 - Fixture simulator, 149
 - Floppy Disk Drive
 - names and functions of parts, 28
 - Format Menu
 - Softkey Functions, 428
 - Formatted Data Array
 - Data Processing, 458
 - formatted data array
 - reading/writing, 466, 474
 - Formatted Memory Array
 - Data Processing, 458
 - formatted memory array
 - reading/writing, 466, 474
 - Frequency Base Display, 239
 - frequency display, 471
 - Frequency Labels
 - erasing, 74
 - frequency offset sweep, 461
 - Frequency Range
 - settings, 59
 - Front Keys
 - Locking, 261
 - front panel
 - names and functions of parts, 24
 - Front Panel Information
 - specification, 342
 - full 1-port calibration, 472
 - Full 2-Port Calibration, 93
 - procedure, 94
 - Using the 2-Port ECal Module, 103
 - full 2-port calibration, 472
 - Full 3-Port Calibration, 96
 - procedure, 97
 - Using the 2-Port ECal Module, 105
 - full 3-port calibration, 462, 472
 - Full 4-Port Calibration, 99
 - procedure, 100
 - Using the 2-Port ECal Module, 105
 - full 4-port calibration, 462, 472
- G**
- Gating, 188
 - General Information
 - specification, 341
 - GPIB, 468
 - setting, 248
 - GP-IB Cables
 - Accessories, 363
 - GPIB Connector
 - names and functions, 47
 - graph layout, 471
 - Graticule Labels
 - turning off the display, 73
 - Group Delay
 - Data Processing, 458
 - group delay
 - data format, 469
- H**
- Handler I/O Port
 - names and functions, 49
 - harmonics measurement, 468, 477
 - High Stability Frequency Reference Output Connector
 - names and functions, 48
 - High Temperature Environments
 - Reduce Measurement Error, 234
 - history,
 - manual printing, 2
 - HP DeskJet 930C Series, 205
 - HP DeskJet 940C Series, 205
 - HP DeskJet 948C Series, 205
- I**
- IF bandwidth, 461, 470
 - IF Range Correction
 - Data Processing, 457
 - imaginary format, 469
 - Impedance, 147
 - Initializing, 52
 - Installation and Quick Start Guide, 7
 - INSTR STATE Block
 - names and functions of parts, 31
 - Instrument Noise Errors, 78
 - Instrument Status Bar
 - names and functions, 38
 - Internal Clock
 - setting, 249
 - internal clock, 476
 - Internal Data
 - Saving and Recalling, 196
 - Internal Reference Signal Output Connector
 - names and functions, 48
 - internal trigger, 471
 - Invert color, 75
 - Isolation errors, 80
- K**
- Keyboard
 - Locking, 261

Keyboard Port
names and functions, 49

L

LAN, 468, 477
LCD backlight, 471
LCD displaying, 471
LCD Screen
names and functions of parts, 25
LCD Screen Backlight
Turning off, 263
Limit Line
Defining, 220
Limit Test
Concept, 216
Limit test
Evaluation result, 218
Beep(n) used as an indicator, 224
Point that failed the limit test, 224
Status register used as an indicator, 224
Limit line, 216
ON/OFF, 224
Limit table
Adding/Deleting segments, 221
Begin Response, 221
Begin Stimulus, 221
Call, 221
Clear, 221
Creating/Editing, 220
End Response, 221
End Stimulus, 221
Initializing, 224
MAX/MIN/OFF, 221
Save to a file, 221
Type, 221
ON/OFF, 224
When the frequency is set at zero span, 221
When the polar chart is used as the format, 222
When the Smith chart is used as the format, 222
limit test
comparison of function, 467, 475
reading result, 475
setting offset, 475
setting up beep sound, 476
status report, 476
limitation of warranty, 5
Line Switch
names and functions, 47
linear magnitude format, 469
linear sweep, 470
list display, 471
list sweep
number of points, 470
stepped mode, 470
sweep of designated segments, 470
swept mode, 470
Load match errors, 81

log magnitude format, 469
log sweep, 470

M

Macro Setup Menu
Softkey Functions, 429
manual changes, 371
manual printing history, 2
Manual Sweep Time Mode
settings, 64
Marker
Listing All the Marker Values, 133
Reading Only the Actual Measurement Point, 131
Reading the Relative Value, 130
Reading the Value Interpolated Between Measurement Points, 131
Reading Values on the Trace, 128
Search for the maximum, 135
Search for the minimum, 135
Search for the Target Value, 136
Search Tracking, 141
Searching for the Peak, 139
Setting Up Markers for Coupled Operations Between Traces, 131
Setting Up Markers for Each Trace, 131
marker
comparison of functions, 466
couple, 474
discrete marker, 474
reading marker value, 475
Marker Function Menu
Softkey Functions, 432
Marker Menu
Softkey Functions, 430
Marker Response Value
setting up, 134
marker search
bandwidth, 466, 475
maximum search, 466, 475
minimum search, 466, 475
peak search, 466, 475
search tracking, 466, 475
target search, 466, 475
Marker Search Menu
Softkey Functions, 433
Matching Circuit
Determining Characteristics, 155
Matching circuit embedding, 151
Measurement capabilities
specification, 349
Measurement Menu
Softkey Functions, 435
Measurement Menu (Balance Measurement, SE-Bal)
Softkey Functions, 436
Measurement Menu (Balanced Measurement, Bal-Bal)
Softkey Functions, 437
Measurement Menu (Balanced Measurement, SE-SE-Bal)

- Softkey Functions, 439
- measurement parameter, 460, 469
- Measurement Parameters
 - selecting, 65
- Measurement Throughput
 - Improving, 235
- Measurement Throughput Summary
 - specification, 346
- Measurement value
 - Displayed in red, 219
- Menu Bar
 - names and functions, 34
- mixer measurement, 461, 468, 477
- MKR/ANALYSIS Block
 - names and functions of parts, 32
- Mouse
 - Locking, 261
 - Setup Step, 251
- Mouse Port
 - names and functions, 49
- N**
- NAVIGATION Block
 - names and functions of parts, 29
- Network
 - Configuring, 255
- Network Connection Function
 - Enable/Disable, 254
- Network De-embedding
 - setting, 153
- Network de-embedding, 151
- Nominal
 - Definitions, 328
- Number of Channels
 - selecting, 56
- Number of Points
 - settings, 63
- number of points, 470
- number of sweeps, 470
- Number of Traces
 - selecting, 57
- O**
- Offset
 - Data Processing, 458
- Open dialog box, 199
- OPEN/SHORT Response Calibration, 85
 - procedure, 86
- Operational Manual, 7
- Order Base Display, 239
- P**
- Parallel port, 205
- Parameter conversion, 147
- Pass
 - Limit test result, 218
- pass control, 468
- phase format, 469
- Phase Measurements
 - Improving the Accuracy, 232
- Phase Offset
 - Data Processing, 458
- phase offset, 470
- plotter, 467, 477
- Polar Format, 67
 - manual scale adjustment, 72
- polar format
 - data format, 469
- Port Characteristics Correction
 - Data Processing, 457
- Port Extension
 - Data Processing, 457
- port extension, 472
- Port Impedance
 - Converting, 154
- Port reference impedance conversion, 151
- Power Cable Receptacle
 - names and functions, 47
- Power Level
 - settings, 62
- power level
 - couple, 469
 - setting range, 469
- power meter calibration, 462
- power meter calibration coefficient array
 - reading/writing, 466, 474
- power slope, 469
- Pre-raw data
 - reading, 466, 474
- Preset Menu
 - Softkey Functions, 441
- Print
 - Inverting colors, 206
 - Orientation, 208
 - Print dialog box, 208
 - Printer setup, 207
 - Select a printer, 207
 - Start/Stop, 206
- Print Setup dialog box, 207
- Printer
 - Available printers, 205
 - Select, 207
 - Settings, 207
- printer, 467, 477
- Printer driver
 - Installation, 213
- Printer Parallel Port
 - names and functions, 49
- Printer parallel port, 205
- printer port, 467, 477
- Printers Folder dialog box, 209
- Programming Manual, 7

Q

Quick Start Guide, 7

R

Random Errors, 78

Ratio Calculation

 Data Processing, 457

Raw Data Array

 Data Processing, 457

raw data array

 reading/writing, 466, 474

 save/recall, 476

reading/writing data, 466

real format, 469

Rear Panel

 names and functions, 46

Rear Panel Information

 specification, 342

Receiver

 System Description, 455

receiver calibration, 472

Rectangular Display Format

 manual scale adjustment, 70

Rectangular Display Formats, 66

Ref In

 names and functions, 48

Ref Out

 names and functions, 48

Ref Oven

 names and functions, 48

Reference Line

 settings, 72

reference line, 471

reference marker, 466, 474

Reflection Test, 85, 91

 procedure, 86, 91

Reflection tracking errors, 81

Replacement of Parts, 368

Reserved Port

 names and functions, 49

reset, 469

response and isolation calibration, 472

RESPONSE Block

 names and functions of parts, 27

response calibration, 472

ripple test, 475

S

S11 1-port calibration, 472

S22 1-port calibration, 472

Safe mode, 25

Safety

 specification, 342

safety

 symbols, 4

safety summary, 3

Save as dialog box, 198

save/recall

 file format, 476

 object, 476

 storage, 467, 476

Save/Recall Menu

 Softkey Functions, 442

Saving/Recalling files

 All, 196

 File compatibility, 196

 State & Cal, 196

 State & Trace, 196

 State Only, 196

SAW Bandpass Filter

 Measuring Examples, 280

Scale

 Data Processing, 458

scale

 comparison of function, 471

 number of divisions, 471

Scale Menu

 Softkey Functions, 444

Scales

 settings, 70

Screen Area

 names and functions, 34

Screen Image

 output, 205

 printing, 206

 Saving to a File, 202

Search Tracking, 141

section titles, 368, 454

Segment Display

 Setting Up, 244

Segment Sweep

 Concept, 237

 Executing, 244

segment sweep, 470

Segment Table

 Creating, 241

 Saving in CSV Format, 245

self-test, 476

Serial Number

 Checking, 264

 Manual Changes, 372

Serial Number Plate

 names and functions, 49

Serial number plate, 372

Signal Separator

 System Description, 455

single sweep, 470

single-ended port

 function, 151

Smith Chart

 manual scale adjustment, 72

Smith Chart Format, 68

Smith chart format

- data format, 469
 - Smoothing
 - Data Processing, 458
 - smoothing
 - aperture, 470
 - Softkey Menu Bar
 - names and functions, 36
 - Source match errors, 81
 - Source Switcher
 - System Description, 455
 - S-parameter, 460, 469
 - S-parameter conversion, 469
 - S-Parameters
 - settings, 65
 - Specification
 - Definitions, 328
 - Specifications, 327
 - standard
 - label, 473
 - parameter, 473
 - type, 473
 - Standby Switch
 - names and functions of parts, 25
 - status byte, 476
 - status report, 476
 - Stimulus
 - settings, 59
 - STIMULUS Block
 - names and functions of parts, 28
 - Stimulus Menu
 - Softkey Functions, 445
 - Supported printers, 205
 - Sweep Averaging
 - Data Processing, 457
 - Sweep Delay Time
 - Segment Sweep, 239
 - sweep mode, 470
 - Sweep Setup Menu
 - Softkey Functions, 446
 - Sweep Time
 - Segment Sweep, 239
 - settings, 63
 - sweep time, 470
 - sweep type, 470
 - Sweep-to-sweep averaging
 - Equation, 229
 - Swept Sweep Mode, 235
 - Switch Repeatability Errors, 78
 - SWR format, 469
 - Synthesized Source
 - System Description, 454
 - System Accessories, 363
 - System Bandwidths
 - specification, 341
 - System Description, 454
 - System Dynamic Range
 - specification, 329
 - System Error Correction
 - Turning Off, 236
 - System Menu
 - Softkey Functions, 448
 - System Racks and Cases
 - Accessories, 363
 - System Recovery
 - How to Execute, 265
 - Systematic Errors, 79
- T**
- Take4 mode, 468, 474
 - take4 mode, 477
 - Test Port
 - names and functions of parts, 32
 - Test Port Cables
 - Accessories, 356
 - Test Port Input (Dynamic Accuracy)
 - specification, 339
 - Test Port Input (Group Delay)
 - specification, 340
 - Test Port Input (Stability)
 - specification, 339
 - Test Port Input (Trace Noise)
 - specification, 337
 - Test Port Input Levels
 - specification, 337
 - test port output, 460, 469
 - Test Port Output Frequency
 - specification, 335
 - Test Port Output Power
 - specification, 335
 - Test Port Output Signal Purity
 - specification, 335
 - Test Ports
 - Maintenance, 367
 - test sequence, 467
 - THRU Response Calibration, 88
 - procedure, 88
 - Time domain, 175
 - Gating, 188
 - Overview, 176
 - Transform, 178
 - time domain transformation, 477
 - Touch Screen
 - Calibration, 268
 - Trace
 - arrangements, 57
 - Comparing, 145
 - Determining the Bandwidth, 143
 - Determining the Mean, Standard Deviation, and p-p, 142
 - trace, 460, 469
 - Trace arrangements
 - selecting, 57
 - Trace Data
 - Saving, 201
 - Trace Display

- maximizing, 73
 - Trace Noise
 - Reducing, 230
 - Traces
 - setting up, 53
 - transfer format, 466, 474
 - Transform, 178
 - Transmission Test, 88
 - procedure, 88
 - Transmission tracking errors, 82
 - Trigger
 - setting, 122
 - Trigger Menu
 - Softkey Functions, 452
 - Trigger Modes
 - function, 124
 - Trigger Source
 - function, 123
 - trigger source, 471
 - trigger system, 463
 - TRL*/LRM* calibration, 462, 472
 - Troubleshooting
 - during Operation, 376
 - during Startup, 376
 - External Devices, 379
 - typeface conventions, 6
 - Typical
 - Definitions, 328
 - Typical Cycle Time for Measurement Completion
 - specification, 346
- U**
- Unbalanced and Balanced Bandpass Filter
 - Measuring Examples, 307
 - unbalanced port
 - function, 151
 - Uncorrected System Performance
 - specification, 334
 - Update Off, 236
 - USB Port
 - names and functions of parts, 33, 47
 - USB port, 205
 - user defined calibration kit, 472
- V**
- velocity factor, 472
 - Video
 - names and functions, 47
- W**
- Warning Message, 390
 - warranty, 5
 - limitation of, 5
 - Window
 - labeling, 74
 - Window Display
 - maximizing, 73
 - settings, 73

REGIONAL SALES AND SUPPORT OFFICES

For more information about Agilent Technologies test and measurement products, applications, services, and for a current sales office listing, visit our web site: <http://www.agilent.com/find/tmdir>. You can also contact one of the following centers and ask for a test and measurement sales representative. 11/29/99

United States:

Agilent Technologies
Test and Measurement Call Center
P.O.Box 4026
Englewood, CO 80155-4026
(tel) 1 800 452 4844

(fax) (61 3) 9272 0749
(tel) 0 800 738 378 (New Zealand)
(fax) (64 4) 802 6881

Canada:

Agilent Technologies Canada Inc.
5150 Spectrum Way
Mississauga, Ontario
L4W 5G1
(tel) 1 877 894 4414

Asia Pacific:

Agilent Technologies
24/F, Cityplaza One, 1111 King's Road,
Taikoo Shing, Hong Kong
(tel) (852)-3197-7777
(fax) (852)-2506-9284

Europe:

Agilent Technologies
Test & Measurement
European Marketing Organization
P.O.Box 999
1180 AZ Amstelveen
The Netherlands
(tel) (31 20) 547 9999

Japan:

Agilent Technologies Japan Ltd.
Call Center
9-1, Takakura-Cho, Hachioji-Shi,
Tokyo 192-8510, Japan
(tel) (81) 426 56 7832
(fax) (81) 426 56 7840

Latin America:

Agilent Technologies
Latin American Region Headquarters
5200 Blue Lagoon Drive, Suite #950
Miami, Florida 33126
U.S.A.
(tel) (305) 267 4245
(fax) (305) 267 4286

Australia/New Zealand:

Agilent Technologies Australia Pty Ltd
347 Burwood Highway
Forest Hill, Victoria 3131
(tel) 1-800 629 485 (Australia)