

Measurement Guide

Agilent Technologies E7495A/B

Base Station Test Set

For firmware revision A.06.20 and above



Manufacturing Part Number: E7495-90054
Supersedes E7495-90053

Printed in USA

December 2008

© Copyright 2002–2008 Agilent Technologies, Inc.

Notice

The material contained in this document is provided “as is,” and is subject to being changed, without notice, in future editions. Further, to the maximum extent permitted by applicable law, Agilent disclaims all warranties, either express or implied with regard to this manual and any information contained herein, including but not limited to the implied warranties of merchantability and fitness for a particular purpose. Agilent shall not be liable for errors or for incidental or consequential damages in connection with the furnishing, use, or performance of this document or any information contained herein. Should Agilent and the user have a separate written agreement with warranty terms covering the material in this document that conflict with these terms, the warranty terms in the separate agreement will control.”

Technology Licenses

The hardware and/or software described in this document are furnished under a license and may be used or copied only in accordance with the terms of such license.

Restricted Rights Legend

If software is for use in the performance of a U.S. Government prime contract or subcontract, Software is delivered and licensed as “Commercial computer software” as defined in DFAR 252.227-7014 (June 1995), or as a “commercial item” as defined in FAR 2.101(a) or as “Restricted computer software” as defined in FAR 52.227-19 (June 1987) or any equivalent agency regulation or contract clause. Use, duplication or disclosure of Software is subject to Agilent Technologies’ standard commercial license terms, and non-DOD Departments and Agencies of the U.S. Government will receive no greater than Restricted Rights as defined in FAR 52.227-19(c)(1-2) (June 1987). U.S. Government users will receive no greater than Limited Rights as defined in FAR 52.227-14 (June 1987) or DFAR 252.227-7015 (b)(2) (November 1995), as applicable in any technical data.

Where to Find the Latest Information

Documentation is updated periodically. For the latest information about Agilent Technologies E7495 spectrum analyzers, including firmware upgrades and application information, please visit the following URL:

<http://www.agilent.com/find/e7495b>

Microsoft® is a U.S. registered trademark of Microsoft Corporation.

1. Getting Started

Introduction.....	20
Unpacking the E7495A/B Test Set.....	22
E7495A/B Cables, Connectors, and Accessories	24
Test set options	28
Your First 15 Minutes with the E7495A/B.....	33
Get to Know the Layout of the E7495A/B	34
Install a Battery	37
Practice Using the Three-way Power Button	37
Make Your First Measurement (Two Port Insertion Loss)	38
Using the Backpack	41
What Goes Where in the Backpack.....	42
Contacting Agilent Technologies	43
More Information from Agilent	43
E7495A/B Base Station Test Set Product Updates	43

2. One Port Insertion Loss

Measuring One Port Insertion Loss	46
Calibration - Minimizing your Workload	46
Performing (and Calibrating) a Basic One Port Insertion Loss measurement	47
Clearing Calibration	50
Displaying Location Information Using GPS	51
Setting Average, Sweep, and Restart.....	52
Adding a Marker	55
Setting One Port Insertion Loss Interference Rejection	56
Setting the Pass/Fail Limits.....	57

3. 1xEV-DO Analyzer and Over Air Test

Accessing 1xEV-DO Tx and Over Air Test	60
Making 1xEV-DO Tx Measurements	61
Common 1xEVDO Tx Analyzer Measurements	61
Performing a Basic 1xEVDO Transmitter Measurement.....	63
Making 1xEV-DO Over Air Measurements	67
Preparing to Make 1xEV-DO Over Air Measurements	68
Criteria for Making Valid 1xEV-DO Over Air Measurements	69
Performing a Basic 1xEV-DO Over Air Measurement	71

Contents

Displaying Location Information Using GPS	74
Interpreting the Display	75
Optional 1xEV-DO Tx and Over Air Analyzer Measurement Settings	77
Setting the Channel or Frequency Step	77
Setting the PN Offset	79
Setting the PN Increment	79
Setting the Active Channel Threshold Level and Auto Threshold Level	80
Setting the Frequency/Time Reference	81
Setting Units	82
Setting the 1xEV-DO Transmitter Reference Level	82
Setting Measurement Time	83
Setting Measurement Offset	84
Setting the Slot Threshold Level	85
Setting the CDP Type	85
Setting the Pilot Dominance Limit	86
Setting the Multipath Power Limit	87
Setting the PN Scanner Sensitivity	87
Setting Average, Sweep, and Restart	88
Adding a Marker	90
Setting the Pass/Fail Limits	92
Setting Up the Signal Generator	101
Metrics Provided by the 1xEV-DO Tx and Over Air Analyzer Measurement	104
Interpretation of 1xEV-DO Tx and Over Air Analyzer Measurement Results	109
Customizing Your Display	114
Sorting by MAC Index or by Walsh Code	115
Converting Between MAC Index and Walsh Code	116
Colors Used on the MAC Code Domain CDP Display	117
Colors Used on the Pilot Code Domain CDP Display	118
Showing or Hiding the OTA PN Scanner	119
Codogram Display	120
Performing a Codogram Measurement	121
 4. Two Port Insertion Loss	
Measuring Two Port Insertion Loss	124
Normalizing and Performing a Basic Two Port Insertion Loss Measurement	125
Displaying Location Information Using GPS	126

Contents

Setting Average, Sweep, and Restart	127
Adding a Marker	130
Measuring Two Port Insertion Loss for Spectrum Analyzer, Channel Scanner, 1xEV-DO Analyzer, CDMA Analyzer, and Signal Generator (RF In Loss and RF Out Loss)	131
Measuring Insertion Loss for Power Meter (Option 600 - Power Meter Only)	134
Determining The Lowest (Worst) Insertion Loss and Its Frequency	135
Determining the Highest (Best) Insertion Loss and Its Frequency	136
Using the Delta Marker to Measure a Difference in Insertion Loss or Frequency	136
Activating Interference Rejection	136
Clearing Normalization	137
Setting Source Level	137
Optimizing Dynamic Range	139
Setting the Pass/Fail Limits	140
 5. Adjacent Channel Power	
Using the Adjacent Channel Power Measurement	142
Making a Basic Adjacent Channel Power Measurement	143
Adjacent Channel Power Measurements for Korean PCS Band	145
Setting the Adjacent Channel Power Format	145
Setting Average, Sweep, and Restart	150
Displaying Accurate Peak Power (Recommended for Pulsed Signals)	152
Setting the Control Units	152
Setting the Range Control	153
Setting the Analyzer Input Gain	154
Setting Noise Correction	154
Setting the Pass/Fail Limits	155
Setting Up the Signal Generator	157
W-CDMA Adjacent Channel Leakage Power Ratio (ACLR) Measurements	161
 6. Working with Batteries	
Installing Batteries	164
Viewing Battery Status	165
Charging Batteries	168
Reconditioning Batteries	170
Battery Care	173
Battery Specifications	176

Contents

7. CDMA Analyzer

- Using the CDMA Analyzer 182
 - Common CDMA Tx Analyzer Measurements 182
 - Performing a Basic CDMA Transmitter Measurement 183
 - Interpreting the Display 187
 - Codogram Display 187
 - Performing a Codogram Measurement. 188
- Optional CDMA Tx Analyzer Measurement Settings 190
 - Setting the Channel or Frequency Step. 190
 - Setting the PN Offset 191
 - Setting the PN Increment 191
 - Setting the Frequency/Time Reference. 192
 - Setting Units 193
 - Setting the CDMA Transmitter Reference Level 193
 - Setting the Active Channel Threshold Level and Auto Threshold Level. 194
 - Setting Measurement Time. 195
 - Setting Quick Page Channel. 196
 - Setting Average, Sweep, and Restart 197
 - Adding a Marker. 198
 - Setting the Pass/Fail Limits 200
 - Setting Up the Signal Generator. 209
- Metrics Provided by the CDMA Tx Analyzer Measurement. 212
- Interpretation of CDMA Tx Analyzer Measurement Results 214

8. CDMA Over Air

- Using the CDMA Over Air Tool 220
 - Preparing to Make CDMA Over Air Measurements 220
 - Criteria for Making Valid CDMA Over Air Measurements 221
 - Performing a Basic CDMA Over Air Measurement 222
 - Displaying Location Information Using GPS. 224
 - Codogram Display 226
 - Performing a Codogram Measurement. 226
 - Setting Amplifier Capacity Metrics 227
 - Interpreting the Display 229
- Optional CDMA Over Air Measurement Settings 231
 - Setting the Channel or Frequency Step. 231

Contents

Setting the PN Increment	232
Setting the Transmitter Reference Level	232
Setting the Active Channel Threshold Level and Auto Threshold Level	234
Resetting Amplifier Capacity and Traffic Metrics	235
Setting Measurement Time	235
Setting Quick Page Channel	236
Setting Average, Sweep, and Restart.	237
Adding a Marker	238
Setting the Pass/Fail Limits.	240
Setting Up the Signal Generator	249
Metrics Provided by CDMA Over Air Measurements	252
Interpretation of CDMA Over Air Measurement Results	256
 9. Channel Scanner	
Using the Channel Scanner.	262
Performing a Basic Channel Scanner Measurement)	263
Displaying Accurate Peak Power (Recommended for Pulsed Signals)	266
Setting the Analyzer Input Gain	267
Setting Noise Correction.	267
Entering the Channels with a List Instead of a Range	268
Entering the Channel Power Measurement Bandwidth and Time	269
Setting Average, Sweep, and Restart.	272
Displaying Frequency or Power	274
Setting the Pass/Fail Limits.	274
 10. Distance to Fault	
Measuring Distance to Fault.	278
Measured Distance - the Effects of Frequency and Points	278
Resolution - the Effects of Frequency and Points	279
Automatic and Manual Distance to Fault Measurements	279
Calibration - Minimizing your Workload	281
Performing a Basic Distance to Fault Measurement (Manual Frequency Range).	283
Performing a Basic Distance to Fault Measurement (Automatic Frequency Range)	286
Clearing Calibration	290

Contents

Displaying Location Information Using GPS	291
Viewing a Single Distance to Fault Sweep	292
Displaying the Top Four Faults	292
Setting Interference Rejection for a Distance to Fault Measurement	293
Setting Average, Sweep, and Restart	294
Adding a Marker	296
Setting the Pass/Fail Limits	297
 11. E1 Analyzer	
Making E1 Measurements	300
Steps for Performing a Basic E1 Analyzer Measurement	300
Setup Button Selections	300
Display/Sound Button Selections	303
Control Button Selections	303
Sample Hard Loop/End-End Full E1 BERT Test	305
Sample Monitor Full E1 Test	308
Setting Up Delay Test Mode	312
Turning On Sound	314
Setting Up E1 Diagnostics	315
Patterns	316
Measurement Results	318
Alarm Indicators	318
Results Indicators	318
Status Indicators	320
Testing and Fault Mitigation	321
More Information About E1 Testing	323
Auto Configuration Flow Diagram	323
Terminology	325
 12. GSM and EDGE Analyzer	
Using the GSM Analyzer and the EDGE Analyzer	329
Performing a Basic GSM or EDGE Transmitter Measurement	330
Interpreting the Display	335
Optional GSM and EDGE Tx Analyzer Measurement Settings	339
Setting your Scan Mode	340
Adding or Deleting a List Item	342

Setting the Start Frequency/Channel.	343
Setting the Frequency or Channel Step Size.	344
Setting the Stop Frequency/Channel.	345
Setting the Channel Standard	346
Setting the Units of Measure for the Graphical Display	346
Setting Autoscale.	347
Setting the Reference Level	348
Setting Scale/Division.	348
Using GPS for Frequency Reference and Location Information	348
Setting the Display Position	349
Setting Auto Order	350
Setting Bar Top and Units	350
Setting Mid-Bar.	351
Setting Zoom.	351
Setting Zoom Offset	352
Setting Zoom Interval	353
Setting PvT Mask	354
Setting Auto Mode Bar Count.	354
Setting Slot Synchronization.	355
Setting TS# (w/ BCCH)	356
Setting the Pass/Fail Limits.	357
Adding a Marker	365
Compensating for the Loss of an External Cable and Attenuator.	367
Setting Average, Sweep, and Restart.	368
GSM and EDGE Modulation and Band Information	371
Metrics Provided by the GSM and EDGE Analyzer Measurement	373
Interpretation of GSM and EDGE Analyzer Measurement Results	376
 13. Power Meter	
Making an Average Power Measurement.	380
Making a Basic Average Power Measurement	381
Setting Power Meter Resolution	384
Setting the Power Meter's High and Low End-Points	385
Setting the Power Meter's Upper and Lower Limits	386
 14. Return Loss	

Contents

Measuring Return Loss.	390
Calibration - Minimizing your Workload	390
Performing (and Calibrating) a Basic Return Loss Measurement	391
Clearing Calibration	394
Isolating a Return Loss Signal Using a Single Sweep	395
Setting Return Loss Interference Rejection	395
Setting Average, Sweep, and Restart	396
Adding a Marker.	398
Displaying Location Information Using GPS	399
Setting the Pass/Fail Limits	400
 15. Signal Generator	
Using the Signal Generator	402
Minimum and Maximum Power levels for Generated Signals.	403
Performing a Basic Signal Generator Measurement.	404
Using the RF OUT Loss field	410
Persistent Signal Generator	411
 16. Spectrum Analyzer	
Using the Spectrum Analyzer.	414
Performing a Basic Spectrum Analyzer Measurement.	415
Setting the Range Control.	418
Setting the Analyzer Input Gain	419
Setting the Analyzer Detector.	420
Setting Up the Signal Generator	421
Setting Average, Sweep, and Restart	423
Changing the Resolution Bandwidth	425
Adding or Removing a Marker.	426
Setting the Pass/Fail Limits	428
Spectrogram Display	435
Performing a Spectrogram Measurement	436
Using the Interference ID Measurement	439
Performing a Basic Interference ID Measurement.	439
Using the Occupied BW Measurement	444
Performing a Basic Occupied BW Measurement.	445
Using the Spectrum Emission Mask Measurement	450

CDMA and 1xEV-DO Channel Standards and Emission Limits	452
W-CDMA UTRA Channel Frequencies and Emission Limits	453
Performing a Basic Spectrum Emissions Mask Measurement	454
17. Basic System Operations	461
System Reference Introduction	461
Setting System References	462
Displaying GPS Location Data	462
Selecting a Frequency/Timing Reference	462
Setting up the DC Bias Option	463
Printing a Screen to a File	465
Printing Screens	465
Selecting Output Media—PCMCIA Card or Compact Flash Card	465
File Naming Options	466
Saving Data	469
Saving data	469
Selecting Output Media—PCMCIA Card or Compact Flash Card	469
File Naming Options	470
Managing Media Types	473
Configuring for Network Connectivity	475
Saving, Recalling, and Deleting Instrument States	478
Saving the State	478
Saving the Power-Up State	478
Recalling the State	479
Returning the Power-Up State to Factory default	479
Deleting States	480
Viewing System Statistics	481
Viewing System Release Versions	481
Viewing System Memory	481
Viewing Battery Statistics	482
Using the Option Manager	483
Viewing Installed Options	483
Viewing Installable Options	483
Installing an Option	484
Viewing Installation Information	484
Testing System Functions	485

Contents

18. T1 Analyzer

Making T1 Measurements	488
Performing a Basic T1 Analyzer Measurement	488
Setup Button Selections	488
Display/Sound Button Selections	491
Control Button Selections	491
Sample Hard Loop/End-End Full T1 BERT Test	493
Sample Loopback CSU Full T1 BERT Test	498
Sample Monitor Full T1 Test	503
Sample Emulate CSU/NIU Test	507
Sample Delay Test	512
Turning on sound	514
Setting up T1 diagnostics	515
Patterns	517
Measurement Results	518
Alarm indicators	518
Results indicators	518
Status indicators	519
Measurement results fields	519
Testing and Fault Mitigation	522
More Information About T1 Testing	527
Detailed Loop Mode and Auto Configuration Descriptions	527
Terminology	533

19. W-CDMA or W-CDMA (with HSDPA) Analyzer

Using the W-CDMA or W-CDMA (with HSDPA) Analyzer	536
Selecting a Reference	537
RF Connections	538
Preparing to Make W-CDMA or W-CDMA (with HSDPA) Tx Analyzer Measurements	539
Performing a Basic W-CDMA or W-CDMA (with HSDPA) Transmitter Measurement	540
Multiple-View Display	542
Setting the Display Options	548
Codogram Display	549
Performing a Codogram Measurement	552
Displaying the Active Code Channel Table	553
W-CDMA or W-CDMA (with HSDPA) Analyzer Measurement Settings	556

Setting the Channel or Frequency Step	556
Setting the Scrambling Codes	556
Setting the Display Reference Level	557
Compensating for the Loss or Gain of External Cables, Attenuators, and Preamps.	558
Setting Average, Sweep, and Restart.	560
Setting the Active Channel Threshold Level and Auto Threshold Level	562
Setting Measurement Time	563
Enabling PICH and S-CCPCH	564
Setting the EVM Mode	565
Setting the IF Equalizer.	565
Adding a Marker	566
Metrics Provided by the W-CDMA or W-CDMA (with HSDPA) Analyzer	568
Interpretation of Measurement Results.	571
 20. W-CDMA or W-CDMA (with HSDPA) Over Air	
Using the W-CDMA or W-CDMA (with HSDPA) Over the Air Tool.	576
Preparing to Make W-CDMA or W-CDMA (with HSDPA) Over the Air Measurements.	577
Criteria for Making Valid Over the Air Measurements	577
Performing a Basic Over the Air Measurement	579
Displaying Location Information Using GPS	581
Setting Amplifier Capacity Metrics	582
Multiple-View Display	583
Setting the Display Options.	587
Codogram Display	588
Performing a Codogram Measurement	591
Optional W-CDMA or W-CDMA (with HSDPA) Over the Air Measurement Settings	593
Displaying the Active Code Channel Table	593
Setting the Channel or Frequency Step	595
Setting the Scrambling Codes	596
Setting the Transmitter Reference.	596
Setting Average, Sweep, and Restart.	598
Setting the Active Channel Threshold Level and Auto Threshold Level	600
Setting Measurement Time	601
Resetting Amplifier Capacity and Traffic Metrics	602
Setting Valid Measurement Limits	603
Setting the S-CCPCH Parameters	603

Contents

Setting the PICH Parameters	604
Setting the EVM Mode	605
Setting the IF Equalizer	605
Adding a Marker	606
Metrics Provided by the W-CDMA or W-CDMA (with HSDPA) Over Air Measurement.	608
Interpretation of Over the Air Measurement Results	612

21. Safety and Regulatory Information and Specifications

Safety considerations	618
Safety Symbols	618
Safety Considerations For This Test Set	619
Lifting and Handling	620
Electrostatic Discharge (ESD) Precautions	621
Product Markings	622
Batteries: Safe Handling and Disposal	623
Certification and Compliance Statements	629
Certification	629
Manufacturer's Declaration	629
Declaration of Conformity for Agilent E7495A	630
Declaration of Conformity for Agilent E7495B	631
Compliance with German Noise Requirements	632
Compliance with Canadian EMC Requirements	632
Disposal of Batteries	632
E7495A/B Base Station Test Set Specifications	633
Battery Pack Specifications	646

22. Connector Care

Using, Inspecting, and Cleaning RF Connectors	648
Repeatability	648
RF Cable and Connector Care	648
Proper Connector Torque	649
Connector Wear and Damage	650
Cleaning Procedure	650

23. Returning the Test Set for Service

Adjustment, Maintenance, or Repair of the Base Station Test Set	652

Contents

Returning your Base Station Test Set for Service. 653

 Warranty 653

 Preparing the Agilent E7495A/B for Shipping 654

24. Glossary

 Glossary of Abbreviations and Acronyms Used. 658

25. Copyright Information

Contents

“Introduction” on page 20

“Unpacking the E7495A/B Test Set” on page 22

“E7495A/B Cables, Connectors, and Accessories” on page 24

“Test set options” on page 28

“Where to find the Latest Information on Upgrading your E7495A/B Test Set”
on page 32

“Your First 15 Minutes with the E7495A/B” on page 33

“Using the Backpack” on page 41

“Contacting Agilent Technologies” on page 43

Introduction

The E7495A/B Base Station Test Set is designed to simplify the job of installing and maintaining base stations. By combining all important base station diagnostic tools in one rugged instrument, the E7495A/B lets you get your work done in the shortest time at each base station.

Basic test functionality includes:

- Spectrum Analysis
- Two Port Insertion Loss
- One Port Insertion Loss
- Return Loss
- Distance to Fault

You can optionally add these measurements:

- Adjacent Channel Power
- CDMA Over Air
- CDMA Analyzer
- WCDMA Analyzer
- WCDMA Over Air
- HSDPA for WCDMA Analyzer and WCDMA Over Air
- 1xEV-DO Analyzer and 1xEVDO Over Air
- GSM Analyzer
- GSM/EDGE Analyzer
- Channel Scanner
- T1
- E1
- CW/cdmaOne/cdma2000/1xEV-DO Reverse Link Signal Generator
- Power Meter
- Test software and utilities

- DC Bias output (internal, available on the E7495B only)

You can store trace data from Return Loss and Distance to Fault measurements on a Windows XP PC for later analysis. This analysis software is a free download from the Agilent web site at http://www.agilent.com/find/e7495_software.

In Getting Started, you will learn how to set up the E7495A/B, and you will learn to perform one basic measurement to start getting familiar with the range of tools contained in the test set.

If you are a new user, also recommended is E7495A Quick Basics, an HTML-based tutorial available on the CD that comes with the test set.

After the Getting Started chapter, you will find, in alphabetical order, one chapter on each E7495A/B measurement. General information on batteries, caring for the E7495A/B, and how to return the instrument for service follows.

Unpacking the E7495A/B Test Set

Unpack and inspect the shipping container and its contents thoroughly to ensure that nothing was damaged during shipment.

If the contents are damaged or defective, contact your nearest Agilent Technologies sales and service office. Keep the shipping materials for the carrier's inspection.

Verify that all the parts were included in the shipping container.

The basic test set package for the E7495A includes:


- E7495A Base Station Test Set
- Shoulder strap
- One battery
- Two 10 dB pads
- AC/DC converter
- Two N-to-N barrels
- Open connector (50 Ω)
- Short connector (50 Ω)
- Load connector (50 Ω)
- GPS antenna
- 64 MB PCMCIA memory card
- CD ROM containing electronic (PDF) version of Measurement Guide, E7495A Quick Basics tutorial, and application notes
- Accessories case
- Two 60-centimeter (2-foot) cables
- One 3-meter (10-foot) cable
- Two N-to-11 millimeter (N-to-7/16 inch) connectors
- Backpack
- High power attenuator
- Measurement Guide (this manual)
- Backpack loading card

The standard test set package for the E7495B includes:

- E7495B Base Station Test Set
- Shoulder strap
- One battery
- Two 10 dB pads
- AC/DC converter
- Two N-to-N barrels
- Open connector (50 Ω)
- Short connector (50 Ω)
- Load connector (50 Ω)
- GPS antenna
- 64 MB PCMCIA memory card
- CD ROM containing electronic (PDF) version of Measurement Guide, E7495A Quick Basics tutorial, and application notes
- One 3-meter (10-foot) cable
- Two 60-centimeter (2-foot) cables
- Two N-to-11 millimeter (N-to-7/16 inch) connectors
- Coax Accessories Case

E7495A/B Cables, Connectors, and Accessories

Part Number	Picture	Description
0950-4404		AC/DC adapter 24 VDC 100W (Supplied as standard)
0950-4409		PCMCIA 64MB Flash memory card (Supplied as standard)
0955-1458		High power attenuator (40 dB 100W)
(E7495A-STD)		(Supplied as standard with E7495A)
(E7495B-803)		Supplied with E7495B Option 803 after 1 Sept 2007
0955-1599		High power attenuator (40 dB 100W)
(E7495B-800)		Supplied with E7495B Option 800 (discontinued)
(E7495B-803)		(Supplied with E7495B Option 803 prior to 1 Sept 2007)

Part Number	Picture	Description
1150-2085		GPS antenna, SMA M (Supplied as standard)
1250-2908		Adapter, N (Female) to 11 millimeter (7/16 inch) (Male) (Supplied as standard)
1250-2810		Adapter, N (Female) to 11 millimeter (7/16 inch) (Female) (Supplied as standard)
1420-0883		Battery (Supplied as standard. Also supplied as Option 820)
8120-8862 Quantity 2		Cable, 60-centimeter (2-ft) N (m) - N (m) (Supplied as standard)

Getting Started

Getting Started
Unpacking the E7495A/B Test Set

Part Number	Picture	Description
8121-1315		Cable, 3-meter (10-ft) N (m) - N (m) (Supplied as standard)
E7495-20165		Shoulder strap (Supplied as standard)
E7495-80053		Soft Carry Bag (Supplied as Option 801)
E7495-80014		Backpack (Supplied as standard with E7495A) (Supplied as part of Options 800 and 802 with E7495B)

Part Number	Picture	Description
E7495-60059	Picture not shown	Coax Accessories Case, plastic and foam (5000-0911)
		Open, 50 ohm, N-type male (1250-3421)
		Short, 50 ohm, N-type male (1250-3424)
		Load, 50 ohm, N-type male (1250-3423)
		Attenuator, fixed 6 GHz max 10 dB N type (0955-1534) Quantity - 2
		Adapter, 50 ohm, N-type F-F (1250-3422) Quantity - 2

Getting Started

Test set options

Option Number	Description (as printed on the analyzer rear panel)	Detailed Description
Option 200	cdmaOne / CDMA 2000 Analyzer	cdmaOne / CDMA 2000 Analyzer, includes: CA-ASSY RF 50 ohm, BNC, male to male cable 3-meter (10-ft) (pn 8121-1230)
Option 205	1xEV-DO Analyzer & Over Air Test	1xEV-DO Analyzer & Over Air Test (Source requires Option 510 CW & Complex Modulation Signal Generator), includes:
Option 210	cdmaOne / CDMA 2000 Over Air Test	cdmaOne/CDMA2000 over-the-air (OTA) test (Requires Option 200 cdmaOne / CDMA 2000 Analyzer; Options 810, 811, or 812 are recommended)
Option 220	Channel Scanner	Channel Scanner
Option 230	GSM Analyzer	GSM Analyzer
Option 235	EDGE Analyzer	Adds EDGE analysis to GSM Analyzer (Requires Option 230 - GSM Analyzer)
Option 240	W-CDMA Analyzer	W-CDMA Analyzer
Option 245	HSDPA Analyzer & HSDPA Over Air Test	Adds HSDPA Analysis and Over Air test functionality to W-CDMA Analyzer and W-CDMA Over Air Test (Requires Option 240 - W-CDMA Analyzer for analyzer functionality;) (Requires Options 240 - W-CDMA Analyzer and 250 - W-CDMA OTA for over-the-air functionality)
Option 250	W-CDMA Over Air Test	W-CDMA Over Air Test Analyzer (Requires Option 240 - W-CDMA Analyzer) (Option 813 European W-CDMA antenna and pre-selector filter is recommended)

Option Number	Description (as printed on the analyzer rear panel)	Detailed Description
Option 270	Interference Analyzer	Interference Analyzer
Option 300	DC Bias	DC Bias (Available on the E7495B Analyzer only)
Option 330	Nortel CDMA Software	Nortel CDMA Base Station Test Software (Requires Option 200 cdmaOne/CDMA2000 OTA, Option 510 CW & complex modulation source, and Option 600 Power Meter)
Option 500	CW Signal Generator	CW Signal Generator
Option 510	CW & Complex Modulation Signal Generator	CW/cdmaOne/CDMA2000 reverse link signal generator
Option 51B		Return to Agilent for repair
Option 50C		Return to Agilent for calibration
Option 600	Power Meter	Power Meter (Requires 8482A/8481A or N8482A/N8481A with Option CFT power sensor), includes: One 3-meter (10 ft) power sensor cable (pn E9288-60002)
Option 700	T1 Analyzer	T1 Analyzer, includes: - Y-bantams to alligator, 3-meter (10-foot) cable (pn 8121-1026) - Y-bantams to RJ-45, 3-meter (10-foot) cable (pn 8121-1025) - Y-bantams to Y-bantams, 3-meter (10-foot) cable (pn 8121-1024)
Option 710	E1 Analyzer	E1 Analyzer, includes: - Balun, 75 - 120 ohm adapter (0950-4551) 75 ohm BNC, four connectors, 3-meter (10-foot) cable (quantity 2) (8121-1228)

Getting Started

Unpacking the E7495A/B Test Set

Option Number	Description (as printed on the analyzer rear panel)	Detailed Description
Option 800		E7495B Accessory Package - discontinued, replaced by Options 802, 803, and 805
Option 801		Soft Carry Bag
Option 802		Backpack
Option 803		40 dB Attenuator
Option 805		Measurement Guide for the Agilent E7495A/B Base Station Test Set (this manual)
Option 810		Cellular antenna and pre-selector filter, includes: • Cellular antenna (pn 1150-2061) • preselector filter (pn 0955-1527) • RF TNC to N connector (pn 1200-1897) for Option 210 - cdmaOne / CDMA 2000 Over Air Test
Option 811		PCS Antenna and pre-selector filter, includes: • PCS antenna (pn 1150-5059) • preselector filter (pn 0955-1526) • RF TNC to N connector (pn 1200-1897) for Option 210 - cdmaOne / CDMA 2000 Over Air Test
Option 812		Korean PCS Antenna and pre-selector filter, includes: • Korean PCS antenna (pn 1150-5059) • preselector filter (pn 0955-1590) • RF TNC to N connector (pn 1200-1897) for Option 210 - cdmaOne / CDMA 2000 Over Air Test

Option Number	Description (as printed on the analyzer rear panel)	Detailed Description
Option 813		W-CDMA antenna and pre-selector filter, includes: • W-CDMA antenna 2.1-2.17 GHz (pn E6455-80003) • preselector filter (pn 0955-1667) • RF TNC to N connector (pn 1200-1897) for Option 210 - cdmaOne / CDMA 2000 Over Air Test
Option 820		External charger/battery pack/DC adapter, includes: • Battery 10.8 V 6 A-HR LI-ION (pn 1420-0883) • External power supply AC/DC adapter 24 VDC 100 W (pn 0950-4404) • DC car adapter DC to DC adaptor output 19 VDC 70 W (pn 0950-4412) • dual battery charger, 12 V AT 1 A (pn 0950-4276)
Option N8482A		Power Sensor, 100 kHz to 4.2 GHz:
Option 840		Hard transit case (pn E7495-80016)
Option 900		UK power cord
Option 901		AUS/NZ/CH power cord
Option 902		Euro power cord
Option 903		US power cord
Option 906		Swiss power cord
Option 912		Denmark power cord
Option 917		So Af/India power cord
Option 918		Japan power cord

Getting Started

Unpacking the E7495A/B Test Set

Option Number	Description (as printed on the analyzer rear panel)	Detailed Description
Option 919		Israel power cord
Option 920		Argentinean power cord
Option 921		Chilean power cord
Option 922		China power cord
Option 927		Thailand power cord

Where to find the Latest Information on Upgrading your E7495A/B Test Set

Upgrade information is updated periodically. For the latest information about Agilent Technologies E7495A/B Base Station Test Sets, including firmware, Hardware, and Licensed Measurement upgrades, please visit the following URL:

http://www.agilent.com/find/sa_upgrades

- and click on the *E7495A/B Base Station Test Set* link.

Your First 15 Minutes with the E7495A/B

Spend 15 minutes getting acquainted with the test set:

- “Get to Know the Layout of the E7495A/B” on page 34
- “Install a Battery” on page 37
- “Practice Using the Three-way Power Button” on page 37
- “Make Your First Measurement (Two Port Insertion Loss)” on page 38

Your E7495A/B analyzer is fitted with a transfective screen, which is viewable under all lighting conditions. If you are using your E7495A/B analyzer in bright lighting conditions, for example, in direct sunlight, avoid the temptation to shield the display from the sunlight. In bright lighting conditions, the display is brighter and easier to read when you allow the light to fall directly on the screen.

CAUTION

The display screen should be cleaned with an Isopropyl Alcohol based cleaner and a soft lint-free cotton cloth. The E7495A/B display has a polycarbonate cover with an anti-reflective coating, which can be damaged if not cleaned properly. The anti-reflective coating is a surface treatment and can be scratched if wiped with an abrasive material. Use only soft lint-free cotton cloth and Isopropyl Alcohol to clean the display.

When selecting a cleaner make sure it does not contain any Ammonia.

CAUTION

The maximum power for the RF In (Port 1) and RF Out/SWR (Port 2) ports is +20 dBm (100 mW). When using the 8481A/8482A or N8481A/N8482A with Option CFT Power Sensors, the maximum input power applied to the Power Sensor is +24 dBm (300 mW). When using the 8481D Power Sensor, the maximum input power is +20 dBm (100 mW). When directly coupled to a base station (BTS) or Access Network (AN), the test set can be damaged by excessive power applied to any of these three ports.

To prevent damage in most situations when you directly couple the test set to a base station, use the high power attenuator between the test set and the BTS.

Getting Started

Your First 15 Minutes with the E7495A/B

Get to Know the Layout of the E7495A/B



Number	Description
1	Power button. Powers the test set on and off, and puts it into standby mode. • To power on, press the power button. When the test set is on, the right LED is lit. • To put into standby mode while the power is on, press the button for about 1 second. In standby mode—which conserves the battery and provides quicker startup—the left LED is lit. For more information about the power button states, refer to “Practice Using the Three-way Power Button” on page 37. • To power off, press the button and hold down until you see both LEDs go out. This takes approximately 5 seconds.
2	• Preset. Recalls the power-up state, applying Agilent defaults or the defaults you define using the Save State button. • Brightness. Changes the brightness of the display in four increments. To increase or decrease the brightness, press the button repeatedly. • Help. Displays online help. • ESC/Lcl. Stops the active function and clears the active function text from the display. Pressing ESC/Lcl after the test set has been placed in remote mode switches to local mode and enables front-panel control. • Mode. Displays a menu of measurement modes. • Save Data. Saves the non-trace measurement data to either a PCMCIA or CompactFlash card. • Save State. Saves the state of all measurement parameters to non-volatile memory in the test set. You can save multiple states, each with its own name. • System. Displays menu of non-measurement operations including configuration, system status updates, data manipulation, and basic system functions testing. • Print Screen. Prints the current screen image to either a PCMCIA or CompactFlash card. • Recall State. Recalls the state of all measurement parameters you saved in non-volatile memory using the Save State button.
3	Numeric keypad. Used for entry of values for many test parameters.

Number	Description
4	• Rotary knob. Allows incremental changes to values for such things as carrier frequency, reference level, and marker positions. Rotate clockwise to increase values, counterclockwise to decrease values. The speed at which you turn the knob affects the rate at which the values are changed. • Down Arrow. Decreases the active function value. The increment size depends upon the current measurement. Each press results in a single increment change. For those parameters with fixed values, the next value in a sequence is selected each time you press the button. • Up Arrow. Increases the active function value.
5	Battery LEDs. Show remaining charge capacity and charging status of batteries. For details, see “Viewing Battery Status” on page 165 .
6	menu keys. Allow you to select measurement modes and other settings for configuring and performing measurements, and for other E7495A/B functions.

CAUTION

The display screen should be cleaned with an Isopropyl Alcohol based cleaner and a soft lint-free cotton cloth. The E7495A/B display has a polycarbonate cover with an anti-reflective coating, which can be damaged if not cleaned properly. The anti-reflective coating is a surface treatment and can be scratched if wiped with an abrasive material. Use only soft lint-free cotton cloth and Isopropyl Alcohol to clean the display.

When selecting a cleaner make sure it does not contain any Ammonia.

Install a Battery



Step	Notes
1 Open the battery door.	Turn the latch counterclockwise several times until loose. Then pull the battery door open.
2 Insert the battery.	Insert one or two batteries.
3 Close the battery door.	Turn the latch clockwise until tight to secure the battery door.

For more information about the batteries, including battery installation and removal, refer to [Chapter 6](#) , “Working with Batteries.”

Practice Using the Three-way Power Button

The E7495A/B Test Set power button is designed to provide additional convenience when you want to pause between measurements, then quickly start again. Besides

Getting Started

Your First 15 Minutes with the E7495A/B

working like a standard on-off button, the E7495A/B power button also lets you put the test set into standby mode, which conserves battery usage and provides a quick startup when you are ready to resume measurements.

Step	Notes
To power on the test set, press the button.	As soon as you press the power button, the right LED goes on. The full power-up sequence can take up to 2 minutes.
To put the test set into standby mode while the power is on, press the button briefly for about a second.	When in standby mode, the left LED is lit. When you power on the test set again, the startup takes only about 30 seconds.
To power off the test set, press the button and hold until both LEDs above the button go off. This usually takes about 5 seconds.	When you hold down the button, at first both LEDs are lit. After about 5 seconds, both go out.

Make Your First Measurement (Two Port Insertion Loss)

The two port insertion loss measurement is perhaps the most fundamental test set measurement. It quantifies exactly how much loss is incurred as a signal travels through a cable or other device. You must account for the signal loss of a connecting cable in order to produce accurate results for a variety of other measurements.

You can perform this measurement using any of the following devices:

Needed for normalization:

- 60-centimeter (2-foot) normalization jumper cable
- Two 10 dB pads

Devices whose insertion loss you measure:


- 60-centimeter (2-foot) test cable
- 3-meter (10-foot) test cable
- High power attenuator
- N-N barrel

Step	Notes
1 Select two port insertion loss. a. Mode b. [Antenna/Cable] c. [Two Port Insertion Loss]	In this and other procedures, front-panel buttons are indicated with bold text, menu keys with brackets.
2 Enter the start frequency. a. Press [Start Freq] if the menu key is not already highlighted. b. Enter the frequency using the numeric keypad. c. Press [Hz], [kHz], [MHz], or [GHz].	
3 Enter the stop frequency. a. Press [Stop Freq]. b. Enter the frequency using the numeric keypad. c. Press [Hz], [kHz], [MHz], or [GHz].	
4 Normalize the test set. a. [Normalize] b. Follow the Normalize Wizard.	The Normalize Wizard, which is built into the test set, displays instructions to guide you through normalization.
5 Attach the device whose insertion loss you want to measure between the two 10 dB pads.	

Getting Started

Your First 15 Minutes with the E7495A/B

Step	Notes



Insertion loss measurement of high power attenuator and cable.

For more information on making insertion loss measurements, see [“Two Port Insertion Loss”](#) on page 123.

Using the Backpack

The E7495A/B backpack (Option 802, and included as part of Option 800) is ergonomically designed to hold the test set as well as its cables and accessories. The backpack allows you to carry all your gear up to a base station while keeping your hands free.



WARNING

To avoid overheating, always disconnect the test set from the AC adapter before storing the test set in the backpack.

If you prefer to leave the test set connected to the AC adapter while inside the backpack, you can disconnect the AC adapter from its power source to prevent overheating.

Getting Started Using the Backpack

What Goes Where in the Backpack



1 Business card



2 Writing supplies



3 Fragile equipment,
such as antennas



4 Rain fly



5 Laptop



6 Food and water



7 Over-air filter and
other accessories



8 High power
attenuator



9 AC adapter



10 Base station test set



11 Cables



12 Batteries



Slide harness up or down
to fit torso. Don't expose
red stitch line.

CAUTION: A fully loaded backpack is heavy.
Use caution when putting it on or taking it off.

Contacting Agilent Technologies

For help with product selection and configuration, technical and application assistance, consulting and integration services, rental and leasing options, refurbished equipment, product purchases, repair, calibration, education and training please go to <http://www.agilent.com/find/assist>

If you do not have access to the Internet, call the appropriate number shown in below or contact your local Agilent Technologies Sales and Service Office.

Americas +1-800-829-4444

Australia +1-800-629-485

Europe, Africa, Middle East +32 (0)2 404-9340

Singapore +1-800-375-8100

More Information from Agilent

For more information about Agilent's E7495A/B Base Station Test Set, go to <http://www.agilent.com/find/e7495b>

For more information about Agilent's solutions for the communications industry, visit our web site at <http://www.agilent.com/comms/industry>

E7495A/B Base Station Test Set Product Updates

For information about E7495A/B Base Station Test Set updates, go to <http://www.agilent.com/find/e7495b>

“Measuring One Port Insertion Loss” on page 46

“Calibration - Minimizing your Workload” on page 46

“Performing (and Calibrating) a Basic One Port Insertion Loss measurement” on page 47

“Clearing Calibration” on page 50

“Displaying Location Information Using GPS” on page 51

“Setting Average, Sweep, and Restart” on page 52

“Adding a Marker” on page 55

“Setting One Port Insertion Loss Interference Rejection” on page 56

“Setting the Pass/Fail Limits” on page 57

Measuring One Port Insertion Loss

The one port insertion loss measurement allows you to quantify signal loss in a cable or other device without connecting both ends of the cable or device to the test set. This measurement can be especially useful in measuring the loss of a feedline connected to the antenna on a tower. This method of measuring antenna feedline insertion loss is accurate for results up to 10 dB.

This measurement is less accurate than Two Port Insertion Loss. When it is not practical to connect both ends of a device to the test set or for insertion loss measurements greater than 10 dB — for example when measuring a 40 dB high power attenuator — it is better to use Two Port Insertion Loss.

NOTE

The test signal emitted from the SWR port is a sine wave, swept from the starting frequency to the stop frequency. When testing cables that are attached to antennas, test signals are radiated, and these test signals can cause interference. Verify that the signal used for the test cannot cause interference to another antenna.

Calibration - Minimizing your Workload

The **One-Port Insertion Loss** calibration is the same calibration as performed for the **Return Loss** and **Distance to Fault** (when it is performed with Frequency Range set to manual) measurements. If you have already calibrated for any of these three measurements, the calibration will apply to the other two measurements and “Calibrated” (together with the frequency range over which the calibration was performed) will be displayed on top left of the screen for all three.

The **Distance to Fault** calibration (*when it is performed with Frequency Range set to Auto*) is only valid for other *Distance to Fault* measurements that are also performed with *Frequency Range set to Auto*, and then only if the calibrated frequency range falls within the previously calibrated frequency range.

If you have not previously performed a calibration, the word “Uncalibrated” appears at the top left of the measurement screen.

It is important that you keep the calibration frequency range as close as possible to the actual sweep frequencies you intend using for the measurement or measurements. Calibrating over a large frequency range (for example, 1 GHz) when you only intend measuring over a much smaller range (a few kHz, for example) will induce inaccuracies into your results.

If you plan to perform a combination of **One-Port Insertion Loss** measurement,

Return Loss measurement, and **Distance to Fault** measurements *using a frequency range that you will set manually*, you can perform one calibration for all three measurements as long as you calibrate over a frequency range that incorporates all three of your measurements, and as long as your cables do not change. For this reason, if you are doing Distance to Fault measurements (*using a frequency range that you have set manually*) as well as any type of Insertion Loss measurement, Agilent recommends that you select your cable type before performing calibrations. Press [Mode], [Antenna/Cable], [Distance to Fault], [Cable Type] to set the cable type.

The calibration remains valid until you do any one of the following:

- set the Distance to Fault frequency range to **Auto**. Note that the calibration will become valid again as soon as you switch from **Auto** back to **Manual** Frequency Range.
- power off the test set
- change the start frequency to a new value that lies below the start frequency of your previous calibration
- change the stop frequency to a new value that lies above the stop frequency of your previous calibration
- change any of the jumper leads that you used for the calibration
- change any of the attenuators that you used for the calibration
- change the type of cable specified under the [Cable Type] menu key.

Performing (and Calibrating) a Basic One Port Insertion Loss measurement

Select the desired frequency range and calibrate the test set for a One Port Insertion Loss measurement. To calibrate your test set, you will need the following pieces of equipment:

- Cable, N (male) to N (male), part number 8120-8862 or 8121-1315
- Calibrated 50 ohm Open connector, part number 1250-3421
- Calibrated 50 ohm Short connector, part number 1250-3424
- Calibrated 50 ohm Load connector, part number 1250-3423

NOTE

All four of these required accessories are supplied as standard with your Agilent E7495A/B test set.

One Port Insertion Loss

Measuring One Port Insertion Loss

Step	Notes
1 Mode	
2 [Antenna/Cable]	
3 [One Port Insertion Loss]	The one port insertion loss measurement takes a few seconds to load.
4 [Start Freq]	
5 Enter the start frequency using the numeric keypad.	
6 [Hz], [kHz], [MHz], or [GHz]	
7 [Stop Freq]	
8 Enter the stop frequency using the keypad.	The stop frequency should be larger than the start frequency.
9 [Hz], [kHz], [MHz], or [GHz]	

Step	Notes
10	Check whether your analyzer has already been calibrated over the frequency range that you wish to measure. If it is already calibrated over the correct frequency range, you can omit the next step (Step 11) and go straight to Step 12. • power off the test set • change the start frequency to a new value that lies below the start frequency of your previous calibration • change the stop frequency to a new value that lies above the stop frequency of your previous calibration • change any of the jumper leads that you used for the calibration • change any of the attenuators that you used for the calibration • change the type of cable specified under the [Cable Type] menu key in the Distance to Fault measurement. For more information, see “Calibration - Minimizing your Workload” on page 46.
11	If your analyzer is uncalibrated, or has been calibrated over an unsuitable frequency, press [Calibrate] Follow the instructions of the Calibration Wizard. The test set will calibrate over the desired frequency range.
12	Connect the antenna feedline and antenna. Connect the antenna feedline cable to the RFout/SWR port.

One Port Insertion Loss

Measuring One Port Insertion Loss

Step	Notes



13	Disconnect the feedline at the top of the tower, and connect a short connector to the feedline.	This step is necessary to get a good mismatch for the measurement.
14	[Level]	Below the trace on the screen is a table displaying the average insertion loss. If the trace is not visible, you can change the reference level or use Autoscale to have the test set select a reference level for you. • To choose Autoscale, press [Autoscale]. • To set the level manually, press [Ref Level], enter a value using the numeric keypad, then press [dB].

Clearing Calibration

Clear Calibration deletes the current calibration data, enabling you to re-calibrate the instrument for the same frequency range.

To Clear the Measurement Calibration Data:

Step	Notes
1 [Setup]	
2 [Clear Calibration]	This will clear the calibration for all three one-port cable measurements.

Displaying Location Information Using GPS

If you are making a One Port Insertion Loss measurement, you can use GPS Location data to verify your location. For additional information on the GPS Data function, refer to “[Displaying GPS Location Data](#)” on page 462.

To Display GPS Location Information:

Step	Notes
1 [Level/Location]	
2 On [Show GPS Location] select On .	Displays GPS satellite location information. Uses the internal GPS to capture the location at which a measurement is made. The GPS information can be used to return to the same location. The Time Ref (Freq/Chan/Time Ref mode) button must be set to Internal GPS for this function to be active. Information logged includes longitude, latitude, altitude (feet/meters), and the number of satellites tracked. Each time you press this softkey, the selected option changes.
3 Highlight [On]	Toggle to [On] to display GPS satellite location information. Toggle to [Off] to remove the location information

NOTE

If you prefer to have an electronic copy of the location information, see “[Saving Data](#)” on page 469.

Setting Average, Sweep, and Restart

Setting the Sweep

You can select either continuous or single sweep. Continuous sweep provides repeated, ongoing measurements. Single sweep performs a single measurement that is repeated only when you push the Single button.

To set sweep:

Step	Notes
1 [Average/Sweep]	
2 [Continuous] or [Single]	Each time you press this softkey, the selected option changes.

Setting Averaging

You can choose to have averaging On or Off and set the number of averages you want to take. Averaging only applies to the data, not to the trace. You can select from the following types of averaging:

- **Off:** Disables averaging.
- **Running:** Computes the new result as the weighted sum of the last result and the new measurement. The last result is weighted by $(n - 1)/n$. The new result is weighted by $1/n$. Each new measurement produces a new result.
- **Max Hold:** Is not an average, but on a point by point basis, displays the maximum amplitude for the given frequency or channel since Max Hold was turned on. It is updated when a new maximum occurs.
- **Group Average:** Makes the requested number of measurements, averages the measurement data, and displays the average as a single result trace. Measurement time will vary based on the requested number of averages and can take minutes for very large number of averages.
- **Group Max Average:** Makes the requested number of measurements before returning a single trace result. This trace is the maximum value seen at each trace point over the requested number of averages (measurements).

To set averaging:

Step	Notes
1	Set the number of averages. a. [Average] b. Enter the number of averages using the numeric keypad. c. [Enter]
2	Select the type of averaging you want to apply. a. [Average/Sweep] b. [Averaging] c. [Off], [Running Average], [Max Hold], [Group Average], or [Group Max Average]

NOTE

These two steps can be performed in any order. However, if you turn averaging on and a large number of averages has previously been set, there may be a delay before you can change the number of averages.

Setting Restart

When you have averaging turned **On** and you are in **Continuous** Sweep mode, you can restart the averaging by pressing the Restart menu key. The Restart key has no effect if you are in **Single** sweep mode.

To restart averaging:

Step	Notes
1	[Average/Sweep]

One Port Insertion Loss

Measuring One Port Insertion Loss

		Step	Notes
2	[Restart]		This key is unavailable or has no effect when Sweep is set to Single . To restart a Single Sweep measurement, press [Single].

Adding a Marker

Markers can be used on traces to help you visually track up to four signals. Each marker has the following settings:

- **Type:** Provides three options, including:
 - **Off**
 - **Normal:** Places a diamond-shaped, colored marker, along with a number, 1-4, on the trace.
 - **Delta:** Associated with a normal marker. Therefore, a normal marker must exist prior to creating the delta marker. The delta marker displays the difference between the normal marker position and the delta marker position. Only one delta marker can be associated with a given normal marker. The normal marker must be active when Delta is selected.
- **Marker to Peak:** Places the active marker on the current greatest value of the trace.
- **Marker to Next Peak:** Places the active marker on the current second greatest value of the trace.
- **Marker to Min:** Places the active marker on the current lowest value of the trace.
- **Marker to Next Min:** Places the active marker on the current second lowest value of the trace.

To add a marker to a trace

Step	Notes
1	[Marker]
2	[Marker]
3	[1], [2], [3], or [4]
4	[Type]
5	[Off], [Normal], or [Delta]
6	Locate the marker relative to the trace: [Marker to Peak], [Marker to Next Peak], [Marker to Min], or [Marker to Next Min]

Setting One Port Insertion Loss Interference Rejection

Other signals can interfere with One Port Insertion Loss measurements. When making a one port insertion loss measurement in the presence of known or suspected interference, you can minimize the effect of the interference on the measurement by activating interference rejection in the test set.

NOTE

Use of interference rejection will increase the measurement time. Interference rejection should be used if a known interfering signal exists or if the one port insertion loss measurement displays suspicious characteristics such as a spike or rapid movements in the noise floor.

To activate interference rejection:

Step		Notes
1	[Setup]	
2	On [Interference Rejection] select On .	Each time you press this softkey, the selected option changes.

Setting the Pass/Fail Limits

The measurement limits setting enables you to alter the value of the maximum and minimum test limits for the Average Insertion Loss measurement. Limits are set in dB. These settings affect the metrics color display: red represents fail, green represents pass. Next to the displayed measurement value, a (P) indicating Pass, or (F) indicating Fail, will be shown to further indicate whether the value is within or outside the set limits.

To Set the Measurement Maximum and Minimum Limits:

Step	Notes
1 [Setup]	
2 [Limits]	
3 On [Limits] select On or Off .	Enables you to toggle the measurement limits function On (active) and Off (inactive). • If set to On, Any measured value that exceeds the upper maximum or is less than the minimum limit will result in a failure indication for that value. • If set to Off, pass fail indicators seen in the metrics display portion of the display will not be displayed.
4 Set the upper limit. a. [Maximum Limit] b. Enter the number on the numeric keypad. c. [dB]	Maximum limit can be set from –100 to 100 dBm.
5 Set the lower limit. a. [Minimum Limit] b. Enter the number on the numeric keypad. c. [dB]	Maximum limit can be set from –100 to 100 dBm.

- “Accessing 1xEV-DO Tx and Over Air Test” on page 60
- “Making 1xEV-DO Tx Measurements” on page 61
- “Making 1xEV-DO Over Air Measurements” on page 67
- “Displaying Location Information Using GPS” on page 74
- “Interpreting the Display” on page 75
- “Optional 1xEV-DO Tx and Over Air Analyzer Measurement Settings” on page 77
- “Metrics Provided by the 1xEV-DO Tx and Over Air Analyzer Measurement” on page 104
- “Interpretation of 1xEV-DO Tx and Over Air Analyzer Measurement Results” on page 109
- “Customizing Your Display” on page 114
- “Sorting by MAC Index or by Walsh Code” on page 115
- “Converting Between MAC Index and Walsh Code” on page 116
- “Colors Used on the MAC Code Domain CDP Display” on page 117
- “Colors Used on the Pilot Code Domain CDP Display” on page 118
- “Showing or Hiding the OTA PN Scanner” on page 119
- “Codogram Display” on page 120
- “Performing a Codogram Measurement” on page 121

Accessing 1xEV-DO Tx and Over Air Test

The 1xEV-DO Analyzer & Over Air Test (Option 205) can, as its name suggests, be used to perform both Tx Analyzer and over-the-air tests.

You can access both the 1xEV-DO Analyzer and the 1xEV-DO Over Air Test either by pressing [Tx Analyzer], then [1xEV-DO Analyzer] or by pressing [Over Air], then [1xEV-DO Over Air]. It is worth noting, however, that you are using the same measurement software in either case.

If you access the measurement through the Tx Analyzer submenu, the Over the Air features will be turned Off. If you access the measurement through the Over Air submenu, the Over the Air features will be turned On. Any of these Over the Air settings can be changed at any time. This means you can easily perform Over the Air measurements after selecting [Tx Analyzer], [1xEV-DO Analyzer], and equally, you can perform Tx Analyzer measurements after selecting [Over Air], [1xEV-DO Over Air]. This will often be faster and more convenient method of switching between the TX Analyzer and the Over the Air Analyzer.

Making 1xEV-DO Tx Measurements

- “Common 1xEVDO Tx Analyzer Measurements” on page 61
- “Preparing to Make 1xEVDO Tx Analyzer Measurements” on page 61
- “Performing a Basic 1xEVDO Transmitter Measurement” on page 63

1xEV-DO transmitter measurements verify proper transmitter performance and are typically made with the access network (AN) still in service. The Access Network only needs to be taken out of service when you are setting or measuring the Tx Power Out level, and this is typically only performed during Installation, Optimization, and Preventative Maintenance.

Important metrics for both Tx and Over the Air measurements include:

- Frequency Error
- PN and Time Offsets
- Non Idle Power
- Idle On/Off Ratio
- Pilot + MAC power
- Pilot Rho (estimated)
- MAC Rho (estimated)

CAUTION

The maximum power for the RF In (Port 1) and RF Out/SWR (Port 2) ports is +20 dBm (100 mW). When using the 8481A/8482A or N8481A/N8482A with Option CFT Power Sensors, the maximum input power applied to the Power Sensor is +24 dBm (300 mW). When using the 8481D Power Sensor, the maximum input power is +20 dBm (100 mW). When directly coupled to a base station (BTS) or Access Network (AN), the test set can be damaged by excessive power applied to any of these three ports.

To prevent damage in most situations when you directly couple the test set to a base station, use the high power attenuator between the test set and the BTS.

Common 1xEVDO Tx Analyzer Measurements

Preparing to Make 1xEVDO Tx Analyzer Measurements

When measuring 1xEVDO transmitter performance, there is no need to take the access network out of service. The Access Network only needs to be taken out of service when you are setting or measuring the Tx Power Out level, and this is

1xEV-DO Analyzer and Over Air Test

Making 1xEV-DO Tx Measurements

typically only performed during Preventative Maintenance.

The first step is to choose the type of time reference available. The measurement configuration depends upon the type of time reference you choose to use. Optimally, a GPS time reference is desired. GPS provides an independent time reference that can help determine if the access network under test is synchronized with the rest of the network. Access networks not synchronized with the rest of the network are referred to as “island cells”.

NOTE

If a **GPS** time reference is available, you will be able to see all the metrics, and you will be able to verify that the access network has correctly locked onto the GPS signal.

If you connect to the access network’s **Even Second Clock**, you will still get all the metrics, but you will not have an independent check that the access network has locked onto the GPS signal.

You need a timing reference (either GPS or ESC) to see PN Offset and Time Offset results. When using another non-time based reference (for example, **Internal Reference**), results for **PN Offset** or for **Time Offset** will be unavailable.

You must also know the channel or frequency of the 1xEVDO signal to be analyzed.

Each access network sector is assigned a unique PN [pseudo-noise] Offset. If you are using a GPS signal or the Even Second Clock, the PN Offset will be detected for you. If you are making measurements without the aid of either a GPS signal or the Even Second Clock, you will need to know the PN Offset of the Access Network that is producing the signal to be analyzed. For more information on PN Offsets refer to [“Adding a Marker” on page 90](#).

Performing a Basic 1xEVDO Transmitter Measurement


Once you have taken the access network out of service (this is necessary, for example, when you are setting the Tx Power Out level) and you have made the proper connections, you can perform 1xEVDO transmitter measurements.

Step	Notes
1. Mode	If your test analyzer is already performing a 1xEV-DO Over the Air measurement, you can switch quickly to 1xEV-DO Transmitter measurements by pressing [Display] and then switching OTA PN Scanner Off. If you do this, you can omit steps 2 and 3, and skip straight to Step 4.
2. [Tx Analyzer]	See above.
3. [1xEV-DO Anl]	See above.
4. [Chan Std]	
5. Highlight the channel standard you want using the up and down arrow buttons.	
6. [Select]	
7. On [Units] select Chan or Freq .	Each time you press this softkey, the selected option changes.
8. Enter the channel or frequency using the numeric keypad.	
9. [Fwd]	Selects the forward 1xEV-DO channel.
10. [Fr/Time Ref]	
11. [GPS] or [External Even Sec]	If the sky (and hence the satellites) is not visible from the position of your analyzer, use External Even Sec as the time reference.

1xEV-DO Analyzer and Over Air Test


Performing a Basic 1xEVDO Transmitter Measurement

Step	Notes
12 On [PN Offset] select Auto or Manual .	The test set defaults to Auto mode. The other choice is Manual. - In Auto mode the test set finds the PN Offset and displays the value in the metrics display at the bottom of the screen. The Time Offset is derived from the PN Offset that has been found. - In Manual mode you must enter the PN Offset, which appears in the metrics display. The Time Offset is derived from the entered PN Offset.
13 Connect to the access network.	




Connections for out of service 1xEVDO measurements with GPS receiver as timing reference. This setup is typically used when setting or measuring Tx Power Out Levels.

Step	Notes



Connections for out of service 1xEVDO measurements with access network even second as timing reference. This setup is typically used when setting or measuring Tx Power Out Levels




Connections for in service 1xEVDO measurements with GPS receiver as timing reference.

1xEV-DO Analyzer and Over Air Test

Performing a Basic 1xEVDO Transmitter Measurement

Step	Notes



Connections for in service 1xEVDO measurements with access network even second as timing reference

NOTE

Using GPS Time Reference signals: During a 1xEVDO Analyzer measurement, a yellow triangle symbol may temporarily appear beside “GPS” in the lower right. The yellow triangle indicates that the test set is re-synchronizing with the GPS even second pulse. Once the test set is synchronized, a green dot appears in place of the triangle. If the GPS is unavailable, a red X appears. If this happens, you must choose another reference.

A red X will also appear beside “GPS” at the bottom right if you are using the Even Second Clock timing reference but have not set the instrument to use the Even Second Clock. If this is happening, press **Fr/Time Ref** and select **External Even Second** as your timing reference.

Making 1xEV-DO Over Air Measurements

- “Preparing to Make 1xEV-DO Over Air Measurements” on page 68
- “Criteria for Making Valid 1xEV-DO Over Air Measurements” on page 69
- “Performing a Basic 1xEV-DO Over Air Measurement” on page 71

1xEV-DO over air measurements provide a quick method of verifying 1xEV-DO transmitter performance. These transmitter measurements can be made on a base station from the convenience of your vehicle without taking the base station out of service. Over air measurements are especially useful in maintaining hard-to-access cell sites such as pole-top base stations.

The 1xEV-DO Analyzer and Over Air option may also be used to measure signals at a coupled port on the transmitter.

Important metrics for both Tx and Over the Air measurements include:

- Frequency Error
- PN and Time Offsets
- Non Idle Power
- Idle On/Off Ratio
- Pilot + MAC power
- Pilot Rho (estimated)
- MAC Rho (estimated)

NOTE

To achieve valid over-the-air measurements, the test set must be stationary (not moving).

Preparing to Make 1xEV-DO Over Air Measurements

An important consideration when making 1xEV-DO over air measurements is your location relative to the base station. There must be no obstructions between your location and the base station antennas.

You must select the type of time reference to be GPS. The GPS antenna must be able to “see” the satellites to obtain lock, and you must have a GPS lock to perform measurements.

GPS provides an independent time reference that can help determine if the access network under test is synchronized with the rest of the network. Access networks not synchronized with the rest of the network are referred to as “island cells”.

NOTE

Once your test instrument successfully locks onto the **GPS** time reference, you will be able to see all the metrics, and you will be able to verify that the access network has correctly locked onto the GPS signal.

You need to know, and to enter on the test analyzer, the channel or frequency of the 1xEV-DO signal to be analyzed.

Each access network sector has a unique PN offset. If you know this, you can enter it manually. If you do not know the PN Offset, you can set PN Offset to Auto, and let the analyzer find the PN offset of the strongest pilot signal for you. You can also use the PN Scanner to identify all active PNs in the area. For more information on PN offsets refer to the “[Metrics Provided by the 1xEV-DO Tx and Over Air Analyzer Measurement](#)” on page 104.

Once you have connected the proper antenna to the test set, chosen a stationary location, and verified that you have a clear view of the base station antennas, you can perform 1xEV-DO over air measurements.

If this is the first 1xEV-DO over air measurement for this base station, you must find a location that meets the criteria for making a valid measurement. Your location must have a dominant pilot and very low multipath power. If you have made 1xEV-DO over air measurements at this location before and know it provides valid measurements, skip to “[Performing a Basic 1xEV-DO Over Air Measurement](#)” on page 71.

Criteria for Making Valid 1xEV-DO Over Air Measurements

The first step in making valid 1xEV-DO over air measurements is to identify a target base station to measure. Then, for your measurements to be valid, you must find a location near the target base station with a sufficiently strong 1xEV-DO signal. 1xEV-DO over air measurements will experience interference from other 1xEV-DO signals on the same RF channel and from multipath echoes. The code domain power view measures two key parameters to indicate these effects:

- Pilot dominance—The difference between the useful energy of the strongest pilot channel and the combined energy of the lower energy active pilot channels (expressed in dB). Ideally, this value should be very large (16 dB).

The E7495A/B test set includes up to nine lower energy active pilots in the pilot dominance calculation. In live testing of 1xEV-DO networks, however, it is unlikely that you will have as many as nine interfering pilots.

NOTE

It is important to remember that the pilot dominance is always measured against the strongest signal. If you have specified your channel of interest manually, this channel might not necessarily be the strongest.

- Multipath power—The amount of power, of the dominant pilot signal, that is dispersed outside the main correlation peak due to multipath echoes (expressed in dB). Ideally, this value should be very small (< 0.1 dB). **Multipath power** is the result of portions of the original broadcast signal arriving at the receiving antenna out of phase with the main power of the original signal. This can be caused by the signal being reflected off objects, such as buildings, or being refracted through the atmosphere differently from the main signal. These out of phase signals can cancel power from the main signal or appear as noise interference at the receiver.

The table below shows the quality of the over air code domain measurements with respect to pilot dominance and multipath power.

Measurement Quality	Pilot Dominance	Multipath Power
Very good	> 16 dB	< 0.1 dB
Fair	> 10 dB	< 0.4 dB

1xEV-DO Analyzer and Over Air Test

Criteria for Making Valid 1xEV-DO Over Air Measurements

Measurement Quality	Pilot Dominance	Multipath Power
Marginal	> 8 dB	< 0.7 dB

The default measurement limits for pilot dominance and multipath power are set to give “fair” measurement quality. If these limits are met, the pilot dominance and multipath power values will be displayed in green. When the pilot dominance and multipath power parameters are outside the acceptable limits, the parameters will turn red. If this occurs, you must move to a different location that meets the “fair” criteria defined above.

In general, you should always use a preselector filter for the band of interest to prevent strong signals from swamping out the signal of interest. Agilent offers these preselectors and antennas:

- Option 810—Cellular downlink band preselector and antenna
- Option 811—PCS downlink band preselector and antenna
- Option 812—Korean PCS downlink band preselector and antenna


Performing a Basic 1xEV-DO Over Air Measurement

Step	Notes
1 Mode	If your test analyzer is already performing a 1xEV-DO Transmitter measurement, you can switch quickly to 1xEV-DO Over the Air measurements by pressing [Display] and then switching OTA PN Scanner On. If you do this, you can omit steps 2 and 3, and skip straight to Step 4.
2 [Over Air]	See above.
3 [1xEV-DO Over Air]	See above.
4 [Chan Std]	
5 Select the channel standard you want using the up and down arrow buttons.	
6 [Select]	
7 On [Units] select Chan or Freq.	Each time you press this softkey, the selected option changes.
8 [Channel] or [Frequency]	• If you selected Chan in the previous step, select [Channel]. • If you selected Freq., select [Frequency].
9 Enter the channel or frequency using the numeric keypad.	
10 [Fwd]	Selects the forward 1xEV-DO channel.
11 Verify that on [Fr/Time Ref] GPS is selected. If not, press [Fr/Time Ref], then press [GPS].	

1xEV-DO Analyzer and Over Air Test

Performing a Basic 1xEV-DO Over Air Measurement

Step	Notes
12 On [PN Offset] select Auto or Manual .	The test set defaults to Auto mode. - In Auto mode the test set finds the PN offset of the strongest pilot signal and displays the value in the metrics display. The delay is derived from the found PN offset. - In Manual mode you must enter the PN offset using the numeric keypad. The delay is derived from the entered PN offset.
13 [Level/Location]	
14 [RF IN Loss]	
15 Set the RF IN Loss to 0 dB using the numeric keypad.	
16 [dB]	
17 Connect to the antenna.	



Connections for in service 1xEVDO measurements with GPS receiver as timing reference.

NOTE

The test set does not record data for post-processing. It provides a snapshot of 1xEV-DO base station transmit parameters at that location.

NOTE

During a 1xEV-DO over air measurement, a yellow triangle symbol may temporarily appear beside “GPS” in the lower right. The yellow triangle indicates that the test set is re-synching with the GPS even second pulse. Once the test set is synchronized, a green dot appears in place of the triangle. If the GPS is unavailable, a red X appears. If this happens, you must move to a different location.

Displaying Location Information Using GPS

If you are making 1xEV-DO over air measurements at a location you previously established as valid, Agilent recommends using GPS to verify that you are at the location from which you previously measured.

If you are making 1xEV-DO over air measurements from a new location, once you validate that the location provides a dominant pilot and low multipath power, Agilent recommends that you record the latitude and longitude coordinates of this location using GPS. Later measurements should be made from this precise location to provide performance trends.

For additional information on the GPS Data function, refer to [“Displaying GPS Location Data” on page 462](#).

To Display GPS Location Information:

Step	Notes
1 [Level/Location]	
2 On [Show GPS Location] select On .	Displays GPS satellite location information. Uses the internal GPS to capture the location of a measurement. The GPS information can be used to return to the same location. The Time Ref (Freq/Chan/Time Ref mode) button must be set to internal GPS for this function to be active. Information logged includes longitude, latitude, altitude (feet/meters), and the number of satellites tracked. Every time you press [Show GPS Location], the GPS location display alternates between On and Off.

NOTE

If you prefer to have an electronic copy of the location information, see [“Saving Data” on page 469](#).

Interpreting the Display

The 1xEV-DO Tx screen is divided into two sections, and the 1xEV-DO Over Air screen is divided into three sections. The extra, third section in the 1xEV-DO Over Air screen shows the OTA PN Scanner results, and appears at the top of the display.

You can switch the OTA PN Scanner **On** or **Off** independently in either a 1xEV-DO Tx Analyzer measurement or in a 1xEV-DO Over Air measurement. The presence or absence of the OTA PN Scanner is the main difference between the 1xEV-DO Tx Analyzer screen and the 1xEV-DO Over Air screen.

If you have the OTA PN Scanner display switched **On**, it appears at the top of the screen. The code domain trace display in the center. The pilot dominance and multipath power parameters are shown to the left of the screen. When you are making Over the Air measurements, awareness of these two parameter values helps you be sure that you are making valid measurements on the sector of interest.

The *code domain trace display* contains 128 Walsh codes when CDP Type is MAC 128, or 64 Walsh codes when CDP Type is MAC 64. These are shown in a bit-reversed order to represent the combined code channels for the varying data rate traffic channels. The Y-axis labels display the relative power (dB) or absolute power (dBm), threshold level, and dB/division. The X-axis labels display active channel Walsh Code numbers. Active code channels shown on the display include:

- Active MAC (Medium Access Control) RPC (Reverse Power Control) channels (shown in orange)
- RA (Reverse Activity) MAC channel (shown in light blue)
- Noise (shown in light gray)
- Unknown (MAC indexes 0 to 3 only) (typically these are displayed in gray, that is, as noise. If they are found to be active, they are shown in light brown)
- Pilot (shown as a red bar, and only when CDP Type is Pilot)

The *metrics display* shows 14 measurement parameters displayed below the CDP display in three columns and five rows—each with a value and units. For more information about the parameters in the metric display, refer to “[Metrics Provided by the 1xEV-DO Tx and Over Air Analyzer Measurement](#)” on page 104.

The time reference indicator is at the bottom right. For each indicator the text indicates which time reference you have chosen. A green LED indicates a locked condition, a red “X” indicates an unlocked condition. You must have a valid time references (either from the GPS system, or from an Even Second Clock) to make

1xEV-DO Analyzer and Over Air Test

Interpreting the Display

valid measurements.

Optional 1xEV-DO Tx and Over Air Analyzer Measurement Settings

You can change several optional measurement parameters in the 1xEV-DO Tx and Over Air Analyzer:

- “Setting the Channel or Frequency Step” on page 77
- “Setting the PN Offset” on page 79
- “Setting the PN Increment” on page 79
- “Setting the Active Channel Threshold Level and Auto Threshold Level” on page 80
- “Setting the Frequency/Time Reference” on page 81
- “Setting Units” on page 82
- “Setting the 1xEV-DO Transmitter Reference Level” on page 82
- “Setting Measurement Time” on page 83
- “Setting Measurement Offset” on page 84
- “Setting the Slot Threshold Level” on page 85
- “Setting the CDP Type” on page 85
- “Setting the Pilot Dominance Limit” on page 86
- “Setting the Multipath Power Limit” on page 87
- “Setting the PN Scanner Sensitivity” on page 87
- “Setting Average, Sweep, and Restart” on page 88
- “Adding a Marker” on page 90
- “Setting the Pass/Fail Limits” on page 92

Setting the Channel or Frequency Step

You can set the channel or frequency step so you can quickly increment to the next

1xEV-DO Analyzer and Over Air Test

Optional 1xEV-DO Tx and Over Air Analyzer Measurement Settings

channel or frequency using the up and down arrow buttons.

Step	Notes
1 [Freq/Chan/Time Ref]	
2 [Chan Step] or [Freq Step]	This choice depends on the [Units] mode you are using.
3 Enter the desired channel or frequency step using the numeric keypad.	
4 [Enter]	Notice (and verify) the number you entered below the Chan Step or Freq Step text on the corresponding button.

Setting the PN Offset

The PN Offset is a “short code” sequence that provides a unique identifier for each sector of each cell site. The PN Offsets are applied to the I and Q signals before modulation. PN Offsets are offset in time by 52.08 μ s and they repeat every 26.666 ms. This yields 512 unique short code sequences (0-511). The access terminal needs the PN Offset to decode information in the Pilot and MAC channels, which are transmitted by the access network.

If you have selected Auto PN Offset, the displayed PN Offset result corresponds to the PN Offset of the Pilot sequence with the highest power. If you have selected Manual PN Offset, the result displayed corresponds to your chosen PN Offset.

The number of slots over which the acquisition is made is determined by the Measurement Interval, which itself is determined by the Measurement Time. For more information, refer to “[Setting Measurement Time](#)” on page 83.

Step	Notes
1. [Freq/Chan/Time]	
2. [PN Offset]	Each time you press this softkey, the selected option changes.

Setting the PN Increment

The PN Increment allows you to choose the increment step for the PN Offset search when PN Offset is set to **Auto**. Typically the PN Increment is set to 1 when measuring 1xEV-DO transmitter performance while connected to the access network via RF cable.

The PN Increment field enables you to search based on a step size of your choice. If PN Increment = 1 (default), the search will step through PN values by one PN at a time. If PN Increment = 5, it will step through PN values 0, 5, 10, and so on. The Measured PN displayed will be a multiple of 5, even if the actual PN is not a multiple of 5. If you know that all access networks in the area have fixed increments, then set the PN Increment field to that increment value. If you don’t know, then use the default value of 1.

1xEV-DO Analyzer and Over Air Test

Optional 1xEV-DO Tx and Over Air Analyzer Measurement Settings

Step	Notes
1. [PN Inc]	
2. Enter the PN Increment using the numeric keypad.	The maximum value you can enter is 15.
3. [Enter]	Notice (and verify) that the number you entered for your chosen PN Increment number appears below the PN Inc text on the corresponding button.

Setting the Active Channel Threshold Level and Auto Threshold Level

The active channel threshold level is an advanced setting that can be set to indicate which code channels are considered active. Any code channels below this power level are considered inactive (or noise), and any code channels exceeding this power level are considered to be *potentially* active traffic channels. Any *potentially* active traffic channels, that is, any channels exceeding the Active Channel Threshold Level, must also have a low power variance over time to be considered truly active channels. A horizontal red line on the screen represents the threshold level. The test set can set this level automatically, or you can manually enter a value.

In Auto mode the threshold level moves as the noise fluctuates. The threshold level is set by the test set at an optimal offset above the average noise floor. If you choose Auto mode, you can alter the auto threshold offset. The recommended and default setting is 0 dB. A negative value moves the threshold lower (closer to the noise floor) and is a more aggressive setting that increases the likelihood of interpreting an inactive channel as active. A positive value moves the threshold higher (away from the noise floor) and is a more conservative setting that increases the likelihood of interpreting an active channel as inactive.

In Manual mode the threshold level is fixed and does not move as the noise fluctuates.

To Set the Active Channel Threshold Level:

Step	Notes
1 [Setup]	

Step	Notes
2 On [Thresh Lvl] select Auto or Manual .	Each time you press this softkey, the selected option changes. If you choose Manual, you must enter the threshold you want using the numeric keypad, then press [dB].
3 [Auto Thres Offset]	The default value is 0 dB. Optionally, you can enter a negative (more aggressive) or positive (more conservative) value, then press [dB].

Setting the Frequency/Time Reference

This key is used to specify the source of your frequency reference, or your frequency and time reference. The analyzer needs an accurate reference signal in order to make accurate measurements, and this is where you specify the source of this reference signal.

Step	Notes
1. [Fr/Time Ref]	The frequency/time reference form is displayed

1xEV-DO Analyzer and Over Air Test

Optional 1xEV-DO Tx and Over Air Analyzer Measurement Settings

Step	Notes
2. Select the frequency and time reference from the list using the up and down arrow buttons.	If the sky (and hence the satellites) is visible from the position of your analyzer, you can select GPS to get frequency and timing references from the GPS signal. The GPS antenna will need to be attached to the analyzer. If you connect to the access network's Even Second Clock, you will still get all the metrics, but you will not have an independent check that the access network has locked onto the GPS signal. Other options available are Internal Reference, External 10 MHz, and External 19.6608 MHz. These last three options only provide a frequency reference. They do not provide a time reference. If you use a pure frequency reference, you will not be able to see results for PN Offset or for Time Offset.
3. [Select]	

Setting Units

This key is used to toggle between **Frequency** and **Channel** for your measurements. That is, you can decide whether to specify (and measure) the frequency in Hertz, or to specify the Channel Number.

Step	Notes
1. [Units]	Each time you press this key, you toggle between Freq (measurements in Hertz) and Chan (measurements by Channel Number).

Setting the 1xEV-DO Transmitter Reference Level

You can set the 1xEV-DO transmitter reference level to display either relative power

(dB) or absolute power (dBm). The test set defaults to relative. The top graticule (horizontal line) represents the total power in the 1xEV-DO channel. The scale per division is set to 5 dB per division by default, but you can change it if you wish.

If the reference level is set to relative, the reference level represents the total power in the 1xEV-DO channel, and is displayed as 0.0 dB. If the reference level is set to absolute, the reference level displays the actual power (in dBm) for the particular time domain section relevant to the selected CDP type. For example, in pilot CDP mode, the absolute power level is measured only over the pilot burst region of the signal.

To Set the 1xEV-DO Transmitter Reference Level:

Step	Notes
1. [Level]	
2. On [Reference] select Abs or Rel .	Each time you press this softkey, the selected option changes.
3. [RF IN Loss]	
4. Enter the RF In Loss using the numeric keypad.	If you are using a cable and attenuator connected to the access network power amplifier, enter the combined cable and attenuator loss here. The RF In Loss can be obtained by measuring the Insertion Loss. See “Two Port Insertion Loss” on page 123. Note: If data had been previously entered in [RF IN Loss], that data will be lost and replaced by the value you enter here.
5. [dB]	

NOTE

The insertion loss of the test cable and high power attenuator must be accounted for to obtain accurate 1xEV-DO power measurements such as Pilot+MAC power. The insertion loss of the test cable/attenuator combination is accounted for as the RF In Loss, which is an offset applied by the test set to the power measurements.

Setting Measurement Time

The measurement time setting allows you to alter the speed at which measurements

1xEV-DO Analyzer and Over Air Test

Optional 1xEV-DO Tx and Over Air Analyzer Measurement Settings

are made. Three choices exist: Slow, Medium, and Fast. The test set defaults to Medium. Slow measurement time provides a more repeatable measurement at the expense of time, and is done by increasing the number of slots that are measured. Fast measurement time provides a quicker measurement at the expense of repeatability, and is done by decreasing the number of slots that are measured. Medium measurement time strikes a balance between measurement speed and repeatability.

Meas Time Setting	CDP & Rho Measurement Interval	Data Channel Modulation Measurement Interval	RF Metric Measurement Interval
Fast	3 full slots	3 full slots	16 full slots
Med	6 full slots	6 full slots	32 full slots
Slow	9 full slots	9 full slots	48 full slots

To Set the Measurement Time:

Step	Notes
1. [Setup]	
2. On [Meas Time] select Slow , Med , or Fast .	Each time you press this softkey, the selected option changes.

Setting Measurement Offset

The Measurement Offset setting determines the start of the measurement interval relative to the start of the pilot sequence frame, that is, relative to the start of PN 0. You can use the Measurement Offset parameter in conjunction with the Meas Time parameter to view a specific part of the frame.

To Set the Measurement Offset:

Step	Notes
1. [Setup]	

Step	Notes
2. Enter the Measurement Offset using the numeric keypad.	The maximum value you can enter is 15.

Setting the Slot Threshold Level

The Slot Threshold is a level, measured relative to the idle power, that determines whether a slot is idle or non-idle. When the power in a slot is greater than the Slot Threshold, that slot is determined to be non-idle. When the power in the slot is less than, or equal to, the Slot Threshold level, the slot is determined to be idle.

To Set the Slot Threshold Level:

Step	Notes
1. [Setup]	
2. Press [Slot Thresh] and enter the threshold value using the numeric keypad, the rotary knob, or the up and down arrows.	Specify the Slot Threshold level in dB. The minimum setting is –100 dB, and the maximum setting is 0 dB.
3. [dB]	

Setting the CDP Type

The CDP Type parameter is used to specify whether you are despreading Pilot, MAC 64, or MAC 128 codes when you are performing your measurement.

NOTE

Rev 0 of the 3GPP2 (Third Generation Partnership Project 2) standards requires 64 MAC codes to be despread; Rev A requires that 128 MAC codes are despread.

To Set the CDP Type:

Step	Notes
1. [Setup]	

1xEV-DO Analyzer and Over Air Test

Optional 1xEV-DO Tx and Over Air Analyzer Measurement Settings

Step	Notes
2. Press [CDP Type].	
3. Press the correct CDP Type key.	There are three CDP Type options available to you. These are Pilot, MAC 64, and MAC 128

Setting the Pilot Dominance Limit

Pilot Dominance is only relevant to Over the Air measurements. It does not apply to Transmitter measurements.

Pilot Dominance is the difference between the useful energy of the strongest pilot channel and the combined energy of the lower energy active pilot channels (expressed in dB). Ideally, this value should be very large (> 16 dB).

The E7495A/B test set includes up to nine lower energy active pilots in the pilot dominance calculation. In live testing of 1xEV-DO networks, however, it is unlikely that you will have as many as nine interfering pilots.

If the measured Pilot Dominance meets the limit you have set, the numeric result displayed in the OTA PN Scanner section of the screen is displayed in green. If the measured Pilot Dominance fails to meet the limit you have set, the result is displayed in red font, and *all metrics* displayed in the metrics portion of the screen will be displayed in gray. This is to indicate to you that the metrics you are seeing are unreliable because the Pilot Dominance limit has not been met.

NOTE

It is important to remember that the pilot dominance is always measured against the strongest signal. If you have specified your channel of interest manually, this channel might not necessarily be the strongest.

To Set the Pilot Dominance Limit:

Step	Notes
1. [Setup]	
2. Press [Plt Dom]	Specify the Pilot Dominance Limit level in dB. The minimum setting is 0.0 dB, and the maximum setting is 20 dB
3. [dB]	

Setting the Multipath Power Limit

Multipath Power is only relevant to Over the Air measurements. It does not apply to Transmitter measurements.

Multipath power is the amount of power, of the dominant pilot signal, that is dispersed outside the main correlation peak due to multipath echoes (expressed in dB). Ideally, this value should be very small (< 0.1 dB). **Multipath power** is the result of portions of the original broadcast signal arriving at the receiving antenna out of phase with the main power of the original signal. This can be caused by the signal being reflected off objects, such as buildings, or being refracted through the atmosphere differently from the main signal. These out of phase signals can cancel power from the main signal or appear as noise interference at the receiver.

If the measured Multipath Power meets the limit you have set, the numeric result displayed in the OTA PN Scanner section of the screen is displayed in green. If the measured Multipath Power fails to meet the limit you have set, the result is displayed in red font, and *all metrics* displayed in the metrics portion of the screen will be displayed in gray. This is to indicate to you that the metrics you are seeing are unreliable because the Multipath Power limit has not been met.

To Set the Multipath Power Limit:

Step	Notes
1. [Setup]	
2. Press [Mp Pwr].	Specify the Multipath Power Limit level in dB. The minimum setting is 0.0 dB, and the maximum setting is 2.0 dB
3. [dB]	

Setting the PN Scanner Sensitivity

PN Scanner Sensitivity determines the noise floor for the OTA PN Scanner. You can select from three sensitivity levels—Low, Medium, or High. Setting the sensitivity to High will result in a lower noise floor but will decrease the measurement speed. Setting the sensitivity to Low will result in a higher noise floor and decreased measurement speed.

PN Scanner Sensitivity is coupled to the OTA PN Scanner. If the OTA PN Scanner is Off, the PN Scanner Sensitivity is disabled; if OTA PN Scanner is On, PN Scanner Sensitivity is automatically enabled.

1xEV-DO Analyzer and Over Air Test

Optional 1xEV-DO Tx and Over Air Analyzer Measurement Settings

To Set the PN Scanner Sensitivity:

Step	Notes
1. [Setup]	
2. Press [PN Scanner Sensitivity].	Each time you press this softkey, the selected option changes. Select High, Medium, or Low.

Setting Average, Sweep, and Restart

Setting the Sweep

You can select either continuous or single sweep. Continuous sweep provides repeated, ongoing measurements. Single sweep performs a single measurement that is repeated only when you push the Single button.

To set sweep:

Step	Notes
1 [Average/Sweep]	
2 [Continuous] or [Single]	Each time you press one of these menu keys, the other menu key is automatically inactivated.

Setting Averaging

You can choose to have averaging On or Off, and to set the number of averages you want to take. When initialized, the Agilent E7495A/B defaults to running average:

- A running average computes the new result as the weighted sum of the last result and the new measurement. The last result is weighted by $(n - 1)/n$. The new result is weighted by $1/n$. Each new measurement produces a new result.

The reported averages for the following measurements will only be updated when idle slots are identified within the update interval. If no idle slots are identified, the average values reported will be from the previous update interval:

- Idle Power
- On/Off Ratio
- Noise Floor

The reported averages for the following measurements will only be updated when non-idle slots are identified within the update interval. If no non-idle slots are identified, the average values reported will be from the previous update interval:

- Non-idle Power

NOTE

The Idle Slots metric itself is always averaged even if averaging is switched **Off**. It represents the average of all the captures since the measurement was started. You can reset the Idle Slots metric by changing a parameter, or by using the **Restart** key.

When you switch averaging **On**, it is averaged in the same way as the other metrics.

To set averaging:

Step	Notes
1	Set the number of averages. a. [Average] b. Enter the number of averages using the numeric keypad. c. [Enter]
2	Set averaging On or Off. a. [Average/Sweep] b. [Averaging] c. [Off] or [On]

NOTE

These two steps can be performed in any order. However, if you turn averaging on and a large number of averages has previously been set, there may be a delay before you can change number of averages.

Using Restart

When you have averaging turned on, you can restart the averaging by pressing the Restart menu key. This restarts the averaging for running average in either Continuous or Single sweep mode.

1xEV-DO Analyzer and Over Air Test

Optional 1xEV-DO Tx and Over Air Analyzer Measurement Settings

To restart averaging:

Step	Notes
1 [Average/Sweep]	
2 [Restart]	This key is unavailable or has no effect when Sweep is set to Single. To restart a Single Sweep measurement, press [Single]. It is worth noting that there are some other events that automatically cause a restart. These events are: • If the analyzer identifies a change in PN Offset. • If you enter a new PN Offset value. • If the PN Offset State is changed to Auto or to Manual. • If you change the X-scale from MAC to Walsh Code, or from Walsh Code to MAC. • If you change the Measurement Time. • If you change the CDP Type.

Adding a Marker

Markers can be used on the CDP display to help you visually track up to four signals. Each marker has the following settings:

- **Type:** Provides three options, including:
 - **Off**
 - **Normal**, which places a diamond-shaped, colored marker, along with a number, 1-4, on the CDP display.
 - **Delta**, is associated with a normal marker. Therefore, a normal marker must exist prior to creating the delta marker. The delta marker displays the difference between the normal marker position and the delta marker position. Only one delta marker can be associated with a given normal marker. The normal marker must be active when Delta is selected.

- **Marker to Peak:** Places the active marker on the current greatest value of the CDP display.
- **Marker to Next Peak:** Places the active marker on the current second greatest value of the CDP display.

Step	Notes
1 [Marker]	
2 [Marker]	
3 [1], [2], [3], or [4]	
4 [Type]	
5 [Off], [Normal], or [Delta]	
6 Locate the marker relative to the code domain plots:	• [Marker to Peak] or • [Marker to Next Peak]

Setting the Pass/Fail Limits

- “To Set the Measurement Frequency Error Limits:” on page 95
- “Setting the Measurement Time Offset Limits” on page 96
- “Setting the Idle On/Off Ratio Limits” on page 97
- “Setting the Estimated Pilot Rho Lower Limits” on page 98
- “Setting the Estimated MAC Rho Lower Limit” on page 99
- “Setting the Maximum Inactive Channel Hight Limit” on page 100

You can use the Limits settings to set pass and fail limits for several measurements. With the Limits setting for a measurement set to Off, the measurement result is displayed in black in the Metrics portion of the screen.

Setting the limits On for your selected measurement can affect the way the result is displayed. If the measurement result falls within the bounds set by your limits settings, the numeric result is displayed in green, and “(P)” is displayed beside the result. If the measurement result falls outside the bounds set by your limits settings, the numeric result is displayed in red, and “(F)” is displayed beside the result.

In addition, the words “ALL PASS” (in green) or “FAILURE” (in red) are displayed in the bar at the bottom of the screen. This message refers to all limits which have been turned on. In other words, if *one or more* of the results for which limits have been set to On has failed, then the “FAILED” message is displayed; the “All PASS” message is displayed only if *all* measurements have passed their limits tests.

NOTE

No summary “All PASS” or “FAIL” messages are displayed if either of the Pilot Dominance or the Multipath Power limits are not being met.

If the OTA PN Scanner is turned On, and either the Pilot Dominance Limit is not being met, or the Multipath Power Limit is not being met, all metrics will be displayed in gray text. This indicates that because either one, or both, of Pilot Dominance and Multipath Power have not met their specified limits, all the results being displayed are inaccurate to an unknown degree, and are therefore unreliable. Ensure that your signal meets the Pilot Dominance Limit and the Multipath Power Limit to ensure you collect accurate results.

Regardless of your limits settings, no indication of a pass or a fail for individual measurements is given if **CDP and Metrics** are turned Off (see “[Metrics Provided by the 1xEV-DO Tx and Over Air Analyzer Measurement](#)” on page 104).

Similarly, the “ALL PASS” or “FAILURE” messages are not displayed if **CDP and Metrics** are switched Off. The single exception to this rule is the **Time Offset**

Limits (see below). If you have Time Offset Limits On, the “ALL PASS” or “FAILURE” messages are still displayed, even if **CDP and Metrics** are switched Off.

To reduce display clutter with all the available limit settings, no limit lines are displayed on this screen.

- **Frequency Error Limits:** Sets the high and low Frequency Error limits for the channel. Any measured frequency error that is outside of the set limits will result in a failure indication. The High limit is set by entering a positive number, and the Low limit is set by entering a negative number.
- **Time Offset Limits:** Sets the high and low time offset limits for the channel. Limits are set in microseconds. Any measured time offset value that is outside of the set limits will result in a failure indication.

NOTE

If you have Time Offset Limits On, the “ALL PASS” or “FAILURE” messages are still displayed, even if **CDP and Metrics** are switched Off.

- **On/Off Ratio Limits:** This refers to the Idle On/Off Power Ratio, which is ratio of the Pilot + MAC Power to the Idle Data Power. The result is blanked out when none of the acquisition slots are idle, that is, when Idle Slots shows 0%. The number of slots over which the acquisition is made is determined by the Update Interval, which itself is determined by the Meas Time setting.
- **Estimated Pilot Rho Limits:** Sets the lower limit for Pilot Rho (the upper limit is always 1.0, representing a perfect signal), and switches the Estimated Pilot Rho Limits On or Off. Any measured, estimated rho value that falls below the lower limit will result in a failure indication.

Pilot Rho is the measure of the modulation quality for a 1xEV-DO transmitter. A Rho value of 1.0 represents a perfect signal, indicating that all the power is being transmitted correctly. Estimated Pilot Rho is only measured over the 96 pilot chips contained within every half-slot.

- **Estimated MAC Rho Limits:** Sets the lower limit for MAC Rho (the upper limit is always 1.0, representing a perfect signal), and switches the Estimated Pilot Rho Limits On or Off. Any measured, estimated rho value that falls below the lower limit will result in a failure indication.

MAC Rho is the measure of the modulation quality for a 1xEV-DO transmitter. A Rho value of 1.0 represents a perfect signal, indicating that all the power is being transmitted correctly. Estimated MAC Rho is only measured over the 128 MAC chips contained within every half-slot.

- **Max Inactive Ch Limits:** This sets the high inactive channel power limits for

MAC channels when you are testing CDP Type MAC 64 or CDP Type MAC 128, and for the Pilot channel when you are testing CDP Type Pilot.

If you have set **Max Inactive Ch Limits** to be **Off**, the maximum inactive channel power is reported on the front panel with no indication of whether this is a good or a bad result. If you have set **Max Inactive Ch Limits** to be **On**, the measured inactive channel power level is tested against the High MAC Limit or the High Pilot Limit (depending on your specified CDP Type), and either “F” (for a fail), or “P” (for a pass) is also displayed against the measurement.

To Set the Measurement Frequency Error Limits:

Step	Notes
1 [Setup]	
2 [Limits]	
3 On [Freq Error Limits] select On or Off .	Enables you to toggle the measurement limits function On (active) and Off (inactive). • If set to On, the Frequency Error will change from black to red (fail), or to green (pass), and will indicate either “P” (pass) or “F” (fail). If the measured value exceeds either the upper limit or the lower limit, the words ‘ALL PASS’ in the bar at the bottom of the screen will change to ‘FAILURE’. • If set to Off, the channel freq/number value will be displayed in blue. The bar at the bottom of the screen will indicate measurement in progress.
4 Set the upper limit. a. [High Limit] b. Enter the number on the numeric keypad. c. [GHz], [MHz], [kHz], or [Hz]	
5 Set the lower limit. a. [Low Limit] b. Enter the number on the numeric keypad. c. [GHz], [MHz], [kHz], or [Hz]	

1xEV-DO Analyzer and Over Air Test

Optional 1xEV-DO Tx and Over Air Analyzer Measurement Settings

Setting the Measurement Time Offset Limits

Step	Notes
1 On [Time Offset Limits] select On or Off .	Enables you to toggle the measurement limits function On (active) and Off (inactive). • If set to On, the displayed time offset metrics will change from blue to red (fail), or to green (pass), and will indicate either “P” (pass) or “F” (fail). If the measured values exceed the upper limit or falls below the the lower limit, the words ‘ALL PASS’ in the bar at the bottom of the screen will change to ‘FAILURE’. • If set to Off, the time offset value will be displayed in blue. The bar at the bottom of the screen will indicate measurement in progress.
2 Set the upper limit. a. [High Limit] b. Enter the number on the numeric keypad. c. [μsec]	
3 Set the lower limit. a. [Low Limit] b. Enter the number on the numeric keypad. c. [μsec]	

Setting the Idle On/Off Ratio Limits

Step	Notes
1 Press [On/Off Ratio Limits].	
2 Press [Limits].	Enables you to toggle the Idle On/Off Ratio Limits function On (active) and Off (inactive). • If set to On, the displayed On/Off Ratio metric will change from blue to red (fail), or to green (pass), and will indicate either “P” (pass) or “F” (fail). If the measured value exceeds the lower limit, the words ‘ALL PASS’ in the bar at the bottom of the screen will change to ‘FAILURE’. • If set to Off, the Idle Power and Non Idle Power values will be displayed in blue. The bar at the bottom of the screen will indicate measurement in progress.
3 Set the lower limit. a. [Low Limit] b. Enter the number on the numeric keypad. c. [Enter]	Lower Limit range: –200 to 200 dB

1xEV-DO Analyzer and Over Air Test

Optional 1xEV-DO Tx and Over Air Analyzer Measurement Settings

Setting the Estimated Pilot Rho Lower Limits

Step	Notes
1 Press [Pilot Rho Limit].	
2 Press [Limits].	Enables you to toggle the Estimated Pilot Rho measurement's lower limit function On (active) and Off (inactive). • If set to On, the displayed Estimated Pilot Rho metrics will change from blue to red (fail), or to green (pass), and will indicate either "P" (pass) or "F" (fail). If the measured value falls below the lower limit, the words 'ALL PASS' in the bar at the bottom of the screen will change to 'FAILURE'. • If set to Off, the Estimated Pilot Rho value will be displayed in blue. The bar at the bottom of the screen will indicate measurement in progress.
3 Set the lower limit. a. [Low Limit] b. Enter the number on the numeric keypad. c. [Enter]	Lower Limit range: 0 to 1

Setting the Estimated MAC Rho Lower Limit

Step	Notes
1 Press [Est MAC Rho Limit].	
2 Press [Limits].	Enables you to toggle the Estimated MAC Rho measurement's lower limit function On (active) and Off (inactive). • If set to On, the displayed Estimated MAC Rho metrics will change from blue to red (fail), or to green (pass), and will indicate either "P" (pass) or "F" (fail). If the measured value falls below the lower limit, the words 'ALL PASS' in the bar at the bottom of the screen will change to 'FAILURE'. • If set to Off, the Estimated MAC Rho value will be displayed in blue. The bar at the bottom of the screen will indicate measurement in progress.
3 Set the lower limit. a. [Low Limit] b. Enter the number on the numeric keypad. c. [Enter]	Lower Limit range: 0 to 1

1xEV-DO Analyzer and Over Air Test

Optional 1xEV-DO Tx and Over Air Analyzer Measurement Settings

Setting the Maximum Inactive Channel Hight Limit

Step	Notes
1 Press [Max Inactive Ch Limit].	
2 Press [Limits].	Enables you to toggle the Maximum Inactive Channel measurement's high limit function On (active) and Off (inactive). • If set to On, the displayed Maximum Inactive Channel metrics will change from blue to red (fail), or to green (pass), and will indicate either "P" (pass) or "F" (fail). If the measured value falls above the high limit, the words 'ALL PASS' in the bar at the bottom of the screen will change to 'FAILURE'. • If set to Off, the Maximum Inactive Channel power value will be displayed in blue. The bar at the bottom of the screen will indicate measurement in progress.
3 Set the high MAC limit. a. [High MAC Limit] b. Enter the number on the numeric keypad. c. [Enter]	High Limit range: -200 to 200 dB
4 Set the high Pilot limit. a. [High Pilot Limit] b. Enter the number on the numeric keypad. c. [Enter]	High Limit range: -200 to 200 dB

Setting Up the Signal Generator

- “Using the RF OUT Loss field” on page 103

You can set up the signal generator while in the Spectrum Analyzer mode from the Setup menu. For more detailed information on the signal generator setup and operation, refer to“Using the Signal Generator” on page 402.

CAUTION

The maximum power for the RF In (Port 1) and RF Out/SWR (Port 2) ports is +20 dBm (100 mW). When using the 8481A/8482A or N8481A/N8482A with Option CFT Power Sensors, the maximum input power applied to the Power Sensor is +24 dBm (300 mW). When using the 8481D Power Sensor, the maximum input power is +20 dBm (100 mW). When directly coupled to a base station (BTS) or Access Network (AN), the test set can be damaged by excessive power applied to any of these three ports.

To prevent damage in most situations when you directly couple the test set to a base station, use the high power attenuator between the test set and the BTS.

NOTE

The lowest level the signal generator can go to is -95 dBm. In order to get a lower level, you must use an external attenuator. You can compensate for the attenuator in the RF Out Loss.

Step	Notes
1	[Setup]
2	[Sig Gen]
3	[Freq/Chan]
4	Enter the channel or frequency using the numeric keypad.
5	• For channel select [Rev] or [Fwd] • For frequency select [GHz], [MHz], [kHz], or [Hz],

1xEV-DO Analyzer and Over Air Test

Optional 1xEV-DO Tx and Over Air Analyzer Measurement Settings

Step	Notes
6 [Mod Format]	
7 Select the channel standard from the list using the up and down arrow buttons.	
8 [Select]	
9 Set the RF output amplitude	You may also enter a new value for amplitude by turning the rotary knob until the desired value is displayed or using the up and down arrow keys.
a. [Amplitude]	
b. Enter the amplitude value using the numeric keypad.	
c. [dBm].	
10 If you have previously stored RF Out Loss from an insertion loss measurement, go to the next step. Or Press [RF OUT Loss] to select On and enter the RF Out Loss value.	For information on the effects of the RF Out Loss function on the amplitude, refer to “Using the RF OUT Loss field,” below. Each time you press this softkey, the selected option changes.
11 Connect to the access network.	
12 On [Enable Sig Gen] select On .	Each time you press this softkey, the selected option changes.

NOTE

The characteristics of any 1xEV-DO signal generated are:

- RRI Active: RRI Bits: 1
- DRC Channel Relative Gain: +3 dB
- ACK Channel relative Gain: 0 dB
- Data Channel Relative Gain: +3.75 dB

- Data Channel: Active
 - Data Channel Data Rate: 9.6 kbps
 - Data Channel bit stream: PN15
 - I Mask: 3FF80000000
 - Q Mask: 3FF00000001
 - Filter Type: IS 95 Std
-

Using the RF OUT Loss field

The RF OUT Loss field is used when it is necessary to test the receiver sensitivity of a typical access network. The test set's source will typically go down to -95 dBm. In order to reach -113 dBm for sensitivity testing, you must use an external attenuator. The measured value of the attenuator and connecting cables are entered into this field. This value is then used when this field is set to **On**. When this field is set to **On**, the test set will set the RF generator level to the correct level offset by the external attenuator/cabling. When you set the RF Generator to -113 dBm (with the RF OUT Loss field turned **On** and the external attenuator/cabling loss value entered) the output at the end of the RF test cabling is -113 dBm.

Example: If you want to set the signal generator to -113 dBm, the attenuator and RF cabling measures 42.51 dB (measured with the 2 port insertion loss measurement screen prior to this test), the RF OUT Loss field is turned **On** (with the 42.51 dB loss value entered). The actual RF output of the signal generator is -70.49 dBm, the attenuator and RF cabling attenuated the signal to the desired level; so the RF signal at the end of the test cable/attenuator is -113 dBm. This also points out the importance of accurately measuring the loss of the attenuator and connecting cables.

Metrics Provided by the 1xEV-DO Tx and Over Air Analyzer Measurement

This section contains descriptions of the individual 1xEV-DO parameters in the metric display of the screen. For information on expected result values and possible causes of error if the expected results are not met, see [“Interpreting the Display” on page 75](#).

You can switch the display of the metric results Off by pressing [Display], and then setting [CDP and Metrics] to Off. Only the Freq, the PN Offset, and the Time Offset metrics will be displayed. All other metrics will appear as dashes.

If the OTA PN Scanner is turned On, and either the measured Pilot Dominance is not within its limits, or the measured Multipath Power is not within its limits, all metrics will be displayed in gray text. This indicates that because either one, or both, of Pilot Dominance and Multipath Power have not met their specified limits, all the results being displayed are inaccurate to an unknown degree, and may therefore be unreliable. Ensure that your signal meets the Pilot Dominance Limit and the Multipath Power Limit to ensure you collect accurate results.

Frequency

Frequency is the center frequency you entered.

Frequency Error

Frequency error is the frequency difference between your access network’s actual center frequency and the frequency (or channel) you entered. With a valid time reference (GPS or ESC) this will have a range of $\pm 25\text{KHz}$ about the selected center frequency. For a pure frequency reference it is limited to $\pm 500\text{Hz}$.

PN Offset

The PN Offset is a “short code” sequence that provides a unique identifier for each sector of each cell site. The PN Offsets are applied to the I and Q signals before modulation. PN Offsets are offset in time by $52.08\text{ }\mu\text{s}$ and they repeat every 26.666 ms. This yields 512 unique short code sequences (0-511). The access terminal needs the PN Offset to decode information in the Pilot channel and the MAC channel, both of which are transmitted by the access network.

Time Offset

The Time Offset compares the PN Offset timing with the overall system time. This measurement checks the start of the PN offset in comparison to the GPS signal, or to the Even Second Clock signal. For example, PN Offset 0 should repeat exactly on the rising edge of the Timing Reference. PN Offset 1 should repeat 52.08 μ s after the rising edge of the Timing Reference, and so forth. Any deviation in time from that event is reported as a Time Offset.

Non Idle Power

The Non Idle Power is a measurement of the average power during an entire slot when the acquired slot is non-idle. When all of the acquired slots are idle (that is, when Idle Slots shows 100%), the measurement result is blanked out. The number of slots over which the acquisition is made is determined by the Update Interval, which itself is determined by the Meas Time setting.

Pilot + MAC Power

The Pilot + MAC Power is a measurement of the average power during the Pilot and MAC periods. When all of the acquired slots are idle (that is, when Idle Slots shows 100%), the measurement result is blanked out. The number of slots over which the acquisition is made is determined by the Update Interval, which itself is determined by the Meas Time setting.

On/Off Ratio

This refers to the Idle On/Off Power Ratio, which is ratio of the Pilot + MAC Power to the Idle Data Power. The result is blanked out when none of the acquisition slots are idle, that is, when Idle Slots shows 0%. The number of slots over which the acquisition is made is determined by the Update Interval, which itself is determined by the Meas Time setting.

Idle Data Power

The Idle Data Power is a measurement of the average power during the data period of an idle slot. When none of the acquired slots are idle (that is, when Idle Slots shows 0%), the measurement result is blanked out. The number of slots over which the acquisition is made is determined by the Update Interval, which itself is determined by the Meas Time setting.

Idle Slots

The Idle Slots measurement shows as a percentage, the number of idle slots out of the total number of slots. Exactly how this percentage figure is worked out depends on the Averaging State you have selected.

Metrics Provided by the 1xEV-DO Tx and Over Air Analyzer Measurement

If averaging is **Off**, the percentage of idle slots since the last restart is reported.

If averaging is **Off** and your analyzer is in **Single** mode, the percentage of slots within the update interval is reported.

If averaging is **On**, the result displayed is the percentage of idle slots within 'n' capture intervals, where 'n' is the current average number. Once your desired number of averages has been reached, the result reported is the percentage of idle slots within the last 'n' measurement capture intervals.

Est Pilot Rho

Pilot Rho is the measure of the modulation quality for a 1xEV-DO transmitter. This measurement is analogous to measuring FM accuracy and distortion in an AMPS network or EVM in a TDMA system. A Rho value of 1.0 represents a perfect signal, indicating that all of the power is being transmitted correctly. Pilot Rho is only measured over the 96 pilot chips contained within every half-slot. The measurement result is blanked out when the code domain measurement does not synchronize to the received input signal. The number of slots over which the acquisition is made is determined by the Capture Interval, which itself is determined by the Meas Time setting.

Est MAC Rho

MAC Rho is the measure of the modulation quality for a 1xEV-DO transmitter. This measurement is analogous to measuring FM accuracy and distortion in an AMPS network or EVM in a TDMA system. A Rho value of 1.0 represents a perfect signal, indicating that all of the power is being transmitted correctly. MAC Rho is only measured over the 128 MAC chips contained within every half-slot. The measurement result is blanked out when the code domain measurement does not synchronize to the received input signal. The number of slots over which the acquisition is made is determined by the Capture Interval, which itself is determined by the Meas Time setting.

Max Inactive Ch

This is a measure of the Maximum Inactive Channel Power. The reported result is the maximum power in the separate I and Q channels when the MAC Channel Walsh Codes are inactive, relative to the total power in both the active and the inactive channels. The number of slots over which the acquisition is made is determined by the Update Interval, which itself is determined by the Meas Time setting.

The result reported is for the currently selected CDP type, for example, if the selected CDP type is Pilot, this will report the highest power level detected across the inactive channels within the 32 pilot codes.

Noise Floor

The Noise Floor is the average inactive Walsh code power level detected in the combined I and Q channels, relative to the total power in both the active and the inactive channels. The number of slots over which the acquisition is made is determined by the Update Interval, which itself is determined by the Meas Time setting.

The result reported is for the currently selected CDP type, for example, if the selected CDP type is Pilot, this will report the average power level detected across the inactive channels within the 32 pilot codes.

NOTE

Take care that you do not confuse Noise Floor with Idle Data Power. Idle Data Power is the power present in the data region of the Idle slots. Noise Floor is the average power present in the inactive Walsh Code channels.

Data Modulation Type

The Data Channel Modulation measurement returns the highest modulation detected within the measurement interval. There are three types of modulation, and hence four possible measurement results: QPSK, 8PSK, and 16QAM, and blank when no

Metrics Provided by the 1xEV-DO Tx and Over Air Analyzer Measurement

modulation is detected. QPSK is the lowest type of modulation, 8PSK is the next higher, and the highest modulation type is 16QAM. Only if all the slots within the measurement interval are idle will the result be blanked out. The number of slots over which the acquisition is made is determined by the capture interval, which itself is determined by the Meas Time setting.

Interpretation of 1xEV-DO Tx and Over Air Analyzer Measurement Results

This section contains expected result values and possible causes of error if the expected results are not met.

Frequency Error

The standards specify very tight Frequency Error performance. In the PCS bands, the 0.05 parts-per-million specification translates to only 99 Hz at a carrier frequency of 1980 MHz or 40 Hz at 850 MHz cellular frequencies. Frequency Error shows up as uncorrelated power that adds to the noise floor or shows up in other Walsh codes.

If a particular site loses its reference to GPS time, its reference signals will begin to drift over time. Access Terminals already using the site can remain on the air because they derive their timing from the signals transmitted by the access network. However, access terminals using other sites/sectors may be prevented from using the site because they are confused by the error in frequency. This creates what is known as the “island cell effect”. By itself, the cell is still functional. To the rest of the system, it's inaccessible.

This island cell effect can be caused by a failure in the site's GPS receiver and timebase distribution network. Using the test set's Internal GPS receiver provides an independent time reference that will allow you to determine if this cell site is out of sync with the rest of the network.

PN Offset

Verify that the PN Offset is correct. If you are in Manual mode, the PN Offset will display the value you entered. Make sure the Time Offset is small (less than 3 μ s). If the Time Offset is greater than expected, see the section on Time Offset below. If you are in Auto mode, the test set will tune to the PN Offset with the smallest amount of Time Offset. If an incorrect PN Offset is displayed, the Time Offset will likely be very small.

Time Offset

Time Offset is a measure of the time of the arrival of the pilot signal from the access network with respect to GPS time. It is expressed in microseconds.

The 1xEV-DO standards specify a maximum time offset of 10 μ s. Generally 5 μ s is a recommended maximum, although many access network manufacturers specify

Interpretation of 1xEV-DO Tx and Over Air Analyzer Measurement Results

that timing must be within 3 μ s. If the Time Offset is large enough, an “island cell” can occur. The “island cell” effect was mentioned already when discussing Frequency Error.

An access terminal moving outward toward the limit of its cell will need to acquire the adjacent cell in order to hand off. If the time offset of the target cell is too far from that of the current site, the handoff may not happen.

The dependence of the access terminal on correct system time limits the physical distance to a target cell's antenna. Each PN Offset is 52.08 μ s; if the propagation delay is too long, the received PN Offset may be different from the value designated on the Sync channel. This difference can confuse the access terminal, causing the handoff to fail.

Another cause of timing error is a bad GPS receiver or timing distribution network within the access network. To test your access network's GPS and timing distribution system, you can use the internal GPS receiver to generate an accurate timing reference for the test set to use while performing access network tests.

Non Idle Power

When making channel power measurements, make sure you have accounted for the loss of the test cable and high power attenuator you are using. If you do not know the loss of your test cable and high power attenuator configuration, perform an insertion loss measurement and enter the insertion loss as the RF In Loss value. For more information see “[Two Port Insertion Loss](#)” on page 123.

If the channel power is lower than expected, verify you have a good connection to the RF output of the access network. Also, verify the cable you are using to connect to the access network is not faulty. A low channel power may also indicate a bad power amplifier.

Inaccurate channel power (high or low) may indicate an incorrect power setting at the access network.

Pilot + MAC Power

The Pilot + MAC Power is a measurement of the average power during the Pilot and MAC periods. This is when the transmitter is only sending overhead messages in a burst mode and is not transmitting any data to users. When the Idle slot activity goes to zero (no idle slots), the Pilot + MAC and a couple of the other measurements blank (as they have no meaning when all slots are active).

On/Off Ratio

The On/Off Ratio is a ratio of the Pilot + MAC Power to the Idle Data Power. The

recommended minimum On/Off Ratio for idle slots was set to 7dB in the standard to allow Access Network manufacturers to protect the power amplifiers from large output power swings between On portions of the signal during bursts and Off portions of the signal in idle slots. Each manufacture may set this value to different levels. This parameter is loaded into the radios from the Switch.

When the Idle slot activity goes to zero (no idle slots), the On/Off Ratio and a couple of the other measurements blank (as they have no meaning when all slots are active).

Idle Data Pwr

This is the average power level in the data portion, averaged across all idle slots in the acquired capture, and can contribute to the overall Noise Floor in the system. A high reading here combined with a high reading in the CDP Noise Floor can indicate a problem with the I/Q Modulator or indicates the amplifier is being overdriven. When the Idle slot activity goes to zero (no idle slots), the Idle Data Power and a couple of the other measurements blank (as they have no meaning when all slots are active).

Idle Slots

This reading is a measure of the number of idle slots, measured as a percentage of the total number of slots available. This reading can be used as a flag to add more capacity at the site as the reading approaches 0%.

Est Pilot Rho

The 1xEV-DO access network standard specifies that Rho must be greater than 0.912. Typical values for a healthy access network are greater than 0.94.

Rho failures can indicate problems in:

- Compression in linear amplifiers
- Magnitude and phase errors in the IQ modulator
- Phase non-linearity (group delay)
- Spurious signals in the transmission path
- Carrier feedthrough

Because the uncorrelated power appears as interference to the access terminals, poor Rho performance will affect the sector's capacity. The added interference can require that the signal on traffic channels be raised to overcome the interference. This may, in turn, be seen as further interference. At some point, the site will have to shed calls in order to supply the remaining calls with enough signal versus the interference in the system.

Interpretation of 1xEV-DO Tx and Over Air Analyzer Measurement Results

Est MAC Rho

The 1xEV-DO access network standard specifies that Rho must be greater than 0.912. Typical values for a healthy access network are greater than 0.94.

Rho failures can indicate problems in:

- Compression in linear amplifiers
- Magnitude and phase errors in the IQ modulator
- Phase non-linearity (group delay)
- Spurious signals in the transmission path
- Carrier feedthrough

Because the uncorrelated power appears as interference to the access terminals, poor Rho performance will affect the sector's capacity. The added interference can require that the signal on traffic channels be raised to overcome the interference. This may, in turn, be seen as further interference. At some point, the site will have to shed calls in order to supply the remaining calls with enough signal versus the interference in the system.

Max Inactive Ch

According to the 1xEV-DO standard, the CDP in all inactive channels must be at least 27 dB below the total MAC power.

If this value exceeds 27 dBc, compression may be occurring in the base station power amplifier or there may be errors in the base station IQ modulator.

Noise Floor

The light gray bars on the CDP trace display are noise. While they appear to be channels on the trace and are referred to as noise channels, they are not real 1xEVDO channels. They represent the noise energy in the inactive displayed code channel. The average level of the top of these noise bars represents the CDP Trace noise floor, and is the figure reported here.

The noise floor level can be influenced by many conditions one of which can be the existence of high power from another CDMA base station or such things as loose RF connections. It is desirable to reduce the noise floor as much as possible before making measurements. If you have a strong signal on the metrics display but still show a high noise floor, then a problem may exist in the base station.

Data Modulation Type

The Data Modulation Type measurement returns the highest modulation detected

1xEV-DO Analyzer and Over Air Test

Interpretation of 1xEV-DO Tx and Over Air Analyzer Measurement Results

within the measurement interval. There are three types of modulation, and hence four possible measurement results: QPSK, 8PSK, and 16QAM, and blank when no modulation is detected. QPSK is the lowest type of modulation, 8PSK is the next higher, and the highest modulation type is 16QAM. Only if all the slots within the measurement interval are idle will the result be blanked out. The number of slots over which the acquisition is made is determined by the Update Interval, which itself is determined by the Meas Time setting.

A reading of 16QAM indicates high throughput for the access network. If only QPSK is shown over time, then there may be a problem in the transmit path of the access network.

Customizing Your Display

You can change the way your measurement results are displayed on your analyzer.

The MAC Code Domain Plot in the graphical area of the display can be switched between displaying MAC Code Power sorted by MAC index, and displaying MAC Code Power sorted by Walsh Code.

The same information, sorted either by MAC index or by Walsh Code, can itself be displayed in two different ways. The CDP plot (the default display) can be switched to show a **Codogram**, which adds the third dimension of time to the display. That is, you can view code domain power (sorted by either MAC Index or be Walsh Code) over time.

Sorting by MAC Index or by Walsh Code

The default view of a CDP plot is sorted by MAC Index. This can be changed to a view sorted by Walsh Code. The order used for Walsh Code display is Hadamard.

Step	Notes
1 Press [Display]	
2 Press [MAC CDP X Axis]	Each time you press this menu key, the selected option changes. Select either MAC or Walsh as your preferred display option.

Converting Between MAC Index and Walsh Code

Converting From	Converting To
Even numbered MAC Indexes	Walsh Code = $\text{MAC Index} / 2$
Odd numbered MAC Indexes	Walsh Code = $((\text{MAC Index} - 1) / 2) + 32$
Walsh Codes 0 – 31	MAC Index = $\text{Walsh Code} * 2$
Walsh Codes 32 – 64	MAC Index = $((\text{Walsh Code} - 32) * 2) + 1$

Colors Used on the MAC Code Domain CDP Display

MAC Index	Walsh Code	Color	Notes
0	0	Gray if inactive Light brown if active	Reserved channel/code, and should always be inactive. If these are light brown, then channel type is "Unknown".
1	32	Gray if inactive Light brown if active	Reserved channel/code, and should always be inactive. If these are light brown, then channel type is "Unknown".
2	1	Gray if inactive Light brown if active	Reserved channel/code, and should always be inactive. If these are light brown, then channel type is "Unknown".
3	33	Gray if inactive Light brown if active	Reserved channel/code, and should always be inactive. If these are light brown, then channel type is "Unknown".
4	2	Light blue	Reverse activity. Should always be active.
>4	3 – 31 and 34 – 63 for CDP Type MAC 64. 3 – 31 and 34 – 127 for CDP Type MAC 128.	Gray if inactive (or "noise") Orange if active	Orange indicates active MAC RPC channels. Active channels display the Walsh Code/MAC Index below the graticule in yellow text.

Colors Used on the Pilot Code Domain CDP Display

Walsh Code	Color	Notes
0	Always red	Pilot
1 – 31	Always gray (inactive)	Noise

Showing or Hiding the OTA PN Scanner

The presence of the OTA PN Scanner at the top of your screen is the main distinguishing feature of an Over the Air measurement. If, from the main (Mode) screen, you selected [Tx Analyzer], then [1xEV-DO Analyzer], the OTA PN Scanner will usually be switched Off; if, from the main (Mode) screen, you selected [Over Air], then [1xEV-DO Over Air], the OTA PN Scanner will usually be switched On.

Step	Notes
1 Press [Display]	
2 Press [OTA PN Scanner]	Each time you press this key, the codogram state switches between On and Off .

When the OTA PN Scanner is turned **Off**, there is more space on the screen to display the **Code Domain Plot**, so the finer details of the Code Domain Plot are easier to see.

When you have the **OTA PN Scanner** display **On**, you also have the option of turning the **CDP and Metrics Off**. This leaves more space on the screen to display the OTA PN Scanner, so the finer details of the OTA PN Scanner measurement are easier to see. At the same time, most of the metrics are turned off so they appear as dashes on the metrics portion of the screen. Only the **Frequency**, the **PN Offset**, and the **Time Offset** are still computed and displayed on the screen. As the test instrument no longer has to compute the metrics results or the CDP plot, the update rate of the OTA PN Scanner is improved.

Codogram Display

Switching to the **Codogram** view adds the third dimension of time to the display. That is, you can view code domain power (sorted by either MAC Index or be Walsh Code) over time. MAC Indexes or Walsh Codes are displayed against the horizontal X-axis, time is represented on the vertical Y-axis, and signal strength is indicated by the color - low power signals are represented by the cooler, blue end of the spectrum, and high power signals by the warmer, red end of the spectrum.

The codogram plot rises over time until it fills the graphical section of the display. Your most recent data appears at the bottom of the display, and your oldest data (several minutes ago to several hours ago, depending on your settings) appears at the top of the display. In this way, you can clearly see the changes in power that occur over a period of time.

The **Update Interval** is the interval, measured in whole seconds, between successive records displayed on the codogram. In other words, if you set the update interval to 5 seconds, the codogram display will not update until the after the first complete measurement following a gap of five seconds. Alternatively, you can set the update interval to provide the maximum data collection speed by pressing [Max Speed], or by setting the update interval to 0 (zero) seconds.

NOTE

It is not always possible for the analyzer to match the update interval you specify. It is possible, for example, to set your update interval to zero seconds (the maximum speed), and then to find that the analyzer can not update any faster than once every two seconds.

You can clear your screen and start a fresh codogram display by pressing the Reset Codogram key. Changing the units of the X-axis (for example, by changing CDP Type, or by switching from MAC to Walsh Code) also clears and resets the codogram.

Performing a Codogram Measurement

Step	Notes
1 [Display]	
2 [Codogram]	This displays the menu that controls the appearance and behavior of the codogram display.
3 On [Codogram] select On or Off .	Each time you press this key, the codogram state switches between On and Off . When you set [Codogram] to On, [Reset Codogram], [Update Interval] and [Palette] become active.
4 [Reset Codogram]	This restarts the data capture for the Codogram. You may see the screen freeze for a few seconds before the display starts plotting data again.
5 If desired set the update interval: a. [Update Interval] b. Enter the interval number of seconds using the numeric keypad. c. Select [sec] or [Max Speed].	Allows you to set the update interval to 0, 1, or more seconds. Alternatively, you may set it to automatically determine the update interval that provides the maximum data collection speed. If you need to return to the automatically determined maximum capture speed, you must press [Update Interval] followed by a numeric keypad key to access [Max Speed].
6 If desired set the display color: a. [Palette] b. Select [Full Color] or [Grayscale].	The color/grayscale top and bottom mappings are determined by the Ref Level and Scale/Div settings. To change the mapping, go to [Level/Location] and change [Ref Level] and [Scale/Div].

1xEV-DO Analyzer and Over Air Test

Performing a Codogram Measurement

NOTE

The key labelled “Update Interval” was labelled “Capture Interval” in earlier versions of the software (A.04.00 or earlier). The way the key works has not changed. Only the key label has changed to clarify what the key does.

4

Two Port Insertion Loss

“Measuring Two Port Insertion Loss” on page 124

“Performing a Basic Two Port Insertion Loss Measurement (Normalize)” on page 125

“Displaying Location Information Using GPS” on page 126

“Setting Average, Sweep, and Restart” on page 127

“Adding a Marker” on page 130

“Measuring Two Port Insertion Loss for Spectrum Analyzer, Channel Scanner, 1xEV-DO Analyzer, CDMA Analyzer, and Signal Generator (RF In Loss and RF Out Loss)” on page 131

“Measuring Insertion Loss for Power Meter (Option 600 - Power Meter Only)” on page 134

“Determining The Lowest (Worst) Insertion Loss and Its Frequency” on page 135

“Determining the Highest (Best) Insertion Loss and Its Frequency” on page 136

“Using the Delta Marker to Measure a Difference in Insertion Loss or Frequency” on page 136

“Activating Interference Rejection” on page 136

“Clearing Normalization” on page 137

“Setting Source Level” on page 137

“Optimizing Dynamic Range” on page 139

“Setting the Pass/Fail Limits” on page 140

Two Port Insertion Loss

Measuring Two Port Insertion Loss

This test measures the loss of a cable or other device over a specified frequency range.

Insertion loss measurements are important in accurately quantifying the amount of loss a signal will incur as it passes through a cable, attenuator, or any other device. In S-parameter terms, insertion loss is referred to as an S_{21} measurement. “S” stands for scattering.

NOTE

Any cable added to your measurement configuration will add some loss that must be accounted for. For example, a jumper cable placed between the test set and the antenna feedline (or other device) you are connecting will add some loss to the measurement.

If you add a jumper cable to your measurement configuration, you must normalize out the loss associated with the cable at your current measurement frequency. Otherwise, your measurement results will be inaccurate, and you will probably adjust transmit parameters in error.

Insertion loss measurements have a variety of uses. However, the example procedures focus on two kinds of two-port insertion loss measurements that you need as preparation for other test set measurements:

- Measuring the 3 meter (10 ft) test cable, 60 cm (2 ft) normalization cable, and high power attenuator provides values you can store as RF In Loss and RF Out Loss.
 - RF In Loss is used with the Spectrum Analyzer, Channel Scanner, cdma Analyzer, cdma2000 analyzer, 1x-EVDO Analyzer, and the GSM Analyzer.
 - RF Out Loss is used with the Signal Generator.
 - RF Out Loss is the measured loss of cables and other devices between the E7495A/B RF Out (Port 1) and the receiver under test.
- Measuring the high power attenuator and 60 cm (2 ft) normalization cable provides stored Power Meter Loss (PM loss), which is needed for using the Power Meter.
 - PM loss is the measured loss of cables and other devices between the signal source and the power sensor.

Normalizing and Performing a Basic Two Port Insertion Loss Measurement

Before you perform a two port insertion loss measurement, you must first normalize the measured values for insertion loss by compensating for the loss associated with the devices (adapters, cables) that connect the E7495A/B Base Station Test Set to the device or assembly being tested. Otherwise, the loss introduced by these connecting devices is added to the loss of the device under test.


Performing a Basic Two Port Insertion Loss Measurement (Normalize)

Step	Notes
1 Mode	
2 [Antenna/Cable]	
3 [Two Port Insertion Loss]	The insertion loss measurement takes a few seconds to load.
4 [Start Freq]	
5 Enter the start frequency of interest using the numeric keypad.	
6 [Hz], [kHz], [MHz], or [GHz]	
7 [Stop Freq]	
8 Enter the stop frequency of interest using the numeric keypad.	The stop frequency should be larger than the start frequency.
9 [Hz], [kHz], [MHz], or [GHz]	
10 [Normalize]	Follow the instructions of the Normalize Wizard.
11 Connect the device whose insertion loss you want to measure.	

Two Port Insertion Loss
Measuring Two Port Insertion Loss

Figure 4-1

Two Port Insertion Loss Measurement Results, After Normalization.



Displaying Location Information Using GPS

If you are making a Two Port Insertion Loss measurement, you may use GPS Location data to verify your location. For additional information on the GPS Data function, refer to “[Displaying GPS Location Data](#)” on page 462.

To Display GPS Location Information:

Step	Notes
1	[Level/Location]

Step	Notes
2 On [Show GPS Location] select On .	Displays GPS satellite location information. Uses the internal GPS to capture the location of a measurement. The GPS information can be used to return to the same location. The Time Ref (Freq/Chan/Time Ref mode) button must be set to Internal GPS for this function to be active. Information logged includes latitude, altitude (feet/meters), and the number of satellites tracked. Each time you press this softkey, the selected option changes.
3 Highlight [On]	Toggle to [On] to display GPS satellite location information. Toggle to [Off] to remove the location information

NOTE

If you prefer to have an electronic copy of the location information, see [“Saving Data” on page 469](#).

Setting Average, Sweep, and Restart

Setting the Sweep

You can select either continuous or single sweep. Continuous sweep provides repeated, ongoing measurements. Single sweep performs a single measurement that is repeated only when you push the Single button.

To Set Sweep:

Step	Notes
1 [Average/Sweep]	
2 [Continuous] or [Single]	Each time you press this softkey, the selected option changes.

Setting Averaging

You can choose to have Averaging On or Off, and to set the number of averages you

Two Port Insertion Loss

Measuring Two Port Insertion Loss

want to take if Averaging is On. Averaging only applies to the data, not to the trace. You can select from the following types of averaging:

- **Off:** Disables averaging.
- **Running:** Computes the new result as the weighted sum of the last result and the new measurement. The last result is weighted by $(n - 1)/n$. The new result is weighted by $1/n$. Each new measurement produces a new result.
- **Max Hold:** Is not an average, but on a point by point basis, displays the maximum amplitude for the given frequency since Max Hold was turned on. It is updated when a new maximum occurs.
- **Group Average:** Makes the requested number of measurements, averages the measurement data, and displays the average as a single result trace. Measurement time will vary based on the requested number of averages, and can take several minutes for very large number of averages.
- **Group Max Average:** Makes the requested number of measurements before returning a single trace result. This trace is the maximum value seen at each trace point over the requested number of averages (measurements).

To Set Averaging:

Step	Notes
1	Set the number of averages. a. [Average] b. Enter the number of averages using the numeric keypad. c. [Enter]
2	Select the type of averaging you want to apply. a. [Average/Sweep] b. [Averaging] c. [Off], [Running Average], [Max Hold], [Group Average], or [Group Max Average]

NOTE These two steps can be performed in any order. However, if you turn averaging on and a large number of averages has previously been set, there may be a delay before you can change number of averages.

Setting Restart

When you have averaging turned **On** and you are in **Continuous** Sweep mode, you can restart the averaging by pressing the Restart menu key. The Restart key has no effect if you are in **Single** sweep mode.

NOTE Pressing the Restart key has no effect on the average count when performing Group Average or Group Max.

To restart averaging:

Step		Notes
1	[Average/Sweep]	
2	[Restart]	This key is unavailable or has no effect when Sweep is set to Single . To restart a Single Sweep measurement, press [Single].

Two Port Insertion Loss

Measuring Two Port Insertion Loss

Adding a Marker

Markers can be used on traces to help you visually track up to four signals. Each marker has the following settings:

- **Type:** Provides three options, including:
 - **Off**
 - **Normal:** Places a diamond-shaped, colored marker, along with a number, 1-4, on the trace.
 - **Delta:** This is associated with a normal marker. Therefore, a normal marker must exist prior to creating the delta marker. The delta marker displays the difference between the normal marker position and the delta marker position. Only one delta marker can be associated with a given normal marker. The normal marker must be active when Delta is selected.
- **Marker to Peak:** Places the active marker on the current greatest value of the trace.
- **Marker to Next Peak:** Places the active marker on the current second greatest value of the trace.
- **Marker to Min:** Places the active marker on the current lowest value of the trace.
- **Marker to Next Min:** Places the active marker on the current second lowest value of the trace.


To Add a Marker to a Trace:

Step	Notes
1 [Marker]	
2 [Marker]	
3 [1], [2], [3], or [4]	
4 [Type]	
5 [Off], [Normal], or [Delta]	
6	Locate the marker relative to the trace: [Marker to Peak], [Marker to Next Peak], [Marker to Min], or [Marker to Next Min]

Measuring Two Port Insertion Loss for Spectrum Analyzer, Channel Scanner, 1xEV-DO Analyzer, CDMA Analyzer, and Signal Generator (RF In Loss and RF Out Loss)

When you perform spectrum analysis, TX analysis (CDMA, W-CDMA, 1xEVDO, and so forth), or measure signal generator outputs, you can measure accurately, and store, the device loss values. These RF In and RF Out Loss values can be used later in the measurements. This gives greater accuracy in your measurement results as you can use these stored RF In and RF Out values instead of entering approximate values.

Step	Notes
1	Connect the cable or device. Connect the 3 meter (10 ft) cable, high power attenuator, and other 60 cm (2 ft) cable (not used for normalization) between the two 10 dB pads that were used for normalization.




Two Port Insertion Loss

Measuring Two Port Insertion Loss

Step	Notes
2 [Level]	If the insertion loss trace is not visible, you can change the reference level or use Autoscale to have the test set select a reference level for you. • Press [Autoscale] to display the trace so that it fills the screen from top to bottom. • Press [Ref Level] and then enter the appropriate value and press [dB] to manually select a level for the trace. • Press [Scale/Div] and then enter the appropriate value and press [dB] to manually select the number of dBs per line on the graticule.
3 [Store As]	
4 [Store As RF IN Loss]	Saves the RF In Loss value for use in later measurements.
5 [Store As RF OUT Loss]	Saves the RF Out Loss value for use in later measurements.

Figure 4-2

Two Port Insertion Loss Measurement Results, Including Effects of 60 cm (2 ft) Cable, 3 meter (10 ft) Cable, and High Power Attenuator.



Two Port Insertion Loss
Measuring Two Port Insertion Loss


Measuring Insertion Loss for Power Meter (Option 600 - Power Meter Only)

NOTE

This measurement is only available if you have *Option 600 - Power Meter*, and requires an 8482A/8481A or N8481A/N8482A with Option CFT power sensor.

Before making a power measurement, you need to store a PM Loss value that will compensate for the loss of the devices you use to connect to the transmitter.

Step	Notes
1	Connect the cable or device. Connect the high power attenuator and remaining 60 cm (2 ft) cable (not the cable used for normalization) between the two 10 dB pads that were used for normalization.



Two Port Insertion Loss

Measuring Two Port Insertion Loss

Step	Notes
2 [Level/Location]	If the insertion loss trace is not visible, you can change the reference level or use Autoscale to have the test set select a reference level for you. - Press [Autoscale] to display the trace so that it fills the screen from top to bottom. - Press [Ref Level] and then enter the appropriate value and press [dB] to manually select a level for the trace. - Press [Scale/Div] and then enter the appropriate value and press [dB] to manually select the number of dBs per line on the graticule.
3 [Store As]	
4 [Store As PM Loss]	Saves the loss for use with the power measurement. This PM Loss figure only remains valid for as long as you continue to use the same “characterized assembly”, that is, the same cables and pads. If <i>Option 600 - Power Meter</i> is not installed, [Store as PM Loss] and [PM Loss] are unavailable.

Determining The Lowest (Worst) Insertion Loss and Its Frequency

Step	Notes
1 [Marker]	
2 On [Type] select Normal .	Each time you press this softkey, the selected option changes.
3 [Marker to Peak]	Places a marker on the highest peak. The marker value is displayed in the upper right.

Two Port Insertion Loss

Measuring Two Port Insertion Loss

Determining the Highest (Best) Insertion Loss and Its Frequency

Step	Notes
1 [Marker]	
2 On [Type] select Normal .	Each time you press this softkey, the selected option changes.
3 [Marker to Min]	Places a marker on the lowest peak. The marker value is displayed in the upper right.

Using the Delta Marker to Measure a Difference in Insertion Loss or Frequency

Step	Notes
1 [Marker]	
2 On [Type] select Normal .	Each time you press this softkey, the selected option changes.
3 [Marker to Peak]	
4 On [Type] select Delta .	Each time you press this softkey, the selected option changes.
5 [Marker to Min]	Two markers, for Normal and Delta, are displayed. The marker values are displayed in the upper right.

Activating Interference Rejection

Other signals sometimes interfere with insertion loss measurements when measuring the isolation between antennas. When measuring isolation between antennas in the presence of known or suspected interference, you can minimize the effect of the interference by activating Interference Rejection in the test set.

NOTE

Use of interference rejection will increase the measurement time. Interference rejection should be used if a known interfering signal exists or if the insertion loss

measurement displays suspicious characteristics such as a spike or rapid movements in the noise floor.

To Activate Interference Rejection:

Step	Notes
1 [Setup]	
2 On [Interference Rejection] select On .	Each time you press this softkey, the selected option changes.

Clearing Normalization

Clear Normalization deletes the current normalization data, enabling you to re-normalize the instrument for the same frequency range.

To Clear the Measurement Normalization Values:

Step	Notes
1 [Setup]	
2 [Clear Normalization]	

Setting Source Level

Source level enables you to set the output level of the internal source at the RF Out/SWR connector. You may enter a value from -100 dBm to +10 dBm.

To Set the Source Level:

Step	Notes
1 [Setup]	
2 On [Source Lev] select Manual .	Each time you press this softkey, the selected option changes.
3 Enter the output level of the internal source using the numeric keypad, the up and down arrow keys, or the knob.	

Two Port Insertion Loss

Measuring Two Port Insertion Loss

Step	Notes
4	[dB]

Optimizing Dynamic Range

When using the default settings, the test set optimizes measurement accuracy at the expense of dynamic range. There may be times, however, when you prefer to gain dynamic range and lose some accuracy. For example, when measuring sector isolation on adjacent antennas, you may want to see a relatively large dynamic range, and your results will not be impaired significantly by 1 to 2 dB less accuracy. Optimizing for dynamic range gains you approximately 30 dB of dynamic range.

Step	Notes
1 [Setup]	
2 On [Optimize] select Range .	Each time you press this softkey, the selected option changes.

Two Port Insertion Loss

Measuring Two Port Insertion Loss

Setting the Pass/Fail Limits

The measurement limits setting enables you to alter the value of the maximum and minimum test limits for the Average Insertion Loss measurement. Limits are set in dB. These settings affect the metrics color display: red represents fail, green represents pass. Next to the displayed measurement value, a (P) indicating Pass, or (F) indicating Fail, will be shown to further indicate whether the value is within or outside the set limits.

To Set the Measurement Maximum and Minimum Limits:

Step	Notes
1 [Setup]	
2 [Limits]	
3 On [Limits] select On or Off .	Enables you to toggle the measurement limits function On (active) and Off (inactive). • If set to On, Any measured value that exceeds the upper maximum or is less than the minimum limit will result in a failure indication for that value. • If set to Off, pass fail indicators seen in the metrics display portion of the display will not be displayed.
4 Set the upper limit. a. [Maximum Limit] b. Enter the number on the numeric keypad. c. [dB]	Maximum limit can be set from –100 dBm to +100 dBm.
5 Set the lower limit. a. [Minimum Limit] b. Enter the number on the numeric keypad. c. [dB]	Minimum limit can be set from –100 dBm to +100 dBm.

- “Using the Adjacent Channel Power Measurement” on page 142
- “Making a Basic Adjacent Channel Power Measurement” on page 143
- “Adjacent Channel Power Measurements for Korean PCS Band” on page 145
- “Setting the Adjacent Channel Power Format” on page 145
- “Setting Average, Sweep, and Restart” on page 150
- “Displaying Accurate Peak Power (Recommended for Pulsed Signals)” on page 152
- “Setting the Control Units” on page 152
- “Setting the Range Control” on page 153
- “Setting the Analyzer Input Gain” on page 154
- “Setting Noise Correction” on page 154
- “Setting the Pass/Fail Limits” on page 155
- “Setting Up the Signal Generator” on page 157
- “W-CDMA Adjacent Channel Leakage Power Ratio (ACLR) Measurements” on page 161

Using the Adjacent Channel Power Measurement

Adjacent Channel Power measures the power of the carrier and the power of the noise in its adjacent channels. The measurement results can help you determine whether the power is set correctly and whether the transmitter filter is working properly. Once you have set the limits, you can easily see whether a test falls within those limits using the mask feature and the color-coded metrics. You can measure the adjacent channel power on one to three adjacent channels on each side of your center channel in the CDMA, W-CDMA, TDMA, GSM Edge and GPRS, AMPS, NMT-450, Tetra, iDEN and Korean PCS channel bands.

CAUTION

When measuring multiple adjacent channels, the combined channel power must not exceed +20 dBm at the RF In port.

CAUTION

The maximum power for the RF In (Port 1) and RF Out/SWR (Port 2) ports is +20 dBm (100 mW). When using the 8481A/8482A or N8481A/N8482A with Option CFT Power Sensors, the maximum input power applied to the Power Sensor is +24 dBm (300 mW). When using the 8481D Power Sensor, the maximum input power is +20 dBm (100 mW). When directly coupled to a base station (BTS) or Access Network (AN), the test set can be damaged by excessive power applied to any of these three ports.

To prevent damage in most situations when you directly couple the test set to a base station, use the high power attenuator between the test set and the BTS.

NOTE

For complex modulation such as CDMA, W-CDMA, 1xEV-DO and GSM, the frequency error measurement is not accurate (see respective analyzers for detailed frequency error results).

NOTE


The RF in loss can be added manually or automatically by performing an insertion loss measurement. For measurement instructions refer to [“Performing \(and Calibrating\) a Basic One Port Insertion Loss measurement”](#) on page 47 or [“Normalizing and Performing a Basic Two Port Insertion Loss Measurement”](#) on page 125.

Making a Basic Adjacent Channel Power Measurement


Step	Notes
1. Select Adjacent Channel Power. a. Mode b. [Spectrum Analyzer/Tools] c. [Adjacent Channel Power]	
2. Select the channel standard. a. [Chan Std] b. Select the standard using the up and down arrow buttons. c. [Select]	
3. On [Units] select Chan .	Each time you press this softkey, the selected option changes. (The instructions in this manual show selections for Channel.)
4. Setup the frequency/channel you want to view. a. [Freq/Chan] b. [Channel] c. Enter the number on the numeric keypad. d. [Fwd] or [Rev]	
5. Connect to the base station.	
6. Set the level/location. a. [Level/Location] b. [Autoscale] c. [Select]	If the adjacent channel power trace is not visible, you can change the reference level or use Autoscale to have the test set select a reference level for you.

Adjacent Channel Power
Using the Adjacent Channel Power Measurement

Step	Notes



Out-of-service connection



In-service connection (valid for center channel; adjacent channel measurements may not be valid because there may be active adjacent channels.)

Adjacent Channel Power Measurements for Korean PCS Band

Most Adjacent Channel Power standards specify the power in the adjacent channels relative to the power in the target center channel. The standards for the Korean PCS band are different in that the third adjacent channel is specified absolutely (that is, in dBm) rather than relatively (that is, as dB).

The specifications for the Korean PCS band are shown in the next table.

Korean PCS Band Specifications (All Frequencies within the Base Station Transmit Band of 1840 MHz to 1870 MHz)		
Offset From Carrier Frequency	Out of Band Bandwidth	Power Level
+ / -885 kHz	30 kHz	-45 dB
+ / -1.98 MHz	30 kHz	-55 dB
+ / -2.25 MHz	1 MHz	-135 dBm
All frequencies not within the specific bands allocated to the operator's system	1 MHz	-135 dBm

Setting the Adjacent Channel Power Format

When performing an adjacent channel power measurement, several measurement settings must be specified. The measurement settings include bandwidth and measurement time for the center channel. In addition, the measurement settings for the adjacent channels are:

- number of adjacent channels
- offset of the first adjacent channel from the center channel
- offset of the adjacent channels from each other
- measurement bandwidth and measurement time for each adjacent channel

These settings determine how the DSP measures the center channel and its adjacent channels. Depending on the modulation type of the signal you are trying to measure (CDMA, GSM, and so forth), different measurement bandwidths, times, and offsets

Adjacent Channel Power

Using the Adjacent Channel Power Measurement

are required.

Default adjacent channel power measurement settings, called ACP formats, are provided in the E7495A/B base station test sets. Generally, the ACP format is determined by the channel standard you select. However, to accommodate your particular situation, you can decouple the default formats from the channel standard, or you can change each measurement setting independently. The three methods of selecting your measurement settings are:

- **Channel:** Each channel standard has an associated ACP format. With this method, the optimum measurement bandwidth and measurement time for the modulation type are automatically selected when you set the channel standard. For example, when you select GSM-950 as the channel standard, with this method the test set selects the bandwidth and time and adjacent channel offsets for the GSM format.
- **List:** Select the ACP format from a list of values that are set automatically—independent of the channel standard.
- **Custom:** Manually set all parameters: the measurement bandwidth and measurement time for the center and adjacent channel(s), the offset from the center channel for the first adjacent channel, and the offset between adjacent channels.

To Select the Channel Format Type:

Step	Notes
1 [ACP Format]	
2 [Format Type]	Each time you press this softkey, the selected option changes. The option you select determines which buttons on the right are active.
3 [Chan]	
4 Select the standard you want. a. [Chan Std] b. Select the standard using the up and down arrow buttons. c. [Select]	Channel BW/Time is available, but all buttons are grayed out, enabling you only to view the settings. To change any of the settings, choose Cust.

To Select the List Format Type:

Step	Notes
1 [ACP Format]	
2 [Format Type]	Each time you press this softkey, the selected option changes. The option you select determines which buttons on the right are active.
3 [List]	
4 Select the format you want. a. [Format List] b. Select the standard using the up and down arrow buttons. c. [Select]	Channel BW/Time is available, but all buttons are grayed out, enabling you only to view the settings. To change any of the settings, choose Cust.

To Select the Custom Format Type:

Step	Notes
1 [ACP Format]	
2 [Format Type]	Each time you press this softkey, the selected option changes. The option you select determines which buttons on the right are active.
3 [Cust]	

Adjacent Channel Power

Using the Adjacent Channel Power Measurement

-
- 4 Set the carrier and adjacent channel bandwidth.
 - a. [Channel BW/Time]
 - b. [Center Chan Meas BW]
 - c. Enter the center channel bandwidth on the numeric keypad.
 - d. [GHz] or [MHz] or [kHz] or [Hz]
 - e. [Center Chan Meas Time]
 - f. Enter the center channel measurement time on the numeric keypad.
 - g. [ms]
 - h. [Adj Chan Meas BW]
 - i. Enter the adjacent channel bandwidth on the keypad.
 - j. [GHz] or [MHz] or [kHz] or [Hz]
 - k. [Adj Chan Meas Time]
 - l. Enter the adjacent channel measurement time on the keypad.
 - m. [ms]
 - 5 Enable the frequency error function from the BW/Time menu.
 - a. On [Freq Err] select **On**. Each time you press this menu key, the Frequency Error state (**On** or **Off**) changes.
 - b. [Back]
-
- When Frequency Error is switched On, the Frequency Error result is added to the metrics display at the bottom of the screen.
-
- 6 Set the offset from the carrier to the first adjacent channel.
 - a. [Ctr to Adj Step Size]
 - b. Enter the offset on the numeric keypad.
 - c. [GHz] or [MHz] or [kHz] or [Hz]
-

-
- 7 Set the offset between adjacent channels.
 - a. [Adj to Adj Step Size]
 - b. Enter the offset on the numeric keypad.
 - c. [GHz] or [MHz] or [kHz] or [Hz]
 - 8 Set the number of adjacent channels (from 0-3).
 - a. Enter the number on the numeric keypad.
 - b. [Enter]
-

Setting Average, Sweep, and Restart

Setting the Sweep

You can select either continuous or single sweep. Continuous sweep provides repeated, ongoing measurements. Single sweep performs a single measurement that is repeated only when you push the Single button.

To set sweep:

Step	Notes
1 [Average/Sweep]	
2 [Continuous] or [Single]	Each time you press this softkey, the selected option changes.

Setting Averaging

You can choose to have averaging on or off and set the number of averages you want to take. Averaging only applies to the data, not the trace. You can select from the following types of averaging:

- **Off:** Disables averaging.
- **Running:** Computes the new result as the weighted sum of the last result and the new measurement. The last result is weighted by $(n - 1)/n$. The new result is weighted by $1/n$. Each new measurement produces a new result.
- **Max Hold:** Is not an average, but on a point by point basis, displays the maximum amplitude for the given frequency or channel since Max Hold was turned on. It is updated when a new maximum occurs.
- **Group Average:** Makes the requested number of measurements, averages the measurement data, and displays the average as a single result trace. Measurement time will vary based on the requested number of averages and can take minutes for very large number of averages.
- **Group Max Average:** Makes the requested number of measurements before returning a single trace result. This trace is the maximum value seen at each trace point over the requested number of averages (measurements).

NOTE

When measuring Korean PCS signals, the only averaging types available to you are

Group Average and Group Max Average. Running Average and Max Hold are unavailable.

To set averaging:

Step	Notes
1 Set the number of averages. a. [Average] b. Enter the number of averages using the numeric keypad. c. [Enter]	
2 Select the type of averaging you want to apply. a. [Average/Sweep] b. [Averaging] c. [Off], [Running Average], [Max Hold], [Group Average], or [Group Max Average]	When measuring Korean PCS signals, the only averaging types available to you are Group Average and Group Max Average. Running Average and Max Hold are unavailable.

NOTE

These two steps can be performed in any order. However, if you turn averaging on and a large number of averages has previously been set, there may be a delay before you can change number of averages.

Setting Restart

When you have averaging turned **On** and you are in **Continuous** Sweep mode, you can restart the averaging by pressing the Restart menu key. The Restart key has no effect if you are in **Single** sweep mode.

To restart averaging:

Step	Notes
1 [Average/Sweep]	

Adjacent Channel Power

Using the Adjacent Channel Power Measurement

Step	Notes
2 [Restart]	This key is unavailable or has no effect when Sweep is set to Single . To restart a Single Sweep measurement, press [Single].

Displaying Accurate Peak Power (Recommended for Pulsed Signals)

For pulsed signals, you can get a more accurate measurement of the signal's peak or average power by using the Peak Power Detector setting (see below) in the test set.

The test set measures average power of signals by default. For non-constant-duty-cycle signals such as GSM, an average power reading fails to accurately show amplitude when the signal is **On** if other timeslots in the frame are powered **Off**.

If the [Power Detector] menu key is grayed out, the test set needs to be upgraded in order to measure pulsed signals. Contact the Agilent Service Center for upgrade information.

If it is not a peak signal, it is probably better to select **Average** for a more accurate result.

To Display Peak Power:

Step	Notes
1 [Setup]	
2 On [Power Detector] select Pk .	Each time you press this softkey, the selected option changes.

Setting the Control Units

In some instances you may be provided specifications by engineering in either dBm or watts. You can switch between the two units in order to make it easier to interpret measurement results.

To Change Units on the Y-Axis:

Step	Notes
1 [Level/Location]	
2 [Units]	Each time you press this softkey, the selected option changes.
3 [dBm] or [Watts]	There is no change made to the Y-axis. The change is to the units for entry. The reference level changes on the graph, but not the axis labels.

Setting the Range Control

The autoranging feature, which is built into the test set, helps ensure accurate measurements by changing front-end amplifier gain as needed, for example, when a strong signal threatens to overload the test set. When this occurs, the noise floor rises (as gain is decreased), then falls again when the strong signal stops. To select this feature:

- On [Range Ctrl] select **Auto** to enable the E7495A/B to continuously adjust the noise floor to the optimum setting. When you have Range Control set to Auto, the Sensitivity Setting (see [“Setting the Analyzer Input Gain” on page 154](#)) is automatically switched to Low whenever the signal level at the test set’s connector (that is, after any external attenuation has been applied) rises above –10 dBm. You can use the noise correction feature (see [“Setting Noise Correction” on page 154](#)) to recover any lost dynamic range.

If you prefer a fixed noise floor, you can disable autoranging in two ways using the Setup function within Spectrum Analyzer:

- On [Range Ctrl] select **Hold** to fix the noise floor at the current level. A subsequent strong signal—even outside the measurement range—may cause an inaccurate reading due to overloading the front-end of the test set.
- On [Range Ctrl] select **Max** to fix the noise floor at the current level until a strong signal comes in. In that case, the floor will rise to maintain accuracy, but

Adjacent Channel Power

Using the Adjacent Channel Power Measurement

will not return to its lower level after the strong signal stops.

Step	Notes
1 [Setup]	
2 [Range Ctrl]	
3 [Auto] [Hold] or [Max]	

Setting the Analyzer Input Gain

Normally the E7495A/B is set to add the most gain in the receive path to boost low-level signals. If the signal is high, there is no reason to add gain. When you’re measuring a strong signal, select **Low** sensitivity to reduce the gain in the receive path and lower the noise floor. For a low level signal, select **High**.

Step	Notes
1 [Setup]	
2 [Sensitivity]	
3 Low or High	

NOTE

The Sensitivity setting is coupled to the Noise Correction setting. Changing the Sensitivity setting from **Low** to **High** will cause the Noise Correction setting to change from **On** to **Off**. Conversely, if the Noise Correction setting is changed from **Off** to **On**, the Sensitivity setting is changed from **High** to **Low**.

Setting Noise Correction

You can turn the Noise Correction function on or off. When set to On, noise correction will be activated and the test set will correct for the noise generated internally by the analyzer. It allows the you to make accurate measurements on

signals close to the noise floor.

To Set the Measurement Noise Correction:

Step	Notes
1 [Setup]	
2 On [Noise Correction] select On or Off .	Each time you press this softkey, the selected option changes.

Setting the Pass/Fail Limits

The E7495A/B uses generic defaults, rather than standard defaults. You can change those to accommodate your base station settings.

- **Power Limits:** Sets the high and low limits of the center channel, as well as the high limit of the adjacent channels. Center channel limits are set in dBm and are absolute. Adjacent channel limits are set in dB and are relative to the center channel power. The settings you choose define the shape of the mask displayed on the screen. To measure only the outer frequencies, turn off the mask. These settings affect the metrics color display: red represents fail, green represents pass.
- **Frequency Limits:** Sets the high and low frequency limits for the center channel only. These settings affect the metrics color display: red represents fail, green represents pass.

To Change Power Limits:

Step	Notes
1 [Setup]	
2 [Limits]	
3 [Power Limits]	
4 [On] or [Off]	

Adjacent Channel Power

Using the Adjacent Channel Power Measurement

Step	Notes
5	Set the center channel upper limit. a. [Center Chan High Limit] b. Enter the number on the numeric keypad. c. [dBm]
6	Set the center channel lower limit. a. [Center Chan Low Limit] b. Enter the number on the numeric keypad. c. [dBm]
7	Set the adjacent channel 1 upper limit. a. [Adj Chan 1 High Limit] b. Enter the number on the numeric keypad. c. [dB]
8	Set the adjacent channel 2 upper limit. a. [Adj Chan 2 High Limit] b. Enter the number on the numeric keypad. c. [dB]
9	[Back]

To Change Frequency Limits:

Step	Notes
1 [Setup]	
2 [Frequency Limits]	
3 [On] or [Off]	
4 Set the upper limit. a. [Frequency High Limit] b. Enter the number on the numeric keypad. c. [GHz] or [MHz] or [kHz] or [Hz]	
5 Set the lower limit. a. [Frequency Low Limit] b. Enter the number on the numeric keypad. c. [GHz] or [MHz] or [kHz] or [Hz]	

Setting Up the Signal Generator

[“Using the RF OUT Loss field” on page 159](#)

You can set up the signal generator while in the Spectrum Analyzer mode from the Setup menu. For more detailed information on the signal generator setup and operation, refer to [“Using the Signal Generator” on page 402](#).

CAUTION

The maximum power for the RF In (Port 1) and RF Out/SWR (Port 2) ports is +20 dBm (100 mW). When using the 8481A/8482A or N8481A/N8482A with Option CFT Power Sensors, the maximum input power applied to the Power Sensor is +24 dBm (300 mW). When using the 8481D Power Sensor, the maximum input

Adjacent Channel Power

Using the Adjacent Channel Power Measurement

power is +20 dBm (100 mW). When directly coupled to a base station (BTS) or Access Network (AN), the test set can be damaged by excessive power applied to any of these three ports.

To prevent damage in most situations when you directly couple the test set to a base station, use the high power attenuator between the test set and the BTS.

NOTE

The lowest level the signal generator can go to is -90 dBm. In order to get a lower level, you must use an external attenuator. You can compensate for the attenuator using RF Out Loss.

Step	Notes
1	[Setup]
2	[Sig Gen]
3	[Freq/Chan]
4	Enter the channel or frequency using the numeric keypad.
5	- For channel select [Rev] or [Fwd] - For frequency select [GHz], [MHz], [kHz], or [Hz],
6	[Mod Format]
7	Select the channel standard from the list using the up and down arrow buttons.
8	[Select]

Step	Notes
9 Set the RF output amplitude a. [Amplitude] b. Enter the amplitude value using the numeric keypad. c. [dBm].	You may also enter a new value for amplitude by turning the rotary knob until the desired value is displayed or using the up and down arrow keys.
10 If you have previously stored RF Out Loss from an insertion loss measurement, go to the next step. Or Press [RF OUT Loss] to select On and enter the RF Out Loss value.	For information on the effects of the RF Out Loss function on the amplitude, refer to “Using the RF OUT Loss field”, below. Each time you press this softkey, the selected option changes.
11 Connect to the base station.	
12 On [Enable Sig Gen] select On .	Each time you press this softkey, the selected option changes.

Using the RF OUT Loss field

The RF OUT Loss field is used when it is necessary to test the receiver sensitivity of a typical base station. The test set’s source will typically go down to –90 dBm, in order to reach –113 dBm for sensitivity testing, you must use an external attenuator. The measured value of the attenuator and connecting cables are entered into this field. This value is then used when this field is set to **On**. When this field is set to **On**, the test set will set the RF generator level to the correct level offset by the external attenuator/cabling. When you set the RF Generator to –113 dBm (with the RF OUT Loss field turned **On** and the external attenuator/cabling loss value entered) the output at the end of the RF test cabling is –113 dBm.

Example: If you want to set the signal generator to –113 dBm, the attenuator and RF cabling measures 42.51 dB (measured with the 2 port insertion loss measurement screen prior to this test), the RF OUT Loss field is turned **On** (with the 42.51 dB loss value entered). The actual RF output of the signal generator is –70.49 dBm, the attenuator and RF cabling attenuated the signal to the desired level; so the RF signal

at the end of the test cable/attenuator is -113 dBm. This also points out the importance of accurately measuring the loss of the attenuator and connecting cables.

W-CDMA Adjacent Channel Leakage Power Ratio (ACLR) Measurements

One of the most important measurements on RF signals for digital communication systems is the leakage power into the adjacent channels. A quantitative figure of merit is adjacent channel power ratio (ACPR) or adjacent channel leakage ratio (ACLR). The ACLR measurement determines how much of the transmitted power is allowed to leak into the first and second neighboring carriers (high side and low side). Leakage of RF power into adjacent channels or bands can cause major interference to occur on another carrier's network.

The measurement of ACLR is defined as the ratio of the average power in the adjacent frequency channel to the average power in the transmitted frequency channel. It is reported in dBc (dB relative to the main carrier).

Test models are used to have pre-defined test conditions for base station conformance test of ACLR. Under 3GPP TS 25.141, five types of test models are defined. Each test model consists of PCCPCH (Primary Common Control Physical Channel), PICH (Paging Indication Channel), CPICH (Common Pilot Channel), SCH (Synchronization Channel) and some DPCCHs (Dedicated Physical Channels).

Adjacent Channel Power
W-CDMA Adjacent Channel Leakage Power Ratio (ACLR)
Measurements

Figure 5-1 Sample Measurement of ACLR on a Valid 3GPP W-CDMA Signal




Figure 5-1 is an example of the measurement results as a bar graph of the power levels at different offsets. This gives you a quick reading of respective powers. The bar graph is green with 'P' on the bar graph, indicating the ACLR measurement passes at the 5 MHz and 10 MHz offsets.

NOTE The 3GPP TS 25.141 standard for W-CDMA requires the adjacent channel power leakage ratio to be better than -44.2 dBc at 5 MHz offset and -49.2 dBc at 10 MHz offset. The minimum requirements for the adjacent channel power leakage ratios are -45 dBc and -50 dBc respectively, but the conformance test requirements add 0.8 dB tolerance to these figures. The conformance limits are consequently -44.2 dBc at 5 MHz offset and -49.2 dBc at 10 MHz offset.

“Installing Batteries” on page 164

“Viewing Battery Status” on page 165

“Charging Batteries” on page 168

“Reconditioning Batteries” on page 170

“Battery Care” on page 173

“Battery Specifications” on page 176

Installing Batteries



Step	Notes
1	Open the battery door. Turn the latch counterclockwise several times until loose. Then pull the battery door open.
2	Insert the battery. Insert one or two batteries.
3	Close the battery door. Turn the latch clockwise until tight to secure the battery door.

Viewing Battery Status

You can view information about battery status in four ways:

- Two battery LEDs embedded in the E7495A/B enclosure
- Icons in the lower right of the front panel screen
- System Statistics—Battery screen, available from the System menu
- LCD gauge built into each battery

Battery LEDs

LED	Charge remaining
Green	Greater than or equal to 25% charge capacity remaining
Blinking green	Battery charging
Green and red (may appear yellow or orange)	Greater than or equal to 10% and less than 25% charge capacity remaining
Red	Less than 10% charge capacity remaining

NOTE

The battery status LEDs will function only when the test set is on, in standby mode, or connected to external power.

Front Panel Icons

Icon	Status
Plug icon	Connected to external power through AC adapter converter or car adapter
2 solid batteries	2 batteries installed
1 solid battery	1 battery installed

Icon	Status
% displayed beneath battery	Amount of charge capacity remaining for battery

System Statistics—Battery Screen

Step	Notes
1 System	
2 [More 1 of 2]	
3 [Battery]	

The Battery screen displays several kinds of information:

- **Temperature**—the internal temperature of each battery as measured by a sensor embedded in each battery
- **Voltage**—for each battery cell stack as measured by each battery’s sensor
- **Run Time to Empty**—while using external power, External DC Power is displayed; while using battery power, the predicted remaining battery run time is displayed in minutes at the present rate of discharge. If two batteries are installed, the second battery will have Not in Use displayed. The instrument mode you select affects the discharge rate, which determines the run time to empty. Antenna/Cable, Spectrum Analyzer, CDMA Tx Analyzer, and CDMA Over Air modes use the most power. Backhaul and Power Meter modes use the least power.
- **Fuel Gauge Error**—the present accuracy of each battery’s fuel gauge or remaining charge capacity. If the error exceeds 10%, you should condition the battery.
- **Percent Charged**—the predicted charge capacity of each battery in percent.
- **Battery Status**—For Battery 1 and Battery 2, Present or Missing tells you whether a battery is installed.

Built-In Battery Gauge

Each Lithium Ion battery has a five-segment LCD gauge that displays its charge

status. Each segment represents 20% of the charge capacity. The gauge is active unless the battery is in shutdown mode. You can view the gauge with the door open.

Gauge	Charge Remaining
5 segments	81-100%
4 segments	61-80%
3 segments	41-60%
2 segment	21-40%
1 segment	1-20%
0 segment	Less than 1%

Charging Batteries

You can charge batteries internally or using the external battery charger (Option #820). The external charger provides much faster charging time.

CAUTION

Charge batteries internally or with the appropriate charger, a SMBus charger of level II or higher.

Never use a non-SMBus charger because the battery issues commands over the SMBus to the charger to control the charge rate and voltage.

Never use a modified or damaged charger.

Internal Charging

You can use the E7495A/B to recharge while the test set is operating or shut down. For a fully depleted battery, charging time is approximately 4 hours if the test set is shut down, 8 hours if the test set is operating.

If two batteries are installed, the test set fully charges Battery 1 before charging Battery 2. During internal charging, the charge indicator blinks to indicate which battery is being charged.

To charge a battery internally, simply attach the car adapter or AC adapter and turn on external power.

External Charging

The external battery charger (available as part of Option 820) lets you charge two batteries simultaneously. Each fully depleted battery takes up to 4 hours to recharge.

You have the option of charging batteries before they become fully depleted. Doing this does not shorten battery life, but repeatedly charging a battery before it is fully discharged will impair the accuracy of its internal charge-remaining indicator. When the fuel gauge error is greater than 10%, the battery should be reconditioned.

External Battery Charger LED	Charging Status
Green on	Fully charged
Green flashing	Fast charging

External Battery Charger LED	Charging Status
Yellow flashing	Reconditioning—the accuracy of the battery’s internal LCD charge gauge is being renewed. See “Reconditioning Batteries.”
Yellow/green	Battery is reconditioned
Red flashing	Error
Yellow on	Standby

Reconditioning Batteries

Each battery contains a microchip that monitors battery usage and tracks how much capacity is available. This function can become less accurate because of temperature fluctuations, aging, self-discharge, repeated partial charging, and other factors. This inaccuracy is displayed on the System Statistics—Battery screen as Fuel Gauge Error.

To ensure the accuracy of the battery's internal capacity tracking system, occasionally you need to recalibrate the battery. Reconditioning—also known as recalibrating—is done by fully charging the battery, fully discharging it, recharging it again, and then verifying that the error has been corrected.

You can recondition a battery internally or with the external charger. The charger makes the process simpler.

Determining if a Battery Needs Reconditioning

Step	Notes
1 System	
2 [More 1 of 2]	
3 [Battery]	On the Battery screen, if the error percentage for the battery is greater than 10%, the battery needs to be reconditioned.

NOTE

After reconditioning, if the battery is not fully charged or still shows more than a 10% Fuel Gauge Error reading, repeat the reconditioning procedure. If the second reconditioning does not restore a full charge and give an error reading of 10% or less, the battery needs replacement. This error will affect all of the displayed battery charge indicators.

Internal Reconditioning

If you don't have the external battery charger, you can use the test set to recondition

a battery. The process takes longer and requires shutting down the test set.

Step	Notes
1 Fully charge the battery. a. Power off the test set. b. Install the battery needing reconditioning into the test set. If you have a second battery installed, remove the second battery. c. Connect the car adapter or AC adapter to the test set, and plug the other end of the adapter in the appropriate power source.	To fully charge the battery, leave the test set power off for approximately 4 hours.
2 Fully discharge the battery. a. Disconnect the external power adapter, then power on the test set. b. Confirm that the battery now has 100% of its charge by checking the Battery 1 or Battery 2 status icon in the lower right of the display or the System Statistics—Battery screen. c. Run the test set without external power until you fully deplete the battery (approximately 1.5 hours).	
3 Charge the battery and verify a full charge. a. Power off the test set again. b. Reconnect the external power adapter and charge the battery again for approximately 4 hours. c. Power on the test set. d. Confirm that the battery is fully charged and reconditioned by checking the System Statistics—Battery screen.	On the System Statistics—Battery screen, the battery should show 100% charge rate and less than a 10% Fuel Gauge Error.

Reconditioning with the External Battery Charger

Step	Notes
1 Insert a battery into the left bay of the external battery charger.	
2 Press the blue button labeled Push to Recalibrate Left Battery Bay .	The charger will charge the battery fully, discharge it completely, then recharge it fully again. The entire process can take up to 10 hours.
3 Install the battery into the test set.	
4 On the System Statistics—Battery screen, verify that the battery is fully charged and reconditioned.	

WARNING

If you are charging the batteries internally, even while the test set is powered off, the test set may become warm. Take care to provide proper ventilation.

Battery Care

WARNING

Lithium Ion and lithium polymer cells and battery packs may get hot, explode, or ignite and cause serious injury if exposed to abuse conditions. Be sure to follow these safety warnings:

- Do not install the battery backward, so the polarity is reversed.
- Do not connect the positive terminal and negative terminal of the battery to each other with any metal object (such as wire).
- Do not carry or store the battery with necklaces, hairpins, or other metal objects.
- Do not pierce the battery with nails, strike the battery with a hammer, step on the battery, or otherwise subject it to strong impacts or shocks.
- Do not solder directly onto the battery.
- Do not expose the battery to water or salt water, or allow the battery to get wet.
- Do not disassemble or modify the battery. The battery contains safety and protection devices, which, if damaged, may cause the battery to generate heat, explode, or ignite.
- Do not place the battery in or near fire, on stoves, or in other high temperature locations. Do not place the battery in direct sunlight, or use or store the battery inside cars in hot weather. Doing so may cause the battery to generate heat, explode, or ignite. Using the battery in this manner may also result in a loss of performance and a shortened life expectancy.
- Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended. Discard used batteries according to manufacturer's instructions.

WARNING

Do not discharge the battery using any device except the specified device. When the battery is used in devices other than the specified device, it may damage the battery or reduce its life expectancy. If the device causes an abnormal current to flow, it may cause the battery to become hot, explode, or ignite and cause serious injury.

Maximizing Battery Life

The Lithium Ion battery used in the E7495A/B has a life span of approximately 300 charge cycles at room temperature, with normal charge and discharge rates. You can maximize the number of charge cycles with reasonable battery care:

- Clean the battery contacts occasionally, using a pencil eraser or alcohol and a cotton swab. Make sure no residue from the eraser or cotton swab is left on the contact points.
- Cycle each battery through a full charge and full discharge on a regular basis, preferably monthly. Even if you use external power most of the time, you will lengthen battery life by occasionally cycling through a full discharge/recharge cycle.
- Do not leave a battery unused for an extended period. Batteries that remain idle eventually lose their ability to hold a charge.
- Unplug the external battery charger (Option #820) when you're not using the test set.
- Store batteries in a cool, dry location, away from metal objects and corrosive gases. Extended exposure to high humidity or temperatures above 45 degrees Celsius (113 degrees Fahrenheit) can impair battery performance and shorten battery life. Storage limits are -20°C to 60°C 80% RH.
- Allow a battery to warm to room temperature before charging it. Temperature shock can damage the battery chemistry and in some cases cause a short circuit.
- Always charge batteries at temperatures between 0 and 45 degrees Celsius (32 to 113 degrees Fahrenheit).
- Operate the test set on battery power between the temperatures of -10 and $+50$ degrees Celsius (-14 to $+122$ degrees Fahrenheit). Using the batteries at lower or higher temperatures can damage the batteries and reduce operating life. Cold temperatures affect battery chemistry, reducing charge capacity, especially below 0 degrees Celsius (32 degrees Fahrenheit).
- Batteries are shipped with a minimum of 20% charge capacity to provide at least

a 6-month shelf life at room temperature, before the battery electronics go into shutdown mode. When a battery has discharged down to a 7.1 volts, it goes into shutdown mode. When this occurs, the battery electronics self-disconnect, removing their electronic load from the cells. This provides approximately 1 year of room temperature storage before the cells self-discharge to the point beyond which they should not be recharged. Once a battery has reached shutdown mode the battery will undergo a self-test immediately upon being put into charge. The charger will then attempt to pre-charge the battery at a very low initial charge rate. If the voltage does not recover, the battery pack has been allowed to discharge beyond the point of safe recovery. The charge cycle will be terminated, and the battery pack needs to be replaced.

If the battery does recover from a shutdown mode, the fuel gauge accuracy will be reduced. Complete a battery recalibration as soon as possible to calibrate the fuel gauge.

Initial Charge Cycle

New batteries must be rapid-charged (typically to 80%), then trickle-charged (slowly charged to 100%) for 24 hours, before their first use and for the first two or three uses.

Because the batteries you receive with the E7495A/B are new, they have a minimal charge when you receive them. All batteries require a “break-in” period, so don't be alarmed if a battery doesn't hold a full charge right away. A new battery commonly will show a false full charge (voltage) as indicated on the test set or charger, and may not power up the test set upon first use. Before using a new battery, leave it charging for 24 hours.

Lithium Ion Battery Disposal

When you notice a large decrease in charge capacity after proper recharging, it's probably time to replace the battery.

Li-Ion batteries need to be disposed of properly. Contact your local waste management facility for information regarding environmentally sound collection, recycling, and disposal of the batteries. Regulations vary for different countries. Dispose of in accordance with local regulations.

Battery Specifications

The E7495A/B Base Station test set uses the Inspired Energy NI2040AG Smart Battery, which produces 10.8 volts DC at approximately 6000 mA. The NI2040AG is a Lithium Ion battery pack, which uses the System Management Bus (SMBus) interface to communicate with the test set and charger. To charge the batteries, use only the Agilent approved SMBus charger of Level II or higher or the E7495A/B.

External charging voltage is 18 V to 24 VDC.

The battery is designed for approximately 300 full charge/discharge cycles at room temperature and under normal rates of discharge.

The NI2040AG uses electronically programmable read-only memory (EPROM) to store key data regarding the battery cells and charge capacity.

Protection Electronics

The NI2040AG SMBus battery uses several protection devices to prevent damage to the battery and test set. The battery is internally protected against excessive current draws and reduced loads (shorts), excessive voltage and temperatures.

During charging and discharging, the battery will monitor and report its voltage, current, and temperature. If any of these monitored conditions exceeded their safety limits, the battery will terminate any further charge or discharge until the error condition is corrected.

Test Set Operation: Battery Current Drain in the Off or Standby Mode

The E7495A/B provides two “powered down” modes: off and standby.

When the test set is operating from battery power, it continues to draw current in both off and standby modes.

- **Standby Mode:**

When in standby mode the test set draws 70 mA, or 28% of a full battery charge in a 24-hour period.

- **Off Mode:**

For Test Sets with a Serial Number Prefix of MY46360101 and above, when in Off mode, the test set draws 7 mA, or 3% of a full battery charge in a 24-hour period.

For Test Sets with a Serial Number Prefix lower than MY46360101, when in Off mode, the test set draws 45 mA, or 18% of a full battery charge in a 24-hour period

Agilent recommends that if the test set is not going to be used for an extended period of time, you periodically check and maintain the batteries' charge, or remove the batteries from your test set. This will ensure you have sufficient battery capacity if you intend to operate the test set from battery power.

Test Set Operation: Battery Drain in the Off or Standby Mode

The following table shows how long a test set can be left in Standby or Off modes before the battery fails to provide enough current to operate the test set.

Test Sets with Serial Number Prefix of MY46360101 and above (Not available for earlier instruments)		
Number of Batteries Installed	Battery Capacity in Standby Mode	Battery Capacity in Off Mode
1	3.5 Days	34.8 Days
	(1.68 Amps per 24 hours)	(0.17 Amps per 24 hours)
2	6.9 Days	69.6 Days
	(1.68 Amps per 24 hours)	(0.17 Amps per 24 hours)
Test Sets with Serial Number Prefix Lower Than MY46360101		
Number of Batteries Installed	Battery Capacity in Standby Mode	Battery Capacity in Off Mode
1	3.5 Days	5.4 Days
	(1.68 Amps per 24 hours)	(1.08 Amps per 24 hours)
2	6.9 Days	10.8 Days
	(1.68 Amps per 24 hours)	(1.08 Amps per 24 hours)

NOTE

Times noted are based on fully chaged batteries operating at full capacity (If batteries are not fully charged this time is reduced by the batery charge %.)

Battery and Charger Part Numbers

Standard Supplied Accessories

Description	Part Number
AC/DC Converter	0950-4404
NI2040AG Battery	1420-0883*

Optional Accessories provided in E7495A/B Option 820

Description	Part Number
Charger 12 V at 1 A	0950-4276
AC/DC Converter	0950-4404
Auto Adapter F1455A	0950-4412
NI2040AG Battery	
E7495A	1420-0883
E7495B	1420-0883

NOTE

* Replace only with NI2040AG or equivalent, Agilent-approved battery.

Additional batteries are also available directly from Inspired Energy, Inc. To purchase additional or replacement batteries, visit www.inspired-energy.com, or call toll free USA 1-888-5-INSPIRE (546-7747).

NOTE

Regarding the battery charger and conditioner:

- Install the instrument so that the ON / OFF switch is readily identifiable and is easily reached by the operator. The ON / OFF switch and the detachable power cord are the instrument disconnecting devices. They disconnect the mains circuits from the mains supply before other parts of the instrument. Alternatively, an externally installed switch or circuit breaker (which is readily identifiable and is easily reached by the operator) may be used as a disconnecting device.
 - Install the instrument so that the detachable power cord is readily identifiable and is easily reached by the operator. The detachable power cord is the instrument disconnecting device. It disconnects the mains circuits from the mains supply before other parts of the instrument. The front panel switch is only a standby switch and is not a LINE switch. Alternatively, an externally installed switch or circuit breaker (which is readily identifiable and is easily reached by the operator) may be used as a disconnecting device.
-

- “Using the CDMA Analyzer” on page 182
- “Common CDMA Tx Analyzer Measurements” on page 182
- “Preparing to Make CDMA Tx Analyzer Measurements” on page 182
- “Performing a Basic CDMA Transmitter Measurement” on page 183
- “Codogram Display” on page 187
- “Performing a Codogram Measurement” on page 188
- “Interpreting the Display” on page 187
- “Setting the Channel or Frequency Step” on page 190
- “Setting the PN Offset” on page 191
- “Setting the PN Increment” on page 191
- “Setting the Frequency/Time Reference” on page 192
- “Setting Units” on page 193
- “Setting the CDMA Transmitter Reference Level” on page 193
- “Setting the Active Channel Threshold Level and Auto Threshold Level” on page 194
- “Setting Measurement Time” on page 195
- “Setting Quick Page Channel” on page 196
- “Setting Average, Sweep, and Restart” on page 197
- “Adding a Marker” on page 198
- “Setting the Pass/Fail Limits” on page 200
- “Setting Up the Signal Generator” on page 209
- “Metrics Provided by the CDMA Tx Analyzer Measurement” on page 212
- “Interpretation of CDMA Tx Analyzer Measurement Results” on page 214

Using the CDMA Analyzer

CDMA transmitter measurements verify proper transmitter performance and are typically made with the base station out of service. Important metrics are:

- frequency error
- PN and time offsets
- channel power
- waveform quality (estimated Rho)
- carrier feedthrough
- noise floor
- pilot channel power
- page channel delta power from pilot
- sync channel delta power from pilot
- quick changing channel delta power from pilot
- For information about CDMA over air measurements, refer to “[CDMA Over Air](#)” on page 219.

CAUTION

The maximum power for the RF In (Port 1) and RF Out/SWR (Port 2) ports is +20 dBm (100 mW). When using the 8481A/8482A or N8481A/N8482A with Option CFT Power Sensors, the maximum input power applied to the Power Sensor is +24 dBm (300 mW). When using the 8481D Power Sensor, the maximum input power is +20 dBm (100 mW). When directly coupled to a base station (BTS) or Access Network (AN), the test set can be damaged by excessive power applied to any of these three ports.

To prevent damage in most situations when you directly couple the test set to a base station, use the high power attenuator between the test set and the BTS.

Common CDMA Tx Analyzer Measurements

Preparing to Make CDMA Tx Analyzer Measurements

The first step in measuring CDMA transmitter performance is to take the base station out of service. The next step is to choose the type of time reference available. The measurement configuration depends upon the type of time reference you choose to use. Optimally, a GPS time reference is desired. GPS provides an independent time reference that can help determine if the base station under test is synchronized with the rest of the network. Base stations not synchronized with the rest of the network are referred to as “island cells”.

NOTE If a GPS time reference is unavailable, you must connect to the even second pulse from the base station.

You must also know the channel or frequency and the PN (pseudo noise) Offset of the CDMA signal to be analyzed. Each base station sector has a unique PN Offset. For more information on PN Offsets refer to [“Adding a Marker” on page 198](#).

Performing a Basic CDMA Transmitter Measurement

Once you have taken the base station out of service and made the proper connections, you can perform CDMA transmitter measurements.


Step	Notes
1. Mode	
2. [Tx Analyzer]	
3. [CDMA Analyzer]	
4. [Chan Std]	
5. Highlight the channel standard you want using the up and down arrow buttons.	
6. [Select]	
7. On [Units] select Chan or Freq .	Each time you press this softkey, the selected option changes.
8. Enter the channel or frequency using the numeric keypad.	• If you selected Chan in the previous step, select [Channel]. • If you selected Freq, select [Frequency].
9. [Fwd]	Selects the forward CDMA channel.
10 [Fr/Time Ref]	

CDMA Analyzer


Using the CDMA Analyzer

Step	Notes
11. [GPS] or [External Even Sec]	GPS is the preferred time reference. If the sky (and hence the satellites) is not visible from the position of your analyzer, use External Even Sec as the time reference. When using the Even Second reference, the base station timing is relative to itself.
12. On [PN Offset] select Auto or Manual .	The test set defaults to Auto mode. The other choice is Manual. • In Auto mode the test set finds the PN Offset and displays the value in the metrics display at the bottom of the screen. The Time Offset is derived from the PN Offset that has been found. • In Manual mode you must enter the PN Offset, which appears in the metrics display. The Time Offset is derived from the entered PN Offset.
13. Connect to the base station.	

Step	Notes




Connections for out of service CDMA measurements with GPS receiver as timing reference




Connections for out of service CDMA measurements with base station even second as timing reference

CDMA Analyzer Using the CDMA Analyzer

Step	Notes



Connections for in service CDMA measurements with GPS receiver as timing reference



Connections for in service CDMA measurements with base station even second as timing reference

NOTE

During a CDMA Analyzer measurement, a yellow triangle symbol may temporarily appear beside "GPS" in the lower right. The yellow triangle indicates that the test set is re-synching with the GPS even second pulse. Once the test set is synchronized, a

green dot appears in place of the triangle. If the GPS is unavailable, a red X appears. If this happens, you must choose another reference.

Interpreting the Display

The CDMA Tx Analyzer screen is divided into two sections:

- The trace display - that is, the graphic bar chart taking up most of the screen
- The metrics display - that is, a table of values at the bottom of the screen

The *trace display* contains a code domain power display. In this display 128 Walsh codes are shown in bit-reversed order to represent the combined code channels for the varying data rate traffic channels. The Y-axis labels display the relative power (dB) or absolute power (dBm), threshold level, and dB/division. The X-axis labels display active channel numbers. Active channel Walsh code numbers shown on the display include:

- Pilot (red)
- Page (green)
- Sync (blue)
- Quick page (light blue)
- IS-95 traffic (yellow)
- cdma2000 traffic (orange)
- Unknown traffic (tan)
- Noise (light gray)

The *metrics display* shows 12 measurement parameters displayed below the trace display in three columns and four rows—each with a value and units. For more information about the parameters in the metric display, refer to [“Metrics Provided by the CDMA Tx Analyzer Measurement” on page 212](#).

The frequency indicator is at the bottom right, the time reference indicator at the bottom left. For each indicator the text indicates which reference you have chosen. A green LED indicates a locked condition, a red “X,” an unlocked condition.

Codogram Display

This view provides a history of the code power. The codogram plot rises over time until it fills the graphical section of the display. Your most recent data appears at the bottom of the display, and your oldest data (several minutes ago to several hours

CDMA Analyzer

Using the CDMA Analyzer

ago, depending on your settings) appears at the top of the display. In this way, you can clearly see the changes in power that occur over a period of time. You can use it to:

- see traffic channels as they initiate and terminate,
- track traffic channel call levels over time.

The **Update Interval** is the interval, measured in whole seconds, between successive records displayed on the codogram. In other words, if you set the update interval to 5 seconds, the codogram display will not update until the after the first complete measurement following a gap of five seconds. Alternatively, you can set the update interval to provide the maximum data collection speed by pressing [Max Speed], or by setting the update interval to 0 (zero) seconds.

NOTE

It is not always possible for the analyzer to match the update interval you specify. It is possible, for example, to set your update interval to zero seconds (the maximum speed), and then to find that the analyzer can not update any faster than once every two seconds.

Performing a Codogram Measurement

Step	Notes
1 [Display]	
2 [Codogram]	This displays the menu that controls the appearance and behavior of the codogram display.
3 On [Codogram] select On or Off .	Each time you press this key, the codogram state switches between On and Off . When you set [Codogram] to On, [Reset Codogram], [Update Interval] and [Palette] become active.
4 [Reset Codogram]	This restarts the data capture for the Codogram. You may see the screen freeze for a few seconds before the display starts plotting data again.

Step	Notes
5 If desired set the update interval: a. [Update Interval] b. Enter the interval number of seconds using the numeric keypad. c. Select [sec] or [Max Speed].	Allows you to set the update interval to 0, 1, or more seconds. Alternatively, you may set it to automatically determine the update interval that provides the maximum data collection speed. If you need to return to the automatically determined maximum capture speed, you must press [Update Interval] followed by a numeric keypad key to access [Max Speed].
6 If desired set the display color: a. [Palette] b. Select [Full Color] or [Grayscale].	The color/grayscale top and bottom mappings are determined by the Ref Level and Scale/Div settings. To change the mapping, go to [Level/Location] and change [Ref Level] and [Scale/Div].

NOTE The key labelled “Update Interval” was labelled “Capture Interval” in earlier versions of the software (v.04.00 or earlier). The way the key works has not changed. Only the key label has changed to clarify what the key does.

Optional CDMA Tx Analyzer Measurement Settings

You can change several optional measurement parameters in the CDMA Tx Analyzer:

- “Setting the Channel or Frequency Step” on page 190
- “Setting the PN Increment” on page 191
- “Setting the CDMA Transmitter Reference Level” on page 193
- “Setting the Active Channel Threshold Level and Auto Threshold Level” on page 194
- “Setting Measurement Time” on page 195
- “Setting Quick Page Channel” on page 196
- “Setting Average, Sweep, and Restart” on page 197
- “Adding a Marker” on page 198
- “Setting the Pass/Fail Limits” on page 200

Setting the Channel or Frequency Step

You can set the channel or frequency step so you can quickly increment to the next channel or frequency using the up and down arrow buttons.

Step	Notes
1. [Chan Step] or [Freq Step]	This choice depends on the [Units] mode you are using.
2. Enter the desired channel or frequency step using the numeric keypad.	
3. [Enter]	Notice (and verify) that the number you entered (the channel step number or the frequency step number) appears below the Chan Step or Freq Step text on the corresponding button.

Setting the PN Offset

The PN Offset (Pseudo-Noise Offset) key allows you to set the analyzer to find the PN Offset automatically, or to set it to manually to a known value.

The PN Offset is a short code sequence that provides a unique identifier for each sector of each cell site. There are 512 unique offsets 0 - 511), which the access terminals use to decode the information broadcast by the access network.

Step	Notes
1. [PN Offset]	Each time you press this key, the setting toggles between Auto and Manual .
2. If you are setting the PN Offset manually, enter the PN Offset number using the numeric keypad.	Any value from 0 to 511 is valid.
3. If you are setting the PN Offset manually, press [Enter]	Notice (and verify) that the number you entered for your chosen PN Offset number appears below the PN Offset text on the corresponding button. Note that no number is displayed if the setting is Auto .

Setting the PN Increment

The PN Increment allows you to choose the increment step for the PN Offset. Typically the PN Increment is set to 1 when measuring CDMA transmitter performance while connected to the base station via RF cable.

The PN Increment field enables you to search based on a step size of your choice. If PN Increment = 1 (default), the search will step through PN values by one PN at a time. If PN Increment = 5, it will step through PN values 0, 5, 10, and so on. The Measured PN displayed will be a multiple of 5, even if the actual PN is not a multiple of 5. If you know that all base stations in the area have fixed increments, then set the PN Increment field to that increment value. If you don't know, then use the default value of 1.

Step	Notes
1. [PN Inc]	
2. Enter the PN Increment using the numeric keypad.	The maximum value you can enter is 15.
3. [Enter]	Notice (and verify) that the number you entered for your chosen PN Increment number appears below the PN Inc text on the corresponding button.

Setting the Frequency/Time Reference

This key is used to specify the source of your frequency reference, or your frequency and time reference. The analyzer needs an accurate reference signal in order to make accurate measurements, and this is where you specify the source of this reference signal.

Step	Notes
1. [Fr/Time Ref]	The frequency/time reference form is displayed

Step	Notes
2. Select the frequency and time reference from the list using the up and down arrow buttons.	If the sky (and hence the satellites) is visible from the position of your analyzer, you can select GPS to get frequency and timing references from the GPS signal. The GPS antenna will need to be attached to the analyzer. If you connect to the access network's Even Second Clock, you will still get all the metrics, but you will not have an independent check that the access network has locked onto the GPS signal. Other options available are Internal Reference, External 10 MHz, and External 19.6608 MHz. These last three options only provide a frequency reference. They do not provide a time reference...
3. [Select]	

Setting Units

This key is used to toggle between **Frequency** and **Channel** for your measurements. That is, you can decide whether to specify (and measure) the frequency in Hertz, to specify the Channel Number.

Step	Notes
1. [Units]	Each time you press this key, you toggle between Freq (measurements in Hertz) and Chan (measurements by Channel Number).

Setting the CDMA Transmitter Reference Level

You can set the CDMA transmitter reference level to display either relative power (dB) or absolute power (dBm). The test set defaults to relative. The top graticule (horizontal line) represents the total power in the CDMA channel. The scale per

CDMA Analyzer

Optional CDMA Tx Analyzer Measurement Settings

division is set to 5 dB per division by default, but you can change it if you wish.

If the reference level is set to relative, the reference level is relative to the total power (in dB) in the CDMA channel. If the reference level is set to absolute, the reference level displays the actual power (in dBm) in the CDMA channel.

To Set the CDMA Transmitter Reference Level:

Step	Notes
1. [Level/Location]	
2. On [Reference] select Abs or Rel.	Each time you press this softkey, the selected option changes.
3. [RF IN Loss]	
4. Enter the RF In Loss using the numeric keypad.	If you are using a cable and attenuator connected to the base station power amplifier, enter the combined cable and attenuator RF In Loss here. The RF In Loss can be obtained by measuring the Insertion loss. See “Two Port Insertion Loss” on page 123 . Note: If data had been previously entered in [RF IN Loss], that data will be lost and replaced by the value you enter here.
5. [dB]	

NOTE

The insertion loss of the test cable and high power attenuator must be accounted for to obtain accurate CDMA power measurements such as channel power and pilot power. The insertion loss of the test cable/attenuator combination are accounted for as the RF In Loss, which is an offset applied to the power measurements by the test set.

Setting the Active Channel Threshold Level and Auto Threshold Level

The active channel threshold level is an advanced setting that can be set to indicate which code channels are considered active. Any code channels exceeding this power level are considered active traffic channels and any code channels below this power level are considered inactive (or noise). A horizontal red line on the screen

represents the threshold. The test set can set this level automatically, or you can manually enter a value.

In Auto mode the threshold level moves as the noise fluctuates. The threshold level is set by the test set at an optimal offset above the average noise floor. In Auto mode, you can alter the Auto Threshold Offset. The recommended and default setting is 0 dB. A negative value moves the threshold lower (closer to the noise floor) and is a more aggressive setting that increases the likelihood of interpreting an inactive channel as active. A positive value moves the threshold higher (away from the noise floor) and is a more conservative setting that increases the likelihood of interpreting an active channel as inactive.

In Manual mode the threshold level is fixed and does not move as the noise fluctuates.

To Set the Active Channel Threshold Level:

Step	Notes
1. [Setup]	
2. On [Thresh Lvl] select Auto or Manual .	Each time you press this softkey, the selected option changes. If you choose Manual, you must enter the threshold you want using the numeric keypad, then press [dB].
3. [Auto Thres Offset]	The default value is 0 dB. Optionally, you can enter a negative (more aggressive) or positive (more conservative) value, then press [dB].

Setting Measurement Time

The measurement time setting allows you to alter the speed at which measurements are made. Three choices exist: Slow, Average, and Fast. The test set defaults to Average.

Slow measurement time provides a more accurate measurement at the expense of time.

Fast measurement time provides a quicker measurement at the expense of accuracy.

Average measurement time strikes a balance between measurement speed and accuracy.

To Set the Measurement Time:

Step	Notes
1. [Setup]	
2. On [Meas Time] select Slow , Avg , or Fast .	Each time you press this softkey, the selected option changes.

Setting Quick Page Channel

With the advent of cdma2000, a new control channel called the Quick Page Channel (QPCH) has been added. The QPCH is used to improve standby time in the phone and may or may not be enabled. The QPCH is generally channel number 80. Note that the QPCH is a burst channel. In other words, it is not on all the time. You may have to wait to see the QPCH show up on the trace. The Delta QPCH Power parameter on the metric display can help you determine the level of the QPCH. The QPCH is also a single-wide channel: it only occupies one of the 128 channels. The pilot, paging, and sync control channels are double-wide channels and occupy two of the 128 channels on the display.

To Set the QPCH:

Step	Notes
1. [Setup]	
2. On [Quick Page Channel] select Off or Ch 80 .	Each time you press this softkey, the selected option changes.

Setting Average, Sweep, and Restart

Setting the Sweep

You can select either continuous or single sweep. Continuous sweep provides repeated, ongoing measurements. Single sweep performs a single measurement that is repeated only when you push the Single button.

To set sweep:

Step	Notes
1 [Average/Sweep]	
2 [Continuous] or [Single]	Each time you press one of these menu keys, the other menu key is automatically inactivated.

Setting Averaging

You can choose to have averaging On or Off and set the number of averages you want to take. Averaging only applies to the data, not the trace. When initialized, the Agilent E7495A/B defaults to running average:

- A running average computes the new result as the weighted sum of the last result and the new measurement. The last result is weighted by $(n - 1)/n$. The new result is weighted by $1/n$. Each new measurement produces a new result.

To set averaging:

Step	Notes
1 Set the number of averages. a. [Average/Sweep] b. [Average] c. Enter the number of averages using the numeric keypad. d. [Enter]	

CDMA Analyzer

Optional CDMA Tx Analyzer Measurement Settings

Step	Notes
2	Set averaging On or Off. a. [Average/Sweep] b. [Averaging] c. [Off] or [On]

NOTE

These two steps can be performed in any order. However, if you turn averaging on and a large number of averages has previously been set, there may be a delay before you can change number of averages.

Setting Restart

When you have averaging turned **On** and you are in **Continuous** Sweep mode, you can restart the averaging by pressing the Restart menu key. The Restart key has no effect if you are in **Single** sweep mode.

To restart averaging:

Step	Notes
1	[Average/Sweep]
2	[Restart] This key is unavailable or has no effect when Sweep is set to Single . To restart a Single Sweep measurement, press [Single].

Adding a Marker

Markers can be used on traces to help you visually track up to four signals. Each marker has the following settings:

- **Type:** Provides three options, including:
 - **Off**
 - **Normal**, which places a diamond-shaped, colored marker, along with a number, 1-4, on the trace.
 - **Delta**, is associated with a normal marker. Therefore, a normal marker must exist prior to creating the delta marker. The delta marker displays the

difference between the normal marker position and the delta marker position. Only one delta marker can be associated with a given normal marker. The normal marker must be active when Delta is selected.

- **Marker to Peak:** Places the active marker on the current greatest value of the trace.
- **Marker to Next Peak:** Places the active marker on the current second greatest value of the trace.

Step	Notes
1 [Marker]	
2 [Marker]	
3 [1], [2], [3], or [4]	
4 [Type]	
5 [Off], [Normal], or [Delta]	
6 Locate the marker relative to the trace:	
	• [Marker to Peak] or • [Marker to Next Peak]

Setting the Pass/Fail Limits

- “Setting the Measurement Frequency Error Limits” on page 201
- “Setting the Measurement Time Offset Limits” on page 202
- “Setting the Measurement Estimated Rho Lower Limit” on page 203
- “Setting the Measurement Carrier Feedthrough Upper Limit” on page 204
- “Setting the Measurement Noise Floor Upper Limit” on page 205
- “Setting the Measurement Pilot Power Limits” on page 206
- “Setting the Measurement Delta Page Power Limits” on page 207
- “Setting the Measurement Delta Sync Power Limits” on page 208

The measurement limits settings enable you to alter the values of the test limits for the important measurements on the CDMA Tx Analyzer Screen. These settings affect the metrics color display: red represents fail, green represents pass. Next to the displayed measurement value, a (P) for Pass, or (F) for Fail, will be shown to further indicate whether the value is within or outside the set limits. In addition, the words “ALL PASS” or “FAILURE” are displayed in the bar at the bottom of the screen for all limits which have been turned on.

- **Frequency Error Limits:** Sets the high and low Frequency Error limits for the channel. Any measured frequency error that is outside of the set limits will result in a failure indication. The High limit is set by entering a positive number, and the Low limit is set by entering a negative number.
- **Time Offset Limits:** Sets the high and low time offset limits for the channel. Limits are set in microseconds. Any measured time offset value that is outside of the set limits will result in a failure indication.
- **Est. Rho Limit:** Sets the lower Estimated Rho limit for the channel. Any measured value of estimate Rho this is below the set limit will result in a failure indication.
- **Carrier Feedthrough Limit:** Sets the upper carrier feedthrough limit for the channel. The upper limit is set in dBc and is relative to channel power. Any measured carrier feedthrough value that is above the set limit will result in a failure indication.
- **Noise Floor Limit:** Sets the upper noise floor limits for the channel. The limit is set in dB. Any measured noise floor value above the set limit will result in a failure indication.
- **Pilot Power Limit:** Sets the upper and lower limits of the pilot power. These

limits are set in dBm. Any measured pilot power value that is above or below the set limits will result in a failure indication.

- **Delta Page Power Limits:** Sets the upper and lower limits of the delta page power. The limits are set in dB and are relative to the pilot power. Any measured delta page power value that is above or below the set limit will result in a failure indication.
- **Delta Sync Power Limits:** Sets the upper and lower limit of the delta sync power. The limit is set in dB and is relative to the pilot power. Any measured Delta Sync Power value above or below the set limit will result in a failure indication.

Setting the Measurement Frequency Error Limits

Step	Notes
1 [Setup]	
2 [Limits]	
3 On [Freq Error Limits] select On or Off .	Enables you to toggle the measurement limits function On (active) and Off (inactive). • If set to On, the Frequency Error will change from black to red (fail) or green (pass) and indicate either a “P” (pass) or “F” (fail). If the measured value exceeds either the upper or lower limit, the words ALL PASS in the bar at the bottom of the screen, will change to FAILURE. • If set to Off, the channel freq/number value will be displayed in blue. The area at the bottom of the screen that is used to indicate Pass or Fail will be over-written. The bar at the bottom of the screen, will indicate measurement in progress.

CDMA Analyzer

Optional CDMA Tx Analyzer Measurement Settings

Step	Notes
4	Set the upper limit. [High Limit] - Enter the number on the numeric keypad. [GHz], [MHz], [kHz], or [Hz]
5	Set the lower limit. [Low Limit] - Enter the number on the numeric keypad. [GHz], [MHz], [kHz], or [Hz]

Setting the Measurement Time Offset Limits

Step	Notes
1	On [Time Offset Limits] select On or Off. Enables you to toggle the measurement limits function On (active) and Off (inactive). - If set to On, the displayed time offset metrics will change from blue to red (fail) or green (pass) and indicate either a “P” (pass) or “F” (fail). If the measured values exceed the upper or lower limit, the words ‘ALL PASS’, in the bar at the bottom of the screen, will change to ‘FAILURE’. - If set to Off, the time offset value will be displayed in blue. The bar at the bottom of the screen will indicate measurement in progress.

Step	Notes
2	Set the upper limit. a. [High Limit] b. Enter the number on the numeric keypad. c. [μsec]
3	Set the lower limit. a. [Low Limit] b. Enter the number on the numeric keypad. c. [μsec]

Setting the Measurement Estimated Rho Lower Limit

Step	Notes
1	On [Est. Rho Limit] select On or Off . Enables you to toggle the measurements lower limit function On (active) and Off (inactive). • If set to On, the displayed estimated Rho metrics will change from blue to red (fail) or green (pass) and indicate either a “P” (pass) or “F” (fail). If the measured values exceed lower limit, the words ‘ALL PASS’, in the bar at the bottom of the screen, will change to ‘FAILURE’. • If set to Off, the time estimated Rho value will be displayed in blue. The bar at the bottom of the screen will indicate measurement in progress.

CDMA Analyzer

Optional CDMA Tx Analyzer Measurement Settings

Step	Notes
2	Set the lower limit. a. [Low Limit] b. Enter the number on the numeric keypad. c. [Enter]

Setting the Measurement Carrier Feedthrough Upper Limit

Step	Notes
1	On [Carr Feed-thru Limit] select On or Off . - If set to On, the displayed carrier feedthrough metric will change from blue to red (fail) or green (pass) and indicate either a “P” (pass) or “F” (fail). If the measured value exceeds the upper limit, ALL PASS, in the bar at the bottom of the screen, will change to FAILURE. - If set to Off, the time carrier feedthrough value will be displayed in blue. The bar at the bottom of the screen will indicate measurement in progress.
2	Set the upper limit. a. [High Limit] b. Enter the number on the numeric keypad. c. [dBc]

Setting the Measurement Noise Floor Upper Limit

Step	Notes
1 On [Noise Floor Limits] select On or Off .	Enables you to toggle the measurement limit function On (active) and Off (inactive). • If set to On, the displayed noise floor metrics will change from blue to red (fail) or green (pass) and indicate either a “P” (pass) or “F” (fail). If the measured value exceeds the upper limit, ALL PASS, in the bar at the bottom of the screen, will change to FAILURE. • If set to Off, the time noise floor value will be displayed in blue. The bar at the bottom of the screen will indicate measurement in progress.
2 Set the upper limit. a. [High Limit] b. Enter the number on the numeric keypad. c. [dB]	Upper Limit range: +100 dBc to –150 dBc

Setting the Measurement Pilot Power Limits

Step	Notes
1 On [Pilot Power Limits] select On or Off .	Enables you to toggle the measurement limits function On (active) and Off (inactive). • If set to On, the delta pilot power metrics will change from blue to red (fail) or green (pass) and indicate either a “P” (pass) or “F” (fail). If the measured value exceeds the upper limit or lower limit, ALL PASS, in the bar at the bottom of the screen, will change to FAILURE. • If set to Off, the time pilot power value will be displayed in blue. If NO limits are set to On, the pass/fail bar will not be displayed at the bottom of the screen.
2 Set the upper limit. a. [High Limit] b. Enter the number on the numeric keypad. c. [dBm]	Delta Limit range: –150 to 100 dBm
3 Set the lower limit. a. [Low Limit] b. Enter the number on the numeric keypad. c. [dBm]	Delta Limit range: –150 to 100 dBm

Setting the Measurement Delta Page Power Limits

Step	Notes
1 On [Δ Page Pwr Limits] select On or Off .	Enables you to toggle the measurement limits function On (active) and Off (inactive). • If set to On, the delta page power metrics will change from blue to red (fail) or green (pass) and indicate either a “P” (pass) or “F” (fail). If the measured value exceeds the upper limit or lower limit, ALL PASS, in the bar at the bottom of the screen, will change to FAILURE. • If set to Off, the time delta page power value will be displayed in blue. If NO limits are set to On, the pass/fail bar will not be displayed at the bottom of the screen.
2 Set the upper delta limit. a. [High Limit] b. Enter the number on the numeric keypad. c. [dB]	Delta Limit range: –150 to 100 dB
3 Set the lower delta limit. a. [Low Limit] b. Enter the number on the numeric keypad. c. [dB]	Delta Limit range: –150 to 100 dB

Setting the Measurement Delta Sync Power Limits

Step	Notes
1 On [Δ Sync Pwr Limits] select On or Off .	Enables you to toggle the measurement limits function On (active) and Off (inactive). • If set to On, the delta sync. power metrics will change from blue to red (fail) or green (pass) and indicate either a “P” (pass) or “F” (fail). If the measured value exceeds the upper limit or lower limit, the words ‘ALL PASS’, in the bar at the bottom of the screen, will change to ‘FAILURE’. • If set to Off, the time delta sync. power value will be displayed in blue. If NO limits are set to On, the pass/fail bar will not be displayed at the bottom of the screen.
2 Set the upper delta limit. a. [High Limit] b. Enter the number on the numeric keypad. c. [dB]	Delta Limit range: –150 to 100 dB
2 Set the lower delta limit. a. [Low Limit] b. Enter the number on the numeric keypad. c. [dB]	Delta Limit range: –150 to 100 dB

Setting Up the Signal Generator

You can set up the signal generator while in the Spectrum Analyzer mode from the Setup menu. For more detailed information on the signal generator setup and operation, refer to [“Using the Signal Generator” on page 402](#).

CAUTION

The maximum power for the RF In (Port 1) and RF Out/SWR (Port 2) ports is +20 dBm (100 mW). When using the 8481A/8482A or N8481A/N8482A with Option CFT Power Sensors, the maximum input power applied to the Power Sensor is +24 dBm (300 mW). When using the 8481D Power Sensor, the maximum input power is +20 dBm (100 mW). When directly coupled to a base station (BTS) or Access Network (AN), the test set can be damaged by excessive power applied to any of these three ports.

To prevent damage in most situations when you directly couple the test set to a base station, use the high power attenuator between the test set and the BTS.

NOTE

The lowest level the signal generator can go to is -90 dBm. In order to achieve a lower level, you must use an external attenuator. You can compensate for the attenuator in the RF Out Loss.

Step	Notes
1	[Setup]
2	[Sig Gen]
3	[Freq/Chan]
4	[Frequency] or [Channel]
5	Enter the channel or frequency using the numeric keypad.
6	- For channel select [Rev] or [Fwd] - For frequency select [GHz], [MHz], [kHz], or [Hz],

CDMA Analyzer

Optional CDMA Tx Analyzer Measurement Settings

Step	Notes
7 [Mod Format]	
8 Select the channel standard from the list using the up and down arrow buttons.	
9 [Select]	
10 Set the RF output amplitude	You may also enter a new value for amplitude by turning the rotary knob until the desired value is displayed or using the up and down arrow keys.
a. [Amplitude]	
b. Enter the amplitude value using the numeric keypad.	
c. [dBm].	
11 If you have previously stored RF Out Loss from an insertion loss measurement, go to the next step. Or Press [RF OUT Loss] to select On and enter the RF Out Loss value.	For information on the effects of the RF Out Loss function on the amplitude, refer to “Using the RF OUT Loss field,” below. Each time you press this softkey, the selected option changes.
12 Connect to the base station.	
13 On [Enable Sig Gen] select On .	Each time you press this softkey, the selected option changes.
14 On [RF] select On .	Each time you press this softkey, the selected option changes.

Using the RF OUT Loss field

The RF OUT Loss field is used when it is necessary to test the receiver sensitivity of a typical base station. The test set's source will typically go down to -95 dBm. In order to reach -113 dBm for sensitivity testing, you must use an external attenuator. The measured value of the attenuator and connecting cables are entered into this field. This value is then used when this field is set to **On**. When this field is set to **On**, the test set will set the RF generator level to the correct level offset by the

external attenuator/cabling. When you set the RF Generator to -113 dBm (with the RF OUT Loss field turned **On** and the external attenuator/cabling loss value entered) the output at the end of the RF test cabling is -113 dBm.

Example: If you want to set the signal generator to -113 dBm, the attenuator and RF cabling measures 42.51 dB (measured with the 2 port insertion loss measurement screen prior to this test), the RF OUT Loss field is turned **On** (with the 42.51 dB loss value entered). The actual RF output of the signal generator is -70.49 dBm, the attenuator and RF cabling attenuated the signal to the desired level; so the RF signal at the end of the test cable/attenuator is -113 dBm. This also points out the importance of accurately measuring the loss of the attenuator and connecting cables.

Metrics Provided by the CDMA Tx Analyzer Measurement

This section contains descriptions of the individual CDMA transmit parameters in the metric display of the screen. The “Interpretation of CDMA Tx Analyzer Measurement Results” section contains expected result values and possible causes of error if the expected results are not met.

Frequency Error

Frequency error is the frequency difference between your transmitter's actual center frequency and the frequency (or channel) you entered.

PN Offset

The PN Offset is a “short code” sequence that provides a unique identifier for each sector of each cell site. The PN Offsets are applied to the I and Q signals before modulation. PN Offsets are offset in time by 52.08 μ s and they repeat every 26.666 ms. This yields 512 unique short code sequences (0-511). The mobile phone needs the PN Offset to decode information in the Sync and Paging channels, which are transmitted by the base station.

Time Offset

The Time Offset compares the PN Offset timing with the overall system time. This measurement checks the start of the PN offset in comparison to either the GPS signal or the Even Second clock signal. For example, PN Offset 0 should repeat exactly on the rising edge of the Even Second clock. PN Offset 1 should repeat 52.08 μ s after the rising edge of the Even Second clock, and so forth. Any error in time from that event is reported as a Time Offset.

Channel Power

Channel Power is the integrated power within a defined bandwidth. For CDMA the channel bandwidth is defined to be 1.25 MHz. Channel Power measures the power the base station is transmitting across the entire 1.25 MHz CDMA channel.

Estimated Rho

Estimated Rho is the measure of the modulation quality for a CDMA transmitter. This measurement is analogous to measuring FM accuracy and distortion in an AMPS network or EVM in a TDMA system. A Rho value of 1.0 is perfect,

indicating that all of the power is being transmitted correctly.

Carrier Feedthrough

Carrier Feedthrough is a result of the RF carrier signal feeding through the I/Q modulator and riding on the output circuitry without being modulated. Carrier Feedthrough is a common cause of bad Rho measurements.

Noise Floor

Noise Floor is the average power of all the inactive channels.

Pilot Power

Pilot Power is the total power in the Pilot code channel, expressed in dBm. The transmit power of the Pilot Channel signal for a given base station is normally constant.

Delta Page Power

Delta Page Power is the amplitude difference between the Paging Channel and Pilot Channel, expressed in dB. The transmit power of the Paging Channel is constant and can be set at a value relative to the Pilot Power. A common value is -4 dB relative to the Pilot.

Delta Sync Power

Delta Sync Power is the amplitude difference between the Sync Channel and Pilot Channel, expressed in dB. The transmit power of the Sync Channel is constant and may be set at a value relative to the Pilot Power. A common value is -10 dB relative to the Pilot.

Delta Quick Page Channel Power

Delta Quick Page Channel (QPCH) Power is the amplitude difference between the Quick Page Channel and Pilot Channel, expressed in dB. The QPCH is a bursted channel and is not on all the time. In order to capture the level of the QPCH, the statistic measures and holds the peak level of the QPCH. Until a QPCH has been measured, the value will be dashes. When “on”, the level of the QPCH is constant and is set at a value relative to the Pilot Power. The QPCH digital gain level can be set to 2, 1, 0, -1, -2, -3, -4, and -5 dB relative to the Pilot.

Interpretation of CDMA Tx Analyzer Measurement Results

This section contains expected result values and possible causes of error if the expected results are not met.

Frequency Error

The standards specify very tight Frequency Error performance. In the PCS bands, the 0.05 parts-per-million specification translates to only 99 Hz at a carrier frequency of 1980 MHz or 40 Hz at 850 MHz cellular frequencies. Frequency Error shows up as uncorrelated power that adds to the noise floor or shows up in other Walsh codes.

If a particular site loses its reference to GPS time, its reference signals will begin to drift over time. Phones already using the site can remain on the air because they derive their timing from the signals transmitted by the base station. However, phones using other sites/sectors may be prevented from using the site because they are confused by the error in frequency. This creates what is known as the “island cell effect”. By itself, the cell is still functional. To the rest of the system, it's inaccessible.

This island cell effect can be caused by a failure in the site's GPS receiver and timebase distribution network. Using the test set's Internal GPS receiver provides an independent time reference that will allow you to determine if this cell site is out of sync with the rest of the network (“island cell effect”).

PN Offset

Verify that the PN Offset is correct. If you are in Manual mode, the PN Offset will display the value you entered. Make sure the Time Offset is small (less than 3 μ s). If the Time Offset is greater than expected, see the section on Time Offset below. If you are in Auto mode, the test set will tune to the PN Offset with the smallest Time Offset. If an incorrect PN Offset is displayed, the Time Offset will likely be very large.

Time Offset

The CDMA standards specify a maximum offset of 10 μ s; generally 5 μ s is a recommended maximum. If the Time Offset is large enough, an “island cell” can occur. The “island cell effect” was mentioned already when discussing Frequency Error.

Interpretation of CDMA Tx Analyzer Measurement Results

A phone moving outward toward the limit of its cell will need to acquire the adjacent cell in order to hand off. If the time offset of the target cell is too far from that of the current site, the handoff may not happen.

The dependence of the phone on correct system time limits the physical distance to a target cell's antenna. Each PN Offset is 52.08 μ s; if the propagation delay is too long, the received PN Offset may be different from the value designated on the Sync channel. This difference can confuse the phone, causing the handoff to fail.

Another cause of timing error is a bad GPS receiver or timing distribution network within the base station. To test your base station's GPS and timing distribution system, you can use the internal GPS receiver to generate an accurate timing reference for the test set to use while performing base station tests.

Channel Power

When making channel power measurements, make sure you have accounted for the loss of the test cable and high power attenuator you are using. If you do not know the loss of your test cable and high power attenuator configuration, perform an insertion loss measurement and enter the insertion loss as the RF In Loss value. For more information see [“Two Port Insertion Loss” on page 123](#).

If the channel power is lower than expected, verify you have a good connection to the RF output of the base station. Also, verify the cable you are using to connect to the base station is not faulty. A low channel power may also indicate a bad power amplifier.

Inaccurate channel power (high or low) may indicate an incorrect power setting at the base station.

Estimated Rho

The CDMA base station standard specifies that Rho must be greater than 0.912. Typical values for a healthy base station are greater than 0.94.

Rho failures can indicate problems in:

- Compression in linear amplifiers
- Magnitude and phase errors in the IQ modulator
- Phase non-linearity (group delay)
- Spurious signals in the transmission path
- Carrier feedthrough

Because the uncorrelated power appears as interference to the phones, poor Rho performance will affect the sector's capacity. The added interference can require that

the signal on traffic channels be raised to overcome the interference. This may, in turn, be seen as further interference. At some point, the site will have to shed calls in order to supply the remaining calls with enough signal versus the interference in the system.

Carrier Feedthrough

A good carrier feedthrough level is less than -25 dB. The IS-97 standard does not specify carrier feedthrough; however, this measurement provides an additional tool to troubleshoot the base station's transmitter.

In the frequency domain, carrier feedthrough can show up as an uncorrelated energy spike that can be seen on the spectrum analyzer by closely spanning into the top of the CDMA signal. The effects of carrier feedthrough can also show up as higher noise levels on the Code Domain Power screen. The inactive Walsh codes will be pushing the -27 dB specification for noise. Carrier feedthrough can be caused by the lack of isolation across the mixer and cavity of the transmitter's I/Q modulator. Shielding can help reduce carrier feedthrough.

Noise Floor

A good noise floor value is between -40 dB and -45 dB for modern base stations. If the noise floor is above these values (for example, -20 dB), the modulator may be the source of the added noise. Another possibility is a problem with the base station's channel card. The channel card generates the individual Walsh codes.

Pilot Power

If the measured value of pilot power is more than ± 0.5 dB different from the intended setting, it may indicate the following:

- There has been a change made to the digital gain setting of the pilot channel.
- The base station power amplifier has a problem.

Delta Page Power

If the measured value of Delta Page Power is more than ± 0.5 dB different from the intended setting, it may indicate that the digital gain setting for the Paging Channel has been changed.

Delta Sync Power

If the measured value of Delta Sync Power is more than ± 0.5 dB different from the intended setting, it may indicate that the digital gain setting for the sync channel has been changed.

Delta Quick Page Channel Power

If the measured value of Delta QPCH Power is more than +/-0.5 dB different from the intended setting, it may indicate that the digital gain setting for the QPCH has been changed.

8

CDMA Over Air

- “Using the CDMA Over Air Tool” on page 220
- “Preparing to Make CDMA Over Air Measurements” on page 220
- “Criteria for Making Valid CDMA Over Air Measurements” on page 221
- “Performing a Basic CDMA Over Air Measurement” on page 222
- “Displaying Location Information Using GPS” on page 224
- “Codogram Display” on page 226
- “Performing a Codogram Measurement” on page 226
- “Setting Amplifier Capacity Metrics” on page 227
- “Interpreting the Display” on page 229
- “Optional CDMA Over Air Measurement Settings” on page 231
- “Adding a Marker” on page 238
- “Setting the Pass/Fail Limits” on page 240
- “Setting Up the Signal Generator” on page 249
- “Metrics Provided by CDMA Over Air Measurements” on page 252
- “Interpretation of CDMA Over Air Measurement Results” on page 256

Using the CDMA Over Air Tool

CDMA over air measurements provide a quick method of verifying CDMA transmitter performance. These transmitter measurements can be made on a base station from the convenience of your vehicle without taking the base station out of service. Over air measurements are especially useful in maintaining hard-to-access cell sites such as pole top base stations. *Option 210 - cdmaOne/CDMA2000 OTA* may also be used to measure signals at a coupled port on the transmitter.

For out-of-service CDMA transmitter measurements, *Option 2000 - cdmaOne / CDMA 2000 Analyzer* is recommended. For more information refer to [“CDMA Analyzer” on page 181](#).

CAUTION

To achieve valid over-the-air measurements, the test set must be stationary (not moving). An alternative is to make these measurements from a coupled port at the base station.

Preparing to Make CDMA Over Air Measurements

An important consideration when making CDMA over air measurements is your location relative to the base station. There must be no obstructions between your location and the base station antennas. Also, the GPS antenna must be able to “see” the satellites to obtain lock. Using internal GPS for the time reference has the same advantages mentioned for CDMA Tx Analyzer measurements (“island cell” detection).

You must know the channel or frequency and the PN offset of the CDMA signal to be analyzed. Each base station sector has a unique PN offset. For more information on PN offsets refer to the [“Metrics Provided by CDMA Over Air Measurements” on page 252](#).

Once you have connected the proper antenna to the test set, chosen a stationary location, and verified that you have a clear view of the base station antennas, you can perform CDMA over air measurements.

If this is the first CDMA over air measurement for this base station, you must find a location that meets the criteria for making a valid measurement. Your location must have a dominant pilot and very low multipath power. If you have made CDMA over air measurements at this location before and know it provides valid measurements, skip to [“Performing a Basic CDMA Over Air Measurement” on page 222](#).

Criteria for Making Valid CDMA Over Air Measurements

The first step in making valid CDMA over air measurements is to identify a target base station to measure. Then, for your measurements to be valid, you must find a location near the target base station with a sufficiently strong CDMA signal. CDMA over air measurements will experience interference from other CDMA signals on the same RF channel and from multipath echoes. The code domain power view measures two key parameters to indicate these effects:

- Pilot dominance—The difference between the energy of the strongest pilot channel and the combined energy in the second and third strongest pilot channels (expressed in dB). Ideally, this value should be very large (> 16 dB)
- Multipath power—The amount of power, of the dominant pilot signal, that is dispersed outside the main correlation peak due to multipath echoes (expressed in dB). Ideally, this value should be very small (< 0.1 dB). **Multipath power** is the result of portions of the original broadcast signal arriving at the receiving antenna out of phase with the main power of the original signal. This can be caused by the signal being reflected off objects, such as buildings, or being refracted through the atmosphere differently from the main signal. These out of phase signals can cancel power from the main signal or appear as noise interference at the receiver.

The table below shows the quality of the over air code domain measurements with respect to pilot dominance and multipath power.

Table 8-1 Over Air Code Domain Measurement Quality

Measurement Quality	Pilot Dominance	Multipath Power
Very good	> 16 dB	< 0.1 dB
Fair	> 10 dB	< 0.4 dB
Marginal	> 8 dB	< 0.7 dB

The default measurement limits for pilot dominance and multipath power are set to give “fair” measurement quality. If these limits are met, the pilot dominance and multipath power values will be displayed in green. When the pilot dominance and multipath power parameters are outside the acceptable limits, the parameters will turn red. If this occurs, you must move to a different location that meets the “fair” criteria defined above.

CDMA Over Air

Using the CDMA Over Air Tool


In general, you should always use a preselector filter for the band of interest to prevent strong signals from swamping out the signal of interest. Agilent offers these preselectors and antennas:

- *Option 810—Cellular downlink band preselector and antenna*
- *Option 811—PCS downlink band preselector and antenna*
- *Option 812—Korean PCS downlink band preselector and antenna*

Performing a Basic CDMA Over Air Measurement

Step	Notes
1 Mode	
2 [Over Air]	
3 [CDMA Over Air]	
4 [Chan Std]	
5 Select the channel standard you want using the up and down arrow buttons.	
6 [Select]	
7 On [Units] select Chan or Freq.	Each time you press this softkey, the selected option changes.
8 [Channel] or [Frequency]	• If you selected Chan in the previous step, select [Channel]. • If you selected Freq., select [Frequency].
9 Enter the channel or frequency using the numeric keypad.	
10 [Fwd]	Selects the forward CDMA channel.

Step	Notes
11	Verify that on [Fr/Time Ref] GPS is selected. If not, press [Fr/Time Ref], then press [GPS].
12	On [PN Offset] select Auto or Manual . - In Auto mode the test set finds the PN offset of the strongest pilot signal and displays the value in the metrics display. The delay is derived from the found PN offset. - In Manual mode you must enter the PN offset using the numeric keypad. The delay is derived from the entered PN offset.
13	[Level/Location]
14	[RF IN Loss]
15	Set the RF IN Loss to 0 dB using the numeric keypad.
16	[dB]
17	Connect to the antenna.



CDMA Over Air

Using the CDMA Over Air Tool

NOTE

The test set does not record data for post-processing. It provides a snapshot of CDMA base station transmit parameters at that location.

NOTE

During a CDMA over air measurement, a yellow triangle symbol may temporarily appear beside “GPS” in the lower right. The yellow triangle indicates that the test set is re-synching with the GPS even second pulse. Once the test set is synchronized, a green dot appears in place of the triangle. If the GPS is unavailable, a red X appears. If this happens, you must choose another reference.

Displaying Location Information Using GPS

If you are making CDMA over air measurements at a location you previously established as valid, Agilent recommends using GPS to verify that you are at the location from which you previously measured.

If you are making CDMA over air measurements from a new location, once you validate that the location provides a dominant pilot and low multipath power, Agilent recommends that you record the latitude and longitude coordinates of this location using GPS. Later measurements should be made from this precise location to provide performance trends.

For additional information on the GPS Data function, refer to [“Displaying GPS Location Data” on page 462](#).

To Display GPS Location Information:

Step	Notes
1	[Level/Location]

Step	Notes
2 On [Show GPS Location] select On .	Displays GPS satellite location information. Uses the internal GPS to capture the location of a measurement. The GPS information can be used to return to the same location. The Time Ref (Freq/Chan/Time Ref mode) button must be set to internal GPS for this function to be active. Information logged includes longitude, latitude, altitude (feet/meters), and the number of satellites tracked. Every time you press [Show GPS Location], the GPS location display alternates between On and Off.

NOTE

If you prefer to have an electronic copy of the location information, see [“Saving Data” on page 469](#).

Codogram Display

This view provides a history of the spectrum. The codogram plot rises over time until it fills the graphical section of the display. Your most recent data appears at the bottom of the display, and your oldest data (several minutes ago to several hours ago, depending on your settings) appears at the top of the display. In this way, you can clearly see the changes in power that occur over a period of time. You can use it to:

- see traffic channels as they initiate and terminate,
- track traffic channel call levels over time.

The **Update Interval** is the interval, measured in whole seconds, between successive records displayed on the codogram. In other words, if you set the update interval to 5 seconds, the codogram display will not update until after the first complete measurement following a gap of five seconds. Alternatively, you can set the update interval to provide the maximum data collection speed by pressing [Max Speed], or by setting the update interval to 0 (zero) seconds.

NOTE

It is not always possible for the analyzer to match the update interval you specify. It is possible, for example, to set your update interval to zero seconds (the maximum speed), and then to find that the analyzer can not update any faster than once every two seconds.

Performing a Codogram Measurement

Step	Notes
1 [Display]	
2 [Codogram]	This displays the menu that controls the appearance and behavior of the codogram display.

Step	Notes
3 On [Codogram] select On or Off .	Each time you press this key, the codogram state switches between On and Off . When you set [Codogram] to On, [Reset Codogram], [Update Interval] and [Palette] become active.
4 [Reset Codogram]	This restarts the data capture for the Codogram. You may see the screen freeze for a few seconds before the display starts plotting data again.
5 If desired set the update interval: a. [Update Interval] b. Enter the interval number of seconds using the numeric keypad. c. Select [sec] or [Max Speed].	Allows you to set the update interval to 0, 1, or more seconds. Alternatively, you may set it to automatically determine the update interval that provides the maximum data collection speed. If you need to return to the automatically determined maximum capture speed, you must press [Update Interval] followed by a numeric keypad key to access [Max Speed].
6 If desired set the display color: a. [Palette] b. Select [Full Color] or [Grayscale].	The color/grayscale top and bottom mappings are determined by the Ref Level and Scale/Div settings. To change the mapping, go to [Level/Location] and change [Ref Level] and [Scale/Div].

NOTE

The key labelled “Update Interval” was labelled “Capture Interval” in earlier versions of the software (v.04.00 or earlier). The way the key works has not changed. Only the key label has changed to clarify what the key does.

Setting Amplifier Capacity Metrics

The Amplifier Capacity measurement is an estimate of the amount of power amplifier capacity that is being used, expressed in percent of maximum. Amplifier capacity properties must be properly set to make valid amplifier capacity

CDMA Over Air

Using the CDMA Over Air Tool

measurements. Amplifier capacity metrics are amplifier capacity, peak amplifier capacity, and average amplifier capacity.

A CDMA base station is typically set up with a specified amount of power allocated to the pilot channel, and specified power settings of the paging and sync channels are defined relative to the pilot channel. Occasionally, the paging and sync channels power settings will also be specified in absolute power units (watts or dBm). Given the pilot, paging, and sync power setup values and the maximum power output of the amplifier, the percentage amplifier capacity setup parameters can be determined.

Setting Amplifier Capacity Properties:

Step	Notes
1 [Reset/Display/Amp Cap]	
2 On [Amp Cap] select On .	
3 [Pilot Pwr]	
4 Enter the pilot power in watts, using the numeric keypad.	The pilot power is the total power in the dominant pilot signal, expressed in dBm or in watts.
5 [dBm] or [W]	
6 [Max PA Pwr]	
7 Enter the maximum power of the power amplifier in watts, using the numeric keypad.	A base station power amplifier is specified to have a maximum power limit.
8 [dBm] or [W]	
9 [Delta Page Pwr]	
10 Enter the Delta Page Pwr in dB, using the numeric keypad.	The delta paging power is the power level of the paging channel expressed as a dB value relative to the pilot channel power level.
11 [dB]	
12 [Delta Sync Pwr]	

Step	Notes
13 Enter the Delta Sync Pwr in dB, using the numeric keypad.	The delta sync power is the power level of the the sync channel expressed as a dB value relative to the pilot channel power level.
14 [dB]	

Interpreting the Display

The CDMA Over Air screen is divided into three sections: the code domain trace display, strongest pilot trace display, and metrics display.

The *code domain trace display* contains 128 Walsh codes, which are shown in a bit-reversed order to represent the combined code channels for the varying data rate traffic channels. The Y-axis labels display the relative power (dB) or absolute power (dBm), threshold level, and dB/division. The X-axis labels display active channel Walsh Code numbers. Active code channels shown on the display include:

- Pilot (red)
- Page (green)
- Sync (blue)
- Quick page (light blue)
- IS-95 traffic (yellow)
- cdma2000 traffic (orange)
- Unknown traffic (tan)
- Noise (light gray)

The *strongest pilot trace display* contains the pilot dominance and multipath power parameters. Awareness of these two parameter values helps you be sure that you are making valid measurements on the sector of interest.

The *metrics display* shows 18 measurement parameters displayed below the trace display in three columns and six rows—each with a value and units. For more information about the metric display, refer to [“Metrics Provided by CDMA Over Air Measurements” on page 252](#).

The frequency indicator is at the bottom right corner of the screen, the time reference indicator at the bottom left. For each indicator the text indicates which reference you have chosen. A green LED indicates a locked condition. A red “X”

CDMA Over Air

Using the CDMA Over Air Tool

indicates an unlocked condition.

Optional CDMA Over Air Measurement Settings

You can alter several optional measurement parameters in CDMA Over Air:

- “Setting the Channel or Frequency Step” on page 231
- “Setting the PN Increment” on page 232
- “Setting the Transmitter Reference Level” on page 232
- “Setting the Active Channel Threshold Level and Auto Threshold Level” on page 234
- “Resetting Amplifier Capacity and Traffic Metrics” on page 235
- “Setting Measurement Time” on page 235
- “Setting Quick Page Channel” on page 236
- “Setting Average, Sweep, and Restart” on page 237
- “Adding a Marker” on page 238
- “Setting the Pass/Fail Limits” on page 240
- “Metrics Provided by CDMA Over Air Measurements” on page 252
- “Interpretation of CDMA Over Air Measurement Results” on page 256

Setting the Channel or Frequency Step

You can set the channel or frequency step so you can quickly increment to the next channel or frequency using the Up Arrow and Down Arrow buttons.

Step	Notes
1 [Chan Step] or [Freq Step]	This choice depends on the [Units] mode you are using.
2 Enter the desired channel or frequency step using the numeric keypad.	
3 [Enter]	Notice (and verify) the number you entered below the Chan Step or Freq Step text on the corresponding button.

Setting the PN Increment

The PN Increment allows you to choose the increment step for the PN Offset. Typically the PN Increment is set to 1 when measuring CDMA transmitter performance while connected to the base station via RF cable.

The PN Increment field enables you to search based on a step size of your choice. If PN Increment = 1 (default), the search will step through PN values by one PN at a time. If PN Increment = 5, it will step through PN values 0, 5, 10, and so on. The Measured PN displayed will be a multiple of 5, even if the actual PN is not a multiple of 5. If you know that all base stations in the area have fixed increments, then set the PN Increment field to that increment value. If you don't know, then use the default value of 1.

Step	Notes
1. [PN Inc]	
2. Enter the PN Increment using the numeric keypad.	The maximum value you can enter is 15.
3. [Enter]	Notice (and verify) that the number you entered for your chosen PN Increment number appears below the PN Inc text on the corresponding button.

Setting the Transmitter Reference Level

You can set the CDMA transmitter reference level to display either relative power (dB) or absolute power (dBm). The test set defaults to relative. The top graticule (horizontal line) represents the total power in the CDMA channel. The scale per division is set to 5 dB per division.

If the reference level is set to relative, the reference level is relative to the total power (in dB) in the CDMA channel. If the reference level is set to absolute, the reference level displays the actual power (in dBm) in the CDMA channel.

Step	Notes
1 [Level/Location]	

CDMA Over Air
Optional CDMA Over Air Measurement Settings

		Step	Notes
2	On [Reference] select Abs or Rel.		Each time you press this softkey, the selected option changes.

Setting the Active Channel Threshold Level and Auto Threshold Level

The active channel threshold level is an advanced setting that can be set to indicate which code channels are considered active. Any code channels exceeding this power level are considered active traffic channels and any code channels below this power level are considered inactive (or noise). A horizontal red line on the screen represents the threshold level. The test set can set this level automatically, or you can manually enter a value.

In Auto mode the threshold level moves as the noise fluctuates. The threshold level is set by the test set at an optimal offset above the average noise floor. If you choose Auto mode, you can alter the auto threshold offset. The recommended and default setting is 0 dB. A negative value moves the threshold lower (closer to the noise floor) and is a more aggressive setting that increases the likelihood of interpreting an inactive channel as active. A positive value moves the threshold higher (away from the noise floor) and is a more conservative setting that increases the likelihood of interpreting an active channel as inactive.

In Manual mode the threshold level is fixed and does not move as the noise fluctuates.

To Set the Active Channel Threshold Level:

Step	Notes
1 [Setup]	
2 On [Thresh Lvl] select Auto or Manual .	Each time you press this softkey, the selected option changes. If you choose Manual, you must enter the threshold you want using the numeric keypad, then press [dB].
3 [Auto Thres Offset]	The default value is 0 dB. Optionally, you can enter a negative (more aggressive) or positive (more conservative) value, then press [dB].

Resetting Amplifier Capacity and Traffic Metrics

The amplifier capacity metrics such as the peak and average amplifier capacity and peak and average utilization can be reset. If you prefer to reset these parameters manually, you may do so using the [Reset Metrics] menu key. The test set may automatically reset these parameters for you if you are using the PN Offset Auto mode.

In PN Offset Auto mode, if the test set finds a new dominant pilot (from a stronger base station signal), the peak and average amplifier capacity values will be reset. The test set will decode the signal containing the new dominant pilot and gather new amplifier capacity data for this signal. In PN Offset Manual mode if the test set finds a new dominant pilot, the signal will not be decoded and the test set will display noise in the code domain power display. The amplifier capacity metrics will be unaffected and the test set will not gather data until the desired signal becomes dominant again.

To Manually Reset the Amplifier Capacity Metrics:

Step	Notes
1	[Reset/Display/Amp Cap]
2	[Reset Metrics]

Setting Measurement Time

The Measurement Time setting allows you to alter the speed at which measurements are being made. Three choices exist: Slow, Average, and Fast. The test set defaults to Average. Slow measurement time provides a more accurate measurement at the expense of time. Fast measurement time provides a quicker measurement at the expense of accuracy. Average measurement time strikes a balance between measurement speed and measurement accuracy.

Step	Notes
1	[Setup]
2	On [Meas Time] select Slow, Avg, or Fast. Each time you press this softkey, the selected option changes.

Setting Quick Page Channel

With the advent of cdma2000, a new control channel called the Quick Page Channel (QPCH) has been added. The QPCH is used to improve standby time in the phone and may or may not be enabled. The QPCH is generally channel number 80. Note that the QPCH is a bursted channel. In other words, it is not on all the time. You may have to wait to see the QPCH show up on the trace. The Delta QPCH Power parameter on the metric display can help you determine the level of the QPCH. The QPCH is also a single-wide channel: it only occupies one of the 128 channels. The pilot, paging, and sync control channels are double-wide channels and occupy two of the 128 channels on the display.

To Set the QPCH:

Step	Notes
1 [Setup]	
2 [More 1 of 2]	
3 On [Quick Page Channel] select Off or Ch 80 .	Each time you press this softkey, the selected option changes.

Setting Average, Sweep, and Restart

Setting the Sweep

You can select either continuous or single sweep. Continuous sweep provides repeated, ongoing measurements. Single sweep performs a single measurement that is repeated only when you push the Single button.

To set sweep:

Step	Notes
1 [Average/Sweep]	
2 [Continuous] or [Single]	Each time you press this softkey, the selected option changes.

Setting Averaging

You can choose to have averaging on or off and set the number of averages you want to take. Averaging only applies to the data, not the trace. You can select from the following types of averaging: When initialized, the Agilent E7495A/B defaults to running average:

- A running average computes the new result as the weighted sum of the last result and the new measurement. The last result is weighted by $(n - 1)/n$. The new result is weighted by $1/n$. Each new measurement produces a new result.

To set averaging:

Step	Notes
1 Set the number of averages. a. [Average/Sweep] b. [Average] c. Enter the number of averages using the numeric keypad. d. [Enter]	

CDMA Over Air

Optional CDMA Over Air Measurement Settings

Step	Notes
2	Set averaging On or Off.
a.	[Average/Sweep]
b.	[Averaging]
c.	[Off] or [On]

NOTE

These two steps can be performed in any order. However, if you turn averaging on and a large number of averages has previously been set, there may be a delay before you can change number of averages.

Setting Restart

When you have averaging turned **On** and you are in **Continuous** Sweep mode, you can restart the averaging by pressing the Restart menu key. The Restart key has no effect if you are in **Single** sweep mode.

To restart averaging:

Step	Notes
1	[Average/Sweep]
2	[Restart]
	This key is unavailable or has no effect when Sweep is set to Single . To restart a Single Sweep measurement, press [Single].

Adding a Marker

Markers can be used on traces to help you visually track up to four signals. Each marker has the following settings:

- **Type:** Provides three options, including:
 - **Off**
 - **Normal**, which places a diamond-shaped, colored marker, along with a number, 1-4, on the trace.
 - **Delta**, is associated with a normal marker. Therefore, a normal marker must exist prior to creating the delta marker. The delta marker displays the

difference between the normal marker position and the delta marker position. Only one delta marker can be associated with a given normal marker. The normal marker must be active when Delta is selected.

- **Marker to Peak:** Places the active marker on the current greatest value of the trace.
- **Marker to Next Peak:** Places the active marker on the current second greatest value of the trace.

Step	Notes
1 [Marker]	
2 [Marker]	
3 [1], [2], [3], or [4]	
4 [Type]	
5 [Off], [Normal], or [Delta]	
6 Locate the marker relative to the trace:	
	• [Marker to Peak] or • [Marker to Next Peak]

CDMA Over Air

Optional CDMA Over Air Measurement Settings

Setting the Pass/Fail Limits

- “Setting the Measurement Frequency Error Limits” on page 241
- “Setting the Measurement Time Offset Limits” on page 242
- “Setting the Measurement Estimated Rho Lower Limit” on page 243
- “Setting the Measurement Carrier Feedthrough Upper Limit” on page 244
- “Setting the Measurement Noise Floor Upper Limit” on page 245
- “Setting the Measurement Pilot Power Limits” on page 246
- “Setting the Measurement Delta Page Power Limits” on page 247

The measurement limits settings enable you to alter the values of the test limits for the important measurements on the CDMA Over the Air Analyzer Screen. These settings affect the metrics color display: red represents fail, green represents pass. Next to the displayed measurement value, a (P) for Pass, or (F) for Fail, will be shown to further indicate whether the value is within or outside the set limits. In addition, the words “ALL PASS” or “FAILURE” are displayed in the bar at the bottom of the screen for all limits which have been turned on.

- **Frequency Limits:** Sets the high and low Frequency Error limits for the channel. Any measured frequency error that is outside of the set limits will result in a failure indication. The High limit is set by entering a positive number, and the Low limit is set by entering a negative number.
- **Time Offset Limits:** Sets the high and low time offset limits for the channel. Limits are set in microseconds. Any measured time offset value that is outside of the set limits will result in a failure indication.
- **Est. Rho Limit:** Sets the lower Estimated Rho limit for the channel. Any measured value of estimate Rho this is below the set limit will result in a failure indication.
- **Carrier Feedthrough Limit:** Sets the upper carrier feedthrough limit for the channel. The upper limit is set in dBc and is relative to channel power. Any measured carrier feedthrough value that is above the set limit will result in a failure indication.
- **Noise Floor Limit:** Sets the upper noise floor limits for the channel. The limit is set in dB and is absolute. Any measured noise floor value above the set limit will result in a failure indication.

- Pilot Power Limit:** Sets the upper and lower limit of the delta page power. This limit is set in dBm. Any measured value that is above or below the set limit will result in a failure indication.
- Delta Page Power Limits:** Sets the upper and lower limit of the delta page power. The limit is set in dB and is relative to the pilot power. The Delta Page Power Limit calculates a value relative to Carrier Power. If the calculated delta value exceeds the maximum or minimum set value, a failure is indicated.
- Delta Sync Power Limits:** Sets the upper and lower limit of the delta sync power. The limit is set in dB and is relative to the pilot power. Any measured Delta Sync Power value above or below the set limit will result in a failure indication.

Setting the Measurement Frequency Error Limits

Step	Notes
1	[Setup]
2	[More 1 of 2]
3	[Limits]
4	On [Freq Error Limits] select On or Off. Enables you to toggle the measurement limits function On (active) and Off (inactive). - If set to On, the Frequency Error will change from blue to red (fail) or green (pass) and indicate either a “P” (pass) or “F” (fail). If the measured value exceed either the upper or lower limit, ALL PASS, in the bar at the bottom of the screen, will change to FAILURE. - If set to Off, the channel freq/number value will be displayed in blue. The area at the bottom of the screen that is used to indicate Pass or Fail will be over-written. The bar at the bottom of the screen, will indicate measurement in progress.

CDMA Over Air

Optional CDMA Over Air Measurement Settings

Step	Notes
5	Set the upper limit. [High Limit] - Enter the number on the numeric keypad. [GHz], [MHz], [kHz], or [Hz]
6	Set the lower limit. [Low Limit] - Enter the number on the numeric keypad. [GHz], [MHz], [kHz], or [Hz]

Setting the Measurement Time Offset Limits

Step	Notes
1	On [Time Offset Limits] select On or Off. Enables you to toggle the measurement limits function On (active) and Off (inactive). - If set to On, the displayed time offset metrics will change from blue to red (fail) or green (pass) and indicate either a “P” (pass) or “F” (fail). If the measured values exceed the upper or lower limit, ALL PASS, in the bar at the bottom of the screen, will change to FAILURE. - If set to Off, the time offset value will be displayed in blue. The bar at the bottom of the screen will indicate measurement in progress.

Step	Notes
2	Set the upper limit. a. [High Limit] b. Enter the number on the numeric keypad. c. [μsec]
3	Set the lower limit. a. [Low Limit] b. Enter the number on the numeric keypad. c. [μsec]

Setting the Measurement Estimated Rho Lower Limit

Step	Notes
1	On [Est. Rho Limit] select On or Off . Enables you to toggle the measurements lower limit function On (active) and Off (inactive). - If set to On, the displayed estimated Rho metrics will change from blue to red (fail) or green (pass) and indicate either a “P” (pass) or “F” (fail). If the measured values exceed lower limit, ALL PASS, in the bar at the bottom of the screen, will change to FAILURE. - If set to Off, the time estimated Rho value will be displayed in blue. The bar at the bottom of the screen will indicate measurement in progress.

CDMA Over Air

Optional CDMA Over Air Measurement Settings

Step	Notes
2	Set the lower limit.
	Lower Limit range: 0 to 1
	a. [Low Limit]
	b. Enter the number on the numeric keypad.
	c. [Enter]

Setting the Measurement Carrier Feedthrough Upper Limit

Step	Notes
1	On [Carr Feed-thru Limit] select On or Off .
	Enables you to toggle the measurement limits function On (active) and Off (inactive).
	- If set to On, the displayed carrier feedthrough metric will change from blue to red (fail) or green (pass) and indicate either a “P” (pass) or “F” (fail). If the measured value exceeds the upper limit, the words ‘ALL PASS’, in the bar at the bottom of the screen, will change to ‘FAILURE’. - If set to Off, the time carrier feedthrough value will be displayed in blue. The bar at the bottom of the screen will indicate measurement in progress.
2	Set the upper limit.
	Upper Limit range: 60 to –150 dBc
	a. [High Limit]
	b. Enter the number on the numeric keypad.
	c. [dBc]

Setting the Measurement Noise Floor Upper Limit

Step	Notes
1 On [Noise Floor Limits] select On or Off .	Enables you to toggle the measurement limit function On (active) and Off (inactive). • If set to On, the displayed noise floor metrics will change from blue to red (fail) or green (pass) and indicate either a “P” (pass) or “F” (fail). If the measured value exceeds the upper limit, the words ‘ALL PASS’, in the bar at the bottom of the screen, will change to ‘FAILURE’. • If set to Off, the time noise floor value will be displayed in blue. The bar at the bottom of the screen will indicate measurement in progress.
2 Set the upper limit. a. [High Limit] b. Enter the number on the numeric keypad. c. [dB]	Upper Limit range: 60 to –150 dBc

CDMA Over Air

Optional CDMA Over Air Measurement Settings

Setting the Measurement Pilot Power Limits

Step	Notes
1 On [Pilot Power Limits] select On or Off .	Enables you to toggle the measurement limits function On (active) and Off (inactive). - If set to On, the delta pilot power metrics will change from blue to red (fail) or green (pass) and indicate either a “P” (pass) or “F” (fail). If the measured value exceeds the upper limit or lower limit, the words ‘ALL PASS’, in the bar at the bottom of the screen, will change to ‘FAILURE’. - If set to Off, the time pilot power value will be displayed in blue. If NO limits are set to On, the pass/fail bar will not be displayed at the bottom of the screen.
2 Set the upper limit. a. [High Limit] b. Enter the number on the numeric keypad. c. [dBm]	Delta Limit range: –150 to 100 dBm
3 Set the lower limit. a. [Low Limit] b. Enter the number on the numeric keypad. c. [dBm]	Delta Limit range: –150 to 100 dBm

Setting the Measurement Delta Page Power Limits

Step	Notes
1 On [Δ Page Pwr Limits] select On or Off .	Enables you to toggle the measurement limits function On (active) and Off (inactive). • If set to On, the delta page power metrics will change from blue to red (fail) or green (pass) and indicate either a “P” (pass) or “F” (fail). If the measured value exceeds the upper limit or lower limit, the words ‘ALL PASS’, in the bar at the bottom of the screen, will change to ‘FAILURE’. • If set to Off, the time delta page power value will be displayed in blue. If NO limits are set to On, the pass/fail bar will not be displayed at the bottom of the screen.
2 Set the upper delta limit. a. [High Limit] b. Enter the number on the numeric keypad. c. [dB]	Delta Limit range: –150 to 100 dB
3 Set the lower delta limit. a. [Low Limit] b. Enter the number on the numeric keypad. c. [dB]	Delta Limit range: –150 to 100 dB

CDMA Over Air

Optional CDMA Over Air Measurement Settings

Setting the Measurement Delta Sync Power Limits

Step	Notes
1 On [Δ Sync Pwr Limits] select On or Off .	Enables you to toggle the measurement limits function On (active) and Off (inactive). • If set to On, the delta sync. power metrics will change from blue to red (fail) or green (pass) and indicate either a “P” (pass) or “F” (fail). If the measured value exceeds the upper limit or lower limit, the words ‘ALL PASS’, in the bar at the bottom of the screen, will change to ‘FAILURE’. • If set to Off, the time delta sync. power value will be displayed in blue. If NO limits are set to On, the pass/fail bar will not be displayed at the bottom of the screen.
2 Set the upper delta limit.	Delta Limit range: –150 to 100 dB
a. [High Limit]	
b. Enter the number on the numeric keypad.	
c. [dB]	
2 Set the lower delta limit.	Delta Limit range: –150 to 100 dB
a. [Low Limit]	
b. Enter the number on the numeric keypad.	
c. [dB]	

Setting Up the Signal Generator

[“Using the RF OUT Loss field” on page 250](#)

You can set up the signal generator while in the Spectrum Analyzer mode from the Setup menu. For more detailed information on the signal generator setup and operation, refer to [“Using the Signal Generator” on page 402](#).

CAUTION

The maximum power for the RF In (Port 1) and RF Out/SWR (Port 2) ports is +20 dBm (100 mW). When using the 8481A/8482A or N8481A/N8482A with Option CFT Power Sensors, the maximum input power applied to the Power Sensor is +24 dBm (300 mW). When using the 8481D Power Sensor, the maximum input power is +20 dBm (100 mW). When directly coupled to a base station (BTS) or Access Network (AN), the test set can be damaged by excessive power applied to any of these three ports.

To prevent damage in most situations when you directly couple the test set to a base station, use the high power attenuator between the test set and the BTS.

NOTE

The lowest level the signal generator can go to is -90 dBm. In order to get a lower level, you must use an external attenuator. You can compensate for the attenuator in the RF Out Loss.

Step	Notes
1	[Setup]
2	[Sig Gen]
3	[Freq/Chan]
4	[Frequency] or [Channel]
5	Enter the channel or frequency using the numeric keypad.

CDMA Over Air

Optional CDMA Over Air Measurement Settings

Step	Notes
6	- For channel select [Rev] or [Fwd] - For frequency select [GHz], [MHz], [kHz], or [Hz],
7	[Mod Format]
8	Select the channel standard from the list using the up and down arrow buttons.
9	[Select]
10	Set the RF output amplitude a. [Amplitude] b. Enter the amplitude value using the numeric keypad. c. [dBm].
11	If you have previously stored RF Out Loss from an insertion loss measurement, go to the next step. Or Press [RF OUT Loss] to select On and enter the RF Out Loss value. You may also enter a new value for amplitude by turning the rotary knob until the desired value is displayed or using the up and down arrow keys. For information on the effects of the RF Out Loss function on the amplitude, refer to “Using the RF OUT Loss field” below. Each time you press this softkey, the selected option changes.
12	Connect to the base station.
13	Set [Enable Sig Gen] to Yes . Each time you press this softkey, the selected option changes.
14	Set [RF] to On .

Using the RF OUT Loss field

The RF OUT Loss field is used when it is necessary to test the receiver sensitivity of

CDMA Over Air

Optional CDMA Over Air Measurement Settings

a typical base station. The test set's source will typically go down to -95 dBm, in order to reach -113 dBm for sensitivity testing, you must use an external attenuator. The measured value of the attenuator and connecting cables are entered into this field. This value is then used when this field is set to **On**. When this field is set to **On**, the test set will set the RF generator level to the correct level offset by the external attenuator/cabling. When you set the RF Generator to -113 dBm (with the RF OUT Loss field turned **On** and the external attenuator/cabling loss value entered) the output at the end of the RF test cabling is -113 dBm.

Example: If you want to set the signal generator to -113 dBm, the attenuator and RF cabling measures 42.51 dB (measured with the 2 port insertion loss measurement screen prior to this test), the RF OUT Loss field is turned **On** (with the 42.51 dB loss value entered). The actual RF output of the signal generator is -70.49 dBm, the attenuator and RF cabling attenuated the signal to the desired level; so the RF signal at the end of the test cable/attenuator is -113 dBm. This also points out the importance of accurately measuring the loss of the attenuator and connecting cables.

Metrics Provided by CDMA Over Air Measurements

This section contains descriptions of the individual CDMA transmit parameters in the metric display of the screen. For expected result values and possible causes of error if the expected results are not met, see [“Interpretation of CDMA Over Air Measurement Results” on page 256](#).

Frequency Error

Frequency error is the frequency difference between your transmitter's actual center frequency and the frequency (or channel) you entered.

PN Offset

The PN Offset is a “short code” sequence that provides a unique identifier for each sector of each cell site. The PN Offsets are applied to the I and Q signals before modulation. PN Offsets are offset in time by 52.08 μs and they repeat every 26.666 ms. This yields 512 unique short code sequences (0-511). The mobile phone needs the PN Offset to decode information in the Sync and Paging channels, which are transmitted by the base station.

Time Offset

The Time Offset compares the PN Offset timing with the overall system time. This measurement checks the start of the PN offset in comparison to either the GPS signal or the Even Second clock signal. For example, PN Offset 0 should repeat exactly on the rising edge of the Even Second clock. PN Offset 1 should repeat 52.08 μs after the rising edge of the Even Second clock, and so forth. Any error in time from that event is reported as a Time Offset.

IS-95 specifies that the base station timing must be within $\pm 10 \mu\text{s}$ of its assigned value. Many base station manufactures specify that the timing must be within $\pm 3 \mu\text{s}$. For example, if you are parked near the transmit antenna, the propagation delay is less than 1 μs . The measured value of delay should be within the recommended limit, which is greater than $-10 \mu\text{s}$ and less than $+10 \mu\text{s}$. As you move away from the transmit antenna, propagation delay needs to be considered—about 1 μs for every 300 meters (1000 feet). So, if you are parked 800 meters ($\frac{1}{2}$ mile) from the transmit antenna, the additional propagation delay would be approximately 2.5 μs . The measured value of delay should be greater than $-7.5 \mu\text{s}$ and less than $+12.5 \mu\text{s}$.

Below is a table showing various delays vs. distance.

Distance	Delay
161 meters (0.1 mile)	0.56 μ s
402 meters (0.25 mile)	1.36 μ s
805 meters (0.5 mile)	2.72 μ s
1609 meters (1 mile)	5.28 μ s
8047 meters (5 miles)	26.4 μ s

Estimated Rho

Estimated Rho is the measure of the modulation quality for a CDMA transmitter. This measurement is analogous to measuring FM accuracy and distortion in an AMPS network or EVM in a TDMA system. A Rho value of 1.0 is perfect, indicating that all of the power is being transmitted correctly.

Carrier Feedthrough

Carrier Feedthrough is a result of the RF carrier signal feeding through the I/Q modulator and appearing at the transmitter port. Carrier Feedthrough is a common cause of bad Rho measurements.

Noise Floor

Noise Floor is the average power of all the inactive channels.

Channel Power

Channel Power is the total power within a defined bandwidth. For CDMA the channel bandwidth is defined to be 1.25 MHz. Channel Power measures the power the base station is transmitting across the entire 1.25 MHz CDMA channel.

Pilot Power

Pilot Power is the total power in the Pilot code channel, expressed in dBm. The transmit power of the Pilot Channel signal for a given base station is constant.

Pilot Ec/Io

The Pilot Ec/Io is the ratio of the pilot power to all the other power in the channel, expressed in dB. Since Ec and Io are measured individually, the system can detect

CDMA Over Air

Metrics Provided by CDMA Over Air Measurements

poor signal quality and tell you if it is caused by low E_c or high I_o . This helps you quickly resolve coverage versus interference issues.

Delta Page Power

Delta Page Power is the amplitude difference between the Paging Channel and Pilot Channel, expressed in dB. The transmit power of the Paging Channel is constant and can be set at a value relative to the Pilot Power. A common value is -4 dB relative to the Pilot. It is important to know what the intended settings are for each carrier and sector of your base station.

Delta Sync Power

Delta Sync Power is the amplitude difference between the Sync Channel and Pilot Channel, expressed in dB. The transmit power of the Sync Channel is constant and may be set at a value relative to the Pilot Power. A common value is -10 dB relative to the Pilot. It is important to know what the intended settings are for each carrier and sector of your base station.

Delta Quick Page Channel Power

Delta Quick Page Channel (QPCH) Power is the amplitude difference between the Quick Page Channel and Pilot Channel, expressed in dB. The QPCH is a bursted channel and is not on all the time. In order to capture the level of the QPCH, the statistic measures and holds the peak level of the QPCH. Until a QPCH has been measured, the value will be dashes. When “on”, the level of the QPCH is constant and is set at a value relative to the Pilot Power. The QPCH digital gain level can be set to 2, 1, 0, -1, -2, -3, -4, and -5 dB relative to the Pilot. It is important to know what the intended settings are for each carrier and sector of your base station.

Amplifier Capacity

Assuming the Amplifier Capacity parameters are set properly, the Amplifier Capacity measurement is an estimate of the amount of power amplifier capacity that is being used, expressed in percent of maximum. When an amplifier is transmitting at maximum output power, it is said to be at 100% of its capacity. For example, an amplifier with a maximum output power of 12 watts would be at 50% of capacity when transmitting 6 watts and at 100% of capacity when transmitting at 12 watts.

The percentage of amplifier capacity increases as the number or level of the traffic channels increase.

Peak Amplifier Capacity

Peak Amplifier Capacity is the peak level of all the valid Amplifier Capacity

measurements while on the same PN offset. In PN Offset Auto mode this measurement is reset if the PN offset changes or the Reset Metrics button is used. In PN Offset Manual mode this measurement is reset only if the Reset Metrics button is used.

Average Amplifier Capacity

Average Amplifier Capacity is the average level of all the valid Amplifier Capacity measurements while on the same PN offset. In PN Offset Auto mode this measurement is reset if the PN offset changes or the Reset Metrics button is used. In PN Offset Manual mode this measurement is reset only if the Reset Metrics button is used.

Utilization

Utilization is a ratio of the active Walsh codes to the total 128 Walsh codes, expressed in percent. Even though active control channels such as the pilot are included in the utilization measurement, utilization is an indication of the traffic that is being carried by the base station.

For example, a CDMA signal with a pilot, paging, and sync channel, two IS-95 traffic channels, and one eight-wide cdma2000 data channel, would use 18 Walsh codes. Each control channel would use two Walsh codes, each IS-95 channel would use two Walsh codes, and the cdma2000 channel would use 8 Walsh codes for a total of 18 Walsh codes. Eighteen Walsh codes in use out of the 128 total Walsh codes would result in a utilization of 14%.

Peak Utilization

Peak Utilization is the peak level of all the valid Utilization measurements while on the same PN offset. In PN Offset Auto mode this measurement is reset if the PN offset changes or the Reset Metrics button is used. In PN Offset Manual mode this measurement is reset only if the Reset Metrics button is used.

Average Utilization

Average Utilization is the average level of all the valid Utilization measurements while on the same PN offset. In PN Offset Auto mode this measurement is reset if the PN offset changes or the Reset Metrics button is used. In PN Offset Manual mode this measurement is reset only if the Reset Metrics button is used.

Interpretation of CDMA Over Air Measurement Results

This section contains expected result values and possible causes of error if the expected results are not met.

Frequency Error

The standards specify very tight Frequency Error performance. In the PCS bands, the 0.05 parts-per-million specification translates to only 99 Hz at a carrier frequency of 1900 MHz or 40 Hz at 850 MHz cellular frequencies. Frequency Error shows up as uncorrelated power that adds to the noise floor or shows up in other Walsh codes.

If a particular site loses its reference to GPS time, its reference signals will begin to drift over time. Mobiles already using the site can remain on the air because they derive their timing from the signals transmitted by the base station. However, mobiles using other sites/sectors may be prevented from using the site because they are confused by the error in frequency. This creates what is known as the “island cell effect”. By itself, the cell is still functional. To the rest of the system, it's inaccessible.

This island cell effect can be caused by a failure in the site's GPS receiver and timebase distribution network. Using the test set's Internal GPS receiver provides an independent time reference that will allow you to determine if this cell site is out of sync with the rest of the network (“island cell effect”).

PN Offset

Verify the PN Offset is correct. If you are in Manual mode, the PN Offset will display the value you entered. Make sure the Time Offset is small (less than 3 μ s). If the Time Offset is greater than expected, see the section on Time Offset below. If you are in Auto mode, the test set will tune to the PN Offset with the least amount of Time Offset. If an incorrect PN Offset is displayed, the Time Offset will likely be very large.

Time Offset

The CDMA standards specify a maximum offset of 10 μ s; generally 5 μ s is a recommended maximum. If the Time Offset is large enough, an “island cell” can occur. The “island cell effect” was mentioned already when discussing Frequency Error.

A phone moving outward toward the limit of its cell will need to acquire the

Interpretation of CDMA Over Air Measurement Results

adjacent cell in order to hand off. If the time offset of the target cell is too far from that of the current site, the handoff may not happen.

The dependence of the phone on correct system time limits the physical distance to a target cell's antenna. Each PN Offset is 52.08 μ s; if the propagation delay is too long, the received PN Offset may be different from the value designated on the Sync channel. This difference can confuse the phone, causing the handoff to fail.

Another cause of timing error is a bad GPS receiver or timing distribution network within the base station. To test your base station's GPS and timing distribution system, you can use the internal GPS receiver to generate an accurate timing reference for the test set to use while performing base station tests.

The Time Offset should be within the following limits:

- Less than $\pm 10 \mu$ s if the receiving antenna is next to the base station, or
- Less than $\pm 10 \mu$ s, plus 1 μ s for every 300 meters (1000 feet) you are away from the base station.

If the measured value of the Delay falls outside of the expected range, consider the following problems:

- The GPS receiver is not working correctly, and the base station timing is incorrect.
- The base station main oscillator is not working correctly, and the base station timing is incorrect.
- The GPS receiver is not locked to the GPS satellites.

Estimated Rho

The CDMA base station standard specifies that Rho must be greater than 0.912. Typical values for a healthy base station are greater than 0.94. When measuring Rho over-the-air, these values can only be achieved under very good conditions for multipath power and pilot dominance. For example, a Multipath Power of < 0.1 dB and a Pilot Dominance of > 15 dB is required to measure Rho of 0.912. For more on the affects of pilot dominance and multipath power on Estimated Rho see [“Criteria for Making Valid CDMA Over Air Measurements” on page 221](#).

Verify that the Estimated Rho meets the following criteria:

- Greater than 0.8 if the Multipath Power and Pilot Dominance properties remain at the defaults of 0.4 dB and 10 dB, respectively, or
- Greater than 0.912 if you have set the Multipath Power and Pilot Dominance properties to 0.1 dB and 15 dB, respectively.

CDMA Over Air

Interpretation of CDMA Over Air Measurement Results

Poor Rho performance affects the base station capacity because the uncorrelated power appears as interference to the mobiles. The added interference will require an increase in the traffic channel level to overcome the interference. This may, in turn, be seen as further interference. At some point, the site will have to shed calls in order to supply the remaining calls with enough signal versus the interference in the system.

If Estimated Rho is lower than expected, check the following:

- External interference may be degrading the CDMA signal. Use the spectrum analyzer to verify that no spurious signals are present in the band of the transmitter.
- Compression may be occurring in the base station power amplifier.
- There may be errors in the base station IQ modulator.

Carrier Feedthrough

A good Carrier Feedthrough level is less than -25 dB. The IS-97 standard does not specify Carrier Feedthrough; however, this measurement provides an additional tool to troubleshoot the base station's transmitter.

In the frequency domain, Carrier Feedthrough can show up as an uncorrelated energy spike that can be seen on the spectrum analyzer by closely spanning into the top of the CDMA signal. The effects of Carrier Feedthrough can also show up as higher noise levels on the Code Domain Power screen. The inactive Walsh codes will be pushing the -27 dB specification for noise. Carrier Feedthrough can be caused by the lack of isolation across the mixer and cavity of the transmitter's I/Q modulator.

Noise Floor

A good Noise Floor value is between -20 dB and -30 dB and depends on the quality of the signal. If the Noise Floor is above these values (for example, -20 dB), the modulator may be the source of the added noise. Another possibility is a problem with the base station's channel card. The channel card generates the individual Walsh codes.

Channel Power

If the Channel Power is lower than expected, verify you are in a location that meets the criteria to provide valid measurements.

Inaccurate Channel Power (high or low) may indicate an incorrect power setting at the base station.

Pilot Power

If the Pilot Power has varied significantly from previous readings at the same location, it may indicate the following:

- There has been a change made to the digital gain setting of the Pilot Channel.
- The base station power amplifier has a problem.
- The transmit antenna system has been changed or damaged.

Pilot Ec/Io

A high value of Ec/Io means there is less interference from other base stations and noise and is an indicator of base station performance. When Ec/Io is mapped, it can be used to determine coverage quality.

Delta Page Power

If the measured value of Delta Page Power is more than +/-0.5 dB different from previous measurements at the same location, it may indicate that the digital gain setting for the Paging Channel has been changed from the intended setting.

Delta Sync Power

If the measured value of Delta Sync Power is more than +/- 0.5 dB different from previous measurements at the same location, it may indicate that the digital gain setting for the Sync Channel has been changed from the intended setting.

Delta Quick Page Channel Power

If the measured value of Delta QPCH Power is more than +/-0.5 dB different from previous measurements at the same location, it may indicate that the digital gain setting for the QPCH has been changed from the intended setting.

Amplifier Capacity

The Amplifier Capacity metric provides an instantaneous reading of how much of the amplifier's capacity is currently being used. More meaningful information is provided by the Peak and Average Amplifier Capacity metrics gathered over a 10 to 15 minute interval.

Peak Amplifier Capacity

If the Peak Amplifier Capacity is greater than 100%, the traffic at this base station has caused the base station amplifier to exceed its maximum power rating. This is not desirable as this problem can result in system degradation or damage to the

CDMA Over Air

Interpretation of CDMA Over Air Measurement Results

amplifier.

You can get an indication of how often the amplifier capacity is being exceeded by watching the Amplifier Capacity measurement. This is an instantaneous measurement of the amplifier capacity.

Average Amplifier Capacity

If the Average Amplifier Capacity is greater than 85%, the base station power amplifier is close to its maximum power limit. Further increase in traffic on this base station could cause system performance problems or damage to the power amplifier. You should notify your RF Engineering Department as soon as possible.

Utilization

The Utilization metric provides an instantaneous reading of the percentage of the traffic channels currently being used. More meaningful information is provided by the Peak and Average Utilization metrics gathered over a 10 to 15 minute interval.

Peak Utilization

If the Peak Utilization of this base station is greater than 65%, this is a warning that peak traffic rates at this base station are getting very high. It is possible that calls could be getting blocked or dropped.

Average Utilization

If the Average Utilization of this base station is greater than 45%, the base station is carrying a great deal of traffic. It may be time to consider adding another carrier or another base station.

- “Using the Channel Scanner” on page 262
- “Performing a Basic Channel Scanner Measurement)” on page 263
- “Displaying Accurate Peak Power (Recommended for Pulsed Signals)” on page 266
- “Setting the Analyzer Input Gain” on page 267
- “Setting Noise Correction” on page 267
- “Entering the Channels with a List Instead of a Range” on page 268
- “Entering the Channel Power Measurement Bandwidth and Time” on page 269
- “Setting Average, Sweep, and Restart” on page 272
- “Displaying Frequency or Power” on page 274
- “Setting the Pass/Fail Limits” on page 274

Using the Channel Scanner

The Channel Scanner measures the power of multiple transmitted signals. It is most useful for measuring channel power in TDMA, GSM, AMPS, and iDEN channel bands. Channel power may be measured on a single channel or across multiple channels or frequencies. The Channel Scanner can be used to measure TDMA, AMPS, GSM and iDEN adjacent channel power.

CAUTION

When measuring multiple channels, the combined channel power must not exceed +20 dBm at the RF In port.

CAUTION

The maximum power for the RF In (Port 1) and RF Out/SWR (Port 2) ports is +20 dBm (100 mW). When using the 8481A/8482A or N8481A/N8482A with Option CFT Power Sensors, the maximum input power applied to the Power Sensor is +24 dBm (300 mW). When using the 8481D Power Sensor, the maximum input power is +20 dBm (100 mW). When directly coupled to a base station (BTS) or Access Network (AN), the test set can be damaged by excessive power applied to any of these three ports.

To prevent damage in most situations when you directly couple the test set to a base station, use the high power attenuator between the test set and the BTS.

NOTE

For complex modulation such as CDMA, W-CDMA, 1xEV-DO and GSM, the frequency error measurement is not accurate (see respective analyzers for detailed frequency error results).

NOTE


The RF In Loss can be added manually or automatically by performing an insertion loss measurement. For measurement instructions refer to [“Performing \(and Calibrating\) a Basic One Port Insertion Loss measurement”](#) on page 47 or [“Normalizing and Performing a Basic Two Port Insertion Loss Measurement”](#) on page 125.

Performing a Basic Channel Scanner Measurement)

Step	Notes
1 Select Channel Scanner.	
a. Mode	
b. [Spectrum Analyzer/Tools]	
c. [Channel Scanner]	
2 Select the channel standard.	
a. [CS Chan Std]	
b. Select the standard using the up and down arrow buttons.	
c. [Select]	
3 On [CS Units] select Chan.	Each time you press this softkey, the selected option changes.
4 On [Scan Mode] select Range.	Each time you press this softkey, the selected option changes.
5 Select the start channel.	
a. [Start Chan]	
b. Enter the start channel using the numeric keypad.	
c. [Fwd] or [Rev]	
6 Enter the CS step size.	
a. [CS Step Size]	
b. Enter the step size using the numeric keypad.	
c. [Enter]	


Channel Scanner
Using the Channel Scanner

Step	Notes
7	Enter the number of channels. a. [Num Chans] b. Enter the number using the numeric keypad. c. [Enter]
8	Connect to the base station.




Out of service connection

Step	Notes



In service connection



Over the air measurement connection

NOTE

The *autoranging* feature under [Setup], [Range Control] that is built into the test set helps ensure accurate measurements by changing front-end amplifier gain as needed. This might be, for example, when a strong signal threatens to overload the test set. When this occurs, the noise floor rises (as gain is decreased), then falls again when the strong signal stops.

If you prefer a fixed noise floor, you can disable autoranging in two ways using the Setup function within Channel Scanner:

- On [Range Ctrl] select **Hold** to fix the noise floor at the current level. A subsequent strong signal—even outside the measurement range—may cause an inaccurate reading due to overloading the front-end of the test set.
- On [Range Ctrl] select **Max** to fix the noise floor at the current level until a strong signal comes in. In that case, the floor will rise to maintain accuracy, but will not return to its lower level after the strong signal stops.

Displaying Accurate Peak Power (Recommended for Pulsed Signals)

For pulsed signals, you can get a more accurate measurement of the signal's peak or average power by using the Peak Power Detector setting.

The test set measures average power of signals by default. But for non-constant-duty-cycle signals such as GSM, an average power reading fails to accurately show amplitude when the signal is on if other timeslots in the frame are powered off.

If the [Power Detector] menu key is grayed out, the test set needs to be upgraded in order to measure pulsed signals. Contact the Agilent Service Center for upgrade information.

Step	Notes
1 [Setup]	
2 On [Power Detector] select Pk .	Each time you press this softkey, the selected option changes.

Setting the Analyzer Input Gain

Normally the E7495A/B is set to add the most gain in the receive path to boost low-level signals. If the signal is high, there is no reason to add gain. When you're measuring a strong signal, select low sensitivity to reduce the gain in the receive path and lower the noise floor. For a low level signal, select High.

Step	Notes
1 [Setup]	
2 [Sensitivity]	
3 Low or High	

The Sensitivity setting is automatically switched to Low whenever the signal level at the test set's connector (that is, after any external attenuation has been applied) rises above -10 dBm. You can use the Noise Correction feature to recover any lost dynamic range.

NOTE

The Sensitivity setting is coupled to the Noise Correction setting. Changing the Sensitivity setting from **Low** to **High** will cause the Noise Correction setting to change from **On** to **Off**. Conversely, if the Noise Correction setting is changed from **Off** to **On**, the Sensitivity setting is changed from **High** to **Low**.

Setting Noise Correction

You can turn the Noise Correction function **On** or **Off**. When set to **On**, noise correction will be activated and correct for the noise generated internally by the analyzer. It allows the you to make accurate measurements on signals close to the noise floor.

To Set the Measurement Noise Correction:

Step	Notes
1 [Setup]	
2 On [Noise Correction] select On or Off .	Each time you press this softkey, the selected option changes.

Entering the Channels with a List Instead of a Range

Step	Notes
1 Select Channel Scanner. a. Mode b. [Spectrum Analyzer/Tools] c. [Channel Scanner]	
2 Select the channel standard. a. [CS Chan Std] b. Select the standard using the up and down arrow buttons. c. [Select]	
3 On [CS Units] select Chan.	Each time you press this softkey, the selected option changes.
4 On [Scan Mode] select List.	Each time you press this softkey, the selected option changes.
5 View or modify your list of channels. a. [List] b. [Ok]	View (and modify if necessary) your list of channels.

Step	Notes
6	Enter channels into the list.
a.	Use [Insert Row] to add a channel, then enter its number using the numeric keypad and [Fwd] or [Rev] to complete each entry.
b.	Use [Delete Row] to remove channels you do not want displayed. Select a channel you want to remove using the up and down arrow buttons. Then press [Delete Row] to remove the selected channel.
c.	[Ok]

Entering the Channel Power Measurement Bandwidth and Time

When performing a channel power measurement, you must specify a measurement bandwidth and measurement time. These parameters determine how the analyzer measures each channel on the Channel Scanner. Depending on the modulation format of signal you are trying to measure (CDMA, GSM, and so forth), different measurement bandwidths and times are required. You have three ways of selecting these parameters:

- Press [Format/BW], then on [Format Type] select **List**, and then select the format from a list—independently of the channel standard.
- Select [Format/BW], then on [Format Type] select **Cust**. Then select the measurement bandwidth and measurement time for each channel.

To Select the Channel Format Type:

Step	Notes
1	[Format/BW]

Channel Scanner

Using the Channel Scanner

Step	Notes
2 On [Format Type] select Chan.	Each time you press this softkey, the selected option changes. The option you select determines which buttons on the right are active. Each channel standard has an associated modulation format. With this method, the optimum measurement bandwidth and measurement time for the modulation format are automatically selected when you set the channel standard. For example, when you select GSM-950 as the channel standard, with this method the test set selects the bandwidth and time for the GSM format.
3 Select the standard you want.	
a. [CS Chan Std]	
b. Select the standard using the up and down arrow buttons.	
c. [Select]	

To Select the List Format Type:

Step	Notes
1 [Format/BW]	
2 On [Format Type] select List.	Each time you press this softkey, the selected option changes. The option you select determines which buttons on the right are active.

3 Select the format you want. a. [Format List] b. Select the standard using the up and down arrow buttons. c. [Select]	This selection is independently of the channel standard selected under [Freq/Chan], [CS Chan Std].

To Select the Custom Format Type:

Step	Notes
1 [Format/BW]	
2 On [Format Type] select Cust.	Each time you press this softkey, the selected option changes. Each channel standard has an associated modulation format. With this method, the optimum measurement bandwidth and measurement time for the modulation format are automatically selected when you set the channel standard. For example, when you select GSM-950 as the channel standard, with this method the test set selects the bandwidth and time for the GSM format.
4 Set the channel power measurement bandwidth and measurement time. a. [Meas BW] b. Enter the bandwidth on the numeric keypad. c. [GHz] or [MHz] or [kHz] or [Hz] d. [Meas Time] e. Enter the time on the numeric keypad. f. [ms]	

Setting Average, Sweep, and Restart

Setting the Sweep

You can select either continuous or single sweep. Continuous sweep provides repeated, ongoing measurements. Single sweep performs a single measurement that is repeated only when you push the Single button.

To set sweep:

Step	Notes
1 [Average/Sweep]	
2 [Continuous] or [Single]	Each time you press this softkey, the selected option changes.

Setting Averaging

You can choose to have averaging **On** or **Off** and set the number of averages you want to take. Averaging only applies to the data, not the trace. You can select from the following types of averaging:

- **Off:** Disables averaging.
- **Running:** Computes the new result as the weighted sum of the last result and the new measurement. The last result is weighted by $(n - 1)/n$. The new result is weighted by $1/n$. Each new measurement produces a new result.
- **Max Hold:** Is not an average, but on a point by point basis, displays the maximum amplitude for the given frequency or channel since Max Hold was turned on. It is updated when a new maximum occurs.
- **Group Average:** Makes the requested number of measurements, averages the measurement data, and displays the average as a single result trace. Measurement time will vary based on the requested number of averages and can take minutes for very large number of averages.
- **Group Max Average:** Makes the requested number of measurements before returning a single trace result. This trace is the maximum value seen at each trace point over the requested number of averages (measurements).

To set averaging:

Step	Notes
1	Set the number of averages. [Average] - Enter the number of averages using the numeric keypad. [Enter]
2	Select the type of averaging you want to apply. [Average/Sweep] [Averaging] [Off], [Running Average], [Max Hold], [Group Average], or [Group Max Average]

NOTE

These two steps can be performed in any order. However, if you turn averaging **On** and a large number of averages has previously been set, there may be a delay before you can change number of averages.

Setting Restart

When you have averaging turned **On** and you are in **Continuous** Sweep mode, you can restart the averaging by pressing the Restart menu key. The Restart key has no effect if you are in **Single** sweep mode.

To restart averaging:

Step	Notes
1	[Average/Sweep]
2	[Restart] This key is unavailable or has no effect when Sweep is set to Single. To restart a Single Sweep measurement, press [Single].

Displaying Frequency or Power

You can display frequency or power values above the bars in the trace display. The displayed frequency is the average instantaneous frequency when the signal is active.

For CDMA type signals, the frequency option is not recommended; accurate frequencies for CDMA are not displayed.

Step	Notes
1 [Setup]	
2 On [Display Value] select Off , Freq , or Pwr .	Each time you press this softkey, the selected option changes. Choosing Off displays no values above the bars.

Setting the Pass/Fail Limits

The measurement limits setting enables you to alter the value of the upper and lower test limits. The settings you choose define the location of the limit lines displayed on the screen. These settings affect the color of the bar graph display and the measured value: red represents fail, green represents pass, and blue indicates that the limits are turned off.

- **Power Limits:** Sets the high and low limits of the channel power. Limits are set in dB and are relative. Any channel value that is outside of the set limits will result in a failure indication.
- **Frequency Limits:** Sets the high and low frequency limits for each channel. Limits are set in Hz. These settings affect the display color as indicated above, but there are no limit lines shown on the display.

To Set the Measurement Upper and Lower Limits:

Step	Notes
1 [Setup]	
2 [Limits]	
3 [Power Limits]	

Step	Notes
3 On [Power Limits] select On or Off .	Enables you to toggle the measurement limits function On (active) and Off (inactive). - If set to On, upper and lower limit lines are displayed on the screen. Any measured channel value that exceeds the upper limit or is less than the lower limit will result in a failure indication for that value. - If set to Off, the channel power value will be displayed in blue. The bar graph will be blue if neither Power or Frequency Error Limit has been set to On. Note: the screen will only display values and pass/fail indications for one set of limits at a time. If you have Frequency limits turned on then choose to turn on Power limits, the Frequency limits will turn off.
4 Set the upper limit. a. [Power High Limit] b. Enter the number on the numeric keypad. c. [dB]	Maximum Upper limit: top of display
5 Set the lower limit. a. [Power Low Limit] b. Enter the number on the numeric keypad. c. [dB]	Maximum Lower Limit: bottom of display

Channel Scanner

Using the Channel Scanner

Step	Notes
6 On [Freq Error Limits] select On or Off .	Enables you to toggle the measurement limits function On (active) and Off (inactive). • If set to On, the displayed channel frequency and the bar graph will change from blue to red (fail) or green (pass). Any measured value that exceeds the upper limit or is less than the lower limit will result in a failure indication for that value. • If set to Off, the channel freq/number value will be displayed in blue. The bar graph will be blue if neither Power or Frequency Error Limit has been set to On Note: the screen will only display values and pass/fail indications for one set of limits at a time. If you have Power limits turned on then choose to turn on Frequency limits, the Power limits will turn off.
4 Set the upper limit. a. [Frequency High Limit] b. Enter the number on the numeric keypad. c. [GHz], [MHz], [kHz], or [Hz]	Maximum Upper limit: 1 GHz Minimum Upper limit: 0.0 GHz
5 Set the lower limit. a. [Frequency Low Limit] b. Enter the number on the numeric keypad. c. [GHz], [MHz], [kHz], or [Hz]	Maximum Lower limit: 0.0 Hz Minimum Lower limit: -1 GHz

- “Measuring Distance to Fault” on page 278
- “Measured Distance - the Effects of Frequency and Points” on page 278
- “Resolution - the Effects of Frequency and Points” on page 279
- “Automatic and Manual Distance to Fault Measurements” on page 279
- “Calibration - Minimizing your Workload” on page 281
- “Performing a Basic Distance to Fault Measurement (Manual Frequency Range)” on page 283
- “Performing a Basic Distance to Fault Measurement (Automatic Frequency Range)” on page 286
- “Clearing Calibration” on page 290
- “Displaying Location Information Using GPS” on page 291
- “Viewing a Single Distance to Fault Sweep” on page 292
- “Displaying the Top Four Faults” on page 292
- “Setting Interference Rejection for a Distance to Fault Measurement” on page 293
- “Setting Average, Sweep, and Restart” on page 294
- “Adding a Marker” on page 296
- “Setting the Pass/Fail Limits” on page 297

Measuring Distance to Fault

A signal is transmitted from the RF Out/SWR port of the test set to the cable-under-test. The signals reflected from faults in the cable are received by the test set.

In performing this measurement, the test set uses frequency domain reflectometry. The changing interference of the transmitted and reflected signals contains information about the distance to one or more faults. This information can be used to find the physical distance to the faults. The distance displayed on the test set is the physical distance to the probable faults, corrected for the cable loss and velocity propagation factor of the cable.

Measured Distance - the Effects of Frequency and Points

It is not always obvious how frequency range affects measured distance and resolution, and it often appears to be counter-intuitive. If you are new to making Distance to Fault measurements, this section will help clarify what is happening.

In the following equations

- The Speed of Light ('c') is a constant value of 3×10^8 meters per second.
- Your test cable's transmission speed (relative to light) is V_{Rel}

The **Measured Distance** (in meters) of the DTF measurement is determined by the following equation:

$$\text{Measured Distance (in meters)} = \frac{\frac{1}{4} \times \text{Number of Points} \times c \times V_{Rel}}{\text{Frequency Span}}$$

You can see from this equation that:

- To **increase** the measured distance:
 - you can **increase** the **number of points**, or
 - you can **reduce** the **frequency span**.
- To **reduce** the measured distance:
 - you can **reduce** the **number of points**, or
 - you can **increase** the **frequency span**.

Resolution - the Effects of Frequency and Points

It is not always obvious how frequency range affects measured distance and resolution, and it often appears to be counter-intuitive. If you are new to making Distance to Fault measurements, this section will help clarify what is happening.

Resolution Distance (in meters) of the DTF measurement, that is, the shortest distance between two faults that can still be resolved by the analyzer, is determined by the following equation:

$$\text{Resolution Distance (in meters)} = \frac{\text{Measured Distance (in meters)}}{\frac{1}{2} \times \text{Number of Points}}$$

NOTE

Please be careful how you interpret this equation. Note that to *increase* the *resolution*, you need to *reduce* the *Resolution Distance*; to *reduce* the *resolution*, you need to *increase* the *Resolution Distance*.

You can see from this equation that:

- To **increase** the resolution, that is, to *reduce* the *Resolution Distance*:
 - you can **increase** the **number of points**, or
 - you can **reduce** the **measured distance**.
- To **reduce** the resolution, that is, to *increase* the *Resolution Distance*:
 - you can **reduce** the **number of points**, or
 - you can **increase** the measured distance.

NOTE

Although you can set your number of points to 256, 512, or 1024, you will only ever be able to save 256 data points when you save trace data. This is because only 256 points are ever used to display the trace, regardless of how many points you have used to actually make the measurement. You will not, however, be losing any resolution, or reducing the quality of your data. The results will still reflect the true number of data points that you specified.

Automatic and Manual Distance to Fault Measurements

The test set provides two ways of measuring distance to fault:

- **Automatic Frequency Range.** You select the measurement distance and the test set automatically selects the **Start Frequency** and the **Stop Frequency**. The

Distance to Fault

Measuring Distance to Fault

measurement distance is set using the [Start Distance] and the [Stop Distance] menu keys on the [Freq/Dist/Calibrate] menu. In this mode, the displayed and measured distances are the same. There are always 256 measurement points across the distance you set, so adjusting the distance settings allows you to display the maximum resolution for the portion of the cable you are testing. The disadvantage is that the start and stop frequencies are automatically set and may limit the test set's ability to sweep through filters or lightning protectors. This mode is best used for checking a cable that has no frequency limiting devices.

Example 1: If you set [Start Distance] to 0 m (0 ft) and the [Stop Distance] to 60 m (197 ft), and you specify 256 Data Points, the instrument automatically selects a [Start Freq] of 375 MHz and a [Stop Freq] of 659.8 MHz.

Example 2: If you again set [Start Distance] to 0 m (0 ft) and the [Stop Distance] to 60 m (197 ft), and but this time you specify 1024 Data Points to give you greater resolution, the instrument automatically selects a [Start Freq] of 375 MHz and a [Stop Freq] of 1.5142 GHz.

- **Manual Frequency Range.** When set to **Manual**, you must specify the **Start Frequency** and the **Stop Frequency**, and the measured distance is worked out from these frequencies. Generally, the typical start and stop frequencies you use will result in a measured distance that will be larger than the distance over which you want to look for faults.

NOTE

The **Measured Distance** and the **Displayed Distance** can be different. The distance over which the instrument has made its measurements, and which has been derived from the frequencies you specified, is called the **Measured Distance**. This is displayed at the top right corner of the measurement screen.

The **Displayed Distance** refers to that part of the entire **Measured Distance** that you choose to display on your measurement screen. You set the **Displayed Distance** manually by pressing the [Start Distance] and the [Stop Distance] menu keys on the [Freq/Dist/Calibrate] menu.

To help isolate faults over the length of interest, you can set a displayed distance less than the measured distance. The displayed distance is set using the [Start Distance] and the [Stop Distance] menu keys on the [Freq/Dist/Calibrate] menu.

Keep in mind that there are 256, 512, or 1024 measurement points across the measured distance. The exact number of measurement points is set using the [Data Points] key on the [Setup] menu. Therefore, the measurement points across the chosen displayed distance will be a ratio of displayed distance to measured distance times the number of points you have specified. The higher the number of data points, the greater the measurement resolution.

In most cases, the default resolution using 256 data points will be adequate to locate the faults, but if more resolution is needed you can increase the span between the start and stop frequencies (which will decrease the measured distance) or use the other approach, automatic frequency range. If the measurement distance is not long enough for the cable you are testing, reduce the span between the start and stop frequencies (which will increase the measurement distance) or use automatic frequency range.

NOTE

When testing cables attached to antennas, test signals are radiated from the test antenna. Verify that the signal used for the test, and therefore being radiated from the test antenna, cannot interfere with other radiated signals from other antennas.

Calibration - Minimizing your Workload

The **Distance to Fault** calibration (*when it is performed with Frequency Range set to manual*) is the same calibration as performed for the **Return Loss** and **One-Port Insertion Loss** measurements. If you have already calibrated for any of these three measurements, the calibration will apply to the other two measurements and “Calibrated” (together with the frequency range over which the calibration was performed) will be displayed on top left of the screen for all three if the Start and Stop frequencies are set within the calibrated frequency range.

The **Distance to Fault** calibration (*when it is performed with Frequency Range set to Auto*) is only valid for other *Distance to Fault* measurements that are also performed with *Frequency Range set to Auto*, and then only if the Start and Stop frequencies fall within the previously calibrated frequency range.

If you have not previously performed a calibration, the word “Uncalibrated” appears at the top left of the measurement screen.

It is important that you keep the calibration frequency range as close as possible to the actual sweep frequencies you intend using for the measurement or measurements. Calibrating over a large frequency range (for example, 1 GHz) when you only intend measuring over a much smaller range (a few kHz, for example) will reduce your measurement accuracy.

If you plan to perform a combination of **One-Port Insertion Loss** measurement, **Return Loss** measurement, and **Distance to Fault** measurements *using a frequency range that you will set manually*, you can perform one calibration for all three measurements as long as you calibrate over a frequency range that incorporates all three of your measurements, and as long as your cables do not change. For this reason, if you are doing Distance to Fault measurements (*using a frequency range that you have set manually*) as well as any type of Insertion Loss measurement,

Distance to Fault

Measuring Distance to Fault

Agilent recommends that you select your cable type before performing calibrations. Press [Mode], [Antenna/Cable], [Distance to Fault], [Cable Type] to set the cable type.

The calibration remains valid until you do any one of the following:

- set the Distance to Fault frequency range to **Auto**. Note that the calibration will become valid again as soon as you switch from **Auto** back to **Manual** Frequency Range.
- power off the test set
- change the start frequency to a new value that lies below the start frequency of your previous calibration
- change the stop frequency to a new value that lies above the stop frequency of your previous calibration
- change any of the jumper leads that you used for the calibration
- change any of the attenuators that you used for the calibration
- change the type of cable specified under the [Cable Type] menu key.

NOTE

None of the following calibrations are valid for Distance to Fault calibrations with **Frequency Range** set to **Auto**:

- Distance to Fault calibrations performed with the **Frequency Range** set to **Manual**
- One Port Insertion Loss calibrations
- Two Port Insertion Loss calibrations
- Return Loss calibrations

Note also that Distance to Fault calibrations performed with the **Frequency Range** set to **Auto** are not valid for any other measurement, including Distance to Fault with the **Frequency Range** set to **Manual**.

Performing a Basic Distance to Fault Measurement
(Manual Frequency Range)

Step	Notes
1	Mode
2	[Antenna/Cable]
3	[Distance to Fault] The distance to fault measurement takes a few seconds to load.
4	On [Freq Range] select Manual . Each time you press this softkey, the selected option changes.
5	[Start Freq]
6	Enter the start frequency using the numeric keypad.
7	[Hz], [kHz], [MHz], or [GHz]
8	[Stop Freq]
9	Enter the stop frequency using the numeric keypad.
10	[Hz], [kHz], [MHz], or [GHz]
11	On [Units] select Meters or Feet . Each time you press this softkey, the selected option changes.
12	[Start Distance]

Distance to Fault

Distance to Fault

Measuring Distance to Fault


Step	Notes
13 Enter the start distance using the numeric keypad.	The start distance you can enter cannot be greater than the distance displayed in the Measured Distance window at the top right. If you need a larger distance, reduce the start and stop frequency span. If your Start Distance is 0 m (0 ft), you will see a peak corresponding to 0 m (0 ft). This is caused by reflection from the junction between your analyzer and the cable under test. This does not necessarily indicate a problem, but be sure that this connection is tight and clean.
14 [Stop Distance]	
15 Enter the stop distance using the numeric keypad.	The stop distance you can enter cannot be greater than the distance displayed in the Measured Distance window at the top right, but must be greater than the start distance previously entered. If you need a larger distance, reduce the start and stop frequency span.
16 [Cable Type]	
17 On [Cable Type] on the right, select RG , BTS , or Cust .	Each time you press this softkey, the selected option changes. If you select RG or BTS, you will be asked to select from a list of common cable types, the specific type of cable you are measuring [Select Cable]. If the type of cable you are measuring is not listed, you need to select Cust (Custom Cable). Proceed to Step 20 for custom cable selection.
18 Press [Select Cable] to display a predefined list of RG and BTS cables.	Use the knob, or the up and down arrow keys, to scroll through the list and to highlight your chosen cable.
19 [Select]	The type of cable you selected will be displayed at the upper left of the screen. Now proceed to Step 21.

Step	Notes
20 For Custom Cables only (Cable Type = Cust), you must specify the characteristics of your cable. Use [Cable Atten] and [Prop Vel] to do this.	Specify your custom cable's attenuation [Cable Atten.] in dB per 100 m (or in dB per 100 ft.) Specify also your custom cable's propagation velocity [Prop Vel], measured as a percentage of the speed of light in a vacuum. The values you enter here will be used for the measurement, and will be displayed at the upper left of the display. Most cable manufacturers provide a table showing attenuation versus frequency for each type of cable. Remember that attenuation varies with frequency, so select an attenuation value that corresponds as closely as possible to the center of the frequency range you are using.
21 Check whether your analyzer has already been calibrated over the frequency range and with the correct cable type that you wish to measure. If it is already calibrated over the correct frequency range and cable type, you can omit the next steps (Step 22 and Step 23) and go straight to Step 24.	The analyzer displays its calibration status on the top left of the measurement screen. You only need to re calibrate if you: • power off the test set • change the start frequency to a new value that lies below the start frequency of your previous calibration • change the stop frequency to a new value that lies above the stop frequency of your previous calibration • change any of the jumper leads that you used for the calibration • change any of the attenuators that you used for the calibration • change the type of cable specified under the [Cable Type] menu key. For more information, see “Calibration - Minimizing your Workload” on page 281.

Distance to Fault

Measuring Distance to Fault

Step	Notes
22	If your analyzer is uncalibrated, or has been calibrated over an unsuitable frequency or with the incorrect cable type, press [Freq/Dist/Calibrate]
23	[Calibrate] Follow the Calibration Wizard.
24	Connect the antenna feedline and antenna. Connect the antenna feedline to the RF Out/SWR port.



25	(Recommended) [Level] [Autoscale]	If you prefer to set the reference level manually, after pressing [Level], press [Ref Level]. Then enter the value you want using the numeric keypad and press [dB].

Performing a Basic Distance to Fault Measurement
(Automatic Frequency Range)

Step	Notes
1	Mode

Step	Notes
2 [Antenna/Cable]	
3 [Distance to Fault]	The distance to fault measurement takes a few seconds to load.
4 On [Freq Range] select Auto .	Each time you press this softkey, the selected option changes.
5 On [Units] select Meters or Feet .	Each time you press this softkey, the selected option changes.
6 [Start Distance]	For greater ease of use, you do not need to display the measurement results for the entire cable length that you are measuring. If you want to zoom in on a small section of the cable, enter here the distance from the start of the cable. If you want to look at the whole cable, leave this at the default setting of 0 m (0 ft). If your Start Distance is 0 m (0 ft), you will see a peak corresponding to 0 m (0 ft). This is caused by reflection from the junction between your analyzer and the cable under test. This does not necessarily indicate a problem, but be sure that this connection is tight and clean.
7 Using the numeric keypad, enter the start distance for the part of the cable that you wish to zoom in on.	After entering the Start Distance value, press [m] for meters, or [ft] for feet, to use the new value.
8 [Stop Distance]	After entering the Stop Distance value, press [m] for meters, or [ft] for feet, to use the new value.

Distance to Fault

Measuring Distance to Fault


Step	Notes
9	Using the numeric keypad, enter the stop distance for the part of the cable that you wish to zoom in on. The greatest accuracy is obtained when you enter a cable length slightly greater than the cable length being tested. If you are not sure of the cable length, enter a value 1.25 times the estimated length, and enter a start distance value of 0 m (0 ft) as described in Step 6. Depending on the return loss of the antenna or device at the end of the cable, you may see a high relative mismatch displayed at the actual length of the cable
10	[Cable Type]
11	On [Cable Type] on the right, select RG, BTS, or Cust. Each time you press this softkey, the selected option changes. If you select RG or BTS, you will be asked to select from a list of common cable types, the specific type of cable you are measuring [Select Cable]. If the type of cable you are measuring is not listed, you need to select Cust (Custom Cable). Proceed to Step 14 for custom cable selection.
12	Press [Select Cable] to display a predefined list of RG and BTS cables. Use the knob, or the up and down arrow keys, to scroll through the list and to highlight your chosen cable.
13	[Select] The type of cable you selected will be displayed at the upper left of the screen. Now proceed to Step 15.

Step	Notes
14 For Custom Cables only (Cable Type = Cust), you must specify the characteristics of your cable. Use [Cable Atten] and [Prop Vel] to do this.	Specify your custom cable's attenuation [Cable Atten.] in dB per 100 m (or in dB per 100 ft.) Specify also your custom cable's propagation velocity [Prop Vel], measured as a percentage of the speed of light in a vacuum. The values you enter here will be used for the measurement, and will be displayed at the upper left of the display. Most cable manufacturers provide a table showing attenuation versus frequency for each type of cable. Remember that attenuation varies with frequency, so select an attenuation value that corresponds as closely as possible to the center of the frequency range you are using.
15 [Freq/Dist/ Calibrate]	
16 [Calibrate]	Follow the Calibration Wizard. If you have previously calibrated using a Frequency Range of Auto, and your frequency range lies within the previously calibrated frequency range, your analyzer will already be calibrated and you will not need to recalibrate.
17 Connect the antenna feedline and antenna.	Connect the antenna feedline to the RF Out/SWR port.

Distance to Fault

Measuring Distance to Fault

Step	Notes



18 (Recommended) [Level] [Autoscale]	If you prefer to set the reference level manually, after pressing [Level], press [Ref Level]. Then enter the value you want using the numeric keypad and press [dB].

Clearing Calibration

Clear Calibration deletes the current calibration data, enabling you to re-calibrate the instrument for the same frequency range, or for a new frequency range.

To Clear the Measurement Calibration Data:

Step	Notes
1 [Setup]	

Step	Notes
2 [Clear Calibration]	If you previously selected Manual Frequency Range, [Clear Calibration] only clears the calibration for the Manual mode. Auto mode calibration data is not cleared. Note also that if you clear a Manual calibration, you will also clear the calibration data for the Return Loss and the One Port Insertion Loss measurements as these measurements all share the same calibration data. If you previously selected Auto Frequency Range, [Clear Calibration] only clears the calibration for the Auto mode. Manual mode calibration data is not cleared.

Displaying Location Information Using GPS

If you are making a Distance to Fault measurement, you may use GPS Location data to verify your location. For additional information on the GPS Data function, refer to [“Displaying GPS Location Data” on page 462](#).

To Display GPS Location Information:

Step	Notes
1 [Level/Location]	
2 On [Show GPS Location] select On .	Displays GPS satellite location information. Uses the internal GPS to capture the location of a measurement. The GPS information can be used to return to the same location. The Time Ref (Freq/Chan/Time Ref mode) button must be set to Internal GPS for this function to be active. Information logged includes longitude, latitude, altitude (feet/meters), and the number of satellites tracked. Each time you press this softkey, the selected option changes.

Distance to Fault

Measuring Distance to Fault

Step	Notes
3 Highlight [On]	Toggle to [On] to display GPS satellite location information. Toggle to [Off] to remove the location information

NOTE

If you prefer to have an electronic copy of the location information, see “[Saving Data](#)” on page 469.

Viewing a Single Distance to Fault Sweep

Step	Notes
1 [Average/Sweep]	
2 [Single]	Activates the single sweep. Press [Continuous] if you want to start multiple sweeps.

NOTE

Every time you wish to perform another single sweep, you need to press the [Single] key. Pressing the [Restart] key does not start another single sweep—[Restart] only restarts the averaging.

Displaying the Top Four Faults

When measuring distance to fault, you can display the top four faults with markers on the trace. Even if the Fault Indicators are not set to **On**, the position and the severity of the top four cable faults are still listed in the Metrics Display section at the bottom of the screen.

If your Start Distance is 0 m (0 ft), you will see a peak corresponding to 0 m (0 ft). This is caused by reflection from the junction between your analyzer and the cable under test. This DC component, sometimes referred to as the “dead zone”, does not

necessarily indicate a problem, but be sure that the connection is tight and clean.

Step	Notes
1 [Setup]	
2 On [Fault Indicators] select On .	Each time you press this softkey, the selected option changes. When set to On , the positions of the top four faults are indicated on the trace with four numbered yellow triangles. If you have Pass/Fail Limits set to On, the yellow triangles will be colored red for any faults that exceed your pre-defined limit. For more information on setting Pass/Fail limits, see “ Setting the Pass/Fail Limits ” on page 297.

Setting Interference Rejection for a Distance to Fault Measurement

Other signals can interfere with distance to fault measurements. When making a distance to fault measurement in the presence of known or suspected interference, you can minimize the effect of the interference on the measurement by activating interference rejection in the test set.

NOTE

Use of interference rejection will increase the measurement time. Interference rejection should be used if a known interfering signal exists or if the distance to fault measurement displays suspicious characteristics such as a spike or rapid movements in the noise floor.

To Activate Interference Rejection:

Step	Notes
1 [Setup]	
2 On [Interference Rejection] select On .	Each time you press this softkey, the selected option changes.

Setting Average, Sweep, and Restart

Setting the Sweep

You can select either continuous or single sweep. Continuous sweep provides repeated, ongoing measurements. Single sweep performs a single measurement that is repeated only when you push the Single button.

To set sweep:

Step	Notes
1 [Average/Sweep]	
2 [Continuous] or [Single]	Each time you press this softkey, the selected option changes.

Setting Averaging

You can choose to have averaging **On** or **Off** and set the number of averages you want to take. Averaging only applies to the data, not the trace. You can select from the following types of averaging:

- **Off:** Disables averaging.
- **Running Average:** Computes the new result as the weighted sum of the last result and the new measurement. The last result is weighted by $(n - 1)/n$. The new result is weighted by $1/n$. Each new measurement produces a new result.
- **Max Hold:** Is not an average, but on a point by point basis, displays the maximum amplitude for the given frequency or channel since Max Hold was turned on. It is updated when a new maximum occurs.
- **Group Average:** Makes the requested number of measurements, averages the measurement data, and displays the average as a single result trace. Measurement time will vary based on the requested number of averages and can take minutes for very large number of averages.
- **Group Max Average:** Makes the requested number of measurements before returning a single trace result. This trace is the maximum value seen at each trace point over the requested number of averages (measurements).

To set averaging:

Step	Notes
1	Set the number of averages. a. [Average] b. Enter the number of averages using the numeric keypad. c. [Enter]
2	Select the type of averaging you want to apply. a. [Average/Sweep] b. [Averaging] c. [Off], [Running Average], [Max Hold], [Group Average], or [Group Max Average]

NOTE

These two steps can be performed in any order. However, if you turn averaging on and a large number of averages has previously been set, there may be a delay before you can change number of averages.

Setting Restart

When you have averaging turned **On** and you are in **Continuous** Sweep mode, you can restart the averaging by pressing the Restart menu key. The Restart key has no effect if you are in **Single** sweep mode.

To restart averaging:

Step	Notes
1	[Average/Sweep]
2	[Restart] This key is unavailable or has no effect when Sweep is set to Single . To restart a Single Sweep measurement, press [Single].

Adding a Marker

Markers can be used on traces to help you visually track up to four signals. Each marker has the following settings:

- **Type:** Provides three options, including:
 - **Off**
 - **Normal**, which places a diamond-shaped, colored marker, along with a number, 1-4, on the trace.
 - **Delta**, is associated with a normal marker. Therefore, a normal marker must exist prior to creating the delta marker. The delta marker displays the difference between the normal marker position and the delta marker position. Only one delta marker can be associated with a given normal marker. The normal marker must be active when Delta is selected.
- **Marker to Peak:** Places the active marker on the current greatest value of the trace.
- **Marker to Next Peak:** Places the active marker on the current second greatest value of the trace.
- **Marker to Min:** Places the active marker on the current lowest value of the trace.
- **Marker to Next Min:** Places the active marker on the current second lowest value of the trace.

Step	Notes
1 [Marker]	
2 [Marker]	Each time you press the [Marker] key, you will step to the next marker in the sequence 1 - 2 - 3 - 4 - 1 - 2, and so on.
3 [1], [2], [3], or [4]	
4 [Type]	
5 [Off], [Normal], or [Delta]	

Step	Notes
6 Locate the marker relative to the trace: [Marker to Peak] or [Marker to Next Peak] or [Marker to Min] or [Marker to Next Min]	This feature is available for both normal markers and for delta markers.

Setting the Pass/Fail Limits

The measurement limits setting enables you to alter the value of the upper limit. Limits are set in dB and are relative. The setting you choose defines the location of the limit line displayed on the screen. The setting affect the metrics color display: red represents fail, green represents pass.

To Set the Measurement Upper and Lower Limits:

Step	Notes
1 [Setup]	
2 [Limits]	
3 On [Limits] select On or Off .	Enables you to toggle the measurement limits function On (active) and Off (inactive). • If set to On, a limit line is displayed on the screen. Any measured value that exceeds the limit will result in a failure indication for that value. • If set to Off, neither a limit line nor a limit indicator are displayed. Also, the pass fail indicator is not shown in the metrics display portion of the display.

Distance to Fault
Measuring Distance to Fault

Step		Notes	
4	Set the upper limit.	Maximum Upper limit: Ref Level (top of display)	
	a. [Upper Limit]	Minimum Upper limit: bottom of display	
	b. Enter the number on the numeric keypad.		
	c. [dB]		

“Making E1 Measurements” on page 300

“Steps for Performing a Basic E1 Analyzer Measurement” on page 300

“Setup Button Selections” on page 300

“Display/Sound Button Selections” on page 303

“Control Button Selections” on page 303

“Sample Hard Loop/End-End Full E1 BERT Test” on page 305

“Sample Monitor Full E1 Test” on page 308

“Setting Up Delay Test Mode” on page 312

“Turning On Sound” on page 314

“Setting Up E1 Diagnostics” on page 315

“Patterns” on page 316

“Alarm Indicators” on page 318

“Results Indicators” on page 318

“Status Indicators” on page 320

“Testing and Fault Mitigation” on page 321

“Auto Configuration Flow Diagram” on page 323

“Terminology” on page 325

Making E1 Measurements

The Agilent E7495A/B provide a simple solution for all your E1 testing needs, from basic transmission testing to BERT testing. For more information about E1 testing, refer to [“Measurement Results” on page 318](#).

Steps for Performing a Basic E1 Analyzer Measurement

Step	Notes
1 [Mode]	
2 [Backhaul]	
3 [E1 Analyzer]	
4 [Get Started/ Test Mode]	The tests are listed on the buttons on the right. Pressing a test mode button will provide you with information about the test and the test options available.
5 [Setup]	Configure the E1 analyzer for the measurement.
6 [Display/Sound]	Setup your view of the measurement results.
7 [Control]	Modify the measurement setup and inject errors as you perform the measurement.

Setup Button Selections

- **Rx Input:** The Primary and Secondary inputs are both affected by this setting.
 - **Terminate** - sets the input impedance to 75 Ohms. Can be performed only when the E1 circuit is interrupted (connected into a jack that interrupts the circuit).
 - **Monitor** - sets the input impedance to 75 Ohms, inserts 20 dB gain, and should be selected when connected to a 'Monitor' jack.
 - **Bridge** - sets the input impedance >1000 Ohms and should be selected when bridging on to an E1 circuit.

- **Line Code:** Configures the test set to transmit and expect to receive a line code that is compatible with the network's design. There are two types of line coding used in E1 networks:
 - **AMI** - Alternate Mark Inversion is a traditional line code.
 - **HDB3** - High Density Bipolar 3 replaces runs of 4 zeroes with a special code that is not compatible with AMI. It allows greater flexibility of data patterns by enhancing repeater synchronization by increasing pulse density, thereby providing greater throughput.
- **Framing:** Configures the test set to transmit and expect to receive a particular framing pattern that is compatible with the network's design. It enables the test set to receive the E1 signal and to then synchronize, identify, and extract the individual channels.
 - **Unframed** - Causes the test set to simulate a loss of frame condition.
 - **PCM30** - A framing format consisting of 30 traffic channels, 1 slot reserved for the frame alignment signal (FAS) and 1 slot reserved for common channel signaling.
 - **PCM30 + CRC4** - A framing format consisting of 30 traffic channels, 1 slot reserved for the frame alignment signal (FAS) with CRC and 1 slot reserved for common channel signaling.
 - **PCM31** - A framing format consisting of 30 traffic channels, 1 slot reserved for the frame alignment signal (FAS)
 - **PCM31 +CRC4** - A framing format consisting of 30 traffic channels, 1 slot reserved for the frame alignment signal (FAS) with CRC
- **Pattern:** Configures the test set to expect a particular test pattern. Many test patterns are available to 'stress' the circuit in a particular manner or to gain maximum insight into a particular problem.
- **Tx Pattern:** Allows you to select either Normal or Inverted patterns.
- **Tx Clock:** Configures the test set to use one of the following methods to derive the transmit clock frequency.
 - **Internal** - The transmit clock is derived within the test set and is independent of the incoming signal. This is useful when the device or line under test is configured to synchronize on the incoming signal. In this case the return clock frequency of the return signal should match the transmit clock frequency of the test set.
 - **Primary Rx** - The transmit clock frequency is derived from the signal

E1 Analyzer

Making E1 Measurements

received at the Primary Rx jack on the test set.

- **Secondary Rx** - The transmit clock frequency is derived from the signal received at the Secondary Rx jack on the test set.
- **Timeslot:** Applicable only in the Channel BERT mode. Sets the active channel to be tested for BERT.
- **Fill Data:** When performing Channel BERT testing this configures the source of data transmitted in the unused slots. For drop-and-insert testing this field is typically set to Secondary Rx.
 - **All 1's** - Set this mode to maintain a sufficient 1's density on the unused channels during testing. All 1's are typically transmitted on unused channels in live E1 circuits.
 - **Idle** - Set this mode to accommodate specific troubleshooting such as to exercise a circuit designed for HDB3.
 - **Primary Rx** - Fills the unused slots with Primary Rx data.
 - **Secondary Rx** - Fills the unused slots with Secondary Rx data.
- **Slip Reference:** Selects the reference for the frame slip measurement.
 - **None** - This selection disables the frame slip measurement.
 - **Internal** - In this mode the test set compares the framing of the incoming signal with the test set's internal clock. Three conditions are necessary when using this mode:
 1. The far end must be receiving a signal from this test set.
 2. The transmit clock on the far end must be configured to synchronize on the incoming signal.
 3. The Tx Clock on this test set must be set to internal.
 - **Second Rx** - In this mode the test set compares the frame clock timing of the received signal on the Primary Rx jack with the frame clock timing of the received signal on the Secondary Rx jack.

- **Second Tx:** Selects the source of data of the signal available at the Secondary Tx jack.
 - **AIS** - The signal at the Secondary Rx jack is an unframed all ones, and is often referred to as **AIS**.
 - **Second Rx** - The Secondary Rx signal is buffered and looped back to the Secondary Tx jack.
 - **Primary Rx** - The signal at the Primary Rx jack is buffered and internally routed to the Secondary Tx jack.

Display/Sound Button Selections

Configure the following for the measurement you're doing:

- **Status:** Allows you to select which status panel is active.
- **Alarms:** Displays those errors occurring on either the primary or secondary channel, depending on your selection. Displays in the bottom-right of the screen.
- **Results:** Can choose an error and select results you want to drill down to. This shows more metrics on the error you select. Displays in bottom-right of screen.
- **Sound:** Enables you to turn sound on and off. Use sound mostly to listen for drop outs or changes in the signal.
- **Volume:** Enables you to set the volume of speaker output.

Control Button Selections

On the Control button, the available buttons are unique to the test mode you select. Once you set up your display, you can change settings such as patterns, alarm injections, and so forth, while you make the measurement.

- **Pattern:** Configures the test set to send and expect to receive a particular test pattern. Many test patterns are available to 'stress' the circuit in a particular manner or to gain maximum insight into a particular problem.
- **Alarm/Error:** Enables a list of available alarms and conditions that can be transmitted on the Primary Tx channel. The alarm or condition is invoked by pressing the Inject button.

To troubleshoot your E1 line, you can monitor for errors or alarms. You can inject errors to see how the system responds.

- **Loss of Signal Alarm** - The test ceases to send a signal.

E1 Analyzer

Making E1 Measurements


- **Loss of Frame Alarm** - Disables the frame pattern.
- **FAS Distant Alarm** - Sets the Remote Alarm Indicator bit in timeslot 0 of the odd frames to simulate an FAS distant alarm.
- **RAI Remote Alarm Indicator** - See FAS Distant Alarm (above).
- **MFAS Distant Alarm** - Sets every sixth bit of each timeslot 16 in the zero frame to simulate an MFAS distant alarm.
- **AIS Alarm** - Alarm Indication Signal (AIS) sends an unframed, all 1s pattern.
- **TS-16 AIS Alarm** - Sets all bits in timeslot 16.
- **BPV Error** - The test set forces a single bipolar violation error with each press of the Inject button.
- **FAS Error** - Causes an error in the frame alignment signal.
- **MFAS Error** - Causes an error in the multi-frame alignment signal.
- **CRC-4 Error** - Causes the test set to generate a CRC error. Note that this is possible only when CRC-4 frame modes are selected.
- **FEB (E-Bit) Error** - Causes the test set to set the E bit on odd frames.
- **Pattern Error** - The test set forces an error in the transmitted pattern with each press of the Inject button.
- **Timeslot:** Applicable only in the Channel BERT mode. Sets the active channel to be tested for BERT.
- **Fill Data:** When performing Channel BERT testing this configures the source of data transmitted in the unused slots. For drop-and-insert testing, this field is typically set to Secondary Rx.
 - **All 1's** - Set this mode to maintain a sufficient 1's density on the unused channels during testing. All 1's are typically transmitted on unused channels in live E1 circuits.
 - **Idle** - Set this mode to accommodate specific troubleshooting such as to exercise a circuit designed for HDB3.
 - **Primary Rx** - Fills the unused slots with Primary Rx data.
 - **Secondary Rx** - Fills the unused slots with Secondary Rx data.
- **Inject:** Causes the error or condition that is currently displayed on the button to occur. Some selections cause a single event to occur, while others maintain a constant state. The text on the button changes to reflect the appropriate action.

Sample Hard Loop/End-End Full E1 BERT Test

You can use this test mode to perform measurements such as BERT on an E1 circuit. This example explains how to setup a hard-loop/ene-end full E1 BERT test. A hard loop test requires one test set at one end, and a hard loop at the other. An end-end test requires a test set at each end, but enables the troubleshooter to identify the direction of the trouble. The E1 circuit is not available for service when using this test mode.

During the commissioning or startup phase of an E1 circuit, a several day end-to-end or hard loop test is often performed. This type of test provides the most comprehensive level of information, but does require that the circuit be taken out of service for the duration of the test. The test results provide more granular resolution on root cause problems than does a monitor test.

Figure 11-1 Sample End to End Connection Using a Terminate Connection with a Dsx Service Panel



Sample Hard Loop/End-End Full E1 Test:

Step	Notes
1	[Mode]
2	[Backhaul]

E1 Analyzer

Making E1 Measurements

Step	Notes
3 [E1 Analyzer]	
4 [Get Started/ Test Mode]	
5 [Hard Loop/End-End]	Use this test mode to perform measurements such as BERT on an E1 circuit. The far end signal must be derived from either a hard loop or from a second test set. The E1 circuit is not available for service when using this test mode.
6 [Full E1 BERT]	Select this to perform a BERT test on a full E1 Circuit.
7 [Auto Config]	Enables the Auto Configuration buttons.
8 [Start Primary Auto Config]	Causes the test set to analyze the incoming E1 signal and align the setup choices to the properties of that signal.
9 [Back]	
10 [Setup]	
11 Setup Rx input. a. [Rx Input] b. [Terminate]	The test set must be connected to a jack that interrupts the E1 circuit.
12 Setup line code. a. [Line Code] b. [HDB3]	This assumes the circuit is designed for HDB3 (High Density Bipolar 3). An E1-line code in which bipolar violations are deliberately inserted if user data contains a string of 4 or more consecutive zeros.
13 Setup framing. a. [Framing] b. [PCM31 + CRC4]	This assumes that the circuit has been designed for PCM31 + CRC4.
14 Setup pattern. a. [Pattern] b. [QRSS]	


Step	Notes
15 Setup Tx pattern. a. [Tx Pattern] b. [Normal]	
16 Setup Tx clock. a. [Tx Clock] b. [Internal]	This is the default selection after test set Preset and covers the situation when a hard loop is configured at the far end. If a separate test set is used at each end, then the test set on one end should have the Tx Clock set to Primary Rx (assuming the incoming signal is connected to this jack). Another alternative is to use a second E1 circuit connected to the Secondary Rx jack to establish proper timing.
17 Setup slip reference. a. [Slip Ref] b. [None]	Disables the frame slip measurement.
18 Setup second Tx. a. [Second Rx] b. [AIS]	Use the default condition.
19 [Display/Sound]	Enables the display and sound options on the buttons on the right.
20 Setup the status. a. [Status] b. [Pri]	Activates only the Primary Status pane. The inactive channel should be deactivated to cease the display of invalid measurements.
21 Setup alarms. a. [Alarms] b. [Pri]	This selection causes the Alarm pane to toggle between Primary and Secondary. Use [Pri] to observe the Primary Results in the Alarm Panel. Each time you press this softkey, the selected option changes.

Step	Notes
22 Setup results display. a. [Results] b. Use up and down buttons to select. c. [Select]	Displays a list of results information that can be displayed in the Results pane. Make a selection based on the need of the application. [Control] enables several soft keys on the right that control choices specific to each test mode.
23 Setup to inject an error. a. [Control] b. [Alarm/Error] c. Use the Up and Down arrow buttons to select. d. [Select] e. [Inject]	Allows you to select and then inject the alarm or error you want to test. Causes the error or condition that is currently displayed on the Inject button to occur. Note that some selections cause a single event to occur while others maintain a constant state. The text on the button changes to reflect the appropriate action. Press the [Inject] menu key to toggle between On and Off . Selecting On will inject the error selected with the [Alarm/Error] menu key during Step 23(b).

Sample Monitor Full E1 Test


This example shows how to monitor an E1 circuit without disrupting service. During this test the source of signal from the far end can be either live data or pattern data from a second test set. This mode is very similar to End-to-End Hard Loop mode, with the exception that the signal present on the Primary Tx jack is a buffered replica of the signal present on the Primary Rx jack. When monitor jacks are not available, this feature allows the technician to break into a live E1 and pass that signal through the test set, thereby keeping the circuit in-service. This is useful for monitoring long-term statistics of an E1 circuit.

Figure 11-2 Sample Monitor Mode with a Monitor Port Connection



When using the above sample connection for monitoring an E1 circuit with a monitor port, you should set Rx Input to monitor.

Figure 11-3 Sample Monitor Mode without a Monitor Port



When using the above sample connection for terminating an E1 circuit, you should set Rx Input to terminate.

E1 Analyzer

Making E1 Measurements

To Preform a Sample Monitoring Procedure

Step	Notes
1 [Mode]	
2 [Backhaul]	
3 [E1 Analyzer]	
4 [Get Started/ Test Mode]	
5 Setup monitoring. a. [Monitor] b. [Monitor Full E1]	Use this test mode to monitor live data on the E1 line without affecting service. The simplest hookup for monitoring does not require the test Set Tx outputs to be connected. In some cases, you may connect the Tx outputs to the E1 circuit. For those cases, the Tx primary and secondary transmitted signals are regenerated from the received signal on the corresponding line. Choose [Monitor Full E1] to monitor performance of a full E1 Circuit.
6 Setup auto configuration. a. [Auto Config] b. [Start Primary Auto Config]	Causes the test set to analyze the incoming E1 signal and to align the setup choices to that signal.
7 [Back]	Shifts focus back to the main mode selection buttons.
8 Setup the Rx Input. a. [Setup] b. [Rx Input] c. [Terminate]	This assumes the test set is connected into a jack that interrupts the E1 circuit. Note: If you are connected to a monitor port, select [Monitor] instead of [Terminate].
9 Setup line code. a. [Line Code] b. [HDB3]	This assumes the circuit is designed for HDB3.

Step	Notes
10 Setup framing. a. [Framing] b. [PCM31 + CRC4]	This assumes that the circuit has been designed for PCM31 + CRC4.
11 Setup pattern. a. [Pattern] b. [QRSS]	Set to the pattern sent by the far end.
12 Setup Tx Pattern. a. [Tx Pattern] b. [Normal]	
13 Setup Tx clock. a. [Tx Clock] b. [Internal]	This selection is not applicable in Monitor mode because the Primary Tx signal is a buffered replica of the signal applied to the Primary Rx jack and is not affected by this setting. Internal is the default selection after test set Preset.
14 [More 1 of 2]	Displays further options. Choose [More 2 of 2] to return to the previous list of options.
15 Setup the slip reference. a. [Slip Ref] b. [None]	Disables the frame slip measurement.
16 Setup the second Tx. a. [Second Tx] b. [AIS]	Use the default condition.
17 [Display/Sound]	Enables the [Display] options on the buttons on the right.

E1 Analyzer


Making E1 Measurements

Step	Notes
18 Setup the status display. a. [Status] b. [Pri]	Activates only the Primary Status pane. The inactive channel should be deactivated to cease the display of invalid measurements.
19 Setup alarms. a. [Alarms] b. [Pri]	This selection causes the Alarm pane to toggle between Primary and Secondary. Use the Pri selection to observe the Primary Results in the Alarm Panel.
20 Setup the results display. a. [Results] b. Use the up and down buttons to move to the desired choice. c. [Select]	Enables a list of results information that can be displayed in the Results pane. Make a selection based on the need of the application.

Setting Up Delay Test Mode

Use this test mode to have the test set measure the round trip delay of an E1 circuit. It is necessary to have a loop condition at the far end during this test. The best accuracy is obtained when a hard loop exists at the far end. Be aware that devices placed in loopback may add additional delay. During this mode, a pattern consisting of a zero inserted into a string of ones is transmitted and analyzed to determine the delay in the path. The selected test pattern is sent as filler during the calculation interval.

Figure 11-4 Delay Connection Diagram



To Preform a Sample Delay Mode Test Procedure

Step	Notes
1 [Mode]	
2 [Backhaul]	
3 [E1 Analyzer]	
4 [Get Started/ Test Mode]	
5 Perform Delay test. a. [Delay] b. [Full E1]	Use this test mode to measure the delay between the Primary Tx and Rx ports. Use this measured delay to determine the approximate distance between near end and far end. The far end of the line must be manually looped during this test. Since a signal is being sent on the E1 line, service on the E1 will be affected. Delay measurements require full E1 bandwidth.
6 [Setup]	Select this to display a list of setup choices that pertain to this test mode.

E1 Analyzer

Making E1 Measurements

Step	Notes
7 Setup Rx Input. a. [Rx Input] b. [Terminate]	This assumes the test set is connected into a jack that interrupts the circuit.
8 Setup Line Code. a. [Line Code] b. [AMI] or [HDB3]	This assumes that the circuit is designed for AMI or HDB3.
9 Setup Framing. a. [Framing] b. [Unframed] or [PCM30] or [PCM30 + CRC4] or [PCM31] or [PCM31 + CRC4]	This assumes that the circuit has been designed for the option you select.
10 Setup the Pattern. a. [Pattern] b. Use the up and down arrow buttons to move to a pattern. c. [Select]	
11 Setup the Tx Pattern. a. [Tx Pattern] b. [Normal] or [Invert]	
12 Setup the Tx Clock. a. [Tx Clock] b. [Internal] or [Primary Rx]	None of the options available on [More 1 of 2] are available in Delay mode.

Turning On Sound

You can listen to a single channel at a time in channel test modes. Sound is disabled when you are in full E1 test modes.

To Turn On the Sound

Step	Notes
1 [Mode]	
2 [Backhaul]	
3 [E1 Analyzer]	
4 [Get Started/ Test Mode]	
5 [Hard Loop/End-End], [Channel BERT] or [Monitor], [Monitor Channel]	
6 Select Channel mode.	
7 [Display/Sound]	
8 [Sound]	
9 [On] or [Off]	Each time you press this softkey, the selected option changes.
10 Set the volume. a. [Volume] b. Enter the volume level from 1 to 10. c. [Enter]	

Setting Up E1 Diagnostics

The diagnostic tests available for E1 include:

- **RAM** - During the RAM test, the memory on the E1 measurement module is tested. Memory hardware failures are detected.
- **ROM** - The ROM test verifies the integrity of the code by performing a checksum measurement.
- **Loop Back** - The loop back test is a functional test of the transmitting and receiving hardware. It attempts to send various signal patterns and levels and then to verify the measured values. It is important that this test be done using short 75 BNC cables (preferably 100-millimeter (4-inch) cables) because long

E1 Analyzer

Making E1 Measurements

cables can reduce the signal levels during the diagnostic tests, and this could case a false failure.

If any of the three tests listed above fail, contact your service center.

To Set Up E1 Diagnostics

Step	Notes
1 [Mode]	
2 [Backhaul]	
3 [E1 Analyzer]	
4 [Tests]	
5 [Verification]	The E1 Loop Cable connection diagram shown on the instrument display, and the accompanying explanation, contain the information you need to set up the test.
6 [Continue]	The test is performed and results are reported on the screen.

Patterns

Many test patterns are available to 'stress' the circuit in a unique way or to gain maximum insight into a particular problem. Much has been written to guide the troubleshooter to select the proper pattern. Below is a list of the patterns available in the test set.

- 2E6-1
- 2E9-1
- 2E11-1
- 2E15-1
- 2E20-1
- QRSS- A pseudorandom pattern that simulates live traffic on a circuit. It is a very common test pattern
- 2E23-1
- All 0's - A pattern that is often selected to verify HDB3 provisioning.

- 1:7 - An eight-bit pattern that contains a single 1. Used to test clock recovery.
- 1:3 - A 4-bit pattern with a single 1.
- 1:1 - A 2-bit pattern with a single 1.
- All 1's - A pattern that causes line drivers to consume the maximum amount of current. If framing is set to 'Unframed' the resulting pattern is equivalent to an Alarm Indication Signal (AIS).

Measurement Results

Alarm Indicators

- **Signal Loss** - The test set encountered the absence of data on the E1 signal. A frame pulse may or may not be present.
- **Frame Loss** - The test set encountered an unexpected frame pattern. The frame pattern did not match the one selected in 'Setup.'
- **AIS Alarm** - The test set encountered an unframed all-ones signal.
- **TS 16 AIS Alarm** - The test set encountered all ones in every timeslot sixteen.
- **FAS Distant Alarm** - The test set detected a FAS alarm being sent from the far end. This alarm indicator is also known as RAI (Remote Alarm Indication)
- **MFAS Distant Alarm** - The test set detected an MFAS alarm being sent from the far end.
- **Pattern Inv** - The pattern of the signal applied to the test set is inverted.

Results Indicators

- **(Code) BPV** - A momentary indicator that responds when a bipolar violation occurs on the incoming signal applied to the Receive jack. HDB3 codes are not considered a BPV and will not activate this indicator when the test set is set to AMI mode.
- **FAS** - A momentary indicator that responds to a disruption in the frame alignment signal.
- **MFAS** - A momentary indicator that responds to a disruption in the multi-frame alignment signal. This indicator is applicable in only PCM-30 framing modes.
- **CRC-4** - A momentary indicator that responds to a disruption of the incoming CRC. This indicator is applicable in only CRC-4 framing modes.
- **E-Bit** - A momentary indicator that responds to the E-bit.
- **Pattern** - A momentary indicator that responds to a disruption of the incoming pattern.
- **Frame Slip** - A momentary indicator that responds when the test set encountered a disruption of the incoming frame pattern.

- **Recv Level** - The voltage level of the signal measured at the Rx jack.
- **Frequency** - The frequency of the signal measured at the Rx jack. The E1 Pulses indicator must be active for this measurement to be displayed.
- **Elapsed Time** - Indicates the amount of elapsed time since the last measurement reset.
- **BPV Errors** - A tally of the number of BPV errors since the last measurement reset.
- **BPV Error Rate** - The percent ratio of BPV errors to total bits transmitted since the last measurement reset.
- **BPV Errd Secs** - The number of one second intervals since the last measurement reset that contained BPV errors.
- **Frame Errors** - A tally of the number of Frame errors since the last measurement reset.
- **Frame Error Rate** - The percent ratio of frame errors to total bits transmitted since the last measurement reset.
- **Frame Errd Secs** - A tally of the number of one-second intervals since the last measurement reset that contained frame errors.
- **Signal Loss** - A tally of the number of one-second intervals since the last measurement reset that contained signal errors.
- **Frame Sync Loss** - A tally of the number of one-second intervals since the last measurement reset that contained frame sync loss.
- **Excess Zeros** - A tally of the number of one-second intervals since the last measurement reset that contained excess zeros.
- **All 1's** - A tally of the number of one-second intervals since the last measurement reset that contained the AIS pattern.
- **Error Free Seconds** - A tally of the number of one-second intervals that were error free since the last measurement reset.
- **Errored Seconds** - A tally of the number of one-second intervals since the last measurement reset that contained errors such as BPVs and frame errors.
- **Severe Errored Seconds** - A tally of the number of one-second intervals since the last measurement reset that were severely errored.
- **Available Seconds** - A tally of the number of one-second intervals since the last measurement reset that were available for service.
- **Unavailable Seconds** - A tally of the number of one-second intervals since the

E1 Analyzer

Measurement Results

last measurement reset that were unavailable for service.

- **Degraded Minutes** - A tally of the number of one-second intervals since the last measurement reset that were degraded.
- **Slip Rate** - The percent ratio of frames cycle slips of the incoming signal relative to the slip reference choice on the setup menu - since the last measurement reset.
- **Peak + Wander** - The peak amount of positive wander, measured in bit intervals, since the last measurement reset.
- **Peak - Wander** - The peak amount of negative wander, measured in bit intervals, since the last measurement reset.
- **+Frame Slips** - A tally of the number of positive frame slips that occurred since the last measurement reset.
- **-Frame Slips** - A tally of the number of positive frame slips that occurred since the last measurement reset.
- **Bit Errors** - A tally of the number of bit errors that occurred since the last measurement reset.
- **Bit Error Rate** - The percent ratio of bit errors to total bits transmitted since the last measurement reset.
- **Pattern Sync Loss** - A tally of the number of times the pattern detector lost synchronization since the last measurement reset.
- **Test Data Rate** - The measured data rate of the bit stream.

Status Indicators

- **E1 Pulses** - The test set is receiving pulses at the receive jack. Frame pulses alone are not sufficient to activate this indicator. There must be pulses present in the payload field.
- **HDB3** - A HDB3 pulse pattern was detected on the incoming signal at the receive jack. Note that only certain patterns transmit HDB3 pulse patterns. The pattern must contain at least 4 consecutive zeroes before a HDB3 pattern is sent. The QRSS pattern will generate HDB3 while an idle E1 circuit transmitting all 1's will not.
- **Frame Sync** - A frame sync pattern matches the one specified in the setup screen on the test set.
- **Pattern Sync** - The received pattern matches the one specified in the setup

screen on the test set.

Testing and Fault Mitigation

The complexity of E1 testing certainly parallels or possibly exceeds that of RF tests at a cell site. Shadowing efforts and customer expression have shown that most cell site technicians reduce the complexities of backhaul E1 testing down into a series of well-defined steps. These tests are often not comprehensive but are often sufficient to determine the continuity of an E1 circuit with a high degree of confidence. Often times the test sequence is developed by an experienced technician and is determined by finding the shortest path to an adequate measurement on a particular piece of readily available equipment. E1 testing often involves one technician on each end of a circuit. In the case of wireless, the technician at the switch end, very experienced at backhaul testing, is often working with a field technician that has a broader-based set of knowledge and is often less experienced in backhaul testing. The switch technician quickly develops a test procedure that involves the least amount of verbal instructions with the field technician.

E1 Facility Summary

This next section describes the elements in a typical E1 backhaul facility. Based on this information, typical fault conditions and what procedures are typically followed to restore service to the E1 span.

With almost no exception all circuits leased from the TELCO are routed through at least one central office facility. If this were not the case, planning and managing the repeaters needed for E1 transmission would be an onerous task.

Isolating Faults Using Test Equipment

Test equipment can be used to generate and monitor alarms and errors. Test equipment is connected to the E1 facility in a variety of ways. BNC jacks are often available on the equipment. When the plug is inserted into the jack the circuit is interrupted. Sometimes a monitor jack is available. When a plug is inserted into the monitor jack the circuit is not interrupted and a -20 dB signal is available at the jack. When none of these is available the signal may be monitored at a connection block, sometimes referred to as a “punch-down block”. The table below, “E1 Facility Access Methods,” describes the three typical access methods.

E1 Facility Access Methods

E1 Analyzer

Measurement Results

Access method	Test set configuration	Notes
Test Jacks	Terminated	Circuit is broken when plug is inserted into jack. The test equipment is normally set to “Terminate” and provides 75 Ohm termination.
Monitor Jacks	Monitor	The circuit is not interrupted when the plug is inserted into the jack. The test set, when set to “Monitor”, provides a 75 Ohm connection, and expects the signal to be 20 dB lower than the original signal.
Direct Connection to “Punch Down Block”.	Bridged	The circuit is not interrupted in this mode. The test set impedance is greater than 1000 Ohms so that the circuit is minimally affected. Test set is set to “Bridged.”

WARNING


It is important to remember that 90 volts DC may exist between the transmit and receive pair. This voltage can be lethal!

More Information About E1 Testing

Auto Configuration Flow Diagram

Selecting **Auto Config** causes the test set to analyze the incoming E1 signal and align the setup choices to that signal. If the incoming data pattern is not recognized, then 'NA Live Data' is displayed, and the pattern selected on the setup screen will remain unchanged. If HDB3 codes are detected, then this condition will be indicated and the line code parameter will be set accordingly. If setup was configured for HDB3 prior to selecting **Auto Config** and the pattern detected does not have sufficient zeros density to warrant HDB3, then 'NA' will be displayed, and the line code choice in the setup screen will remain unchanged. Finally, the framing format is detected, displayed and selection changed accordingly on the setup screen.

Figure 11-5 Flow Diagram for Auto Configuration



Terminology

CRC

To an observer, the data on a live E1 Circuit appears to be random. Fortunately there is a way to perform limited testing when the circuit is designed for Cyclic Redundancy Checksum (CRC) format. A portion of the frame bits is reserved for a CRC sequence that can be monitored for performance. Simply stated, the CRC bits are calculated on the transmit end and inserted as a pattern on the frame bit. The CRC pattern depends on the pattern of other bits transmitted by the E1 Circuit. The receiving end also computes this pattern and compares it with the CRC that was computed and sent by the transmitting end. Since both ends use the same rules for computing the pattern, the CRC bits will be identical when all the bits involved in the computation agree. The CRC check provides good insight into the end-to-end integrity of the E1 Circuit and should be used in conjunction with other tests that can help determine what the cause of the CRC failure might be.

BPV

The electrical signals on a properly functioning E1 circuit conform to the specification set forth in the standards. The standards specify that the presence of a voltage indicates a data '1' and the absence of a voltage represents a data '0'. Each occurrence of a data one produces a voltage for half a bit interval that is the opposite polarity of the previous bit, hence the name Alternate Mark Inversion (AMI). The alternating nature of the signal ensures that the average DC voltage is zero, allowing it be transformer coupled. Transformer coupling ensures a high degree of common mode rejection to the equipment that processes E1 signals.

High Density Bipolar 3 (HDB3) is an exception to AMI that replaces runs of 4 consecutive zeroes with a special code that violates the AMI rules. It allows greater flexibility of data pattern by enhancing repeater synchronization by increasing pulse density thereby providing greater throughput.

When the electrical signal does not adhere to the alternating nature of the waveform specification a BiPolar Violation (BPV) has occurred. This can happen for a number of reasons, many of which are outside the control of the wireless technician. One cause may be from electrical noise radiating from florescent lamps, motors, or spark plug ignition circuits coupling into the copper lines that carry E1 signals. Shielded cable is often chosen for E1 circuits to minimize electrical interference. This shield must be grounded to be effective. When the cable is spliced or terminated, the shield on both cables should be connected together. Often the transmit and receive signals are routed in separate cable bundles.

The receive signal is often much weaker than the transmit signal. Cross talk in the

cable pairs can cause the transmit signal to appear on the receive pair and interfere with the low-level receive signal.

Frame

Pulses streaming in an E1 circuit would be meaningless if there were no way to organize the pulses into a meaningful structure.

- “Using the GSM Analyzer and the EDGE Analyzer” on page 329
- “Performing a Basic GSM or EDGE Transmitter Measurement” on page 330
- “Interpreting the Display” on page 335
- “Optional GSM and EDGE Tx Analyzer Measurement Settings” on page 339
- “Setting your Scan Mode” on page 340
- “Setting the Start Frequency/Channel” on page 343
- “Setting the Frequency or Channel Step Size” on page 344
- “Setting the Stop Frequency/Channel” on page 345
- “Setting the Channel Standard” on page 346
- “Setting the Units of Measure for the Graphical Display” on page 346
- “Setting Autoscale” on page 347
- “Setting the Reference Level” on page 348
- “Setting Scale/Division” on page 348
- “Using GPS for Frequency Reference and Location Information” on page 348
- “Setting the Display Position” on page 349
- “Setting Auto Order” on page 350
- “Setting Bar Top and Units” on page 350
- “Setting Mid-Bar” on page 351
- “Setting Zoom” on page 351
- “Setting Zoom Offset” on page 352
- “Setting Zoom Interval” on page 353
- “Setting PvT Mask” on page 354
- “Setting Auto Mode Bar Count” on page 354
- “Setting Slot Synchronization” on page 355
- “Setting TS# (w/ BCCH)” on page 356
- “Setting the Pass/Fail Limits” on page 357
- “Adding a Marker” on page 365

GSM and EDGE Analyzer

“Compensating for the Loss of an External Cable and Attenuator” on page 367

“Setting Average, Sweep, and Restart” on page 368

“GSM and EDGE Modulation and Band Information” on page 371

“Metrics Provided by the GSM and EDGE Analyzer Measurement” on page 373

“Interpretation of GSM and EDGE Analyzer Measurement Results” on page 376

Using the GSM Analyzer and the EDGE Analyzer

Option 230 - GSM Analyzer enables measurements of GSM signals. Similarly, Option 235 - EDGE Analyzer enables measurements of EDGE signals.

This chapter explains how to make standard GSM measurements using Option 230 - GSM Analyzer. It also explains how to make the more advanced EDGE measurements for which you will require Option 235 - EDGE Analyzer.

GSM and EDGE transmitter measurements verify proper transmitter performance and can be made with the base station in service or out of service. Important metrics include:

- Frequency Error
- BSIC (Base Station Identification Code)
- TSC (Training Sequence Code)
- Modulation Type
- TS Pwr (Timeslot Power) in dBm
- TS Pwr in W
- Occupied Bandwidth
- I/Q Offset
- RMS Phase Error
- Peak Phase Error
- RMS EVM (Error Vector Magnitude)
- Peak EVM
- 95%tile EVM (95th Percentile EVM)

NOTE

RMS EVM, Peak EVM, and 95%tile EVM measurements are only available if Option 235 - EDGE Analyzer is installed

GSM and EDGE Analyzer

Using the GSM Analyzer and the EDGE Analyzer

Three different graphical views of your measurements are available. You can view:

- Channel Scanner
- Power versus Time
- Spectrum

The measurements conform to the following GSM standards:

- GSM 450
- GSM 480
- GSM 850
- GSM 900
- DCS 1800
- PCS 1900

CAUTION

The maximum power for the RF In (Port 1) and RF Out/SWR (Port 2) ports is +20 dBm (100 mW). When using the 8481A/8482A or N8481A/N8482A with Option CFT Power Sensors, the maximum input power applied to the Power Sensor is +24 dBm (300 mW). When using the 8481D Power Sensor, the maximum input power is +20 dBm (100 mW). When directly coupled to a base station (BTS) or Access Network (AN), the test set can be damaged by excessive power applied to any of these three ports.

To prevent damage in most situations when you directly couple the test set to a base station, use the high power attenuator between the test set and the BTS.

NOTE

To prevent unusual display information from being shown, ensure that you have selected a valid GSM Standard. It is possible for you to set a Chan Std that allows you to enter a lower Stop channel number than the current Start channel number resulting in unexpected information in the display. This is because some of the channel standards have discontinuities and reversals in channel numbers.

Performing a Basic GSM or EDGE Transmitter Measurement

The first step in measuring GSM or EDGE transmitter performance is to take the base station out of service or, for an in-service measurement, connect the test set to the coupled port. You must also know the channel or frequency of the EDGE signal to be analyzed.

To Make a GSM or EDGE Tx Analyzer Measurement:

Step	Notes
1 Mode	
2 [Tx Analyzer] or [Over Air]	Regardless of whether you select [Tx Analyzer] or [Over Air] at this stage, you will access the same measurement software in the analyzer. This means you can select [Tx Analyzer] and proceed to make an Over the Air measurement, and you can select [Over Air] and proceed to make a Tx Measurement. The two options here are presented for your convenience only, and have no further effect.
3 [GSM Analyzer] or [GSM (w/ EDGE) Analyzer], or [GSM Over Air] or [GSM (w/ EDGE) Over Air]	The wording on the key label is dependent on whether or not you have Option 235 - EDGE Analyzer installed, and also whether you selected [Tx Analyzer] or [Over Air] at Step 2.
4 [Chan Std]	
5 Highlight the channel standard you want using the up and down arrow buttons.	Select a valid GSM standard such as GSM-850 or EGSM-900. Notice that some valid standards may not be visible to you until you scroll down the screen.
6 [Select]	
7 On [Scan Mode] select Range , Auto , or List . a. If you selected Range or Auto , go to step 8. b. If you selected List , go to step 9.	Each time you press this menu key, the selected option changes.

GSM and EDGE Analyzer

Using the GSM Analyzer and the EDGE Analyzer


Step	Notes
8	If you selected Range or Auto, you may set Start and Stop frequency/channel and the Step Size of the display range. - On [Start Chan] enter the channel or frequency using the numeric keypad. - On [Stop Chan] enter the channel or frequency using the numeric keypad - On [Step Size] enter the channel or frequency step using the numeric keypad Menu keys label will read “Chan” or “Freq” depending on the Units you have selected.
9	If you selected List, you may select and change any or all of the available Freqs/Chans on the List screen. [List] - Highlight the list item you want using the up and down arrow buttons. - Enter a new Freq./Chan. - Repeat steps b and c as necessary. [OK] In addition, you may add Freqs/Chans to the list or delete Freqs/Chans from the list. Refer to “Adding or Deleting a List Item” on page 342.
10	Press [Display].

Step	Notes
11 On [Position], specify the frequency or the channel (depending on your units of measurement - see Step 8) at which you wish to make your measurement.	The position you specify (specified either by frequency or by channel number) is the position at which your measurement will be made. The numeric results that are displayed refer to this frequency or channel only. This position is indicated graphically on the Channel Scanner view (see Step 13) by a vertical yellow line.
12 Press [View].	
13 Select the measurement view you want shown by pressing one of the three buttons listed below: a. [Channel Scanner] b. [Power vs. Time] c. [Spectrum]	You can select any one of the three graphical views. The numeric results shown in the lower portion of the screen are independent of the graphical view you select. Changing your graphical view does not change which numeric results are displayed. The numeric results are always taken from the Position (frequency or channel) that you specified at Step 11, and from the first slot at that Position, that is, from Slot 0. This applies even when you are not actually displaying Slot 0 on the screen.
14 Connect to the base station or to your antenna.	If you are making a transmitter measurement, connect your analyzer to the base station. If you are making an Over the Air measurement, connect your analyzer to its antenna.


GSM and EDGE Analyzer

Using the GSM Analyzer and the EDGE Analyzer

Step	Notes




Out of service connection for a Transmitter Measurement



In service connection for a Transmitter Measurement

Step	Notes



In service connection for an Over the Air Measurement

15	[Level/Location]
16	[Autoscale]

Interpreting the Display

The GSM/EDGE Tx Analyzer screen is divided into two sections in the Channel Scanner and the Spectrum views, and into three sections in the Power versus Time view:

- The graphics display, that is, the graphic chart taking up most of the upper part of the screen
- The metrics display, that is, the table of values at the bottom of the screen
- *In the Power versus Time view only*, the third section displayed is of slot information. This is the row of power values at the top of the screen

NOTE The results metrics that are displayed will not correlate precisely with the plot that you see. This is because the analyzer performs two or more separate data acquisitions - at least one to gather the data for the graphical plot, and a separate acquisition to display data for the metrics. Any small variances between the two

GSM and EDGE Analyzer

Using the GSM Analyzer and the EDGE Analyzer

displayed results are due to variances in the signal over time.

The **Graphics Display** contains the graphical view of your measurement. You can change this view by pressing [Display] and [View], and then selecting one of the three view options available to you. The three views are:

- **Channel Scanner:** The graphics display shows channel power. In this display, the power of each selected channel is shown. The Y-axis labels display the absolute power (dBm), and dB/division. The X-axis labels display the frequency or channel number. Channel Scanner in GSM Tx Analyzer and in EDGE Tx Analyzer both use the 'Peak Detector' and therefore the displayed bar height is the 'Peak power in the acquisition'.
- **Power vs. Time with Zoom set to "Slots":** The graphics display shows power versus time for the channel selected using [Display], then [Position]. In this display, the power of the channel (or of part of the channel) you selected is shown against time. The Y-axis labels display the absolute power (dBm), and dB/division. The X-axis represents time, and shows from 60 μ s before the first of your specified timeslots, up to 60 μ s after the last of your specified timeslots.

You can display one or more of the eight slots in the channel of interest. The number of slots displayed is determined by your Zoom Interval setting. For more details, see ["Setting Zoom Interval" on page 353](#).

The left-most slot displayed is determined by your Zoom Offset setting. For more details, see ["Setting Zoom Offset" on page 352](#).


NOTE

It is worth noting that regardless of which slot you have displayed in the graphics portion of the screen, the displayed metrics always refer to the first slot, that is, to Slot 0.

If the Power versus Time mask is set to On, you will also see a mask indicating the lower and the upper limits for the channels you are displaying. The lower limit mask is displayed in yellow, and the upper limit mask in magenta (pink). The green signal trace must lie between these limits for it to pass the Mask Test. For more details on the PvT mask, see ["Setting PvT Mask" on page 354](#).

The power in each slot is displayed at the top of the screen, together with the results of the mask test for each slot. A 'P' in a green circle represents a Pass, and an 'F' in a red triangle represents a Fail. Each red triangle has an arrow beside it that indicates whether it is the upper limit, the lower limit, or both limits that have failed. A double-ended arrow indicates both upper and lower limits failed, an arrow pointing up indicates an upper limit failure, and an arrow pointing down indicates a lower limit failure. These pass and fail indicators are

shown below. The entire channel's Pass or Fail status is also displayed.



- **Power vs. Time with Zoom set to “Rise/Fall”:** The graphics display shows power versus time for part of the selected slot ([Zoom Offset]) in the selected channel ([Display], then [Position]). The power of the slot you selected is shown against time.

The Y-axis labels display the absolute power (dBm), and dB/division. The X-axis represents time. The portion of the X-axis to the left of the gray bar represents from 60 μ s before the start, to 60 μ s after the start, of the slot of interest.

The gray bar in the center of the display represents the central portion of the slot for which no data is displayed.

The portion of the X-axis to the right of the gray bar represents from 60 μ s before the end, to 60 μ s after the end, of the slot of interest. The power values (“TS Pwr”) at the top of the screen represent the maximum TS Power for each of the eight slots in the frame.

The slot whose trace is displayed is determined by your Zoom Offset setting. For more details, see [“Setting Zoom Offset” on page 352](#).

NOTE

It is worth noting that regardless of which slot you have displayed in the graphics portion of the screen, the displayed metrics always refer to the first slot, that is, to Slot 0.

If the Power versus Time mask is set to On, you will also see a mask indicating the lower and the upper limits for the channels you are displaying. The lower limit mask is displayed in yellow, and the upper limit mask in magenta (pink). The green signal trace must lie between these limits for it to pass the Mask Test. For more details on the PvT mask, see [“Setting PvT Mask” on page 354](#).

The power in each slot is displayed at the top of the screen, together with the results of the mask test for each slot. A green ‘P’ represents a Pass, and a red ‘F’

GSM and EDGE Analyzer

Using the GSM Analyzer and the EDGE Analyzer

represents a Fail. The entire channel's Pass or Fail status is also displayed.

- **Spectrum:** The graphics display shows spectral power for the selected slot ([Slot Sync]) in the selected channel ([Display], then [Position]) measured in a 500 kHz acquisition bandwidth. The Y-axis labels display the absolute power (dBm), and dB/division. The X-axis represents frequency, and shows the frequency across the Channel selected with your [Position] setting.

The *metrics display* shows measurement parameters displayed below the trace display in three columns and five rows—each with a value and units (the exceptions are BSIC, TSC, and Mod Type, which have no units.) For more information about the parameters in the metric display, refer to [“Metrics Provided by the GSM and EDGE Analyzer Measurement” on page 373](#).

The frequency reference indicator is at the bottom right, and the time reference indicator at the bottom left. For each indicator the text indicates which reference you have chosen. A green LED indicates a locked condition, a red “X,” an unlocked condition.

Optional GSM and EDGE Tx Analyzer Measurement Settings

You can change several optional measurement parameters in the GSM/EDGE Tx Analyzer:

- “Setting your Scan Mode” on page 340
- “Adding or Deleting a List Item” on page 342
- “Setting the Start Frequency/Channel” on page 343
- “Setting the Frequency or Channel Step Size” on page 344
- “Setting the Stop Frequency/Channel” on page 345
- “Setting the Channel Standard” on page 346
- “Setting the Units of Measure for the Graphical Display” on page 346
- “Setting Autoscale” on page 347
- “Setting the Reference Level” on page 348
- “Setting Scale/Division” on page 348
- “Using GPS for Frequency Reference and Location Information” on page 348
- “Setting the Display Position” on page 349
- “Setting Auto Order” on page 350
- “Setting Bar Top and Units” on page 350
- “Setting Mid-Bar” on page 351
- “Setting Zoom” on page 351
- “Setting Zoom Offset” on page 352
- “Setting Zoom Interval” on page 353
- “Setting PvT Mask” on page 354
- “Setting Auto Mode Bar Count” on page 354
- “Setting Slot Synchronization” on page 355
- “Setting TS# (w/ BCCH)” on page 356
- “Setting the Pass/Fail Limits” on page 357

- “Adding a Marker” on page 365
- “Compensating for the Loss of an External Cable and Attenuator” on page 367
- “Setting Average, Sweep, and Restart” on page 368

Setting your Scan Mode

The selected Scan Mode provides three different methods of specifying the channels you wish to look at. These are Range Mode, Auto Mode, and List Mode:

- **Range Mode:** All channels between the Start and Stop Freq/Channel are displayed. The channels are separated by the Freq/Channel Step value. Metrics are only computed for the single channel indicated by the vertical yellow line, which can be adjusted by using the [Display], [Position] menu keys. For further details, see “[Setting the Display Position](#)” on page 349.

If the channel you specified using the [Position] menu key can not be demodulated, you will see the message “No valid Slot Sync found” displayed on the graphic portion of the screen for all three views, and the numeric metrics at the bottom of the screen will be dashed out. In the Power versus Time view, the PvT Mask will not be shown even if you have switched it on.

To Set the Scan Mode to Range:

Step	Notes
1 [Freq/Chan]	
2 [Scan Mode]	Each time you press this key, the selected option changes. Set Scan Mode to Range.
3 [Start Freq]	Enter the start frequency or the start channel for your desired scan, and terminate it with the appropriate Units key.
4 [Stop Freq]	Enter the stop frequency or the stop channel for your desired scan, and terminate it with the appropriate Units key.
3 [Step Size]	Enter the step size for your desired scan, and terminate it with the appropriate Units key. For further details on Step Size, see “ Setting the Start Frequency/Channel ” on page 343.

- Auto Mode:** All channels between the Start and Stop Freq/Channel are examined, but only the channels with the highest power are measured. Metrics are computed for all of the displayed channels, but are only displayed for the single channel indicated by the vertical yellow line, which can be adjusted by using the [Display], [Position] menu keys. For further details, see [“Setting the Display Position” on page 349](#).

The maximum number of displayed channels is 20.

If the channel you specified using the [Position] menu key can not be demodulated, you will see the message “No valid Slot Sync found” displayed on the graphic portion of the screen for all three views, and the numeric metrics at the bottom of the screen will be dashed out.

If the channel determined by your Position setting is not found within the high power channels found by this Auto Mode, you will see the message “Display Position not found within Auto Mode Bar Count”.

To Set the Scan Mode to Auto:

Step	Notes
1 [Freq/Chan]	
2 [Scan Mode]	Each time you press this key, the selected option changes. Set Scan Mode to Auto.
3 [Start Freq]	Enter the start frequency or the start channel for your desired scan, and terminate it with the appropriate Units key.
4 [Stop Freq]	Enter the stop frequency or the stop channel for your desired scan, and terminate it with the appropriate Units key.
5 [Step Size]	Enter the step size for your desired scan, and terminate it with the appropriate Units key. For further details on Step Size, see “Setting the Start Frequency/Channel” on page 343 .
6 [Setup], [Auto Mode Bar Count]	Enter the number of channels you wish to display on the screen. The maximum number is 20. Terminate your choice by pressing the [Enter] key.

- List Mode:** All channels in the list are measured. Metrics are computed for all of

GSM and EDGE Analyzer

Optional GSM and EDGE Tx Analyzer Measurement Settings

the displayed channels, but are only displayed for the single channel indicated by the vertical yellow line, which can be adjusted by using the [Display], [Position] menu keys. The maximum number of list items is 40. For further details, see [“Setting the Display Position” on page 349](#).

To Set the Scan Mode to List:

Step	Notes
1 [Freq/Chan]	
2 [Scan Mode]	Each time you press this key, the selected option changes. Set Scan Mode to List. For further details on how to add or remove items from your Scan List, see below.

Adding or Deleting a List Item

You may add and delete list items from the Scan Mode List for the specific channel/frequencies you want to measure.

NOTE

If you duplicate a channel entry in your list, you might notice that the graphical results for the duplicated channel vary. This is because the analyzer takes a separate acquisition of data for each of the channel plots. The variance you see in the displayed plots are due to the signal’s variance over time from one acquisition to the next.

To Add or Delete a List Item:

Step	Notes
1 Enter channels into the list.	The maximum number of list items is 40. If the number of channels displayed is 20 or fewer, a single bar graph is used to display them.
a. Use [Insert Row] to add a channel. First highlight a row, then use [Insert Row] to insert a row below the highlighted row. Then enter its number using the numeric keypad and [Up] or [Dn] to complete each entry.	If the number of channels displayed is greater than 20, two bar graphs are used to display them. Half of your selected channels are shown in a horizontal bar graph displayed in the upper portion of the screen, and the remaining channels are shown similarly in the lower portion of the screen.
b. Use [Delete Row] to remove channels you do not want displayed. Select a channel you want to remove using the up and down arrow buttons. Then press [Delete Row] to remove the selected channel.	
c. [Ok]	

Setting the Start Frequency/Channel

The Start Frequency or Start Channel sets the frequency (or channel) from which any scan will start. You can specify either a Start Frequency or a Start Channel, depending on your Units setting. This is described in [“Setting the Units of Measure for the Graphical Display” on page 346](#).

If your Start Channel mode is set to Chan, you can only view one channel at a time. The Stop Channel key will be disabled, and set to the same value as your Start Channel.

Start Channel and Start Band are independent of each other, so if you switch from Start Channel to Start Band, your previous Start Band and Stop Band settings will be restored.

If the channel you specified using the [Position] menu key can not be demodulated,

GSM and EDGE Analyzer

Optional GSM and EDGE Tx Analyzer Measurement Settings

you will see the message “No valid Slot Sync found” displayed on the graphic portion of the screen for all three views, and the numeric metrics at the bottom of the screen will be dashed out. In the Power versus Time view, the PvT Mask will not be shown even if you have switched it on.

To Set the Start Frequency or Start Channel:

Step	Notes
1 [Start Freq] or [Start Chan]	This choice depends on the [Units] mode you are using.
2 Enter the desired channel or frequency step using the numeric keypad.	
3 [Up] or [Dn] OR [Hz], [kHz], [MHz], or [GHz]	This choice depends on the [Units] mode you are using. When specifying channel numbers, terminate your selection with [Up] or [Dn] to specify either an Uplink channel or Downlink channel. When specifying a frequency, terminate your selection with one of the frequency units of measure. Notice (and verify) that the number you entered appears below the Start Freq or Start Chan text on the corresponding button.

Setting the Frequency or Channel Step Size

The Channel or Frequency Step sets the distance between the measured channels. The GSM standard has a channel spacing of 200 kHz, but the signal is actually somewhat wider than that. Therefore service providers often space their channels 400 kHz apart. The entered step value must be a multiple of 200 kHz.

You can specify your Step Size as a frequency band or as a number of channels, depending on your Units setting. This is described in [“Setting the Units of Measure for the Graphical Display”](#) on page 346.

To Set the Frequency or Channel Step Size:

Step	Notes
1 [Step Size]	This choice depends on the [Units] mode you are using.
2 Enter the desired channel or frequency step using the numeric keypad.	
3 [Up] or [Dn] or [Hz], [kHz], [MHz], or [GHz]	This choice depends on the [Units] mode you are using. When specifying a frequency, terminate your selection with one of the frequency units of measure. Notice (and verify) that the number you entered appears below the Chan Step or Freq Step text on the corresponding button.

Setting the Stop Frequency/Channel

- The Stop Frequency or Stop Channel sets the end frequency (or channel) to which the analyzer will scan. You can specify either a Stop Frequency or a Stop Channel, depending on your Units setting. This is described in [“Setting the Units of Measure for the Graphical Display”](#) on page 346.

To Set the Stop Frequency or the Stop Channel:

Step	Notes
1 [Stop Freq] or [Stop Chan]	This choice depends on the [Units] mode you are using.
2 Enter the desired channel or frequency step using the numeric keypad.	

Step	Notes
3 [Enter] OR [Hz], [kHz], [MHz], or [GHz]	This choice depends on the [Units] mode you are using. When specifying channel numbers, terminate your selection with [Up] or [Dn] to specify either an Uplink Channel or Downlink Channel. When specifying a frequency, terminate your selection with one of the frequency units of measure. Notice (and verify) that the number you entered appears below the Stop Freq or Stop Chan text on the corresponding button.

Setting the Channel Standard

You can specify one of the recognized GSM or EDGE standards for your measurements.

When you select your Channel Standard, the Start and Stop channels are automatically set to valid channels within the selected band only if your Units are set to Chan. If your Units are set to Freq, the Start and Stop Frequencies will not change from your current settings. For details on setting Units, see [“Setting the Units of Measure for the Graphical Display” on page 346](#).

To Set the Channel Standard:

Step	Notes
1 [Chan Std]	This displays a list of the pre-loaded channel standards.
2 Highlight the Channel Standard you want.	Use the Up and the Down arrows, or the knob, to navigate to the standard you want. Note that some standards might be off the top or the bottom of the screen.
3 [Select]	

Setting the Units of Measure for the Graphical Display

You can set your analyzer to display the graphical measurement results in either

absolute frequency or in channel numbers. This setting also determines whether frequency or channel number is displayed on the following keys:

- Start Freq
- Step Size
- Stop Freq or Stop Chan

To Set the Units:

Step	Notes
1 [Freq/Chan]	
2 [Units]	Each time you press this menu key, the selected option changes. Note and verify that the correct unit of measure (either frequency or channel number) is displayed on the X-axis beneath the graphics on the screen (Channel Scanner view only), and on the keys listed above.

NOTE

If the relevant frequencies on your display do not correspond to a valid channel number in the channel plan of the GSM or EDGE standard you have selected, both the graphics display and the key labels will show a “?”. For more details on setting channel standards, see [“Setting the Channel Standard” on page 346](#).

Setting Autoscale

When [Autoscale] is selected, [Ref Level] and [Scale/Div] are automatically calculated and any manually entered values will be reset. [Ref Level] and [Scale/Div] are only reset once when you press [Autoscale]. That is, they will not be repeatedly reset as your measurement results change.

To Set the Reference Level and Scale/Div Automatically:

Step	Notes
1 [Level/Location]	
2 [Autoscale]	

Setting the Reference Level

You can adjust the absolute amplitude represented by the top graticule line on the display (the reference level). Also, you can set the units per vertical graticule division on the display. When [Autoscale] is selected, [Ref Level] and [Scale/Div] are automatically calculated and any manually entered values will be reset.

To Set the Reference Level:

Step	Notes
1	[Level/Location]
2	Enter the reference level using the numeric keypad, the up and down arrows, or the knob.
3	[dBm] or [W]

Setting Scale/Division

You can use [Scale/Div] to determine the spacing of the graticule lines on your display.

To Set the Scale/Division:

Step	Notes
1	[Level/Location]
2	[Scale/Div]
3	Enter the graticule spacing value using the numeric keypad
4	[dB]

Using GPS for Frequency Reference and Location Information

You can use GPS Location data to verify your location and to provide an accurate frequency reference.

To Display GPS Location Information:

Step	Notes
1 [Level/Location]	
2 On [Show GPS Location] select On .	Displays GPS satellite location information. Uses the internal GPS to capture the location at which a measurement is made. The GPS information can be used to return to the same location. The Time Ref (Freq/Chan/Time Ref mode) button must be set to Internal GPS for this function to be active. Information logged includes longitude, latitude, altitude (feet/meters), and the number of satellites tracked. Each time you press this menu key, the selected option changes.
3 Highlight [On]	Toggle to [On] to display GPS satellite location information. Toggle to [Off] to remove the location information.

Setting the Display Position

You can set the location or position of the channel of interest. This determines the channel used to calculate the measurement metrics displayed in the metrics portion of the display. It also determines the center frequency in Spectrum View, and the channel from where slot information is displayed in the Power versus Time view.

In the Channel Scanner view only, the channel of interest is indicated by vertical yellow line.

To Set the Display Position:

Step	Notes
1 [Display]	
2 [Position]	

GSM and EDGE Analyzer

Optional GSM and EDGE Tx Analyzer Measurement Settings

Step	Notes
3	Enter the desired channel number or frequency using the numeric keypad, the up and down arrows, or the knob.
4	If Frequency/Channel Units have been set to Chan, select [Up] or [Dn] If Frequency/Channel Units have been set to Freq, select [Hz], [kHz], [MHz], or [GHz] If you use the up and down arrows or knob to change the channel number/frequency, the terminator units keys will not be displayed. However, the display will update to the entered number of bars after a few seconds.

Setting Auto Order

You can select the order that the channel bars are displayed. You can set them to be arranged in order of the relative power level or in order of the channel frequency. If you select **Pwr**, the bars are arranged in order of descending power. If you select **Freq**, the bars are arranged in order of ascending frequency.

This setting is only available when View is set to Channel Scanner, and Scan Mode is set to Auto.

To Set Auto Order:

Step	Notes
1	[Display]
2	On [Auto Order] select Pwr or Freq . Each time you press this menu key, the selected option changes.

Setting Bar Top and Units

You can set the channel power to be displayed (in dBm or watts) at the top of the channel bars. This only affects the power displayed on the top of the bars. The vertical scale of the graph does not change.

This setting is only available when View is set to Channel Scanner.

To Set Bar Top:

Step	Notes
1 [Display]	
2 On [Bar Top] select Off or Pwr.	Each time you press this menu key, the selected option changes.
2 On [Units] select dBm or Watts.	Each time you press this menu key, the selected option changes.

Setting Mid-Bar

You can set BSIC to be displayed at the middle of the channel bars.

This setting is only available when View is set to Channel Scanner, and when Scan Mode is set to Auto or to List.

To Set Mid-Bar:

Step	Notes
1 [Display]	
2 On [Mid-Bar] select Off or BSIC.	Each time you press this menu key, the selected option changes.

Setting Zoom

You can zoom into one or more of the eight slots in a channel, or you can zoom in further to look at just the rising and falling edges of a single slot. You use this Zoom setting to determine whether the analyzer displays the complete slot(s), or only the rising and falling edges.

If you select Zoom Rise/Fall to look at the rising and falling edges of a single slot, and your Zoom Interval is set to greater than one slot, the slot whose rising and falling edges are displayed is the slot corresponding to your Zoom Offset setting.

This setting is only available when View is set to Power versus Time.

For details on setting the Zoom Interval, see [“Setting Zoom Interval” on page 353.](#)

For details on setting the Zoom Offset, see [“Setting Zoom Offset” on page 352.](#)

GSM and EDGE Analyzer

Optional GSM and EDGE Tx Analyzer Measurement Settings

To Set Zoom:

Step	Notes
1 [Display]	
2 On [Zoom] select Slots or Rise/Fall .	Each time you press this menu key, the selected option changes.

Setting Zoom Offset

You can zoom into one or more of the eight slots in a channel using a combination of this Zoom Offset and the Zoom Interval. If you decide to zoom in on a portion of the channel, that is, you zoom in on fewer than the eight slots available, you can use the Zoom Offset setting to determine which of the slots is displayed first on the left side of the screen.

Your Zoom Offset setting also determines which slot is displayed when Zoom is set to Rise/Fall, that is, you choose to display only the rising and falling edges of a single slot.

The possible values you can set for Zoom Offset depend on your Zoom setting. If Zoom is set to Slots, that is, you want to display one or more slots or partial slots, you can set Zoom Offset to any value between 0.25 and 7.75 using 0.25 increments. If your Zoom setting is Rise/Fall, you can only set Zoom Offset to a whole integer value between 0 and 7.

Your Zoom Offset setting is also limited by your Zoom Interval setting. With eight slots in any one channel, your Zoom Offset and your Zoom Interval settings can not total any more than eight slots. As an example, if your Zoom Interval is already set to five, you can not set this Zoom Offset any higher than three. Using the same example, if you want to set your Zoom Offset higher than three, you must first lower your Zoom Interval setting.

NOTE

It is this Zoom Offset setting here that is limited by your Zoom Interval setting. Be aware that this Zoom Offset setting can be reduced by a later setting of a high Zoom Interval.

NOTE

The first of the eight slots in a channel is always referred to as Slot 0, and the final slot in the channel is Slot 7.

This setting is only available when View is set to Power versus Time.

For details on setting the Zoom Interval, see “[Setting Zoom Interval](#)” on page 353.
 For details on setting Zoom, see “[Setting Zoom](#)” on page 351.

To Set Zoom Offset:

Step	Notes
1 [Display]	
2 [Zoom Offset]	Enter the slot number using the numeric keypad, and terminate your selection using the [Slots] menu key. You can also use the knob or the up and down arrow keys to set the Zoom Offset.

Setting Zoom Interval

You can zoom into one or more of the eight slots in a channel using a combination of this Zoom Interval and the Zoom Offset. If you decide to zoom in on a portion of the channel, that is, you zoom in on fewer than the eight slots available, you use this Zoom Interval setting to determine how many of the eight slots are displayed.

The possible values you can set for Zoom Interval depend on your Zoom setting. If Zoom is set to Slots, that is, you want to display one or more slots or partial slots, you can set Zoom Interval to any value between 0.25 and 8.0 using 0.25 increments. If your Zoom setting is Rise/Fall, this key is not available because the Rise/Fall display is focussed on one particular slot only.

Your Zoom Offset is limited by this Zoom Interval setting. With eight slots in any one channel, your Zoom Offset and your Zoom Interval settings can not total any more than eight slots. If you enter a Zoom Interval figure here that, when added to the Zoom Offset setting, totals more than eight, your Zoom Offset setting will be reduced so that Zoom Offset + Zoom Interval = 8.

This Zoom Interval setting is only available if View is set to Power versus Time and if Zoom is set to Slots.

- NOTE

It is this Zoom Interval setting here that can have an effect on your Zoom Offset setting. Your Zoom Offset setting is limited by your setting of Zoom Interval.
- NOTE

The first of the eight slots in a channel is always referred to as Slot 0, and the final slot in the channel is Slot 7.

GSM and EDGE Analyzer

Optional GSM and EDGE Tx Analyzer Measurement Settings

For details on setting the Zoom Offset, see “Setting Zoom Offset” on page 352.

For details on setting Zoom, see “Setting Zoom” on page 351.

To Set Zoom Interval:

Step	Notes
1 [Display]	
2 [Zoom Interval]	Enter the number of slots using the numeric keypad, and terminate your selection using the [Slots] menu key. You can also use the knob or the up and down arrow keys to set the Zoom Interval.

Setting PvT Mask

You can choose to display or to hide the Power versus Time Mask using the PvT Mask menu key.

The EDGE specifications set minimum and maximum limits to the slot power when measured over time. The PvT mask displays these limits on the screen. The Lower Limit Mask is shown in yellow, and the Upper Limit Mask is shown in magenta (pink).

This setting is only available when View is set to Power versus Time.

To Set the PvT Mask:

Step	Notes
1 [Display]	
2 On [PvT Mask], select On or Off .	Each time you press this menu key, the selected option changes.

Setting Auto Mode Bar Count

The **Measurement Bar Count** setting allows you to alter the number of channel data bars displayed when you set the [Scan Mode] to **Auto**. The channels that have the highest power will be displayed, up to the number of channels you have set.

If you set you Start Freq mode to Chan, your E7495 test set displays only one channel, so your Auto Mode Bar Count is automatically set to 1. If you later set your

Start Freq mode to Freq so you can display several channels, your Auto Mode Bar Count setting will stay at 1. You will need to change Auto Mode Bar Count manually if you want to display more than one channel, or set your Scan Mode to Range or to List.

To Set the Measurement Auto Mode Bar Count:

Step	Notes
1 [Setup]	
2 [Auto Mode Bar Count]	
3 Enter the number of bars to display using the numeric keypad, the up and down arrows, or the knob.	The maximum number of bars that can be displayed is 20.
4 [Enter]	If you use the up and down arrows or the knob to change the bar count number, the Enter key will not be displayed. However, the display will update to the entered number of bars after a few seconds.

Setting Slot Synchronization

The **Slot Sync** setting allows you to specify which slot is used for demodulation. The default is **Auto**.

If Option 235 - EDGE Analyzer is installed, both GMSK and 8PSK signals can be demodulated. If Option 235 - EDGE Analyzer is not installed, only GMSK signals can be demodulated.

The different slot synchronization settings available to you are:

- **Highest Pwr:** The slot that is demodulated is the active slot with the highest power
- **Auto:** The analyzer demodulates a randomly selected active slot.
- **GMSK:** The analyzer demodulates a randomly selected active GMSK slot. This option is grayed out if Option 235 - EDGE Analyzer is not installed.
- **8PSK:** The analyzer demodulates the randomly selected active 8PSK slot. This option is grayed out if Option 235 - EDGE Analyzer is not installed.
- **Specified TS# (w/ BCCH):** The analyzer demodulates the specified TS#

GSM and EDGE Analyzer

Optional GSM and EDGE Tx Analyzer Measurement Settings

(Training Sequence number) if a **BCCH** (Broadcasting Control Channel) is detected. If Option 235 - EDGE Analyzer is not installed, only GMSK signals can be demodulated. For more details on TS#, refer to [“Setting TS# \(w/ BCCH\)” on page 356](#).

If no BCCH is detected, **Auto** is used even though **Specified TS# (w/ BCCH)** is still selected.

If you have Slot Sync set to **Specified TS# (w/ BCCH)**, and no BCCH channel is found, the message “BCCH not found - using Auto Slot Sync” will be displayed.

To Set the Slot Synchronization:

Step	Notes
1 [Setup]	
2 [Slot Sync]	
3 [Highest Pwr], [Auto], [GMSK], [8PSK], or [Specified TS# (w/ BCCH)]	[GMSK] and [8PSK] are only available if you have Option 235 - EDGE Analyzer installed.

Setting TS# (w/ BCCH)

The **TS# (w/ BCCH)** setting allows you to specify which Training Sequence is used for slot synchronization. This parameter is disabled unless Slot Sync is set to Specified TS# (w/ BCCH). For more details on setting Slot Sync, refer to [“Setting Slot Synchronization” on page 355](#).

To Set the Training Sequence Number:

Step	Notes
1 [Setup]	
2 [Specified TS# (w/ BCCH)]	This key is disabled unless Slot Sync is set to Specified TS# (w/ BCCH)
3 Enter the TS# using the numeric keypad.	You must enter a number between 0 and 7.
4 [Enter]	

Setting the Pass/Fail Limits

The measurement limits settings allow you to alter the values of a range of upper and lower test limits. All of these settings, with the exception of Channel Scanner Power, affect the metrics color display: red represents fail, green represents pass.

You can switch each measurement limit On or Off independently of all other limits. If one or more measurement limits is turned On, and they all pass, the summary text “ALL PASS” is displayed below the numerical results of the screen. If any limit test fails, the summary text “FAILURE” is displayed in the same area.

NOTE

A pass or fail of the Channel Scanner Power Limit does not affect the summary status.

[“Setting Channel Scanner Power Limits” on page 357](#)

[“Setting Frequency Error Limits” on page 358](#)

[“Setting TS Power Limits” on page 359](#)

[“Setting the I/Q Offset Limit” on page 360](#)

[“Setting the RMS Phase Error Limit” on page 361](#)

[“Setting the Peak Phase Error Limit” on page 362](#)

[“Setting the RMS EVM Limit” on page 362](#)

[“Setting the Peak EVM Limit” on page 363](#)

[“Setting the 95th Percentile EVM Limit” on page 364](#)

Setting Channel Scanner Power Limits

You can set upper and lower Channel Scan Power Limits to determine which of the channels scanned are valid. Channels whose power falls within your specified limits are displayed in green on your graphics display, and are further indicated with a “P” for “Pass”. Channels whose power either falls below the lower limit, or exceeds the upper limit, are displayed in red on your graphics display, and are indicated with an “F” for “Fail”. A pass or fail of this Channel Scanner Power Limit does not affect the summary status message. If Channel Power Limits are set to Off, the channels are displayed in blue on the screen, and no Pass/Fail indicator is shown.

If Chan Scan Pwr Limits are set to On, the limits you specified are represented on the graphics display with two yellow lines. The High Limit line is indicated with “H>”, and the Low Limit line with “<L”.

GSM and EDGE Analyzer

Optional GSM and EDGE Tx Analyzer Measurement Settings

To Set the Channel Scan Upper and Lower Limits:

Step	Notes
1 [Setup]	
2 [Chan Scan Pwr Limits]	
3 [Limits]	
4 [On] or [Off]	
5 Set the upper limit.	The limit is specified in dBm.
a. [High Limit]	
b. Enter the number on the numeric keypad.	
c. [dBm]	
6 Set the lower limit.	The limit is specified in dBm.
a. [Low Limit]	
b. Enter the number on the numeric keypad.	
c. [dBm]	

Setting Frequency Error Limits

You can set upper and lower Frequency Error Limits for your Frequency Error Measurement results.

If Freq Error Limits are turned On, and your measured frequency error is within the limits you have specified, the numeric result reported in the metrics portion of the screen will be displayed in green, and the Limit Pass will be indicated by “(P)” after the result. If your measured frequency error is outside your specified limits, the numeric result reported in the metrics portion of the screen will be displayed in red, and the Limit Failure will be indicated by “(F)” after the result.

To Set the Frequency Error Upper and Lower Limits:

Step	Notes
1 [Setup]	

Step	Notes
2 [Freq Error Limits]	
3 [Limits]	
4 [On] or [Off]	
5 Set the upper limit. a. [High Limit] b. Enter the number on the numeric keypad. c. [ppm]	
6 Set the lower limit. a. [Low Limit] b. Select Auto or Manual c. If you have selected Manual in Step 6b, enter the number on the numeric keypad. d. If you have selected Manual in Step 6b, press [ppm].	If you select Auto, the Low Limit is automatically set to negative (High Limit). For example, if High Limit is set to 0.05 ppm, then the Auto Low Limit is set to −0.05 ppm. If you select Manual, you must specify the limit in ppm. If you switch from Manual to Auto, and then back to Manual, the previous Manual setting is not restored.

NOTE

The disabled gray keys showing your High Limit and your Low Limit in Hz are for information only. They display the calculated frequency error limits in Hz. The displayed values (in Hertz) are calculated from your current frequency and your specified limits in ppm.

Setting TS Power Limits

You can set upper and lower Timeslot Power Limits for your TS Power Measurement results.

If TS Power Limits are turned On, and your measured TS power is within the limits you have specified, the numeric results reported in the metrics portion of the screen will be displayed in green, and the Limit Pass will be indicated by “(P)” after the

GSM and EDGE Analyzer

Optional GSM and EDGE Tx Analyzer Measurement Settings

results. If your measured TS Power is outside your specified limits, the numeric results reported in the metrics portion of the screen will be displayed in red, and the Limit Failure will be indicated by “(F)” after the results.

To Set the TS Power Limits:

Step	Notes
1	[Setup]
2	[TS Pwr Limits]
3	[Limits]
4	[On] or [Off]
5	Set the upper limit. [High Limit] - Enter the number on the numeric keypad. [dBm]
6	Set the lower limit. [Low Limit] - Enter the number on the numeric keypad. [dBm]

Setting the I/Q Offset Limit

You can set an upper I/Q Offset Limit for your Measurement results.

If I/Q Offset Limit is turned On, and your measured I/Q Offset is below the limit you have specified, the numeric results reported in the metrics portion of the screen will be displayed in green, and the Limit Pass will be indicated by “(P)” after the result. If your measured I/Q Offset is above your specified limit, the numeric result reported in the metrics portion of the screen will be displayed in red, and the Limit Failure will be indicated by “(F)” after the results.

To Set the I/Q Offset Limit:

Step	Notes
1	[Setup]
2	[I/Q Offset Limits]
3	[Limits]
4	[On] or [Off]
5	Set the high limit. a. [High Limit] b. Enter the number on the numeric keypad. c. [dB]

Setting the RMS Phase Error Limit

You can set an upper RMS Phase Error Limit for your Measurement results.

If RMS Ph Err Limit is turned On, and your measured RMS Phase Error is below the limit you have specified, the numeric results reported in the metrics portion of the screen will be displayed in green, and the Limit Pass will be indicated by “(P)” after the result. If your measured RMS Phase Error is above your specified limit, the numeric result reported in the metrics portion of the screen will be displayed in red, and the Limit Failure will be indicated by “(F)” after the results.

To Set the RMS Phase Error Limit:

Step	Notes
1	[Setup]
2	[RMS Ph Err Limits]
3	[Limits]
4	[On] or [Off]

GSM and EDGE Analyzer

Optional GSM and EDGE Tx Analyzer Measurement Settings

Step	Notes
5	Set the high limit.
	a. [High Limit]
	b. Enter the number on the numeric keypad.
	c. [deg]

Setting the Peak Phase Error Limit

You can set an upper Peak Phase Error Limit for your Measurement results.

If Peak Ph Err Limit is turned On, and your measured Peak Phase Error is below the limit you have specified, the numeric results reported in the metrics portion of the screen will be displayed in green, and the Limit Pass will be indicated by “(P)” after the result. If your measured Peak Phase Error is above your specified limit, the numeric result reported in the metrics portion of the screen will be displayed in red, and the Limit Failure will be indicated by “(F)” after the results.

To Set the Peak Phase Error Limit:

Step	Notes
1	[Setup]
2	[Peak Ph Err Limits]
3	[Limits]
4	[On] or [Off]
5	Set the high limit.
	a. [High Limit]
	b. Enter the number on the numeric keypad.
	c. [deg]

Setting the RMS EVM Limit

You can set an upper RMS Error Vector Magnitude Limit for your Measurement

results.

If RMS EVM Limit is turned On, and your measured RMS EVM is below the limit you have specified, the numeric results reported in the metrics portion of the screen will be displayed in green, and the Limit Pass will be indicated by “(P)” after the result. If your measured RMS EVM is above your specified limit, the numeric result reported in the metrics portion of the screen will be displayed in red, and the Limit Failure will be indicated by “(F)” after the results.

To Set the RMS EVM Limit:

Step	Notes
1	[Setup]
2	[RMS EVM Limits]
3	[Limits]
4	[On] or [Off]
5	Set the high limit. a. [High Limit] b. Enter the number on the numeric keypad. c. [%]

Setting the Peak EVM Limit

You can set an upper Peak Error Vector Magnitude Limit for your Measurement results.

If Peak EVM Limit is turned On, and your measured Peak EVM is below the limit you have specified, the numeric results reported in the metrics portion of the screen will be displayed in green, and the Limit Pass will be indicated by “(P)” after the result. If your measured Peak EVM is above your specified limit, the numeric result reported in the metrics portion of the screen will be displayed in red, and the Limit Failure will be indicated by “(F)” after the results.

To Set the Peak Phase Error Limit:

Step	Notes
1	[Setup]

GSM and EDGE Analyzer

Optional GSM and EDGE Tx Analyzer Measurement Settings

Step	Notes
2	[Peak EVM Limits]
3	[Limits]
4	[On] or [Off]
5	Set the high limit. [High Limit] - Enter the number on the numeric keypad. [%]

Setting the 95th Percentile EVM Limit

You can set an upper 95th Percentile Error Vector Magnitude Limit for your Measurement results.

If 95%tile EVM Limit is turned On, and your measured 95th Percentile EVM is below the limit you have specified, the numeric results reported in the metrics portion of the screen will be displayed in green, and the Limit Pass will be indicated by “(P)” after the result. If your measured 95th Percentile EVM is above your specified limit, the numeric result reported in the metrics portion of the screen will be displayed in red, and the Limit Failure will be indicated by “(F)” after the results.

To Set the Peak Phase Error Limit:

Step	Notes
1	[Setup]
2	[95%tile EVM Limits]
3	[Limits]
4	[On] or [Off]

Step	Notes
5	Set the high limit. a. [High Limit] b. Enter the number on the numeric keypad. c. [%]

Adding a Marker

Markers can only be used when your View is either Power versus Time, or Spectrum. The Marker keys are disabled when your View is Channel Scanner. If you activate a marker in one view, and then change to another view, the marker(s) will not be transferred to the new View. Markers in each view are independent of each other. If, however, you then return to your original view with the markers, your previous marker settings will be restored.

Markers can be used on traces and masks to help you visually track up to four points. Each marker has the following settings:

- **Type:** Provides three options, including:
 - **Off**
 - **Normal:** Places a diamond-shaped, colored marker, along with a number, 1-4, on the trace.
 - **Delta:** Associated with a normal marker. Therefore, a normal marker must exist prior to creating the delta marker. The delta marker displays the difference between the normal marker position and the delta marker position. Only one delta marker can be associated with a given normal marker. The normal marker must be active when Delta is selected.
- **Trace:** Provides three options in the Power versus Time view, and two options in the Spectrum view. The Trace options are:
 - **RF Envelope (PvT only):** Places the currently selected marker on the RF Envelope trace.
 - **Upper Mask (PvT only):** Places the currently selected marker on the Upper Mask.
 - **Lower Mask (PvT only):** Places the currently selected marker on the Lower

GSM and EDGE Analyzer

Optional GSM and EDGE Tx Analyzer Measurement Settings

Mask.

- **Normal (Spectrum view only):** Places the currently selected marker on the Normal trace, that is, on an unaveraged trace.
- **Averaged (Spectrum view only):** Places the currently selected marker on the Averaged trace. This Trace option is only available if Averaging is turned On, and then only in the Spectrum view.
- **Marker to Peak:** Places the active marker on the current greatest value of the specified trace. When you press this menu key, you will see **1/32** at the bottom of the key, indicating that the marker is currently placed on the highest (the “1” in 1/32) of the 32 highest trace positions. This display will change every time you press **Marker to Next Peak** (see below).
- **Marker to Next Peak:** Moves the active marker left or right to the next greatest value on the trace. Every time you press this menu key, the label at the bottom of the **Marker to Peak** menu key will cycle from 1/32 to 2/32, then to 3/32, and so forth until it reaches 32/32. At this point, when the **Marker to Peak** menu key is displaying 32/32, this **Marker to Next Peak** menu key will be deactivated, and will no longer be available to you. Your marker is then positioned on the 32nd (and last) of the 32 highest peak positions. You will need to press the **Marker to Peak** menu key to reactivate this **Marker to Next Peak** menu key.

The fractional number, that is, 1/32, 2/32, and so forth, that is displayed on the **Marker to Peak** menu key label indicates that the marker is currently positioned on the first (1/32) of the 32 highest peak positions available, the second (2/32) of the highest peak positions, and so forth.

To add a marker to a trace

Step	Notes
1 [Marker]	
2 [Marker]	Every time you press this menu key, the selected marker number changes by 1.
3 [Type]	
4 [Off], [Normal], or [Delta]	
5 [Trace]	In the Spectrum view, the Trace key will be disabled if you have Averaging switched Off.

Step	Notes
6	In PvT view, select [RF Envelope], [Upper Mask], or [Lower Mask]. In Spectrum view, select [Normal] or [Averaged].
7	Locate the marker relative to the trace: [Marker to Peak] or [Marker to Next Peak]

Compensating for the Loss of an External Cable and Attenuator

The insertion loss of the test cable and high power attenuator must be compensated for to obtain accurate GSM power measurements. This process is called “normalization” and is described in [“Measuring Two Port Insertion Loss” on page 124](#).

The insertion loss of the combination of test cable and attenuator is accounted for as the RF In Loss, which is an offset applied to the power measurements by the test set.

Step	Notes
1	[Level/Location]
2	[RF IN Loss]
3	Enter the RF In loss using the numeric keypad. If you are using a cable and additional devices connected to the antenna, enter the combined cable and device RF In loss here. The RF In loss can be obtained by measuring the Insertion loss. See “Two Port Insertion Loss” on page 123. Note: If data had been previously entered in [RF In Loss], that data will be lost and replaced by the value you enter here.
4	[dB]

Setting Average, Sweep, and Restart

Setting the Sweep

You can select either continuous or single sweep. Continuous sweep provides repeated, ongoing measurements. Single sweep performs a single measurement that is repeated only when you push the Single button.

If you have set Sweep to Single, and you are in the Power versus Time view or the Spectrum view, you will see the message “No Graph Data. Re-acquire using current Display Position” if you change your Position setting. To remove this message, either change your Position back to its original setting, or restart your measurement by pressing [Single] again. For more details on setting the Display Position, see [“Setting the Display Position” on page 349](#).

To set sweep:

Step	Notes
1 [Average/Sweep]	
2 [Continuous] or [Single]	Each time you press this menu key, the selected option changes.

NOTE

A very useful facility if you have completed a single sweep is being able to look at that sweep's data in a variety of different ways without taking a new measurement. You can change any of the View settings (Channel Scanner, Power versus Time, or Spectrum), you can change any of the Zoom settings (Zoom, Zoom Offset, or Zoom Interval), and you can even change the Position setting. This enables you to look very closely at every aspect of one particular sweep measurement, knowing all the time that you are looking at the same measurement data every time.

Setting Averaging

You can choose to have averaging On or Off and set the number of averages you want to take. Averaging only applies to measuring of the channel power. You can select from the following types of averaging:

- **Off:** Disables averaging.
- **Running Average:** Computes the new result as the weighted sum of the last

result and the new measurement. The last result is weighted by $(n - 1)/n$. The new result is weighted by $1/n$. Each new measurement produces a new result.

If you are measuring an intermittent signal and no valid demodulated signal is acquired, the numeric results will display the last valid, Running Average results until a fresh, valid signal is acquired. This enables you inspect the averaged results for poor quality, intermittent signals that might otherwise be lost.

- Max Hold:** Is not an average, but on a point by point basis, displays the maximum amplitude for the given frequency or channel since Max Hold was turned on. It is updated when a new maximum occurs.

If you are measuring an intermittent signal and no valid demodulated signal is acquired, the numeric results will display the last valid, averaged Max Hold results until a fresh, valid signal is acquired.
- Group Average:** Makes the requested number of measurements, averages the measurement data, and displays the average as a single result-trace. Measurement time will vary based on the requested number of averages and can take minutes for very large number of averages.
- Group Max Average:** Makes the requested number of measurements before returning a single result-trace. This trace is the maximum value seen at each trace point over the requested number of averages (measurements).

To set averaging:

Step	Notes
1	Set the number of averages. a. [Average/Sweep] b. [Average] c. Enter the number of averages using the numeric keypad. d. [Enter]

GSM and EDGE Analyzer

Optional GSM and EDGE Tx Analyzer Measurement Settings

Step	Notes
2	Select the type of averaging you want to apply.
	e. [Averaging]
	f. [Off], [Running Average], [Max Hold], [Group Average], or [Group Max Average]

NOTE

These two steps can be performed in any order. However, if you turn averaging on and a large number of averages has previously been set, there may be a delay before you can change number of averages.

Setting Restart

When you have averaging turned **On** and you are in **Continuous** Sweep mode, you can restart the averaging by pressing the Restart menu key. The Restart key has no effect if you are in **Single** sweep mode.

To restart averaging:

Step	Notes
1	[Average/Sweep]
2	[Restart]
	This key is unavailable or has no effect when Sweep is set to Single . To restart a Single Sweep measurement, press [Single].

GSM and EDGE Modulation and Band Information

The standard includes multiple traffic channels, a control channel, and a cell broadcast channel. Although the GSM specification defines a channel spacing of 200 kHz, it is worth noting that service providers often space their channels 400 kHz apart.

GSM 450, GSM 480, GSM 900, GSM 850, DCS 1800, and PCS 1900 are GSM-defined frequency bands. The term GSM 900 is used for any GSM system operating in the 900 MHz band, which includes P-GSM, E-GSM, and R-GSM. Primary (or standard) GSM 900 band (P-GSM) is the original GSM band. Extended GSM 900 band (E-GSM) includes all the P-GSM band plus an additional 50 channels. Railway GSM 900 band (R-GSM) includes all the E-GSM band plus additional channels.

DCS 1800 is an adaptation of GSM 900, created to allow for smaller cell sizes for higher system capacity. PCS 1900 is intended to be identical to DCS 1800 except for frequency allocation and power levels. The term GSM 1800 is sometimes used for DCS 1800, and the term GSM 1900 is sometimes used for PCS 1900. For specifics on the bands, refer to “[GSM and EDGE Modulation and Band Data](#)” table below.

The framing structure for GSM measurements is based on a hierarchical system consisting of timeslots, TDMA frames, multiframe, superframes, and hyperframes. One timeslot consists of 156.25 (157) symbol periods including tail, training sequence, encryption, guard time, and data bits. Eight of these timeslots make up one TDMA frame. Either 26 or 51 TDMA frames make up one multiframe. Frames 13 and 26 in the 26 frame multiframe are dedicated to control channel signaling.

EDGE (Enhanced Data for Global Evolution) is an enhanced version of GSM that uses 8PSK (**8-Phase Shift Keying**) as opposed to the GMSK (**Gaussian Minimum Shift Keying**) of GSM. EDGE can therefore transmit three times as many bits per symbol as GSM while using the same framing structure.

GSM and EDGE Analyzer

GSM and EDGE Modulation and Band Information

Table 12-1 GSM and EDGE Modulation and Band Data

	GSM 450	GSM 480	GSM 850	P-GSM (GSM 900)	E-GSM (GSM 900)	R-GSM (GSM 900)	DCS 1800 (GSM 1800)	PCS 1900 (GSM 1900)
Uplink (MS Transmit)	450.4 to 457.6 MHz	478.8 to 486.0 MHz	824 to 849 MHz	890 to 915 MHz	880 to 915 MHz	876 to 915 MHz	1710 to 1785 MHz	1850 to 1910 MHz
Downlink (BTS Transmit)	460.4 to 467.6 MHz	488.8 to 496.0 MHz	869 to 894 MHz	935 to 960 MHz	925 to 960 MHz	921 to 960 MHz	1805 to 1880 MHz	1930 to 1990 MHz
Range (ARFCN)	259 to 293	306 to 340	128 to 251	1 to 124	0 to 124 and 975 to 1023	1 to 124 and 955 to 1023	512 to 885	512 to 810
TX/RX Spacing (Freq.)	45 MHz	45 MHz	45 MHz	45 MHz	45 MHz	45 MHz	95 MHz	80 MHz
TX/RX Spacing (Time)	3 timeslots	3 timeslots	3 timeslots	3 timeslots	3 timeslots	3 timeslots	3 timeslots	3 timeslots
Modulation Data Rate GMSK (kbits/s): 8PSK (kbits/s)	270.833 810	270.833 810	270.833 810	270.833 810	270.833 810	270.833 810	270.833 810	270.833 810
Frame Period	4.615 ms	4.615 ms	4.615 ms	4.615 ms	4.615 ms	4.615 ms	4.615 ms	4.615 ms
Timeslot Period	576.9 μs	576.9 μs	576.9 μs	576.9 μs	576.9 μs	576.9 μs	576.9 μs	576.9 μs
GSM Bit and Symbol Period	3.692 μs	3.692 μs	3.692 μs	3.692 μs	3.692 μs	3.692 μs	3.692 μs	3.692 μs
EDGE Bit and Symbol Period	1.235 μs	1.235 μs	1.235 μs	1.235 μs	1.235 μs	1.235 μs	1.235 μs	1.235 μs
Modulation - GSM	0.3 GMSK	0.3 GMSK	0.3 GMSK	0.3 GMSK	0.3 GMSK	0.3 GMSK	0.3 GMSK	0.3 GMSK
Modulation - EDGE	3π/8 8PSK	3π/8 8PSK	3π/8 8PSK	3π/8 8PSK	3π/8 8PSK	3π/8 8PSK	3π/8 8PSK	3π/8 8PSK
Channel Spacing	200 kHz	200 kHz	200 kHz	200 kHz	200 kHz	200 kHz	200 kHz	200 kHz
TDMA Mux	8	8	8	8	8	8	8	8
Voice Coder Bit Rate	13 kbits/s	13 kbits/s	13 kbits/s	13 kbits/s	13 kbits/s, 5.6 kbits/s	13 kbits/s	13 kbits/s	13 kbits/s

Metrics Provided by the GSM and EDGE Analyzer Measurement

This section contains descriptions of the individual GSM transmit parameters in the metrics display of the screen. The “Interpretation of GSM Tx Analyzer Measurement Results” section contains expected result values and possible causes of error if the expected results are not met.

Frequency

Frequency of the channel indicated by the vertical yellow line on the Channel Scanner display. The position of this yellow line can be adjusted by using the [Display], [Position] menu keys. For further details, see [“Setting the Display Position” on page 349](#).

Frequency Error

Frequency error is the frequency difference between your transmitter's actual center frequency and the frequency (or channel) you entered.

BSIC (Base Station Identification Code)

A two digit number that identifies the base station for the indicated channel. It consists of the PLMN color code with a range from 0 to 7, and the S color code with a range from 0 to 7. The BSIC is shown in Decimal format $(8 * NCC) + BCC$. For example, if the NCC is 4, BCC is 3, the BSIC will be 35 ($4*8+3 = 35$). BSIC is transmitted on a synchronization channel and is used to identify a cell and to indicate the timing sequence being used.

- BCC = Base station Color Code
- BSIC = Base Station Identity Code
- NCC = Network Color Code
- PLMN = Public Land Mobile Network

TSC

TSC (Training Sequence Code) is a single digit integer from 0 to 7, “n/a (Sync)” if the demodulated slot is a GMSK Sync burst. The training Sequence is in the center of every burst, and is used to determine the start and stop of the useful part of the burst.

GSM and EDGE Analyzer

Metrics Provided by the GSM and EDGE Analyzer Measurement

Mod Type

Modulation Type can be either GMSK or 8PSK. GSM signals use GMSK modulation, and EDGE signals use 8PSK modulation.

TS Pwr (Timeslot Power)

The average power of the highest power timeslot in the acquired frame. This is the absolute power level and displayed in both dBm and microWatts.

OBW (Occupied Bandwidth)

This is the 99% power bandwidth of the centered 500 kHz span at the channel frequency. In other words, the total power of 500 kHz span centered at the channel frequency is computed, then the bandwidth that contains 99% of the total power is returned as the occupied bandwidth.

I/Q Offset

I/Q origin offset is a value in dB of the I and Q error (magnitude squared) offset from the origin. It indicates the magnitude of the carrier feedthrough signal. When there is no carrier feedthrough, I/Q Offset is zero.

RMS and Peak Phase Error

Phase error is the fundamental measure of modulation quality in GSM and EDGE systems. Since GSM and EDGE systems use relative phase to transmit information, the phase accuracy of the GSM or EDGE transmission is critical to the system's performance, and ultimately to its effective range.

The Phase Error metrics are only reported for GSM signals with their GMSK modulation. Phase Error is not reported for EDGE signals, with their 8PSK modulation, since this measurement of signal quality is reported as part of the Error Vector Magnitude metric. For more details on Error Vector Magnitude measurements with EDGE signals, see [“RMS, Pk, and 95%tile Error Vector Magnitude” on page 375](#).

The phase error is computed by measuring the test signal and computing the difference between the phase of the transmitted signal and the phase of a theoretically perfect signal.

RMS Phase Error: This is the RMS of the phase error (in degrees) between the measured phase and the ideal phase of a TCH timeslot. The GSM standard specifies the RMS phase error not to exceed 5 degrees during the useful part of the GSM burst.

Pk Phase Error: Peak phase error is the maximum phase error (in degrees) between

Metrics Provided by the GSM and EDGE Analyzer Measurement

the measured phase and the ideal phase of a TCH timeslot, at a single instant. The GSM standard specifies the peak phase error not to exceed 20 degrees during the useful part of the GSM burst.

RMS, Pk, and 95%tile Error Vector Magnitude

Error Vector Magnitude (EVM) is used as a measure of the quality of a signal, and represents the difference, in both phase and magnitude, between a theoretically perfect signal and the actual signal received.

Another measure of quality similar to EVM is Modulation Error Ratio (MER), which is sometimes referred to as Carrier to Interference Ratio (C/I). For further details on MER and C/I, see the section at the end of [“Interpretation of GSM and EDGE Analyzer Measurement Results” on page 376](#).

NOTE

RMS EVM, Peak EVM, and 95%tile EVM measurements are only available if Option 235 - EDGE Analyzer is installed

RMS EVM: This is the RMS of the EVM (Error Vector Magnitude), and is only reported for 8PSK modulated signals, that is, for EDGE signals only and not for GSM signals. EVM is measured and calculated over the useful part of the burst, and is shown as a percentage.

The EVM metrics are only reported for EDGE signals with their 8PSK modulation. EVM is not reported for GSM signals, with their GMSK modulation, since this measurement of signal quality is reported as the Phase Error metric. For more details on Phase Error measurements with GSM signals, see [“RMS and Peak Phase Error” on page 374](#).

Pk EVM: This is the Peak of the EVM (Error Vector Magnitude), and is only reported for 8PSK modulated signals, that is, for EDGE signals only and not for GSM signals. EVM is measured and calculated over the useful part of the burst, and is shown as a percentage.

95%tile EVM: This is the 95th Percentile of the EVM (Error Vector Magnitude), and is only reported for 8PSK modulated signals, that is, for EDGE signals only and not for GSM signals. In other words, it is the EVM value below which 95% of all measurements fall. EVM is measured and calculated over the useful part of the burst, and is shown as a percentage.

Interpretation of GSM and EDGE Analyzer Measurement Results

This section contains expected result values and possible causes of error if the expected results are not met.

Frequency Error

The GSM standard specifies very tight frequency error performance. In the GSM 900 band, the 0.05 ppm (parts-per-million) specification translates to only 45 Hz error.

Frequency error measurements indicate synthesizer/phase lock loop performance. This is especially important in a BTS with frequency hopping active. Poor frequency error measurements can show, for example, that a synthesizer is failing to settle quickly enough as it shifts frequency between transmissions. Poor frequency error can cause a multitude of problems, for example, the target receiver may be unable to gain lock, and the transmitter may cause interference with other users.

You will need to use an external reference or GPS (if available) in order to achieve an accurate frequency error reading.

BSIC (Base Station Identity Code)

If the BSIC can not be decoded, dashes will be displayed. If it is not as expected, check the base station settings against the plan.

TS Pwr (Timeslot Power)

Maximum Timeslot Power is the measure of in-channel power for GSM Systems. The purpose of the Maximum Timeslot Power measurement is to determine the power delivered to the antenna system in the radio frequency/channel under test. The Maximum Timeslot Power measurement verifies the accuracy of the transmitted RF carrier power.

If the maximum timeslot power is lower than expected, verify you have a good connection to the RF output of the base station. Also, verify the cable you are using to connect to the base station is not faulty. A low power may also indicate an issue with the power amplifier.

Inaccurate channel power (high or low) may indicate an incorrect power setting at the base station.

Phase Error and I/Q offset

Phase error (not EVM) is the fundamental measure of modulation quality in GSM systems. Since GSM systems use relative phase to transmit information, the phase accuracy of the GSM transmission is critical to the system's performance, and ultimately to its effective range. EVM is not the primary metric for GSM signals because GMSK modulation uses constant amplitude.

The phase error is computed by measuring the test signal and computing the difference between the phase of the transmitted signal and the phase of a theoretically perfect signal.

Poor phase error or I/Q offset could indicate a problem with the I/Q baseband generator, filters, or modulator in the transmitter circuitry. The output amplifier in the transmitter can also create distortion that causes unacceptably high phase error. Poor phase error will reduce the ability of a receiver to correctly demodulate signals, especially in marginal signal conditions. This ultimately affects range.

The Phase Error metrics are only reported for GSM signals with their GMSK modulation. Phase Error is not reported for EDGE signals, with their 8PSK modulation, since this measurement of signal quality is reported as part of the Error Vector Magnitude metric. For more details on Error Vector Magnitude measurements with EDGE signals, see below.

Another measure of quality similar to EVM is Modulation Error ratio (**MER**), which is sometimes referred to as Carrier to Interference Ratio (**C/I**). For further details on MER and C/I, see [“Modulation Error Ratio \(MER\) and Carrier to Interference Ratio \(C/I\)” on page 378](#).

RMS EVM: This is the RMS of the EVM (Error Vector Magnitude). EVM is measured and calculated over the useful part of the burst, and is shown as a percentage. The EVM figure represents the difference, in both phase and magnitude, between a theoretically perfect signal and the actual signal received. The EDGE standard specifies the RMS EVM not to exceed 7.0% during the useful part of the EDGE burst, when under normal operating conditions, and excluding the effect of passive combining equipment. RMS EVM may go as high as 8% under extreme operating conditions, again excluding the effect of passive combining equipment.

The EVM metrics are only reported for EDGE signals with their 8PSK modulation. EVM is not reported for GSM signals, with their GMSK modulation, since this measurement of signal quality is reported as the Phase Error metric.

Pk EVM: This is the RMS of the EVM (Error Vector Magnitude). EVM is measured and calculated over the useful part of the burst, and is shown as a percentage. The EVM figure represents the difference, in both phase and magnitude, between a theoretically perfect signal and the actual signal received. The EDGE

GSM and EDGE Analyzer

Interpretation of GSM and EDGE Analyzer Measurement Results

standard specifies the Peak EVM not to exceed 11.0% during the useful part of the EDGE burst, under all operating conditions, and excluding the effect of passive combining equipment.

The EVM metrics are only reported for EDGE signals with their 8PSK modulation. EVM is not reported for GSM signals, with their GMSK modulation, since this measurement of signal quality is reported as the Phase Error metric.

95 %tile EVM: This is the 95th Percentile of the EVM (Error Vector Magnitude). In other words, it is the EVM value below which 95% of all measurements fall. EVM is measured and calculated over the useful part of the burst, and is shown as a percentage. The EVM figure represents the difference, in both phase and magnitude, between a theoretically perfect signal and the actual signal received. The EDGE standard specifies the 95th Percentile EVM not to exceed 11.0% during the useful part of the EDGE burst, under all operating conditions, and excluding the effect of passive combining equipment.

The EVM metrics are only reported for EDGE signals with their 8PSK modulation. EVM is not reported for GSM signals, with their GMSK modulation, since this measurement of signal quality is reported as the Phase Error metric.

Modulation Error Ratio (MER) and Carrier to Interference Ratio (C/I)

Modulation Error Ratio (also referred to as Carrier to Interference Ratio) is a measure of signal quality that is similar to EVM. A measured signal can be modeled as the sum of an ideal signal and an error signal. MER represents the ratio of the ideal signal's power and amplitude to the error signal's power and amplitude. The result is usually expressed in dB.

Although the Agilent E7495A/B base station test sets do not display the MER (or Carrier to Interference Ratio) results, they can be calculated from the EVM result using the following equation:

Modulation Error Ratio or Carrier to Interference Ratio = $-20 * \log(\text{EVM}/100)$ dB

Example: If you measure a signal and find its EVM to be 2.56%, the calculation to find the MER or C/I is as follows:

MER (or C/I) = $-20 * \log(\text{EVM}/100)$ dB

= $-20 * \log(2.56/100)$ dB

= $-20 * \log 0.0256$ dB

= $-20 * -1.59176$ dB

so EVM of 2.56% is equivalent to MER (or C/I) = 31.84 dB

[“Making an Average Power Measurement” on page 380](#)

[“Making a Basic Average Power Measurement” on page 381](#)

[“Setting Power Meter Resolution” on page 384](#)

[“Setting the Power Meter’s High and Low End-Points” on page 385](#)

[“Setting the Power Meter’s Upper and Lower Limits” on page 386](#)

Making an Average Power Measurement

Average power measurements provide a key metric in transmitter performance. Transmit power must be set accurately to achieve optimal coverage in wireless networks. If transmit power is set too high due to inaccurate power measurements, undesired interference can occur. If transmit power is set too low, coverage gaps or holes may occur. Either case affects system capacity and translates into decreased revenue for service providers.

Average power can be measured while the base station is active for the channel of interest. All other channels should be inactive. Average power is a broadband measurement, so if there are other signals present it will also measure their power contributions.

NOTE

The test set supports the Agilent 8482A, 8481A, and N8481A/N8482A with Option CFT power sensors.

CAUTION

The maximum power for the RF In (Port 1) and RF Out/SWR (Port 2) ports is +20 dBm (100 mW). When using the 8481A/8482A or N8481A/N8482A with Option CFT Power Sensors, the maximum input power applied to the Power Sensor is +24 dBm (300 mW). When using the 8481D Power Sensor, the maximum input power is +20 dBm (100 mW). When directly coupled to a base station (BTS) or Access Network (AN), the test set can be damaged by excessive power applied to any of these three ports.

To prevent damage in most situations when you directly couple the test set to a base station, use the high power attenuator between the test set and the BTS.

NOTE

If you suspect other signals may be present, it is recommended that you turn off all the other channels and measure average power on the signal of interest alone. Another option is to measure channel power (which is inherently less accurate), but filters out all other channels (signals). You can measure channel power for CDMA using the CDMA Analyzer or CDMA Over Air tool. For other modulation formats, use their respective analyzers (that is, GSM, 1xEV-DO, or W-CDMA) or measure channel power using either the spectrum analyzer or the Channel Scanner tool.

NOTE

If you have not done so, measure the loss of the high power attenuator by using the Insertion Loss measurement. Refer to [“Two Port Insertion Loss” on page 123](#).

NOTE

Connect the Power Meter as close as possible to the power amplifier/duplexer output. Do not use a coupled port. The levels of the sensors do not function well at the levels provided by a coupled port.

Making a Basic Average Power Measurement

To make an average power measurement, you connect the power sensor and cable, zero and calibrate the meter, and then take a reading.

When should you zero the Power Meter?

- Every time you use the Power Meter.
- When a 5 degree C. change in temperature occurs.
- Whenever you change the power sensor.
- Every 24 hours.
- Before measuring low level signals—for example, 10 dB above the lowest specified power for your power sensor.

When should you calibrate the Power Meter? Every time you cycle the power on and off.

To Make a Basic Average Power Measurement:


Step	Notes
1 Mode	
2 [Power Meter]	
3 [Zero]	Follow the Zeroing Wizard, which displays instructions on the screen.
4 [Continue]	
5 [Ref CF]	
6 Enter the reference cal factor using the numeric keypad.	The reference cal factor is printed on the label of the power sensor head.
7 [%]	

Power Meter

Making an Average Power Measurement

Step	Notes
8	[Calibrate]
9	Connect the power sensor to the Power Ref 50 MHz port. The test set supports the Agilent 8482A, 8481A, and N8481A/N8482A with Option CFT power sensors.
10	[Continue]
11	[Cal Factor]
12	Enter the cal factor using the numeric keypad. A list of cal factors is printed on the label of the power sensor head. Select one that's within the operating frequency of the base station. For an example of a power sensor calibration table, see below. Using the example power sensor calibration table, if you were interested in 800 MHz, then: 800 MHz has a Cal Factor percentage of ~98.2 Note: Interpolate the Cal Factor from the frequency range provided on the power sensor. The example sensor calibration table shows that 800 MHz is between 300 to 1000 MHz. Since 300 MHz is listed at 98.5 and 1000 MHz (1 GHz) is at 98.1, 800 MHz would be ~98.2.
13	[%]
14	Connect the external attenuator.

Step	Notes
15	If you have previously stored PM loss from an insertion loss measurement, go to the next step. Or Press [PM Loss] and enter the PM loss value.
16	Connect to the base station. Connect the power sensor to the signal to be measured. The connection is typically after the output of the power amplifier or duplexer. The connection requires, in addition to the power sensor and attenuator, a 2 ft. cable and two Type-N barrel connectors.



Using the Power Meter Loss Field

Typical base stations exceed the maximum input to most power sensor heads. Therefore an attenuator (typically a 40 dB 100 W attenuator) is required. The measured value of the attenuator and connecting cables is entered into this field. This value is then used when this field is set to **On**. When this field is set to **On**, the test set will add this loss value to the true measured value indicating the displayed measured value.

Example: The base station transmits 40 dBm (10 W), the attenuator and RF cabling

Power Meter

Making an Average Power Measurement

measures 42.51 dB (measured with the 2 port insertion loss measurement prior to this test), and the PM loss is turned **On** (with the 42.51 dB loss value entered). The true measured level (using an 8481A sensor) is -2.51 dBm (the attenuator and RF cabling attenuated the signal to within the proper range for the sensor), but the displayed measured value is 40 dBm (10 W), which is correct. This also points out the importance of accurately measuring the loss of the attenuator and connecting cables.

Using the Power Ref Button to Verify the Sensor Is Working Properly

With the sensor head connected to the Power Ref 50 MHz RF Port and selecting Power Ref to **On**, you can verify that the sensor is working correctly. In this configuration, the power meter should indicate approximately 0 dBm (1 mW) as it reads the 50 MHz, 0 dBm RF signal.

Example of a Sensor Calibration Table (Agilent 8482A)

MHz	CF%
.1000	97.3
.3000	99.0
1.0	99.0
3.0	99.0
10.0	99.5
30.0	99.1
100	98.8
300	98.5
1000	98.1
2000	97.4
3000	98.1
4000	90.5

Setting Power Meter Resolution

You can choose from four levels of Power Meter resolution. Higher resolutions provide more accuracy but slow the measurement speed.

Step	Notes
1	[Mode]
2	[Power Meter]
3	[Setup]
4	On [Resolution] select 1, 2, 3, or 4. [1] = 1 [2] = 0.1 [3] = 0.01 [4] = 0.001

Setting the Power Meter’s High and Low End-Points

Changing the high and low end points changes the scale resolution, making it easier to view small changes in power. This does not change the range of the sensor.

Step	Notes
1	[Mode]
2	[Power Meter]
3	[Setup]
4	[Low End]
5	Enter the minimum value you want using the numeric keypad.
6	[dBm]
7	[Hi End]
8	Enter the maximum scale value you want using the numeric keypad.


Power Meter

Making an Average Power Measurement

Step	Notes
9	[dBm]

Setting the Power Meter's Upper and Lower Limits

You can configure the Power Meter to detect when a measurement has failed predefined upper and lower limits.



Step	Notes
1	[Mode]
2	[Power Meter]
3	[Setup]
4	On [Limit] select On . Each time you press this softkey, the selected option changes.
5	[Low Limit]
6	Enter the low limit using the numeric keypad.

Step	Notes
7	[dBm]
8	[Hi Limit]
9	Enter the high limit using the numeric keypad.
10	[dBm]

- “Measuring Return Loss” on page 390
- “Calibration - Minimizing your Workload” on page 390
- “Performing (and Calibrating) a Basic Return Loss Measurement” on page 391
- “Clearing Calibration” on page 394
- “Isolating a Return Loss Signal Using a Single Sweep” on page 395
- “Setting Return Loss Interference Rejection” on page 395
- “Setting Average, Sweep, and Restart” on page 396
- “Adding a Marker” on page 398
- “Displaying Location Information Using GPS” on page 399
- “Setting the Pass/Fail Limits” on page 400

Measuring Return Loss

Return loss is a measure of reflection characteristics. One way you can use the return loss measurement is to detect problems in the antenna feedline system and the antenna itself. A portion of the incident power will be reflected back to the source from each transmission line fault as well as the antenna. The ratio of the reflected voltages to the incident voltage is called the reflection coefficient. The reflection coefficient is a complex number, meaning it has both magnitude and phase information. In S-parameter terms, Return Loss is referred to as an S_{11} measurement.

NOTE

Test signals can cause interference. When testing cables attached to antennas, test signals are radiated. Verify that the signal used for the test cannot cause interference to another antenna.

Calibration - Minimizing your Workload

The **Return Loss** calibration is the same calibration as performed for the **One Port Insertion Loss** and **Distance to Fault** (when it is performed with Frequency Range set to manual) measurements. If you have already calibrated for any of these three measurements, the calibration will apply to the other two measurements and “Calibrated” (together with the frequency range over which the calibration was performed) will be displayed on top left of the screen for all three if the Start and the Stop frequencies are set within the calibrated frequency range.

The **Distance to Fault** calibration (*when it is performed with Frequency Range set to Auto*) is only valid for other *Distance to Fault* measurements that are also performed with *Frequency Range set to Auto*, and then only if the Start and the Stop Frequencies fall within the previously calibrated frequency range.

If you have not previously performed a calibration, the word “Uncalibrated” appears at the top left of the measurement screen.

It is important that you keep the calibration frequency range as close as possible to the actual sweep frequencies you intend using for the measurement or measurements. Calibrating over a large frequency range (for example, 1 GHz) when you only intend measuring over a much smaller range (a few kHz, for example) will reduce your measurement accuracy.

If you plan to perform a combination of **One-Port Insertion Loss** measurement, **Return Loss** measurement, and **Distance to Fault** measurements *using a frequency*

range that you will set manually, you can perform one calibration for all three measurements as long as you calibrate over a frequency range that incorporates all three of your measurements, and as long as your cables do not change. For this reason, if you are doing Distance to Fault measurements (*using a frequency range that you have set manually*) as well as any type of Insertion Loss measurement, Agilent recommends that you select your cable type before performing calibrations. Press [Mode], [Antenna/Cable], [Distance to Fault], [Cable Type] to set the cable type.

The calibration remains valid until you do any one of the following:

- set the Distance to Fault frequency range to **Auto**. Note that the calibration will become valid again as soon as you switch from **Auto** back to **Manual** Frequency Range.
- power off the test set
- change the start frequency to a new value that lies below the start frequency of your previous calibration
- change the stop frequency to a new value that lies above the stop frequency of your previous calibration
- change any of the jumper leads that you used for the calibration
- change any of the attenuators that you used for the calibration
- change the type of cable specified under the [Cable Type] menu key.

Performing (and Calibrating) a Basic Return Loss Measurement

Select the desired frequency range and calibrate the test set (using calibrated Open, Short, and Load connectors) for a return loss measurement.


Step	Notes
1 Mode	
2 [Antenna/Cable]	
3 [Return Loss]	The return loss measurement takes a few seconds to load.
4 [Start Freq]	

Return Loss

Measuring Return Loss

Step	Notes
5	Enter the start frequency using the numeric keypad.
6	[Hz], [kHz], [MHz], or [GHz]
7	[Stop Freq]
8	Enter the stop frequency using the keypad. The stop frequency should be larger than the start frequency.
9	[Hz], [kHz], [MHz], or [GHz]
10	Check whether your analyzer has already been calibrated over the frequency range that you wish to measure. If it is already calibrated over the correct frequency range, you can omit the next step (Step 11) and go straight to Step 12. • power off the test set • change the start frequency to a new value that lies below the start frequency of your previous calibration • change the stop frequency to a new value that lies above the stop frequency of your previous calibration • change any of the jumper leads that you used for the calibration • change any of the attenuators that you used for the calibration • change the type of cable specified under the [Cable Type] menu key in the Distance to Fault measurement. For more information, see “Calibration - Minimizing your Workload” on page 390.

Step	Notes
11	If your analyzer is uncalibrated, or has been calibrated over an unsuitable frequency, press [Calibrate]
12	Connect the antenna feedline and antenna.



Return Loss

Return Loss

Measuring Return Loss

Step	Notes
13 [Level]	Below the Return Loss display is a table displaying the Frequency, the Return Loss, and the Standing Wave Ratio (SWR) of the best and worst return losses. These values may be changing rapidly. To isolate a signal, use a single sweep, or apply averaging to the trace data. If the Return Loss trace is not visible, you can change the reference level, or use Autoscale to have the test set select a reference level for you. • To choose Autoscale, press [Autoscale]. • To set the reference level manually, press [Ref Level], enter a value using the numeric keypad, then press [dB].

NOTE

If the Return Loss measurement looks suspect (less than 5 dB), you may want to perform a Distance to Fault measurement to determine if a noticeable fault exists and where it may be located. For more information see [“Distance to Fault” on page 277](#).

Clearing Calibration

Clear Calibration deletes the current calibration data, enabling you to re-calibrate the instrument for the same frequency range, or for a new frequency range.

To Clear the Measurement Calibration Data:

Step	Notes
1 [Setup]	
2 [Clear Calibration]	When you clear the calibration, you will also clear the calibration for both the One-Port Insertion Loss measurement and for the Distance to Fault Manual Range measurement as all three measurements share the same calibration data.

Isolating a Return Loss Signal Using a Single Sweep

Step	Notes
1 [Average/Sweep]	
2 [Single]	Activate the single sweep. Press [Continuous] if you want to start multiple sweeps.

Setting Return Loss Interference Rejection

Other signals can interfere with return loss measurements. When making a return loss measurement in the presence of known or suspected interference, you can minimize the effect of the interference on the measurement by activating interference rejection in the test set.

NOTE	Use of interference rejection will increase the measurement time. Interference rejection should be used if a known interfering signal exists or if the Return Loss measurement displays suspicious characteristics such as a spike or rapid movements in the noise floor.

Step	Notes
1 [Setup]	
2 On [Interference Rejection] select On .	Each time you press this softkey, the selected option changes.

Setting Average, Sweep, and Restart

Setting the Sweep

You can select either continuous or single sweep. Continuous sweep provides repeated, ongoing measurements. Single sweep performs a single measurement that is repeated only when you push the Single button.

To set sweep:

Step	Notes
1 [Average/Sweep]	
2 [Continuous] or [Single]	Press the menu key to select the sweep mode you require.

Setting Averaging

You can choose to have averaging on or off and set the number of averages you want to take. Averaging only applies to the data, not the trace. You can select from the following types of averaging:

- **Off:** Disables averaging.
- **Running Average:** Computes the new result as the weighted sum of the last result and the new measurement. The last result is weighted by $(n - 1)/n$. The new result is weighted by $1/n$. Each new measurement produces a new result.
- **Max Hold:** Is not an average, but on a point by point basis, displays the maximum amplitude for the given frequency or channel since Max Hold was turned on. It is updated when a new maximum occurs.
- **Group Average:** Makes the requested number of measurements, averages the measurement data, and displays the average as a single result trace. Measurement time will vary based on the requested number of averages and can take minutes for very large number of averages.
- **Group Max Average:** Makes the requested number of measurements before returning a single trace result. This trace is the maximum value seen at each trace point over the requested number of averages (measurements).

To set averaging:

Step	Notes
1	Set the number of averages. a. [Average] b. Enter the number of averages using the numeric keypad. c. [Enter]
2	Select the type of averaging you want to apply. a. [Average/Sweep] b. [Averaging] c. [Off], [Running Average], [Max Hold], [Group Average], or [Group Max Average]

NOTE

These two steps can be performed in any order. However, if you turn averaging on and a large number of averages has previously been set, there may be a delay before you can change number of averages.

Setting Restart

When you have averaging turned **On** and you are in **Continuous** Sweep mode, you can restart the averaging by pressing the Restart menu key. The Restart key has no effect if you are in **Single** sweep mode.

To restart averaging:

Step	Notes
1	[Average/Sweep]
2	[Restart] This key is unavailable or has no effect when Sweep is set to Single . To restart a Single Sweep measurement, press [Single].

Adding a Marker

Markers can be used on traces to help you visually track up to four signals. Each marker has the following settings:

- **Type:** Provides three options, including:
 - **Off**
 - **Normal**, which places a diamond-shaped, colored marker, along with a number, 1-4, on the trace.
 - **Delta**, is associated with a normal marker. Therefore, a normal marker must exist prior to creating the delta marker. The delta marker displays the difference between the normal marker position and the delta marker position. Only one delta marker can be associated with a given normal marker. The normal marker must be active when Delta is selected.
- **Marker to Peak:** Places the active marker on the current greatest value of the trace.
- **Marker to Next Peak:** Places the active marker on the current second greatest value of the trace.
- **Center Freq to Marker:** Scrolls to locate the current marker in the center of the trace.
- **Ref Level to Marker:** Scrolls the trace to place the marker at the top of the screen. To reset the reference level, choose [Level/Location] [Autoscale].

To Add a Marker to a Trace:

Step	Notes
1 [Marker]	
2 [Marker]	Each time you press the [Marker] key, you will step to the next marker in the sequence 1 - 2 - 3 - 4 - 1 - 2, and so on.
3 [1], [2], [3], or [4]	
4 [Type]	
5 [Off], [Normal], or [Delta]	

Step	Notes
6 Locate the marker relative to the trace: • [Marker to Peak] • [Marker to Next Peak] [Marker to Next Min]	This feature is available for both normal markers and for delta markers.

Displaying Location Information Using GPS

If you are making a Return Loss measurement, you may use GPS Location data to verify your location. For additional information on the GPS Data function, refer to “Displaying GPS Location Data” on page 462.

To Display GPS Location Information:

Step	Notes
1 [Level/Location]	
2 On [Show GPS Location] select On .	Displays GPS satellite location information. Uses the internal GPS to capture the location of a measurement. The GPS information can be used to return to the same location. The Time Ref (Freq/Chan/Time Ref mode) button must be set to Internal GPS for this function to be active. Information logged includes longitude, latitude, altitude (feet/meters), and the number of satellites tracked. Each time you press this softkey, the selected option changes.
3 Highlight [On]	Toggle to [On] to display GPS satellite location information. Toggle to [Off] to remove the location information

Return Loss

NOTE	If you prefer to have an electronic copy of the location information, see “Saving Data” on page 469.

Setting the Pass/Fail Limits

The measurement limits setting enables you to alter the value of the upper limit. Limits are set in dB and are relative. The setting you choose defines the location of the limit line displayed on the screen. The setting affect the metrics color display: red represents fail, green represents pass.

To Set the Measurement Limit:

Step	Notes
1 [Setup]	
2 [Limits]	
3 On [Limits] select On or Off .	Enables you to toggle the measurement limits function On (active) and Off (inactive). • If set to On, a limit line is displayed on the screen. The “Best” Return Loss value must equal or exceed the limit line to generate a Pass Indication (P). If the “Best” Return Loss value does exceed the limit line, a Fail indication (F) will be displayed. • If set to Off, neither a limit line is displayed nor is a pass fail indicator seen in the metrics display portion of the display.
4 Set the limit.	Maximum limit: Ref Level (top of display)
a. [RTN Loss Limit]	Minimum limit: bottom of display
b. Enter the number on the numeric keypad.	
c. [dB]	

[“Using the Signal Generator” on page 402](#)

[“Performing a Basic Signal Generator Measurement” on page 404](#)

[“Minimum and Maximum Power levels for Generated Signals” on page 403](#)

[“Using the RF OUT Loss field” on page 410](#)

[“Persistent Signal Generator” on page 411](#)

NOTE

The information here applies to the use of the signal generator when accessed from the Spectrum Analyzer/Tools menu. For information on the use of the [Sig Gen] menu under a measurement [Setup] key menu, refer to the specific measurement chapter or measurement help topic.

Using the Signal Generator

The Signal Generator is used to check the performance of base station receivers. It supports both Received Signal Strength Indicator (**RSSI**) and CDMA Frame Error Rate (**FER**) measurements. The Signal Generator provides multiple forward and reverse-link modulation types. For a complete list of supported modulation types, press the [Modulation] menu key after you begin the measurement.

CAUTION

The maximum power for the RF In (Port 1) and RF Out/SWR (Port 2) ports is +20 dBm (100 mW). When using the 8481A/8482A or N8481A/N8482A with Option CFT Power Sensors, the maximum input power applied to the Power Sensor is +24 dBm (300 mW). When using the 8481D Power Sensor, the maximum input power is +20 dBm (100 mW). When directly coupled to a base station (BTS) or Access Network (AN), the test set can be damaged by excessive power applied to any of these three ports.

To prevent damage in most situations when you directly couple the test set to a base station, use the high power attenuator between the test set and the BTS.

NOTE

The lowest power levels the signal generator can reach for different signal formats are shown in [“Minimum and Maximum Power levels for Generated Signals” on page 403](#).

In order to get a lower level, you must use an external attenuator. You can compensate for the attenuator using RF Out Loss.

NOTE

To properly test Bit Error Rate (**BER**) through the Receiver path on an iDEN system, the test signal needs to be injected through the system Band Pass Filter or an external Band Pass Filter. The system Band Pass Filter is usually integrated in the LNA or the Duplexer, or both.

NOTE

It usually takes around 5 to 10 seconds for your chosen signal to be generated, but some signals (for example, an iDEN signal) can take up to 45 seconds. A progress indicator shows you the percentage of the signal generation that has been completed.

Minimum and Maximum Power levels for Generated Signals

	E7495A		E7495B	
Signal	Max. Power	Min. Power	Max. Power	Min. Power
CW (Firmware A.06.10 or older)	-23 dBm	-90 dBm	-23 dBm	-90 dBm
CW (Firmware A.06.20 or later ^a)	-23 dBm	-90 dBm	-5 dBm	-90 dBm
CDMA Forward Link Pilot Only No Filter	-47 dBm	-95 dBm	-28 dBm	-95 dBm
CDMA Forward Link Pilot Only Filtered	-47 dBm	-95 dBm	-28 dBm	-95 dBm
CDMA IS-95 Rev Link RC1 9.6 Kbps Zero Data Traffic	-47 dBm	-95 dBm	-28 dBm	-95 dBm
CDMA IS-95 Rev Link Zero Data Access	-47 dBm	-95 dBm	-28 dBm	-95 dBm
CDMA IS-95 Rev Link RC1 9.6Kbps Random Data Traffic	-47 dBm	-95 dBm	-28 dBm	-95 dBm
CDMA IS-95 Rev Link RC2 14.4Kbps Zero Data Traffic Channel	-47 dBm	-95 dBm	-28 dBm	-95 dBm
R-FCH RC3 Zero Data Fundamental	-47 dBm	-95 dBm	-28 dBm	-95 dBm
R-FCH RC3 Random Data Fundamental	-47 dBm	-95 dBm	-28 dBm	-95 dBm

Signal Generator

Using the Signal Generator

	E7495A		E7495B	
Signal	Max. Power	Min. Power	Max. Power	Min. Power
1xEV-DO Rev Link 9.6Kb 15PN Data (ARB) (Firmware A.04.00 to A.06.00)	–48.5 dBm	–96.5 dBm	–29.5 dBm	–96.5 dBm
1xEV-DO Rev Link 9.6Kb 15PN Data (ARB) (Firmware A.06.10 or above)	–49.3 dBm	–97.3 dBm	–30.3 dBm	–97.3 dBm
1xEV-DO Rev A Rev Link 9.6Kbps 15PN Data (ARB)	–50.5 dBm	–98.5 dBm	–31.5 dBm	–98.5 dBm
1xEV-DO Rev A Rev Link 460.8Kbps 15PN Data (ARB)	–51.7 dBm	–99.7 dBm	–32.7 dBm	–99.7 dBm
iDEN 1/6th Inbound (ARB)	–52.1 dBm	–100.1 dBm	–33.1 dBm	–100.1 dBm

- a. Power accuracy is reduced at CW power levels greater than –23 dBm, that is, with power levels between –23 dBm and –5 dBm. The message, “Source output unlevelled > –23 dBm” is displayed to warn you of this.

Performing a Basic Signal Generator Measurement

Step	Notes
1	Mode
2	[Spectrum Analyzer/Tools]
3	[Signal Generator]
4	[Chan Std]

Step	Notes
5	Select the channel standard from the list using the up and down arrow buttons.
6	[Select]
7	On [Units] select Chan. Each time you press this menu key, the analyzer switches between Channel (Chan) and Frequency (Freq). The Units settings are coupled across multiple tools.
8	[Fr/Time Ref] Complex signals such as cdma and 1xEV-DO require accurate time and frequency references before they can be reliably generated or demodulated.
9	[GPS] or [External Even Sec] Only GPS and External Even Second provide the timing information necessary to generate an accurately modulated signal. Select GPS if you are receiving GPS location information (System , [Fr/Time Ref Location], [Show GPS Location] set to On). Otherwise, select External Even Second, and connect your external even second reference signal to the Even Second Sync In port on your test set. It is worth noting that the signal may disappear momentarily when you switch between different time references because the signal needs to be realigned with the system time. If you are not needing a time aligned signal (for example, you are simply generating a carrier wave), you do not need to use either GPS or External Even Second Clock as your time reference. If you are using a frequency only reference, the signal will be modulated with the same accuracy as when using a time reference. The difference is that it will not be time aligned to the system time during playback

Signal Generator

Using the Signal Generator

Step	Notes
10 [Select]	
11 [Channel]	
12 Enter the channel number using the numeric keypad.	When the channel is set, it is set across all the test set tools, so as you switch between tools, the channel is preset.
13 [Rev] or [Up]	Always choose the reverse or the uplink channel when performing a receiver sensitivity test measurement. The terms “Reverse link” and “Uplink” have the same meaning. GSM standards use the term “Up” whereas cdma standards use the term “Reverse”.
14 [Modulation] If the key is grayed out, go to step 16. Or If the key is active, go to the next step.	If the [Modulation] menu key is grayed out, your test set does not include the <i>Option 510 - CW & Complex Modulation Signal Generator</i> . You have only CW source.


Step	Notes
15 [Format]	You will now see a list of all the available signal formats: • CW (No modulation) - an unmodulated carrier wave • CDMA Forward Link (Pilot only) without Equalization Filter • CDMA Forward Link (Pilot only) with Equalization Filter • CDMA IS-95 Reverse Link - RC1 9.6Kbps Zero Data Traffic Channel • CDMA IS-95 Reverse Link - Zero Data Access Channel • CDMA IS-95 Reverse Link - RC1 9.6Kbps Random Data Traffic Channel • CDMA IS-95 Reverse Link - RC2 14.4Kbps Zero Data Traffic Channel • R-FCH RC3 Zero Data Fundamental Channel • R-FCH RC3 Random Data Fundamental Channel • iDEN Inbound 1/6 Duty Cycle 16QAM (ARB) • 1xEV-DO Reverse Link 9.6Kb 15PN data (ARB) - parameters such as PN Offset are fixed in this file and cannot be altered. Be aware that it can take up to 30 seconds for a 1xEV-DO signal to start being generated.^a • 1xEV-DO Rev A Reverse Link 9.6Kbps 15PN data (ARB)^a • 1xEV-DO Rev A Reverse Link 460.8Kbps 15PN data (ARB).^a

Signal Generator

Using the Signal Generator

Step	Notes
16	Select the signal format from the list using the up and down arrow keys. a. If you have selected a CDMA Forward Link modulation type, select PN Offset. For other modulation types, you do not need to select PN Offset. b. If you have selected cdma2000 modulation with fundamental channels, you also need to press [R-FCH Pwr].
	The PN Offset is a “short code” sequence that provides a unique identifier for each sector of each cell site. The PN Offsets are applied to the I and Q signals before modulation. PN Offsets are offset in time by 52.08 μs and they repeat every 26.666 ms. This yields 512 unique short code sequences (0-511). The mobile phone needs the PN Offset to decode information in the Sync and Paging channels, which are transmitted by the base station. R-FCH Pwr specifies the Reverse Fundamental Channel Power, and applies only to cdma-2000 RC3 channels. It does not apply to cdma IS-95 RC1 and cdma IS-95 RC2 reverse link channels.
17	Enable the RF output, set the RF output amplitude, and set the step key increments. a. [Amplitude] b. [RF] Select On. c. [Amplitude] d. Enter the amplitude value using the numeric keypad. e. [dBm] f. [Ampl Step] g. Enter the step value using the numeric keypad. h. [dB]
	You may also enter a new value for amplitude by turning the rotary knob until the desired value is displayed or by using the up and down arrow keys.

Step	Notes
18	If you have previously stored RF Out Loss from an insertion loss measurement, go to the next step. Or Press [RF OUT Loss] to select On and enter the RF Out Loss value.
19	Connect to the base station.




Low level non duplex connection

Signal Generator

Using the Signal Generator

Step	Notes



High level non duplex connection

20	On [RF] select On .	Each time you press this softkey, the selected option changes.

a. The characteristics of any 1xEV-DO signal generated are:

RRI Active: RRI Bits: 1

DRC Channel Relative Gain: +3 dB

ACK Channel relative Gain: 0 dB

Data Channel Relative Gain: +3.75 dB

Data Channel: Active

Data Channel Data Rate (low Speed Signal): 9.6 kbps

Data Channel Data Rate (High Speed Signal: 460.8 kbps at payload size
12288 bits

Data Channel bit stream: PN15

I Mask: 3FF80000000

Q Mask: 3FF00000001

Filter Type: IS 95 Std

Using the RF OUT Loss field

The RF OUT Loss field is used when it is necessary to test the receiver sensitivity of a typical base station. The test set's source will typically go down to -90 dBm. In order to reach -113 dBm for sensitivity testing, you must use an external attenuator. The measured value of the attenuator and connecting cables are entered into this field. This value is then used when this field is set to **On**. When this field is set to **On**, the test set will set the RF generator level to the correct level offset by the

external attenuator/cabling. When you set the RF Generator to -113 dBm (with the RF OUT Loss field turned **On** and the external attenuator/cabling loss value entered) the output at the end of the RF test cabling is -113 dBm.

Example: If you want to set the signal generator to -113 dBm, the attenuator and RF cabling measures 42.51 dB (measured with the 2 port insertion loss measurement screen prior to this test), the RF OUT Loss field is turned **On** (with the 42.51 dB loss value entered). The actual RF output of the signal generator is -70.49 dBm, the attenuator and RF cabling attenuated the signal to the desired level; so the RF signal at the end of the test cable/attenuator is -113 dBm. This also points out the importance of accurately measuring the loss of the attenuator and connecting cables.

Persistent Signal Generator

The signal generator function can be used simultaneously with other measurement functions of the test set. This allows you to use the test set as both the source and the measurement device when making your measurements. To do this, setup the signal generator as described in “Performing a Basic Signal Generator Measurement” on page 404.

Then proceed as described below.

Step	Notes
1 Mode	
2 [Spectrum Analyzer/Tools]	
3 [Signal Generator]	
4 [Freq/Chan/Time Ref]	
5 On [Persist Sig Gen] select Yes .	Each time you press this softkey, the selected option changes. Yes turns the persistent signal generator function On and No turns the function Off . When the persistent signal generator is turned On , an icon (☺) appears in the lower-right corner of the display.
6 Mode	

Signal Generator

Using the Signal Generator

Step	Notes
7	Select the desired measurement mode and proceed with your measurements
17 [Amplitude]	Changes the RF output power. Amplitude becomes the active function and the current value is shown in the active entry area of the display. To enter a new value for amplitude, turn the rotary knob until the desired value is displayed, use the up and down arrow keys, or enter the value using the numeric keypad. Then press [dBm].

- “Using the Spectrum Analyzer” on page 414
- “Performing a Basic Spectrum Analyzer Measurement” on page 415
- “Setting the Range Control” on page 418
- “Setting the Analyzer Input Gain” on page 419
- “Setting the Analyzer Detector” on page 420
- “Setting Up the Signal Generator” on page 421
- “Setting Average, Sweep, and Restart” on page 423
- “Changing the Resolution Bandwidth” on page 425
- “Adding or Removing a Marker” on page 426
- “Setting the Pass/Fail Limits” on page 428
- “Spectrogram Display” on page 435
- “Performing a Spectrogram Measurement” on page 436
- “Using the Interference ID Measurement” on page 439
- “Performing a Basic Interference ID Measurement” on page 439
- “Using the Occupied BW Measurement” on page 444
- “Performing a Basic Occupied BW Measurement” on page 445
- “Using the Spectrum Emission Mask Measurement” on page 450
- “CDMA and 1xEV-DO Channel Standards and Emission Limits” on page 452
- “W-CDMA UTRA Channel Frequencies and Emission Limits” on page 453
- “Performing a Basic Spectrum Emissions Mask Measurement” on page 454

Spectrum Analyzer

Using the Spectrum Analyzer

Using the Spectrum Analyzer

Use the Spectrum Analyzer in direct connect mode to:

- Verify that your transmitted signal does not interfere (produce spurs and harmonics) with other signals.
- Verify spectral integrity—look at a signal to see if it meets expectations, look for unwanted signals.

Use the Spectrum Analyzer in Over Air mode to:

- Look for interference generated by other transmitters that can interfere with your transmit band.

CAUTION

The maximum power for the RF In (Port 1) and RF Out/SWR (Port 2) ports is +20 dBm (100 mW). When using the 8481A/8482A or N8481A/N8482A with Option CFT Power Sensors, the maximum input power applied to the Power Sensor is +24 dBm (300 mW). When using the 8481D Power Sensor, the maximum input power is +20 dBm (100 mW). When directly coupled to a base station (BTS) or Access Network (AN), the test set can be damaged by excessive power applied to any of these three ports.

To prevent damage in most situations when you directly couple the test set to a base station, use the high power attenuator between the test set and the BTS.

NOTE

The RF In loss can be added manually, or automatically by performing an insertion loss measurement. For measurement instructions refer to [“Performing \(and Calibrating\) a Basic One Port Insertion Loss measurement”](#) on page 47 or [“Normalizing and Performing a Basic Two Port Insertion Loss Measurement”](#) on page 125.


Performing a Basic Spectrum Analyzer Measurement

Step	Notes
1 Select Spectrum Analyzer. a. Mode b. [Spectrum Analyzer/Tools] c. [Spectrum Analyzer]	
2 Enter the channel standard. a. [Freq/Chan] b. [Chan Std] c. Select the standard using the up and down arrow buttons. d. [Select] e. On [Units] select Chan .	Each time you press the [Units] menu key, the selected option changes between Freq (frequency) and Chan (channel number).
3 Enter the channel number. a. [Channel] b. Enter the channel number using the numeric keypad. c. Select [Fwd] or [Rev].	
4 Set the span. a. [Span] b. Enter the frequency using the numeric keypad. c. [Hz], [kHz], [MHz], or [GHz]	
5 Connect to the base station.	


Spectrum Analyzer

Using the Spectrum Analyzer

Step	Notes
6	




Out of service connection



In service connection

Step	Notes
7	For an over the air measurement, connect an antenna and an external filter to the RF input.
	The external filter is necessary to eliminate out-of-band signals that would otherwise reduce the dynamic range of measurements in the band of interest. The effect of the out-of-band signals is to raise the noise floor, possibly hiding some or all of the signal of interest.

8



Over the air measurement connection

- 9 Set the level to Autoscale.
 - a. [Level]
 - b. [Autoscale]

Spectrum Analyzer

Using the Spectrum Analyzer

Step	Notes
10 (Recommended) Display a marker and set it to peak.	The marker value appears in the upper right.
a. [Marker]	Pressing [Marker] on the left menu displays the Marker menu on the right. Pressing Marker on the right menu selects your marker number. Marker numbers cycle from 1 to 2 to 3 to 4, and back again, each time you press this key.
b. [Marker]	
c. On [Type] select Normal .	
d. [Marker to Peak]	

Setting the Range Control

The autoranging feature, which is built into the test set, helps ensure accurate measurements by changing front-end amplifier gain as needed when a strong signal threatens to overload the test set. When this occurs, the noise floor rises (as gain is decreased), then falls again when the strong signal stops. You should leave the range control in autorange for general use to ensure the accuracy of the measurement results.

If you prefer to use a fixed noise floor, you can disable autoranging in two ways using the [Setup], [Range Ctrl] function within Spectrum Analyzer:

- On [Range Ctrl] select **Hold** to fix the front-end amplifier gain at the current level. You may use [Range Up] or [Range Down] to change the noise floor. A word of caution: when you use the **Hold** setting, a subsequent strong signal—even outside the measurement range—may cause an inaccurate reading due to overloading the front-end of the test set. While in **Hold**, you can adjust the gain of the front-end amplifier with the **Range Up** and **Range Down** menu keys. The **Hold** setting cannot be saved. Leaving the measurement or going into the sleep mode will reset the Range Ctrl to **Auto**.
- On [Range Ctrl] select **Max** to fix the front-end amplifier gain at the current level until a strong signal comes in. When a strong signal is received, the front-end amplifier gain will be reduced to maintain accuracy, but it will not return to its lower level after the strong signal stops.

If the noise floor is too high to measure the signal of interest, reducing the resolution bandwidth will reduce the noise floor, at the expense of the measurement update

rate.

Using the Range Control Function:

Step	Notes
1 Set the Range Ctrl to Hold. a. [Setup] b. [Range Ctrl] c. On [Range Ctrl] select [Hold] d. Select [Range Up] or [Range Down]	 Each time you press this softkey, the selected option changes. Use the Range Up or Range Down menu keys to adjust the gain to ensure the accuracy of the measurement results.
2 Set the Range Ctrl to Max. a. [Setup] b. [Range Ctrl] c. On [Range Ctrl] select [Max]	 For more information on the autoranging feature, refer to the note above.

Setting the Analyzer Input Gain

Normally the E7495A/B is set to add the most gain in the receive path to boost low-level signals. If the signal is high, there is no reason to add gain. When you're measuring a strong signal, select low sensitivity to reduce the gain in the receive path and lower the noise floor. For a low level signal, select high.

Step	Notes
1 [Setup]	

Spectrum Analyzer

Using the Spectrum Analyzer

Step	Notes
2 [Sensitivity]	
3 Low or High	

NOTE

The Sensitivity setting is coupled to the Noise Correction setting. Changing the Sensitivity setting from **Low** to **High** will cause the Noise Correction setting to change from **On** to **Off**. Conversely, if the Noise Correction setting is changed from **Off** to **On**, the Sensitivity setting is changed from **High** to **Low**.

Setting the Analyzer Detector

You can set a detector mode for spectrum measurements.

Positive peak detection displays the highest sample level measured during each sampling period.

Sample detection displays the peak of CW-like signals and maximums and minimums of noise-like signals.

Negative peak detection displays the lowest sample level measured during each sampling period.

Average detection displays the average power in each frequency measured across the spectrum.

Step	Notes
1 [Setup]	
2 [Detector]	
3 [Peak], [Sample], [Negative Peak], or [Average]	

Setting Up the Signal Generator

[“Setting the Range Control” on page 418](#)

You can set up the signal generator while in the Spectrum Analyzer mode from the Setup menu. For more detailed information on the signal generator setup and operation, refer to [“Using the Signal Generator” on page 402](#).

CAUTION

The maximum power for the RF In (Port 1) and RF Out/SWR (Port 2) ports is +20 dBm (100 mW). When using the 8481A/8482A or N8481A/N8482A with Option CFT Power Sensors, the maximum input power applied to the Power Sensor is +24 dBm (300 mW). When using the 8481D Power Sensor, the maximum input power is +20 dBm (100 mW). When directly coupled to a base station (BTS) or Access Network (AN), the test set can be damaged by excessive power applied to any of these three ports.

To prevent damage in most situations when you directly couple the test set to a base station, use the high power attenuator between the test set and the BTS.

NOTE

The lowest level the signal generator can go to is –90 dBm. In order to get a lower level, you must use an external attenuator. You can compensate for the attenuator in the RF Out Loss.

Step	Notes
1	[Setup]
2	[Sig Gen]
3	[Freq/Chan]
4	Enter the channel number or the frequency using the numeric keypad.
5	- For channel select [Rev] or [Fwd] - For frequency select [GHz], [MHz], [kHz], or [Hz],

Spectrum Analyzer

Using the Spectrum Analyzer

Step	Notes
6 [Mod Format]	
7 Select the channel standard from the list using the up and down arrow buttons.	
8 [Select]	
9 Set the RF output amplitude	You may also enter a new value for amplitude by turning the rotary knob until the desired value is displayed or using the up and down arrow keys.
a. [Amplitude]	
b. Enter the amplitude value using the numeric keypad.	
c. [dBm].	
10 If you have previously stored RF Out Loss from an insertion loss measurement, go to the next step. Or Press [RF OUT Loss] to select On and enter the RF Out Loss value.	For information on the effects of the RF Out Loss function on the amplitude, refer to “Using the RF Out Loss field” below. Each time you press this softkey, the selected option changes.
11 Connect to the base station.	
12 On [Enable Sig Gen] select On .	Each time you press this softkey, the selected option changes.

Using the RF OUT Loss field

The RF OUT Loss field is used when you need to test the receiver sensitivity of a typical base station. The test set's source will typically go down to -95 dBm, so in order to reach -113 dBm for sensitivity testing, you must use an external attenuator. The measured value of the attenuator and connecting cables are entered into this field. This value is then used when this field is set to **On**. When this field is set to **On**, the test set will set the RF generator level to the correct level offset by the external attenuator/cabling. When you set the RF Generator to -113 dBm (with the RF OUT Loss field turned **On** and the external attenuator/cabling loss value entered)

the output at the end of the RF test cabling is -113 dBm.

Example: If you want to set the signal generator to -113 dBm, the attenuator and RF cabling measures 42.51 dB (measured with the 2 port insertion loss measurement screen prior to this test), the RF OUT Loss field is turned **On** (with the 42.51 dB loss value entered). The actual RF output of the signal generator is -70.49 dBm, the attenuator and RF cabling attenuated the signal to the desired level; so the RF signal at the end of the test cable/attenuator is -113 dBm. This also points out the importance of accurately measuring the loss of the attenuator and connecting cables.

Setting Average, Sweep, and Restart

Setting the Sweep

You can select either continuous or single sweep. Continuous sweep provides repeated, ongoing measurements. Single sweep performs a single measurement that is repeated only when you push the Single button.

To set sweep:

Step	Notes
1 [Average/Sweep]	
2 [Continuous] or [Single]	Each time you press one of these menu keys, the selected option changes.

Setting Averaging

You can choose to have averaging on or off and set the number of averages you want to take. You can select from the following types of averaging:

- **Off:** Disables averaging.
- **Running:** Computes the new result as the weighted sum of the last result and the new measurement. The last result is weighted by $(n - 1)/n$. The new result is weighted by $1/n$. Each new measurement produces a new result.
- **Max Hold:** Is not an average, but on a point by point basis, displays the maximum amplitude for the given frequency or channel since Max Hold was turned on. It is updated when a new maximum occurs.
- **Group Average:** Makes the requested number of measurements, averages the measurement data, and displays the average as a single result trace.

Spectrum Analyzer

Using the Spectrum Analyzer

Measurement time will vary based on the requested number of averages and can take minutes for very large number of averages.

- **Group Max Average:** Makes the requested number of measurements before returning a single trace result. This trace is the maximum value seen at each trace point over the requested number of averages (measurements).

To set averaging:

Step	Notes
1	Set the number of averages. a. [Average] b. Enter the number of averages using the numeric keypad. c. [Enter]
2	Select the type of averaging you want to apply. a. [Average/Sweep] b. [Averaging] c. [Off], [Running Average], [Max Hold], [Group Average], or [Group Max Average]

NOTE

These two steps can be performed in any order. However, if you turn averaging on and a large number of averages has previously been set, there may be a delay before you can change number of averages.

Setting Restart

When you have averaging turned **On** and you are in **Continuous** Sweep mode, you can restart the averaging by pressing the Restart menu key. The Restart key has no effect if you are in **Single** sweep mode.

To restart averaging:

Step	Notes
1 [Average/Sweep]	
2 [Restart]	This key is unavailable or has no effect when Sweep is set to Single . To restart a Single Sweep measurement, press [Single].

Changing the Resolution Bandwidth

The default resolution bandwidth is 0.1% of the span in Auto mode. By selecting Manual, you can define a narrower bandwidth and thereby see spurious signals that you might miss in Auto mode. However, the measurement will be slower.

NOTE

The auto mode is appropriate for most measurements. When you set the Res BW to **Manual**, you must remember to change the Res BW whenever you change the span. Otherwise, the measurement may take longer than expected or will not have the expected accuracy and or resolution.

Furthermore, if you set the span greater than 1 MHz, the maximum resolution bandwidth allowed is 1% of the span. For example, if you set the span to 20 MHz, the maximum resolution bandwidth will be 200 kHz.

Step	Notes
1 [Setup]	
2 On [Res BW] select Manual .	Each time you press this softkey, the selected option changes. In Auto mode, the resolution bandwidth is coupled to the span setting, Manual mode decouples the resolution bandwidth from the span.
3 Enter the bandwidth using the numeric keypad.	
4 [Hz] or [kHz]	

Spectrum Analyzer

Using the Spectrum Analyzer

Adding or Removing a Marker

Markers can be used on traces to help you visually track up to four signals. Each marker has the following settings:

- **Type:** Provides three options, including:
 - **Off**
 - **Normal**, which places a diamond-shaped, colored marker, along with a number, 1-4, on the trace.
 - **Delta**, is associated with a normal marker. Therefore, a normal marker must exist prior to creating the delta marker. The delta marker displays the difference between the normal marker position and the delta marker position. Only one delta marker can be associated with a given normal marker. The normal marker must be active when Delta is selected.
- **Marker to Peak:** Places the active marker on the current greatest value of the trace. This key is only enabled when your currently selected marker is of type Normal or Delta.
- **Marker to Next Peak:** Places the active marker on the current next greatest value of the trace. This key is only enabled after you have performed a Marker to Peak search, and when the currently selected marker is of type Normal or Delta.
- **Center Freq to Marker:** Changes the center frequency to locate the current marker in the center of the trace.
- **Ref Level to Marker:** Scrolls the trace to place the marker at the top of the screen. To reset the reference level, choose [Level/Location] [Autoscale].

To Add a Marker to a Trace:

Step	Notes
1 [Marker]	
2 [Marker]	Press [Marker] repeatedly to select Marker 1, 2, 3, or 4.
4 [Type]	
5 [Normal] or [Delta]	

Step	Notes
6	Locate the marker relative to the trace: • [Marker to Peak] • [Marker to Next Peak]
7	Locate the trace relative to the marker: • [Center Freq to Marker] • [Ref Level to Marker]

To Remove a Marker from a Trace:

Step	Notes
1	[Marker]
2	[Marker] Press [Marker] repeatedly to select Marker 1, 2, 3, or 4.
4	[Type]
5	[Off]

Spectrum Analyzer

Using the Spectrum Analyzer

Setting the Pass/Fail Limits

The measurement limits setting allows you to alter the value of the upper and lower test limits. Center segment limits are set in dBm and are absolute limit values. The first and second segment limit values are set in dB and are limit values relative to the center segment. The settings you choose define the location of the limit lines displayed on the screen. These settings will result in a pass/fail flag being displayed above the limit line: a red triangle with a “F” is a fail, a green circle with a “P” is a pass.

You can set a variety of limit configurations to suit your needs: a single upper or lower limit, an upper and lower limit pair (see [Figure 16-2](#)), a segmented upper or lower limit, or an upper and lower segmented limit mask (see [Figure 16-1](#)). You can specify a maximum of one center segment, two lower segments, and two upper segments.

Figure 16-1

Segmented Limit Mask





Figure 16-2

Limit Lines Upper & Lower



Spectrum Analyzer

Using the Spectrum Analyzer

To Set the Measurement Upper and Lower Limits:

Step	Notes
1 [Setup]	
2 [Limits]	
3 Set the upper limit. a. On [Limits] select Upper	
4 Set the center segment limit. a. On [Segments] select Center	
5 On [Center Segment] select On or Off .	Enables you to toggle the measurement limit line segment function On (active) and Off (inactive). - If set to On, an upper limit line with a pass or fail icon above the line is displayed on the screen. This enables you to set the center segment limit value and the width of the center segment. (Center segment width (Center Span) is unavailable unless the first segment is turned on.) Any measured value that exceeds the upper limit will result in a failure indication. - If set to Off, neither limit lines nor pass fail indicators are displayed.
6 Set the center segment limit value. a. [Center Level] b. Enter the number on the numeric keypad. c. [dBm]	Maximum Upper limit: 50 dBm to –150 dBm (if a lower limit is set, the upper limit should be set higher than the lower limit)

Step	Notes
7	• If you only need an upper limit line, stop here. • If you need a lower limit line: a. On [Limits] select Lower b. Repeat steps 4, 5, and 6. • For a segmented limit line, proceed with step 8.
8	Set the first segment limit. a. On [Segments] select 1st
9	On [1st Segment] select On or Off. Enables you to toggle the measurement limit line segment function On (active) and Off (inactive). • If set to On, a left and right upper limit line segment with a pass or fail icon above each segment is displayed on the screen. This enables you to set the first segment left and right limit values and the width of the left and right first segment. (The first segment width (Span) is unavailable unless the second segment is turned on.) Any measured value that exceeds the upper limit will result in a failure indication. • If set to Off, neither limit lines nor pass fail indicators are displayed. Nor are second segment functions available.

Spectrum Analyzer

Using the Spectrum Analyzer

Step	Notes
10	Set the first segment left and right limit values. Maximum Upper limit: 50 dBm to –150 dBm (if a lower limit is set, the upper limit should be set higher than the lower limit) - On [1st Segment] select Left. [Level] - Enter the number on the numeric keypad. [dB] - On [1st Segment] select Right. - Repeat steps b, c, and d.
11	Set the center segment width value. - On [Segments] select Center [Center Span] - Enter the number on the numeric keypad. [GHz], [MHz], [kHz], or [Hz]
12	- If you only need a two segment limit line, stop here. - For a three segment limit line, proceed with step 13.
13	On [Segments] select 2nd

Step	Notes
14 On [2 nd Segment] select On or Off .	Enables you to toggle the measurement limit line segment function On (active) and Off (inactive). • If set to On, a left and right upper limit line segment with a pass or fail icon above each segment is displayed on the screen. This enables you to set the second segment left and right limit values. Any measured value that exceeds the upper limit will result in a failure indication. • If set to Off, neither limit lines nor pass fail indicators are displayed.
15 Set the second segment left and right limit values. a. On [2 nd Segment] select Left . b. [Level] c. Enter the number on the numeric keypad. d. [dB] e. On [2 nd Segment] select Right . f. Repeat steps b, c, and d.	Maximum Upper limit: 50 dBm to –150 dBm. If a Lower Limit is set, the Upper Limit should be set higher than the Lower Limit)

Spectrum Analyzer

Using the Spectrum Analyzer

Step	Notes
16	Set the first segment width value. - On [Segments] select 1st [Span] - Enter the number on the numeric keypad. [GHz], [MHz], [kHz], or [Hz]
17	Set the lower limit. - On [Limits] select Lower - Repeat steps 4 through 16 as appropriate for the number of segments you need.

Spectrogram Display

The Spectrogram view can be used with the Interference ID or the Occupied BW measurements and standard spectrum. Troubleshooting a transmitter system is often aided by examining the time evolution of the power distribution.

This view provides a history of the spectrum. You can use it to:

- locate intermittent signals.
- track signal levels over time.

You may set the following parameters for this view:

- The **Update Interval** is the interval, measured in whole seconds, between successive records displayed on the spectrogram. In other words, if you set the update interval to 5 seconds, the spectrogram display will not update until the after the first complete measurement following a gap of five seconds. Alternatively, you can set the update interval to provide the maximum data collection speed by pressing [Max Speed], or by setting the update interval to 0 (zero) seconds.

NOTE

It is not always possible for the analyzer to match the update interval you specify. It is possible, for example, to set your update interval to zero seconds (the maximum speed), and then to find that the analyzer can not update any faster than once every two seconds.

A data sample is taken every n seconds for display on the spectrogram. Increasing the update time allows data capturing over a longer period of time in the spectrogram. However, it is a sampling technique that allows intermittent events, which may occur between samplings, to be lost. Therefore, if you are searching for intermittent signals, consider using Group Max average type in conjunction with increasing the capture time (see [“Setting Average, Sweep, and Restart” on page 423](#)).

Approximate Times Taken to Display the Spectrogram

Update Interval	Time for a Full Screen Display
Max. Speed	34 seconds
1 second	3 minutes

Spectrum Analyzer

Spectrogram Display

Update Interval	Time for a Full Screen Display
2 seconds	6 minutes
4 seconds	12 minutes
30 seconds	90 minutes (1.5 hours)
60 seconds (1 minute)	180 minutes (3.0 hours)
300 seconds (5 minutes)	900 minutes (15.0 hours)
600 seconds (10 minutes)	1800 minutes (30.0 hours)

The frequency indicator is at the bottom right corner of the screen, the time reference indicator at the bottom left. For each indicator the text indicates which reference you have chosen. A green LED indicates a locked condition. A red “X” indicates an unlocked condition.

- **Frame Skip:** Allows you to set the number of frames you would like to skip when capturing data. You may set this value from skip 0 to 2147,483,647 frames. Increasing the frame skip value causes the display to redraw the spectrum every n^{th} trace and a block of lines is shown at once instead of a single line at a time. Higher frame skip values are for use with fast measurements.
- **Palette:** Allows you to set the display to full color or grayscale.

Performing a Spectrogram Measurement

Step	Notes
1 [Spectrum Analyzer]	
2 [Measurements]	
3 [Spectrogram]	


Step	Notes
4 On [Spectrogram] select On .	Each time you press this key, the spectrogram state switches between On and Off . When you set [Spectrogram] to On, [Reset Spectrogram], [Update Interval], [Frame Skip], and [Palette] become active.
5 If you need to restart the data capture press [Reset Spectrogram]	This restarts the data capture for the Codogram. You may see the screen freeze for a few seconds before the display starts plotting data again.
6 If desired set the update interval: a. [Update Interval] b. Enter the interval number using the numeric keypad. c. Select [sec] or [Max Speed].	Allows you to set the update interval to 0, 1, or more seconds. Alternatively, you may set it to automatically determine the update interval that provides the maximum data collection speed. If you need to return to the automatically determined maximum capture speed, you must press [Update Interval] followed by a numeric keypad key to access [Max Speed].
7 If desired set the number of frames you want to skip: a. [Frame Skip] b. Enter the interval number using the numeric keypad. c. Select [frames].	

Spectrum Analyzer
Spectrogram Display

Step	Notes
8	If desired set the display color:
a. [Palette]	The color/grayscale top and bottom mappings are determined by the Ref Level and Scale/Div settings. To change the mapping, go to [Level/Location] and change [Ref Level] and [Scale/Div].
b. Select [Full Color] or [Grayscale].	

Figure 16-3

Spectrogram View of a 1xEV-DO Signal



Using the Interference ID Measurement

Use the Interference ID measurement to find and identify interference signals over a designated spectrum. This measurement requires that *Option 270 - Interference Analyzer* be installed on your instrument. Interference ID provides you with a list of possible signal types for a designated signal. For example, a selected interference signal might be indicated as a possible CW or a CDMA signal. This measurement does not demodulate the signals. Therefore the list is not definitive. The list retains some history to help identify intermittent signals. The history can be reset with the [Average] [Restart] menu keys.


Performing a Basic Interference ID Measurement

Step	Notes
1 Select Spectrum Analyzer. a. Mode b. [Spectrum Analyzer/Tools] c. [Spectrum Analyzer]	
2 Enter the channel standard. a. [Chan Std] b. Select the standard using the up and down arrow buttons. c. [Select] d. On [Units] select Chan .	Each time you press the [Units] menu key, the selected option changes.
3 Enter the channel number. a. [Channel] b. Enter the channel number using the numeric keypad. c. Select [Fwd] or [Rev].	

Spectrum Analyzer

Using the Interference ID Measurement


Step	Notes
4	Set the span. [Span] - Enter the frequency using the numeric keypad. [Hz], [kHz], [MHz], or [GHz]
5	Connect to the base station.



Connect to the Antenna

Spectrum Analyzer Using the Interference ID Measurement

Step	Notes
6	For an Over The Air measurement, connect an antenna and an external filter to the RF input. The external filter is necessary to eliminate out-of-band signals that would otherwise reduce the dynamic range of measurements in the band of interest. The effect of the out-of-band signals is to raise the noise floor, possibly hiding some or all of the signal of interest. However, the external filter is optional in this set up: • If you want to limit your search to a specific band of interest, then you should use the external filter. • If you want to search beyond a specific band, then you can leave the filter off.



Over the air measurement connection

Spectrum Analyzer

Using the Interference ID Measurement

Step	Notes
7 Set the level to Autoscale.	
a. [Level]	
b. [Autoscale]	
8 Select the Interference ID Measurement.	A marker will appear on the trace at the left of the display. The Frequency and power level at the marker (Signal Pointer) is displayed in the data window below the trace display window. The type of signal that is causing the interference is also indicated.
a. [Measurements]	
b. [Interference ID]	
c. On [Interference ID] select On .	
9 You can set marker to a signal peak by:	The number displayed at the bottom of the Pointer to Peak button indicates the number of the marked peak and the total number of peaks. For example, 1/22 indicates the peak with the highest power on the display and a total of 22 peaks displayed. 2/22 would indicate the second highest peak, 3/22 the third highest, and so forth.
a. [Signal Pointer]	
b. Enter the frequency using the numeric keypad.	
c. Select [GHz], [MHz], [kHz], or [Hz].	
OR by:	
a. [Pointer to Peak]	Pointer to Peak always returns the marker to the highest peak.
b. Enter the frequency using the numeric keypad.	
c. Select [Pointer To Next Peak] to mark successively lower peaks.	

Step	Notes
10 You can set the threshold level to automatically set value or manual select a value by: a. On [Threshold] select Auto Or a. On [Threshold] select Manual b. Enter the threshold value using the numeric keypad. c. Select [dBm].	The threshold limit line is displayed on the graticule at the desired level. Ensure that the threshold value you enter is within the graticule range or the threshold limit line will be off the display. The threshold is used to determine the “edges” of the signal. Manual adjustment may be required to correctly identify some signals, especially in crowded spectrums.
11 You can set center frequency of the display to the marker frequency by: a. [Zoom to Signal] b. [Zoom In]	The marker will track with the new center frequency at the center of the display. The Span will be decreased to enhance viewing of the designated interference signal.
12 Under [Zoom to Signal] you may also select [Zoom Out]	[Zoom Out] will back out the [Zoom In] series. If you Manually set the Frequency/Channel or Span, it will clear the [Zoom Out] history.

Using the Occupied BW Measurement

Occupied Bandwidth integrates the power of the displayed spectrum and puts markers at the frequencies between which a selected percentage of the power is contained. The measurement defaults to 99% of the occupied bandwidth power. The power-bandwidth routine first computes the combined power of all signal responses contained in the trace. For 99% occupied power bandwidth, markers are placed at the frequencies on either side of 99% of the power. This would leave 1% of the power evenly distributed outside the markers. The difference between the marker frequencies is the 99% power bandwidth and is the value displayed.

The Occupied BW result will correspond to the span between the two markers and will be a multiple of the span between two points. So, for a 10 MHz span, the OBW will come in multiples of 39.216 kHz (10 MHz divided by 255). Values will be 0, 39.216 kHz, 78.431 kHz, 117.647 kHz, and so forth. For narrow signals (TDMA, PDC, and so forth) you will need to zoom in on the signal to get a reasonably accurate Occupied BW result. For a 100 kHz span the Occupied BW resolution will be 392 Hz (100 kHz divided by 255).

The occupied bandwidth measurement can be made in single or continuous sweep mode. The center frequency and reference level may be set by you.

Performing a Basic Occupied BW Measurement

NOTE

The E7495A/B defaults to Average (RMS) detection to measure the occupied bandwidth power. Average (RMS) detection gives the most accurate results, so the default detector setting should therefore be maintained for OBW measurements. Sample detection will give similar results to the Average (RMS) detection, although the results will be less repeatable. Peak and Negative Peak detection will give higher and lower results, respectively, from the actual power.


To reproduce repeatable power readings, use the default Average (RMS) detector. In addition, you should use Running Average or Group Average with 50 or more averages. For more details on averaging, see [“Setting Average, Sweep, and Restart” on page 423](#).

Step	Notes
1 Select Spectrum Analyzer. a. Mode b. [Spectrum Analyzer/Tools] c. [Spectrum Analyzer]	
2 Enter the channel standard. a. [Chan Std] b. Select the standard using the up and down arrow buttons. c. [Select] d. On [Units] select Chan .	Each time you press the [Units] menu key, the selected option changes.
3 Enter the channel number. a. [Channel] b. Enter the channel number using the numeric keypad. c. Select [Fwd] or [Rev].	


Spectrum Analyzer

Using the Occupied BW Measurement

Step	Notes
4 Set the span.	Refer to the note above.
a. [Span]	Use [Setup] [Res BW] to ensure the RBW is set between Span/255 & Span/127.
b. Enter the frequency using the numeric keypad.	
c. [Hz], [kHz], [MHz], or [GHz]	
5 Turn on Averaging.	Use [Average/Sweep] to set Averaging ON, set to Running Average or Group Average, and set Average number to 50 or greater.
a. [Span]	
b. Enter the frequency using the numeric keypad.	
c. [Hz], [kHz], [MHz], or [GHz]	
6 Connect to the base station.	



Out of service connection



In service connection

- For an over the air measurement, connect an antenna and an external filter to the RF input.


The external filter is necessary to eliminate out-of-band signals that would otherwise reduce the dynamic range of measurements in the band of interest. The effect of the out-of-band signals is to raise the noise floor, possibly hiding some or all of the signal of interest. However, the external filter is optional in this set up:

- If you want to limit your search to a specific band of interest you should use it
- If you want to search beyond a specific band then can leave the filter off.

Spectrum Analyzer

Using the Occupied BW Measurement

Step	Notes



Over the air measurement connection

8 Set the level to Autoscale. a. [Level] b. [Autoscale]	
9 Select the Occupied BW Measurement. a. [Measurements] b. [Occupied BW] c. On [Occupied BW] select On.	A marker pair will appear on the trace and the occupied bandwidth value and the integrated power in the Occupied BW are displayed in the data window below the trace graticule.
10 Set the percentage of power for calculating the Occupied BW. a. [Power] b. Enter the percentage number using the numeric keypad. c. Select [%].	The default percentage is 99%.

Step	Notes
11	If you are measuring a narrow signal such as TDMA or PDC, zoom in on the signal for a more accurate Occupied BW results. a. [Freq/Chan/Span] b. [Span] c. Enter the frequency using the numeric keypad. d. [Hz], [kHz], [MHz], or [GHz]

Using the Spectrum Emission Mask Measurement

Use the Spectrum Emission Mask (SEM) measurement (also sometimes referred to as Conducted Spurious Emissions measurement) to identify and determine the power levels of spurious emissions outside the assigned CDMA channel. The measurement is made at the access network output port or at the repeater RF output port.

The SEM measurement only supports cdma2000, 1xEV-DO, and the W-CDMA UTRA channel standards, covering band classes 0,1,3,4,5,6, and 10. If you enable the SEM measurement using an unsupported channel standard, the limit mask will not be turned on and a message will be displayed telling you that the SEM Measurement does not support your selected channel standard. The table below summarizes supported and unsupported CDMA, 1xEV-DO and W-CDMA channel standards.

Band Class	Band Name (Applies to CDMA and 1xEV-DO Only)	Channel Standard Name (Applies to CDMA and 1xEV-DO Only)	SEM Measurements Supported?
0	800 MHz Band.	North American Cellular CDMA (commonly referred to as, 'Cellular Band')	Yes
1	1900 MHz Band	North American PCS CDMA (commonly referred to as, "PCS").	Yes
2	TACS Band	TACS CDMA	SEM Not Supported
3	JTACS Band	Japan CDMA	Yes
4	Korean PCS Band.	Korean PCS CDMA	Yes
5	450 MHz Band	NMT-450	Yes
6	2 GHz Band	IMT-2000 cdma2000	Yes
7	700 MHz Band:	North American 700 MHz Cellular CDMA	SEM Not Supported

Spectrum Analyzer

Using the Spectrum Emission Mask Measurement

Band Class	Band Name (Applies to CDMA and 1xEV-DO Only)	Channel Standard Name (Applies to CDMA and 1xEV-DO Only)	SEM Measurements Supported?
8	1800 MHz Band	1800 MHz CDMA	SEM Not Supported
9	900 MHz Band	900 MHz CDMA	SEM Not Supported
10	Secondary 800 MHz Band	Secondary 800 CDMA	Yes
11	400 MHz European PAMR Band	400 MHz European PAMR	SEM Not Supported
12	800 MHz PAMR Band	800 MHz PAMR	SEM Not Supported

NOTE

1xEVDO SEM measurements are made under two conditions. These are:

- Continuous Data mode, that is, with no idle slots.
- Idle mode, that is, with all slots idle except the control channel

Your E7495A or E7495B test instrument can only make SEM measurements for the first condition, that is, in Continuous Data mode

To make an SEM measurement, the power level limits at different frequency offsets need to be specified. These power limits vary between different channel standards, but have all been predefined for you. These limits are listed in the two tables below. The first table shows the limits for CDMA and 1xEV-DO standards, and the second shows WCDMA UTRA standards.

For all possible channel standards for which you can make an SEM measurement (see the table above), the power limits have been predefined and will be displayed on the screen as a stepped yellow line. This line is known as the 'mask'. If you attempt to make an SEM measurement for a channel standard that does not support SEM measurements, no mask will be displayed, and the message, "SEM Measurement does not support the selected Channel Standard" will be displayed on the bottom of the test instrument's screen.

Spectrum Analyzer

Using the Spectrum Emission Mask Measurement

CDMA and 1xEV-DO Channel Standards and Emission Limits

Band Class	Band Name	Frequency Variance	Emission Limit / RBW
0	800 MHz Band.	750 kHz to 1.98 MHz	–45 dBc / 30 kHz
		1.98 MHz to 4.00 MHz	–60 dBc / 30 kHz
1	1900 MHz Band	885 kHz to 1.98 MHz	–45 dBc / 30 kHz
		1.98 MHz to 2.25 MHz	–55 dBc / 30 kHz
2	TACS Band	SEM Not Supported	
3	JTACS Band	750 kHz to 1.98 MHz	–45 dBc / 30 kHz
		1.98 MHz to 4.00 MHz	–60 dBc / 30 kHz
4	Korean PCS Band.	885 kHz to 1.98 MHz	–45 dBc / 30 kHz
		1.98 MHz to 2.25 MHz	–55 dBc / 30 kHz
5	450 MHz Band	750 kHz to 1.98 MHz	–45 dBc / 30 kHz
		1.98 MHz to 4.00 MHz	–60 dBc / 30 kHz
6	2 GHz Band	885 kHz to 1.98 MHz	–45 dBc / 30 kHz
		1.98 MHz to 2.25 MHz	–55 dBc / 30 kHz
7	700 MHz Band:	SEM Not Supported	
8	1800 MHz Band	SEM Not Supported	
9	900 MHz Band	SEM Not Supported	
10	Secondary 800 MHz Band	750 kHz to 1.98 MHz	–45 dBc / 30 kHz
		1.98 MHz to 4.00 MHz	–60 dBc / 30 kHz
11	400 MHz European PAMR Band	SEM Not Supported	
12	800 MHz PAMR Band	SEM Not Supported	

W-CDMA UTRA Channel Frequencies and Emission Limits

Frequency Offset of Measurement Filter - 3 dB point, Δ (Delta) f	Frequency Offset of Measurement Filter Center Frequency, f_{offset}	Test Requirement Band I, II, III, IV, V, VII, VIII, and X	Measurement Bandwidth
2.5 MHz $\leq \Delta$ (Delta) f < 2.7 MHz	2.515 MHz $\leq f_{\text{offset}} <$ 2.715 MHz	-12.5 dBm	30 kHz
2.7 MHz $\leq \Delta$ (Delta) f < 3.5 MHz	2.715 MHz $\leq f_{\text{offset}} <$ 3.515 MHz	$-12.5 \text{ dBm} - 15 \cdot \left(\frac{f_{\text{offset}}}{\text{MHz}} - 2.715 \right) \text{ dB}$	30 kHz
	3.515 MHz $\leq f_{\text{offset}} <$ 4.000 MHz	-24.5 dBm	30 kHz
3.5 MHz $\leq \Delta$ (Delta) f < 7.5 MHz	4.000 MHz $\leq f_{\text{offset}} <$ 8.000 MHz	-11.5 dBm	1 MHz
7.5 MHz $\leq \Delta$ (Delta) f < Δ (Delta) f _{max}	8.000 MHz $\leq f_{\text{offset}} <$ $f_{\text{offset max}}$	-11.5 dBm	1 MHz

NOTE

Note: The reference channel is measured with an RBW of 76.8 kHz

Note: The minimum requirement for operation in Bands II, IV, V and X is the lower power of the minimum requirement for bands I, II, III, IV, V, and VII and the additional requirements for bands II, IV, V and X

Spectrum Analyzer

Using the Spectrum Emission Mask Measurement

Performing a Basic Spectrum Emissions Mask Measurement

Step	Notes
1	Select Spectrum Analyzer. a. Mode b. [Spectrum Analyzer/Tools] c. [Spectrum Analyzer]
2	Enter the channel standard. a. [Chan Std] b. Select the standard using the up and down arrow buttons. c. [Select] d. On [Units] select Chan.
3	Enter the channel number. a. [Channel] b. Enter the channel number using the numeric keypad. c. Select [Fwd] or [Rev].
4	Select the SEM measurement. a. [Measurements] b. [SEM]

Step	Notes
5 Switch the SEM measurement On. a. [SEM]	Each time you press the [SEM] menu key, the selected option changes. As soon as you switch the SEM measurement On, the SEM mask (a stepped yellow line) will appear on the screen. If no SEM mask appears, check that SEM measurements are supported for your selected channel standard. CDMA or 1xEV-DO signals only: Each individual mask line segment will be annotated with either a green circle with ‘P’ inside it (indicating that the limit line segment has not been exceeded) or with a red triangle with an ‘F’ (indicating the limit has been exceeded and the test has failed). WCDMA UTRA signals only: The green circles with “P” (for a pass) and the red triangles with “F” (for a fail) are not displayed on WCDMA SEM measurements. Instead, if any segment of the mask fails, the limit line segment in question will thicken, and will change from yellow to red and white.

Spectrum Analyzer

Using the Spectrum Emission Mask Measurement

Step	Notes
6 Switch Noise Correction On or Off according to your needs (W-CDMA channel standard only).	Each time you press the [Noise Corr] menu key, the selected option changes.
a. [Noise Corr]	Noise Correction only takes effect when measuring W-CDMA channel standards. There is no Noise Correction for any other channel standards. Agilent Technologies recommends that at least 10 averages should be used when Noise Correction is being used.

When the SEM Measurement is turned **On**, the states of the following parameters are stored for restoration when the SEM Measurement is turned **Off**:

- Resolution bandwidth mode
- Frequency span
- Averaging mode
- Number of averages
- Upper limits
- Lower limits

The following parameters are then set to perform the measurement. Each time the SEM measurement is turned **On**, these parameters are set to the values as detailed below. In addition the upper limits are reset to appropriate default values when the SEM measurement is **On** and the selected channel standard is changed.

- **Occupied bandwidth** measurement turned **Off**
- **Interference analysis** measurement turned **Off**
- **Resolution bandwidth mode** set to **Manual**
- **Resolution bandwidth** set to **30 kHz**
- **Lower limit** center, segment 1 and segment 2 set to **Off**
- **Number of averages** set to **10**

Spectrum Analyzer

Using the Spectrum Emission Mask Measurement

- **Averaging mode** set to
 - **Running** for CDMA and 1xEVDO channel standards
 - **Group Average** for W-CDMA channel standard
- If currently selected channel standard is **Band class 0, 2, 3, 5, 7, 9 or 10** (see table above)
 - **Span** set to **8 MHz**
- If currently selected channel standard is **Band class 1, 4, 6 or 8**
 - **Span** set to **5 MHz**
- Upper limits are set to the levels specified in the table above.

The SEM Measurement is turned **Off** when either the Occupied Bandwidth or Interference Analysis measurements are turned **On**.

NOTE

The SEM standards for W-CDMA signals specify different RBW settings at different frequency offsets (see [“W-CDMA UTRA Channel Frequencies and Emission Limits” on page 453](#)). This requires your base station test set to build up the W-CDMA SEM trace from several discrete segments, and can make the test set appear slow. The progress of your W-CDMA SEM measurement is indicated by the following status messages:

- Measuring SEM Outer Segments...
- Measuring SEM Inner Segments...
- Measuring reference Channel...


Note also that if you have Noise Correction switched On, your test instrument needs to take two sweeps for every update. This will make your test instrument cycle through the three progress messages (above) twice before the screen is updated.

Spectrum Analyzer

Using the Spectrum Emission Mask Measurement

Figure 16-4

Spectrum Emissions Mask (SEM) Measurement



- “System Reference Introduction” on page 461
- “Setting System References” on page 462
 - “Displaying GPS Location Data” on page 462
 - “Selecting a Frequency/Timing Reference” on page 462
 - “Setting up the DC Bias Option” on page 463
- “Printing a Screen to a File” on page 465
 - “Printing Screens” on page 465
 - “Selecting Output Media—PCMCIA Card or Compact Flash Card” on page 465
 - “File Naming Options” on page 466
- “Saving Data” on page 469
 - “Saving data” on page 469
 - “Selecting Output Media—PCMCIA Card or Compact Flash Card” on page 469
 - “File Naming Options” on page 470
- “Managing Media Types” on page 473
 - “Formatting a PCMCIA or CompactFlash Card” on page 473
 - “Test Software Operation” on page 473
- “Configuring for Network Connectivity” on page 475
- “Saving, Recalling, and Deleting Instrument States” on page 478
 - “Saving the State” on page 478
 - “Saving the Power-Up State” on page 478
 - “Recalling the State” on page 479
 - “Returning the Power-Up State to Factory default” on page 479
 - “Deleting States” on page 480
- “Viewing System Statistics” on page 481
 - “Viewing System Release Versions” on page 481

Basic System Operations

- “Viewing System Memory” on page 481
- “Viewing Battery Statistics” on page 482
- “Using the Option Manager” on page 483
 - “Viewing Installed Options” on page 483
 - “Viewing Installable Options” on page 483
 - “Installing an Option” on page 484
 - “Viewing Installation Information” on page 484
- “Testing System Functions” on page 485

System Reference Introduction

The Agilent E7495A/B Base Station Test Sets provide a system utility that allows you to perform non-measurement activities and to configure the test set for:

- General operations
- System status updates
- Data manipulation
- Basic system functions testing

Setting System References

The Agilent E7495A/B provide a utility to preconfigure the global settings for the box.

Displaying GPS Location Data

Perform this procedure to have the current GPS location data visible on the screen at all times.

Step	Notes
1 [System]	
2 [Fr/Time Ref Location]	
3 On [Show GPS Location] select On .	Each time you press this softkey, the selected option changes.

NOTE

A GPS locked or unlocked indicator is located in the bottom-left of the screen. It indicates whether or not the GPS signal is being captured.

Selecting a Frequency/Timing Reference

Perform this procedure to select a common frequency or timing reference to be used for all measurement tools (when applicable).

Step	Notes
1 [System]	
2 [Fr/Time Ref Location]	

Step	Notes
3 [Fr/Time Ref]	Displays additional menu buttons. With Internal GPS and External Even Sec, both frequency and time references are active. This is used when measuring CDMA signals to get valid PN offsets. With the other five options, you get only frequency.
4 Select the frequency/timing reference you want.	

NOTE

A frequency/time reference indicator in the lower-right of the screen shows both the selected reference and its status.

Reference indicators include: “GPS,” “Int Ref,” “Even Sec,” “Ext 10 MHz,” “Ext 13 MHz,” or “Ext 19.66 MHz.”

Status indicators include:

- Green dot to indicate that the reference is locked
- Yellow triangle to indicate that the reference is acquiring lock
- Red X to indicate that the reference is not locked

Setting up the DC Bias Option

The DC Bias Tee, *Option 300 - DC Bias*, provides power from the Agilent E7495B to the amplifier at the top of a base station tower, or the end of the cable run. The DC voltage (12 volts) is output on the center conductor of Port 1, RF Out. The option enables you to test with the amplifier powered on. DC bias defaults to off when you select a new measurement type which does not depend on either Port 1 or Port 2, and it must be turned on each time you want to use it. It stays on as long as you’re using measurements that use RF In or Out. DC Bias cannot be saved in the On position as a state and is turned off when the power is cycled, including when going into the sleep state. If you do not have the option, it is grayed out on the screen.

NOTE

The maximum current draw is 800 milliamps.

Step	Notes
1 System	
2 [Fr/Time Ref Location]	
3 [DC Out] [On]	Each time you press this softkey, the selected option changes.

WARNING

If you have tripped the RPP or are over the current limit for the DC bias, a warning screen appears. However, if you have shorted the output, the short may not be detected, and the test set will shut off current to the DC Bias port.

Printing a Screen to a File

The E7495A/B lets you save screen images to PNG files. You can save the image files to a PCMCIA card or to a CompactFlash card.

Printing Screens

Step	Notes
1	Display data on a measurement screen.
2	Insert the PCMCIA or CompactFlash card.
3	Select the card you want to use by selecting the output media (see “Selecting Output Media—PCMCIA Card or Compact Flash Card” on page 465).
4	Select how you want to name the data file you’re saving (see “File Naming Options” on page 466).
5	[Print Screen]
6	Enter a name for the file (or it is done automatically, depending on the file naming method you selected).

Selecting Output Media—PCMCIA Card or Compact Flash Card

Step	Notes
1	[System]

Basic System Operations

Printing a Screen to a File

Step	Notes
2 [Print Screen Setup]	
3 On [File Location] select PCMCIA or CF .	Each time you press this softkey, the selected option changes.

File Naming Options

You have three options for naming image files. You can

- Name each file automatically using this format:
saveData_YYYYMMDD_HHMMSS.png
- Name each file individually, and enter the name you want. This is called User file naming.
- Have the test set ask you how you want to name each file for each file you save.

Setting Up Automatic File Naming

Step	Notes
1 [System]	
2 [Print Screen Setup]	
3 On [Filename] select Auto .	Each time you press this softkey, the selected option changes.

Setting Up User File Naming

Step	Notes
1 [System]	
2 [Print Screen Setup]	
3 On [Filename] select User .	Each time you press this softkey, the selected option changes.

Step	Notes
4	Setup file naming. [User Filename] - If the filename does not exist, use the rotary knob or up and down arrow buttons to select a letter and the buttons on the left to change cursor position - For each character entered, press [Enter]. If the filename does exist, select [Choose File...] on the right to display a list of the current files on the selected media. - Use the rotary knob to select the file and press Select. [Ok]
5	[If File Exists]
6	[Overwrite], [Prompt], [Auto Incr], or [Timestamp] Overwrite—overwrites existing file data with new file data. Prompt—prompts you to input a new file name. Auto Incr—automatically increments the filename and retains the existing filename. Timestamp—attaches a timestamp to the filename to distinguish it from the existing file.

Setting Up Asking For Filename

You can choose to have the test set ask you at the time you print a screen how you want to name the file. For every file you save, you can choose to specify automatic naming or to enter the filename you want.

Basic System Operations
Printing a Screen to a File

Step		Notes	
1	[System]		
2	[Print Screen Setup]		
3	On [Filename] select Ask.	Each time you press this softkey, the selected option changes.	

Saving Data

Saving data

Step	Notes
1	Display data on a measurement view.
2	Insert the PCMCIA or CompactFlash card.
3	Select the card you want to use by selecting the output media (see “Selecting Output Media—PCMCIA Card or Compact Flash Card” on page 469).
4	Select how you want to name the data file you’re saving (see “File Naming Options” on page 466).
5	[Save Data]
6	Enter a name for the file (or it is done automatically, depending on the file naming method you selected).

Selecting Output Media—PCMCIA Card or Compact Flash Card

Step	Notes
1	[System]
2	[Print Screen Setup]

Step	Notes
3 On [File Location] select PCMCIA or CF .	Each time you press this softkey, the selected option changes.

File Naming Options

You have three options for naming data files. You can:

- Name each file automatically using this format:
saveData_YYYYMMDD_HHMMSS.xls
- Name each file individually, and enter the name you want. This is called User file naming.
- Have the test set ask you how you want to name each file at the time you save the data.

Setting Up Automatic File Naming

Step	Notes
1 [System]	
2 [Save Data Setup]	
3 On [Filename] select Auto .	Each time you press this softkey, the selected option changes.

Setting Up User File Naming

Step	Notes
1 [System]	
2 [Save Data Setup]	
3 On [Filename] select User .	Each time you press this softkey, the selected option changes.

Step	Notes
4	Setup file naming. a. [User Filename] b. If the filename does not exist, use the rotary knob or up and down arrow buttons to select a letter and the buttons on the left to change cursor position c. For each character entered, press [Enter]. If the filename does exist, select [Choose File...] on the right to display a list of the current files on the selected media. d. Use the rotary knob to select the file and press Select. e. [Ok]
5	[If File Exists]
6	[Overwrite], [Prompt], [Auto Incr], or [Timestamp] • Overwrite—overwrites existing file data with new file data. • Prompt—prompts you to input a new file name. • Auto Incr—automatically increments the filename and retains the existing file name. • Timestamp—attaches a timestamp to the filename to distinguish it from the existing file.

Setting Up Asking For Filename

You can choose to have the test set ask you at the time you save a data file how you want to name the file. This option means that for every file you save, you will be able to specify automatic naming or enter the filename you want.

Step		Notes
1	[System]	
2	[Save Data Setup]	
3	On [Filename] select Ask.	Each time you press this softkey, the selected option changes.

Managing Media Types

The E7495A/B is compatible with two media types for storing and retrieving data: PCMCIA card and CompactFlash card. The media type buttons are not active until a media card is inserted and recognized by the E7495A/B. Upon proper recognition, the test set allows you to perform basic media tasks with each media type.

Formatting a PCMCIA or CompactFlash Card

You need to perform this procedure to prepare a new or existing PCMCIA or CompactFlash storage card for data storage.

Step	Notes
1	Make sure the card you will format is inserted in its slot.
2	[System]
3	[Media Manager]
4	[Format PCMCIA] or [Format CF] Prepares a PCMCIA or CompactFlash card for storage. Erases existing data on the card.

Test Software Operation

Your E7495A/B can be optioned for various software options. Refer to the appropriate software manual for the usage of the Test Software key and Software Utilities key.

Importing or Exporting Configuration Files from a compact flash or PCMCIA flash memory card.

You can perform this procedure to import or export Test Software configuration files to or from a PCMCIA or a CompactFlash storage card.

Step	Notes
1	Make sure the card with the software configuration files or a card with adequate free space to receive the files is inserted in its slot.
2	[System]
3	[Media Manager]
4	To import configuration files from a memory card [Import Config Files] a. [from PCMCIA] or [from CF]; depending on which memory card you are using. b. Follow the on screen instructions.
5	To export configuration files to a memory card [Export Config Files] a. [to PCMCIA] or [to CF]; depending on which memory card you are using. b. Follow the on screen instructions.

Configuring for Network Connectivity

The E7495A/B can operate as a device on any compatible network. In order to be accessible on the network, certain information must be entered so the test set can communicate with other devices. Configuring the test set for network activity is performed by using the IP administrator located in the system utilities.

IP Administration Using DHCP

Perform this procedure to allow your test set to be integrated into an existing network that uses DHCP to dynamically assign an IP address. This procedure requires that you have the System Name (available from your network administrator).

Step	Notes
1 [System]	
2 [Controls]	
3 [IP Admin]	
4 [Sys Name]	
5 Enter the name of the test set.	This is automatically assigned by the network administrator.
6 [Ok]	
7 On [DHCP] select On.	An IP address and other network information will automatically be assigned if the Sys Name is recognized by the network.
8 [Save]	
9 [Ok]	Saves the current configuration and restarts the test set. DHCP will dynamically assign an IP address.

IP Administration Without DHCP

Perform this procedure to allow your test set to be integrated into an existing network that uses a technique other than DHCP for its IP address assignments. One

Basic System Operations

Configuring for Network Connectivity

example of an alternative technique used for IP address assignments is DNS. This procedure requires the following specific data from the network administrator:

- System name
- IP address
- Net mask
- Gateway

Step	Notes
1 [System]	
2 [Controls]	
3 [IP Admin]	
4 [Sys Name]	
5 Enter the name of the test set.	This name is usually assigned by the network administrator.
6 [Ok]	
7 On [DHCP] select Off .	Each time you press this softkey, the selected option changes.
Now you must specify relevant network information for the test set to be recognized. Contact your network administrator if you do not have this information.	
8 [IP Address]	
9 Enter the IP address.	Use the rotary knob and menu keys on the left.
10 [Ok]	
11 [Net Mask]	
12 Enter the Net Mask.	Use the rotary knob and menu keys on the left.
13 [Ok]	
14 [Gateway]	
15 Enter the Gateway.	Use the rotary knob and menu keys on the left.

Step	Notes
16 [Ok]	
17 [Save]	
18 [Ok]	Saves the current network configuration and restarts the test set.

Saving, Recalling, and Deleting Instrument States

You can save the current configuration of buttons and settings for recall at a later time. You can also save a customized power-up state, which the test set will use the each subsequent time it is powered on. This enables you to configure common usage and power-on states to speed up base station testing.

Saving the State

Step	Notes
1 Configure all measurement settings you want to save.	Make sure you're viewing the screen you want to recall later.
2 [Save State]	
3 Enter the state name you want to use, for example, "Remote base station.	Each time you press this softkey, the selected option changes.
4 [Ok]	

Saving the Power-Up State

Step	Notes
1 Configure all measurement settings you want to save.	Make sure you're viewing the screen you want to display at power up.
2 [Save State]	

Step	Notes
3	Enter the state name, “Power up” (the test set is case-sensitive, so be sure to capitalize the “P”).
4	[Ok]

Recalling the State

Step	Notes
1	[Recall State]
2	Select from the list the state you want to recall. Use the rotary knob or the up and down arrow buttons to select the state you want to delete. All states, in addition to two supplied in the test set, are displayed: - Powerup - The default power-up state shipped with the test set, or the power-up state last saved with the test set. - Factory Defaults - The default power-up state shipped with the test set. You can always revert to it by selecting it in this procedure.
3	[Select]

Returning the Power-Up State to Factory default

Step	Notes
1	[Recall State]
2	Select Factory Defaults from the list. Use the rotary knob or the up and down arrow buttons to select the state you want to delete.

Basic System Operations

Saving, Recalling, and Deleting Instrument States

Step	Notes
3	[Select]
4	[Save State]
5	Enter the filename, “Powerup” (the test set is case-sensitive, so be sure to capitalize the “P”).
6	[Ok]

Deleting States

If you have saved a state you will no longer use, you can delete it.

Step	Notes
1	[System]
2	[Save/Recall]
3	[Delete States]
4	Select the state you want to delete or [All] to delete all saved states. Use the rotary knob or up and down arrow buttons to select the state you want to delete.
5	[Select]

NOTE

Selecting [All] does not delete the Powerup or Factory Defaults states.

Viewing System Statistics

The E7495A/B provides a utility that allows you to:

- Check test set status
- Verify operational readiness
- Perform system configuration
- Check the system software version

Viewing System Release Versions

Perform this procedure to view the current version of software and firmware for enabled features.

Step	Notes
1 [System]	
2 [More 1 of 2]	
3 [System Stats]	
4 [Rev Info]	View version information for system firmware.
5 [Page Up]	Use these buttons to scroll to the next screen.
or	
[Page Down]	

Viewing System Memory

Perform this procedure to view current allocation and usage statistics of the memory available.

Step	Notes
1 [System]	
2 [More 1 of 2]	
3 [System Stats]	

Step	Notes
4 [Memory]	View status of total, used, and available memory.

Viewing Battery Statistics

Perform this procedure to view current status and battery usage.

Step	Notes
1 [System]	
2 [More 1 of 2]	
3 [System Stats]	
4 [Battery]	View the status of battery conditions. For details, see “System Statistics—Battery Screen” on page 166 .
5 As needed, [Page Up] or [Page Down]	Use these menu keys if you need to scroll up or down to see all the information.

Using the Option Manager

The E7495A/B provides a utility that allows you to:

- View installed options
- View installable options (by user and by factory)
- View installation information
- Install an option

Viewing Installed Options

Step	Notes
1 [System]	
2 [More 1 of 2]	
3 [Option Manager]	
4 [Installed Options]	Provides a list of all installed options.
5 [Page Up] or [Page Down]	Use as necessary to scroll to the next screen.

Viewing Installable Options

Perform this procedure to view a list of all options that you can install for the test set. Two lists are displayed: options you can install yourself and options that must be installed at the factory.

Step	Notes
1 [System]	
2 [More 1 of 2]	
3 [Option Manager]	

Step	Notes
4 [Installable Options]	Provides a list of options that can be installed.
5 [Page Up] or [Page Down]	Use as necessary to scroll to the next screen

Installing an Option

Step	Notes
1 [System]	
2 [More 1 of 2]	
3 [Option Manager]	
4 [Installing an Option]	Follow the on-screen instructions.

Viewing Installation Information

Perform this procedure to view current manufacturing information about your test set that must be provided to Agilent to install a user-installable option.

Step	Notes
1 [System]	
2 [More 1 of 2]	
3 [Option Manager]	
4 [Install Info]	When you call your Agilent sales representative to order an option, you will need to provide the information you see on this screen: • Model number • Serial number • Host ID

Testing System Functions

The E7495A/B provides two simple tests you can perform to test the basic system functionality: a display test and a keyboard test.

Testing Your Display

Perform this procedure to verify the correct operation of your display device.

Step	Notes
1	[System]
2	[More 1 of 2]
3	[Service]
4	[Verification]
5	[Display Test] Follow directions on screen.

Testing Your Keyboard

Perform this procedure to verify the correct operation of your keyboard device.

Step	Notes
1	[System]
2	[More 1 of 2]
3	[Service]
4	[Verification]
5	[Keyboard Test] Press the available buttons and view the results on the screen.

Basic System Operations
Testing System Functions

- “Making T1 Measurements” on page 488
- “Performing a Basic T1 Analyzer Measurement” on page 488
- “Setup Button Selections” on page 488
- “Display/Sound Button Selections” on page 491
- “Control Button Selections” on page 491
- “Sample Hard Loop/End-End Full T1 BERT Test” on page 493
- “Sample Loopback CSU Full T1 BERT Test” on page 498
- “Sample Monitor Full T1 Test” on page 503
- “Sample Emulate CSU/NIU Test” on page 507
- “Sample Delay Test” on page 512
- “Turning on sound” on page 514
- “Setting up T1 diagnostics” on page 515
- “Patterns” on page 517
- “Measurement Results” on page 518
- “Alarm indicators” on page 518
- “Results indicators” on page 518
- “Status indicators” on page 519
- “Measurement results fields” on page 519
- “Testing and Fault Mitigation” on page 522
- “Detailed Loop Mode and Auto Configuration Descriptions” on page 527
 - “Remote CSU/NIU Loop Mode” on page 527
 - “Auto Configuration Flow Diagram” on page 531
- “Terminology” on page 533

Making T1 Measurements

The Agilent E7495A/B provide a simple solution for all your T1 testing needs, from basic transmission testing to BERT testing. For more information about T1 testing, refer to [“Measurement Results” on page 518](#).

Performing a Basic T1 Analyzer Measurement

Step	Notes
1. [Mode]	
2. [Backhaul]	
3. [T1 Analyzer]	
4. [Get Started/ Test Mode]	The tests are listed on the buttons on the right. Pressing a test mode button will provide you with information about the test and the test options available.
5. [Setup]	Configure the T1 analyzer for the measurement.
6. [Display]	Setup your view of the measurement results.
7. [Control]	Modify the measurement setup and inject errors as you perform the measurement.

Setup Button Selections

- **Rx Input:** The Primary and Secondary inputs are both affected by this setting.
 - **Terminate** - Sets the input impedance to 100 Ohms. Can be performed only when the T1 circuit is interrupted (connected into a jack that interrupts the circuit).
 - **Monitor** - Sets the input impedance to 100 Ohms, inserts 20 dB gain, and should be selected when connected to a 'Monitor' jack.
 - **Bridge** - Sets the input impedance >1000 Ohms and should be selected when bridging on to a T1 circuit.

- **Line Code:** Configures the test set to transmit and expect to receive a line code that is compatible with the network's design. There are two types of line coding used in T1 networks:
 - **AMI** - Alternate Mark Inversion is a traditional line code.
 - **B8ZS** - Bipolar 8 Zero Substitution replaces runs of 8 zeroes with a special code that is not compatible with AMI. It allows greater flexibility of data patterns by enhancing repeater synchronization by increasing pulse density, thereby providing greater throughput.
- **Framing:** Configures the test set to transmit and expect to receive a particular framing pattern that is compatible with the network's design. It enables the test set to receive the T1 signal and to then synchronize, identify, and extract the individual channels.
 - **Unframed** - The 193rd (framing) bit is set to 0 or 1, depending on the pattern.
 - **D3/D4** - A 12 frame structure accomplished by sending a unique pattern on the 193rd (framing) bit.
 - **ESF** - A 24 frame structure accomplished by sending a unique pattern on the 193rd (framing) bit. In this mode the frame bits are used to transmit a CRC and carry information to accommodate alarms and control
- **Pattern:** Configures the test set to expect a particular test pattern. Many test patterns are available to 'stress' the circuit in a particular manner or to gain maximum insight into a particular problem.
- **Tx Pattern:** Allows you to select either Normal or Inverted patterns.
- **Tx Clock:** Configures the test set to use one of the following methods to derive the transmit clock frequency:
 - **Internal** - The transmit clock is derived within the test set and is independent of the incoming signal. This is useful when the device or line under test is configured to synchronize on the incoming signal. In this case the return clock frequency of the return signal should match the transmit clock frequency of the test set.
 - **Primary Rx** - The transmit clock frequency is derived from the signal received at the Primary Rx jack on the test set.
 - **Secondary Rx** - The transmit clock frequency is derived from the signal received at the Secondary Rx jack on the test set.
- **Channel:** Applicable only in the Channel BERT mode. Sets the active channel

T1 Analyzer

Making T1 Measurements

to be tested for BERT.

- **Fill Data:** When performing Channel BERT testing this configures the source of data transmitted in the unused slots. For drop-and-insert testing this field is typically set to Secondary Rx.
 - **All 1's** - Set this mode to maintain a sufficient 1s density on the unused channels during testing. All 1s are typically transmitted on unused channels in live T1 circuits.
 - **Idle** - Set this mode to accommodate specific troubleshooting such as to exercise a circuit designed for B8ZS.
 - **Primary Rx** - Fills the unused slots with Primary Rx data.
 - **Secondary Rx** - Fills the unused slots with Secondary Rx data.
- **Loop Code:** Selects the format of the transmitted code when a loop-up or loop-down is requested.
 - **ESF Datalink** - Loopback state change requests are sent to the far end in the framing pattern in the ESF datalink channel. Note that this mode is possible when only ESF is selected for the framing pattern.
 - **In-band** - Loopback state change requests are sent to the far end by replacing the normal channel data with the loop code. Note that in this mode the code must persist for 5 seconds for the far end to respond
- **Slip Reference:** Selects the reference for the frame slip measurement.
 - **None** - This selection disables the frame slip measurement.
 - **Internal** - In this mode the test set compares the framing of the incoming signal with the test set's internal clock. Three conditions are necessary when using this mode: the far end must be receiving a signal from this test set, the transmit clock on the far end must be configured to synchronize on the incoming signal, and the Tx Clock on this test set must be set to **Internal**.

Internal is the default selection after test set preset and covers the situation when a hard loop is configured at the far end. If a separate test set is used at each end, then the test set on one end should have the Tx Clock set to **Primary Rx** (Assuming the incoming signal is connected to this jack.) Another alternative is to use a second T1 circuit connected to the Secondary Rx jack to establish proper timing.
 - **Second Rx** - In this mode the test set compares the frame clock timing of the received signal on the Primary Rx jack with the frame clock timing of the received signal on the Secondary Rx jack.

- **Tx Line Build Out [Tx LBO]:** Sets the Tx level and pulse shape to simulate the signal conditions that would be encountered at the end of a distant transmission cable. This is useful for testing equipment suspected of having trouble receiving the signals found in typical applications.
 - 0 dB LBO = 0 dBdsx = 6 Vpp
 - -7.5 dB LBO = -7.5 dBdsx = 2.53 Vpp
 - -15 dB LBO = -15 dBdsx = 1.07 Vpp
- **Second Tx:** Selects the source of data of the signal available at the Secondary Tx jack.
 - AIS - The signal at the Secondary Rx jack is an unframed all ones aka AIS.
 - Second Rx - The Secondary Rx signal is buffered and looped back to the Secondary Tx jack.
 - Primary Rx - The signal at the Primary Rx jack is buffered and internally routed to the Secondary Tx jack.

Display/Sound Button Selections

Configure the following for the measurement you're doing:

- **Status:** Allows you to select which status panel is active.
- **Alarms:** Displays those errors occurring on either the primary or secondary channel, depending on your selection. Displays in the bottom-right of the screen.
- **Results:** You can choose an error and select results you want to drill down to; shows more metrics on error you select. Displays in bottom-right of screen.
- **Sound:** Works on single channels only and enables you to turn sound on and off. Use sound mostly to listen for drop outs or changes in the signal.
- **Volume:** Enables you to set the volume of speaker output.

Control Button Selections

On the Control button, the available buttons are unique to the test mode you select. Once you set up your display, you can change settings such as patterns, alarm injections, and so forth, while you make the measurement.

- **Pattern:** Configures the test set to expect a particular test pattern. Many test patterns are available to 'stress' the circuit in a particular manner or to gain maximum insight into a particular problem.

T1 Analyzer

Making T1 Measurements

- **Alarm/Error:** Enables a list of available alarms and conditions that can be transmitted on the Primary Tx channel. The alarm or condition is invoked by pressing the Inject button.

To troubleshoot your T1 line, you can monitor for errors or alarms. Inject errors to see how the system responds.

- **Loss of Signal Alarm** - The test set ceases to send a signal.
- **Loss of Frame Alarm** - Forces the framing bit to always be set to 1.
- **Yellow Alarm** - The test set sends a Yellow Alarm. In D3/D4 mode, the test set sets bit #2 of each timeslot to 0. In ESF mode, the datalink bits are configured to send a repetitive pattern of 8 ones, followed by 8 zeros.
- **AIS Alarm** - The test set sends an AIS, or 'Blue Alarm', by sending an unframed, all 1s pattern (a constant contiguous stream of 1s).
- **Idle Alarm** - The test set sends a framed, all zero pattern. Note that the far end will interpret this as a Yellow Alarm.
- **BPV Error** - The test set forces a single, bipolar violation error with each press of the Inject button.
- **Frame Error** - The test set forces a single frame error with each press of the Inject button.
- The test set forces a CRC error with each press of the Inject button only when ESF mode is selected.
- The test set forces an error in the transmitted pattern with each press of the Inject button.
- **Fill Data:** When performing Channel BERT testing, this configures the source of data transmitted in the unused slots. For drop-and-insert testing, this field is typically set to Secondary Rx.
 - **All 1's** - Set this mode to maintain a sufficient 1s density on the unused channels during testing. All 1s are typically transmitted on unused channels in live T1 circuits.
 - **Idle** - Set this mode to accommodate specific troubleshooting such as to exercise a circuit designed for B8ZS.
 - **Primary Rx** - Fills the unused slots with Primary Rx data.
 - **Secondary Rx** - Fills the unused slots with Secondary Rx data.
- **Inject:** Causes the error or condition that is currently displayed on the button to occur. Some selections cause a single event to occur, while others maintain a

constant state. The text on the button changes to reflect the appropriate action.

- **Loop Up/Loop Down:** Available in emulate mode, these buttons enable you to manually put the test set into either loop up or loop down mode.
- **Send Loop Up/Send Loop Down:** Available in emulate mode, the Send Loop Up button sends a loop up command to the far end. Send Loop Down sends a loop down command to the far end.


Sample Hard Loop/End-End Full T1 BERT Test

Use this test mode to perform measurements, such as BERT, on a known test pattern being sent from the far end. The far end signal can be generated by looping back the transmitted signal from this test set or by a second test set. To use this test, have someone at the far end manually loop-up the equipment or generate a known pattern with a far end test set. Since a pattern is being sent on the T1 line, service on the T1 will be affected.

This example explains how to setup a hard-loop/end-end full T1 BERT test. A hard loop test requires one test set at one end and a hard loop at the other. An end-end test requires a test set at each end but enables the troubleshooter to identify the direction of the trouble. The T1 circuit is not available for service when using this test mode.

During the commissioning or startup phase of a T1 circuit, a several day end-end or hard loop test is often performed. This type of test provides the most comprehensive level of information but does require the circuit to be taken out-of-service for the duration of the test. The test results provide more granular resolution on root cause problems than a monitor test.

Figure 18-1 Sample End to End Connection Diagram



To Perform a Hard Loop/End-End Full T1 BERT Test

Step	Notes
1	Connect the BSTS to the DSX panel
2	[Mode]
3	[Backhaul]
4	[T1 Analyzer]
5	Select a test mode.
a.	[Get Started/ Test Mode]
b.	[Hard Loop/End-End]
c.	[Full T1 BERT]

Use this test mode to perform measurements such as BERT on a T1 circuit. The far end signal must be derived from either a hard loop or from a second test set. The T1 circuit is not available for service when using this test mode.

Select this to perform a BERT test on a full T1 Circuit.

Step	Notes
6 Setup auto configuration. a. [Auto Config] b. [Start Primary Auto Config]	Enables the Auto Configuration buttons and causes the test set to analyze the incoming T1 signal and align the setup choices to the properties of that signal.
7 [Back]	Shifts focus back to the main mode selection buttons.
8 [Setup]	Select this to display a list of setup choices that pertain to this test mode.
9 Setup the Rx input. a. [Rx Input] b. [Terminate]	This assumes the test set is connected into a jack that interrupts the T1 circuit.
10 Setup the line code. a. [Line Code] b. [B8ZS]	This assumes the circuit is designed for B8ZS (Bipolar 8 Zero Substitution). A T-carrier line code in which bipolar violations are deliberately inserted if user data contains a string of 8 or more consecutive zeros.
11 Setup the framing. a. [Framing] b. [ESF]	This assumes that the circuit has been designed for ESF. Extended Superframe Format utilizes the framing bit capacity for additional purposes. The number of frames per multiframe is expanded to 24 frames.
12 Setup the pattern. a. [Pattern] b. Use up and down buttons to select. c. [QRSS] d. [Select]	

T1 Analyzer

T1 Analyzer

Making T1 Measurements

Step	Notes
13 Setup the Tx clock. a. [Tx Clock] b. [Internal]	Internal is the default selection after test set preset and covers the situation when a hard loop is configured at the far end. If a separate test set is used at each end, then the test set on one end should have the TX Clock set to Primary Rx (assuming the incoming signal is connected to this jack). Another alternative is to use a second T1 circuit connected to the Secondary Rx jack to establish proper timing.
14 Setup the Tx LBO. a. [Tx LBO] b. [0 dB]	This is a typical level found at the customer demarcation point.
15 Setup the slip reference. a. [Slip Ref] b. [None]	Disables the frame slip measurement.
16 Setup the second Tx. a. [Second Tx] b. [AIS]	Use the default condition.
17 Setup the display. a. [Display] b. [Status] c. [Pri]	Enables the [Display] options on the buttons on the right. Activates only the Primary Status pane. The inactive channel should be deactivated to cease the display of invalid measurements.
18 Setup alarms. a. [Alarms] b. [Pri]	Use this selection to observe the Primary Results in the Alarm Panel.

Step	Notes
19 Setup the results display. a. [Results] b. Use up and down buttons to select. c. [Select]	Enables a list of results information that can be displayed in the Results pane. Make a selection based on the need of the application.
20 Setup the results display. a. [Results] b. Use the up and down arrows to select. c. Make a selection. d. [Select]	Enables a list of results information that can be displayed in the Results pane. Make a selection based on the need of the application.
21 Setup the controls and select a pattern. a. [Control] b. [Pattern] c. Use the up and down buttons to select. d. QRSS e. [Select]	
22 Select the alarm. a. [Alarm/Error] b. Use the up and down buttons to select. c. Loss of Signal d. [Select]	

Step	Notes
23 Inject an error. a. [Inject] b. [On]	Causes the error or condition that is currently displayed on the button to occur.

Sample Loopback CSU Full T1 BERT Test

Use this test mode to perform a measurement, such as BERT, on a known test pattern being sent from the far end. The far end signal will be generated by looping back the transmitted signal from this test set. You will use this test set to send a code to automatically loop-up either a CSU or NIU at the far end. Since a pattern is being sent on the T1 line, service on the T1 will be affected.

Once you have selected this test mode, you can send the loop-up or loop-down code using the buttons on the Control menu. If you are you are using ESF, configure the appropriate ESF Loop Code on the Setup menu.


The T1 circuit is not available for service when using this test mode. End-to-end loopback tests are normally limited to the CSU since NIU loop codes are normally suppressed at the central office.

When the far end of a T1 circuit is in a remote location and trouble is suspected, it is possible to place the equipment at the far end into loopback by sending a special code designated for this purpose. If the T1 circuit is leased, then the wireless technician is often limited to looping only the CSU, as NIU loop codes are usually blocked at the central office. The loop code can be sent either in-band or on the ESF datalink channel by the test set to the far end equipment. The first method, in-band, replaces the bits in the T1 traffic channels with the unique loop code. The remote equipment must see this code for 5 seconds before it will respond in order to minimize the potential that patterns in live data will falsify this request. The downside of this technique is that all devices in the transmit path see this code and any may respond. This could lead to a confusing situation if a T1 route consists of multiple hops, each with its own CSU pair. If the far end has a hard loop then the loop code could come back to the near end and inadvertently place that CSU into loopback. The test set does monitor for a pre-existing loop and will notify you when remote loopback is attempted using an in-band loop code.

Another method is available if the circuit is designed for Extended Super Frame (ESF). This method, ESF datalink, sends the loop code on the ESF data link bits. This method is not prone to false information and, therefore, responds very rapidly. This is the default mode of the test set. For more information, see the section

detailing loopback operation.

Figure 18-2 CSU Full T1 BERT Loopback Connection Diagram



To Preform a Loopback CSU Full T1 BERT Test

Step	Notes
1	Connect the BSTS to the DSX panel
2	[Mode]
3	[Backhaul]
4	[T1 Analyzer]

T1 Analyzer

Making T1 Measurements

Step	Notes
5 Select a test mode. a. [Get Started/ Test Mode] b. [Loopback CSU/NIU] c. [CSU Full T1 BERT]	Use this test mode to perform measurements such as BERT on a T1 circuit by placing the far end CSU or NIU into a loopback state. The T1 circuit is not available for service when using this test mode. End-to-end loopback tests are normally limited to the CSU since NIU loop codes are normally suppressed at the central office. Select this to perform a BERT test on a full T1 Circuit.
6 [Setup]	Select this to display a list of setup choices that pertain to this test mode.
7 Setup Rx input. a. [Rx Input] b. [Terminate]	This assumes the test set is connected into a jack that interrupts the T1 circuit.
8 Setup line code. a. [Line Code] b. [B8ZS]	This assumes the circuit is designed for B8ZS.
9 Setup framing. a. [Framing] b. [ESF]	This assumes that the circuit has been designed for ESF.
10 Select a pattern. a. [Pattern] b. Use the up and down buttons to select. c. QRSS d. [Select]	

Step	Notes
11 Setup Tx clock. a. [Tx Clock] b. [Internal]	This is the default selection after test set preset and covers the situation when a hard loop is configured at the far end. If a separate test set is used at each end then the test set on one end should have the Tx Clock set to Primary Rx (assuming the incoming signal is connected to this jack.) Another alternative is to use a second T1 circuit connected to the Secondary Rx jack to establish proper timing.
12 Setup the Tx LBO. a. [Tx LBO] b. [0 dB]	This is a typical level found at the customer demarcation point.
13 Setup the loop code. a. [Loop Code] b. [In-band]	Your choice depends on the far end CSU configuration.
14 Setup the slip reference. a. [Slip Ref] b. [None]	Disables the frame slip measurement.
15 Setup the second Tx. a. [Second Tx] b. [AIS]	Use the default condition.
16 Setup the display. a. [Display] b. [Status] c. [Pri]	Enables the [Display] options on the buttons on the right. Activates only the Primary Status pane. The inactive channel should be deactivated to cease the display of invalid measurements.
17 Setup the alarms. a. [Alarms] b. [Pri]	This selection causes the Alarm pane to toggle between Primary and Secondary. Use this selection to observe the Primary Results in the Alarm Panel.

T1 Analyzer

Making T1 Measurements

Step	Notes
18 Setup the results display. a. [Results] b. Use the up and down arrows to select. c. Make a selection. d. [Select]	Enables a list of results information that can be displayed in the Results pane. Make a selection based on the need of the application.
19 Setup the controls and select a pattern. a. [Control] b. [Pattern] c. Use the up and down buttons to select. d. QRSS e. [Select]	
20 Select the alarm. a. [Alarm/Error] b. Use the up and down buttons to select. c. Loss of Signal d. [Select]	
21 [Send Loop Up]	Sends a loop up command to the far end and reports the loop state on the status line. If a pre-existing loop is detected at the far end then “Pre-existing loop” is displayed on the status line. This is only possible in In-band mode.
22 [Send Loop Down]	Sends a loop down command to the far end and reports the loop state on the status line.


Step	Notes
23 Inject an error. a. [Inject] b. [On]	Causes the error or condition that is currently displayed on the button to occur.

Sample Monitor Full T1 Test

Use this test mode to monitor live data on the T1 line without affecting service. The simplest hookup for monitoring does not require the test set Tx outputs to be connected. In some cases, you may connect the Tx outputs to the T1 circuit. For those cases, the Tx primary and secondary transmitted signals are regenerated from the received signal on the corresponding line.

In this example, you use the monitor test mode to test performance without disrupting service on a T1 circuit. During this test, the source of the signal from far end can be either live data or pattern data from a second test set. This mode is very similar to End-to-End Hard Loop mode, with the exception that the signal present on the Primary Tx jack is a buffered replica of the signal present on the Primary Rx jack. When monitor jacks are not available, this feature allows the technician to break into a live T1 and pass that signal through the test set, thereby keeping the circuit in-service. This is useful for monitoring long-term statistics of a T1 circuit.

Figure 18-3 Sample Monitor Mode With Monitor Port Connection.




T1 Analyzer

T1 Analyzer

Making T1 Measurements

When using the above sample connection for monitoring a T1 circuit with a monitor port, you should set Rx Input to monitor.

Figure 18-4 Sample Monitor Mode Without a Monitor Port Connection



When using the above sample connection for terminating an T1 circuit, set Rx Input to terminate.

To Perform a Monitor Full T1 BERT Test

Step	Notes
1	Connect the BSTS to the DSX panel For a DSX with a monitor port connection, refer to Figure 18-3 For a DSX without a monitor port connection, refer to Figure 18-4
2	[Mode]
3	[Backhaul]
4	[T1 Analyzer]
5	[Get Started/ Test Mode]

Step	Notes
6 Setup monitoring. a. [Monitor] b. [Monitor Full T1]	Choose this to monitor performance of a full T1 Circuit.
7 Setup auto configuration. a. [Auto Config] b. [Primary Auto Config]	Causes the test set to analyze the incoming T1 signal and align the setup choices to that signal.
8 [Back]	Shifts focus back to the main mode selection buttons.
9 [Setup]	Select this to display a list of setup choices that pertain to this test mode.
10 Setup the Rx Input. a. [Setup] b. [Rx Input] c. [Terminate]	This assumes the test set is connected into a jack that interrupts the T1 circuit. Note: If you are connected to a monitor port, select [Monitor] instead of [Terminate].
11 Setup line code. a. [Line Code] b. [B8ZS]	This assumes the circuit is designed for B8ZS.
12 Setup framing. a. [Framing] b. [ESF]	This assumes that the circuit has been designed for ESF.

T1 Analyzer

T1 Analyzer

Making T1 Measurements

Step	Notes
13 Select a pattern. a. [Pattern] b. Use the up and down buttons to select. c. QRSS d. [Select]	Set to the pattern sent by the far end.
14 Setup Tx clock. a. [Tx Clock] b. [Internal]	This selection is not applicable in Monitor mode because the Primary Tx signal is a buffered replica of the signal applied to the Primary Rx jack and is not affected by this setting. This is the default selection after test set preset.
15 Setup the Tx LBO. a. [Tx LBO] b. [0 dB]	This is a typical level found at the customer demarcation point.
16 Setup the slip reference. a. [Slip Ref] b. [None]	Disables the frame slip measurement.
17 Setup the second Tx. a. [Second Tx] b. [AIS]	Use the default condition.
18 [Display]	Enables the [Display] options on the buttons on the right.
19 Setup the display. a. [Display] b. [Status] c. [Pri]	Enables the [Display] options on the buttons on the right. Activates only the Primary Status pane. The inactive channel should be deactivated to stop the display of invalid measurements.

Step	Notes
20 Setup the alarms. a. [Alarms] b. [Pri]	This selection causes the Alarm pane to toggle between Primary and Secondary. Use this selection to observe the Primary Results in the Alarm Panel.
21 Setup the results display. a. [Results] b. Use the up and down arrows to select. c. Make a selection. d. [Select]	Make a selection based on the need of the application.
22 [Control]	The selection enables several soft keys on the right that control choices specific to each test mode.
23 Select a pattern. a. [Pattern] b. Use the up and down buttons to select. c. QRSS d. [Select]	Select a pattern.

Sample Emulate CSU/NIU Test

The purpose of this test mode is to emulate a CSU or NIU. The test set will terminate the T1 line, and a loop-up code sent from the far end will cause this test set to enter a loopback state. Conversely, a loop-down code sent from the far end will cause this test set to exit the loopback state.

If you are using ESF, configure the appropriate ESF Loop Code on the Setup menu.

In this example, you use the emulate CSU/NSU test mode to have the test set emulate a CSU or NIU at the near end. In this mode it is possible for the far end to place this test set into loopback mode. The T1 circuit is not available for service

T1 Analyzer

T1 Analyzer

Making T1 Measurements

during loopback. Loopback tests are normally limited to the CSU since NIU loop codes are normally suppressed at the central office. When the test set is in a loopback state, AIS is present at the Secondary Tx jack. When not in loopback state, the Primary Rx signal is routed to the Secondary Tx jack and the Secondary Rx signal is routed to the Primary Tx jack.

NOTE


Avoid having a hard loop in the Secondary channel as it will cause a constant loop condition to exist.

You may want to emulate the functionality of a CSU/NIU if trouble is suspected in that equipment. The wireless technician will often be interested in only the CSU mode. The functionality of a CSU is emulated in this mode and the test set will respond to loop codes received at the Primary Rx input.

The test set has the capability to emulate the functionality of a CSU/NIU.

The test set will respond only to the type of loop code selected on the setup screen. Be aware that when the test set is not in loopback mode, the source of data on the Primary Tx jack is the Secondary Rx jack, and the source of data on the Secondary Tx jack is the Primary Rx jack. If B8ZS is selected on the test set, then the signal (or no signal - which is decoded as all zeros) will be translated to B8ZS format.

Figure 18-5 Sample Emulate CSU/NIU Test Setup



The following table provides the data source for primary Tx and secondary Tx

during loop-up and loop-down states in emulate mode.

Data Source in Emulate Mode

Jack	Loop Up	Loop Down
Primary Tx	Primary Rx	- AIS when no signal present at Secondary Rx - Secondary Rx
Secondary Tx	Secondary Rx	AIS

T1 Analyzer
Making T1 Measurements

Sample Emulated CSU/NIU Test:

Step	Notes
1	Connect the BSTS to the DSX panel
2	[Mode]
3	[Backhaul]
4	[T1 Analyzer]
5	Select a test mode. a. [Get Started/ Test Mode] b. [Emulate CSU/NIU] c. [Emulate CSU]
6	[Setup]
7	Setup Rx input. a. [Rx Input] b. [Terminate]
8	Setup line code. a. [Line Code] b. [B8ZS]
9	Setup framing. a. [Framing] b. [ESF]


Step	Notes
10 Select a pattern. a. [Pattern] b. Use the up and down buttons to select. c. QRSS d. [Select]	
11 Setup Tx LBO. a. [Tx LBO] b. [0 dB]	This is a typical level found at the customer demarcation point.
12 [More 1 of 2]	Displays the rest of the Setup options.
13 Setup the loop code. a. [Loop Code] b. [ESF Data Link]	Configures what type of loop code this test set will respond to. Requires a Datalink loop code for this test set to enter loopback mode.
14 [Display]	Enables the Display options on the buttons on the right.
15 Setup the results display. a. [Results] b. Use the up and down arrows to select. c. Make a selection. d. [Select]	Enables a list of results information that can be displayed in the Results pane. Make a selection based on the need of the application.
16 [Control]	The selection enables several soft keys on the right that control choices specific to each test mode.
17 [Pattern]	Select a pattern.
18 [Self Loop Up]	Forces the test set to enter loop-up state.
19 [Self Loop Down]	Forces the test set to enter loop-down state.

Sample Delay Test

Use this test mode to measure the delay between the primary Tx and Rx ports. This measured delay can be used to determine the approximate distance between near end and the far end. The far end of the line must be manually looped during this test. Since a signal is being sent on the T1 line, service on the T1 will be affected.

In this example, you can use this test mode to have the test set measure the round trip delay of a T1 circuit. It is necessary to have a loop condition at the far end during this test. The best accuracy is obtained when a hard loop exists at the far end. The far end CSU can be remotely looped up using the CSU/NIU Loopback mode, however, be aware that the loopback method in the remote device could add additional delay. During this mode a pattern consisting of a zero inserted into a string of ones is transmitted and analyzed to determine the delay in the path. The selected test pattern is sent as filler during the calculation interval.

Figure 18-6 Delay Connection Diagram



Sample Delay Test

Step	Notes
1	Connect the BSTS to the DSX panel
2	[Mode]
3	[Backhaul]
4	[T1 Analyzer]
5	Select a test mode. a. [Get Started/ Test Mode] b. [Delay] c. [Full T1]
6	[Setup]
7	Setup Rx input. a. [Rx Input] b. [Terminate]
8	Setup line code. a. [Line Code] b. [B8ZS]
9	Setup framing. a. [Framing] b. [ESF]

T1 Analyzer

T1 Analyzer

Making T1 Measurements

Step	Notes
10. Select a pattern. a. [Pattern] b. Use the up and down buttons to select. c. QRSS d. [Select]	
11. Setup Tx LBO. a. [Tx LBO] b. [0 dB]	This is a typical level found at the customer demarcation point.

Turning on sound

You can listen to a single channel at a time in channel test mode. Sound is disabled when you are in full T1 test mode.

To Turn On the Sound

Step	Notes
1. [Mode]	
2. [Backhaul]	
3. [T1 Analyzer]	
4. [Get Started/Test Mode]	
5. Select a measurement.	
6. Select Channel mode.	
7. [Display/Sound]	
8. [Sound]	
9. [On] or [Off]	Each time you press this softkey, the selected option changes.

Step	Notes
10. Set the volume.	
a. [Volume]	
b. Enter the volume level from 1 - 10.	
c. [Enter]	

Setting up T1 diagnostics

The diagnostic tests available for T1 include:

- **RAM** - During the RAM test, the memory on the T1 measurement module is tested. Any memory hardware failures are detected.
- **ROM** - The ROM test verifies the integrity of the code by performing a checksum measurement.
- **Loop Back** - The loop back test is a functional test of the transmitting and receiving hardware. It attempts to send various signal patterns and levels and then to verify the measured values. It is important that this test be done using short bantam jumpers (plugs) as even a 1.2 – 2.0 meter (4 – 6 foot) cable can reduce the signal levels during the diagnostic tests, and this can cause a false failure.

If any of the above tests fail, contact your service center.

To Set Up T1 Diagnostics

Step	Notes
1. [Mode]	
2. [Backhaul]	
3. [T1 Analyzer]	
4. [Tests]	
5. [Verification]	The “Connect the T1 Patch Plugs” diagram and explanation in the instrument contain the information you need to set up the test.

T1 Analyzer

T1 Analyzer
Making T1 Measurements

Step	Notes
6. [Continue]	The test is performed and results are reported on the screen.

Patterns

Many test patterns are available to 'stress' the circuit in a unique way or to gain maximum insight into a particular problem. Much has been written to guide the troubleshooter to select the proper pattern. Below is a summary of the qualities of the patterns available in the test set.

- **1:7** - An eight-bit pattern that contains a single one. Used to test clock recovery.
- **2 in 8** - An eight bit pattern with two ones and a maximum of four consecutive zeroes. B8ZS is never sent.
- **3 in 24** - A twenty-four bit-pattern containing 3 ones with the longest length of consecutive zeroes constrained to fifteen. It has a ones density of 12.5% and is used to check clock recovery.
- **All 1's** - A pattern that causes line drivers to consume the maximum amount of current. If framing is set to 'Unframed' the resulting pattern is equivalent to a 'Blue Alarm' or 'Alarm Indication Signal' or AIS.
- **All 0's** - A pattern that is often selected to verify B8ZS provisioning.
- **QRSS** - A pseudorandom pattern that simulates live traffic on a circuit. It is a very common test pattern
- **T1-DALY** - A pattern that changes rapidly between high and low density. This pattern is used to stress ALBO, equalizer and timing recovery circuits.
- **55 Octet** - Similar to the T1-DALY pattern except that it contains runs of fifteen consecutive zeroes that violate ones density requirements if sent unframed.
- **2E15-1** - A pseudorandom pattern based on a 15 bit shift register.
- **2E20-1** - A pseudorandom pattern based on a 20 bit shift register.
- **2E23-1** - A pseudorandom pattern based on a 23 bit shift register.
- **Alternating Ones and Zeroes** - A pattern that alternates between ones and zeroes.

Measurement Results

Alarm indicators

- **Signal Loss** - The test set encountered the absence of 192 or more consecutive pulses. A frame pulse may or may not be present
- **Frame Loss** - The test set encountered an unexpected frame pattern. The frame pattern did not match that selected in 'Setup'
- **Excess Zeros** - The test set encountered the absence at least 16 consecutive pulses in AMI mode, or the absence of at least 8 consecutive pulses in B8ZS mode.
- **All Ones** - The test set encountered an unframed, all 1s pattern (a constant contiguous stream of 1s). This pattern is also known as an Alarm Indication Signal (AIS), 'Keep-Alive Signal', or 'Blue Alarm'. Blue alarms are generated by faulty transmission equipment such as T3 to T1 multiplexers.
- **Yellow Alarm** - A Remote Alarm Indication (RAI) signal pattern was received. This is normally sent by the far end interface equipment (CSU) in response to receiving a blue alarm on its network side. In D4 framing mode, a yellow alarm is created at the far end by setting bit 2 to 0 for 255 consecutive frames. In ESF, a pattern of eight 0s and eight 1s is repeated 16 times to indicate a yellow alarm.
- **Idle (CDI)** - A Customer Disconnect Indication signal was received from the far end interface unit indicating that the customer is no longer supplying a signal. A CDI signal is an in-band pattern 0001 0100. Eight ones followed by eight zeros interrupted each second for 100 ms with LAPD Idle code (01111110) will be sent in the ESF Facility Data Link (ESF FDL).

Results indicators

- **BPV** - A momentary indicator that responds when a bipolar violation occurs on the incoming signal applied to the Receive jack. B8ZS codes are not considered a BPV and will not activate this indicator when the test set is set to AMI mode.
- **Frame** - A momentary indicator that responds when the test set encountered a disruption of the incoming frame pattern.
- **Pattern** - A momentary indicator that responds to a disruption of the incoming pattern.

- **CRC** - A momentary indicator that respond to a disruption of the incoming CRC. This indicator is applicable in only ESF mode.

Status indicators

- **T1 Pulses** - The test set is receiving pulses at the receive jack. Frame pulses alone are not sufficient to activate this indicator. There must be pulses present in the payload field.
- **B8ZS** - A B8ZS pulse pattern was detected on the incoming signal at the receive jack. Note that only certain patterns transmit B8ZS pulse patterns. The pattern must contain at least 8 consecutive zeroes before a B8ZS pattern is sent. The QRSS pattern will generate B8ZS while an idle T1 circuit transmitting all 1's will not.
- **Frame Sync** - A frame sync pattern matches that specified in the setup screen on the test set.
- **Pattern Sync** - The received pattern matches that specified in the setup screen on the test set

Measurement results fields

Recv Level

The voltage level of the signal measured at the Rx jack. (0 dBdsx = 6 Vpp)

Frequency

The frequency of the signal measured at the Rx jack. The T1 Pulses indicator must be active for this measurement to be displayed.

Elapsed Time

Indicates the amount of elapsed time since the last measurement reset.

BPV Errors

A tally of the number of BPV errors since the last measurement reset.

BPV Error Rate

The percent ratio of BPV errors to total bits transmitted since the last measurement reset.

T1 Analyzer

Measurement Results

BPV Errd Secs

The number of one second intervals since the last measurement reset that contained BPV errors.

Frame Errors

A tally of the number of Frame errors since the last measurement reset.

Frame Error Rate

The percent ratio of frame errors to total bits transmitted since the last measurement reset.

Frame Errd Secs

A tally of the number of one-second intervals since the last measurement reset that contained frame errors.

Signal Loss

A tally of the number of one-second intervals since the last measurement reset that contained signal errors.

Frame Sync Loss

A tally of the number of one-second intervals since the last measurement reset that contained frame sync loss.

Excess Zeros

A tally of the number of one-second intervals since the last measurement reset that contained excess zeros.

All 1's

A tally of the number of one-second intervals since the last measurement reset that contained the AIS pattern.

Yellow Alarm

A tally of the number of one-second intervals since the last measurement reset that contained the yellow alarm pattern.

Error Free Seconds

A tally of the number of one-second intervals that were error free since the last measurement reset.

Errored Seconds

A tally of the number of one-second intervals since the last measurement reset that contained errors such as BPVs and frame errors.

Severe Errored Seconds

A tally of the number of one-second intervals since the last measurement reset that were severely errored.

Available Seconds

A tally of the number of one-second intervals since the last measurement reset that were available for service.

Unavailable Seconds

A tally of the number of one-second intervals since the last measurement reset that were unavailable for service.

Degraded Minutes

A tally of the number of one-second intervals since the last measurement reset that were degraded.

Slip Rate

The percent ratio of frames cycle slips of the incoming signal, relative to the slip reference choice on the setup menu, since the last measurement reset.

Peak +Wander

The peak amount of positive wander, measured in bit intervals, since the last measurement reset. Each peak wander interval of 193 qualifies as a frame slip.

Peak -Wander

The peak amount of negative wander, measured in bit intervals, since the last measurement reset. Each peak wander interval of 193 qualifies as a frame slip.

T1 Analyzer

Measurement Results

+Frame Slips

A tally of the number of positive frame slips that occurred since the last measurement reset.

-Frame Slips

A tally of the number of positive frame slips that occurred since the last measurement reset.

Bit Errors

A tally of the number of bit errors that occurred since the last measurement reset.

Bit Error Rate

The percent ratio of bit errors to total bits transmitted since the last measurement reset.

Pattern Sync Loss

A tally of the number of times the pattern detector lost synchronization since the last measurement reset.

Test Data Rate

The measured data rate of the bit stream.

Testing and Fault Mitigation


The complexity of T1 testing certainly parallels or possibly exceeds that of RF tests at a cell site. Shadowing efforts and customer expression have shown that most cell site technicians reduce the complexities of backhaul T1 testing down into a series of well-defined steps. These tests are often not comprehensive, but are often sufficient to determine the continuity of a T1 circuit with a high degree of confidence. The test sequence is often developed by an experienced technician and is determined by finding the shortest path to an adequate measurement on a particular piece of readily available equipment. T1 testing often involves one technician on each end of a circuit. In the case of wireless, the technician at the switch end, very experienced at backhaul testing, is often working with a field technician who has a broader-based set of knowledge and is often less experienced in backhaul testing. The switch technician quickly develops a test procedure that involves the smallest number of verbal instructions to the field technician.

T1 Facility Summary

This next section describes the elements in a typical T1 backhaul facility. Based on this information, the next section shows typical fault conditions and what procedures are typically followed to restore service to the T1 span.

With almost no exception all circuits leased from the TELCO are routed through at least one central office facility. If this were not the case, planning and managing the repeaters needed for T1 transmission would be an onerous task. Repeater facilities are need to be spaced at a distance of 6000 feet (about 1.8 km) and generally contain slots for multiple repeater units. Figure 18-7 shows a typical circuit layout.

Figure 18-7 Typical T1 Circuit Layout



The following definitions apply:

Central Office: This is usually located at the geographic center of a particular service area. It is normally a building that contains the switching equipment and cable cross-connect facilities. Although this diagram shows a single central office, each end is often served by a separate central office. Facilities exist at the central office to accommodate remote testing and monitoring of T1 facilities.

Field Repeater: Repeaters are necessary when the customer is located beyond 6000 feet (about 1.8 km) from the central office. Multiple repeaters are necessary when the span exceeds 12000 feet. Most commercial customers are located within 12000 feet (about 3.6 km) of the central office. The repeaters are powered from the central office. Typically 90 volts is provided between the center-taps of the transmit and receive transformers. A particular repeater can be looped back by applying a specific loop-back tone. Often a label affixed to the cabinet denotes the loop-back tone. This may look like "FLTR A" or "FLTR B".

NIU: A device provided by the TELCO that contains the necessary equipment to provide the expected electrical levels to the customer. This device may be active and the serves as the customer demarcation (demark) point. When this device is active it can be looped back by applying the proper loop-back code. The customer is

T1 Analyzer

Measurement Results


responsible for equipment beyond this point.

CSU: A customer provided unit that is required by the TELCO as part of the tariffed service agreement. This device may be looped back applying a specific loop-back code.

Isolating Faults with Alarm and Errors:

Elements in a T1 facility are subject to failure. The most common failure is due to inadvertent cable dig-ups. Fault conditions cause errors and errors cause alarms. The alarms are often remotely monitored and can be observed by test equipment attached to the circuit. The most common alarm is the Alarm Indication Signal (AIS), also known as a 'Blue Alarm'. This alarm can be generated by a network element that not functioning or is receiving no signal. A CSU that is not receiving a signal (from the end-equipment) might generate an AIS depending on its configuration. When the CSU at the distant end sees AIS from the network it responds by sending a 'Yellow Alarm' back to the network. Figure 18-8 shows a typical circuit layout.

Figure 18-8 (Blue) and Yellow Alarm Diagram



The CSU is a customer-supplied device. The Network Interface Unit (NIU) is provided by the network supplier. It may be a simple passive device with terminals or an advanced electronic package such as an optical to copper interface. Some NIU devices sense the presence or absence of the CSU and, if absent, send a Customer Disconnect Indication (CDI) toward the network.

Isolating Faults Using Test Equipment:

Test equipment can be used to generate and monitor alarms and errors. Test equipment is connected to the T1 facility in a variety of ways. Bantam jacks are often available on the equipment. When the plug is inserted into the jack the circuit is interrupted. Sometimes a monitor jack is available. When a plug is inserted into the monitor jack the circuit is not interrupted and a -20 dB signal is available at the jack. When none of these is available, the signal may be monitored at a connection block, sometimes referred to as a “punch-down block”. The “T1 Facility Access Methods” table below describes the three typical access methods.

T1 Facility Access Methods

Access method	Test set configuration	Notes
Test Jacks	Terminated	Circuit is broken when plug is inserted into jack. The test equipment is normally set to “Terminate” and provides 100 Ohm termination.
Monitor Jacks	Monitor	The circuit is not interrupted when the plug is inserted into the jack. The actual signal is available at a level 20 dB lower than the original. The test set normally set to “Monitor” provides a 100 Ohm termination and expects the signal to be 20 dB down from what is usually expected.
Direct Connection to “Punch Down Block”.	Bridged	The circuit is not interrupted in this mode. The test set impedance is greater than 1000 Ohms so that the circuit is minimally affected. Test set is set to “Bridged”

WARNING

The following table describes the typical levels encountered in a T1 circuit. It is important to remember that 90 volts DC may exist between the transmit and receive pair. This voltage can be lethal!

Typical Levels Encountered in a T1 Circuit

0 dBdsx	6 Volts peak to peak
-7.5 dBdsx	2.53 Volts peak to peak
-15 dBdsx	1.07 Volts peak to peak

More Information About T1 Testing

Detailed Loop Mode and Auto Configuration Descriptions

Remote CSU/NIU Loop Mode

At each end of a T1 facility there is a Channel Service Unit (CSU) and possibly a Network Interface Unit (NIU). Both of these units have the ability to be remotely “looped up” by sending the proper loopback code. This can be done either by sending the expected loopback code in-band or out-of-band. When sent in-band, a particular pattern is transmitted on every slot for 5 seconds. When the code is sent out-of-band, the pattern is sent as part of the framing bit stream and is referred to as ‘data-link’. It is important to note that once a CSU or NIU is remotely placed into loopback, it remains in that state. When a CSU or NIU is in a loopback state, that unit will loop the in-band loop code back to the near end. If the near end CSU sees the in-band loopback code repeated from the far end CSU then both CSU units can become locked in a loopback state. The test set is designed to minimize this possibility. However, you should take precautions to prevent this from happening and be aware of this potential situation. Some CSU/NIU units do not respond to in-band loop codes when they are configured for ESF. In general, NIU loop codes will be blocked at the central office.

Figure 18-9

Flow Diagram of In-band Loop-up Code Originating from the Test Set






Figure 18-10 **Flow Diagram of In-band Loop-down Code Originating from the Test Set**




The flow of events differs when the out-of-band method of loopback is selected. In this case, loopback can occur within 16 ms, and therefore it is not possible to determine if a pre-existing loop exists.

Figure 18-11 Flow Diagram of Out-of-band Loop-up Code Originating from the Test Set



Please note that $2^{15} - 1$ (2047) pattern is used because it is normally used for fractional T1 testing and has a low probability of being present on the full T1.

Figure 18-12 Flow Diagram of Out-of-band Loop-down Code Originating from the Test Set




Please note that $2^{15} - 1$ (2047) pattern is used because it is normally used for fractional T1 testing and has a low probability of being present on the full T1.

Auto Configuration Flow Diagram

Selecting **Auto Config** causes the test set to analyze the incoming T1 signal and align the setup choices to that signal. If the incoming data pattern is not recognized then “NA Live Data” is displayed and the pattern selected on the setup screen will remain unchanged. If B8ZS codes are detected then this condition will be indicated and the line code parameter will be set accordingly. If setup was configured for B8ZS prior to selecting **Auto Config** and the pattern detected does not have sufficient zeros density to warrant B8ZS then “NA” will be displayed and the line

code choice in the setup screen will remain unchanged. Finally, the framing format is detected, displayed and selection changed accordingly on the setup screen.

• **Flow Diagram for Auto Configuration**



Terminology

CRC:

To an observer, the data on a live T1 Circuit appear to be random. Fortunately there is a way to perform limited testing when the circuit is designed for Extended Super Frame (ESF) format. A portion of the frame bits are reserved for a Cyclic Redundancy Checksum (CRC) sequence that can be monitored for performance. Simply stated, the CRC bits are calculated on the transmit end and inserted as a pattern on the frame bit. The CRC pattern depends on the pattern of other bits transmitted by the T1 Circuit. The receiving end also computes this pattern and compares it with the CRC that was computed and sent by the transmitting end. Since both ends use the same rules for computing the pattern, the CRC bits will be identical when all the bits involved in the computation agree. The CRC check provides good insight into the end-to-end integrity of the T1 Circuit and should be used in conjunction with other tests that can help determine what the cause of the CRC failure might be.

BPV:

The electrical signals on a properly functioning T1 circuit conform to the specification set forth in the standards. The standards specify that the presence of a voltage indicates a data '1' and the absence of a voltage represents a data '0'. Each occurrence of a data one produces a voltage for half a bit interval that is the opposite polarity of the previous bit, hence the name Alternate Mark Inversion (AMI). The alternating nature of the signal ensures that the average DC voltage is zero, allowing it to be transformer coupled. Transformer coupling ensures a high degree of common mode rejection to the equipment that processes T1 signals.

Bipolar 8 Zero Substitution (B8ZS) is an exception to AMI that replaces runs of 8 consecutive zeroes with a special code that violates the AMI rules. It allows greater flexibility of data patterns by enhancing repeater synchronization by increasing pulse density thereby providing greater throughput.

When the electrical signal does not adhere to the alternating nature of the waveform specification a BiPolar Violation (BPV) has occurred. This can happen for a number of reasons, many of which are outside the control of the wireless technician. One cause may be from electrical noise radiating from florescent lamps, motors, or spark plug ignition circuits coupling into the copper lines that carry T1 signals. Shielded cable is often chosen for T1 circuits to minimize electrical interference. This shield must be grounded to be effective. When the cable is spliced or terminated the shield on both cables should be connected together. Often the transmit and receive signals are routed in separate cable bundles.

The receive signal is often much weaker than the transmit signal. Cross talk in the cable pairs can cause the transmit signal to appear on the receive pair and interfere with the low-level receive signal.

Frame:

Pulses streaming in a T1 circuit would be meaningless if there was no way to organize them in a meaningful structure. In T1, bits are organized into 192 bit frames with an associated single frame bit for a total of 193 bits. The frame bit pattern has unique characteristics that allow the receiving end to recognize it and to synchronize to it. D3/D4 framing patterns have the ability to identify a super frame of 12 sub-frames. Extended Super Frame (ESF) has the ability to identify a super frame of 24 sub-frames and include a data link channel and Cyclic Redundancy Checksum (CRC) check bits.

W-CDMA or W-CDMA (with HSDPA) Analyzer

- “Using the W-CDMA or W-CDMA (with HSDPA) Analyzer” on page 536
- “Selecting a Reference” on page 537
- “RF Connections” on page 538
- “Preparing to Make W-CDMA or W-CDMA (with HSDPA) Tx Analyzer Measurements” on page 539
- “Performing a Basic W-CDMA or W-CDMA (with HSDPA) Transmitter Measurement” on page 540
- “Multiple-View Display” on page 542
- “Setting the Display Options” on page 548
- “Codogram Display” on page 549
- “Performing a Codogram Measurement” on page 552
- “Displaying the Active Code Channel Table” on page 553
- “Setting the Channel or Frequency Step” on page 556
- “Setting the Scrambling Codes” on page 556
- “Setting the Display Reference Level” on page 557
- “Compensating for the Loss or Gain of External Cables, Attenuators, and Preamps” on page 558
- “Setting Average, Sweep, and Restart” on page 560
- “Setting the Active Channel Threshold Level and Auto Threshold Level” on page 562
- “Setting Measurement Time” on page 563
- “Enabling PICH and S-CCPCH” on page 564
- “Setting the EVM Mode” on page 565
- “Setting the IF Equalizer” on page 565
- “Adding a Marker” on page 566
- “Metrics Provided by the W-CDMA or W-CDMA (with HSDPA) Analyzer” on page 568
- “Interpretation of Measurement Results” on page 571

Using the W-CDMA or W-CDMA (with HSDPA) Analyzer

W-CDMA and W-CDMA (with HSDPA) transmitter measurements verify proper transmitter performance of a Base Station (commonly referred to as a Node B) and are typically made with the base station out-of-service in test mode. Non-intrusive measurements can also be made on a live network if a monitor or test port is present. This is usually a coupled port, with power levels that are –20 or –30 dB down from the main Tx output power RF path. The power levels on the main Tx output power path can exceed 10 Watts. Important metrics include:

- Frequency Error
- Error Vector Magnitude (EVM)
- Peak Code Domain Error (PCDE)
- Channel Power
- Carrier Feedthrough
- Code Domain Noise Floor
- CPICH Power
- Delta Powers between CPICH (Common Pilot Channel) and P-CCPCH (Primary Common Control Physical Channel), S-CCPCH (Secondary Common Control Physical Channel), PICH (Paging Indicator Channel), P-SCH (Primary Synchronization Channel) and S-SCH (Secondary Synchronization Channel).

These latter measurements are all performed in the “Code Domain” and are sometimes referred to as Code Domain Power (**CDP**) measurements.

One of the defining elements of a 3G system is high-speed data transmission. The 3GPP standard allows for multiple data rates depending on the application. This flexibility requires complex processing in both the transmitter and receiver to retain information quality and still transfer a variety of user information in the noisy spread spectrum environment. The CDP measurements allow you to quickly verify the operation of a 3GPP transmitter. In addition, it can give a high-level evaluation of modulation quality, channel power, and signal-to-noise in the code domain.

High Speed Downlink Packet Access (**HSDPA**) was added in Release 5 of the 3GPP specifications. HSDPA was added in an attempt to make the W-CDMA systems more efficient for packet data applications by increasing peak data rates and reducing packet latency. You will need *Option 245 - HSDPA Analyzer & HSDPA*

Over Air Test to make HSDPA-specific measurements, although other W-CDMA measurements can still be made without this option installed on your test set.

This chapter covers *Option 240 - W-CDMA Analyzer* installed on its own, and *Option 240 - W-CDMA Analyzer* installed together with *Option 245 - HSDPA Analyzer & HSDPA Over Air Test*.

Where differences exist between using *Option 240 - W-CDMA Analyzer* installed on its own, and using it in conjunction with *Option 245 - HSDPA Analyzer & HSDPA Over Air Test*, these differences are usually called out in this document. Where the differences are small, however, they are not called out.

Example of a difference that is not called out: a title on a menu can be either *W-CDMA Anl.* or *HSDPA Anl.* depending on whether or not *Option 245 - HSDPA Analyzer & HSDPA Over Air Test* has been installed. The keys under that menu do not change, and only the title of the menu changes. Such differences are not called out here.

Selecting a Reference

The E7495A/B supports three different types of frequency reference input for making frequency measurements. These are listed in the table below.

E7495A/B Reference Inputs

Reference	Type of reference provided	Notes
GPS Ref	Time and Frequency	Strongly recommended – provides accurate and network-independent measurements
Ext Ref	Frequency Only: 2.048 MHz, 10 MHz or 13 MHz	Recommended if no GPS signal is obtainable. Will only measure frequency and frequency error relative to BTS reference
Int Ref	Frequency Only: Uses the test set's internal oscillator	Only recommended if no other reference signal is available. You must typically be within 750 Hz of the base station operating frequency when entering frequency or channel information in order for the test set to be able to lock to the Tx signal.

It is strongly recommended that you use the Global Positioning System (GPS) signal

W-CDMA or W-CDMA (with HSDPA) Analyzer

Using the W-CDMA or W-CDMA (with HSDPA) Analyzer

as the frequency reference for the W-CDMA and the W-CDMA (with HSDPA) Tx measurements because it provides an independent reference for measuring the operating frequency of the base station. A GPS antenna must be connected to the GPS input of the test set, and the antenna must have a clear view of the sky in order for the GPS to lock. If a GPS signal cannot be obtained, you can use the frequency reference provided by the base station to perform the measurement.

The E7495A/B test set supports all of the following frequency references and time references:

- Frequency and Time - GPS (External antenna supplied)
- Frequency and Time - External Even Second Pulse
- Frequency only - Internal Reference
- Frequency only - External 1.000 MHz (E7945B only)
- Frequency only - External 2.048 MHz (E7945B only)
- Frequency only - External 4.950 MHz (E7945B only)
- Frequency only - External 10.000 MHz
- Frequency only - External 13.000 MHz (E7945B only)
- Frequency only - External 15.000 MHz (E7945B only)
- Frequency only - External 19.6608 MHz

If you use the frequency reference provided by the base station, keep in mind that the frequency error metric will only be measuring the error relative to the base station reference signal, and not relative to absolute frequency and time. You will not be able to determine if the base station frequency is aligned with the other base stations in the network. Since the GPS provides an independent reference, the frequency error metric can be used to determine if the base station frequency is offset from the rest of the network.

RF Connections

For the RF connection, you can connect the E7495A/B RF Input Port either directly to the Tx RF output of the base station, or to the coupled output port on the base station when you are making W-CDMA or HSDPA transmitter measurements. In this way, the base station can remain on-air (in-service) while Tx measurements are being made. If the RF Input port of the instrument is connected directly to the Tx RF output, then the base station (or at least that sector) must be taken out of service.

CAUTION

The maximum power for the RF In (Port 1) and RF Out/SWR (Port 2) ports is

+20 dBm (100 mW). When using the 8481A/8482A or N8481A/N8482A with Option CFT Power Sensors, the maximum input power applied to the Power Sensor is +24 dBm (300 mW). When using the 8481D Power Sensor, the maximum input power is +20 dBm (100 mW). When directly coupled to a base station (BTS) or Access Network (AN), the test set can be damaged by excessive power applied to any of these three ports.

To prevent damage in most situations when you directly couple the test set to a base station, use the high power attenuator between the test set and the BTS.

NOTE

Most base stations also provide a coupled output, which is a port used for testing. This output port is usually in the form of a small RF connector on the front of the base station rack, located on or near the high power amplifier module, and is usually labeled “Test Out,” “Monitor Out,” “Tx MON” or “TEST.” Be sure to check the specifications provided by the base station's manufacturer prior to connecting the E7495A/B test set. This enables you to determine the output power range of this test port, and therefore avoid the possibility of damaging the test set.

Preparing to Make W-CDMA or W-CDMA (with HSDPA) Tx Analyzer Measurements


The first step in measuring W-CDMA transmitter performance (with or without HSDPA) is to take the base station out of service. In-service measurements are also possible, as long as you either use an external coupler, or you use a test port as described in the note above. The next step is to choose the type of time reference available. The measurement configuration depends upon the type of time reference you choose. If you use GPS as your time reference, you can also use it to verify the frequency independently.

You must know the channel or carrier frequency of the transmitter to be analyzed. Additionally, each base station sector has a unique scrambling code that is transmitted to mobiles in that sector. These scrambling codes can be detected automatically by the test set, or can be entered manually if desired.

Performing a Basic W-CDMA or W-CDMA (with HSDPA) Transmitter Measurement

Step	Notes
1 Mode	
2 [Tx Analyzer]	
3 [W-CDMA Analyzer] or [W-CDMA (w/ HSDPA) Analyzer]	The menu key label changes to include “(w/ HSDPA)” if you have <i>Option 245 - HSDPA Analyzer & HSDPA Over Air Test</i> installed on your test set.
4 Setup the channel standard. a. [Chan Std] b. Highlight the channel standard you want using the up and down arrow buttons. c. [Select]	
5 Use the [Units] menu key to select Freq or Chan . Select Chan for this example.	Each time you press this softkey, the selected option changes.
6 Setup the channel. a. [Channel] b. Enter the channel using the numeric keypad. c. [Fwd] or [Rev]	
7 Setup the scrambling codes. a. [Scramble C...] b. [Auto] or [Manual]	Each time you press this softkey, the selected option changes. Auto takes the strongest code. Manual lets you specify the scrambling code.


Step	Notes
8	Setup the frequency/time reference.
a.	[Fr/Time Ref]
b.	[GPS] or [External Even Second] for frequency and time reference. [Internal Reference] or any other [External...] for frequency reference only
9	Connect to the base station.



Connections for out of service W-CDMA or W-CDMA (w/ HSDPA) measurements with GPS receiver as timing reference

W-CDMA or W-CDMA (with HSDPA) Analyzer Using the W-CDMA or W-CDMA (with HSDPA) Analyzer

Step	Notes



Connections for in service W-CDMA or W-CDMA (w/ HSDPA) measurements with GPS receiver as timing reference

NOTE

During a W-CDMA or W-CDMA (with HSDPA) Analyzer measurement, a yellow triangle symbol may temporarily appear beside “GPS” in the lower right. The yellow triangle indicates that the test set is re-synchronizing with the GPS pulses. Once the test set is synchronized, a green dot appears in place of the triangle. If the GPS is unavailable, a red X appears. If this happens, you must choose another reference.

Multiple-View Display

The W-CDMA and W-CDMA (w/ HSDPA) Tx analyzer multiple-view screens are divided into two sections in both the Zoom View (default—[Figure 19-1 on page 545](#) and [Figure 19-2 on page 546](#)) and in the Full View ([Figure 19-3 on page 547](#) and [Figure 19-4 on page 548](#)). The upper portion contains three graphical views of your data, and the lower portion contains the measurement metrics.

The upper, graphical portion shows the following three views:

- In Full View, the top-left graph shows the power in the lower 256 of the 512 channels (OVSFs or spread codes). The remaining 256 channels are shown in the lower left graph.

In Zoom View, the top-left graph shows all 512 channels (OVSFs or spread

codes). A light blue section link is the bottom bar of the upper graph to the whole of the lower graph (described below). The red line across the graph represents the active channel threshold. The traffic channel displays in orange color, the rest are in the color shown in the control view.

- In Full View, the lower-left graph shows the upper 256 of the 512 channels (OVSFs or spread codes).

In Zoom View, the lower-left graph shows the power in the section highlighted in light blue in the top-left graph. This is a selection of either 32, 64, or 128 codes.

- The top-right graph (Control View) shows the power in the control channels (see Table below). The PICH and the S-CCPCH channels are only displayed if you have enabled them using the Setup menu. For further details, see [“Enabling PICH and S-CCPCH” on page 564](#).

The bottom portion (Metrics View) displays the current measurement metrics.

NOTE

In W-CDMA or W-CDMA (with HSDPA), the P-SCH and S-SCH are not assigned spread codes and therefore do not appear in the code domain power display (Full View). The E7495A/B features a control channel graph view (Control View) for these two Sync channels to measure power only, since there is no spread code associated with these channels. They have special non-orthogonal scrambling codes and are only actually **On** 10% of the time


Acronym	Full Name	Viewable in Which Display Area?	<i>Option 245 - HSDPA Analyzer & HSDPA Over Air Test Required?</i>
CPICH	Common Pilot Channel	Visible in all views (red bar)	Not required
DPCH	Dedicated Physical Channel/Dedicated Pilot Channel	Visible ONLY in the Full View and in the Zoom View (orange bars). Not Visible in the Control View	Required. You will not be able to see this channel unless you have <i>Option 245 - HSDPA Analyzer & HSDPA Over Air Test</i> installed.

W-CDMA or W-CDMA (with HSDPA) Analyzer
Using the W-CDMA or W-CDMA (with HSDPA) Analyzer

Acronym	Full Name	Viewable in Which Display Area?	<i>Option 245 - HSDPA Analyzer & HSDPA Over Air Test Required?</i>
HS-PDSCH (HSDPA signals only)	High Speed Physical Downlink Shared Channel NOTE: You can have QPSK and QAM versions of HS-PDSCH	Visible ONLY in the Full View and in the Zoom View (Pale yellow bars). Not Visible in the Control View	Required. You will not be able to see this channel unless you have <i>Option 245 - HSDPA Analyzer & HSDPA Over Air Test</i> installed.
P-CCPCH	Primary Common Control Physical Channel	Visible in all views (yellow bar)	Not required
PICH	Paging Indicator Channel	Visible in all views (light blue bar), but only if activated (for further details, see “Enabling PICH and S-CCPCH” on page 564)	Not required
P-SCH	Primary Synchronization Channel	Visible ONLY in the Control View (blue bar)	Not required
S-CCPCH	Secondary Common Control Physical Channel	Visible in all views (green bar), but only if activated (for further details, see “Enabling PICH and S-CCPCH” on page 564)	Not required
S-SCH	Secondary Synchronization Channel	Visible ONLY in the Control View (purple bar)	Not required

Figure 19-1

The Multiple-View Zoom Display Without an HSDPA Signal or Without Option 245 - HSDPA Analyzer & HSDPA Over Air Test Installed



NOTE

The Multiple-View Zoom Display (above) is virtually identical for both of the following situations:

- Option 245 - HSDPA Analyzer & HSDPA Over Air Test has not been installed
- Option 245 - HSDPA Analyzer & HSDPA Over Air Test has been installed, but there is no HSDPA signal to display

The only differences you might notice are cosmetic only. There is a change to the description above the left menu, and there is a change to the measurement description at the bottom of the screen.

W-CDMA or W-CDMA (with HSDPA) Analyzer Using the W-CDMA or W-CDMA (with HSDPA) Analyzer

Figure 19-2

The Multiple-View Zoom Display With Option 245 - HSDPA Analyzer & HSDPA Over Air Test and HSDPA Signal Present





Figure 19-3 The Multiple-View Full Display Without an HSDPA Signal, or Without Option 245 - HSDPA Analyzer & HSDPA Over Air Test Installed




NOTE The Multiple-View Full Display (above) is virtually identical for both of the following situations:

- Option 245 - HSDPA Analyzer & HSDPA Over Air Test has not been installed
- Option 245 - HSDPA Analyzer & HSDPA Over Air Test has been installed, but there is no HSDPA signal to display

The only differences you might notice are cosmetic only. There is a change to the description above the left menu, and there is a change to the measurement description at the bottom of the screen.

Figure 19-4 The Multiple-View Full Display With Option 245 - HSDPA Analyzer & HSDPA Over Air Test and HSDPA Signal Present



Setting the Display Options

The display options enable you to zoom in on portions of the graph, or to see the entire trace at once.

Step	Notes
1	[Display]

Step	Notes
2 On [View] select [Zoom] or [Full].	If you are displaying Zoom view and select Full view, the display changes the top-left and bottom-left graphs to show the first 256 codes in the top graph, and the second 256 codes in the bottom graph. If you select Zoom, the two keys, Position and Width (see Steps 3 and 6 below), become available.
3 [Position]	When you are in Zoom view, this option changes the starting point (spread code) of the section of the full view (upper graph) that the Zoom view (lower graph) will expand for more detailed analysis.
4 Enter the position using the numeric keypad.	
5 [Enter]	
6 On [Width] select [32], [64], [128], or [256].	In Zoom view, smaller numbers selected with this option correspond to narrower zoom windows on the full view. If you select 32 for example, you will have the minimum window and maximum zoom. You will also see channel information displayed below each active channel. The data displayed is the spreading factor used by that channel and its spread code or OVSF number.

Codogram Display

This view provides a history of the spectrum. The codogram plot rises over time until it fills the graphical section of the display. Your most recent data appears at the bottom of the display, and your oldest data (several minutes ago to several hours ago, depending on your settings) appears at the top of the display. In this way, you can clearly see the changes in power that occur over a period of time. You can use it to:

- see traffic channels as they initiate and terminate,

W-CDMA or W-CDMA (with HSDPA) Analyzer

Using the W-CDMA or W-CDMA (with HSDPA) Analyzer

- track traffic channel call levels over time.

The W-CDMA or W-CDMA (with HSDPA) Tx analyzer Codogram screen is divided into 3 sections in the Zoom view (default—[Figure 19-5 on page 551](#)) and 4 sections in the Full view ([Figure 19-6 on page 552](#)) as follows:

- **Zoom and Full views:** The lower-right graph (**Code Domain Trace view**) shows the power in all 512 OVSF (Orthogonal Variable rate Spread Factor) Code Channels. For display details, refer to “[Multiple-View Display](#)” on [page 542](#).
- **Zoom view:** The left graph (**Codogram view**) provides a display of data captured over time. The OVSF codes are shown on the x-axis and correspond to the light blue highlight on the Code Domain Trace view. The OVSF codes selected for your Zoom View are determined by the **Position** setting, which sets the lowest (or left) OVSF code, and by the **Width** setting, which sets the number of OVSF codes displayed. For example, with **Position** set to 400, and **Width** set to 32, your Zoom View will show codes 400 to 431, that is, from Position 400 for a Width of 32 codes.

You can change the time interval to allow longer spectrum history. The color corresponds to the OVSF channel strength.

- **Full view:** The top-left graph (**Codogram view**) shows the power in the first half of the OVSF channels (SF512 channels 0 - 255). The lower-left graph shows the power in the other half of the channels (SF512 channels 256-511). Both graphs provide a display of data captured over time.

You can change the time interval to allow longer spectrum history. The color corresponds to the OVSF channel strength.

- **Zoom and Full views:** The top-right graph (**Color Legend**) provides a color vs. power legend to help you interpret the power level in the Codogram.

The **Update Interval** is the interval, measured in whole seconds, between successive records displayed on the codogram. In other words, if you set the update interval to 5 seconds, the codogram display will not update until the after the first complete measurement following a gap of five seconds. Alternatively, you can set the update interval to provide the maximum data collection speed by pressing [Max Speed], or by setting the update interval to 0 (zero) seconds.

NOTE

It is not always possible for the analyzer to match the update interval you specify. It is possible, for example, to set your update interval to zero seconds (the maximum speed), and then to find that the analyzer can not update any faster than once every two seconds.

The frequency indicator is at the bottom right corner of the screen, the time reference indicator at the bottom left. For each indicator the text indicates which reference you have chosen. A green LED indicates a locked condition. A red “X” indicates an unlocked condition.

Figure 19-5

The Codogram Zoom Display





Figure 19-6

The Codogram Full Display



Performing a Codogram Measurement

Step	Notes
1 [Display]	
2 [Codogram]	This displays the menu that controls the appearance and behavior of the codogram display.
3 On [Codogram] select On or Off .	Each time you press this key, the codogram state switches between On and Off . When you set [Codogram] to On, [Reset Codogram], [Update Interval] and [Palette] become active.

Step	Notes
4 [Reset Codogram]	This restarts the data capture for the Codogram. You may see the screen freeze for a few seconds before the display starts plotting data again.
5 If desired set the update interval: a. [Update Interval] b. Enter the interval number of seconds using the numeric keypad. c. Select [sec] or [Max Speed].	Allows you to set the update interval to 0, 1, or more seconds. Alternatively, you may set it to automatically determine the update interval that provides the maximum data collection speed. If you need to return to the automatically determined maximum display update rate, you must press [Update Interval] followed by a numeric keypad key to access [Max Speed].
6 If desired set the display color: a. [Palette] b. Select [Full Color] or [Grayscale].	The color/grayscale top and bottom mappings are determined by the Ref Level and Scale/Div settings. To change the mapping, go to [Level/Location] and change [Ref Level] and [Scale/Div].

NOTE

The key labelled “Update Interval” was labelled “Capture Interval” in earlier versions of the software (A.04.00 or earlier). The way the key works has not changed. Only the key label has changed to clarify its function.

Displaying the Active Code Channel Table

This display option enables you to look at a numeric and textual description of all the active code channels in your signal. The table of active channels is displayed on the left of the graphic area of the screen. The control channel chart, and a small graphic display of all 512 channels, are both displayed to the right of the table.


Step	Notes
1 [Display]	

W-CDMA or W-CDMA (with HSDPA) Analyzer
Using the W-CDMA or W-CDMA (with HSDPA) Analyzer

Step	Notes
2 [Active Code Ch Table]	When you press the Active Code Ch Table key, a fresh menu is displayed.
3 Press [Active Code Ch Table]	Each time you press this key, the selected option changes. Switching Active Code Channel Table On displays a table of all the active channels. For each active code you will see in the first column the channel's channel number, and its spreading factor (in parentheses). In the second column is a textual description of that channel. In the third column is its code domain power (CDP) in dBc. The CDP figure is accurate to one decimal place. The menu keys to navigate up and down the table also become active when the Active Channel Code Table is switched On. If you have previously positioned a marker on one of the active channels, this channel's entry in the table is highlighted with a yellow background (see Figure 19-7 on page 555 for an example).

Figure 19-7

The Active Code Channel Table Display (with Option 245 - HSDPA Analyzer & HSDPA Over Air Test Installed)



W-CDMA or W-CDMA (with HSDPA) Analyzer Measurement Settings

Setting the Channel or Frequency Step

You can set the channel or frequency step so you can quickly increment to the next channel or frequency using the up and down arrow buttons.

Step	Notes
1 [Chan Step] or [Freq Step]	This choice depends on the [Units] mode you are using.
2 Enter the desired channel or frequency step using the numeric keypad.	
3 [Enter]	Notice (and verify) the number you entered below the Chan Step or Freq Step text on the corresponding button.

Setting the Scrambling Codes

The E7495A/B has two ways to identify the scrambling code being used by the transmitter under analysis: an automatic detection mode, **Auto**, and a manually-specified mode, **Manual**.

- In **Auto** mode, the test set automatically detects the scrambling code present in the signal.
- In **Manual** mode, the scrambling code can be entered by you instead of being auto-detected by the instrument.

If the scrambling code is known, its value can be entered and the test set can decode and display the code domain power of the signal, even if no P-SCH and S-SCH are present (a CPICH must be present, however). In normal operating conditions, these synchronization channels are available, so the P-SCH and S-SCH are used by the E7495A/B (and W-CDMA or W-CDMA (with HSDPA) mobiles) to determine the

correct sequence of scrambling codes required to demodulate the DPCH channels.

Step	Notes
1 [Freq/Chan/Time Ref]	
2 [Scramble C...]	
3 [Auto] or [Manual]	Each time you press this softkey, the selected option changes. In Manual mode, you can enter a number using the keypad.

Setting the Display Reference Level

You can set the W-CDMA or W-CDMA (with HSDPA) Tx analysis display to show the power in each channel as either relative power (dB) or absolute power (dBm). The test set's default display mode is relative. In relative mode, the top horizontal line (top-most graticule) of the display represents the total power (channel power) in the 3.84 MHz bandwidth of that W-CDMA or W-CDMA (with HSDPA) signal being broadcast by the transmitter. It is always 0 dB in this mode since it is a relative measurement. The power in each channel is shown as a vertical bar, with its height expressed in dB relative to the total channel power.

If you set the reference level mode to absolute, then the top graticule in the display still corresponds to total channel power in the 5 MHz bandwidth. However, the reference level and all the power values of the vertical bars showing the power in each channel are now indicated with absolute power in dBm.

To set the W-CDMA or W-CDMA (with HSDPA) transmitter reference level (while in W-CDMA or W-CDMA (with HSDPA) Analyzer mode):

Step	Notes
1 [Level/Location]	
2 On [Reference] select Abs or Rel .	Each time you press this softkey, the selected option changes.

Compensating for the Loss or Gain of External Cables, Attenuators, and Preamps

The insertion loss of the test cable and high power attenuator must be compensated for to obtain accurate W-CDMA or W-CDMA (with HSDPA) power measurements, such as channel power. This process is called normalization and is described in [“Measuring Two Port Insertion Loss” on page 124](#).

The insertion loss of the test cable/attenuator combination is accounted for as the RF In Loss, which is an offset applied to the power measurements by the test set.

Similarly, the insertion gain of an external preamp must be compensated for to obtain accurate W-CDMA or W-CDMA (with HSDPA) measurements. Although an external preamp produces a gain rather than a loss, this is also compensated for using RF In Loss. To enter a gain figure for a preamp, you must enter a negative loss figure. For example, to enter a gain of 20 dB, you must enter “–20 dB” here.

Step	Notes
1 [RF IN Loss]	
2 Enter the RF In loss using the numeric keypad. Enter a negative number to indicate a gain.	If you are using a cable and attenuator connected to the base station power amplifier, enter the combined cable and attenuator RF In loss here. The RF In loss can be obtained by measuring the Insertion loss. See “Two Port Insertion Loss” on page 123. If you are using an external preamp and need to make an allowance for the preamp’s gain, enter the gain by using a negative number. Example of a loss: if you have to account for an external attenuation of 20 dB, enter “20 dB” here. Example of a gain: if your preamp has a gain of 12 dB, enter the negative figure “–12 dB” here. Note: If data had been previously entered in [RF IN Loss], that data will be lost and replaced by the value you enter here.
3 [dB]	

Setting Average, Sweep, and Restart

Setting the Sweep

You can select either continuous or single sweep. Continuous sweep provides repeated, ongoing measurements. Single sweep performs a single measurement that is repeated only when you push the Single button.

To set sweep:

Step	Notes
1 [Average/Sweep]	
2 [Continuous] or [Single]	Each time you press this softkey, the selected option changes.

Setting Averaging

You can choose to have averaging On or Off and to set the number of averages you want to take. Averaging only applies to the data, not the trace. When initialized, the Agilent E7495A/B defaults to running average:

- A running average computes the new result as the weighted sum of the last result and the new measurement. The last result is weighted by $(n - 1)/n$. The new result is weighted by $1/n$. Each new measurement produces a new result.

Averaging applies to the following measurement metrics and the control channel view only:

- Freq Error
- Noise Floor
- EVM
- PCDE
- Carrier Feedthrough
- Chan Pwr
- CPICH power
- all the delta powers

- Control Channel Graph

The following measurements are *never* averaged:

- CDP Trace
- Threshold

To set averaging:

Step	Notes
1	Set the number of averages. a. [Average] b. Enter the number of averages using the numeric keypad. c. [Enter]
2	Set averaging On or Off. a. [Average/Sweep] b. [Averaging] c. [Off] or [On]

NOTE

These two steps can be performed in any order. However, if you turn averaging on and a large number of averages has previously been set, there may be a delay before you can change number of averages.

Setting Restart

When you have averaging turned **On** and you are in **Continuous** Sweep mode, you can restart the averaging by pressing the Restart menu key. The Restart key has no effect if you are in **Single** sweep mode.

To restart averaging:

Step	Notes
1	[Average/Sweep]

Step	Notes
2 [Restart]	This key is unavailable or has no effect when Sweep is set to Single . To restart a Single Sweep measurement, press [Single].

Setting the Active Channel Threshold Level and Auto Threshold Level

The active channel threshold level is an advanced setting that can be set to indicate which code channels are considered active. Any code channels exceeding this power level are considered active traffic channels and any code channels below this power level are considered inactive (or noise). Those channels that are considered active, that is, channels that meet or exceed the threshold level, are indicated by the presence of their OVSF Code below the bar in the display. Inactive channels do not have their OVSF Codes displayed.

A horizontal red line on the screen represents the threshold. The test set can set this level automatically, or you can manually enter a value.

In Auto mode the threshold level moves as the noise fluctuates. The threshold level is set by the test set at an optimal offset above the average noise floor. In Auto mode, you can alter the Auto Threshold Offset. The recommended and default setting is 0 dB. A negative value moves the threshold lower (closer to the noise floor) and is a more aggressive setting that increases the likelihood of interpreting an inactive channel as active. A positive value moves the threshold higher (away from the noise floor) and is a more conservative setting that increases the likelihood of interpreting an active channel as inactive.

In Manual mode the threshold level is fixed and does not move as the noise fluctuates.

Setting the active channel threshold level:

Step	Notes
1 [Setup]	
2 On [Threshold] select Auto or Manual .	Each time you press this softkey, the selected option changes. If you choose Manual, you must enter the threshold you want using the numeric keypad, then press [dB].

Step	Notes
3 [Auto Thres Offset]	The default value is 0 dB. Optionally, you can enter a negative (more aggressive) or positive (more conservative) value, then press [dB].

NOTE

Knowing which inactive code channels are contributing the most noise to the overall W-CDMA or W-CDMA (with HSDPA) channel may provide clues to the source of noise, such as a bad channel card in the base station.

Setting Measurement Time

The Measurement Time setting allows you to alter the speed at which measurements are being made. Three choices exist: Slow, Medium, and Fast. The test set defaults to Medium. Slow measurement time provides a more accurate measurement at the expense of time. Fast measurement time provides a quicker measurement at the expense of accuracy. Medium measurement time strikes a balance between measurement speed and measurement accuracy.

Changes in measurement time, or measurement speed, are achieved by varying the amount of data used to plot the CDP trace, and by varying the type of frame alignment used. [Table on page 564](#) shows this.

Table 19-1 Slots and Frame Alignment at Different Meas. Speeds

Meas Time	Number of Slots	W-CDMA (HSDPA Off)	W-CDMA (HSDPA On)
Slow	2	Aligned to Scramble Sequence Frame (CPICH = 0)	
Medium	2	Random Slot	Aligned to the start of the next sub-frame boundary
Fast	2	Random Slot	Random Slot

NOTE

CDP measurements will only meet Agilent's published specifications when you are using either Medium or Slow measurement speeds.

Step	Notes
1 [Setup]	
2 On [Meas Time] select Slow , Medium , or Fast .	Each time you press this softkey, the selected option changes.

Enabling PICH and S-CCPCH

In 3GPP W-CDMA or W-CDMA (with HSDPA), two optional control channels are provided: S-CCPCH and PICH. These can have different spreading codes and spreading factors. For this reason, the E7495A/B only identifies them as PICH and S-CCPCH channels when enabled by you. The test set defaults to the disabled (off) state. In the default mode, the test set still shows the energy by assuming a spread factor of 512 in the Full view and Zoom view graphs. Either the actual spreading factor or spreading code must be entered manually before the test set will display the PICH or S-CCPCH parameters with their correct spread factors and OVSF codes.

To enable the PICH and S-CCPCH

Step	Notes
1 [Setup]	The same procedure is used for both settings. S-CCPCH is used in this example.
2 [S-CCPCH]	Each time you press this softkey, the selected option changes.

Step	Notes
3 On [S-CCPCH Enable], select [Off] or [On]	
4 [Spread Factor]	If you choose spread factor, you must press enter the spreading factor you want using the numeric keypad, then press [Enter].
5 [Channel]	If you choose channel, you must press enter the channel you want using the numeric keypad, then press [Enter].

Setting the EVM Mode

EVM Mode allows you to select either of the two EVM modes of measurements. The two modes available to you are **Composite** and **Pilot**.
Select Pilot to measure the EVM of the CPICH channel using Code Number 0 at Code Level 256. The SCH channels are included in the measurement, giving you a total of 10 symbols (one time slot).
Select Composite to measure the combined EVM of all the channels.

Step	Notes
1 [Setup]	
2 [EVM Mode]	Each time you press this softkey, the selected option changes. You can choose between Pilot and Composite .

Setting the IF Equalizer

IF Equalizer allows you to control how you use the test set’s in-built IF Flatness Equalizer. The IF Equalizer reduces the noise levels of your measurements, typically resulting in a CDP noise floor reduction of 2 or 3 dB, and an EVM noise reduction of about one percentage point.

NOTE The noise reduction effect of the IF Equalizer is not immediate, so it is best to allow

W-CDMA or W-CDMA (with HSDPA) Analyzer

W-CDMA or W-CDMA (with HSDPA) Analyzer Measurement Settings

your test set to settle by performing several sweeps first.

NOTE

Agilent Technologies recommends that you set Meas Time to Slow. If Meas Time is set to Medium or to Fast, there is insufficient time to collect enough data to generate an accurate equalization estimate. Press [Setup], then [Meas Time] to set your measurement speed.

Even with Meas Time set to Slow, you may see some instability for a short time until the test instrument has settled.

If you set IF Equalizer to **Run**, the data from the current data capture is used to generate an approximate correction for any IF slope. This correction is repeatedly averaged to remove the effects of noise.

If you set IF Equalizer to **Hold**, the correction applied is that from the last time Run mode was used. The test set will not update or adjust the correction being applied.

If you have not yet performed a measurement with IF Equalizer Status set to Run, there will be no correction data present in the test set, and no correction will be applied.

When IF Equalizer is **Off**, no attempt is made to correct any flatness error inherent in the test set.

Step	Notes
1 [Setup]	
2 [IF Eq Status]	Each time you press this softkey, the selected option changes. You can choose between Off (no flatness correction is applied), Run (flatness correction is continually revised and updated) and Hold (a fixed flatness correction is applied).

Adding a Marker

Markers can be used on traces to help you visually track up to four signals. Each marker has the following settings:

- **Type:** Provides three options, including:
 - **Off**

- **Normal** which places a diamond-shaped, colored marker, and a number from 1-4, on the trace.
- **Δ (Delta)** is associated with a normal marker. Therefore, a normal marker must exist prior to creating the Δ (delta) marker. The Δ (delta) marker displays the difference between the normal marker position and the Δ (delta) marker position. Only one Δ (delta) marker can be associated with a given normal marker. The normal marker must be active when Δ (Delta) is selected.
- **Marker to Peak:** Places the active marker on the plot of the code with the highest power level.
- **Marker to Next Peak:** Places the active marker on the next highest peak as measured from your current marker’s position.
- **Marker to Next Active Ch Left:** Places the active marker on the next active channel to the left of your current marker.
- **Marker to Next Active Ch Right:** Places the active marker on the next active channel to the right of your current marker.

To add a marker to a trace

Step	Notes
1	[Marker]
2	[Marker]
3	[1], [2], [3], or [4]
4	[Type]
5	[Off], [Normal], or [Δ (Delta)]
6	Locate the marker relative to the trace: • [Marker to Peak] • [Marker to Next Peak] • [Marker to Next Active Channel Left] or • [Marker to Next Active Channel Right]

Metrics Provided by the W-CDMA or W-CDMA (with HSDPA) Analyzer

This section contains descriptions of the individual W-CDMA or W-CDMA (with HSDPA) transmitter metrics in the Metrics view of the screen. For information on expected result values and possible causes of error if the expected results are not met, see [“Interpretation of Measurement Results” on page 571](#).

Frequency

Frequency is the selected transmitter operating frequency entered by you (or calculated from the channel number entered by you).

Freq Error (Frequency Error)

Frequency error, as set up in Controls, is the frequency difference between your transmitter's actual center frequency and the frequency (or channel) you entered.

Scramble Code

The Scrambling Code being measured (manual or auto). In W-CDMA or W-CDMA (with HSDPA), each Access Network (or BTS) output signal is scrambled by multiplying each of its data channels by a unique pseudo-noise (PN) code. In the W-CDMA specifications, this is referred to as a Scrambling Code.

Noise Floor

Noise Floor is the average power level of all the inactive channels.

Threshold

Threshold is the active channel threshold level and is an advanced setting that can be set to indicate which code channels are considered active. (For more information, see [“Setting the Active Channel Threshold Level and Auto Threshold Level” on page 562](#).)

EVM Pilot and EVM Comp (Pilot and Composite Error Vector Magnitude)

EVM is the measure of signal quality specified as a percent of noise to pure signal. It is the difference between the measured waveform and the theoretical modulated waveform (the error vector). EVM metrics are used to measure the modulation quality of a transmitter. The 3GPP standard requires the Composite EVM not to

exceed 17.5% for normal W-CDMA (defined as Test Models 1 and 4), and not to exceed 12.5% in the case of 16QAM HSDPA (defined as Test Model 5).

PCDE (Peak Code Domain Error)

PCDE takes the noise and projects the maximum impact it will have on all OVVSF codes. PCDE is the maximum value for the code domain error for all codes (both active and inactive).

In W-CDMA or W-CDMA (with HSDPA), specifically to address the possibility of uneven error power distribution, the EVM measurement has been supplemented with PCDE. The 3GPP standard requires the PCDE not to exceed -33 dB at a spreading factor of 256, but the Conformance Test adds in a Test Tolerance of 1dB. This gives a Conformance Limit for Peak Code Domain Error of -32 dB at a spreading factor of 256.

Carr Feedthru or Carr FT (Carrier Feedthrough)

Carrier Feedthrough is a result of the RF carrier signal feeding through the I/Q modulator and riding on the output circuitry without being modulated.

Chan Pwr (Channel Power)

Channel Power is the integrated power within a defined bandwidth. For W-CDMA or W-CDMA (with HSDPA) the channel bandwidth is 3.84 MHz. Channel Power measures the power the base station is transmitting across the entire 3.84 MHz W-CDMA or W-CDMA (with HSDPA) channel.

CPICH (Common Pilot Channel)

Common Pilot Channel (CPICH) is the channel that carries the scrambling code. The CPICH metric reports the power in this channel in dBc. By default, the CPICH Limits are set to Off. If you set CPICH Limits On, the default upper limit value is 0 dBc, and the lower limit value is -20 dBc.

NOTE

The CPICH default limits are set at a level suitable for catching only gross errors when field testing live signals. To perform conformance testing, you will need to set the limits to your own specifications. Conformance testing for Test Model 2 (TM2), for example, requires that the CPICH limits are set to ± 2.9 dB, that is, to -7.1 dB and -12.9 dB with a -10 dBc signal.

Control Channel Delta (Δ) Powers

The last column on the far right of the Metrics view shows the relative powers of the five control channels relative to the Common Pilot Channel. For example,

P-CCPCH is the amplitude difference between the CPICH and the P-CCPCH. In W-CDMA or W-CDMA (with HSDPA) systems, the transmit power of all the control channels can be set at different values relative to the CPICH. the five control channel Δ power metrics are:

- Δ P-CCPCH - primary common control physical channel
- Δ S-CCPCH - secondary common control physical channel
- Δ PICH - paging indicator channel
- Δ P-SCH - primary sync channel
- Δ S-SCH - secondary sync channel

Interpretation of Measurement Results

This section contains expected result values and possible causes of error if the expected results are not met.

Freq (Frequency)

If you are in the channel mode, verify that the correct channelization and channel number are set.

Freq Error (Frequency Error)

The frequency error of the analyzer should be <1 kHz. If it is not, check to ensure that the test set is performing a correct measurement. You can do this by reviewing the frequency reference settings for the test set (refer to [“Selecting a Reference” on page 537](#)).

Ensure that these settings are correct, and that the test set shows reference lock. Lastly, make sure the test set has been powered on, and has been locked for at least 15 minutes.

If the error is still occurring after performing the above procedures, you will need to check the Base Station equipment for a source of the error. You can also verify that the base station is malfunctioning by turning off its modulation hardware and performing a frequency measurement on the Base Station carrier signal in the spectrum analyzer mode of the test set (refer to [“Performing a Basic Spectrum Analyzer Measurement” on page 415](#)).

You can use the **Frequency Limits** setting to make your analyzer indicate automatically whether or not a signal has exceeded the pre-defined limits you set.

Scramble Code

If the Scrambling Code is not as expected, it could be due to an incorrect Base Station setting or to incorrect positioning of the test set. If the correct Scrambling code cannot be located, check the base station settings.

Noise Floor

An unexpectedly high noise floor could be due to interfering signals.

If you have not already done so, you can reduce the noise floor by activating the IF Equalizer (See [“Setting the IF Equalizer” on page 565](#).)

Threshold

If the **Threshold** is not as expected, check the following:

Check the Threshold settings to make sure they are correct. (See [“Setting the Active Channel Threshold Level and Auto Threshold Level” on page 562](#) for more information.).

- If the Threshold setting is Auto with no offset, it is an indication that there is a poor signal to noise ratio.
- Check the Channel Power to ensure the level is as expected.
- If the power level is good, look for EVM and PCDE problems.

EVM Pilot and EVM Comp (Pilot (CPICH) and Composite Error Vector Magnitude

An unexpectedly high EVM could be due to interfering signals, carrier feedthrough, transmitter I/Q modulator, or signal path problems.

If you have not already done so, you can reduce the noise floor by activating the IF Equalizer (See [“Setting the IF Equalizer” on page 565.](#))

PCDE (Peak Code Domain Error)

An unexpectedly high PCDE could be due to interfering signals, carrier feedthrough, transmitter I/Q modulator, or signal path problems.

Carr Feedthru (Carrier Feedthrough)

A good Carrier Feedthrough level is less than -25 dB. The 3GPP standard does not specify Carrier Feedthrough; however, this measurement provides an additional tool to troubleshoot the base station's transmitter.

In the frequency domain, Carrier Feedthrough can show up as an energy spike that can be seen on the spectrum analyzer by closely spanning into the top of the W-CDMA or W-CDMA (with HSDPA) signal. The effects of Carrier Feedthrough can also show up as higher noise levels on the Code Domain Power screen. Carrier Feedthrough can be caused by the lack of isolation across the mixer and cavity of the transmitter's I/Q modulator.

Chan Pwr (Channel Power)

If the Channel Power level is not as expected, check pilot dominance and the number of Scrambling codes visible. All visible sectors will contribute to channel power. Also, check Amplifier Capacity and Utilization as they could have exceeded the maximum capacity. A high power data call could be indicated by a very wide

and tall bar.

CPICH (Common Pilot Channel)

CPICH will vary with distance from the base station and clear line of sight to the antenna. If the CPICH is not as expected, check pilot dominance and base station settings (ratio to other control channels should be good).

Control Channel Delta (Δ) Powers

The Delta results should match the Base Station settings. If not, ensure the Base Station settings are as expected.

W-CDMA or W-CDMA (with HSDPA) Analyzer
Interpretation of Measurement Results

W-CDMA or W-CDMA (with HSDPA) Over Air

[“Using the W-CDMA or W-CDMA \(with HSDPA\) Over the Air Tool” on page 576](#)

[“Preparing to Make W-CDMA or W-CDMA \(with HSDPA\) Over the Air Measurements” on page 577](#)

[“Criteria for Making Valid Over the Air Measurements” on page 577](#)

[“Performing a Basic Over the Air Measurement” on page 579](#)

[“Displaying Location Information Using GPS” on page 581](#)

[“Setting Amplifier Capacity Metrics” on page 582](#)

[“Multiple-View Display” on page 583](#)

[“Setting the Display Options” on page 587](#)

[“Codogram Display” on page 588](#)

[“Performing a Codogram Measurement” on page 591](#)

[“Optional W-CDMA or W-CDMA \(with HSDPA\) Over the Air Measurement Settings” on page 593](#)

[“Adding a Marker” on page 606](#)

[“Metrics Provided by the W-CDMA or W-CDMA \(with HSDPA\) Over Air Measurement” on page 608](#)

[“Interpretation of Over the Air Measurement Results” on page 612](#)

Using the W-CDMA or W-CDMA (with HSDPA) Over the Air Tool

W-CDMA and W-CDMA (with HSDPA) over the air measurements provide a quick method of verifying W-CDMA or W-CDMA (with HSDPA) transmitter performance. These transmitter measurements can be made on a base station (commonly referred to as a Node B) from the convenience of your vehicle without taking the base station out of service. Over the air measurements are especially useful in maintaining hard-to-access cell sites such as pole top base stations. The W-CDMA Over the Air and W-CDMA (with HSDPA) options (*Option 250 - W-CDMA Over Air Test*, and *Option 245 - HSDPA Analyzer & HSDPA Over Air Test*) may also be used to measure signals at a coupled port on the transmitter.

High Speed Downlink Packet Access (**HSDPA**) was added in Release 5 of the 3GPP specifications. HSDPA was added in an attempt to make the W-CDMA systems more efficient for packet data applications by increasing peak data rates and reducing packet latency. You will need *Option 245 - HSDPA Analyzer & HSDPA Over Air Test* to make HSDPA-specific measurements, although other W-CDMA measurements can still be made without this option installed on your test set.

This chapter covers *Option 250 - W-CDMA Over Air Test* installed on its own, and *Option 250 - W-CDMA Over Air Test* installed together with *Option 245 - HSDPA Analyzer & HSDPA Over Air Test*.

Where differences exist between using *Option 250 - W-CDMA Over Air Test* installed on its own, and using it in conjunction with *Option 245 - HSDPA Analyzer & HSDPA Over Air Test*, these differences are usually called out in this document. Where the differences are small, however, they are not called out.

Example of a difference that is not called out: a title on a menu can be either *W-CDMA Ovr Air* or *HSDPA Over Air* depending on whether or not *Option 245 - HSDPA Over Air Test & HSDPA Over Air Test* has been installed. The keys under that menu do not change, and only the title of the menu changes. Such differences are not called out here.

For out-of-service W-CDMA (without HSDPA) transmitter measurements, the W-CDMA Tx Analyzer option (*Option 240 - W-CDMA Analyzer*) is recommended. For all HSDPA measurements, including out-of-service HSDPA transmitter measurements, the HSDPA option (*Option 245 - HSDPA Analyzer & HSDPA Over Air Test*) is recommended. For more information refer to “[W-CDMA or W-CDMA \(with HSDPA\) Analyzer](#)” on page 535.

CAUTION

To achieve valid over-the-air measurements, the test set must be stationary (not moving). An alternative is to make these measurements from a coupled port at the base station.

Preparing to Make W-CDMA or W-CDMA (with HSDPA) Over the Air Measurements

An important consideration when making W-CDMA or W-CDMA (with HSDPA) over the air measurements is your location relative to the base station. There must be no obstructions between your location and the base station antennas. Also, the GPS antenna must be able to “see” the satellites to obtain lock. You must know the channel or frequency and the Channel Standard of the W-CDMA or W-CDMA (with HSDPA) signal to be analyzed.

Once you have connected the proper antenna and filter to the test set, chosen a stationary location, and verified that you have a clear view of the base station antennas, you can perform W-CDMA or W-CDMA (with HSDPA) over the air measurements.

If this is the first W-CDMA or W-CDMA (with HSDPA) over the air measurement for this base station, you must find a location that meets the criteria for making a valid measurement. Your location must have a dominant pilot and very low multipath power. If you have made W-CDMA or W-CDMA (with HSDPA) over the air measurements at this location before and know it provides valid measurements, skip to [“Performing a Basic Over the Air Measurement” on page 579](#).

Criteria for Making Valid Over the Air Measurements

The first step in making valid W-CDMA (with or without HSDPA) over the air measurements is to identify a target base station to measure. Then, for your measurements to be valid, you must find a location near the target base station with an unobstructed view of the base station antenna and a sufficiently strong W-CDMA or W-CDMA (with HSDPA) signal. W-CDMA or W-CDMA (with HSDPA) over the air measurements will experience interference from other W-CDMA or W-CDMA (with HSDPA) signals on the same RF channel and from multipath echoes. The code domain power view measures two key parameters to indicate these effects:

- Pilot dominance—The difference between the useful energy of the strongest pilot channel and the combined energy of the lower energy active pilot channels (expressed in dB). Ideally, this value should be very large (> 18 dB).

W-CDMA or W-CDMA (with HSDPA) Over Air

Using the W-CDMA or W-CDMA (with HSDPA) Over the Air Tool

The E7495A/B test set includes up to six lower energy active pilots in the pilot dominance calculation.

NOTE

It is important to remember that the pilot dominance is always measured against the strongest signal. If you have specified your channel of interest manually, this channel might not necessarily be the strongest.

- **Multipath power**—The amount of power from the dominant pilot signal that is dispersed outside the main correlation peak, due to multipath echoes (expressed in dB). Ideally, this value should be very small (< 0.1 dB). **Multipath power** is the result of portions of the original broadcast signal arriving at the receiving antenna out of phase with the main power of the original signal. This can be caused by the signal being reflected off objects, such as buildings, or being refracted through the atmosphere differently from the main signal. These out of phase signals can cancel power from the main signal, or can appear as noise interference at the receiver.

The table below gives guidelines to the quality of the over the air code domain measurements with respect to pilot dominance and multipath power.

Measurement Quality	Pilot Dominance	Multipath Power
Very good	≥ 10 dB	< 0.1 dB
Fair	> 8 dB	< 0.4 dB
Marginal	> 5 dB	< 0.7 dB

The default measurement limits for pilot dominance and multipath power are set to give “fair” measurement quality. If these limits are met, the pilot dominance and multipath power values will be displayed in green. When the pilot dominance and multipath power parameters are outside the acceptable limits, the parameters will turn red. If this occurs, you must move to a different location that meets the “fair” criteria defined above.

In general, you should always use a preselector filter for the band of interest to prevent strong signals from overwhelming the signal of interest. Agilent offers the following preselector and antenna:

- Option 813—W-CDMA preselector filter and antenna for W-CDMA.

W-CDMA or W-CDMA (with HSDPA) Over Air
Using the W-CDMA or W-CDMA (with HSDPA) Over the Air Tool

Performing a Basic Over the Air Measurement


Step	Notes
1 Mode	
2 [Over Air]	
3 [W-CDMA Over Air] or [W-CDMA (w/ HSDPA) Over Air]	The menu key label changes to include “(w/ HSDPA)” if you have <i>Option 245 - HSDPA Analyzer & HSDPA Over Air Test</i> installed on your test set.
4 [Chan Std]	
5 Select the channel standard you want using the up and down arrow buttons.	
6 [Select]	
7 On [Units] select Chan or Freq .	Each time you press this softkey, the selected option changes.
8 [Channel] or [Frequency]	- If you selected Chan in the previous step, select [Channel]. - If you selected Freq, select [Frequency].
9 Enter the channel or frequency using the numeric keypad.	- If you selected Channel in the previous step, terminate your selection with either [Fwd] or [Rev]. - If you selected Frequency in the previous step, terminate your selection with the appropriate unit of measure.
10 [Fwd]	Selects the forward W-CDMA or W-CDMA (with HSDPA) channel.
11 Verify that on [Fr/Time Ref] GPS is selected. If not, press [Fr/Time Ref], then press [GPS].	This step is not required but it can improve the accuracy of the test set frequency reference.

W-CDMA or W-CDMA (with HSDPA) Over Air

Using the W-CDMA or W-CDMA (with HSDPA) Over the Air Tool

Step	Notes
12 On [Scramble C...] select Auto or Manual .	The test set defaults to Auto mode. - In Auto mode the test set finds the Scramble code of the strongest pilot signal and displays the value in the metrics display. - In Manual mode you must enter the Scramble code using the numeric keypad.
13 [Level/Location]	
14 On [Ref Level] select Abs or Rel .	Enables you to toggle the measurement reference value between Abs (absolute) and Rel (relative). - If set to Abs, the measurement is made in reference to absolute power and the results in the CDP chart are displayed in dBm. - If set to Rel, the measurement is made relative to the Channel Power and the results are displayed in dB.
15 [RF IN Loss]	
16 Enter the RF In Loss using the numeric keypad.	If you are using a cable and additional devices connected to the antenna, enter the combined cable and device RF In Loss here. The RF In Loss can be obtained by measuring the Insertion loss. See “Two Port Insertion Loss” on page 123. Note: If data has been previously entered in [RF IN Loss], that data will be lost and replaced by the new value you enter here.
17 [dB]	
18 Connect to the antenna.	

W-CDMA or W-CDMA (with HSDPA) Over Air
Using the W-CDMA or W-CDMA (with HSDPA) Over the Air Tool

Step	Notes
	

NOTE	The test set itself does not record data for post-processing. It provides a snapshot of W-CDMA or W-CDMA (with HSDPA) base station transmit parameters at that location.
NOTE	During a W-CDMA or W-CDMA (with HSDPA) over the air measurement, a yellow triangle symbol may temporarily appear beside “GPS” in the lower right. The yellow triangle indicates that the test set is re-synchronizing with the GPS pulse per second signal. Once the test set is synchronized, a green dot appears in place of the triangle. If the GPS is unavailable, a red X appears. If this happens, you must choose another reference.

Displaying Location Information Using GPS

If you are making W-CDMA or W-CDMA (with HSDPA) over the air measurements at a location you previously established as valid, Agilent recommends using GPS to verify that you are at the location from which you previously measured.

If you are making W-CDMA or W-CDMA (with HSDPA) over the air

W-CDMA or W-CDMA (with HSDPA) Over Air

Using the W-CDMA or W-CDMA (with HSDPA) Over the Air Tool

measurements from a new location, once you validate that the location provides a dominant pilot and low multipath power, Agilent recommends that you record the latitude and longitude coordinates of this location using GPS. Later measurements should be made from this precise location to provide performance trends.

To Display GPS Location Information:

Step	Notes
1 [Level/Location]	
2 On [Show GPS Location] select On .	Displays GPS satellite location information. Uses the internal GPS to capture the location of a measurement. These coordinates can be used to return to the same location to compare and contrast reference measurements to future measurements. The Time Ref (Freq/Chan/Time Ref mode) button must be set to GPS for this function to be active. Information logged includes longitude, latitude, altitude (feet/meters), and the number of satellites tracked. Each time you press this softkey, the selected option changes.
3 Highlight On	Toggle to On to display GPS satellite location information. Toggle to Off to remove the location information

NOTE

If you prefer to have an electronic copy of the location information, see [“Saving Data” on page 469](#).

Setting Amplifier Capacity Metrics

The Amplifier Capacity measurement is an estimate of the amount of power amplifier capacity that is being used, expressed in percent of maximum. Amplifier capacity properties must be properly set to make valid amplifier capacity measurements. Amplifier capacity metrics are amplifier capacity, peak amplifier capacity, and average amplifier capacity.

A W-CDMA or W-CDMA (with HSDPA) base station is typically set up with a

W-CDMA or W-CDMA (with HSDPA) Over Air
Using the W-CDMA or W-CDMA (with HSDPA) Over the Air Tool

specified amount of power allocated to the CPICH (Common Pilot Channel). The specified power settings of the PCCPCH (Primary Common Control Physical Channel) are defined relative to the CPICH. Occasionally, the PCCPCH power setting will also be specified in absolute power units (watts or dBm). Given the CPICH and PCCPCH setup values and the maximum power output of the amplifier, the percentage amplifier capacity setup parameters can be determined.

Setting Amplifier Capacity Properties:

Step	Notes	
1	[Setup]	
2	[Amp Cap Settings]	
3	On [Amp Cap] select On .	
4	[Max PA Pwr]	
5	[W]	
6	Enter the maximum power amplifier power in watts, using the numeric keypad.	A base station power amplifier is specified to have a maximum power limit.
7	[CPICH Pwr]	CPICH refers to Common Pilot Channel.
8	Enter the CPICH power in watts, using the numeric keypad.	The CPICH power is the total power in the dominant pilot signal, expressed in watts.
9	[W]	
10	[Δ (Delta) PCCPCH...]	PCCPCH refers to Primary Common Control Physical Channel.
11	Enter the Δ (Delta) PCCPCH Pwr in dB, using the numeric keypad.	The Δ (Delta) PCCPCH is the expected amplitude difference between the PCCPCH channel and CPICH channel, expressed in dB.
12	[dB]	

Multiple-View Display

The W-CDMA or W-CDMA (with HSDPA) Over the Air analyzer multiple-view

W-CDMA or W-CDMA (with HSDPA) Over Air

Using the W-CDMA or W-CDMA (with HSDPA) Over the Air Tool

screens are divided into two sections in the Zoom view (default—[Figure 20-1 on page 586](#)) and five sections in the Full view ([Figure 20-2 on page 587](#)) as follows:

- **Zoom view:** The top-left graph (Code Domain Trace View) shows the power in all 512 OVSF (Orthogonal Variable rate Spread Factor) Code Channels. Code channels have variable width depending on the Spread Factor for the channel. SF512 has 512 code channels with each channel 1 unit in width. SF256 has 256 channels with each channel 2 units in width. The width continues to double for SF128, SF64, and so forth. The Y-axis labels display the relative power (dB) or absolute power (dBm), threshold level, and dB/division. The X-axis labels display active channel numbers.

The light blue section on the bottom bar corresponds with the section displayed in zoom view (described below). The red line across the graph represents the active channel threshold. The control channels are in the color indicated in [“Channel Descriptions and Acronyms”](#).

Active code channels shown on the display include:

- Red - Common Pilot Channel (CPICH)
- Yellow - Primary common control channel (P-CCPCH)
- Green - Secondary common control channel (S-CCPCH); if enabled under the Setup menu
- Light blue - Paging Indication Channel (PICH) if enabled under the Setup menu; also P-SCH
- Purple - S-SCH
- Orange - Active DPCH traffic channels
- Light yellow - Active HS-PDSCH (QPSK and 16QAM) traffic channels
- Noise (light gray)
- **Full view:** The top-left graph (Code Domain Trace View) shows the power in the first half of the OVSF channels (SF512 channels 0 - 255). The lower-left graph shows the power in the other half of the channels (SF512 channels 256-511). The code channel appearance and colors are the same as described above.
- **Zoom view:** The lower-left graph (Zoom View) shows the power in the section of the graph highlighted in light blue in the top-left graph, a section of 32, 64, 128, or 256 codes.
- **Zoom and Full views:** The top-right graph (Strongest Pilot View) contains the pilot dominance and multipath power parameters. This shows the strongest Scrambling Codes seen by the test set. Active codes, that is, codes that reach or

W-CDMA or W-CDMA (with HSDPA) Over Air
Using the W-CDMA or W-CDMA (with HSDPA) Over the Air Tool

exceed the Threshold Level, are indicated by having their Scrambling Code displayed on the X-axis. Codes that do not reach the Threshold Level are considered inactive, and do not have their Scrambling Code displayed.

The Scrambling Code of interest should clearly dominate. The display is useful when positioning the test set to see what other base stations or sectors need to be avoided. Awareness of these two parameter values helps you be sure that you are making valid measurements on the sector of interest.

- Full view:** The lower-right graph (Control View) shows the power in the control channels (see “[Channel Descriptions and Acronyms](#)”).

The Δ (delta) power (relative to CPICH) is shown in the middle of the control bars.

- Zoom and Full views:** The bottom portion (Metrics View) displays 15 measurement parameters for the current measurement, displayed in three columns and five rows—each with a value and units. For more information about the metric display, refer to “[Metrics Provided by the W-CDMA or W-CDMA \(with HSDPA\) Over Air Measurement](#)” on page 608.

The frequency reference indicator is at the bottom right corner of the screen, the time reference indicator at the bottom left. For each indicator the text indicates which reference you have chosen. A green LED indicates a locked condition. A red “X” indicates an unlocked condition.

NOTE

In W-CDMA or W-CDMA (with HSDPA), the P-SCH and S-SCH are not assigned OVSF codes and therefore do not appear in the code domain trace view. The E7495A/B features a control channel graph view (Control View) for these two Sync channels to measure power only, since there are no OVSF codes associated with these channels. They have special non-orthogonal codes and are only **On** 10% of the time

Table 20-1 Channel Descriptions and Acronyms

Acronym	Full Name	Viewable in Which Display Area
CPICH	Common Pilot Channel	Visible in all views (red bar)
PCCPCH	Primary Common Control Physical Channel	Visible in all views (yellow bar)
SCCPCH	Secondary Common Control Physical Channel	Visible in all views (green bar)


W-CDMA or W-CDMA (with HSDPA) Over Air

Using the W-CDMA or W-CDMA (with HSDPA) Over the Air Tool

Table 20-1 Channel Descriptions and Acronyms


Acronym	Full Name	Viewable in Which Display Area
PICH	Paging Indicator Channel	Visible in all views (light blue bar)
P-SCH	Primary Sync Channel	Visible ONLY in the Control View (blue bar)
S-SCH	Secondary Sync Channel	Visible ONLY in the Control View (purple bar)

Figure 20-1 The Multiple-View Zoom Display



W-CDMA or W-CDMA (with HSDPA) Over Air
Using the W-CDMA or W-CDMA (with HSDPA) Over the Air Tool

Figure 20-2 The Multiple-View Full Display



Setting the Display Options

The display options enable you to zoom in on portions of the graph, or to see the entire trace at once.

Step	Notes
1 [Display]	
2 On [View] select [Zoom] or [Full].	If you are displaying Zoom view and select Full view, the display changes the top-left and bottom-left graphs to show the first 256 codes in the top graph, and the second 256 codes in the bottom graph. If you select Zoom, the two keys, Position and Width (see Steps 3 and 6 below), become available.

W-CDMA or W-CDMA (with HSDPA) Over Air

Using the W-CDMA or W-CDMA (with HSDPA) Over the Air Tool

Step	Notes
3 [Position]	When you are in Zoom view, this option changes the starting point (spread code) of the section of the full view (upper graph) that the Zoom view (lower graph) will expand for more detailed analysis.
4 Enter the position using the numeric keypad.	
5 [Enter]	
6 On [Width] select [32], [64], [128] or [256].	In Zoom view, smaller numbers selected with this option correspond to narrower zoom windows on the full view. If you select 32 for example, you will have the minimum window and maximum zoom. You will also see channel information displayed below each active channel. This information is the spreading factor used by that channel and its spread code or OVSF number.

Codogram Display

This view provides a history of the code domain power. The codogram plot rises over time until it fills the graphical section of the display. Your most recent data appears at the bottom of the display, and your oldest data (several minutes ago to several hours ago, depending on your settings) appears at the top of the display. In this way, you can clearly see the changes in power that occur over a period of time. You can use it to:

- see traffic channels as they initiate and terminate,
- track traffic channel call levels over time.

The W-CDMA or W-CDMA (with HSDPA) Over the Air Codogram screen is divided into 3 sections in the Zoom view (default—[Figure 20-3 on page 590](#)) and 4 sections in the Full view ([Figure 20-4 on page 591](#)) as follows:

- **Zoom and Full views:** The lower-right graph (**Code Domain Trace view**) shows the power in all 512 OVSF (Orthogonal Variable rate Spread Factor) Code Channels. For display details, refer to [“Multiple-View Display” on](#)

W-CDMA or W-CDMA (with HSDPA) Over Air

Using the W-CDMA or W-CDMA (with HSDPA) Over the Air Tool

page 583.

- **Zoom view:** The left graph (**Codogram view**) provides a display of data captured over time. The OVSF codes are shown on the X-axis and correspond to the light blue highlight on the Code Domain Trace view. The OVSF codes selected for your Zoom View are determined by the **Position** setting, which sets the lowest (or left) OVSF code, and by the **Width** setting, which sets the number of OVSF codes displayed. For example, with **Position** set to 400, and **Width** set to 32, your Zoom View will show codes 400 to 431, that is, from Position 400 for a Width of 32 codes.

You can change the time interval to allow longer spectrum history. The color corresponds to the OVSF channel strength.

- **Full view:** The top-left graph (**Codogram view**) shows the power in the first half of the OVSF channels (SF512 channels 0 - 255). The lower-left graph shows the power in the other half of the channels (SF512 channels 256-511). Both graphs provide a display of data captured over time.

You can change the time interval to allow longer spectrum history. The color corresponds to the OVSF channel strength.

- **Zoom and Full views:** The top-right graph (**Color Legend**) provides a color vs. power legend to help you interpret the power level in the Codogram.

The **Update Interval** is the interval, measured in whole seconds, between successive records displayed on the codogram. In other words, if you set the update interval to 5 seconds, the codogram display will not update until the after the first complete measurement following a gap of five seconds. Alternatively, you can set the update interval to provide the maximum data collection speed by pressing [Max Speed], or by setting the update interval to 0 (zero) seconds.

NOTE


It is not always possible for the analyzer to match the update interval you specify. It is possible, for example, to set your update interval to zero seconds (the maximum speed), and then to find that the analyzer can not update any faster than once every two seconds.

The frequency indicator is at the bottom right corner of the screen, the time reference indicator at the bottom left. For each indicator the text indicates which reference you have chosen. A green LED indicates a locked condition. A red "X" indicates an unlocked condition.

W-CDMA or W-CDMA (with HSDPA) Over Air
Using the W-CDMA or W-CDMA (with HSDPA) Over the Air Tool


Figure 20-3

The Codogram Zoom Display



W-CDMA or W-CDMA (with HSDPA) Over Air
Using the W-CDMA or W-CDMA (with HSDPA) Over the Air Tool

Figure 20-4 The Codogram Full Display



Performing a Codogram Measurement

Step	Notes
1 [Display]	
2 [Codogram]	This displays the menu that controls the appearance and behavior of the codogram display.
3 On [Codogram] select On or Off .	Each time you press this key, the codogram state switches between On and Off . When you set [Codogram] to On, [Reset Codogram], [Update Interval] and [Palette] become active.

W-CDMA or W-CDMA (with HSDPA) Over Air

Using the W-CDMA or W-CDMA (with HSDPA) Over the Air Tool

Step	Notes
4 [Reset Codogram]	This restarts the data capture for the Codogram. You may see the screen freeze for a few seconds before the display starts plotting data again.
5 If desired set the update interval:	Allows you to set the update interval to 0, 1, or more seconds. Alternatively, you may set it to automatically determine the update interval that provides the maximum data collection speed.
a. [Update Interval]	
b. Enter the interval number of seconds using the numeric keypad.	
c. Select [sec] or [Max Speed].	If you need to return to the automatically determined maximum display update rate, you must press [Update Interval] followed by a numeric keypad key to access [Max Speed].
6 If desired set the display color:	The color/grayscale top and bottom mappings are determined by the Ref Level and Scale/Div settings. To change the mapping, go to [Level/Location] and change [Ref Level] and [Scale/Div].
a. [Palette]	
b. Select [Full Color] or [Grayscale].	

NOTE

The key labelled “Update Interval” was labelled “Capture Interval” in earlier versions of the software (A.04.00 or earlier). The way the key works has not changed. Only the key label has changed to clarify its function.

Optional W-CDMA or W-CDMA (with HSDPA) Over the Air Measurement Settings

You can alter several optional measurement parameters in W-CDMA or W-CDMA (with HSDPA) Over the Air:

- “Setting the Channel or Frequency Step” on page 595
- “Setting the Scrambling Codes” on page 596
- “Setting the Transmitter Reference” on page 596
- “Setting Average, Sweep, and Restart” on page 598
- “Setting the Active Channel Threshold Level and Auto Threshold Level” on page 600
- “Setting Measurement Time” on page 601
- “Resetting Amplifier Capacity and Traffic Metrics” on page 602
- “Setting Valid Measurement Limits” on page 603
- “Setting the S-CCPCH Parameters” on page 603
- “Setting the PICH Parameters” on page 604
- “Adding a Marker” on page 606

Displaying the Active Code Channel Table

This display option enables you to look at a numeric and textual description of all the active code channels in your signal. The table of active channels is displayed on the left of the graphic area of the screen. The full graphic display of all 512 channels is reduced in size and displayed to the right of the table.

Step	Notes
1 [Display]	
2 [Active Code Ch Table]	When you press the Active Code Ch Table key, a fresh menu is displayed.


W-CDMA or W-CDMA (with HSDPA) Over Air

Optional W-CDMA or W-CDMA (with HSDPA) Over the Air Measurement Settings

Step	Notes
3 Press [Active Code Ch Table]	Each time you press this key, the selected option changes. Switching Active Code Channel Table On displays a table of all the active channels. For each active code you will see in the first column the channel's spreading factor, and its OVSF code number (in parentheses). In the second column is a textual description of that channel. In the third column is its code domain power (CDP) in dBc. The CDP figure is accurate to one decimal place. The menu keys to navigate up and down the table also become active when the Active Channel Code Table is switched On. If you have previously positioned a marker on one of the active channels, this channel's entry in the table is highlighted with a yellow background (see Figure 20-5 on page 595 for an example).

W-CDMA or W-CDMA (with HSDPA) Over Air
Optional W-CDMA or W-CDMA (with HSDPA) Over the Air Measurement
Settings

Figure 20-5 The Active Code Channel Table Display (with Option 245 Installed)



Setting the Channel or Frequency Step

You can set the channel or frequency step so you can quickly increment to the next channel or frequency using the Up Arrow and Down Arrow buttons.

Step	Notes
1 [Freq/Chan/Time Ref]	
2 [Chan Step] or [Freq Step]	This choice depends on the [Units] mode you are using.
3 Enter the desired channel or frequency step using the numeric keypad.	
4 [Enter]	Notice (and verify) that the number you entered is displayed below the Chan Step or Freq Step text on the corresponding button.

W-CDMA or W-CDMA (with HSDPA) Over Air

Optional W-CDMA or W-CDMA (with HSDPA) Over the Air Measurement Settings

Setting the Scrambling Codes

The E7495A/B has two ways to identify the scrambling code being used by the transmitter under analysis: an automatic detection mode, **Auto**, and a manually-specified mode, **Manual**.

- In **Auto** mode, the test set automatically detects the scrambling code present in the signal.
- In **Manual** mode, you enter the scrambling code instead of it being auto-detected by the instrument.

If the scrambling code is known, its value can be entered and the test set can decode and display the code domain power of the signal, even if no P-SCH and S-SCH are present (a CPICH must be present, however). In normal operating conditions, these sync channels are available, so the P-SCH and S-SCH are used by the E7495A/B (and W-CDMA or W-CDMA (with HSDPA) mobiles) to determine the correct sequence of scrambling codes required to demodulate the DPCH channels.

Step	Notes
1 [Freq/Chan/Time Ref]	
2 [Scramble C...]	
3 [Auto] or [Manual]	Each time you press this softkey, the selected option changes. In Manual mode, you can enter a number using the keypad.

Setting the Transmitter Reference

You can set the W-CDMA or W-CDMA (with HSDPA) Over the Air display to show the power in each channel as either relative power (dB) or absolute power (dBm). The test set's default display mode is relative. In relative mode, the top horizontal line (top-most graticule) of the display represents the total power (channel power) in the 3.84 MHz bandwidth of that W-CDMA or W-CDMA (with HSDPA) signal being broadcast by the transmitter. It is always 0 dB in this mode since it is a relative measurement. The power in each channel is shown as a vertical bar, with its height expressed in dB relative to the total channel power.

If you set the reference level mode to absolute, then the top graticule in the display still corresponds to total channel power in the 3.84 MHz bandwidth. However, the reference level and all the power values of the vertical bars showing the power in

W-CDMA or W-CDMA (with HSDPA) Over Air
**Optional W-CDMA or W-CDMA (with HSDPA) Over the Air Measurement
Settings**

each channel are now indicated with absolute power in dBm.

NOTE

This setting only affects the CDP display, the Control Channel display, and the Codogram display. The Metrics display and the Pilot View are not affected.

**To set the W-CDMA or W-CDMA (with HSDPA) Transmitter Display
Reference level:**

Step		Notes
1	[Level/Location]	
2	On [Reference] select Abs or Rel.	Each time you press this softkey, the selected option changes.

Setting Average, Sweep, and Restart

Setting the Sweep

You can select either continuous or single sweep. Continuous sweep provides repeated, ongoing measurements. Single sweep performs a single measurement that is repeated only when you push the Single button.

To set sweep:

Step	Notes
1 [Average/Sweep]	
2 [Continuous] or [Single]	Each time you press this softkey, the selected option changes.

Setting Averaging

You can choose to have averaging On or Off and to set the number of averages you want to take. Averaging only applies to the data, not the trace. When initialized, the Agilent E7495A/B defaults to running average:

- A running average computes the new result as the weighted sum of the last result and the new measurement. The last result is weighted by $(n - 1)/n$. The new result is weighted by $1/n$. Each new measurement produces a new result.

Averaging applies to the following measurement metrics and the control channel view only:

- Frequency Error
- Noise Floor
- EVM
- PCDE
- Carrier Feedthrough
- Channel Power
- CPICH power
- all the delta powers

W-CDMA or W-CDMA (with HSDPA) Over Air
**Optional W-CDMA or W-CDMA (with HSDPA) Over the Air Measurement
Settings**

- Control Channel Graph

The following measurements are unaffected by setting Averaging On or Off. They are *always* averaged up to a maximum count of 32768:

- Utilization
- Peak Utilization
- Average Utilization
- Amplifier Capacity
- Peak Amplifier Capacity
- Average Amplifier Capacity

The following measurements are *never* averaged:

- CDP Trace
- Scramble Code Scanner Trace
- Threshold

To set averaging:

Step	Notes
1	Set the number of averages. a. [Average] b. Enter the number of averages using the numeric keypad. c. [Enter]
2	Set averaging On or Off. a. [Average/Sweep] b. [Averaging] c. [Off] or [On]

NOTE	These two steps can be performed in any order. However, if you turn averaging on and a large number of averages has previously been set, there may be a delay before you can change number of averages.

W-CDMA or W-CDMA (with HSDPA) Over Air

Optional W-CDMA or W-CDMA (with HSDPA) Over the Air Measurement Settings

Setting Restart

When you have averaging turned **On** and you are in **Continuous** Sweep mode, you can restart the averaging by pressing the Restart menu key. It also resets the Amplifier Capacity and Traffic metrics. The Restart key has no effect if you are in **Single** sweep mode.

To restart averaging:

Step	Notes
1 [Average/Sweep]	
2 [Restart]	This key is unavailable or has no effect when Sweep is set to Single . To restart a Single Sweep measurement, press [Single].

Setting the Active Channel Threshold Level and Auto Threshold Level

The active channel threshold level is an advanced setting that can be set to indicate which code channels are considered active. Any code channels exceeding this power level are considered active traffic channels and any code channels below this power level are considered inactive (or noise). Those channels that are considered active, that is, channels that meet or exceed the threshold level, are indicated by the presence of their OVFSF Code below the bar in the display. Inactive channels do not have their OVFSF Codes displayed.

A horizontal red line on the screen represents the threshold. The test set can set this level automatically, or you can manually enter a value.

In Auto mode the threshold level moves as the noise fluctuates. The threshold level is set by the test set at an optimal offset above the average noise floor. In Auto mode, you can alter the Auto Threshold Offset. The recommended and default setting is 0 dB. A negative value moves the threshold lower (closer to the noise floor) and is a more aggressive setting that increases the likelihood of interpreting an inactive channel as active. A positive value moves the threshold higher (away from the noise floor) and is a more conservative setting that increases the likelihood of interpreting an active channel as inactive.

In Manual mode the threshold level is fixed and does not move as the noise fluctuates.

W-CDMA or W-CDMA (with HSDPA) Over Air
**Optional W-CDMA or W-CDMA (with HSDPA) Over the Air Measurement
Settings**

To set the active channel threshold level:

Step	Notes
1 [Setup]	
2 On [Threshold] select Auto or Manual .	Each time you press this softkey, the selected option changes. If you choose Manual, you must enter the threshold you want using the numeric keypad, then press [dB].
3 [Auto Thres Offset]	The default value is 0 dB. Optionally, you can enter a negative (more aggressive) or positive (more conservative) value, then press [dB].

NOTE

Knowing which inactive code channels are contributing the most noise to the overall W-CDMA or W-CDMA (with HSDPA) channel may provide clues to the source of noise, such as a bad channel card in the base station.

Setting Measurement Time

The Measurement Time setting allows you to alter the speed at which measurements are being made. Three choices exist: Slow, Medium, and Fast. The test set defaults to Medium. Slow measurement time provides a more accurate measurement at the expense of time. Fast measurement time provides a quicker measurement at the expense of accuracy. Medium measurement time strikes a balance between measurement speed and measurement accuracy.

Changes in measurement time, or measurement speed, are achieved by varying the amount of data used to plot the CDP trace, and by varying the type of frame alignment used.

W-CDMA or W-CDMA (with HSDPA) Over Air
Optional W-CDMA or W-CDMA (with HSDPA) Over the Air Measurement Settings

Slots and Frame Alignment at Different Measurement Speeds

Meas Time	Number of Slots	W-CDMA (HSDPA Off)	W-CDMA (HSDPA On)
Slow	2	Aligned to Scramble Sequence Frame (CPICH = 0)	
Medium	2	Random Slot	Aligned to the start of the next sub-frame boundary
Fast	2	Random Slot	Random Slot

To set the Measurement Speed:

Step	Notes
1 [Setup]	
2 On [Meas Time] select Slow, Medium, or Fast.	Each time you press this softkey, the selected option changes.

NOTE

CDP measurements will only meet Agilent’s published specifications when you are using either Medium or Slow measurement speeds.

Resetting Amplifier Capacity and Traffic Metrics

The amplifier capacity metrics such as the peak and average amplifier capacity and peak and average utilization can be reset. If you prefer to reset these parameters manually, you may do so using the [Reset Metrics] menu key.

NOTE

Pressing [Reset Metrics] also causes a restart of your analyzer.

To Manually Reset the Amplifier Capacity Metrics:

Step	Notes
1 [Display/Reset]	
2 [Reset Metrics]	This will also cause a restart of your analyzer.

W-CDMA or W-CDMA (with HSDPA) Over Air
Optional W-CDMA or W-CDMA (with HSDPA) Over the Air Measurement Settings

Setting Valid Measurement Limits

The Valid Measurement Setting allows you to set the Multipath Power and Pilot Dominance limits. These settings control will help the test set to determine if valid over the air measurements are being made.

Step	Notes
1	[Setup]
2	[Valid Meas Settings]
3	Set Multipath Power limit. a. [Mp Pwr <] b. Enter the power level using the numeric keypad. c. [dB]
4	Set Pilot Dominance limit. a. [Plt Dom >] b. Enter the power level using the numeric keypad. c. [dB]

Setting the S-CCPCH Parameters

The S-CCPCH (Secondary Common Control Physical Channel) Setting allows you enable S-CCPCH, set the spread factor, and designate the channel number. The S-CCPCH settings help the test set determine which channel is the S-CCPCH channel. Once the test set has identified this channel, it can perform the delta power measurements for this channel and display them to the you.

Step	Notes
1	[Setup]

W-CDMA or W-CDMA (with HSDPA) Over Air

Optional W-CDMA or W-CDMA (with HSDPA) Over the Air Measurement Settings

Step	Notes
2 [S-CCPCH]	This key displays the current Spread Factor, selected channel, and Enable /Disable status.
3 On [S-CCPCH Enable] select On or Off .	Each time you press this softkey, the selected option changes.
4 Set the Spread Factor.	
a. [Spread Factor]	
b. [4], [8], [16], [32], [64], [128], or [256].	
5 Set the channel.	Always enter the channel number even if you have set Units to Freq.
a. [Channel]	
b. Enter the channel number using the numeric keypad.	
c. [Enter]	

Setting the PICH Parameters

The PICH (Paging Indicator Channel) Setting allows you enable PICH and designate the channel number. The PICH settings help the test set to determine which channel is the PICH channel. Once the test set has identified this channel, it can perform the delta power measurements for this channel and display them to you.

Step	Notes
1 [Setup]	
2 [PICH]	This key displays the current Spread Factor, selected channel (in parenthesis), and Enable /Disable status.
3 On [PICH Enable] select On or Off .	Each time you press this softkey, the selected option changes.
	[Spread Factor] is grayed out and unavailable because the spread factor is fixed at 256.

W-CDMA or W-CDMA (with HSDPA) Over Air
Optional W-CDMA or W-CDMA (with HSDPA) Over the Air Measurement
Settings

Step	Notes
4	Set the channel.
a.	[Channel]
b.	Enter the channel number using the numeric keypad.
c.	[Enter]

Setting the EVM Mode

EVM Mode allows you to select either of the two EVM modes of measurements. The two modes available to you are **Composite** and **Pilot**.

Select **Pilot** to measure the EVM of the CPICH channel using Code Number 0 at Code Level 256. The SCH channels are included in the measurement, giving you a total of 10 symbols (one time slot).

Select **Composite** to measure the combined EVM of all the channels.

Step	Notes
1	[Setup]
2	[EVM Mode]
	Each time you press this softkey, the selected option changes.
	You can choose between Pilot and Composite .

Setting the IF Equalizer

IF Equalizer allows you to control how you use the test set's in-built IF Flatness Equalizer. The IF Equalizer reduces the noise levels of your measurements, typically resulting in a CDP noise floor reduction of 2 or 3 dB, and an EVM noise reduction of about one percentage point.

If there is sufficient input power, the IF Equalizer will also remove some of the multipath channel fading that can be present.

NOTE

The noise reduction effect of the IF Equalizer is not immediate, so it is best to allow

W-CDMA or W-CDMA (with HSDPA) Over Air

Optional W-CDMA or W-CDMA (with HSDPA) Over the Air Measurement Settings

your test set to settle by performing several sweeps first.

NOTE Agilent Technologies recommends that you set Meas Time to Slow. If Meas Time is set to Medium or to Fast, there is insufficient time to collect enough data to generate an accurate equalization estimate. Press [Setup], then [Meas Time] to set your measurement speed.

Even with Meas Time set to Slow, you may see some instability for a short time until the test instrument has settled.

If you set IF Equalizer to **Run**, the data from the current data capture is used to generate an approximate correction for any IF slope. This correction is repeatedly averaged to remove the effects of noise.

If you set IF Equalizer to **Hold**, the correction applied is that from the last time Run mode was used. The test set will not update or adjust the correction being applied.

If you have not yet performed a measurement with IF Equalizer Status set to Run, there will be no correction data present in the test set, and no correction will be applied.

When IF Equalizer is Off, no attempt is made to correct any flatness error inherent in the test set.

Step	Notes
1 [Setup]	
2 [IF Eq Status]	Each time you press this softkey, the selected option changes. You can choose between Off (no flatness correction is applied), Run (flatness correction is continually revised and updated) and Hold (a fixed flatness correction is applied).

Adding a Marker

Markers can be used on traces to help you visually track up to four signals. Each marker has the following settings:

- **Type:** Provides three options, including:
 - **Off**

W-CDMA or W-CDMA (with HSDPA) Over Air
Optional W-CDMA or W-CDMA (with HSDPA) Over the Air Measurement
Settings

- **Normal**, which places a diamond-shaped, colored marker, along with a number, 1-4, on the trace.
- **Δ (Delta)**, is associated with a normal marker. Therefore, a normal marker must exist prior to creating the Δ (delta) marker. The Δ (delta) marker displays the difference between the normal marker position and the Δ (delta) marker position. Only one Δ (delta) marker can be associated with a given normal marker. The normal marker must be active when Δ (Delta) is selected.
- **Marker to Peak:** Places the active marker on the current greatest value of the trace.
- **Marker to Next Peak:** Places the active marker on the next highest peak as measured from your current marker's position.
- **Marker to Next Active Ch Left:** Places the active marker on the next active channel to the left of your current marker.
- **Marker to Next Active Ch Right:** Places the active marker on the next active channel to the right of your current marker.

Step	Notes
1 [Marker]	
2 [Marker]	
3 [1], [2], [3], or [4]	
4 [Type]	
5 [Off], [Normal], or [Δ (Delta)]	
6 Locate the marker relative to the trace:	
	• [Marker to Peak] • [Marker to Next Peak] • [Marker to Next Active Channel Left]
	or
	• [Marker to Next Active Channel Right]

Metrics Provided by the W-CDMA or W-CDMA (with HSDPA) Over Air Measurement

This section contains descriptions of the individual W-CDMA or W-CDMA (with HSDPA) transmitter metrics in the Metrics view of the screen. For expected result values and possible causes of error if the expected results are not met, see [“Interpretation of Over the Air Measurement Results” on page 612.](#)

Freq (Frequency)

Frequency is the selected transmitter operating frequency you have entered (or calculated from the channel number you have entered).

Freq Error (Frequency Error)

Frequency error is the frequency difference between your transmitter's actual center frequency and the frequency (or channel) you entered.

Scramble Code

The Scrambling Code being measured (manual or auto). In W-CDMA or W-CDMA (with HSDPA), each Access Network (or BTS) output signal is scrambled by multiplying each of its data channels by a unique pseudo-noise (PN) code. In the W-CDMA specifications, this is referred to as a Scrambling Code.

Noise Floor

Noise Floor is the average power level of all the inactive channels.

Carr Feedthru or Carr FT (Carrier Feedthrough)

Carrier Feedthrough is a result of the RF carrier signal feeding through the I/Q modulator and riding on the output circuitry without being modulated.

EVM Pilot and EVM Comp (Pilot (CPICH) and Composite Error Vector Magnitude

EVM is the measure of signal quality specified as a percent of noise to pure signal. It is the difference between the measured waveform and the theoretical modulated waveform (the error vector). EVM metrics are used to measure the modulation quality of a transmitter. The 3GPP standard requires the Composite EVM not to exceed 17.5% for normal W-CDMA (defined as Test Models 1 and 4), and not to exceed 12.5% in the case of 16QAM HSDPA (defined as Test Model 5).

W-CDMA or W-CDMA (with HSDPA) Over Air Metrics Provided by the W-CDMA or W-CDMA (with HSDPA) Over Air Measurement

PCDE (Peak Code Domain Error)

PCDE takes the noise and projects the maximum impact it will have on all OVSF codes. PCDE is the maximum value for the code domain error for all codes (both active and inactive).

In W-CDMA or W-CDMA (with HSDPA), specifically to address the possibility of uneven error power distribution, the EVM measurement has been supplemented with PCDE. The 3GPP standard requires the PCDE not to exceed -33 dB at a spreading factor of 256, but the Conformance Test adds in a Test Tolerance of 1dB. This gives a Conformance Limit for Peak Code Domain Error of -32 dB at a spreading factor of 256.

Utilization

Utilization is a ratio of the active OVSF codes to the total SF512 codes, expressed as a percentage. Even though active control channels such as the pilot are included in the utilization measurement, utilization is an indication of the traffic that is being carried by the base station.

For example, W-CDMA or W-CDMA (with HSDPA) signal with CPICH, PCCPCH, SCCPCH using SF256, and PICH, would use 8 of 512 SF512 codes, giving a utilization of 1.6%.

Pk Util (Peak Utilization)

Peak Utilization is the peak level of all the valid Utilization measurements while on the same Scrambling code. In Scrambling code Auto mode this measurement is reset if the Scrambling code changes or the Reset Metrics button is used. In Scrambling code Manual mode this measurement is reset only if the Reset Metrics button is used.

NOTE

Pressing [Reset Metrics] also causes a restart of your analyzer.

Avg Util (Average Utilization)

Average Utilization is the average level of all the valid Utilization measurements while on the same Scrambling code. In Scrambling code Auto mode this measurement is reset if the Scrambling code changes or the Reset Metrics button is used. In Scrambling code Manual mode this measurement is reset only if the Reset Metrics button is used.

NOTE

Pressing [Reset Metrics] also causes a restart of your analyzer.

W-CDMA or W-CDMA (with HSDPA) Over Air

Metrics Provided by the W-CDMA or W-CDMA (with HSDPA) Over Air Measurement

Chan Pwr (Channel Power)

Channel Power is the integrated power within a defined bandwidth. For W-CDMA or W-CDMA (with HSDPA) the channel bandwidth is 3.84 MHz. Channel Power measures the power the base station is transmitting across the entire 3.84 MHz W-CDMA or W-CDMA (with HSDPA) channel.

CPICH (Common Pilot Channel)

Common Pilot Channel (CPICH) is the channel that carries the scrambling code. The CPICH metric reports the power in this channel in dBc. By default, the CPICH Limits are set to Off. If you set CPICH Limits On, the default upper limit value is 0 dBc, and the lower limit value is -20 dBc.

NOTE

The CPICH default limits are set at a level suitable for catching only gross errors when field testing live signals. To perform conformance testing, you will need to set the limits to your own specifications. Conformance testing for Test Model 2 (TM2), for example, requires that the CPICH limits are set to ± 2.9 dB, that is, to -7.1 dB and -12.9 dB with a -10 dBc signal.

Amp Cap (Amplifier Capacity)

Assuming the Amplifier Capacity parameters are set properly, the Amplifier Capacity measurement is an estimate of the amount of power amplifier capacity that is being used, expressed in percent of maximum. When an amplifier is transmitting at maximum output power, it is said to be at 100% of its capacity. For example, an amplifier with a maximum output power of 12 watts would be at 50% of capacity when transmitting 6 watts and at 100% of capacity when transmitting at 12 watts.

The percentage of amplifier capacity generally increases as the number or level of the traffic channels increase.

Pk Amp Cap (Peak Amplifier Capacity)

Peak Amplifier Capacity is the peak level of all the valid Amplifier Capacity measurements while on the same Scrambling code. In Scrambling code Auto mode this measurement is reset if the Scrambling code changes or the Reset Metrics button is used. In Scrambling code Manual mode this measurement is reset only if the Reset Metrics button is used.

NOTE

Pressing [Reset Metrics] also causes a restart of your analyzer.

Avg Amp Cap (Average Amplifier Capacity)

W-CDMA or W-CDMA (with HSDPA) Over Air Metrics Provided by the W-CDMA or W-CDMA (with HSDPA) Over Air Measurement

Average Amplifier Capacity is the average level of all the valid Amplifier Capacity measurements while on the same Scrambling code. In Scrambling code Auto mode this measurement is reset if the Scrambling code changes or the Reset Metrics button is used. In Scrambling code Manual mode this measurement is reset only if the Reset Metrics button is used.

NOTE

Pressing [Reset Metrics] also causes a restart of your analyzer.

W-CDMA or W-CDMA (with HSDPA) Over Air

Interpretation of Over the Air Measurement Results

Interpretation of Over the Air Measurement Results

This section contains expected result values and possible causes of error if the expected results are not met.

Freq (Frequency)

If you are in the channel mode, verify that the correct channelization and channel number are set.

Freq Error (Frequency Error)

The frequency error of the analyzer should be <1 kHz. If the frequency error is greater than this, there could be a possible malfunction in the base station equipment. Other possible explanations for Frequency Error include:

- the effects of multipath transmission
- pilot dominance
- failure of the base station to lock onto a GPS signal

Before performing a procedure to check the base station equipment, check to ensure that the test set is performing a correct measurement. You can do this by reviewing the frequency reference settings for the test set (refer to [“Setting the Transmitter Reference” on page 596](#)).

Ensure that these settings are correct, and that the test set shows reference lock. Lastly, make sure the test set has been powered on, and has been locked for at least 15 minutes.

If the error is still occurring after performing the above procedures, you will need to check the Base Station equipment for a source of the error. You can also verify that the base station is malfunctioning by turning off its modulation hardware and performing a frequency measurement on the Base Station carrier signal in the spectrum analyzer mode of the test set (refer to [“Performing a Basic Spectrum Analyzer Measurement” on page 415](#)).

You can use the **Frequency Limits** setting to make your analyzer indicate automatically whether or not a signal has exceeded the pre-defined limits you set.

Scramble Code

If the Scramble code is not as expected, it could be due to an incorrect Base Station setting or to incorrect positioning of the test set. Use of the “strongest pilot” display

W-CDMA or W-CDMA (with HSDPA) Over Air Interpretation of Over the Air Measurement Results

to position the test set. If the correct Scrambling code cannot be located, check the base station settings.

Noise Floor

An unexpectedly high noise floor could be due to interfering signals.

If you have not already done so, you can reduce the noise floor by activating the IF Equalizer (See “Setting the IF Equalizer” on page 605.)

Carr Feedthru (Carrier Feedthrough)

A good Carrier Feedthrough level is less than -25 dBc. The 3GPP standard does not specify Carrier Feedthrough; however, this measurement provides an additional tool to troubleshoot the base station's transmitter.

In the frequency domain, Carrier Feedthrough can show up as an energy spike that can be seen on the spectrum analyzer by closely spanning into the top of the W-CDMA or W-CDMA (with HSDPA) signal. The effects of Carrier Feedthrough can also show up as higher noise levels on the Code Domain Power screen. Carrier Feedthrough can be caused by the lack of isolation across the mixer and cavity of the transmitter's I/Q modulator.

EVM Pilot and EVM Comp (Pilot (CPICH) and Composite Error Vector Magnitude

An unexpectedly high EVM could be due to interfering signals, carrier feedthrough, transmitter I/Q modulator, or signal path problems.

If you have not already done so, you can reduce the noise floor by activating the IF Equalizer (See “Setting the IF Equalizer” on page 605.)

PCDE (Peak Code Domain Error)

An unexpectedly high PCDE could be due to interfering signals, carrier feedthrough, pilot dominance, or multipath power. If these are all correct, check for transmitter I/Q modulator or signal path problems.

Utilization

The Utilization metric provides an instantaneous reading of the percentage of the traffic channels currently being used. More meaningful information is provided by the Peak and Average Utilization metrics gathered over a 10 to 15 minute interval.

Pk Util (Peak Utilization)

If the Peak Utilization of this base station is greater than 65%, this is a warning that

W-CDMA or W-CDMA (with HSDPA) Over Air

Interpretation of Over the Air Measurement Results

peak traffic rates at this base station are getting very high. It is possible that calls could be getting blocked or dropped.

Avg Util (Average Utilization)

If the Average Utilization of this base station is greater than 45%, the base station is carrying a great deal of traffic. Service providers may want to consider expanding their network infrastructure to support higher system (call) demands.

Chan Pwr (Channel Power)

If the Channel Power level is not as expected, check pilot dominance and the number of Scramble codes visible. All visible sectors will contribute to channel power. Also, check Amplifier Capacity and Utilization as they could have exceeded the maximum capacity. A high power data call could be indicated by a very wide and tall bar.

CPICH (Common Pilot Channel)

CPICH will vary with distance from the base station and clear line of sight to the antenna. If the CPICH is not as expected, check pilot dominance and base station settings (ratio to other control channels should be good).

Amp Cap (Amplifier Capacity)

The Amplifier Capacity metric provides an instantaneous reading of how much of the amplifier's capacity is currently being used. More meaningful information is provided by the Peak and Average Amplifier Capacity metrics gathered over a 10 to 15 minute interval.

Pk Amp Cap (Peak Amplifier Capacity)

If the Peak Amplifier Capacity is greater than 100%, the traffic at this base station has caused the base station amplifier to exceed its maximum power rating. This is not desirable as this problem can result in system degradation or damage to the amplifier.

You can get an indication of how often the amplifier capacity is being exceeded by watching the Amplifier Capacity measurement. This is an instantaneous measurement of the amplifier capacity.

Avg Amp Cap (Average Amplifier Capacity)

If the Average Amplifier Capacity is greater than 85%, the base station power amplifier is close to its maximum power limit. Further increase in traffic on this base station could cause system performance problems or damage to the power amplifier.

W-CDMA or W-CDMA (with HSDPA) Over Air Interpretation of Over the Air Measurement Results

You should notify your RF Engineering Department as soon as possible.

W-CDMA or W-CDMA (with HSDPA) Over Air Interpretation of Over the Air Measurement Results

21

Safety and Regulatory Information and Specifications

- “Safety considerations” on page 618
 - “Safety Symbols” on page 618
 - “Safety Considerations For This Test Set” on page 619
 - “Lifting and Handling” on page 620
 - “Electrostatic Discharge (ESD) Precautions” on page 621
 - “Product Markings” on page 622
 - “Batteries: Safe Handling and Disposal” on page 623
- “Certification and Compliance Statements” on page 629
 - “Certification” on page 629
 - “Manufacturer’s Declaration” on page 629
 - “Declaration of Conformity for Agilent E7495A” on page 630
 - “Declaration of Conformity for Agilent E7495B” on page 631
 - “Compliance with German Noise Requirements” on page 632
 - “Compliance with Canadian EMC Requirements” on page 632
- “E7495A/B Base Station Test Set Specifications” on page 633
 - “Battery Pack Specifications” on page 646

Safety and Regulatory Information and Specifications

Safety considerations

Safety considerations

General

This product and related documentation must be reviewed for familiarization with safety markings and instructions before operation.

This product has been designed and tested in accordance with IEC Publication 61010-1+A1+A2:1992 Safety Requirements for Electrical Equipment for Measurement, Control and Laboratory Use and has been supplied in a safe condition. This instruction documentation contains information and warnings which must be followed by the user to ensure safe operation and to maintain the product in a safe condition.

Safety Earth Ground

A uninterruptible safety earth ground must be provided from the main power source to the product input wiring terminals, power cord, or supplied power cord set.

Chassis Ground Terminal

To prevent a potential shock hazard, always connect the rear-panel chassis ground terminal to earth ground when operating this test set from a dc power source.

Safety Symbols



Indicates test set damage can occur if indicated operating limits are exceeded. Refer to the instructions in this guide.



Indicates hazardous voltages.



Indicates earth (ground) terminal

WARNING

A **WARNING** note denotes a hazard. It calls attention to a procedure, practice, or the like, which, if not correctly performed or adhered to, could result in personal injury. Do not proceed beyond a **WARNING** sign until the indicated

conditions are fully understood and met.

CAUTION

A CAUTION note denotes a hazard. It calls attention to an operation procedure, practice, or the like, which, if not correctly performed or adhered to, could result in damage to or destruction of part or all of the product. Do not proceed beyond an CAUTION note until the indicated conditions are fully understood and met.

Safety Considerations For This Test Set

WARNING

Whenever it is likely that the protection has been impaired, the test set must be made inoperative and be secured against any unintended operation.

If this test set is to be energized via an autotransformer (for voltage reduction), make sure the common terminal is connected to the earth terminal of the power source.

If this product is not used as specified, the protection provided by the equipment could be impaired. This product must be used in a normal condition (in which all means for protection are intact) only.

No operator serviceable parts in this product. Refer servicing to qualified personnel. To prevent electrical shock, do not remove covers.

Servicing instructions are for use by qualified personnel only. To avoid electrical shock, do not perform any servicing unless you are qualified to do so.

The opening of covers or removal of parts is likely to expose dangerous voltages. Disconnect the product from all voltage sources while it is being opened.

Adjustments described in the manual are performed with power supplied to the test set while protective covers are removed. Energy available at many points may, if contacted, result in personal injury.

For Continued protection against fire hazard, replace the line fuse(s) with T 250 V 5.0 A fuse(s) or the same current rating and type. Do not use repaired fuses or short circuited fuseholders.

WARNING

This product is a Safety Class I test set (provided with a protective earthing ground incorporated in the power cord). The mains plug shall only be inserted in a socket outlet provided with a protective earth contact. Any interruption of the protective conductor inside or outside of the product is likely to make the product dangerous. Intentional interruption is prohibited.

Safety and Regulatory Information and Specifications

Safety considerations

WARNING

Always use the three-prong ac power cord supplied with this product. Failure to ensure adequate earth grounding by not using this cord may cause personal injury and/or product damage.

This product is designed for use in Installation Category II and Pollution Degree 3 per IEC 61010 and IEC 60664 respectively.

This product has autoranging line voltage input, be sure the supply voltage is within the specified range.

To prevent electrical shock, disconnect test set from mains (line) before cleaning. Use a dry cloth or one slightly dampened with water to clean the external case parts. Do not attempt to clean internally.

Ventilation Requirements: When installing the product in a cabinet, the convection into and out of the product must not be restricted. The ambient temperature (outside the cabinet) must be less than the maximum operating temperature of the product by 4 ° C for every 100 watts dissipated in the cabinet. If the total power dissipated in the cabinet is greater than 800 watts, then forced convection must be used.

WARNING

If you are charging the batteries internally—even while the test set is powered off—the test set may become warm. Take care to provide proper ventilation.

WARNING

Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended. Discard used batteries according to manufacturer's instructions.

WARNING

To avoid overheating, always disconnect the test set from the AC adapter before storing the test set in the soft carrying case.

If you prefer to leave the test set connected to the AC adapter while inside the soft carrying case, you can disconnect the AC adapter from its power source to prevent overheating.

Lifting and Handling

When lifting and handling the Agilent E7495A/B Base Station Test Set use ergonomically correct procedures. Lift and carry the test set by the carrying strap.

Electrostatic Discharge (ESD) Precautions

This test set was constructed in an ESD (electrostatic discharge) protected environment. This is because most of the semiconductor devices used in this test set are susceptible to damage by static discharge.

Depending on the magnitude of the charge, device substrates can be punctured or destroyed by contact or mere proximity of a static charge. The result can cause degradation of device performance, early failure, or immediate destruction.

These charges are generated in numerous ways such as simple contact, separation of materials, and normal motions of persons working with static sensitive devices.

When handling or servicing equipment containing static sensitive devices, adequate precautions must be taken to prevent device damage or destruction.

Only those who are thoroughly familiar with industry accepted techniques for handling static sensitive devices should attempt to service circuitry with these devices.

Safety and Regulatory Information and Specifications

Safety considerations

Product Markings



The CE mark shows that the product complies with all relevant European legal Directives (if accompanied by a year, it signifies when the design was proven).



The CSA mark is a registered trademark of the Canadian Standards Association.



The off symbol is used to mark a position of the instrument power line switch.



The on symbol is used to mark a position of the instrument power line switch.



The standby symbol is used to mark a position of the instrument power line switch.



The C-Tick mark is a registered trademark of the Australian Spectrum Management Agency.

Batteries: Safe Handling and Disposal

COBALT CELL

MATERIAL SAFETY DATA SHEET
FSSF00001AG - FOR CUSTOMER DISTRIBUTION

Feb 14, 2003

SECTION 1 - PRODUCT IDENTIFICATION AND USE				
Product:	Molicel - Cobalt based Lithium-Ion cell (up to and including 2.4 Ah)		P.I.N.: Not Regulated	
Use:	High performance lithium-ion rechargeable battery system.		W.H.M.I.S.: exempt. manufactured article	
Manufacturer:	E-One Moli Energy (Canada) Limited 20,000 Stewart Cres. Maple Ridge, BC, Canada V2X 9E7 (604) 466-6654 FAX: (604) 466-6600		24 HOUR EMERGENCY NUMBER (604) 466-6654 (MOLI)	
SECTION 2 - HAZARDOUS INGREDIENTS				
Hazardous Ingredients	%	CAS Number	LD ₅₀ (mg/kg) (oral-rat)	LC ₅₀ (mg/L)
Aluminium foil	0.1- 1 w/w	7429-90-5	N/AV	N/AV
Biphenyl (BP)	0-0.3 w/w	92-52-4	2400	N/AV
Copper foil	0.1- 1 w/w	7440-50-8	3.5 (ipr-mouse)	N/AV
Dioxathiolane 2,2-Dioxide (DTD)	0 – 3 w/w	1072-53-3	1600	N/AV
Linear and Cyclic Carbonate Solvents (See Other Information)	5- 17w/w	N/APP	~11000 (weighted avg)	N/AV
Graphite, powder	10- 30 w/w	7440-44-0	440 (ivn-mouse)	N/AV
Lithium Carbonate	0–0.3 w/w	554-13-2	525	N/APP
Lithium Cobaltite (LiCoO ₂)	10- 30 w/w	12190-79-3	N/AV	N/AV
Lithium Hexafluorophosphate (LiPF ₆)	1- 5 w/w	21324-40-3	1702	Rat: >20
Poly (vinylidene fluoride) (PVDF)	0.1- 1 w/w	24937-79-9	N/AV	N/AV
Propane Sultone (PS)	0 – 3 w/w	1120-71-4	100	N/AV
Steel, nickel and inert polymer	Balance	N/APP	N/APP	N/APP

Safety and Regulatory Information and Specifications

Safety considerations

COBALT CELL MATERIAL SAFETY DATA SHEET Feb 14, 2003
FSSF00001AG - FOR CUSTOMER DISTRIBUTION

SECTION 3 - PHYSICAL DATA				
Physical state: Nickel plated metal canister under label		Odour None		Odour threshold: N/APP
Vapour pressure (mmHg) N/APP	Vapour Density (air =1) N/APP	Evaporation rate : N/APP	Boiling Point N/APP	Freezing point N/APP
pH (10% in water) N/APP	Specific gravity: 1.5-2.0	Coeff. of water/oil distribution N/APP	Water solubility: insoluble	Percent Volatiles: NONE
SECTION 4 - FIRE AND EXPLOSION DATA				
Flammability NO	Conditions: Organic components will burn if cell incinerated. Combustion of cell contents will cause evolution of Hydrogen Fluoride.			
Means of Extinction and Special Procedures: Water spray, Carbon Dioxide, Dry chemical powder or appropriate foam. Use agent appropriate for surrounding materials. Wear self-contained breathing apparatus and protective clothing to prevent contact with skin and eyes. Extremely corrosive Hydrogen Fluoride gas is produced upon combustion of cell contents.				
Flashpoint: NONE	Upper Flammable Limit: NONE		Lower Flammable Limit: NONE	
Auto-ignition Temp: NONE	Hazardous Combustion Products: Hydrogen Fluoride, Phosphorus Oxides, Carbon oxides, Lithium Hydroxide, Cobalt Oxides, Aluminium Oxide, Sulphuric acid, Sulphur oxides, possible fluoro-compounds, Carbon soot			
Impact sensitive: NO	Static Discharge Sensitive: NO, but cell may contain up to 4.2 volts.			
SECTION 5 - REACTIVITY DATA				
Stability: STABLE	Hazardous polymerization will not occur. Spontaneous decomposition at normal temperatures will not occur.			
Incompatibilities: Do not crush, puncture, incinerate, immerse in water or heat over 100 C. Steel casing slowly dissolves in strong mineral acids.				
Reactivities: None known				
Hazardous Decomposition Products: Hydrogen Fluoride, Phosphorus Oxides, Carbon oxides, Lithium Hydroxide, Cobalt Oxides, Aluminium Oxide, Sulphuric acid, Sulphur oxides, possible fluoro-compounds, Carbon soot				

COBALT CELL MATERIAL SAFETY DATA SHEET Feb 14, 2003
FSSF00001AG - FOR CUSTOMER DISTRIBUTION

SECTION 6 - TOXICOLOGICAL PROPERTIES			
Routes of Entry: Skin Contact: NO Skin Absorption NO Eye contact: NO Inhalation NO Ingestion NO			
Acute Exposure			
Skin: No effect noticed in routine handling of product.			
Eyes: The bulk solid has no effect on the eye beyond blunt impact.			
Inhalation: Not applicable.			
Ingestion: Ingestion is not likely, given the physical size and state of the cell.			
Chronic Exposure			
Skin: None anticipated.			
Eyes: Not applicable.			
Inhalation: Not applicable.			
Ingestion: Ingestion is not a likely exposure route.			
Exposure Limits None listed	Irritancy: None	Sensitization: Not anticipated	Carcinogenicity Not anticipated
Teratogenicity: Not anticipated		Mutagenicity: Not anticipated.	
Reproductive toxicity: Not anticipated		Synergistic Products: None expected	
SECTION 7- PREVENTIVE MEASURES			
Personal protective equipment:			
Gloves: Not required for handling individual cells. Fabric gloves for warehouse container handling.	Respirator: No respirator required for normal handling. SCBA required for fires.		Eyewear: Not required beyond employer policy.
Clothing: Standard industrial clothing in normal use. Impervious suit in fires.		Footwear: Wear steel-toed footwear if large containers of cells are being handled.	
Engineering controls: Keep away from heat and open flames. Store in a cool, dry place.			

Page 3 of 6

Safety and Regulatory Information and Specifications

Safety considerations

COBALT CELL MATERIAL SAFETY DATA SHEET Feb 14, 2003
FSSF00001AG - FOR CUSTOMER DISTRIBUTION

Leak and spill procedure: Evacuate area if fire present or likely. Wear SCBA for fire-related emergencies. Using gloves, pick up or sweep up fire-damaged cells, bag individually in plastic bags and place in closed metal containers. 205 Litre lined steel drums are appropriate. Cardboard boxes may be used for small quantities. Avoid raising dust while sweeping. Transport container outdoors. Hold burned cells and fire cleanup solids for disposal as potential hazardous waste. Unburned cells are not hazardous waste. A fire with over 100 kg of cells burnt will likely require reporting to environment officials. Always consult and obey all international, federal and local environmental laws.	
Waste disposal: Always consult and obey all international, federal, provincial/state and local hazardous waste disposal laws. Some jurisdictions require recycling of this spent product.	
Handling procedures and equipment: Store in a cool, dry place away from sparks and flame. Keep below 125 °C. Keep above -60 °C. Charge between 0 °C and 45 °C. Use only approved charging equipment. Do not disassemble battery or battery pack. Do not puncture, crush or dispose of in fire.	
Storage requirements: Store at room temperature for best results.	
Special Shipping Information: Not regulated. This product is made from materials with no detectable mercury. Equivalent lithium content as per Section 38.3.2 of the UN Manual of Tests and Criteria (ST/SG/AC.10/11/27 Add. 2): Equivalent grams of lithium is equal to 0.3 times the rated Amp-hour capacity of the individual cell, regardless of cell size. 1.8 Ah = 0.54 g 2.0 Ah = 0.60 g 2.2 Ah = 0.66g 2.4 Ah = 0.72 g	
SECTION 8 - FIRST AID MEASURES	
Skin:	Not a health hazard.
Eyes:	Not an eye hazard
Inhalation:	Not an inhalation hazard.
Ingestion:	If swallowed, seek emergency medical aid. If patient choking and can partially breathe, encourage patient to cough. Do not strike patient's back. This may lodge cell further in throat. If patient is not breathing, perform standing Heimlich manoeuvre until object is dislodged or patient becomes unconscious. An unconscious patient should be lowered gently to the floor on their back and abdominal thrusts performed continuously until cell is ejected from throat or medical aid arrives.

Safety and Regulatory Information and Specifications
Safety considerationsCOBALT CELL MATERIAL SAFETY DATA SHEET Feb 14, 2003
FSSF00001AG - FOR CUSTOMER DISTRIBUTION

SECTION 9 - PREPARATION INFORMATION			
Prepared by: Martin RIDGWAY, B.Sc. Safety Co-ordinator	Phone: (604) 466-6654	Date Created: Mar 31, 1995	Revision Information: First Issue
		Date Last Revised: Jul 31, 1998	Revision Information: Assign document control number. Company name change.
		Date Last Revised: Jun 15, 2000	Revision Information: Company name change.
		Date Last Revised: Jan 23, 2001	Revision Information: Shipping: Contains no mercury.
		Date Last Revised: May 1, 2001	Revision Information: Incompatibilities – Do not heat over 100C (to match UL warning statement)
		Date Last Revised: Jan 28, 2003	Revision Information: Shipping Information – Added equivalent lithium content information
		Date Last Revised: Feb 4, 2003	Revision Information: Product – Up to and including 2.4 Ah Ingredients – Added PS, LiCO ₂ and DTD Decomposition – Added sulphur compounds
Approval			

OTHER INFORMATION

The above information is believed to be correct but does not purport to be all-inclusive and shall be used only as a guide. Exact composition information is immediately available on a confidential basis to medical professionals treating exposure to cell components or combustion by-products.

HYDROFLUORIC ACID EXPOSURE DURING FIRE FIGHTING

This information is given for the use of professional fire fighters responding to a warehouse fire

Safety and Regulatory Information and Specifications

Safety considerations

COBALT CELL MATERIAL SAFETY DATA SHEET Feb 14, 2003
FSSF00001AG - FOR CUSTOMER DISTRIBUTION

where fire from other materials may incinerate Molicels. This section is provided solely in case of exposure, during fire fighting, to the combustion by-products. Hydrofluoric acid is not present in the product. Contact with Molicels causes none of the following symptoms.

Hydrofluoric acid is extremely corrosive. Contact with hydrogen fluoride fumes is to be avoided. Permissible exposure limit is 3 ppm. In case of contact with hydrogen fluoride fumes, immediately leave the area and seek first aid and emergency medical attention. Symptoms may have delayed onset. Fluoride ions penetrate skin readily causing destruction of deep tissue layers and even bone. Fluoride interferes with nerve impulse conduction causing severe pain or absence of sensations. Immediately flush eyes or skin with water for at least 20 minutes to neutralize the acidity and remove some fluoride. Remove and destroy all contaminated clothing and permeable personal possessions. Before re-use, impermeable possessions should be soaked in benzalkonium chloride after water washing. Following flushing of the affected areas, an iced aqueous solution of benzalkonium chloride or 2.5 % calcium gluconate gel should be applied to react with the fluoride ion. Compresses and wraps may be used for areas where immersion is not practical. Medicated dressing should be changed every 2 minutes. Exposure to hydrofluoric acid fumes sufficient to cause pain requires immediate hospitalization for monitoring for pulmonary edema.

Certification and Compliance Statements

Certification

Agilent Technologies certifies that this product met its published specifications at the time of shipment from the factory. Agilent further certifies that its calibration measurements are traceable to the United States National Institute of Standards and Technology, to the extent allowed by the Institute's calibration facility, and to the calibration facilities of other International Standards Organization members.

Manufacturer's Declaration

This product has been designed and tested in accordance with the standards listed on the Manufacturer's Declaration of Conformity, and has been supplied in a safe condition. The documentation contains information and warnings that must be followed by the user to ensure safe operation and to maintain the product in a safe condition.

Safety and Regulatory Information and Specifications Certification and Compliance Statements

Declaration of Conformity for Agilent E7495A

DECLARATION OF CONFORMITY	
According to ISO/IEC Guide 22 and CEN/CENELEC EN 45014	
Manufacturer's Name:	Agilent Technologies, Inc.
Manufacturer's Address:	1400 Fountaingrove Parkway Santa Rosa, CA 95403-1799 USA
Declares that the products	
Product Name:	Base Station Test Set
Model Number:	E7495A
Product Options:	This declaration covers all options of the above products.
Conform to the following product standards:	
EMC: IEC 61326:1997+A1:1998+A2:2000/ EN 61326:1997+A1:1998+A2:2001	
Standard	Limit
CISPR 11:1997 / EN 55011:1998/A-1999	Group 1, Class A
IEC 61000-4-2:1995+A1998 / EN 61000-4-2:1995	4 kV CD, 8 kV AD
IEC 61000-4-3:1995 / EN 61000-4-3:1995	3 V/m, 80 - 1000 MHz
IEC 61000-4-4:1995 / EN 61000-4-4:1995	0.5 kV sig., 1 kV power
IEC 61000-4-5:1995 / EN 61000-4-5:1996	0.5 kV L-L, 1 kV L-G
IEC 61000-4-6:1996 / EN 61000-4-6:1998	3 V, 0.15 - 80 MHz
IEC 61000-4-11:1994 / EN 61000-4-11:1998	1 cycle, 100%
Safety: IEC 61010-1:1990 + A1:1992 + A2:1995 / EN 61010-1:1993 +A2:1995 CAN/CSA-C22.2 No. 1010.1-92	
Supplementary Information:	
The products herewith comply with the requirements of the Low Voltage Directive 73/23/EEC and the EMC Directive 89/336/EEC and carry the CE-marking accordingly.	
	
Santa Rosa, CA, USA	19 December, 2002
Greg Pfeiffer/Quality Engineering Manager	
For further information, please contact your local Agilent Technologies sales office, agent or distributor.	

Rev. A 12/19/2002

Declaration of Conformity for Agilent E7495B

DECLARATION OF CONFORMITY	
According to ISO/IEC Guide 22 and CEN/CENELEC EN 45014	
Manufacturer's Name:	Agilent Technologies, Inc.
Manufacturer's Address:	1400 Fountaingrove Parkway Santa Rosa, CA 95403-1799 USA
Declares that the products	
Product Name:	Base Station Test Set
Model Number:	E7495B
Product Options:	This declaration covers all options of the above products.
Conform to the following product standards:	
EMC: IEC 61326:1997+A1:1998+A2:2000/ EN 61326:1997+A1:1998+A2:2001	
<u>Standard</u>	<u>Limit</u>
CISPR 11:1997 / EN 55011:1998/A-1999	Group 1, Class A
IEC 61000-4-2:1995+A1998 / EN 61000-4-2:1995	4 kV CD, 8 kV AD
IEC 61000-4-3:1995 / EN 61000-4-3:1995	3 V/m, 80 - 1000 MHz
IEC 61000-4-4:1995 / EN 61000-4-4:1995	0.5 kV sig., 1 kV power
IEC 61000-4-5:1995 / EN 61000-4-5:1996	0.5 kV L-L, 1 kV L-G
IEC 61000-4-6:1996 / EN 61000-4-6:1998	3 V, 0.15 - 80 MHz
IEC 61000-4-11:1994 / EN 61000-4-11:1998	1 cycle, 100%
Safety: IEC 61010-1:1990 + A1:1992 + A2:1995 / EN 61010-1:1993 +A2:1995 CAN/CSA-C22.2 No. 1010.1-92	
Supplementary Information: The products herewith comply with the requirements of the Low Voltage Directive 73/23/EEC and the EMC Directive 89/336/EEC and carry the CE-marking accordingly.	
	
Santa Rosa, CA, USA 26 September 2003	Paul Forrester/Quality Engineering Manager
For further information, please contact your local Agilent Technologies sales office, agent or distributor.	

Rev. A

Safety and Regulatory Information and Specifications
Certification and Compliance Statements

Compliance with German Noise Requirements

This is to declare that this test set is in conformance with the German Regulation on Noise Declaration for Machines (Laermangabe nach der Maschinenlaermrerordnung –3 GSGV Deutschland).

Acoustic Noise Emission/Geraeuschemission	
LpA <70 dB	LpA <70 dB
Operator Position	am Arbeitsplatz
Normal Position	normaler Betrieb
per ISO 7779	nach DIN 45635 t. 19

Compliance with Canadian EMC Requirements

This ISM device complies with Canadian ICES-001.
 Cet appareil ISM est conforme a la norme NMB du Canada.

Disposal of Batteries

 Do not throw batteries away but collect as small chemical waste.

E7495A/B Base Station Test Set Specifications

Specifications describe the test set's warranted performance and are valid over the entire operating/environmental range unless otherwise noted.

The E7495A/B Base Station Test Set has been tested to the specifications of IEC 529 “Degrees of Protection Provided by Enclosures (IP Code).” Using this standard, the E7495A/B is rated IPX4.

Supplemental Characteristics are intended to provide additional information useful in applying the test set by giving typical, but non-warranted performance parameters.

Characteristics and specifications are shown as follows:

- **Bold type** indicates a warranted, hard specification.
- Normal type indicates a nominal value. Nominal values are design center values and not normally tested during manufacturing.
- *Italics type* indicates a typical value. Typical performance is defined as 80% of the points over the specified range will meet or exceed the typical value.

Table 1 E7495A/B Base Station Test Set General Specifications

Unless otherwise noted, the following specifications apply to all measurements/tools using Port 2.	
Frequency accuracy:	
Using internal time base:	≤ 1 ppm with > 15 minute warm-up
Internal frequency aging	± 1 ppm aging/year
With GPS lock for > 15 minutes:	≤ 0.03 ppm
Input frequency range:	
	10 MHz to 2700 MHz
	Usable to 500 KHz (specifications and typical values do not apply below 375 MHz unless otherwise noted)
	(Refer to individual measurement tools below for applicable frequency ranges.)
Maximum input level (applies to Port 1 and Port 2):	+ 20 dBm (0.1 W), + 50 dBm with supplied attenuator

Safety and Regulatory Information and Specifications
E7495A/B Base Station Test Set Specifications

Table 1 E7495A/B Base Station Test Set General Specifications

Maximum input power without damaging instrument (applies to Port 1 and Port 2):	100 W (with external attenuator) 1 W (without attenuator)
Frequency and time reference:	
Can use internal timebase or external signal:	
GPS (external antenna supplied) Even second; pulse	
1.000 MHz:	≥ 0 dBm (E7495B only)
2.048 MHz:	≥ 0 dBm (E7495B only)
4.950 MHz:	≥ 0 dBm (E7495B only)
10.000 MHz:	≥ 0 dBm
13.000 MHz:	≥ 0 dBm (E7495B only)
15.000 MHz:	≥ 0 dBm (E7495B only)
19.6608 MHz:	≥ 0 dBm
Display:	
Scale:	1 to 20 dB / div. Settable in 1 dB increments.
Number of points:	256
Number of divisions:	10
40 dB Attenuator:	
Frequency range:	DC to 3000 MHz
Attenuation accuracy:	± 0.5 dB
Max power:	50 dBm (100 W)
Spectrum Analyzer / Tools	
Input frequency range (E7495A):	10 MHz to 2500 MHz (usable to 500 kHz)
Input frequency range (E7495B):	10 MHz to 2700 MHz (usable to 500 kHz)
Reference level range:	-150 to +100 dBm
Dynamic range:	+50 dBm to -150 dBm (with supplied external 40 dB attenuator) (30 Hz RBW)

Table 1 E7495A/B Base Station Test Set General Specifications

Input attenuation:	0 to 30 dB automatically selected. 10 dB controllable manually.
Amplitude accuracy (E7495A):	± 1 dB (100 MHz – 2500 MHz at 25 °C)
Amplitude accuracy (E7495B):	± 1 dB (100 MHz – 2700 MHz at 25 °C)
Adjacent Channel Power accuracy:	± 0.75 dBc
Resolution bandwidth:	10 Hz to 1 MHz, settable to 1 Hz precision
Span:	1 kHz to 2.6995 GHz
Trace update:	
Span:	2.6995 GHz (autocouple) = 5.1 seconds 60 MHz (autocouple) = 400 ms 1 MHz (100 Hz RBW) = 1.2 seconds
Simultaneous dynamic range:	>90 dB (CW signals at 300 kHz separation, span 500 kHz, 30 Hz RBW)
SSB phase noise:	≤ 85 dBc (30 kHz offset)
Spurious responses:	
Range control set to auto, high sensitivity mode internally generated.	
50 ohm load on input:	< 115 dBm
Crossing spurs:	≤ 0 dBc
Displayed average noise level:	-150 dBm (30 Hz RBW, 375 MHz to 1.5 GHz)
Port 2 VSWR:	< 2:1

Antenna/Cable Tester

For each of the following measurements, a short self-calibration procedure must be run prior to making the measurement.

Frequency range:	375 to 2500 MHz
Frequency resolution:	< 500 Hz
Immunity to interfering signals:	+20 dBm (with interference rejection turned on)

Safety and Regulatory Information and Specifications
E7495A/B Base Station Test Set Specifications

Table 1 E7495A/B Base Station Test Set General Specifications

Measurement speed:				
Full span:				<i>< 17 ms/point</i>
60 MHz span:				<i>< 7 ms/point</i>
Return loss (Port 1): With ≥ 4 averages and 375 MHz to 2200 MHz				
Range:				<i>E 7495B >40 dB, E 7495A >30 dB</i>
VSWR:				<i>E 7495B < 1.02, E 7495A < 1.07</i>
Resolution:				0.1 dB
Display range:				–5 to +150 dB
SWR range:				1 to 500
Distance to Fault (Port 1):				
Range (m):				1 m to 300 m
Resolution:				$(1.5 \times 10^8) (V_f)/(f_2 - f_1)$ Hz where V_f is relative propagating velocity of the cable. Typically 1% of measurement distance
VSWR:				1 to 500
Example table illustrating the effects of data points and span versus measured distance and resolution (V_f of 93.1%):				
	Data Points	Span	Measured distance	Resolution
	256	140 MHz	127.68 m	50 cm (19.6 inch)
	512	140 MHz	255.36 m	50 cm (19.6 inch)
	512	280 Mhz	127.68 m	25 cm (9.8 inch)
	1024	560 MHz	127.68 m	12.5 cm (4.9 inch)

Table 1 E7495A/B Base Station Test Set General Specifications

Insertion loss (Port 1 to Port 2):

Measurement uses supplied 10 dB pads.

Usable range:	<i>>100 dB wide range mode</i>
Accuracy:	± 1 dB (over 0 to 60 dB, ≥ 16 averages)
Readout resolution:	± 0.1 dB
Average insertion loss (readout) accuracy: ± 0.1 dB for	± 0.1 dB; for Range – 0 to 40 dB, Frequency (mobile phone bands) – 824 to 960 MHz, 1710 to 2170 MHz

Table 2 E7495A/B Base Station Test Set Option Specifications

cdmaOne / cdma2000 Tx Analyzer Option 200

Waveform quality accuracy (rho):	± 0.005 for $0.9 < p < 1.0$ (min. power at RF input > -85 dBm)
Pilot time alignment (tau):	± 500 nSec
Code domain power accuracy:	± 1.5 dBm absolute, ± 0.5 dB relative (> -20 dB)
Pilot power:	± 1.5 dB

cdma2000 1xEV-DO (Rev 0, Rev A) analyzer Option 205

Waveform quality accuracy (rho):	± 0.008 for $0.9 < p < 1.0$ (min. power at RF input > -70 dBc)
Frequency error:	± 20 Hz (with freq/time ref set to External Even Sec or GPS)
Pilot time alignment (tau):	± 500 nSec
Code domain power accuracy:	± 1.5 dBm absolute, ± 0.5 dB relative (> -20 dB)
Pilot + MAC power:	± 1.5 dB

Safety and Regulatory Information and Specifications

E7495A/B Base Station Test Set Specifications

Table 2 E7495A/B Base Station Test Set Option Specifications

RF Channel Scanner Option 220 (includes adjacent channel power)	
Measurement range	<i>+20 dBm to -125 dBm >375 MHz, 10 kHz RBW (up to +50 dBm with external attenuator)</i>
Frequency readout accuracy:	<i>Timebase accuracy +3 Hz + 1 / (measurement time X duty cycle)</i>
Frequency range (E7495A):	10 MHz to 2500 MHz
Frequency range (E7495B):	10 MHz to 2700 MHz
RF channel power:	± 1 dB (100 to 2500 MHz)
Adjacent channel power accuracy:	± 0.75 dBc
GSM/EDGE Tx Analyzer Options 230 / 235	
Frequency range:	<i>100 MHz to 2500 MHz (usable to 10 MHz)</i>
RF channel power:	± 1 dB (0 to -70 dBm)
Phase error floor:	<i>< 2.0 degrees RMS</i>
Phase error accuracy:	<i>< 1 degree RMS, 2 degrees ΔPhase Error Δ5 degrees</i>
Frequency error accuracy:	± 40 Hz with external reference
EVM Floor:	<3.5 % RMS
EVM accuracy:	<i><1.4 % RMS, 4 % ΔEVM Δ10 %</i>
W-CDMA/HSDPA Tx Analyzer Options 240 / 245	
Error Vector Magnitude (EVM): Conditions:	Resolution 0.1%; residual error <6% Min power at RF input >-65 dBm, 3GPP test model 4
Code Domain Power Accuracy:	<i>± 0.5 dB (for code channel power >-25 dB relative to total power, using test model 1 (with 16 DPCH, 32 DPCH, and 64 DPCH), test model 2 and test model 3 (with 16 DPCH and 32 DPCH), and test model 5 (with 8 HS-PDSCH)</i>
Scrambling Code Determination	<i>1 second (in auto mode)</i>
Code domain power display update	<i>1.5 seconds</i>

Table 2 E7495A/B Base Station Test Set Option Specifications

DC Bias Option 300 (Port 1) E7495B only	
DC Voltage:	+12.7 VDC <i>maximum</i>
DC Current:	800 mA <i>maximum</i>
Volt-Amps:	9.84 VA <i>maximum</i>
Signal Generator (CW) Option 500 (Port 1)	
Frequency range:	375 to 2500 MHz
Output level (E7495A):	−23 to −90 dBm
Output level (E7495B):	−5 to −90 dBm (<i>output unlevelled > −23 dBm</i>)
Level accuracy:	± 1 dB <i>between −25 to −85 dBm</i>
Phase error:	<i>At 30 KHz offset −90 dBc/Hz</i>
cdmaOne / cdma2000 1X, cdma2000 1xEV-DO, iDEN (requires Option 205) Reverse Link Signal Generator Option 510 (port 1)	
Frequency range:	375 to 2500 MHz
Output level (E7495A):	−47 to −95 dBm
Output level (E7495B):	−28 to −95 dBm
Level accuracy:	± 0.7 dB (<i>at 25 °C, −44 dBm to −95 dBm</i>) ± 1 dB (<i>at 25 °C, −28 dBm to −43 dBm</i>)
Power Meter Option 600	
Display	
Range:	−100 dBm to +100 dBm
Limits:	±−100 dBm
Resolution:	Settable 1.0, 0.1, 0.01, 0.001 in logarithmic mode or 1, 2, 3, or 4 significant digits in learner mode.

Safety and Regulatory Information and Specifications
E7495A/B Base Station Test Set Specifications

Table 2 E7495A/B Base Station Test Set Option Specifications

Instrumentation Accuracy:	
Absolute:	± 0.02 dB (log) or $\pm 0.5\%$ (linear) Add the corresponding power sensor linearity percentage.
Relative:	± 0.04 dB (log) or $\pm 1.0\%$ (linear) Add the corresponding power sensor linearity percentage.
Zero set accuracy:	
Zero set is the digital zero with an N8482A sensor ± 63 nW	
Power reference accuracy:	
Power output:	1.00 mW (0.0 dBm) traceable to the U.S. National Institute of Standards and Technology (NIST).
Accuracy:	$\pm 1.2\%$ worst case ($\pm 0.9\%$ rss) for one year
VSWR:	< 1.08
External attenuator:	
Max power:	100 watts
Attenuation:	40 dB ± 0.5 dB
Power meter Option 600 with Agilent N8482A-CFT power sensor (also supports Agilent 8481A/8482A, N8481A-CFT and 8481D power sensors)	
Frequency Range:	100 kHz to 6 GHz
VSWR	
100 kHz to 300 kHz:	< 1.52
300 kHz to 1 MHz:	< 1.12
1 MHz to 2 GHz:	< 1.06
2 GHz to 6 GHz:	< 1.07
Power linearity:	
- 1 dBm to +15 dBm; $\pm 0.52\%$	
+15 dBm to +20 dBm; $\pm 0.80\%$	
Maximum power:	300 mW average. 15W Peak for 2 μs
Measurement noise:	< 114 nW
Zero drift:	$< \pm 7$ nW

Table 2 E7495A/B Base Station Test Set Option Specifications

T1 Analyzer Option 700

Receive level (line 1 and line 2):	+6 dB DSC to –36 dB DSX or 100 mv peak-to-peak to 12 V peak-to-peak Receive frequency (line 1 and line 2) display receive frequency (5 ppm) “Loopback” control send CSU or NIU loop codes CSU/NIU emulation respond to CSU or NIU loop codes
Electrical interface:	
Connectors, Rx, Tx:	Primary and secondary ports
Output:	Conforms to TR-TSY-000499, CCITT Rec.G.703 AT&T Pubs CB113, CB119, CB132, CB143 PUB62508 and PUB62411 pulse shape specifications when terminated in 100 ohms and 0 dB line build-out is selected
Line build out	0 dB, –7.5, –15 dB
Input:	
Terminate:	DSX +6 dB to DSX –36 dB, 100 ohms
Monitor:	DSX –14 dB to DSX –40 dB, 100 ohms
Bridge	DSX + 6 dB to DSX –36 dB, > 1000 ohms
Clock:	1.544 MHz
Internal:	± 5 ppm
External:	± 300 ppm
Recovered:	± 300 ppm
Transmitter and receiver:	
Framing: Unframed:	D3 / D4 and ESF
Channel formats:	Full T1, 64 X 1
Test patterns:	QRSS, all Os, 1:7, 2 in 8, 3 in 24, all 1s, T-1-Daly, 55 OCTET
Error injection type:	BPV, frame, CRC, pattern (logic)
Error rate:	Single
Alarm inject type:	LOS, LOF, yellow, AIS, idle (CDI)

Safety and Regulatory Information and Specifications

E7495A/B Base Station Test Set Specifications

Table 2 E7495A/B Base Station Test Set Option Specifications

E1 Analyzer Option 710	
Error detect:	Code (BPV), FAS, MFAS,CRC-4, Far End Block (FEBE), Pattern, Fame Slip
Error rate calculation:	Bit-Error-Rate, Error Free Seconds, Errored seconds
Alarm detect:	AIS, TS-16 AIS, FAST DISTANT, MFAS DISTANT
Clock and frame slips:	Clock Slips, Frame slips, Peak Wander, Clock slip rate
Auto configuration:	Automatically detect line code, framing and test pattern
Receive level (line 1 and line 2):	+6 dB DSX to –36 dB DSX or 100 mv p-to-p to 12 v p-to-p
Receive frequency (line 1):	Display receive frequency (± 5 ppm)
Channel access:	Output audio to system
Delay measurement:	Measure delay in unit intervals for “looped-back” signal
Electrical Interface:	
Connectors, Rx, Tx:	Primary and secondary ports
Output:	Conforms to ITU-T Rec.G.703
Line code:	AMI, HDB3
Impedance:	Terminate: 75 ohms $\pm 5\%$ Bridge: > 1000 ohms
Input:	Terminate: DSX +6 dB to DSX –36 dB
Bridge:	DSX +6 dB to DSX –36 dB
Clock:	2.048 MHz
Internal:	± 5 ppm
External:	± 300 ppm
Recovered:	± 300 ppm
Transmitter and receiver	
Framing:	Unframed, PCM-30, PCM-30 with CRC, PCM-31, PCM-31 with CRC
Channel Formats:	Full E1, 64x1

Table 2 E7495A/B Base Station Test Set Option Specifications

Test Patterns:	(True or Inverse, ITU Rec) 2^6-1 (Q6&Q5), 2^9-1 (V.52), $2^{11}-1$ (0.152), $2^{15}-1$ (0.151) $2^{20}-1$ (V.57), QRSS, $2^{23}-1$ (0.151), All 0's, 1:7, 1:3, 1:1, All 1's
Error injection	
Type:	Code (BPV), FAS, MFAS, CRC-4, Far End Block (FEBE), Pattern
Error rate:	Single Alarm generation AIS, TS-16 AIS, FAS DISTANT, MFAS DISTANT, Loss of signal, Loss of Frame

Safety and Regulatory Information and Specifications
E7495A/B Base Station Test Set Specifications

Table 3 E7495A/B Base Station Test Set General Specifications

Display:	Transflective VGA and color LCD
Dimensions	
Height:	11.6", 295 mm
Width:	14.5", 368 mm
Depth:	5.3", 135 mm
Weight (without batteries):	20 lbs, 9.1 kg fully hardware optioned
Power supply:	
Internal:	<i>Lithium Ion battery: 10.8 volts, 6.0 Ah (1 NI2040AG shipped standard, will accept 2 batteries)</i>
External:	DC Input +9 V to +25 V dc (55 Watts)
Battery life:	<i>Approximately 1.5 hour per battery (time varies depending upon instrument mode)</i>
Interface Ports:	Two RS 232 (DB-9) (reserved for future use) Two USB 1.1 (reserved for future use) One LAN Port 10 Base T Built-in speaker PCMCIA Card slot CompactFlash memory (type 1 & 2) Stereo headphone jack General purpose input/output - TTL level (reserved for future use)

Table 3 E7495A/B Base Station Test Set General Specifications

Inputs	
Port 2 RF in:	50 ohm type N
External DC input:	+9 V to + 25 V DC (55 Watts)
Frequency reference:	
Input power:	<i>−10 to + 10 dBm</i>
Connector:	<i>50 ohm BNC</i>
Even second:	
Connector:	<i>High impedance BNC</i>
Level:	<i>TTL compatible</i>
GPS antenna:	
Connector:	SMA
Output:	5 V at 50 mA
Outputs:	
Port 1 RF Out/SWR Connector:	<i>50 ohm type N</i>
Power reference:	<i>50 ohm type N; SWR < 1.06</i>
Optional Connectors:	
Option 600 power meter:	
Outputs:	50 ohm type N power reference
Inputs:	Sensor input for N848x series sensors
Option 700 T1 analyzer:	
Out puts:	(2) Bantum outputs; Tx primary and secondary
Inputs:	(2) Bantum inputs; Rx primary and secondary
Option 710 E1 analyzer:	
Outputs:	(2) 75 ohm BNC outputs; Tx primary and secondary
Inputs:	(2) 75 ohm BNC inputs; Rx primary and secondary
Operating temperature specified range:	<i>−10 ° to 50 °C; 14 ° to 122 °F</i>
Storage temperature:	<i>−40 ° to 70 °C; −40 ° to 158 °F</i>
Calibration Cycle:	1 year
Warranty Duration:	1 year

Safety and Regulatory Information and Specifications

E7495A/B Base Station Test Set Specifications

Battery Pack Specifications



Product Safety Data Sheet

PRODUCT NAME: Inspired Energy Rechargeable Battery Pack Model: NI2040AG Rev2
 ALTERNATE NAME: 1420-0883
 TRADE NAME: NI2040AG Rev 2 / NI2040AG2 Volts: 10.8
 CHEMICAL SYSTEM: Lithium Ion Approximate Weight: 484 g
 Date Prepared: November 13th 2002 Updated April 7th 2003

SECTION I – MANUFACTURER INFORMATION

Inspired Energy, Inc.
 12705 N US Hwy 441
 Alachua, FL 32615
 Telephone: (888) 5-INSPIRE (888-546-7747)

SECTION II – HAZARDOUS INGREDIENTS

Important Note:

The battery should not be opened or burned. Exposure to the ingredients contained within or their combustion products could be harmful.

Please refer to the attached cell Material Safety Data Sheet Filename: MSDS Moli 18650 up to 2400mAh.pdf

SECTION III – OPERATING PARAMETERS

Maximum Charge Voltage: 12.6 V
 Minimum Charge Voltage: 7.5 V
 Maximum Charge Current: 3.0 A
 Maximum Discharge Current: 6.0 A

Recommended Charging Method: Use an Agilent approved charger to provide a 3.0 A current limited constant voltage of 12.6 V. The charging cycle will terminate when the average current falls below 150mA.

The information contained within is provided for your information only. This battery is an article pursuant to 29 CFR 1910.1200 and, as such, is not subject to the OSHA Hazard Communication standard requirement for preparation of a material safety data sheet. The information and recommendations set forth herein are made in good faith and are believed to be accurate as of the date of preparation. However, INSPIRED ENERGY, INC. MAKES NO WARRANTY, EITHER EXPRESSED OR IMPLIED, WITH RESPECT TO THIS INFORMATION AND DISCLAIMS ALL LIABILITY FROM RELIANCE ON IT.

Inspired Energy, Inc. 12705 US Hwy 441 N, Alachua, FL 32615
 US toll free: 1-888-5-INSPIRE (1-888-546-7747) Tel: 386 462 3676 Fax: 386 462 6765
 www.inspired-energy.com

“Using, Inspecting, and Cleaning RF Connectors” on page 648

“Repeatability” on page 648

“RF Cable and Connector Care” on page 648

“Proper Connector Torque” on page 649

“Connector Wear and Damage” on page 650

“Cleaning Procedure” on page 650

Using, Inspecting, and Cleaning RF Connectors

Taking proper care of cables and connectors will protect your test set's ability to make accurate measurements. Inaccurate measurements often result from improperly made connections or dirty or damaged connectors.

Worn, out-of-tolerance, or dirty connectors degrade the accuracy and repeatability of measurements. For more information on connector care, refer to the documentation that came with your calibration kit.

Repeatability

If you make two identical measurements with your test set, the differences should be so small that they do not affect the value of the measurement. Repeatability (the amount of similarity from one measurement to another of the same type) can be affected by:

- Dirty or damaged connectors
- Connections that have been made without using proper torque techniques (this applies primarily when connectors in the test set have been disconnected, then reconnected)

CAUTION

This test set contains test sets and devices that are static-sensitive. Always take proper electrostatic precautions before touching the center conductor of any connector, or the center conductor of any cable that is connected to the test set.

RF Cable and Connector Care

Connectors are the most critical link in a precision measurement. These devices are manufactured to extremely precise tolerances and must be used and maintained with care to protect the measurement accuracy and repeatability of your test set.

To Extend the Life of Your Cables or Connectors:

- Avoid repeated bending of cables—a single sharp bend can ruin a cable instantly.
- Avoid repeated connection and disconnection of cable connectors.
- Inspect the connectors before connection; look for dirt, nicks, and other signs of damage or wear. A bad connector can ruin the good connector instantly.

- Clean dirty connectors. Dirt and foreign matter can cause poor electrical connections and may damage the connector.
- Minimize the number of times you bend cables.
- Never bend a cable at a sharp angle.
- Do not bend cables near the connectors.
- If any of the cables will be flexed repeatedly, buy a back-up cable. This will allow immediate replacement and will minimize your test set’s down time.

Before Connecting the Cables to Any Device:

- Check all connectors for wear or dirt.
- When making the connection, torque the connector to the proper value.

Proper Connector Torque

- Provides more accurate measurements
- Keeps moisture out the connectors
- Eliminates radio frequency interference (RFI) from affecting your measurements

The torque required depends on the type of connector. Refer to [Table 22-1](#). Do not overtighten the connector.

CAUTION

Never exceed the recommended torque when attaching cables.

Table 22-1 Proper Connector Torque

Connector	Torque cm-kg	Torque N-cm	Torque in-lbs	Wrench part number
Type-N	52	508	45	8710-1935
3.5 mm	9.2	90	8	8710-1765
SMA	5.7	56	5	8710-1582

Connector Wear and Damage

Look for metal particles from the connector threads and other signs of wear (such as discoloration or roughness). Visible wear can affect measurement accuracy and repeatability. Discard or repair any device with a damaged connector. A bad connector can ruin a good connector on the first mating. A magnifying glass or jeweler's loupe is useful during inspection.

Cleaning Procedure

1. Blow particulate matter from connectors using an environmentally-safe aerosol such as Ultrajet. This product is recommended by the United States Environmental Protection Agency and contains chlorodifluoromethane.
2. Use an alcohol wipe to wipe connector surfaces. Wet a small swab with alcohol (from the alcohol wipe) and clean the connector with the swab.
3. Allow the alcohol to evaporate off the connector before making connections

CAUTION

Do not allow excessive alcohol to run into the connector. Excessive alcohol entering the connector collects in pockets in the connector's internal parts. The liquid will cause random changes in the connector's electrical performance. If excessive alcohol gets into a connector, lay it aside to allow the alcohol to evaporate. This may take up to three days. If you attach that connector to another device it can take much longer for trapped alcohol to evaporate.

[“Adjustment, Maintenance, or Repair of the Base Station Test Set” on page 652](#)

[“Returning your Base Station Test Set for Service” on page 653](#)

[“Preparing the Agilent E7495A/B for Shipping” on page 654](#)

Adjustment, Maintenance, or Repair of the Base Station Test Set

Any adjustment, maintenance, or repair of the E7495A/B Base Station Test Set must be performed by qualified personnel. Contact your customer engineer through your local Agilent Technologies Service Center. You may contact Agilent through the Internet or by telephone. For contact information refer to “[Contacting Agilent Technologies](#)” on page 43.

NOTE

For specific test set packing instructions, refer to “[Returning your Base Station Test Set for Service](#)” on page 653.

Returning your Base Station Test Set for Service

The instructions in this section explain how to properly package the system for return to Agilent Technologies.

NOTE

Please notify Agilent Technologies before returning your system for service. Any special arrangements for the system can be discussed at this time. This will help Agilent Technologies repair and return your system as quickly as possible.

Warranty

If the system is still under warranty or is covered by an Agilent Technologies maintenance contract, it will be repaired under the terms of the warranty or contract. If the system is no longer under warranty or is not covered by an Agilent Technologies maintenance plan, Agilent Technologies will notify you of the cost of the repair after examining the unit.

When a system is returned to Agilent Technologies for servicing, it must be adequately packaged (see [“Preparing the Agilent E7495A/B for Shipping” on page 654](#)) and have a complete description of the failure symptoms attached.

When describing the failure, please be as specific as possible about the nature of the problem. Include copies of additional failure information (such as receiver or computer failure settings, data related to system failure, and error messages) along with the system being returned.

Preparing the Agilent E7495A/B for Shipping

CAUTION

Cover electrical connectors to protect sensitive components from electrostatic damage. Test set damage can result from using packaging materials other than the original materials. Never use styrene pellets as packaging material. They do not adequately cushion the system or prevent it from shifting in the carton. They may also cause system damage by generating static electricity.

Step	Notes
1 Write a complete description of the failure and attach it to the system.	Include any specific performance details related to the problem. The following information should be returned with the system: • Type of service required • Date system was returned for repair • Description of the problem: • Whether problem is constant or intermittent • Whether system is temperature-sensitive • Whether system is vibration sensitive • System settings required to reproduce the problem • Error Code • Performance data • Company Name and return address • Name and phone number of technical contact person • Model number of returned system • Full serial number of returned system • List of any accessories returned with the system

Step	Notes
2	Caution: Cover all front and rear panel connectors that were originally covered when you first received the system.
3	Pack the system in the original shipping containers. Original materials are available through Agilent Technologies office. See step 4 for more information.
4	Wrap the system in anti-static plastic to reduce the possibility of damage caused by electrostatic discharge. For systems weighing less than 54 kg (120 lbs.), use a double-walled, corrugated cardboard carton of 159 kg (350 lbs.) test strength. The carton must be large enough to allow 3 to 4 inches on all sides of the system for packing material, and strong enough to accommodate the weight of the system. Surround the equipment with 3 to 4 inches of packing material, to protect the system and prevent it from moving in the carton. If packing foam is not available, the best alternative is S.D-240 Air Cap™ from Sealed Air Corporation (Commerce, California 90001). Air Cap looks like a plastic sheet filled with air bubbles. Use the pink (anti-static) Air Cap to reduce static electrical damage. Wrapping the system several times in this material will protect the system and prevent it from moving in the carton.
5	Seal the carton with strong nylon adhesive tape and mark it “FRAGILE, HANDLE WITH CARE”.

Returning the Test Set for Service

Returning your Base Station Test Set for Service

Step	Notes
6	Retain copies of all shipping papers.

Here you will find a list of the more common abbreviations and acronyms used in the rest of this manual.

Glossary of Abbreviations and Acronyms Used

Table 24-1

Access Network (AN)	The network equipment providing data connectivity between a packet switched data network (typically the Internet) and the access terminals. Connectivity is typically provided at the Link Layer (PPP). Equivalent terminology to BTS.
Access Terminal (AT)	A device providing data connectivity to a user. An access terminal may be connected to a computing device such as a laptop personal computer or may be self contained data device such as a personal digital assistant. Equivalent terminology to MS.
BS or BTS	Base Station
CDMA	Code Division Multiple Access.
CPICH	Common Pilot Channel
DPCH	Dedicated Physical Channel/Dedicated Pilot Channel
DSP	Digital Signal Processing
DTF	Distance to Fault
EVM	Error Vector Magnitude.
FDR	Frequency Domain Reflectometry
FFT	Fast Fourier Transform
FIR Filter	
GPS	Global Positioning System. Global Positioning System comprises of multiple satellites all of which orbit the earth twice a day. Users with a GPS receiver use timing information from the satellites in order to triangulate their position on the earth surface.

Table 24-1

GUI	Graphical User Interface
HS-DSCH	High Speed Downlink Channel
HS-PDSCH	High Speed Physical Downlink Shared Channel
HS-SCCH	High Speed Shared Control Channel
HSDPA	High Speed Data Packet Access
MAC Channel	Medium Access Control Channel.
MS	Mobile Station
OTA	Over The Air
P-CCPCH	Primary Common Control Physical Channel
P-SCH	Primary Synchronization Channel
PCDE	Peak Code Domain Error
PICH	Paging Indication Channel/Pilot Channel
PSA	Agilent Technologies Performance Spectrum Analyzer (Model Numbers E4440A, E4443A, E4445A, E4448A).
PN Offset	
PN Sequence	Pseudo noise sequence. A periodic binary sequence.
QPSK	Quadrature Phase Shift Keying. QPSK is a digital frequency modulation technique used for sending data over coaxial cable networks. Since it's both easy to implement and fairly resistant to noise, QPSK is used primarily for sending data from the cable subscriber upstream to the Internet.
Reverse Activity (RA)	
Reverse Power Control (RPC)	

Glossary

Glossary of Abbreviations and Acronyms Used

Table 24-1

RF	Radio Frequency. Any frequency within the electromagnetic spectrum normally associated with radio wave propagation.
S-CCPCH	Secondary Common Control Physical Channel
S-SCH	Secondary Synchronization Channel
SCH	Synchronization Channel
SEM	Spectrum Emission Mask.
TDR	Time Domain Reflectometry.
TSTD	Time Switched Transmit Diversity
VSA	Agilent Technologies Vector Signal Analyzer.
VSWR	Voltage Standing Wave Ratio. A standing wave may be formed when a wave is transmitted into one end of a transmission line and is reflected from the other end by an impedance mismatch. VSWR is the ratio of maximum to minimum voltage in a standing wave pattern.
W-CDMA	Wideband Code Division Multiple Access
8PSK	8 Phase Shift Keying. This is a modulation technique in which the carrier can exist in one of eight different states. As such, each state can represent three bits - 000 through 111. This modulation technique is used in EDGE (Enhanced Data rates for Global Evolution).
16QAM	

“Where to Find Additional Copyright Information” on page 662

“” Copyright 1999 The Apache Software Foundation’. All rights reserved. The Apache Software License, Version 1.1” on page 662

“” Copyright 1994-2004 Sun Microsystems’, Inc. All Rights Reserved.” on page 663

“” Copyright 1989, 1991 Free Software Foundation, Inc. GNU General Public License Version 2, June 1991.” on page 663

“” Copyright 1991, 1999 Free Software Foundation, Inc. GNU Lesser General Public License Version 2.1, February 1999.” on page 668

“” Copyright 1998-2004, CEE-J’, Skelmir, LLC. All rights reserved.” on page 676

Copyright Information

Where to Find Additional Copyright Information

Additional Copyright information is available on the Documentation CD-ROM and in the front matter of this manual.

© Copyright 1999 The Apache Software Foundation™. All rights reserved. The Apache Software License, Version 1.1

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. The end-user documentation included with the redistribution, if any, must include the following acknowledgment: "This product includes software developed by the Apache Software Foundation (<http://www.apache.org>)."
Alternately, this acknowledgment may appear in the software itself, if and wherever such third-party acknowledgments normally appear.
4. The names "Xerces" and "Apache Software Foundation" must not be used to endorse or promote products derived from this software without prior written permission. For written permission, please contact apache@apache.org.
5. Products derived from this software may not be called "Apache", nor may "Apache" appear in their name, without prior written permission of the Apache Software Foundation.

THIS SOFTWARE IS PROVIDED ``AS IS" AND ANY EXPRESSED OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE APACHE SOFTWARE FOUNDATION OR ITS CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

=====

This software consists of voluntary contributions made by many individuals on behalf of the Apache Software Foundation and was originally based on software copyright © 1999, International Business Machines, Inc., <http://www.ibm.com>. For more information on the Apache Software Foundation, please see <http://www.apache.org>.

© **Copyright 1994-2004 Sun Microsystems™, Inc. All Rights Reserved.**

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistribution of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistribution in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

Neither the name of Sun Microsystems, Inc. or the names of contributors may be used to endorse or promote products derived from this software without specific prior written permission.

This software is provided “AS IS,” without a warranty of any kind. ALL EXPRESS OR IMPLIED CONDITIONS, REPRESENTATIONS AND WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT, ARE HEREBY EXCLUDED. SUN MICROSYSTEMS, INC. (“SUN”) AND ITS LICENSORS SHALL NOT BE LIABLE FOR ANY DAMAGES SUFFERED BY LICENSEE AS A RESULT OF USING, MODIFYING OR DISTRIBUTING THIS SOFTWARE OR ITS DERIVATIVES. IN NO EVENT WILL SUN OR ITS LICENSORS BE LIABLE FOR ANY LOST REVENUE, PROFIT OR DATA, OR FOR DIRECT, INDIRECT, SPECIAL, CONSEQUENTIAL, INCIDENTAL OR PUNITIVE DAMAGES, HOWEVER CAUSED AND REGARDLESS OF THE THEORY OF LIABILITY, ARISING OUT OF THE USE OF OR INABILITY TO USE THIS SOFTWARE, EVEN IF SUN HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

You acknowledge that this software is not designed, licensed or intended for use in the design, construction, operation or maintenance of any nuclear facility.

© **Copyright 1989, 1991 Free Software Foundation, Inc.**
GNU General Public License Version 2, June 1991.

Free Software Foundation, Inc. 59 Temple Place, Suite 330, Boston, MA

Copyright Information

02111-1307 USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

GNU GENERAL PUBLIC LICENSE TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The “Program”, below, refers to any such program or work, and a “work based on the Program” means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term “modification”.) Each licensee is addressed as “you”.

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.
- b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.
- c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary

way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

- a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files,

Copyright Information

plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular

circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and “any later version”, you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING

THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM “AS IS” WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

© **Copyright 1991, 1999 Free Software Foundation, Inc.**
GNU Lesser General Public License Version 2.1, February 1999.

Free Software Foundation, Inc. 59 Temple Place, Suite 330, Boston, MA
 02111-1307 USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed. [This is the first released version of the Lesser GPL. It also counts as the successor of the GNU Library Public License, version 2, hence the version number 2.1.]

GNU LESSER GENERAL PUBLIC LICENSE TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License Agreement applies to any software library or other program which contains a notice placed by the copyright holder or other authorized party saying it may be distributed under the terms of this Lesser General Public License (also called “this License”). Each licensee is addressed as “you”.

A “library” means a collection of software functions and/or data prepared so as to be conveniently linked with application programs (which use some of those functions and data) to form executables.

The “Library”, below, refers to any such software library or work which has been distributed under these terms. A “work based on the Library” means either the

Library or any derivative work under copyright law: that is to say, a work containing the Library or a portion of it, either verbatim or with modifications and/or translated straightforwardly into another language. (Hereinafter, translation is included without limitation in the term “modification”.)

“Source code” for a work means the preferred form of the work for making modifications to it. For a library, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the library.

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running a program using the Library is not restricted, and output from such a program is covered only if its contents constitute a work based on the Library (independent of the use of the Library in a tool for writing it). Whether that is true depends on what the Library does and what the program that uses the Library does.

1. You may copy and distribute verbatim copies of the Library's complete source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and distribute a copy of this License along with the Library.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Library or any portion of it, thus forming a work based on the Library, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- a) The modified work must itself be a software library.
- b) You must cause the files modified to carry prominent notices stating that you changed the files and the date of any change.
- c) You must cause the whole of the work to be licensed at no charge to all third parties under the terms of this License.
- d) If a facility in the modified Library refers to a function or a table of data to be supplied by an application program that uses the facility, other than as an argument passed when the facility is invoked, then you must make a good faith effort to ensure that, in the event an application does not supply such function or table, the facility still operates, and performs whatever part of its purpose remains meaningful. (For example, a function in a library to compute square roots has a purpose that is entirely well-defined independent of the application. Therefore, Subsection 2d requires that any application-supplied function or table used by this function must

Copyright Information

be optional: if the application does not supply it, the square root function must still compute square roots.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Library, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Library, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Library.

In addition, mere aggregation of another work not based on the Library with the Library (or with a work based on the Library) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may opt to apply the terms of the ordinary GNU General Public License instead of this License to a given copy of the Library. To do this, you must alter all the notices that refer to this License, so that they refer to the ordinary GNU General Public License, version 2, instead of to this License. (If a newer version than version 2 of the ordinary GNU General Public License has appeared, then you can specify that version instead if you wish.) Do not make any other change in these notices.

Once this change is made in a given copy, it is irreversible for that copy, so the ordinary GNU General Public License applies to all subsequent copies and derivative works made from that copy.

This option is useful when you wish to copy part of the code of the Library into a program that is not a library.

4. You may copy and distribute the Library (or a portion or derivative of it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange.

If distribution of object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place satisfies the requirement to distribute the source code, even though third parties are not compelled to copy the source along with the object code.

5. A program that contains no derivative of any portion of the Library, but is designed to work with the Library by being compiled or linked with it, is called a

“work that uses the Library”. Such a work, in isolation, is not a derivative work of the Library, and therefore falls outside the scope of this License.

However, linking a “work that uses the Library” with the Library creates an executable that is a derivative of the Library (because it contains portions of the Library), rather than a “work that uses the library”. The executable is therefore covered by this License. Section 6 states terms for distribution of such executables.

When a “work that uses the Library” uses material from a header file that is part of the Library, the object code for the work may be a derivative work of the Library even though the source code is not. Whether this is true is especially significant if the work can be linked without the Library, or if the work is itself a library. The threshold for this to be true is not precisely defined by law.

If such an object file uses only numerical parameters, data structure layouts and accessories, and small macros and small inline functions (ten lines or less in length), then the use of the object file is unrestricted, regardless of whether it is legally a derivative work. (Executables containing this object code plus portions of the Library will still fall under Section 6.)

Otherwise, if the work is a derivative of the Library, you may distribute the object code for the work under the terms of Section 6. Any executables containing that work also fall under Section 6, whether or not they are linked directly with the Library itself.

6. As an exception to the Sections above, you may also combine or link a “work that uses the Library” with the Library to produce a work containing portions of the Library, and distribute that work under terms of your choice, provided that the terms permit modification of the work for the customer's own use and reverse engineering for debugging such modifications.

You must give prominent notice with each copy of the work that the Library is used in it and that the Library and its use are covered by this License. You must supply a copy of this License. If the work during execution displays copyright notices, you must include the copyright notice for the Library among them, as well as a reference directing the user to the copy of this License. Also, you must do one of these things:

a) Accompany the work with the complete corresponding machine-readable source code for the Library including whatever changes were used in the work (which must be distributed under Sections 1 and 2 above); and, if the work is an executable linked with the Library, with the complete machine-readable “work that uses the Library”, as object code and/or source code, so that the user can modify the Library and then relink to produce a modified executable containing the modified Library. (It is understood that the user who changes the contents of definitions files in the Library will not necessarily be able to recompile the application to use the modified definitions.)

Copyright Information

b) Use a suitable shared library mechanism for linking with the Library. A suitable mechanism is one that (1) uses at run time a copy of the library already present on the user's computer system, rather than copying library functions into the executable, and (2) will operate properly with a modified version of the library, if the user installs one, as long as the modified version is interface-compatible with the version that the work was made with.

c) Accompany the work with a written offer, valid for at least three years, to give the same user the materials specified in Subsection 6a, above, for a charge no more than the cost of performing this distribution.

d) If distribution of the work is made by offering access to copy from a designated place, offer equivalent access to copy the above specified materials from the same place.

e) Verify that the user has already received a copy of these materials or that you have already sent this user a copy.

For an executable, the required form of the “work that uses the Library” must include any data and utility programs needed for reproducing the executable from it. However, as a special exception, the materials to be distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

It may happen that this requirement contradicts the license restrictions of other proprietary libraries that do not normally accompany the operating system. Such a contradiction means you cannot use both them and the Library together in an executable that you distribute.

7. You may place library facilities that are a work based on the Library side-by-side in a single library together with other library facilities not covered by this License, and distribute such a combined library, provided that the separate distribution of the work based on the Library and of the other library facilities is otherwise permitted, and provided that you do these two things:

a) Accompany the combined library with a copy of the same work based on the Library, uncombined with any other library facilities. This must be distributed under the terms of the Sections above.

b) Give prominent notice with the combined library of the fact that part of it is a work based on the Library, and explaining where to find the accompanying uncombined form of the same work.

8. You may not copy, modify, sublicense, link with, or distribute the Library except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense, link with, or distribute the Library is void, and will automatically

terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

9. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Library or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Library (or any work based on the Library), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Library or works based on it.

10. Each time you redistribute the Library (or any work based on the Library), the recipient automatically receives a license from the original licensor to copy, distribute, link with or modify the Library subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties with this License. _

11. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Library at all. For example, if a patent license would not permit royalty-free redistribution of the Library by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Library.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply, and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

Copyright Information

12. If the distribution and/or use of the Library is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Library under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

13. The Free Software Foundation may publish revised and/or new versions of the Lesser General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Library specifies a version number of this License which applies to it and “any later version”, you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Library does not specify a license version number, you may choose any version ever published by the Free Software Foundation.

14. If you wish to incorporate parts of the Library into other free programs whose distribution conditions are incompatible with these, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

15. BECAUSE THE LIBRARY IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE LIBRARY, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE LIBRARY “AS IS” WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE LIBRARY IS WITH YOU. SHOULD THE LIBRARY PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

16. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE LIBRARY AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING

ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE LIBRARY (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE LIBRARY TO OPERATE WITH ANY OTHER SOFTWARE), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Copyright Information

© Copyright 1998-2004, CEE-J™, Skelmir, LLC. All rights reserved.

Symbols

, 103, 206, 207, 208, 243, 246, 247, 248

Numerics

1xEV-DO analyzer

- adding a marker, 90
- basic measurement, 63
- common measurements, 61
- data channel modulation, 107, 112
- estimated MAC Rho, 106, 112
- estimated pilot Rho, 106, 111
- frequency, 104
- frequency error, 104, 109
- frequency error limits, 95
- idle data power, 111
- idle on/off ratio limits, 97
- idle slots, 111
- inactive channel high limits, 100
- interpretation of measurement results, 109
- interpreting the display, 75
- MAC rho limits, 99
- max inactive channel, 107, 112
- measurement time limits, 96
- noise floor, 112
- non-idle power, 110
- optional measurement settings, 77
- pass/fail limits, 92
- pilot + MAC power, 110
- pilot rho limits, 98
- PN offset, 104, 109
- rf out loss, 103
- rho (MAC) limits, 99
- rho (pilot) limits, 98
- setting 1xEV-DO transmitter reference level, 82
- setting CDP type, 85
- setting channel or frequency step, 77
- setting frequency/time reference, 81

- setting measurement offset, 84
- setting measurement time, 83
- setting PN increment, 79
- setting slot threshold level, 85
- setting units, 82
- signal generator, 101
- time offset, 109
- uses, 61

1xEV-DO over air

- adding a marker, 90
- basic measurement, 71
- criteria for making valid measurements, 69
- data channel modulation, 107, 112
- displaying location information using GPS, 74
- estimated MAC Rho, 106, 112
- estimated pilot Rho, 106, 111
- frequency, 104
- frequency error, 104, 109
- frequency error limits, 95
- idle data power, 111
- idle on/off ratio limits, 97
- idle slots, 111
- inactive channel high limits, 100
- interpretation of measurement results, 109
- interpreting the display, 75
- loss (rf out), 103
- MAC rho limits, 99
- max inactive channel, 107, 112
- measurement time limits, 96
- noise floor, 112
- non-idle power, 110
- optional measurement settings, 77
- pass/fail limits, 92
- pilot + MAC power, 110
- pilot rho limits, 98
- PN offset, 104, 109
- rf out loss, 103
- rho (MAC) limits, 99
- rho (pilot) limits, 98

- setting active channel threshold and auto threshold levels, 80
- setting CDP type, 85
- setting channel or frequency step, 77
- setting frequency/time reference, 81
- setting measurement offset, 84
- setting measurement time, 83
- setting multipath power limit, 87
- setting pilot dominance, 86
- setting PN offset, 79
- setting slot threshold level, 85
- setting units, 82
- time offset, 109

A

- abbreviations used, 658
- acp
 - analyzer input gain, 154, 419
 - sensitivity, 154, 419
- acronyms, 658
- active channel threshold level, 562, 600
- active code channel table
 - HSDPA, 553, 593
 - W-CDMA, 553
- adjacent channel power, 142
- autoranging, 153
- basic measurement, 143
- format, 145
- measurement settings, 146
- pass/fail limits, 155
- peak power, 152
- range control, 153
- adjustment, maintenance, or repair of test set, 652
- Agilent
 - customer assistance, 43
 - sales offices, 43
- analyzer input gain
 - acp, 154, 419

channel scanner, 267
 auto scan mode bar count, 354
 average & averaging, 52, 88, 127, 150, 197, 237, 272, 294, 368, 396, 423, 560, 598
 averaging restart, 53, 89, 129, 151, 198, 238, 273, 295, 370, 397, 424, 561, 600

B

batteries
 built-in battery gauge, 166
 caring for, 173
 charger part numbers, 178
 charging, 168
 disposal, 175
 front panel icons, 165
 installing, 37, 164
 LEDs, 165
 maximizing battery life, 174
 part numbers, 178
 precautions, 173
 reconditioning/recalibrating, 170
 specifications, 176
 statistics, 482
 status, 165
 System Statistics - Battery Screen, 166
 buttons on front panel, 34

C

C/I ratio, 378
 cable and connector care, 648
 cables, connectors, and accessories, 24
 calibration
 distance to fault, 290
 one port insertion loss, 46, 47, 50
 return Loss, 394
 Canadian EMC requirements, 629
 capture interval
 see "update interval"

update interval (differences between...), 122, 189, 227, 553, 592
 carrier feedthrough limits
 CDMA over air analyzer, 244
 CDMA Tx Analyzer, 204
 carrier to interference ratio, 378
 carrying case
 using, 41
 what goes where, 42
 CDMA analyzer
 basic measurement, 183
 carrier feedthrough, 213, 216
 channel power, 212, 215
 common measurements, 182
 delta page power, 213, 216
 delta quick page channel power, 213, 217
 delta sync power, 213, 216
 estimated Rho, 212, 215
 frequency error, 212, 214
 interpretation of measurement results, 214
 interpreting the display, 187
 metrics, 198
 noise floor, 213, 216
 optional measurement settings, 190
 pilot power, 213, 216
 PN offset, 212, 214, 408
 setting active channel threshold and auto threshold levels, 194
 setting CDMA transmitter reference level, 193
 setting channel or frequency step, 190
 setting frequency/time reference, 192
 setting measurement time, 195
 setting PN increment, 191
 setting PN offset, 191
 setting quick page channel, 196
 setting units, 193
 time offset, 214

uses, 182
 CDMA over air
 amplifier capacity, 254, 259
 average amplifier capacity, 255, 260
 average utilization, 255, 260
 basic measurement, 222
 carrier feedthrough, 253, 258
 carrier feedthrough limits, 244
 channel power, 253, 258
 criteria for making valid measurements, 221
 delta page power, 254, 259
 delta page power limits, 247
 delta quick page channel power, 254, 259
 delta sync power, 254, 259
 delta sync power limits, 248
 displaying location information using GPS, 224
 estimated Rho, 253, 257
 estimated rho limits, 243
 frequency error, 256
 frequency error limits, 241
 interpretation of measurement results, 256
 measurement time offset error limits, 242
 metrics, 252
 noise floor, 253, 258
 noise floor limits, 245
 optional measurement settings, 231
 pass/fail limits, 240
 peak amplifier capacity, 254, 259
 pilot Ec/Io, 253, 259
 pilot power, 253, 259
 pilot power limits, 246
 PN offset, 252, 256
 resetting amplifier capacity and traffic metrics, 235
 setting active channel threshold and auto threshold levels, 234

- setting amplifier capacity metrics, 227
- setting channel or frequency step, 231
- setting measurement time, 235
- setting PN increment, 232
- setting quick page channel, 236
- setting transmitter reference level, 232
- signal generator, 249
- time offset, 256
- utilization, 255
- CDMA Tx Analyzer
 - carrier feedthrough limits, 204
 - delta page power limits, 207
 - delta sync power limits, 208
 - frequency error limits, 201
 - noise floor limits, 205
 - pass/fail limits, 200
 - pilot power limits, 206
 - rho lower limits, 203
 - time offset limits, 202
- certification, 629
- channel scanner
 - analyzer input gain, 267
 - autoranging, 266
 - basic measurement, 263
 - displaying accurate peak power for pulsed signals, 266
 - displaying frequency or power, 274
 - entering channels with list instead of range, 268
 - entering measurement bandwidth and time, 269
 - pass/fail limits, 274
 - sensitivity, 154, 267
- charging batteries, 168
- cleaning supplies, connector, 650
- cleaning the screen, 33, 36
- clear calibration
 - distance to fault, 290
 - one port insertion loss, 50
 - return Loss, 394
- clear normalization
 - one port insertion loss, 137
- CompactFlash cards, 473
- compliance statements, 629
- configuring for network connectivity, 475
- connectors
 - care, 648
 - cleaning, 650
 - cleaning RF, 648
 - inspecting for wear, 650
 - inspecting RF, 648
 - ordering cleaning supplies, 650
 - torque specifications, 649
- copyrights, 661
- D**
 - data
 - saving, 469
 - declaration of conformity, 630
 - delta page power limits
 - CDMA over air analyzer, 247
 - CDMA Tx Analyzer, 207
 - delta sync power limits
 - CDMA over air analyzer, 248
 - CDMA Tx Analyzer, 208
 - detector mode
 - spectrum analyzer, 420
 - DHCP, 475
 - display
 - cleaning, 33, 36
 - testing, 485
 - distance to fault
 - basic measurement (automatic frequency range), 286
 - basic measurement (manual frequency range), 283
 - clear calibration, 290
 - displaying location information using GPS, 291
 - interference rejection, 293
- manual vs. automatic frequency range, 278
- pass/fail limits, 297
- viewing a single sweep, 292
- viewing trace data on a PC, 21
- dynamic range optimization
 - two port insertion loss, 139
- E**
 - E1
 - (code) BPV, 318
 - alarm indicators, 318
 - all 1's, 319
 - available seconds, 319
 - bit error rate, 320
 - bit errors, 320
 - BPV, 325
 - BPV errd secs, 319
 - BPV error rate, 319
 - BPV errors, 319
 - BVP, 318
 - CRC, 325
 - CRC-4, 318
 - degraded minutes, 320
 - E-bit, 318
 - elapsed time, 319
 - error free seconds, 319
 - errored seconds, 319
 - excess zeros, 319
 - facility summary, 321
 - FAST, 318
 - frame errd secs, 319
 - frame error rate, 319
 - frame errors, 319
 - frame slip, 318
 - frame slip, -, 320
 - frame slips, +, 320
 - frame sync loss, 319
 - frequency, 319
 - isolating faults using test equipment, 321

- isolating faults with alarm and errors, 321
- making E1 measurements, 300
- measurement results, 318
- MFAST, 318
- pattern, 318
- pattern sync loss, 320
- patterns, 316
- peak - wander, 320
- peak +wander, 320
- recv level, 319
- results indicators, 318
- selecting hard loop/end-end full E1, 305
- severe errored seconds, 319
- signal loss, 319
- slip rate, 320
- terminology, 325
- test data rate, 320
- testing and fault mitigation, 321
- unavailable seconds, 319
- E1 analyzer
 - alarm indicators, 318
 - control screen, 303
 - delay, 312
 - diagnostics, 315
 - display/sound screen, 303
 - hard loop/end-end full E1, 305
 - Isolating faults using test equipment, 321
 - measurement results, 318
 - monitor test mode, 308
 - patterns, 316
 - performing basic measurement, 300
 - results indicators, 318
 - setup screen, 300
 - slip reference, 302
 - status indicators, 320
 - testing and fault mitigation, 321
- E1 facility summary, 321
- E7495A/B options, 28
- E7495A/B specifications, 633
- EDGE
 - definition, 371
 - modulation, 371
 - pass/fail limits, 357
- EDGE analyzer
 - adding or deleting list items, 342
 - base station identity code, 373, 376
 - basic measurement, 330
 - BSIC, 373, 376
 - C/I, 378
 - carrier to interference ratio, 378
 - Ch Obw, 374
 - channel occupied bandwidth power, 374
 - error vector magnitude, 95%tile, 375
 - error vector magnitude, peak, 375
 - error vector magnitude, RMS, 375
 - EVM, 377
 - evm, 95%tile, 375
 - evm, peak, 375
 - evm, RMS, 375
 - external cable and attenuator loss, 367
 - frequency, 373
 - frequency error, 373, 376
 - interpretation of measurement results, 376
 - interpreting the display, 335
 - IQ offset, 374, 377
 - max TS power, 376
 - maximum timeslot power, 374, 376
 - MER, 378
 - modulation error ratio, 378
 - modulation type, 374
 - OBW, 374
 - occupied bandwidth power, 374
 - optional measurement settings, 339
 - phase error, 377
 - phase error and IQ offset, 377
 - phase error, peak, 374
 - phase error, RMS, 374
 - setting auto mode bar count, 354
 - setting auto order, 350
 - setting autoscale, 347
 - setting bar top, 350
 - setting channel or frequency step, 344
 - setting channel standard, 346
 - setting display position, 349
 - setting mid-bar, 351
 - setting PVT mask, 354
 - setting reference level, 348
 - setting scale/division, 348
 - setting scan mode, 340
 - setting slot synchronization, 355
 - setting start channel or start frequency, 343
 - setting stop channel or stop frequency, 345
 - setting TS# (w/ BCCH), 356
 - setting units of measure, 346
 - setting zoom, 351
 - setting zoom interval, 353
 - setting zoom offset, 352
 - training sequence code, 373
 - TSC, 373
 - uses, 329
- EDGE max TS power, 374
- EDGE modulation type, 374
- EDGE standards
 - DCS 1800, 371
 - E-GSM, 371
 - GSM 1900, 371
 - GSM 450, 371
 - GSM 480, 371
 - GSM 850, 371
 - GSM 900, 371
 - PCS 1900, 371
 - P-GSM, 371
 - R-GSM, 371
- electrostatic discharge (ESD)
 - precautions, 621
- estimated rho limits
 - CDMA over air analyzer, 243
- EVM
 - EDGE Analyzer, 377

- RMS, 377
- EVM (composite)
 - HSDPA analyzer, 568, 572, 613
 - HSDPA over air, 608
 - W-CDMA analyzer, 568, 572, 613
 - W-CDMA over air, 608
- EVM (pilot)
 - HSDPA analyzer, 568, 572, 613
 - HSDPA over air, 608
 - W-CDMA analyzer, 568, 572, 613
 - W-CDMA over air, 608
- EVM mode, 565, 605
- F**
 - file naming
 - asking for, 467
 - automatic, 466
 - options, 466
 - user, 466
 - formatting a PCMCIA or CompactFlash card, 473
 - frequency error limits
 - 1xEV-DO analyzer, 95
 - 1xEV-DO over air, 95
 - CDMA over air analyzer, 241
 - CDMA Tx Analyzer, 201
 - frequency reference
 - 1xEVDO analyzer, 81
 - 1xEVDO over air, 81
 - CDMA analyzer, 192
 - frequency/timing reference, 462
 - front panel layout, 34
 - functionality in the test set, 20
- G**
 - German noise compliance, 629
 - glossary, 658
 - GPS location data, 462
 - 1xEV-DO over air, 74
 - CDMA over air, 224
 - distance to fault, 291
 - two port insertion loss, 126
- GSM
 - modulation, 371
 - pass/fail limits, 357
- GSM analyzer
 - adding or deleting list items, 342
 - base station identity code, 373, 376
 - basic measurement, 330
 - BSIC, 373, 376
 - Ch Obw, 374
 - channel occupied bandwidth power, 374
 - external cable and attenuator loss, 367
 - frequency, 373
 - frequency error, 373, 376
 - interpretation of measurement results, 376
 - interpreting the display, 335
 - IQ offset, 374, 377
 - max TS power, 376
 - maximum timeslot power, 374, 376
 - modulation type, 374
 - OBW, 374
 - occupied bandwidth power, 374
 - optional measurement settings, 339
 - phase error, 377
 - phase error and IQ offset, 377
 - phase error, peak, 374
 - phase error, RMS, 374
 - setting auto mode bar count, 354
 - setting auto order, 350
 - setting autoscale, 347
 - setting bar top, 350
 - setting channel or frequency step, 344
 - setting channel standard, 346
 - setting display position, 349
 - setting mid-bar, 351
 - setting PvT mask, 354
 - setting reference level, 348
 - setting scale/division, 348
 - setting scan mode, 340
 - setting slot synchronization, 355
 - setting start channel or start frequency, 343
 - setting stop channel or stop frequency, 345
 - setting TS# (w/ BCCH), 356
 - setting units of measure, 346
 - setting zoom, 351
 - setting zoom interval, 353
 - setting zoom offset, 352
 - training sequence code, 373
 - TSC, 373
 - uses, 329
- GSM max TS power, 374
- GSM modulation type, 374
- GSM standards
 - DCS 1800, 371
 - E-GSM, 371
 - GSM 1900, 371
 - GSM 450, 371
 - GSM 480, 371
 - GSM 850, 371
 - GSM 900, 371
 - PCS 1900, 371
 - P-GSM, 371
 - R-GSM, 371
- H**
 - Hard Loop/End-End Full E1, 305
 - highest (best) insertion loss, 136
 - HSDPA analyzer, 536, 576
 - active code channels, 553, 593
 - basic transmitter measurement, 540
 - carrier feedthrough, 569
 - chan pwr, 569, 572
 - channel or frequency step, 556
 - channel power, 569, 572
 - control channel delta power, 569, 573
 - CPICH, 569, 573, 610
 - display options, 548
 - EVM, 568, 572, 613
 - EVM mode, 565

- external amplifier gain, 558
- external cable and attenuator loss, 558
- freq error, 568, 571
- frequency, 568, 571
- frequency error, 568, 571
- IF correction, 565
- markers, 566
- metrics, 566
- noise floor, 568, 571
- PCDE, 569, 572
- S-CCPCH, 564
- scramble code, 556, 568, 571, 608
- scrambling code, 568, 571, 608
- scrambling codes, 556
- setting active channel threshold and auto threshold levels, 562, 600
- setting HSDPA transmitter reference level, 557
- setting PN increment, 556
- sweep (continuous or single), 566
- threshold, 568, 572
- threshold level, 562, 600
- transmitter reference level, 557
- uses, 536
- HSDPA over air, 576
 - amplifier capacity, 610, 614
 - average amplifier capacity, 610, 614
 - average utilization, 609, 614
 - basic measurement, 579
 - carr ft, 572, 608, 613
 - carrier feedthrough, 572, 608, 613
 - chan pwr, 610, 614
 - channel power, 610, 614
 - common pilot channel, 614
 - CPICH, 614
 - criteria for making valid measurements, 577
 - display options, 587
 - displaying location information using GPS, 581
 - error vector magnitude, 608, 609
 - EVM, 608, 609
 - EVM mode, 605
 - freq, 612
 - freq error, 612
 - frequency, 608, 612
 - frequency error, 608, 612
 - IF correction, 605
 - interpretation of measurement results, 571, 612
 - noise floor, 608, 613
 - optional measurement settings, 593
 - pcde, 613
 - peak amplifier capacity, 610, 614
 - peak code domain error, 613
 - peak utilization, 613
 - pk amp cap, 614
 - pk util, 613
 - resetting amplifier capacity and traffic metrics, 602
 - scramble code, 596, 612
 - scrambling code, 596, 612
 - setting amplifier capacity metrics, 582
 - setting channel or frequency step, 595
 - setting measurement limits, 603
 - setting measurement time, 563, 601
 - setting PICH parameters, 604
 - setting PN increment, 596
 - setting S-CCPCH parameters, 603
 - setting transmitter reference level, 596
 - utilization, 609, 613
- I
 - idle on/off ratio limits
 - 1xEV-DO analyzer, 97
 - 1xEV-DO over air, 97
 - IF correction, IF equalization, 565, 605
 - inactive channel high limits
 - 1xEV-DO analyzer, 100
 - 1xEV-DO over air, 100
 - installation information, 484
 - installing a battery, 37, 164
 - interference ID measurement, 439, 454
 - interference rejection
 - one port insertion loss, 56
 - interpretation of measurement results
 - EDGE, 376
 - GSM, 376
 - introduction to the test set, 20
 - IP administration
 - using DHCP, 475
 - without DHCP, 475
- K
 - keyboard testing, 485
- L
 - layout of front panel, 34
 - leveling source
 - two port insertion loss, 137
 - lifting and handling the test set, 620
 - loss (rf out)
 - 1xEV-DO analyzer, 103
 - 1xEV-DO over air, 103
 - lowest (worst) insertion loss, 135
- M
 - MAC rho limits
 - 1xEV-DO analyzer, 99
 - 1xEV-DO over air, 99
 - managing media types, 473
 - manufacturer's declaration, 630
 - marker, adding, 55, 365
 - measurement time limits
 - 1xEV-DO analyzer, 96
 - 1xEV-DO over air, 96
 - measurement time offset limits
 - CDMA over air analyzer, 242
 - measurements, optional, 20

- MER, 378
- mode
 - EVM, 565, 605
- modulation
 - 8PSK, 371
 - EDGE, 371
 - GMSK, 371
 - GSM, 371
- modulation error ratio, 378
- N**
- network connectivity, 475
- noise compliance, German, 629
- noise floor limits
 - CDMA over air analyzer, 245
 - CDMA Tx Analyzer, 205
- normalization
 - one port insertion loss, 137
- O**
- occupied BW measurement, 445
- one port insertion loss
 - basic measurement, 47
 - calibration, 46, 47
 - clear calibration, 50
 - interference rejection, 56
 - measuring, 46
 - pass/fail limits, 57
- option manager, 483
- optional measurements, 20
- options
 - installing, 484
 - viewing installable, 483
 - viewing installed, 483
- options for test set, 28
- over air
 - HSDPA, 576
 - W-CDMA, 576
- P**
- pass/fail limits
 - 1xEV-DO analyzer, 92
 - 1xEV-DO over air, 92
 - CDMA over air analyzer, 240
 - CDMA Tx Analyzer, 200
 - channel scanner, 274
 - distance to fault, 297
 - one port insertion loss, 57
 - return loss, 400
 - spectrum analyzer, 428
 - two port insertion loss, 140
- PC software, 21
- PCMCIA cards, 473
- persistent signal generator, 411
- pilot power limits
 - CDMA over air analyzer, 246
 - CDMA Tx Analyzer, 206
- pilot rho limits
 - 1xEV-DO analyzer, 98
 - 1xEV-DO over air, 98
- post processor software, 21
- power (delta page) limits
 - CDMA over air analyzer, 247
 - CDMA Tx Analyzer, 207
- power (delta sync) limits
 - CDMA over air analyzer, 248
 - CDMA Tx Analyzer, 208
- power (pilot) limits
 - CDMA over air analyzer, 246
 - CDMA Tx Analyzer, 206
- power button, 35, 37
- power meter
 - basic average power measurement, 381
 - making an average power measurement, 380
 - setting high and low end-points, 385
 - setting resolution, 384
 - setting upper and lower limits, 386
- printing screens, 465
- product markings, 622
- R**
- reconditioning/recalibrating batteries, 170
- release versions, 481
- restart, 52, 88, 127, 150, 197, 237, 272, 294, 368, 396, 423, 560, 598
- restart averaging, 53, 89, 129, 151, 198, 238, 273, 295, 370, 397, 424, 561, 600
- return loss, 389
 - basic measurement, 391
 - clear calibration, 394
 - interference rejection, 395
 - isolating a return loss signal using a single sweep, 395
 - isolating using a single sweep, 395
 - pass/fail limits, 400
 - viewing trace data on a PC, 21
- returning the test set for service, 653
- RF cable and connector care, 648
- RF connectors, 648
- rf out loss
 - 1xEV-DO analyzer, 103
 - 1xEV-DO over air, 103
- rho (estimated) limits
 - CDMA over air analyzer, 243
- rho (MAC) limits
 - 1xEV-DO analyzer, 99
 - 1xEV-DO over air, 99
- rho (pilot) limits
 - 1xEV-DO analyzer, 98
 - 1xEV-DO over air, 98
- rho lower limits
 - CDMA Tx Analyzer, 203
- S**
- safety considerations, 618
- safety symbols, 618
- sales and service offices, 43
- saving data, 469
- scan mode, auto bar count, 354

- scramble code
 - HSDPA, 568, 612
 - HSDPA over air, 596
 - W-CDMA, 568, 612
 - W-CDMA over air, 596
 - scramble codes
 - HSDPA, 556
 - W-CDMA, 556
 - screen
 - cleaning, 33, 36
 - sensitivity
 - acp, 154, 419
 - channel scanner, 154, 267
 - service
 - returning the test set, 653
 - shipping the test set, 654
 - service offices, 43
 - shipping the test set, 654
 - signal generator
 - 1xEV-DO analyzer, 101
 - basic measurement, 404
 - CDMA over air, 249
 - persistent signal generator, 411
 - selecting a channel, time and frequency reference, 404
 - spectrum analyzer, 157, 209, 421
 - uses, 402
 - software for PCs, 21
 - specifications for test set, 633
 - spectrogram measurement, 436
 - spectrogram view
 - spectrum analyzer, 435
 - spectrum analyzer
 - basic measurement, 415
 - detector mode, 420
 - interference ID measurement, 439, 454
 - occupied BW measurement, 445
 - pass/fail limits, 428
 - signal generator, 157, 209, 421
 - spectrogram measurement, 436
 - spectrogram view, 435
 - uses, 414, 439, 444, 450
 - state
 - deleting, 480
 - power-up, 478
 - recalling, 479
 - returning power-up to factory defaults, 479
 - saving, 478
 - statistics
 - system, 481
 - viewing, 481
 - sweep, 52, 88, 127, 150, 197, 237, 272, 294, 368, 396, 423, 560, 598
 - sweep (continuous or single), 52, 88, 127, 150, 197, 237, 272, 294, 368, 396, 423, 560, 598
 - system
 - memory, 481
 - release versions, 481
 - statistics, 481
 - system operations
 - configuring for network connectivity, 475
 - displaying GPS location data, 462
 - formatting a PCMCIA or CompactFlash card, 473
 - IP administration using DHCP, 475
 - IP administration without DHCP, 475
 - managing media types, 473
 - printing screens, 465
 - saving data, 469
 - selecting a timing reference, 462
 - setting system references, 462
 - using the option manager, 483
 - viewing battery statistics, 482
 - viewing system memory, 481
 - viewing system release versions, 481
 - viewing system statistics, 481
- ## T
- ### T1
- alarm indicators, 518
 - all 1's, 520
 - available seconds, 521
 - bit error rate, 522
 - bit errors, 522
 - BPV, 533
 - BPV errd secs, 520
 - BPV error rate, 519
 - BPV errors, 519
 - control screen, 491
 - CRC, 533
 - degraded minutes, 521
 - detailed loop mode and auto configuration descriptions, 527
 - display/sound screen, 491
 - error free seconds, 521
 - errored seconds, 521
 - excess zeros, 520
 - facility summary, 523
 - frame errd secs, 520
 - frame error rate, 520
 - frame errors, 520
 - frame slips, 522
 - frame sync loss, 520
 - isolating faults using test equipment, 525
 - isolating faults with alarm and errors, 524
 - making T1 measurements, 488
 - measurement results, 518
 - measurement results fields, 519
 - monitor test mode, 503
 - pattern sync loss, 522
 - patterns, 514
 - peak - wander, 521
 - peak +wander, 521
 - performing basic measurement, 488
 - remote CSU/NIU loop mode, 527
 - results indicators, 518
 - selecting delay, 512

- selecting emulate CSU/NIU, 507
- selecting hard loop/end-end full T1, 493
- selecting loopback CSU full T1 BERT, 498
- setup button, 488
- severe errored seconds, 521
- signal loss, 520
- slip rate, 521
- slip reference, 490
- status indicators, 519
- terminology, 533
- test data rate, 522
- testing and fault mitigation, 522
- unavailable seconds, 521
- test patterns
 - E1, 316
- test set functionality, 20
- test set options, 28
- test set specifications, 633
- time offset limits
 - CDMA Tx Analyzer, 202
- time reference
 - 1xEVDO analyzer, 81
 - 1xEVDO over air, 81
 - CDMA analyzer, 192
- torque, 649
- two port insertion loss
 - as your first measurement, 38
 - basic measurement, 125
 - clear normalization, 137
 - determining the highest insertion loss and its frequency, 136
 - determining the lowest insertion loss and its frequency, 135
 - displaying location information using GPS, 126
 - dynamic range optimization, 139
 - for power meter, 134
 - for spectrum analyzer, channel scanner, 1xEVDO, CDMA analyzer, and signal generator, 131
- interference rejection, 136
- measuring, 124
- pass/fail limits, 140
- performing a basic measurement, 125
- source leveling, 137
- uses, 124
- U
 - unpacking the test set, 22
 - update interval, 121, 122, 188, 189, 227, 437, 552, 553, 591, 592
 - uses of
 - EDGE analyzer, 329
 - GSM analyzer, 329
 - signal generator, 402
 - spectrum analyzer, 414, 439, 444, 450
 - two port insertion loss, 124
 - using connectors, 648
 - using the occupied BW measurement, 444
 - using the spectrum analyzer, 414, 439, 450
- V
 - viewing battery statistics, 482
 - viewing trace data on a PC
 - distance to fault, 21
 - return loss, 21
- W
 - warranty, 653
- W-CDMA analyzer, 536, 576
 - active code channels, 553, 593
 - basic transmitter measurement, 540
 - carrier feedthrough, 569
 - chan pwr, 569, 572
 - channel or frequency step, 556
 - channel power, 569, 572
 - control channel delta power, 569, 573
 - CPICH, 569, 573, 610
 - display option, 548
 - EVM, 568, 572, 613
 - EVM mode, 565
 - external amplifier gain, 558
 - external cable and attenuator loss, 558
 - freq error, 568, 571
 - frequency, 568, 571
 - frequency error, 568, 571
 - IF correction, 565
 - markers, 566
 - metrics, 566
 - noise floor, 568, 571
 - PCDE, 569, 572
 - S-CCPCH, 564
 - scramble code, 556, 568, 571, 608
 - scrambling code, 568, 571, 608
 - scrambling codes, 556
 - setting active channel threshold and auto threshold levels, 562, 600
 - setting PN increment, 556
 - setting W-CDMA transmitter reference level, 557
 - sweep (continuous or single), 566
 - threshold, 568, 572
 - threshold level, 562, 600
 - transmitter reference level, 557
 - uses, 536
- W-CDMA over air, 576
 - amplifier capacity, 610, 614
 - average amplifier capacity, 610, 614
 - average utilization, 609, 614
 - basic measurement, 579
 - carr ft, 572, 608, 613
 - carrier feedthrough, 572, 608, 613
 - chan pwr, 610, 614
 - channel power, 610, 614
 - common pilot channel, 614
 - CPICH, 614
 - criteria for making valid measurements, 577

- display options, [587](#)
- displaying location information
 - using GPS, [581](#)
- error vector magnitude, [608](#)
- EVM, [608](#)
- EVM mode, [605](#)
- freq, [612](#)
- freq error, [612](#)
- frequency, [608](#), [612](#)
- frequency error, [608](#), [612](#)
- IF correction, [605](#)
- interpretation of measurement
 - results, [571](#), [612](#)
- noise floor, [608](#), [613](#)
- optional measurement settings, [593](#)
- PCDE, [609](#)
- pcde, [613](#)
- peak amplifier capacity, [610](#), [614](#)
- peak code domain error, [609](#), [613](#)
- peak utilization, [613](#)
- pk amp cap, [614](#)
- pk util, [613](#)
- resetting amplifier capacity and
 - traffic metrics, [602](#)
- scramble code, [596](#), [612](#)
- scrambling code, [596](#), [612](#)
- setting amplifier capacity metrics,
 - [582](#)
- setting channel or frequency step,
 - [595](#)
- setting measurement limits, [603](#)
- setting measurement time, [563](#), [601](#)
- setting PICH parameters, [604](#)
- setting PN increment, [596](#)
- setting S-CCPCH parameters, [603](#)
- setting transmitter reference level,
 - [596](#)
- utilization, [609](#), [613](#)
- Working with Batteries, [163](#), [657](#)