


# 4141B

## DC SOURCE/MONITOR



**HEWLETT  
PACKARD**

## **SAFETY SUMMARY**

The following general safety precautions must be observed during all phases of operation, service, and repair of this instrument. Failure to comply with these precautions or with specific warnings given elsewhere in this manual violates safety standards of design, manufacture, and intended use of the instrument. Hewlett-Packard Company assumes no liability for the customer's failure to comply with these requirements.

### **GROUND THE INSTRUMENT**

To minimize shock hazard, the instrument chassis and cabinet must be connected to an electrical ground. The instrument is equipped with a three-conductor ac power cable. The power cable must either be plugged into an approved three-contact electrical outlet or used with a three-contact to two-contact adapter with the grounding wire (green) firmly connected to an electrical ground (safety ground) at the power outlet. The power jack and the mating plug of the power cable meet International Electrotechnical Commission (IEC) safety standards.

### **DO NOT OPERATE IN AN EXPLOSIVE ATMOSPHERE**

Do not operate the instrument in the presence of flammable gases or fumes. Operation of any electrical instrument in such an environment constitutes a definite safety hazard.

### **KEEP AWAY FROM LIVE CIRCUITS**

Operating personnel must not remove instrument covers. Component replacement and internal adjustments must be made by qualified maintenance personnel. Do not replace components with power cable connected. Under certain conditions, dangerous voltages may exist even with the power cable removed. To avoid injuries, always disconnect power and discharge circuits before touching them.

### **DO NOT SERVICE OR ADJUST ALONE**

Do not attempt internal service or adjustment unless another person, capable of rendering first aid and resuscitation, is present.

### **DO NOT SUBSTITUTE PARTS OR MODIFY INSTRUMENT**

Because of the danger of introducing additional hazards, do not install substitute parts or perform any unauthorized modification to the instrument. Return the instrument to a Hewlett-Packard Sales and Service Office for service and repair to ensure that safety features are maintained.

### **DANGEROUS PROCEDURE WARNINGS**

Warnings, such as the example below, precede potentially dangerous procedures throughout this manual. Instructions contained in the warnings must be followed.

#### **WARNING**

**DANGEROUS VOLTAGES, CAPABLE OF CAUSING DEATH, ARE PRESENT IN THIS INSTRUMENT. USE EXTREME CAUTION WHEN HANDLING, TESTING, AND ADJUSTING.**

# MANUAL CHANGES

## 4141B

### DC SOURCE/MONITOR

#### MANUAL IDENTIFICATION

Model Number: 4141B  
Date Printed: DEC. 1985  
Part Number: 04141-90000

This supplement contains information for correcting manual errors and for adapting the manual to newer instruments that contain improvements or modifications not documented in the existing manual.

To use this supplement

1. Make all ERRATA corrections
2. Make all appropriate serial-number-related changes listed below

SERIAL PREFIX OR NUMBER      MAKE MANUAL CHANGES

SERIAL PREFIX OR NUMBER	MAKE MANUAL CHANGES

SERIAL PREFIX OR NUMBER      MAKE MANUAL CHANGES

SERIAL PREFIX OR NUMBER	MAKE MANUAL CHANGES

► New Item

#### ► ERRATA

Page 1-5, Table 1-1. Specifications (2 of 4):

Add the following paragraph after the last paragraph on the page.

Maximum Capacitance Load : 1000pf

Page 4-1, Para 4-1, INTRODUCTION

Change the Part Number for the 4062B Service Manual to PN 04062-90501.

#### NOTE

Manual change supplements are revised as often as necessary to keep manuals as current and accurate as possible. Hewlett-Packard recommends that you periodically request the latest edition of this supplement. Free copies are available from all HP offices. When requesting copies, quote the manual identification information from your supplement, or the model number and print date from the title page of the manual.

Date/Div: MAY 29, 1986/33

Page: 1 of 1



PRINTED IN JAPAN



## **CERTIFICATION**

Hewlett-Packard Company certifies that this product met its published specifications at the time of shipment from the factory. Hewlett-Packard further certifies that its calibration measurements are traceable to the United States National Bureau of Standards, to the extent allowed by the Bureau's calibration facility, and to the calibration facilities of other International Standards Organization members.

## **WARRANTY**

This Hewlett-Packard system product is warranted against defects in material and workmanship for a period of 90 days from date of installation, except that in the case of certain components listed in Section 1 of this manual, the warranty shall be for the specified period. During the warranty period, Hewlett-Packard Company will, at its option, either repair or replace products which prove to be defective.

For warranty service or repair, this product must be returned to a service facility designated by HP. Buyer shall prepay shipping charges to HP and HP shall pay shipping charges to return the product to Buyer. However, Buyer shall pay all shipping charges, duties, and taxes for products returned to HP from another country.

HP warrants that its software and firmware designated by HP for use with a system will execute its programming instructions when properly installed on that system. HP does not warrant that the operation of the system, or software, or firmware will be uninterrupted or error free.

## **LIMITATION OF WARRANTY**

The foregoing warranty shall not apply to defects resulting from improper or inadequate maintenance by Buyer, Buyer-supplied software or interfacing, unauthorized modification or misuse, operation outside of the environment specifications for the product, or improper site preparation or maintenance.

**NO OTHER WARRANTY IS EXPRESSED OR IMPLIED. HP SPECIFICALLY DISCLAIMS THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.**

## **EXCLUSIVE REMEDIES**

THE REMEDIES PROVIDED HEREIN ARE BUYER'S SOLE AND EXCLUSIVE REMEDIES. HP SHALL NOT BE LIABLE FOR ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, WHETHER BASED ON CONTRACT, TORT, OR ANY OTHER LEGAL THEORY.

## **ASSISTANCE**

Product maintenance agreements and other customer assistance agreements are available for Hewlett-Packard products.

For any assistance, contact your nearest Hewlett-Packard Sales and Service Office. Addresses are provided at the back of this manual.

## SAFETY SYMBOLS


### General Definitions of Safety Symbols Used On Equipment or in Manuals.



Instruction manual symbol: the product will be marked with this symbol when it is necessary for the user to refer to the instruction manual in order to protect against damage to the instrument.




Indicates dangerous voltage (terminals fed from the interior by voltage exceeding 1000 volts must be so marked).



Protective conductor terminal. For protection against electrical shock in case of a fault. Used with field wiring terminals to indicate the terminal which must be connected to ground before operating equipment.



Low-noise or noiseless, clean ground (earth) terminal. Used for a signal common, as well as providing protection against electrical shock in case of fault. A terminal marked with this symbol must be connected to ground in the manner described in the installation (operating) manual, and before operating the equipment.



Frame or chassis terminal. A connection to the frame (chassis) of the equipment which normally includes all exposed metal structures.



Alternating current (power line).



Direct current (power line).



Alternating or direct current (power line).

### WARNING

A **WARNING** denotes a hazard. It calls attention to a procedure, practice, condition or the like, which, if not correctly performed or adhered to, could result in injury or death to personnel.

### CAUTION

The **CAUTION** sign denotes a hazard. It calls attention to an operating procedure, practice, condition or the like, which, if not correctly performed or adhered to, could result in damage to or destruction of part or all of the product.

### Note

A **Note** denotes important information. It calls attention to a procedure, practice, condition or the like, which is essential to highlight.

### **Herstellerbescheinigung**

Hiermit wird bescheinigt, daß das Gerät HP 4141B (DC Source/Monitor) in Übereinstimmung mit den Bestimmungen von Postverordnung 1046/84 funkenstört ist.

Der Deutschen Bundespost wurde das Inverkehrbringen dieses Gerätes angezeigt und die Berechtigung zur Überprüfung der Serie auf Einhaltung der Bestimmungen eingeräumt.

Anm: Werden Meß- und Testgeräte mit ungeschirmten Kabeln und/oder in offenen Meßaufbauten verwendet, so ist vom Betreiber sicherzustellen, daß die Funk-Entstörbestimmungen unter Betriebsbedingungen an seiner Grundstücksgrenze eingehalten werden.

### **Manufacturer's Declaration**

This is to certify that this product, the HP 4141B DC Source/Monitor, meets the radio frequency interference requirements of directive 1046/84. The German Bundespost has been notified that this equipment was put into circulation and was granted the right to check the product type for compliance with these requirements.

Note: If test and measurement equipment is operated with unshielded cables and/or used for measurements on open setups, the user must insure that under these operating conditions, the radio frequency interference limits are met at the border of his premises.







**OPERATION MANUAL**

**MODEL 4141B**

**DC SOURCE/MONITOR**

**(Including Option 011)**

© COPYRIGHT: YOKOGAWA-HEWLETT-PACKARD, LTD., 1985  
9-1, TAKAKURA-CHO, HACHIOJI-SHI, TOKYO, JAPAN

Manual Part No. 04141-90000  
Microfiche Part No. 04141-90050

Printed: DEC. 1985



# CONTENTS

## SECTION 1 GENERAL INFORMATION

- 1-1. Introduction 1-1
- 1-2. Description 1-2
- 1-3. Specifications 1-2
- 1-4. Safety Considerations 1-2
- 1-5. Instruments Covered by Manual 1-2
- 1-6. Options 1-3
- 1-7. Accessories 1-3

## SECTION 2 INSTALLATION

- 2-1. Introduction 2-1
- 2-2. Initial Inspection 2-1
- 2-3. Power Requirements 2-1
- 2-4. Line Voltage and Line Fuse Selection 2-2
- 2-5. Line Frequency Filter 2-2
- 2-6. Power Cable 2-2
- 2-7. Interconnections 2-5
- 2-8. Operating Environment 2-5
- 2-9. Storage and Shipment 2-5
- 2-10. Packaging 2-6
- 2-11. Installation Instructions 2-6

## SECTION 3 OPERATION

- 3-1. Introduction 3-1
- 3-2. Panel Features 3-3
- 3-3. Self Test 3-6
- 3-4. 4141B Operating Outline 3-7
- 3-5. Source/Monitor Units (SMUs) 3-8
- 3-6. Voltage Sources (VS) and Voltage Monitors (VM) 3-10
- 3-7. Ground Unit (GNDU) 3-11
- 3-8. Compliance 3-12
- 3-9. Kelvin Connections 3-13
- 3-10. Guarding 3-14
- 3-11. Floating Measurements 3-16
- 3-12. Integration Time 3-17
- 3-13. Self Calibration 3-17
- 3-14. Measurement Ranges and Resolution 3-18
- 3-15. Spot Measurement 3-20
- 3-16. Sweep Measurement 3-21
- 3-17. Measurement Time 3-22

- 3-18. DUT Connections 3-24
- 3-19. DUT Connection Using the Connector Plate 3-25
- 3-20. DUT Connection Using the 16058A 3-29
- 3-21. HP-IB Interface 3-32
- 3-22. HP-IB Interface Capabilities 3-32
- 3-23. HP-IB Connection 3-33
- 3-24. HP-IB Status Indicators 3-33
- 3-25. Remote Program Codes and Parameter Settings 3-33
- 3-26. Data Output 3-48
- 3-27. Interlock 3-52
- 3-28. Device Clear 3-52
- 3-29. Device Trigger 3-52
- 3-30. Service Request Status Byte 3-53
- 3-31. Sample Measurement and Programming 3-55

## **SECTION 4 PERFORMANCE VERIFICATION**

- 4-1. Introduction 4-1
- 4-2. PV4141 Contents 4-1
- 4-3. Equipment Required 4-2
- 4-4. Program Execution 4-2
- 4-5. SMU Test 4-4
- 4-6. VS/VM Test 4-8
- 4-7. GNDU Test 4-10
- 4-8. SMU Board Replacement 4-10

## ILLUSTRATIONS

- 1-1. HP 4141B and Furnished Accessories 1-1
- 1-2. Serial Number Plate 1-3
  
- 2-1. Voltage and Fuse Selection 2-2
- 2-2. Power Cables 2-4
- 2-3. Rack Mount Kit 2-7
  
- 3-1. Organization of Section 3 3-1
- 3-2. Front Panel Features 3-2
- 3-3. Rear Panel Feature 3-4
- 3-4. 4141B Simplified Block Diagram 3-7
- 3-5. Simplified SMU Circuit Diagram 3-8
- 3-6. Specifiable Voltage/Current Output 3-9
- 3-7. VS Simplified Circuit Diagram 3-10
- 3-8. VM Simplified Circuit Diagram 3-10
- 3-9. GNDU Simplified Circuit Diagram 3-12
- 3-10. Kelvin Connections 3-13
- 3-11. Guarding Techniques 3-14
- 3-12. SMU Output Terminal Configuration 3-15
- 3-13. COMMON-GROUND Terminal 3-15
- 3-14. Measurement Range and Resolution 3-18
- 3-15. Staircase Sweep Output 3-21
- 3-16. DUT Connection Using the Connector Plate 3-25
- 3-17. DUT Connection Using the 16058A 3-29
- 3-18. Measurement Setup 3-55
- 3-19. Sample Program 1 3-58
- 3-20. Sample Program 2 3-60
- 3-21. Sample Program 3 3-62
- 3-22. Sample Program 4 3-64
- 3-23. Sample Program 5 3-66
- 3-24. Sample Program 6 3-70
  
- 4-1. SMU Accuracy Test Setup 4-5
- 4-2. VS/VM Test Setup 4-8
- 4-3. SMU Board Removal 4-11

## **TABLES**

- 1-1. Specifications 1-4**
- 1-2. Supplemental Performance Characteristics 1-8**
- 1-3. Accessories 1-10**
  
- 3-1. 4141B Self Test 3-6**
- 3-2. SMU Source Range 3-12**
- 3-3. HP-IB Interface Capability 3-32**
- 3-4. Remote Program Codes and Parameter Settings 3-35**
- 3-5. Data Output Format 3-48**
- 3-6. Initial Control Settings 3-52**
- 3-7. 4141B Status Byte 3-53**
- 3-8. Binary Files Required for Programming 3-55**

# SECTION 1

## GENERAL INFORMATION

### 1-1. INTRODUCTION

This manual contains the information required to install, operate, and maintain the Hewlett-Packard Model 4141B DC Source/Monitor. Figure 1-1 shows the 4141B and its furnished accessories. This section covers specifications, instrument identification, description, options, accessories, and other basic information.




Figure 1-1. HP 4141B and Furnished Accessories

Listed on the title page of this manual is a microfiche part number that can be used to order 4 × 6 inch microfilm transparencies of the manual. Each microfiche contains up to 60 photo-duplicates of the manual pages. The microfiche package also includes the latest pertinent service notes. To order an additional manual, use the part number listed on the title page of this manual.

## **GENERAL INFORMATION**

### **1-2. DESCRIPTION**

The 4141B DC Source/Monitor is a high performance, fully programmable test instrument designed to stimulate voltage and current sensitive devices and measure the resulting current and voltage responses. Intended primarily for use in computer-controlled semiconductor test systems, the 4141B is ideal for a wide range of dc measurement applications such as computer-aided design (CAD), wafer process evaluation, wafer testing, packaged device testing, new process development, and incoming/outgoing inspection of diodes, transistors, and ICs.

The 4141B is equipped with four programmable source/monitor units, two programmable voltage sources, two voltage monitors, and an active ground unit, allowing the user to realize virtually any connection configuration, from a simple two-wire connection to the more sophisticated, more accurate full-Kelvin connection. The 4141B's driven guard capability and extensive internal shielding ensure measurement accuracy down to the microvolt and picoampere ranges.

All operations on the 4141B--measurement set up and execution, self test, and self calibration--are computer-controlled via the Hewlett-Packard Interface Bus (HP-IB).

### **1-3. SPECIFICATIONS**

Table 1-1 lists complete specifications for the 4141B. These specifications are the performance standards against which the instrument is tested. Test procedures for verifying performance are covered in Section 4. When shipped from the factory, the 4141B meets all the specifications listed in Table 1-1. Table 1-2 lists supplemental performance characteristics. Supplemental performance characteristics are not specifications but are typical characteristics included as additional information for the operator.

### **1-4. SAFETY CONSIDERATIONS**

The 4141B has been designed to conform to the International Electromechanical Committee's Safety Class I requirements and is shipped from the factory in a safe condition.

This manual contains information, cautions, and warnings which must be followed to ensure the safety of the operator and to maintain the instrument in a safe condition.

### **1-5. INSTRUMENTS COVERED BY MANUAL**

Hewlett-Packard uses a two-section, nine character serial number which is stamped on the serial number plate (see Figure 1-2) attached to the instrument's rear-panel. The first four digits and the letter are the serial prefix and the last five digits are the suffix. The letter placed between the two sections identifies the country where the instrument was manufactured. The prefix is the same for all identical instruments; it changes only when a change is made to the instrument. The suffix, however, is assigned sequentially and is different for each instrument.






Figure 1-2. Serial Number Plate

Hewlett-Packard will publish a yellow Manual Changes supplement to inform you of any manual changes or errors (Errata). To keep this manual as current and as accurate as possible, request the latest Manual Changes supplement from time to time. The supplement for this manual is identified with this manual's print date and part number, both of which appear on the title page. Complimentary copies of the supplement are available from Hewlett-Packard.

## 1-6. OPTIONS

The following options are available for the 4141B.

- OPT 011: Extra SMU board
- OPT 050: For 50Hz line frequency
- OPT 060: For 60Hz line frequency
- OPT 907: Front Handle Kit
- OPT 908: Rack Flange kit
- OPT 909: Rack and Handle Kit
- OPT 910: Extra Manual

For Option 907, 908, and 909 installation information, refer to Section 2.

## 1-7. ACCESSORIES

Figure 1-1 shows the 4141B and its furnished accessories. Also included but not shown is the 4141B's manual (PN 04141-90000). Table 1-3 lists all furnished and available 4141B accessories and provides a brief description of each.

## GENERAL INFORMATION

Table 1-1. Specifications (sheet 1 of 4)

### GENERAL INFORMATION

**Basic Functions:**

To stimulate voltage and current sensitive devices and measure the resulting current and voltage responses. All instrument operations are computer-controlled via the HP-IB.

**Source/Monitor Units (SMU):**

Four SMU channels; each SMU can be programmed to function as a dc voltage source/current monitor or as a dc current source/voltage monitor.

**Voltage Sources (Vs):**

Two Vs channels; each Vs is programmable.

**Voltage Monitors (Vm):**

Two Vm channels; each Vm can measure up to  $\pm 20\text{Vdc}$ .

**Ground Unit (GNDU):**

One GNDU channel. Maintains 0V output; enables full-Kelvin connections.

### SOURCE/MONITOR FUNCTIONS

Measurement and output accuracies are specified at the rear panel terminals under the following conditions.

Warm-up Time:	40 minutes
Ambient Temperature:	$23^{\circ}\text{C} \pm 5^{\circ}\text{C}$
Voltage Reference:	Floating Ground ( $\nabla$ )
Auto calibration:	On
Integration Time:	Short

Specified accuracies double for operation between  $10^{\circ}\text{C}$  and  $40^{\circ}\text{C}$ .

**Source/Monitor Units (SMUs):**

Each of the four SMUs can measure current when operating as a voltage source, or voltage when operating as a current source. Each SMU is designed to provide full-Kelvin connection. Source and measurement ranges, resolution, and accuracy specifications are listed in the following table.

Accuracy is specified as  $\pm\%$  of setting or reading  $+\%$  of range.  $V_0$  in the current accuracy table is SMU output voltage.

Table 1-1. Specifications (sheet 2 of 4)

Voltage Accuracy

Range	Max. Res.	Accuracy
±20V	1mV	±(0.1%+0.05%)
±40V	2mV	
±100V	5mV	

Current Accuracy

Range	Max. Res.	Accuracy
±100mA	100µA	±[0.3%+(0.1+0.2 Vo/100)%]
±10mA	10µA	
±1000µA	1µA	
±100µA	100nA	
±10µA	10nA	
±1000nA	1nA	±[0.5%+(0.1+0.2 Vo/100)%]
±100nA	100pA	±[1%+(0.1+0.1 Vo/100)%+5pA]
±10nA	10pA	
±1000pA	1pA	

Maximum Power Output from each SMU: 2 watts

Setting Resolution: Voltage, 4 1/2 digits (1mV max.), Current, 4 digits (1pA max.)

Measurement Resolution: Voltage, 4 1/2 digits (1mV max.), Current, 4 digits (0.05pA max.)

Ranging Modes: Auto/Limited-Auto

Residual dc Resistance (Voltage Source/Current Monitor Mode): 5mΩ

Input dc Resistance (Current Source/Voltage Monitor Mode): 10<sup>12</sup>Ω

Maximum Residual dc Resistance (through furnished cables): 7Ω (Force), 14Ω (Sense)

## GENERAL INFORMATION

Table 1-1. Specifications (sheet 3 of 4)

### Voltage Sources (Vs):

Two Vs channels. Each can be programmed to function as a variable or constant dc voltage source. Output ranges, resolution, and accuracy specifications are listed in the following table.

Range	Resolution	Accuracy	Max. Output Current
±20V	1mV	±(0.5% of setting +10mV)	10mA

Output Resistance:  $\leq 0.2\Omega$

Maximum Allowable Capacitive Load:  $\leq 1000\text{pF}$

### Voltage Monitors (Vm):

Two Vm channels. Output ranges, resolution, and accuracy specifications are listed in the following table.

Range	Resolution	Accuracy
±2V	100 $\mu\text{V}$	±(0.5% of reading+10mV)
±20V	1mV	±(0.2% of reading+10mV)

Input Resistance:  $1\text{M}\Omega \pm 1\%$

Capacitance in Parallel with Output:  $150\text{pF} \pm 10\%$

### Ground Unit (GNDU):

Maximum Output Current:  $\pm 500\text{mA}$

Output Voltage:  $0\text{V} \pm 2\text{mV}$

Maximum Residual dc Resistance (through furnished cables):  $2\Omega$  (Force),  $5\Omega$  (Sense)

Maximum Allowable Capacitive Load:  $10000\text{pF}$

Table 1-1. Specifications (sheet 4 of 4)

**SPECIFICATIONS COMMON TO ALL UNITS**

Maximum dc Withstand Voltage: 100V (SMUs, Vs and Vm 1 and 2, and guard terminals)

Maximum dc Voltage between Common (COM) and GND:  $\pm 42V$

Voltage/Current Sweep: Output from each SMU and Vs can be swept.

**GENERAL SPECIFICATIONS**

**Data Input/Output:**

Controlled remotely via HP-IB. The 4141B may be interfaced with any HP-IB compatible controller. (HP-IB is Hewlett-Packard's implementation of IEEE 488 and ANSI-MC.1.1 standards.)

**Self-Test Function:**

Automatically performed each time the 4141B is turned on. The Self Test can also be performed at any time via HP-IB.

Operating Temperature Range:  $10^{\circ}C$  to  $40^{\circ}C$  @  $\leq 70\% RH$

Permissible Temperature Change:  $\leq 1^{\circ}C/5$  min.

Power Requirements: 100V/120V/220V  $\pm 10\%$ ; 240V-10%+5%; 48 - 66Hz; 200VA max.

Dimensions: 426W x 235H x 612D (mm) (approx.)

Weight: Approximately 19kgs.

## GENERAL INFORMATION

Table 1-2. Supplemental Performance Characteristics (sheet 1 of 2)

Supplemental characteristics are not guaranteed specifications but are typical characteristics that are included only as additional information.

### Source/Monitor Units (SMUs):

Offset Current when operated as a voltmeter:  $6\text{pA} + 2\text{pA} \times V_o/100$

Offset Voltage when operated as a current meter: 10mV

### Noise Characteristics:

Voltage Source Noise: 0.01% of range (rms)

Current Source Noise: 0.1% of range + 3pA + 0.005pA  $\times C_g$ (rms)  
( $C_g$ : Guard Capacitance in pF)

Voltage Monitor: 0.02% of range (peak-to-peak)

Current Monitor: 0.3% of range + 10pA (peak-to-peak)

### Output Overshoot:

Voltage Source Overshoot: 5mV

Current Source Overshoot: 1% of setting

### Current Range Switching Transient Noise:

Range Increment: 0.01% of voltage range + 10mV\*

Range Decrement: 10mV\*

\* When switching to the 10nA or 1nA range,  $10\text{mV} + 120/(3 + C_x)\text{mV}$ , where  $C_x$  is load capacitance (pF).

Maximum Internal Guard to Ground Capacitance: 700pF

Guard Offset Voltage: 1mV

Guard Current-Induced Voltage Error:  $100\Omega \times I_g$  ( $I_g$  = guard current)

### Voltage Sources ( $V_s$ ):

Output Noise: 6mVrms

### Voltage Monitors ( $V_M$ ):

Noise Level: 0.3mV p-p on 2V range (when integration time is set to MEDIUM or LONG); 3mV p-p on 20V range.

Table 1-2. Supplemental Performance Characteristics (sheet 2 of 2)

**Ground Unit (GNDU):**

Output Noise: 6mVrms

Maximum Load Capacitance: 10000pF

**Noise Rejection: (integration time set to MEDIUM or LONG)**

Normal Mode Rejection:  $\geq 60\text{dB}$

Common Mode Rejection:

Voltage monitor:  $\geq 60\text{dB}$

Current monitor:  $\leq 2\text{pA}$

**Measurement Speed: (when using an HP 9000 series 200/300 computer)**

Force (current or voltage) -- Approx. 35ms

Spot Measurement (current or voltage) -- Approx. 25ms

Sweep measurement (binary data transfer format) -- Approx. 490ms (51 points)

**Note**

The times listed, which apply only when SHORT integration is used, include the measurement data transfer time between the 4141B and the controller but do not include ranging time. These times do not apply on the 1nA or 10nA range.

**GENERAL INFORMATION**

**Table 1-3. Accessories (sheet 1 of 2)**








Accessories	Description
	<p><b>PN 04085-61651 Interconnect Cable Assembly</b></p> <p>For interconnecting the 4141B and the Connector Plate (PN 04141-60001).</p>
	<p><b>PN 04141-60001 Connector Plate</b></p> <p>For interfacing the 4141B with a wafer prober. Refer to Section 3 for details on Connector Plate usage.</p> 
	<p><b>PN 04145-61630 BNC Cables</b></p> <p>For connecting the 4141B's V<sub>s</sub> and V<sub>k</sub> terminals to the Connector Plate. Four cables are furnished; each cable is 3 meters long.</p>



Table 1-3. Accessories (sheet 2 of 2)

Accessories	Description
	<p>*HP 16058A Test Fixture (not furnished)</p> <p>Test fixture for performing measurements on packaged devices. Equipped with a safety lid and the following fixture accessories.</p> <p>PN 16058-60003 Personality Board            PN 16058-61603 Triaxial Cables, 1.5m, 4ea.            PN 16058-61604 System Cable            Socket Boards/Connection Cable Set</p> <p>Refer to the 16058A Operating Note for more information on how to use this test fixture.</p>
	<p>*HP 16059A Adapter (not furnished)</p> <p>For interconnecting the 4141B and the 16058A Test Fixture. Refer to Section 3 for details.</p>
	<p>Performance Verification Software (not furnished)</p> <p>Can be purchased on a 5-1/4" mini-flexible disc, PN 04141-65101 (for use with the HP 9000 Series 200 Model 236 Computer), on a tape cartridge, PN 04141-90501 (for use with the HP85 Computer), or on a 3-1/2" micro-flexible disc, PN 04141-65301 (for use with the HP 9000 Series 300 Computer).</p> <p>This software is for servicing the 4141B only. Refer to Section 4 for more information.</p>
<p>* The Ground Unit of the 4141B cannot be used for measurements through the 16058A/16059A, because the 16058A does not have a Ground Unit terminal.</p>	



## **SECTION 2**

### **INSTALLATION**

#### **2-1. INTRODUCTION**

This section provides installation instructions for the Model 4141B DC Source/Monitor. It also includes information on initial inspection and damage claims, on preparation for using the 4141B, and on packaging, storage, and shipment.

#### **2-2. INITIAL INSPECTION**

The 4141B, when shipped from the factory, meets all the specifications listed in Table 1-1. Upon receipt, inspect the shipping container for damage. If the shipping container or cushioning material is damaged, it should be kept until the contents of the shipment have been checked for completeness and the instrument has been checked mechanically and electrically. The contents of the shipment should be as shown in Figure 1-1. The procedures for checking the general electrical operation are given in Section 3 (Self Test) and the procedures for checking the 4141B against its specifications are given in Section 4. First, do the self test. If the 4141B is electrically questionable, then do the Performance Tests to determine whether the 4141B has failed or not.

If the shipment is incomplete, if the contents show any sign of mechanical damage or other defects (scratches, dents, broken switches, etc.), or if the instrument does not pass the self test or performance tests, notify the nearest Hewlett-Packard office (see list at back of this manual). The HP office will arrange for repair or replacement without waiting for claim settlement.

#### **2-3. POWER REQUIREMENTS**

The 4141B requires a power source of 100, 120, 220 Volts ac  $\pm 10\%$ , or 240 Volts ac  $+5\%/-10\%$ , 48 to 66Hz, single phase. Maximum power consumption is 140VA.

#### **WARNING**

**IF THE INSTRUMENT IS TO BE ENERGIZED VIA AN EXTERNAL AUTO-TRANSFORMER FOR VOLTAGE REDUCTION, BE SURE THE COMMON TERMINAL IS CONNECTED TO THE NEUTRAL POLE OF THE POWER SOURCE.**

## INSTALLATION

### 2-4. LINE VOLTAGE AND FUSE SELECTION

Figure 2-1 provides instructions for line voltage and fuse selection. The 4141B is shipped from the factory with the fuse and LINE VOLTAGE SELECTOR switch setting appropriate for the geographic area in which the instrument will be used.

#### CAUTIONS

- (1) BEFORE TURNING ON THE 4141B, VERIFY THAT THE LINE VOLTAGE SELECTOR SWITCH IS CORRECTLY SET FOR THE LINE VOLTAGE BEING USED. USE A FUSE PROPER FOR THE SELECTED LINE VOLTAGE.
- (2) USE ONLY REPLACEMENT FUSES OF THE CORRECT CURRENT RATING AND OF THE SPECIFIED TYPE. DO NOT USE MENDED FUSES, AND DO NOT SHORT CIRCUIT THE FUSE HOLDERS.




Figure 2-1. Voltage and Fuse Selection

### 2-5. LINE FREQUENCY FILTER

To reject the effects of line-frequency noise, set the FILTER switch on the rear panel to the frequency of the ac power source.

### 2-6. POWER CABLE

To protect operating personnel, the National Electrical Manufacturers Association (NEMA) recommends that the instrument panel and cabinet be grounded. The 4141B is equipped with a three-conductor power cable which, when plugged into an appropriate receptacle, grounds the instrument. The offset pin on the power cable is the ground wire.

## INSTALLATION

To preserve the protection feature when operating the instrument from a two contact outlet, use a three prong-to-two prong adapter (PN 1251-8196) and connect the green grounding tab on the adapter to power line ground.

### CAUTION

**THE MAINS PLUG MUST ONLY BE INSERTED IN A SOCKET OUTLET PROVIDED WITH A PROTECTIVE EARTH CONTACT. THE PROTECTIVE ACTION MUST NOT BE NEGATED BY THE USE OF AN EXTENSION CORD (POWER CABLE) WITHOUT A PROTECTIVE CONDUCTOR (GROUNDING).**

Figure 2-2 shows the available power cords for use in various countries including the standard power cord furnished with the instrument. HP Part number, applicable standards for power plug, power cord color, electrical characteristics and countries using each power cord are listed in the figure. If assistance is needed for selecting the correct power cable, contact the nearest Hewlett-Packard office.

# INSTALLATION









<p><b>OPTION 900</b> <span style="float: right;"><b>United Kingdom</b></span></p>  <p>Plug : BS 1363A, 250V Cable : HP 8120-1351</p>	<p><b>OPTION 901</b> <span style="float: right;"><b>Australia/New Zealand</b></span></p>  <p>Plug : NZSS 198/AS C112, 250V Cable : HP 8120-1369</p>
<p><b>OPTION 902</b> <span style="float: right;"><b>European Continent</b></span></p>  <p>Plug : CEE-VII, 250V Cable : HP 8120-1689</p>	<p><b>OPTION 903</b> <span style="float: right;"><b>U.S./Canada</b></span></p>  <p>Plug : NEMA 5-15P, 125V, 15A Cable : HP 8120-1378</p>
<p><b>OPTION 905*</b> <span style="float: right;"><b>Any country</b></span></p>  <p>Plug : CEE 22-VI, 250V Cable : HP 8120-1396</p>	<p><b>OPTION 906</b> <span style="float: right;"><b>Switzerland</b></span></p>  <p>Plug : SEV 1011.1959-24507 Type 12, 250V Cable : HP 8120-2104</p>
<p><b>OPTION 912</b> <span style="float: right;"><b>Denmark</b></span></p>  <p>Plug : DHCR 107, 220V Cable : HP 8120-2956</p>	<p><b>OPTION 917</b> <span style="float: right;"><b>India/Republic of S.Africa</b></span></p>  <p>Plug : SABS 164, 250V Cable : HP 8120-4211</p>
<p><b>NOTE:</b> Each option number includes a 'family' of cords and connectors of various materials and plug body configurations (straight, 90° etc.).</p> <p>* Plug option 905 is frequently used for interconnecting system components and peripherals.</p>	

Figure 2-2. Power Cables

## **2-7. INTERCONNECTIONS**

To interconnect the 4141B to an external controller or peripheral device using the HP-IB interface capability (IEEE Std. 488/ANSI-MC1.1), connect an HP-IB interface cable between the HP-IB connector on the rear panel of the 4141B and the HP-IB connector on the peripheral device. Refer to Section 3 for details on the HP-IB.

## **2-8. OPERATING ENVIRONMENT**

To maintain the proper operating environment for the 4141B, do not exceed the following limitations.

**Temperature:**

Operate the 4141B at temperatures from 0°C to 40°C.

**Humidity:**

The 4141B can be operated in environments with relative humidities up to 70% at 40°C, but must be protected from temperature extremes which cause internal condensation.

## **2-9. STORAGE AND SHIPMENT**

The instrument may be stored or shipped under the following environmental conditions:

**Storage:**

Temperature: -22°C to +55°C

Humidity: 8% to 80% (RH)

**Shipment:**

Temperature: -40°C to +62°C

Humidity: 8% to 80% (RH)

The instrument must be protected from temperature extremes which cause internal condensation.

## **INSTALLATION**

### **2-10. PACKAGING**

**Original Packaging:** Containers and materials identical to those used in factory packaging are available from Hewlett-Packard.

**Other Packaging:** The following general instructions should be used for repacking the 4141B with commercially available materials.

1. Wrap the instrument in heavy paper or plastic.
2. Use a strong shipping container. A double-walled carton made of 350 pound test material is adequate.
3. Use enough shock absorbing material (3-to 4-inch layer) around all sides of the instrument to provide a firm cushion and to prevent movement inside the container. Protect the front panel with cardboard.
4. Seal the shipping container securely and mark it **FRAGILE** to ensure careful handling.
5. In any correspondence with HP, refer to the instrument by model and serial number.

### **2-11. INSTALLATION INSTRUCTIONS**


The 4141B can be operated from a bench or it can be rack-mounted for use in a measurement system. The instrument is equipped with two retractable stands which are mounted on the instrument's bottom cover. To use the stands, pull each one away from the bottom cover until it locks into position. To mount the 4141B in a rack, you'll need Options 907, 908, and 909. Rack-mounting information is given in Figure 2-3.



## INSTALLATION

Option	Kit Part Number
907	Handle Kit, 5061-9691
908	Rack Flange Kit, 5061-9679
909	Rack Flange & Handle Kit, 5061-9685

1. Remove the adhesive-backed trim strips ① from the right and left front sides of the 4141B.
2. **HANDLE INSTALLATION:** Attach the front handles ③ to the right and left front sides of the 4141B with the screws provided. Attach the trim ④ to the handles.



### Note

To perform steps 3 and 4, remove the feet from the bottom cover. Lift the bar at the inner side of each foot and slide the foot towards the bar.

3. **RACK MOUNTING:** Attach the rack mount flanges ② to the right and left front sides of the 4141B with the screws provided.
4. **HANDLE AND RACK MOUNTING:** Attach the front handles ③ and the rack mount flanges ⑤ to the right and left front sides of the 4141B with the screws provided.

Figure 2-3. Rack Mount Kit



# SECTION 3 OPERATION

## 3-1. INTRODUCTION

This section explains how to operate the HP 4141B DC Source/Monitor. Included are descriptions of the front- and rear-panels, lamps, and connectors; discussions of operating procedures and measurement techniques; and instructions on how to run instrument's SELF TEST. **WARNINGS**, **CAUTIONS**, and **Notes** are given throughout; they must be observed to ensure the safety of the operator and the integrity of the instrument. Figure 3-1 shows the organization of this section.




Figure 3-1. Organization of Section 3

## OPERATION

### WARNING

BEFORE YOU TURN ON THE 4141B, CONNECT ALL PROTECTIVE EARTH TERMINALS, EXTENSION CORDS, AUTO-TRANSFORMERS, AND OTHER DEVICES CONNECTED TO THE INSTRUMENT TO A PROTECTIVE EARTH-GROUNDED SOCKET. ANY INTERRUPTION OF THE PROTECTIVE EARTH GROUNDING WILL CAUSE A POTENTIAL SHOCK HAZARD THAT COULD RESULT IN SERIOUS PERSONAL INJURY.

ONLY FUSES OF THE REQUIRED CURRENT RATING AND OF THE SPECIFIED TYPE MAY BE USED. DO NOT USE REPAIRED FUSES OR SHORTED FUSE HOLDERS. TO DO SO COULD CAUSE A SHOCK OR FIRE HAZARD.

### CAUTION

BEFORE THE INSTRUMENT IS TURNED ON, THE VOLTAGE SELECTOR SWITCH ON THE REAR-PANEL MUST BE SET TO MATCH THE LINE VOLTAGE BEING USED. FAILURE TO SET THE PROPER LINE VOLTAGE MAY RESULT IN DAMAGE TO THE INSTRUMENT.

## 3-2. PANEL FEATURES

Figures 3-2 and 3-3 identify and briefly describe each key, indicator, and connector on the 4141B's front and rear panel, respectively.




Figure 3-2. Front Panel Features (sheet 1 of 2)

**2. HP-IB Status Indicators:**

Four LEDs that indicate the 4141B's HP-IB status (SRQ, LISTEN, TALK and REMOTE) when interfaced to a controller.

**3. MEASURING Lamp:**

Indicates that the 4141B is outputting a voltage or current and performing a measurement.

**4. HIGH VOLTAGE Lamp:**

Indicates that the 4141B is set to output a voltage in excess of  $\pm 42V$ .

**WARNING**

**DO NOT TOUCH THE OUTER CONDUCTORS OF THE SMU OUTPUT CONNECTORS WHEN THE HIGH VOLTAGE LAMP IS LIT. THIS LAMP INDICATES THAT DANGEROUS VOLTAGES OF UP TO  $\pm 100V$  MAY BE PRESENT AT THESE CONNECTORS.**


**5. LOCAL/SELF TEST Key:**

This key initiates the 4141B's SELF TEST. The 4141B is released from HP-IB control (the REMOTE lamp will go out) when you press this key. This key is disabled when the 4141B is set to local lockout.

**6. FAIL Lamp:**

Indicates the 4141B has failed SELF TEST.

Figure 3-2. Front Panel Features (sheet 2 of 2)



### 1. I•V CHANNELS:

Four SMU connectors (triaxial), one Ground Unit (GNDU) connector (triaxial), and one INTERLOCK connector (BNC). These connectors interconnect the 4141B to a test fixture or wafer prober using Interconnect Cable Assembly (PN 04085-61651). The INTERLOCK function prevents the SMUs from outputting more than  $\pm 42V$  unless a  $0\Omega$  termination or a shorting plug is used on the INTERLOCK connector. This function is discussed in paragraph 3-27.

### WARNING

**VOLTAGES OF UP TO  $\pm 100V$  MAY BE PRESENT AT THE OUTER CONDUCTORS OF THE SMU OUTPUT CONNECTORS. DO NOT TOUCH THE OUTPUT CONNECTORS IF THE FRONT-PANEL HIGH VOLTAGE LAMP IS ON. CONNECT ONLY THE FURNISHED INTERCONNECT CABLE ASSEMBLY TO THE I•V CHANNELS.**

### 2. LINE FUSE Holder:

The instruments power line fuse is installed into this holder.

100/120V operation: 2.5A/250V. PN 2110-0015  
 200/240V operation: 1.25A/250V. PN 2110-0305

### 3. LINE VOLTAGE SELECTOR Switches:

These switches are used to select the ac operating voltage. The voltages selectable are 100, 120, 220, and 240V. Refer to Section 2 for more information on the 4141B's power requirements.

Figure 3-3. Rear Panel Features (sheet 1 of 2)

**4. LINE Input Receptacle:**

Power cord receptacle.

**5. HP-IB Connector:**

A 24-pin connector for interconnecting the 4141B to HP-IB.

**6. HP-IB ADDRESS Switches:**

Used to set the 4141B's HP-IB address to any setting between 0 and 30.

**7. VOLTAGE MONITORS (VM) Input Connectors:**

Two female BNC connectors used with a user-furnished test fixture. The outer conductors are connected to common (  $\psi$  ).

**8. VOLTAGE SOURCES (Vs) Output Connectors:**

Two female BNC connectors used with a user-furnished test fixture. The outer conductors are connected to common (  $\psi$  ).

**9. FILTER Switch:**

Used to set the measurement integration time to minimize the effects of line-frequency related noise. Set this switch to the frequency of the ac power source.

**10. COM (COMMON) - GROUND Terminals:**

Common (  $\psi$  ) and Ground (  $\perp$  ) terminals are used when making floating or grounded measurements. The Common terminal is connected to the outer-conductors of the VM (7) and Vs (8) connectors. The Ground terminal is tied to the 4141B's chassis. When making floating measurements, disconnect the shorting-bar.

**WARNING**

**A POTENTIAL SHOCK HAZARD EXISTS WHEN THE COMMON TERMINALS ARE NOT GROUNDED (SHORTING-BAR DISCONNECTED). REGARDLESS OF THE OUTPUT VOLTAGE, DO NOT TOUCH THE COMMON TERMINAL OR THE OUTER CONDUCTORS OF THE VS OR VM CONNECTORS WHILE A MEASUREMENT IS IN PROGRESS.**

Figure 3-3. HP 4141B Rear Panel Features (sheet 2 of 2)

## OPERATION

### 3-3. SELF TEST

The 4141B has self-diagnostic capabilities which are initiated each time the instrument is turned on to confirm normal operation. SELF TEST can also be initiated using the HP-IB or the LOCAL/SELF TEST key on the front panel. When the instrument is turned on, three SELF TESTs (Table 3-1) are performed. When a SELF TEST is initiated by an HP-IB command or with the LOCAL/SELF TEST key, only two tests are performed (MPU Test and SMU Test). A SELF TEST takes about ten seconds to perform. If the instrument fails SELF TEST, the FAIL lamp on the front panel will light and an error code will be output when a Test Result command "TR" is sent via HP-IB.

#### Note

If exposed to an extreme change of ambient temperature, the 4141B might fail SELF TEST. If you suspect this to be the case, let the instrument warm-up, then turn it OFF and ON one time.

Table 3-1. 4141B Self Test

Test Name	Description
MPU test	Checks the basic functions of the MPU (Microprocessor Unit) by checking four ROMs (Read-only Memory) and sixteen RAMs (Random-Access Memory)
HP-IB test	Checks all HP-IB interface capability.
SMU test	Checks the basic functions of the four SMUs.



### 3-4. 4141B OPERATING OUTLINE

A simplified block diagram of the 4141B appears in Figure 3-4. The 4141B has eight channels for device source and monitors. Four of these channels are used for Source/Monitor units (SMU1 to 4). The remaining channels are used as Voltage Source Units (VS1 and VS2) and Voltage Monitor Units (VM1 and VM2). All channels are individually controlled by the control section, which via HP-IB transmits all setup instructions to the appropriate channels, and then receives the measurement results from the channels. The control section also controls sweep measurements. Receiving sweep measurement commands, the 4141B automatically enables a sweep measurement and outputs all measurement data after completion of the measurement. The ground unit (GNDU) is used as the SMUs' common to help the SMU make accurate voltage measurements by reducing the residual resistance of the output cable.




Figure 3-4. 4141B Overview

## OPERATION

### 3-5. SOURCE/MONITOR UNITS (SMUs)

Figure 3-5 shows a simplified circuit diagram of an SMU. You can set each SMU to function as a voltage source/current monitor or as a current source/voltage monitor by specifying source the V or I mode, respectively. When set to the V source mode, each SMU can source 0 to  $\pm 100\text{V}$  with a maximum resolution of  $1\text{mV}$ , and can measure up to  $100\text{mA}$ . Conversely, when set to I source mode, each SMU can source (or sink) up to  $100\text{mA}$  with a maximum resolution of  $1\text{pA}$ , and can measure up to  $\pm 100\text{V}$ . The SMU's ranges when in the V or I modes are listed in Table 3-2 along with the resolution and maximum output in each range. Also listed in the table are the applied voltage and the measured current of the SMU (maximum current measurement resolution of  $0.05\text{pA}$ ). The range changing can be set to either to auto or manual. The output power is internally limited to  $2\text{W}$ . Graphs which show the specifiable voltage or current output are shown in Figure 3-6 Specifiable Voltage/Current Output. The voltage and current values enclosed within the bold lines are specifiable. The output voltage and current can be set within the limits specified and can be swept as a linear or logarithmic function.

Each SMU's output connected to a triaxial output connector and the center conductor is connected to the Sense line, a high input impedance voltage monitor. The inter-conductor, the Force line, is the output of the voltage source or current source. This "Force" and "Source" construction enables accurate voltage measurement regardless of voltage drop along the output cable. Detailed information about Force and Sense is contained in paragraph 3-18. The outer-conductor of the SMU is connected to the guard terminal (maintains the same voltage as that of the "Force" terminal), which helps to accurately measure low current. COM (COMMON) is a common reference for all channels. The SMU is electrically disconnected from its output terminal when a measurement is not in progress or when a zero output HP-IB "DZ" command is sent.




Figure 3-5. Simplified SMU Circuit Diagram




Figure 3-6. Specifiable Voltage/Current Output

## OPERATION

### 3-6. VOLTAGE SOURCES (VS) AND VOLTAGE MONITORS (VM)

A simplified circuit diagram of the VS1 and VS2 voltage sources are shown in Figure 3-7, and that of the VM1 and VM2 voltage monitors in Figure 3-8. The voltage source has only one range with a maximum output voltage of  $\pm 20\text{V}$ , a maximum output current of  $10\text{mA}$ , and a measurement resolution of  $1\text{mV}$ . The output voltage of each VS can be held constant or can be swept as a linear or log function. The VM channels have two measurement ranges,  $\pm 2\text{V}$  with a resolution of  $100\mu\text{V}$  and  $\pm 20\text{V}$  with a resolution of  $1\text{mV}$ .




Figure 3-7. VS Simplified Circuit Diagram




Figure 3-8. VM Simplified Circuit Diagram

### 3-7. GROUND UNIT (GNDU)

A simplified circuit diagram of the ground unit (GNDU) is shown in Figure 3-9. The GNDU has a "Force" and "Sense" line similar to that of the SMU. The force line connects to a voltage source and the sense line to a high input impedance voltage monitor. The voltage monitor controls the voltage source and keeps the input voltage at 0V by feeding the input voltage back to the voltage source. The GNDU reduces the residual resistance of the cable connected to the device under test to help ensure accurate voltage measurements by the SMU.

#### Note

The ground unit cannot be used with the 16058A Test Fixture.




Figure 3-9. GNDU Simplified Circuit Diagram

## OPERATION

### 3-8. COMPLIANCE

To prevent over-voltage or over-current damage to the device under test, several levels of output protection (compliance), are used in the 4141B. The maximum output voltage or current from an SMU, operating as a current or voltage source, can be specified. The maximum specifiable compliance depends on the voltage or current range over which the source is operating. To determine the maximum output value see Table 3-2. Here, because the compliance has the same range and resolution as the output voltage and current, Table 3-2 also applies. Once an SMU has reached its compliance limit, the output voltage or current will not increase any further. Compliance is valid for the polarity specified. The VS (voltage source) has no user definable current compliance function.

Table 3-2. SMU Source Range

Source Mode	Range	Resolution	Maximum Output	
V	±20V	1mV	100mA	
	±40V	2mV	50mA	
	±100V	5mV	20mA	
I	±1nA	1pA	100V	
	±10nA	10pA		
	±100nA	100pA		
	±1µA	1nA		
	±10µA	10nA		
	±100µA	100nA		
	±1mA	1µA		
	±10mA	10µA		
	±100mA*	20mA		100µA
		50mA	20V	
		100mA		

\*: The 100mA range consists of three subranges.

### 3-9. KELVIN CONNECTIONS

When a device is connected to an instrument through a long cable or through many switch contacts, the residual resistance of the cable or the contacts will add to the measurement error due to the voltage drop across the total residual resistance. To reduce the errors caused by residual resistance, Kelvin connections are used in the 4141B's SMU and GNDU circuits. In a measurement example using a non-Kelvin SMU and GNDU (Figure 3-10 (a)), the SMU is set to the I mode (Current Source/Voltage Monitor) and the DUT's resistance is calculated using the specified current value and the measured voltage value. When the DUT's resistance is low, the residual resistance ( $r_1+r_2$ ) adversely affects the measurement result. When a Kelvin SMU and non-Kelvin GNDU (Figure 3-10 (b)) is used, and when the voltage monitor input impedance is high enough, only the residual resistance ( $r_2$ ) affects the measurement result. Point A stays at some non-zero voltage because of  $r_2$ . When the voltage at point A is 0V, the measurement is satisfactory regardless of the effects of  $r_1$  and  $r_2$ . When the Kelvin GNDU is connected as in Figure 3-10 (c), the GNDU regulates point A to 0V through the use of feedback.




Figure 3-10. Kelvin Connections

## OPERATION

### 3-10. GUARDING

When you are making low-current measurements (SMU set to current monitor), guarding helps to reduce the effects of leakage current. In the current measurement example without guarding (Figure 3-11a), when the insulation resistance between the current path and ground line is low, the resultant leakage current will affect the measurement result. When guarding techniques are used (Figure 3-11b), the the effects of leakage will be cancelled. Leakage current does not flow between the current path and the guard terminal because the guard terminal's voltage is held at the same potential as the SMU's output voltage, and the the leakage current between the guard terminal and ground line does not affect the measurement result. (See Figure 3-12, SMU output terminal configuration).

### WARNING

**THE GUARD POTENTIAL IS THE SAME AS THE SMU'S OUTPUT POTENTIAL THEREFORE, DO NOT TOUCH THE GUARD TERMINAL WHILE A MEASUREMENT IS IN PROGRESS.**

#### Note

Do not connect the guard terminal to any of the Sense, Force, or Common terminals.




Figure 3-11. Guarding Techniques






Figure 3-12. SMU Output Terminal Configuration




Figure 3-13. COMMON-GROUND Terminal

## **OPERATION**

### **3-11. FLOATING MEASUREMENTS**

When the DUT is grounded or the DUT's external voltage source or shield case is grounded, the measurement results can sometimes be affected by ground loops. Therefore when using the 4141B for floating measurements, disconnect the shorting bar on the rear panel (Figure 3-13). The measurement and source circuit can be floated  $\pm 42V$  above chassis ground and a voltage of over  $\pm 42V$  can be obtained at the COM (common) terminal.

#### **WARNING**

**A POTENTIAL SHOCK HAZARD MAY RESULT IF THE COMMON TERMINAL IS NOT GROUNDED (SHORTING-BAR DISCONNECTED). THEREFORE, REGARDLESS OF THE OUTPUT VOLTAGE, DO NOT TOUCH THE COMMON TERMINAL (  $\nabla$  ) OR ANY OF THE OUTER-CONDUCTORS OF THE GNDU, INTERLOCK TERMINAL, VS, OR VM CONNECTORS WHILE A FLOATING MEASUREMENT IS IN PROGRESS.**

#### **CAUTION**

**DO NOT FLOAT THE COMMON TERMINAL AT VOLTAGES ABOVE  $\pm 42V$  REFERENCED TO CHASSIS GROUND.**

### **3-12. INTEGRATION TIME**

Three integration times can be selected via HP-IB to prevent line frequency and other noise sources from affecting the measurement accuracy. The following is a description of each:

**SHORT:** Four samples are taken independent of line frequency and averaged.

**MEDIUM:** Sixteen samples are taken during one line frequency period and averaged.

**LONG:** 256 samples are taken during 16 line frequency periods and averaged.

When the 4141B is turned on, the default integration time selection is SHORT.

### **3-13. SELF CALIBRATION**

To minimize output drift and measurement fluctuations (caused primarily by changes in the ambient temperature), the 4141B enables self-calibration of the SMUs and their control circuits (A/D and D/A converters). Long or short self-calibration can be selected. Allow for a 40 minute warmup time before performing the 4.2 second long self-calibration. The long self-calibration is usually performed after instrument turn on and the 0.6 second short-calibration is usually performed every thirty minutes, or if the ambient temperature changes by more than 3 °C (6 °F).

## OPERATION

### 3-14. MEASUREMENT RANGES AND RESOLUTION

The measurement ranges and resolution of the SMUs and voltage monitors are given in Figure 3-14. An SMU's ranging function is dependent on the compliance setting. When under HP-IB control, the data is output as five digits for both current and voltage measurements.

#### SMU Voltage Output:

Output can be selected in ranges of 20V, 40V, or 100V.

#### SMU Voltage measurement:

Auto-ranging with the highest range depending on the specified voltage compliance.

#### SMU Current Output:

Auto-ranging and limited auto-ranging spans nine ranges from 1nA to 100mA.

#### SMU Current measurement:

Auto-ranging and limited auto-ranging spans nine ranges from 1nA to 100mA.

#### Vs Output:

Only the 20V range is available.

#### V<sub>M</sub> Measurement:

Auto-ranging over the 2V and 20V ranges, or a fixed 20V range.




Figure 3-14. Measurement Range and Resolution (Sheet 1 of 2)




Figure 3-14. Measurement Range and Resolution (sheet 2 of 2)

## **OPERATION**

### **3-15. SPOT MEASUREMENT**

The output of the SMUs and VSs can be kept constant and can be measured by triggering the specified monitor channels. Internal or external triggering can be selected, each of which is described below:

**Internal Trigger:**

Triggering automatically with specified monitor channel at 0.3 second intervals.

**External Trigger:**

Triggering with the specified monitor channel each time a trigger command ("XE", "TV", or "TI") is sent via HP-IB.

### 3-16. SWEEP MEASUREMENT

The SMUs and voltage sources (VSs) outputs can be swept as a staircase function (Figure 3-15). In the HP-IB mode a sweep setup command is sent with the following sweep parameters.

**START:** The starting value of voltage or current value when a sweep begins

**STOP:** The end value of voltage or current when a sweep stops

**STEP:** The sweep increment or decrement value specified in the LINEAR SWEEP MODE only.

**SWEEP MODE:** LINEAR or LOG. In the LINEAR mode, the output is swept linearly according to the specified STEP value; with the maximum number of steps set at 1021. The 4141B stores 1021 points of measurement data. In the LOG mode, the STEP value in [dB] can be up to 20 dB with a resolution of 0.2dB.




Figure 3-15. Staircase Sweep Output

Of the six source channels (four SMUs and two voltage sources), the only two channels, which can be swept simultaneously, are the primary sweep channel and the secondary sweep channel. The secondary sweep channel must differ from the primary sweep channel, but the sweep mode (LINEAR or LOG), source mode (I or V), and the number of steps must agree. The start, stop, and compliance values, however, may differ.

## OPERATION

### 3-17. MEASUREMENT TIME

Measurement time is defined below. The times given are not guaranteed, and are intended only for reference. They are obtainable using an HP 9000 Series 200/300 Computer and the BASIC language system.

(1) Sweep Measurement

Measurement Time = Overhead Time + (Response Time + Ranging Time + Integration Time)/ point

\*Overhead Time: Interprets sweep command at 80 to 200ms

\*Response Time: The following calculation applies when the current range does not change. The response time consists of the settling time, setup time, HP-IB and SMU wait times.

Current Range	Setting, Set-up, HP-IB Time	SMU Wait Time
100nA to 100mA	3.8ms	2ms
1nA to 10nA		30ms

\*Ranging Time: 0 to 196ms

Measurement Time/ point

Settling, Set-Up and HP-IB Time	Delay Time	SMU Wait Time	Ranging Time	Integration Time
3.8 ms	Settling value	2ms or 30ms	0ms to 196ms	1.4ms to 320ms

Example: For the minimum measurement time, the current range does not change:

$$= 80 + (3.8 + 2 + 1.4) \times (\text{Number of steps})$$

(2) Spot Measurement

Measurement Time: Forcing Time + Measuring Time

\* Forcing Time

Overhead, HP-IB	SMU wait time	Ranging time
23ms	2ms or 30ms	0ms to 196ms



\*Measurement Time

Settling, Set-up and HP-IB	SMU Wait Time	Ranging Time	Integration Time
30ms	2ms or 30ms	0ms to 196ms	1.4ms to 320ms

Example: For the minimum measurement time, the current range does not change:

$$= (23 + 2) + (30 + 2 + 1.4) = 58.4ms$$

The measurement techniques explained below minimize or eliminate range changes during high speed measurements. To exemplify these techniques, see Sample Program 5.

1) Eliminate Range Changes

The simplest and most effective way to reduce the measurement time is to fix the force and monitor ranges to eliminate range changes from occurring during a measurement. For example, to source from 1µA to 10mA using the "DI" command, specify the 10mA (10.000mA) range in the command, since it provides 1µA resolution and 10mA full-scale capability. Similarly, to trigger a current measurement, fix the required current monitor range and the measurement resolution using the "RI" command. Set the "DV" or "WV" command's current compliance to a value within the current monitor range specified in the "RI" command because the current monitor range is determined by the compliance value specified.

2) Minimize Range Changes and Avoid Using "Slow" Ranges

If the resolution requirements prevent using a fixed range, then limit the number of range changes that can occur during the measurement. This can be done by specifying a range of ranges with regard to the compliance settings.

Measurement time depends on the current range set: the lower the current range, the longer a measurement will take. If measurement speed is more important than resolution, use the higher current ranges.

The following table lists range changing times. If more than one range change is required, total ranging time is the sum of the times required for each range change. For example, to change from the 10mA range to the 1µA range will require 13 + 21 + 13 + 25ms = 72ms.

100mA	10mA	1mA	100µA	10µA	1µA	100nA	10nA	1nA
22ms	13ms	21ms	13ms	25ms	14ms	70ms	58ms	

## **OPERATION**

### **3-18. DUT CONNECTIONS**

DUTs can be connected to the 4141B using the Interconnect Cable Assembly (PN 04085-61651) and the four BNC cables for VSs, VMs or by using the 16059A Adaptor. The Interconnect Cable Assembly connects with the Connector Plate (PN 04141-60001). The 16059A Adaptor enables connection of the 16058A Test Fixture. Connection using the furnished Connector Plate is described in paragraph 3-19 and connection using the 16058A is described in paragraph 3-20.

### **WARNING**

**DO NOT USE THE TRIAXIAL CABLES DIRECTLY BECAUSE A POTENTIAL SHOCK HAZARD EXISTS IN THE OUTER CONDUCTOR (GUARD).**

### 3-19. DUT Connection Using the Connector Plate

The furnished Connector Plate (PN 04141-60001) is for use with the Interconnect Cable Assembly (PN 04085-61651) and BNC Cables (PN 04145-61630). This Assembly has four triaxial connectors for the SMUs, one triaxial connector for the GNDU, and one BNC connector for the Interlock. Four BNC cables for the VSs and VMs are intended for use with user-fabricated test fixtures. For the best measurement results, enclose the test fixture in a shielding-box and mount the Connector Plate onto the box, as shown in Figure 3-16. This will significantly reduce the effects of RFI and EMI. This is especially important when making low-current measurements of wafers at a probe station. To connect the Connector Plate, shielding-box, and 4141B, see Figure 3-16.

#### Mounting the Connector Plate and Connecting 4141B:


1. Drill holes to mount the Connector Plate onto the shielding-box. (See spacing in Table 1-3).
2. Mount the Connector Plate on the shielded-box, and ensure that there is good electrical contact between the plate and shielded-box.
3. Turn the 4141B off.
4. Connect 4141B to Interconnect Cable Assembly (PN 04085-61651), and connect the four BNC cables (PN 04145-61630) to the Connector Plate as shown in the following figure.

#### Note

When the Interconnect Cable Assembly is connected to the Connector Plate, the output of the SMUs is limited to  $\pm 42V$  as if the 4141B is detecting the fixture-lid-open condition. Short the INTERLOCK terminal USING A  $0\Omega$  to get an output of up to  $\pm 100V$ .


Figure 3-16. DUT Connection Using the Connection Plate (sheet 1 of 4)

**OPERATION**



The figure on the opposite page shows the connections between the 4141B and the furnished Connector Plate.

Figure 3-16. DUT Connection Using the Connector Plate (sheet 2 of 4)



5. Turn the 4141B on and make the required connection for the measurement setup.

**WARNING**

A POTENTIAL SHOCK HAZARD EXISTS WHEN INTERCONNECTION CABLE (PN 04085-61651) IS CONNECTED TO CONNECTOR PLATE. THEREFORE, DO NOT TOUCH THE OUTPUT TERMINAL OR THE OUTER CONDUCTOR OF THE SMUs WHILE A MEASUREMENT IS IN PROGRESS.

Figure 3-16. DUT Connection Using the Connector Plate (sheet 3 of 4)


## OPERATION

### Note

Do not connect the outer shield (guard) of an SMU to ground ( $\perp$ ) or common ( $\nabla$ ).


#### [Cable Connection from Connector Plate]

- 1) For the best measurement results, use two separate leads for extending cables to a wafer prober in order to maintain the Kelvin connection. Use the low-noise coaxial cables, PN 8120-0102 or 8120-3674 cable (See the following Figure). Connect the center conductor of one cable to SENSE, connect the other cable to FORCE and connect the outer conductors (shields) of both cables to GUARD. The outer conductors of these cables need not be connected at the wafer prober. To prevent oscillations when making dc measurements, do not use a cable whose length exceeds 1.5m.



Recommended Cable: PN 8120-0102 or  
PN 8120-3674

- 2) The cable length can be increased to 3m using a single cable and shorting SENSE to FORCE at the Connector Plate, as in the following Figure. Since this connection is not a Kelvin connection, the measurement results will include the residual resistance of the connection cable and will be affected by environmental noise.



Recommended Cable: PN 8120-0120 or  
PN 8120-3674

The cables will cause significant errors, so do not make low current measurements using the Connector Plate.

Figure 3-16. DUT Connection Using the Connector Plate (sheet 4 of 4)

### 3-20. DUT Connection Using the 16058A

The 16058A Test Fixture is designed to connect packaged devices, such as transistors, diodes and ICs, to the SMUs, voltage sources and voltage monitors of the 4141B. Eight interchangeable DUT Socket Boards are furnished with the 16058A. Use the 16059A Adaptor which is designed for connections between the 4141B and 16058A. Connection between the 16058A and the 4141B is shown in Figure 3-17.

#### Note

The Ground Unit in the 4141B cannot be connected to the 16059A because there is no connection for the Ground Unit on the 16058A.

#### Note

The 16059A cannot be used for Kelvin connections because it is designed for use with the 16058A which does not use Kelvin connections.




Figure 3-17. DUT Connection Using the 16058A (sheet 1 of 3)

## OPERATION

5. Turn the 4141B on and make the connections for the measurement setup.
6. Close test fixture lid and perform the measurement.

### Note

If the output voltage of an SMU or VS will exceed  $\pm 42\text{V}$  during measurement, close the test fixture lid to start the measurement. If an attempt is made to start the measurement while the test fixture lid is open, the 4141B will generate an SRQ signal that indicates the 4141B is not interlocked and the measurement will not start.

### Note

If test fixture lid opens while a measurement is in progress and the output voltage is greater than  $\pm 42\text{V}$ , the measurement will stop immediately and all SMU's and VS's outputs will be set to zero just as if an "DZ" command had been sent.

Figure 3-17. DUT Connection Using the 16058A (sheet 2 of 3)



The following figure shows the connections between the 4141B and the 16059A Adapter.




Figure 3-17. DUT Connection Using the 16058A (sheet 3 of 3)

## OPERATION

### 3-21. HP-IB INTERFACE

The 4141B can be remote controlled via the HP-IB instrument/computer interface.

#### Note

HP-IB is Hewlett-Packard's implementation of IEEE Standard 488, "Standard Digital Interface for Programmable Instrumentation."

### 3-22. HP-IB INTERFACE CAPABILITIES

The 4141B has eight HP-IB interface functions. (See list in Table 3-3).

Table 3-3. HP-IB Interface Capability

Code	Interface Function * (HP-IB Capabilities)
SH1* *	Source Handshake
AH1	Acceptor Handshake
T6	Talker (basic talker, serial poll, unaddress to talk If addressed to listen)
L4	Listener (basic listener, unaddress to listen If addressed to talk)
SR1	Service Request
RL1	Remote/local (with local lockout)
DC1	Device Clear
DT1	Device Trigger
<p>* Interface functions provides the means for a device to receive, process, and transmit messages over the bus.</p> <p>** The numeric suffix of the interface code indicates the limitation of the function, as defined in Appendix C of IEEE Standard 488-1978.</p>	

### 3-23. HP-IB CONNECTION

The 4141B can be connected to the HP-IB bus with or without a controller.

### 3-24. HP-IB STATUS INDICATORS

The four HP-IB Status Indicator LED lamps on the front panel will light to show the status of the 4141B on the HP-IB bus as follows:

- SRQ: SRQ SIGNAL FROM 4141B to controller on the HP-IB line. Refer to paragraph 3-30.
- LISTEN: 4141B set to listener.
- TALK: 4141B set to talker.
- REMOTE: 4141B is in the remote mode.

### 3-25. REMOTE PROGRAM CODES AND PARAMETER SETTINGS

The available remote program codes and parameter settings are briefly described in Table 3-4, and detailed format information is given below.

#### REMOTE PROGRAM CODE FORMAT

Remote program code sent to 4141B must be in upper case because the The 4141B ignores lower case characters.

#### (1) Delimiters

Commas, spaces, and carriage returns (CR, ASCII Code 13) separate (delimit) multiple commands and command operands. Delimiters are always ignored to prevent their influencing commands or program execution.

#### (2) Execution

The 4141B executes single commands and command strings when it receives a line terminator, a semicolon or a line feed (LF<ASCII Code 10). After command execution, the input buffer is cleared and the next command or command string is read into the buffer, and executed when a line terminator is encountered.

## OPERATION

### Note

Commands that require output data, such as "TV", "TI", "XE", "WS", "ID", or "TR", must be followed by a terminator if they are not the last command in a string, otherwise, a PROG ERROR SRQ message will be displayed. For example, the command string, "ID,XE", is illegal because the 4141B will try to execute both commands simultaneously. The correct format is "ID;XE". When executed, these commands will first clear the HP-IB output buffer and then fill it with new output data.

### Note

Up to eight commands can be included in a command string, but the parameter buffer may overflow, even if the command string contains fewer than eight commands. When this happens, a PROG ERROR SRQ message will be displayed.

#### (3) Command Operand

- \* Channel Number: A one digit integer specifying an SMU, VS or VM.
- \* num\_exp: A one digit integer.
- \* value: Numeric values can be entered in fixed or floating decimal format, with up to 12 digits including "+", "-" and "E" being acceptable. The exponent can be no greater than two digits and leading zeros are ignored. For example,

Floating decimal:	1.234E+01
	1.23456E-12
Fixed decimal:	1.234
	-.123456

### Note

Units for voltage, current and time are not needed when entering numeric values because these units are fixed as V (volts), A (amperes) and s (seconds).

- \* [ ] : Operands enclosed in brackets are optional, i.e., omissible.
- \* @ : @ Indicates initial control setting. (This symbol need not be included in operands.)

Table 3-4. Remote Program Codes and Parameter Settings (sheet 1 of 13)

**(1) GENERAL CONTROL GROUP**

The following program codes control the 4141B's functions:

\* **Clear all (CL)**

Initializes 4141B measurement function.

- Turns off all SMUs (SMU 1 TO 4) [Sets all SMUs to NOT USE],
- Turns off VS1 and VS2 [Sets VSs to ZERO OUTPUT].
- Sets VM1 and VM2 to auto range,
- Aborts the sweep in progress,
- Sets integration time to short,
- Sets HP-IB data output format to ASCII, and
- Clears the HP-IB data buffer.

Syntax: CL

**Note**

**NOT USE:** This is the SMU's default setting. The output relays are open.

**ZERO OUTPUT:** The VS's default setting, 0V output. SMUs are also set to ZERO OUTPUT under certain conditions. When in ZERO OUTPUT status, the SMU has the following settings: Output relays are on, voltage source mode, 20V range, 0V output, 10 $\mu$ A current limit.

\* **Test Start (TS)**

Initiates a SELF TEST.

Syntax: TS

\* **Test Result (TR)**

Copies the SELF TEST results to the 4141B's output buffer. An ENTER command will read and display the contents of the output buffer.

Syntax: TR

\* **Identification (ID)**

Copies DEVICE ID and software revision code to the output buffer. An ENTER command will read and display the contents of the buffer.

Syntax: ID

## OPERATION

Table 3-4. Remote Program Codes and Parameter Settings (sheet 2 of 13)

### \* Auto Calibration (CM)

Enables or disables the auto calibration function and can not be performed unless all SMUs are set to NOT USE.

Syntax: CM num-exp

num-exp: 0: Auto calibration disabled  
@1: Auto calibration enabled

### \* Calibration (CA)

Performs a calibration.

Syntax: CA num-exp

num-exp: 1: Executes a short calibration (0.6s).  
2: Executes a long calibration (4.2).

### \* Buffer Clear (BC)

Clears the HP-IB output data buffer and sweep data buffer before outputting data from the 4141B. This command resets the DATA READY status bit.

Syntax: BC

### \* Binary Data Format (BD)

Selects the HP-IB data output format. Does not affect the data already stored in the HP-IB output buffer.

Syntax: BD num-exp

num-exp: @0: ASCII data output.  
1: Binary data output.

### \* Set Ready Mask (SS)

Masks the Set Ready bit of the HP-IB status byte (Disables Set Ready RQS).

### Data Ready Mask (SD)

Masks data ready bit of HP-IB status byte (Disables Data Ready RQS).

Table 3-4. Remote Program Codes and Parameter Settings (sheet 3 of 13)

**End Status Mask (SE)**

Masks the End Status bit of the HP-IB status byte (Disables End Status RQS).

Syntax: SS num-exp  
SD num-exp  
SE num-exp

num-exp: @0: Masks (Disables RQS)  
1: Not mask (Enables RQS)

**(2) COMMON MEASUREMENT CONTROL GROUP**

The following program codes are used when making spot or sweep measurements.

**\* Integration Time (IT)**

Determines 4141B's integration time.

Syntax: IT num-exp

num-exp: @1: SHORT  
2: MEDIUM  
3: LONG

**\* VM Voltage Monitor Range (RV)**

Selects the voltage range of voltage monitors VM1 and VM2.

Syntax: RV Channel Number, num-exp

Channel Number: 1 or 5: VM1  
2 or 6: VM2

num-exp: @0: Auto-ranging  
1: 20V

## OPERATION

Table 3-4. Remote Program Codes and Parameter Settings (sheet 4 of 13)

### \* SMU Current Monitor Range (RI)

Used to select the current monitor range of the specified SMU. The current monitor range is varied when SMU is set to voltage source/current monitor mode.

#### Note

The current range actually used is either the current range set by the RI command or the range most suitable for the compliance value specified with the "DV" or "WV" commands.

Syntax: RI Channel Number, num-exp

Channel Number: SMU number (1 to 4)

num-exp: 0 to 9, same as current output command (DI). Refer to the DI command in the spot measurement control group. Default setting is auto-ranging.

### \* Monitor Channel (MC)

Sets up a monitor channel. When a specified SMU is set to NOT USE, the "MC" command sets the SMU to ZERO OUTPUT.

Syntax: MC Channel Number, num-exp

Channel Number: SMU number (1 to 4), VM number (VM1 or VM2 corresponds to 5 or 6 respectively)

num-exp: @0: Measurement disabled  
1: Measurement enabled

#### Note

The monitor range or channel set by an "RV", "RI" or "MC" command is valid only for an "XE" command, device trigger, internal trigger, and a sweep measurement. The "TV" and "TI" commands, always assume auto-ranging and cannot be used to trigger a measurement channel set by an "MC" command.

### (3) SPOT MEASUREMENT CONTROL GROUP

The following program codes are used to make spot measurements.



Table 3-4. Remote Program Codes and Parameter Settings (sheet 5 of 13)

**\* SMU and VS Voltage Output (DV)**

Enables an SMU and VS, and outputs the voltage specified.

Syntax: DV Channel Number [,num-exp, value1 [,value2] ]

Channel Number: SMU number (2 to 4), VS number (VS1 or VS2 corresponds to 5 or 6 respectively)

When only a channel number is specified, the SMU is set to NOT USE and the measurement is disabled just as if "MC#,0" had been sent, and the VS is set to ZERO OUTPUT.

num-exp: 0: auto-ranging  
 1: 20 V range (100mA max)  
 2: 40 V range (50mA max)  
 3: 100V range (20mA max)  
 4-9: previous range setting

When 4-9 is specified as an SMU set to NOT USE or to current source mode, a PROG ERROR SRQ is generated. When 5 or 6 is specified for the Channel Number, this parameter is ignored because a VS has a range of only 20V.

value1: source voltage value in [V]

The source voltage value must be within the range specified. The resolution of value1 depends on the range specified by the num-exp.

value2: current compliance value (optional) in [A]

When this parameter is omitted, the previous current compliance setting remains in effect. When a DV command without this parameter is sent to a NOT USE SMU or to an SMU set to a current source mode, a PROG ERROR SRQ is generated. When the channel number is set to 5 or 6, this parameter is ignored because a VS has no user definable current compliance function. The maximum output current depends on the range specified by the num-exp. The current compliance resolution depends on the current range being used.

**\* VS Voltage Output (DS)**

Enables voltage source VS to output the specified voltage.

Syntax: DS Channel Number [, value]

Channel Number: VS number (1 or 2)

When only the channel number is sent, the VS is set to ZERO OUTPUT.

value: source voltage value in [V]

Value must not exceed  $\pm 20V$ .

## OPERATION

Table 3-4. Remote Program Codes and Parameter Settings (sheet 6 of 13)

### \* SMU Current Output (DI)

Enables the SMU to output the specified current.

Syntax: DI Channel Number [, num-exp, value1 [,value2 ]]

Channel Number: SMU number (1 to 4).

When only the channel number operand is specified, the SMU is set to NOT USE and the measurement is disabled just as if "MC#,0" has been sent.

num-exp:   0: Auto-ranging  
            1: 1nA or higher (same as auto-ranging)  
            2: 10nA or higher  
            3: 100nA or higher  
            4: 1 $\mu$ A or higher  
            5: 10 $\mu$ A or higher  
            6: 100 $\mu$ A or higher  
            7: 1mA or higher  
            8: 10mA or higher  
            9: 100mA

When the num-exp is 1 to 8 inclusive, the SMU is set to the limited auto-ranging mode. When value1 exceeds the specified range the SMU up-ranges to the appropriate range. The value cannot exceed  $\pm 100$ mA on any range.

value1: source current value in [A]

The Resolution of value1 depends on the output range in use.

value2: voltage compliance value (optional) in [V]

When this parameter is omitted, the previous voltage compliance setting remains in effect. When a "DI" command without this parameter is sent to a NOT USE SMU or to an SMU that set to the voltage source mode, a PRG ERROR SRQ is displayed. The maximum output voltage depends on the range specified by the num-exp. The voltage compliance resolution depends on the voltage range in use.

### \* Zero Output (DZ)

Sets any SMU and VS to ZERO OUTPUT.

Syntax: DZ Channel Number

Channel Number:   0: all channels  
                  1-4: SMU 1-4  
                  5-6: VS1, VS2

When this command is sent, the range setting and the current compliance value for the SMU are changed to auto-ranging and 10 $\mu$ A.

Table 3-4. Remote Program Codes and Parameter Settings (sheet 7 of 13)

**\* Trigger Mode (TM)**

Selects internal or external trigger.

Syntax: TM num-exp

num-exp: @0: External  
1: Internal

Internal trigger works as if an "XE" command had been sent in an 0.3 second interval.

This command is valid only for SMUs or VMs assigned to measure by "MC" command.

**\* Trigger (XE)**

Triggers a multi-channel measurement. The voltage source mode SMU measures current and the current source mode SMU measures voltage.

Syntax: XE

Only SMUs and VMs assigned to measure by an "MC" command can perform a measurement

**\* Trigger V Measurement (TV)**

Triggers a single-channel voltage measurement.

Syntax: TV Channel Number

Channel Number: SMU number (1 to 4), VM number (VM1 or VM2 corresponds to 5 or 6 respectively).

**\* Trigger I Measurement (TI)**

Triggers a single-channel current measurement.

Syntax: TI Channel Number

Channel Number: SMU number (1 to 4)

**(4) SWEEP MEASUREMENT CONTROL GROUP**

The 4141B can sweep the output of two channels simultaneously. One channel is called the "primary sweep" channel and the other is called the "Secondary sweep" channel. The sweep mode (linear or log), source mode (I or V), and the number of steps must be the same. Start, stop, and compliance values however may differ. For the following the program codes, the primary sweep parameters first used must be specified using a "WV" or "WI" command and the secondary sweep parameters using a "WP" command.

## OPERATION

Table 3-4. Remote Program Codes and Parameter Settings (sheet 8 of 13)

### \* Voltage Sweep Setup (WV)

Sets the primary sweep channel and sweep parameters for a voltage sweep.

Syntax: WV Channel Number [,num-exp1, num-exp2, value1, value2, value3  
[,value4]]

Channel Number: SMU number (1 through 4), VS number (VS1 or VS2 corresponds to 5 or 6 respectively).

When only the channel number operand is sent, the previous primary sweep parameter settings are used, that is, only the primary channel changes. When no valid voltage sweep parameter exists, a PROG ERROR SRQ is generated.

num-exp1: 1: Linear sweep  
2: Log sweep

num-exp2: 0: Auto-ranging  
1: 20V range  
2: 40V range  
3: 100V range

When the channel number is 5 or 6, this parameter is ignored because the VS is automatically set to the 20V range.

value1: sweep start voltage in [V]  
value2: sweep stop voltage in [V]

When the channel number is from 1 to 4, value1 must be within the range specified by num-exp2. If the channel number is 5 or 6, value1 must not exceed  $\pm 20V$ .

value3: sweep step value

When num-exp1 is 1, the step value is specified in [V]

When num-exp1 is 2, the step value must be specified in [dB] up to 20dB with a resolution of 0.2dB, and the signs of value1 and value2 must be the same. The maximum number of steps is 1021. Therefore, 4141B can store 1021 data points for each measurement channel in the output data buffer.

value4: current compliance value (optional) in [A]

When this parameter is omitted, the previous current compliance settings are used. When a WV command without the current compliance parameter is sent to the NOT USE SMU or to the current source mode SMU, a PROG ERROR SRQ is generated. The maximum output power is calculated using value1 and value2. When the output power exceeds 2 watts, a PROG ERROR SRQ is generated and the sweep is disabled. When the channel number is 5 or 6, this parameter is ignored because a VS has no user definable current compliance function.

Table 3-4. Remote Program Codes and Parameter Settings (sheet 9 of 13)

## Note

The "WV" command clears all secondary sweep parameters. Therefore this command must precede the secondary sweep declaration.

## Note

The actual stop voltage, equal to the start voltage value plus the accumulated step values, may exceed value2 because of rounding error and the instrument's finite measurement resolution.

## \* Current Sweep Setup (WI)

Sets the primary sweep channel and sweep parameters for the current sweep.

Syntax: WI Channel Number [, num-exp1, num-exp2, value1, value2, value3 [, value4]]

Channel Number: SMU number (1 to 4)

When only the channel number operand is sent, the previous primary settings are used and only the primary sweep channel is changed. When no valid current sweep parameters exist, a PROG ERROR SRQ is generated.

num-exp1: 1: Linear sweep  
2: Log sweep

num-exp2: 0: Auto-ranging  
1: 1nA or higher (same as auto-range)  
2: 10nA or higher  
3: 100nA or higher  
4: 1µA or higher  
5: 10µA or higher  
6: 100µA or higher  
7: 1mA or higher  
8: 10mA or higher  
9: 100mA

When num-exp1 is 1 (linear sweep), the auto-ranging function selects the optimum range for the entire sweep.

When num-exp1 is 2 (log sweep), the instrument will up-range or down-range as necessary.

value1: sweep start current in [A]

value2: sweep stop current in [A]

value3: sweep step value

## OPERATION

Table 3-4. Remote Program Codes and Parameter Settings (sheet 10 of 13)

When num-exp1 is 1, the step value is in [A]

When num-exp1 is 2, the step value is in [dB], up to 20dB with a resolution of 0.2dB resolution.

The maximum number of steps is 1021. The 4141B will store the data for each point in the output data buffer.

value4: voltage compliance value (optional) in [V]

When this parameter is omitted, the previous voltage setting will be used. When the "WI" command is sent to a NOT USE SMU, or to an SMU set as a voltage source without the voltage compliance operand, a PROG ERROR SRQ is generated.

The maximum output power is calculated using value1 and value2. When the output power exceeds 2 watts, a PROG ERROR SRQ is generated and the sweep is disabled.

### Note

The "WI" command clears all secondary sweep parameters. Therefore, this command must precede the secondary sweep declaration.

### Note

The actual stop current, equal to the start current plus the accumulated step values, may exceed value2 because of rounding errors and finite resolution.

### \* Secondary Sweep Setup (WP)

Sets up the sweep parameters for a secondary sweep. Secondary sweep channel must differ from primary sweep channel specified by the "WV" or "WI" command. When only the Channel Number operand is sent, the previous secondary sweep parameter settings are used, only secondary sweep channel changes. When no valid secondary sweep parameters exist, a PROG ERROR SRQ is generated.

Syntax: WP Channel Number [, num\_exp, value1, value2 [,value3] ]

Table 3-4. Remote Program Codes and Parameter Settings (sheet 11 of 13)

**Case 1** Primary sweep channel is specified by "WV" command (voltage sweep).

Channel Number: SMU number (1 to 4), VS number (VS1 or VS2 corresponds to 5 or 6 respectively). When 0 is specified, the secondary sweep is disabled.

num\_exp: 0: Auto-ranging  
 1: 20V range  
 2: 40V range  
 3: 100V range

The auto-ranging function selects the optimum range for the entire sweep.

value1: sweep start voltage in [V]

value2: sweep stop voltage in [V]

value3: current compliance value (optional) in [A]

When the Channel Number is 5 or 6, this parameter is ignored because VS has no user definable current compliance function.

**Case 2** Primary sweep channel is specified by the "WI" command (current sweep).

Channel Number: SMU number (1 to 4). If 0 is specified, the secondary sweep will be disabled.

num\_exp: 0: Auto-ranging  
 1: 1nA or higher  
 2: 10nA or higher  
 3: 100nA or higher  
 4: 1μA or higher  
 5: 10μA or higher  
 6: 100μA or higher  
 7: 1mA or higher  
 8: 10mA or higher  
 9: 100mA or higher

When num\_exp is 1 (linear sweep), the auto-ranging function selects the optimum range for the sweep. If num\_exp is 2 (log sweep), however, the range changes as necessary.

value1: sweep start current in [A]

value2: sweep stop current in [A]

value3: voltage compliance value (optional) in [V]

## OPERATION

Table 3-4. Remote Program Codes and Parameter Settings (sheet 12 of 13)

### Note

The sweep mode (linear/log), source mode (I/V) and the number of steps of the secondary sweep must be the same as those of the primary sweep. The step value is calculated from value1, value2, and the number of steps. If the log sweep mode is specified, the sign of value1 and value2 must be the same. The actual step value is equal to the start value plus the accumulated step values, and may exceed value2 because of rounding errors and the instruments finite measurement resolution.

### Note

If the value3 parameter is omitted, the previous current/voltage compliance settings will be used, and the SMU specified by the channel number will be set to voltage/current source mode. If a "WP" command without this parameter is sent to a NOT USE SMU or an SMU set to current/voltage source mode, a PROG ERROR SRQ will be generated.

### Note

The maximum output power is calculated using value1 and value2. If the output power exceeds 2 watts, A PROG ERROR SRQ will be generated and the secondary sweep will be disabled.

#### \* Sweep Point Output (WN)

Returns number of sweep points data available for output.

Syntax: WN

#### \* Hold Time (WH)

Sets sweep hold time.

Syntax: WH value

Value: The maximum hold time is 655.35 [sec] with a resolution of 0.01 [sec], and the sign is ignored.

#### \* Step Delay Time (WT)

Sets step delay time.

Syntax: WT value

value: The maximum step delay time is 655.35 [sec] with a resolution of 0.01sec, and the sign is ignored.



Table 3-4. Remote Program Codes and Parameter Settings (sheet 13 of 13)

## Note

If the hold/step delay time exceeds 655.35 seconds, a PROG ERROR SRQ will be generated. The Hold/Step Delay time is initialized to zero (minimum) when the power is turned on and when the 4141B receives a Device Clear command.

**\* Sweep Start (WS)**

Starts sweep measurement and sets output data formula

num\_exp: 0: Sweep source data not returned  
 1: Primary sweep source data returned  
 2: Secondary sweep source data returned

A valid sweep parameter set must be set before entering the "WS" command.

**\* Sweep Abort (WB)**

Aborts the sweep measurement.

Syntax: WB

Once a sweep is aborted using this command, all outputs are disabled as if the sweep had finished normally.

**[ PROGRAMMING ERROR ]**

The 4141B generates a PROG ERROR SRQ to inform the controller that the 4141B cannot execute commands because of a syntax error in the operand, or that the 4141B has received an illegal program code.

When a PROG ERROR SRQ is generated, the PROG ERROR and RQS bits of the status byte are set and:

1. The SMU and VS settings, measurement range settings, measurement channel assignments, and the sweep parameter settings are not affected.
2. The sweep measurement is not affected while in progress, and can be continued.
3. The HP-IB input buffer is cleared of all commands.
4. The Sweep data buffer and HP-IB output buffer are not affected.

## OPERATION

### 3-26. DATA OUTPUT

The 4141B outputs measurement and status data to external devices via HP-IB using the ASCII (American Standard Code for Information Interchange) data format or the Binary data format. The self-test result and Device ID can be output. The output format appears in Table 3-5.

Table 3-5. Data Output Format (sheet 1 of 4)

<p><b>SELF TEST Result</b></p> <p>When the 4141B receives a "TR" (Test Result) command, the 4141B prepares to output the previous SELF TEST results.</p> <p><b>Format:</b></p> <p>S1 status S2 status S3 status S4 status (CR)(LF)</p> <p>S1 to S4 correspond to SMU 1 to 4, respectively.</p> <p><b>Status:</b></p> <ul style="list-style-type: none"><li>0: No error</li><li>1: V offset error</li><li>2: I offset error</li><li>3: I leak error</li><li>4: V range error</li><li>5: I range error</li><li>6: I-in offset error</li><li>7: Loop change detector error</li><li>9: Communication error</li></ul> <p><b>Device ID</b></p> <p>When the 4141B receives a remote program code "ID" (Identification), it outputs an identification code.</p> <p><b>Format:</b></p> <p>ID HP 4141B REV. Revision code (CR)(LF)</p> <p><b>Revision code:</b> A 3-character revision number for identifying the 4141B's software.</p>
---

Table 3-5. Data Output Format (sheet 2 of 4)

## Measurement data and Sweep source data Format

## (1) ASCII Data Format

Definition: Data= <status><channel><mode><value>

<status>    N: Normal measurement data.  
               T: Another (not assigned to measure) channel has reached compliance.  
               C: This channel has reached compliance.  
               X: This channel is oscillating.  
               V: AD converter is saturated in voltage measurement. The <value> is +149.99E+00 or -149.99E+00.  
               D: SMU shutdown (SMU will not output during a sweep).  
               W: Sweep source data.  
               E: Last sweep source data.

Priority --- E > W > D > V > X > C > T > N

<channel>    A: SMU 1  
               B: SMU 2  
               C: SMU 3  
               D: SMU 4  
               E: VS1 OR VM1  
               F: VS2 OR VM2  
               G: SMU shutdown

<mode>        I: Current data  
               V: Voltage data

<value>        5 digit point decimal number in engineering format. When <status> is D, <value> is meaningless.

              sn.nnnnEsnn  
               snn.nnnEsnn  
               snnn.nnEsnn

s: sign + or -  
 n: digit 0 → 9  
 .: decimal point  
 E: exponent sign

(1-1). Single channel measurement (response to "TV" and "TI")

Syntax:        <data><CR><LF>

(1-2). Multichannel measurement (response to "XE" command, Internal trigger and Device trigger).

Syntax:        <data>[,<data>[.....]]<CR><LF>

The number of <data> is specified with the "MC" command. <data> for SMU1 is first and <data> for VM2 is last.

**OPERATION**

Table 3-5. Data Output Format (sheet 3 of 4)

(1-3). Sweep measurement

Syntax: <block>[,<block>[.....]]<CR><LF>

<block>=[<data>[,<data>.....] ]

The amount of data is specified with the "MC" and "WS" commands. The <data> for SMU1 is output first and the <data> for VM2 is next to last. The last <data> is the sweep source value when it has been specified. The number of <block> is equal to the number of steps reported by the "WN" command, unless the sweep is aborted by a "WB" command or by SMU shutdown.

(2) Binary Data Format

Definition: b\_data=<byte1><byte2><byte3><byte4>

<byte1>: status

bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
------	------	------	------	------	------	------	------

bit2, bit1, bit0: channel number

- 000 011: SMU 1 to 4
- 100 101: VM1 and VM2
- 110: Source value
- 111: SMU shut down

- bit3 1: ADC saturation
- bit4 1: SMU oscillation
- bit5 1: Another (not assigned to measure) channel has reached compliance
- bit6 1: Channel has reached compliance
- bit7 0: Voltage data
- 1: Current data

<byte2>: range

<byte3>, <byte4>: 16 bits signed integer ( 2's complement)

voltage data --- value = {<byte2>}×{<byte3><byte4>}/20000

current data --- value = (10 {-<byte2>})×{<byte3><byte4>}/20000

(2-1) Single channel measurement (response to "TV" and "TI")

Syntax: <b\_data>

Last byte returned with an EOI (End Or Identify)

Table 3-5. Data Output Format (sheet 4 of 4)

(2-2) Multichannel measurement (response to "XE" command, Internal trigger, and Device trigger)

Syntax: <b\_data>[ <b\_data>[.....] ]

The amount of <b\_data> is specified with "MC" command. The <b\_data> of SMU1 is output first and the <b\_data> of VM2 is last. The last byte is returned with an EOI.

(2-3) Sweep measurement

Syntax: <b\_block>[<b\_block>[.....] ]

<b\_block>=[<b\_data>[ <b\_data>[.....] ] ]

The amount of <b\_data> is specified using the "MC" or "WS" command. The <b\_data> for SMU1 is output first and the <b\_data> for VM2 is next to last. The last <b\_data> is the sweep source data when it has been specified. The number of <b\_block> is equal to the number of steps reported with the "WN" command, unless the sweep is aborted by a "WB" command or by SMU shut-down. The last byte is returned with an EOI.

## OPERATION

### 3-27. INTERLOCK

The 4141B outputs voltages of up to  $\pm 100V$  with the output voltage appearing at the outer conductors of the SMU output terminals on the rear panel. To prevent potential shock hazards, the outer-conductors of the SMU output terminals should not be exposed when the 4141B is interconnected to other devices (e.g., wafer prober, or user-fabricated test fixture). The interconnection must be secured, use the INTERLOCK function! The output of the SMU is limited to  $\pm 42V$ , if the INTERLOCK terminal is not terminated.

### 3-28. DEVICE CLEAR

The 4141B control settings will return to the initial control settings when a Selected Device Clear or Group Device Clear is received. The 4141B's initial control settings are given in Table 3-6.

Table 3-6. Initial Control Settings

4141B Status	Equivalent Program Code
All SMUs turned off. VS1 and VS2 turned off. VM1 and VM2 set to auto-range Sweep aborted. Integration time set to SHORT. HP-IB data output format set to ASCII. HP-IB data buffer cleared.	CL
Internal Trigger set to OFF.	TMO
All monitor functions set to OFF>	RI1 - 4.0 RV5 - 6.0
Auto-calibration available.	CM1
Sweep parameter settings cleared. HP-IB Status byte cleared.	

### 3-29. DEVICE TRIGGER

When the 4141B receives a Device Trigger, Group Execute Trigger or the program code "XE", each specified channel performs a measurement.

### 3-30. SERVICE REQUEST STATUS BYTE

The make-up of the 4141B Status Byte and a brief description of each bit appear in Table 3-6. Bit 7, an SRQ (Request Service), makes the 4141B output an RQS signal whenever any other bit of the Status Byte is set. The RQS mask can be set to bit 0, 2 and 3, independently. Once masked, the RQS bit is not set even if bits 0, 2 and 3 are set.

Table 3-7. 4141B Status Byte (sheet 1 of 2)

Bit 7 (128)	Bit 6 (64)	Bit 5 (32)	Bit 4 (16)	Bit 3 (8)	Bit 2 (4)	Bit 1 (2)	Bit 0 (1)
SMU Shut Down	RQS	Self- Test Fail	Inter- lock Open	Set* Ready	END* Status	Prog. Error	Data* Ready

( ): Decimal Value  
\* : RQS Maskable

**Bit 0: Data Ready (Maskable)**  
Bit 0 is set when all measurement data is ready for output via HP-IB. It is reset when the data transfer starts or when the HP-IB data buffer is cleared.

**Bit 1: Program Error**  
Bit 1 is set when the 4141B receives an Erroneous remote program code or when the syntax is wrong. It is reset when the 4141B receives a Serial Poll or Device Clear.

**Bit 2: End Status (Maskable)**  
Bit 2 is set when a sweep measurement or SELF TEST is completed. It is reset when the next sweep measurement or SELF TEST starts, or when the 4141B receives a Serial Poll or Device Clear.

**Bit 3: Set Ready (Maskable)**  
Bit 3 is set when the voltage or current output are settled. It is reset when the output changes or when the 4141B receives a Serial Poll or Device Clear.

## OPERATION

Table 3-7. 4141B Status Byte (sheet 2 of 2)

<b>Bit 4:</b>	<b>Interlock Open</b>
	Bit 4 is set when the INTERLOCK terminal is not terminated during or at the start of a measurement in which the output voltage exceeds $\pm 42V$ . It is reset when the 4141B receives a Serial Poll, Device Clear or the remote program code "CL."
<b>Bit 5:</b>	<b>Self-test Fail</b>
	Bit 5 is set when the Self-Test fails in the REMOTE mode. It is reset when the Self-Test is performed again and the result passes or when the 4141B receives a Serial Poll or Device Clear.
<b>Bit 6:</b>	<b>RQS</b>
	Bit 6 is set whenever any other nonmasked bit is set. It is reset when the 4141B receives a Serial Poll.
<b>Bit 7:</b>	<b>SMU Shut Down</b>
	Bit 7 is set when the SMU output shuts down by a command from the Instrument to prevent damage to the SMU or the SMU output resets (NOT USE) because of a momentary power loss.



### 3-31. SAMPLE MEASUREMENT AND PROGRAMMING

Some examples of basic semiconductor measurements using the 4141B with an HP-IB controller are shown in Figures 3-19 through 3-24. The DUTs for the sample measurements include bipolar transistors and MOSFETs. Measurement programs are given for the HP 9000 Series 200 Model 236 Computer using the BASIC 3.0 Language System. To use these sample programs, the BIN (Binary) Files in Table 3-8 must be loaded. Specific information for HP-IB programming with the computer is provided in the Series 200 BASIC programming manual. See Figure 3-18 for measurement setup procedures.

Table 3-8. Binary Files Required for Programming

	BASIC 3.0 Drivers Disc	BASIC 3.0 Language Extension Disc
File Name	HP-IB	IO, MAT GRAPH, ERR

Note

The equipment required to run these sample programs includes an HP 9000 Series 200 Model 216S, 236A/S, 236C/CS Desktop Computer or an HP 9000 Series 300 Technical Workstation with HP-IB Interface (select code 7).

#### MEASUREMENT SETUP

**PROCEDURE:**

The following explains how to use the Interconnect Cable Assembly.

1. Turn off the 4141B and the HP-IB Controller.
2. Connect the 4141B to the HP-IB Controller using an HP-IB Cable and connect your user-fabricated fixture using the Interconnect Cable Assembly and Connection Plate as shown below. To test packaged devices, connect the 4141B to the 16058A Test Fixture using the 16059A Adaptor.




Figure 3-18. Measurement Setup (sheet 1 of 2)

## OPERATION

3. Set 4141B HP-IB Address Switch on the rear panel to 23. See the figure below.



4. Turn the 4141B and HP-IB controller on.
5. Load the BASIC 3.0 Language System and the required Binary Files.

### Connecting DUTs

Use Interconnect Cable Assembly (PN 04085-61651) and Connector Plate (PN 04141-60001) for interconnection with the user-fabricated fixture, and use BNC Cable (PN 04145-61630) for the VM and VS if necessary. Avoid using triaxial cables which have the outer-conductors exposed. The outer-conductor of each SMU is tied directly to the guard terminal which can have up to  $\pm 100V$  on it.


### WARNING

**DANGEROUS VOLTAGE OF UP TO  $\pm 100V$  MAY BE PRESENT ON THE OUTER-CONDUCTORS OF THE SMU OUTPUT CONNECTORS.**

- 1) **DO NOT TOUCH THE OUTER-CONDUCTORS DURING MEASUREMENT.**
- 2) **DO NOT USE A CABLE WHICH DOES NOT GO THROUGH ON THE INTERCONNECT CABLE ASSEMBLY AND THE CONNECTOR PLATE**

Figures (1) and (2) below show some connection examples.

#### (1) Bipolar Transistor



#### (2) MOSFET





Figure 3-18. Measurement Setup (sheet 2 of 2)

**Sample Program 1 Description:**

This is an example of a Breakdown Voltage ( $BV_{ceo}$ ) measurement on an npn bipolar transistor. DUT connections are shown on the left.  $BV_{ceo}$  is the collector-emitter voltage needed to cause a specified value of collector current when the base is open.

```

10  ! *** Bipolar Tr Breakdown Voltage (BVceo) Measurement ****
20  !
30  DIM A$(14)
40  Dc=723
50  OUTPUT Dc;"CL"
60  OUTPUT Dc;"IT;"
70  OUTPUT Dc;"BD0"
80  !
90  Smu=1
100 Force_ic=1.E-3
110 Comp=100
120 OUTPUT Dc;"DI";Smu;".8,";Force_ic,Comp
130 OUTPUT Dc;"TV";Smu.
140 OUTPUT Dc;"DZ1"
150 ENTER Dc;A$
160 PRINT "BVceo=";A$(4.14);"[V]"
170 END

```

$BV_{ceo}=+47.875E+00[V]$

The following comments explain Sample Program 1.


Line	Description
30	Defines the string variable, A\$, which is used to store the measurement data.
40	Defines the 4141B's device selector.
50	Initializes the 4141B.

Figure 3-19. Sample Program 1 (sheet 1 of 2)

## OPERATION

60	Sets the integration time to short.
70	Sets the data output format to ASCII.
90-120	Sets up SMU1's current output parameters.
130	Outputs a Trigger to start a V measurement by SMU1.
140	Sets SMU1's output to zero.
150	Enters the measurement data into the string variable, A\$.
160	Displays the result showing only the data value.

Figure 3-19. Sample Program 1 (sheet 2 of 2)

**Sample Program 2 Description:**

This program measures the Leakage Current ( $I_{dss}$ ) of an MOSFET. The DUT connection is shown at the left. The gate and substrate voltages are held constant and the source is grounded. The drain current is increased until the predetermined value of drain voltage is reached, this current is  $I_{dss}$ . The data is stored in the Binary Data Format.

```

10      ! *** MOSFET Leakage Current (Idss) Measurement ***
20      !
30      INTEGER A,B,C,Dc
40      REAL Id
50      Dc=723
60      OUTPUT Dc;"CL"
70      OUTPUT Dc;"IT1"
80      OUTPUT Dc;"BD1"
90      !
100     Vds=12.
110     Vgs=2.
120     Vsub=-2.
130     !
140     OUTPUT Dc;"DV1,1,";Vds:",1E-6"
150     OUTPUT Dc;"DV2,1,";Vgs:",1E-6"
160     OUTPUT Dc;"DV3,1,";Vsub:",1E-6"
170     OUTPUT Dc;"TI1"
180     OUTPUT Dc;"DZ0"
190     !
200     IMAGE #,B,B,W
210     ENTER Dc USING 200;A,B,C
220     Id=10^(-B)*C/20000
230     IMAGE 5A,MZ.4DE,4A
240     PRINT USING 230;"Idss=",Id," (A)"
250     END

```

$I_{dss} = 6.1300E-11$  (A)

The following comments explain Sample Program 2.

Line	Description
30-40	Defines the integers and the real variable Id.
50-70	Sets up the same conditions as in Sample 1.
80	Sets the output format to the Binary data format.
100-160	Sets up SMU1-SMU3's voltage output parameters

Figure 3-20. Sample Program 2 (sheet 1 of 2)

## OPERATION

170	Triggers a current measurement by SMU1.
180	Sets all SMUs to zero output.
200-210	Enters binary data (bytes) using the IMAGE function.
220	Converts the binary data type to the real data type (voltage data).
230-240	Displays the real variable Id.

Figure 3-20. Sample Program 2 (sheet 2 of 2)




Figure 3-21. Sample Program 3 (sheet 1 of 2)


## OPERATION

The following comments explain Sample Program 3.

Line	Description
40	Defines three string variables for data.
50-80	Sets up the same conditions as in Sample 1.
90	Sets the data output format to ASCII.
110-160	Sets up SMU1-4's voltage output parameters.
170	Assigns three channels for measurements.
180	Sets up the measurement channels's ranges.
190	Triggers a multichannel measurement.
200	Sets all SMUs to zero output.
220-250	Enters ASCII data and prints it on CRT.

Figure 3-21. Sample Program 3 (sheet 2 of 2)



**Sample Program 4 Description:**

This program measures bipolar transistor hFE-IC characteristics using the sweep function. DUT connection is shown on the left. The base current is varied while holding the Collector-Emitter voltage constant, and the base current  $I_b$  which results in a collector current of 10mA is used to calculate hFE-IC.

```

10  ! *** Bipolar Tr Hfe-Ic Measurement using Sweep Function ***
20  !
30  OPTION BASE 1
40  DIM A$(4830)
50  REAL Ic,Ib,Hfe
60  INTEGER Dc,Status_byte,Data_ready
70  !
80  Dc=723
90  OUTPUT Dc;"CL"
100 OUTPUT Dc;"IT1"
110 OUTPUT Dc;"BD0"
120  !
130 OUTPUT Dc;"DV1,1,5,0.01"           !search Hfe at Ic=10mA
140 OUTPUT Dc;"WI2,2,1,1E-9,100E-3,1.20"
150 OUTPUT Dc;"RI1,8"
160 OUTPUT Dc;"MC1,1"
170  !
180 OUTPUT Dc;"WS1"
190  !
200 OUTPUT Dc;"SD1"
210 ON INTR 7,2 GDSUB Service
220 ENABLE INTR 7:2
230 LOOP
240 EXIT IF Data_ready=1
250 END LOOP

```

Figure 3-22. Sample Program 4 (sheet 1 of 3)

## OPERATION

```
260 !
270 ENTER Dc;A$
280 I=0
290 LOOP
300 I=I+1
310 EXIT IF A$[((2*I-1)-1)*15+1;1]="C"      I reached Compliance
320 END LOOP
330 Ic=VAL(A$[((2*I-1)-1)*15+4,15*(2*I-1)-1])
340 Ib=VAL(A$[(2*I-1)*15+4,15*2*i-1])
350 Hfe=Ic/Ib
360 PRINT "Hfe=";Hfe;"[Ic=10mA]"
370 STOP
380 !
390 Service: !
400 Status_byte=SPOLL(Dc)
410 IF BIT(Status_byte,0)=1 THEN
420 Data_ready=1
430 END IF
440 IF BIT(Status_byte,4)=1 THEN
450 PRINT "!!!!!! NOT INTERLOCKED !!!!!!"
460 BEEP
470 STOP
480 END IF
490 ENABLE INTR 7;2
500 RETURN
510 END
```

Hfe= 153.615384615 [Ic=10mA]


Figure 3-22. Sample Program 4 (sheet 2 of 3)

The following comments explain Sample Program 4.

Line	Description
30-60	Defines the variables.
80-100	Sets up the same conditions as in Sample 1.
110	Sets the data output format to ASCII.
130	Sets up SMU1's voltage output parameters.
140	Sets up SMU2's sweep parameters for a current sweep.
150	Sets the current measurement range to 10 mA or higher.
160	Sets up measurement channel.
180	Starts a sweep and sets source data returned.
200	Sets the "DATA READY" bit of the HP-IB status byte to enable SRQ generation.
210-250	Sets the priority of HP-IB interrupt to continue
270	Enters all string variables.
280-360	Searches for a collector current of 10mA using the compliance function and calculates the hFE.
390-500	This is the execution path when the measurement data is ready and the interlock function is not set.

Figure 3-22. Sample Program 4 (sheet 3 of 3)

## OPERATION



### Sample Program 5 Description:

This program is an example of the high speed measurement of the bipolar transistor static collector characteristics using the sweep function. It is effective for minimizing the range changes in high speed measurements. Connection to the DUT is shown below. To get the desired characteristics, the collector is stimulated while the base current is held constant. The source base current then changes as a second variable.

```
10  ! *** Bipolar Tr Ic-Vce Measurement using Sweep Function ***
20  !
30  OPTION BASE 1
40  INTEGER Dc,Var2
50  REAL K
60  DIM A$(3)[1515]
70  !
80  Dc=723
90  OUTPUT Dc;"CL"
100 OUTPUT Dc;"IT1"
110 OUTPUT Dc;"BD0"
120  !
130 Start=0
140 Stop=5
150 Step=.05
160 Compliance=.001
170  !
180 FOR Var2=1 TO 3
190   K=Var2*1.0E-6
200   OUTPUT Dc;"DI2,5,";K;",10"
210   OUTPUT Dc;"WV1,1,1,";Start;",,";Stop;",";Step;",";Compliance
220   OUTPUT Dc;"R11,7MC1,1WS0"
230  !
240   ENTER Dc;A$(Var2)
250  !
260 NEXT Var2
270  !
280 GOSUB Graphics
290 STOP
300  !
```

Figure 3-23. Sample Program 5 (sheet 1 of 4)

```

310 Graphics: !
320 ! GRAPHICS DISPLAY !
330 ! ! !
340 !
350 GINIT
360 GRAPHICS ON
370 PRINT CHR$(12)
380 Xmax=100*MAX(1,RATIO)
390 Ymax=100*MAX(1,1/RATIO)
400 LORG 6
410 MOVE Xmax/2,Ymax
420 LABEL "COLLECTOR CHARACTERISTICS"
430 DEG
440 LDIR 90
450 CSIZE 4.5
460 MOVE 0,Ymax/2
470 LABEL "Ic(A)"
480 LORG 4
490 LDIR 0
500 MOVE Xmax/2,0
510 LABEL "Vce(V)"
520 VIEWPORT .15*Xmax,.99*Xmax,.15*Ymax,.9*Ymax
530 FRAME
540 WINDOW 0,100,0,1.E-3
550 !
560 AXES 1,1.E-4,0,0,10,1,3
570 CLIP OFF

580 CSIZE 4.0,.5
590 LORG 6
600 FOR I=0 TO 100 STEP 10
610 MOVE I,0.
620 LABEL USING "#,K":I*.05
630 NEXT I
640 LORG 8
650 FOR I=0 TO 1.E-3 STEP 2.E-4
660 MOVE -.5,I
670 LABEL USING "#,D,DE":I
680 NEXT I
690 !
700 FOR Var2=1 TO 3
710 FOR X=1 TO 101
720 PLOT X-1,VAL(AS$(Var2)[15*(X-1)+4,15*X-1])
730 NEXT X
740 PENUP
750 NEXT Var2
760 RETURN
770 END

```

Figure 3-23. Sample Program 5 (sheet 2 of 4)

OPERATION





Figure 3-23. Sample Program 5 (sheet 3 of 4)

The following comments explain Sample Program 5.

Line	Description
30-60	Defines the variables.
80-100	Sets the same conditions as in Sample 1.
110	Sets the data output format to ASCII.
130-210	Sets up SMU1's voltage sweep parameters and sets up SMU2's current output parameters as a second sweep parameter.
220	Sets SMU1's current measurement range to the compliance range previously set with the "WV" command and start the sweep (sweep source data set to not returned).
240	Enter ASCII data.
280-760	Call the "Graphics" subroutine to draw data on the graphics screen.

Figure 3-23. Sample Program 5 (sheet 4 of 4)

## OPERATION



### Sample Program 6 Description:

This program is an example of searching for the MOSFET threshold voltage by repeated spot measurements. Connection to the DUT is shown below. This parameter can be obtained as a gate voltage when the drain current is  $1\mu\text{A}$ .

```

10      ! *** MOSFET Threshold Voltage (Vth) Measurement ***
20      !
30      INTEGER Dc,I,A
40      !
50      Dc=723
60      OUTPUT Dc;"CL"
70      OUTPUT Dc;"IT1"
80      OUTPUT Dc;"BD1"
90      !
100     Id_comp=1.E-6           ! search Vgs at Id=1uA
110     V_sub=-.4
120     OUTPUT Dc;"DV1,1,5,";Id_comp
130     OUTPUT Dc;"DV3,1,";V_sub;"0.1"
140     I=0
150     LOOP
160     OUTPUT Dc;"DV2,1,";I*.05;"1E-6"
170     OUTPUT Dc;"TI1"
180     !
190     IMAGE #,B
200     ENTER Dc USING 190;A
210     IF BIT(A,6)=1 THEN
220         PRINT "Vgs=";I*.05;"(V) [Id=1uA]"
230         STOP
240     END IF
250     I=I+1
260     END LOOP
270     END

```

Vgs= 2.4 (V) [Id=1uA]

Figure 3-24. Sample Program 6 (sheet 1 of 2)



The following comments explain Sample Program 6.

Line	Description
30	Defines the integer variables.
50-70	Sets same conditions as in Sample 1.
80	Sets the data output format to Binary.
100-130	Sets compliance of drain current to $1\mu\text{A}$ and forces voltage to the Drain and Substrate.
140-260	Starts to force voltage onto gate from 0 volt in 0.05V steps, and when drain current reaches the compliance level, $1\mu\text{A}$ , the program terminates and prints the gate voltage.

Figure 3-24. Sample Program 6 (2 of 2)



## SECTION 4

# PERFORMANCE VERIFICATION

### 4-1. INTRODUCTION

This section provides information on the HP 4141B's performance verification software (PV4141), for confirming the 4141B's specifications. This program is not a furnished accessory, but may be purchased separately. Included here is information on PV4141 contents, the test equipment required, and how to execute the performance verification program. Additionally, a brief description of each test and its operating theory, instructions on how to interpret test results, and how to remove and replace SMU boards is also included. For detailed 4141B service information (troubleshooting, repair, replaceable parts, etc.), refer to the 4062B Semiconductor Parametric Test System's Service Manual, PN 04062-90501.

#### Note

To ensure proper test results and instrument operation, allow the 4141B to warm-up and stabilize for at least 40 minutes before you execute any performance tests.

### 4-2. PV4141 CONTENTS

The 4141B's performance verification software comes on a 5-1/4" mini-flexible disc (PN 04141-65101) for use with HP 9000 Series 200 Model 236 computers, on a tape cartridge (PN 04141-90501) for use with HP 85 computers, or on a 3-1/2" micro-flexible disc (PN 04141-65301) for use with HP 9000 Series 300 Computers. The tests included in the performance verification software are listed below. PV4141 takes approximately 15 minutes to execute.

ALL TESTS:	Performs the GNDU, SMU, and VS/VM tests.
SMU TEST:	Tests current and voltage measurement and control (monitor) accuracy, and provides a Kelvin connection check for each Source/Monitor Unit (SMU).
VS/VM TEST:	Checks the specifications of the Voltage Sources (Vs) and Voltage Monitors (Vm).
GNDU TEST:	Checks the specifications of the 4141B's Ground Unit (GNDU).

## PERFORMANCE VERIFICATION

### 4-3. EQUIPMENT REQUIRED

The test equipment required during the performance verification program is listed here.

- HP 3456A: Digital Voltmeter (DVM)
- HP 16347A ~ E: SMU Calibrators 1 through 5
- PN 1251-2277 (or equivalent): Dual Banana Plug-to-BNC Adapter
- PN 1250-0781 (or equivalent): BNC-T Adapter
- HP 11170A : BNC-to-BNC Cable (30cm)
- One BNC-to-BNC cable (3m minimum)

For detailed information on the 16347A ~ E SMU Calibrators, refer to the Operating Note included with the calibrators.

### 4-4. PROGRAM EXECUTION

The following procedure explains how to execute the PV4141 program when using the HP 9000 Series 200 Model 236 computer. This program can be executed in a similar manner on HP 85 computers and on HP 9000 Series 300 Computers.

- (1) Insert the BASIC 3.0 Disc into the computer's right-hand disc drive and turn the computer on. The language system will load automatically and the following message will be displayed when BASIC is loaded.

BASIC Ready 3.0

Remove the disc.

- (2) Load the following BIN files from the BASIC 3.0 Drivers Disc and the Language Extensions Disc.

Basic 3.0 Drivers Disc	BASIC 3.0 Language Extensions Disc
HPIB	ERR IO

Remove the discs.

- (3) Insert the performance verification disc into the right-hand disc drive and load the PV4141 program.

## PERFORMANCE VERIFICATION

- (4) Press the 'RUN' key to start the program. The HP4141B Performance Test page will be displayed as shown below.

```
***** HP4141B PERFORMANCE TEST *****

This program verifies performance of the HP4141B. (HP-IB ADDRESS = 723)
Required test equipment is listed below.

HP16347A-E (SMU CALIBRATOR 1-5)
HP3456A (HP-IB ADDRESS = 710) (Digital Voltmeter)
HP P/N 1251-2277 or equivalent (Dual Banana - BNC)
BNC - BNC Cable (30 cm)
BNC - BNC Cable (3 m)
HP P/N 1250-0781 or equivalent (BNC T-Adapter : Dual-Female to Male)

Press START to begin.
```

START				EXIT
-------	--	--	--	------

- (5) Press the 'START' softkey and the following MENU will be displayed.

```
***** HP4141B PERFORMANCE TEST *****

Press desired softkey.

---- MENU ----

K5: ALL TESTS
K6: SMU TEST
K7: Vs/Vm TEST
K8: GNDU TEST
```

ALL TESTS	SMU TEST	Vs/Vm TEST	GNDU TEST	EXIT
-----------	----------	------------	-----------	------

Select the test(s) you wish to perform by pressing the corresponding softkey. Follow the displayed instructions.

## PERFORMANCE VERIFICATION

If you're using the HP 85 instead of a Series 200/300, there will be several differences in the PV4141 program. These differences are listed in the following table.

	Series 200/300	Model 85
Data Output	CRT display or external printer	Internal printer only
Operation	Softkey	Hardkey
Messages	Full messages and displays	Omitted or as short as possible

### 4-5. SMU TEST

The SMU accuracy test consists of:

- Kelvin Connection Check
- Voltage Control Test
- Voltage Measurement Test
- Current Control Test
- Current Measurement Test

The procedure for performing the SMU test is as follows.

- (1) From the MENU page, press the 'SMU TEST' softkey. The SMU ACCURACY TEST display, as shown below, will appear. From this display, you can select the SMU(s) you wish to test by pressing the corresponding softkey(s). For example, to test SMUs 1 and 3, press the 'SMU1' and 'SMU3' softkeys, then press the 'START' softkey.

**** SMU ACCURACY TEST ****				
Select the desired test with the softkeys. More than one test can be selected. When ready press START.				
ALL SMU	SMU1	SMU2	SMU3	SMU4
START				EXIT

- (2) Connect the 16347A Callibrator to the 4141B's rear panel I•V CHANNELS connectors. Next, connect the DVM to the GNDU-V connector of the 16347A with a BNC-to-BNC cable as shown in Figure 4-1. Press the 'NEXT' softkey to start the GNDU Test.

Note

Before the SMU Accuracy Test can be run, the 4141B must pass the GNDU Test. The GNDU Test, therefore, is included in the SMU Test. If the 4141B fails the GNDU Test, contact the nearest HP Service office.




Figure 4-1. SMU Accuracy Test Setup

## PERFORMANCE VERIFICATION

- (3) Upon completion of the GNDU Test, follow the displayed instructions. After each SMU is tested, test results will be output, as shown in the following example. If an SMU fails the accuracy tests, a failure message will be output at the end of the test. Should a failure occur, replace the faulty SMU board, as described later in this section.

\*\*\* SMU ACCURACY TEST \*\*\*

\* SMU1 \*

KELVIN CONNECTION OK

\*\* VOLTAGE CONTROL ACCURACY \*\*

RANGE	ERROR/ OFFSET	ACTUAL RESULTS	TEST LIMITS
			0+/-
20V	E 0	-.021% -.067mV	0.1% 10mV
40V	E 0	-.022% 1.282mV	0.1% 20mV
100V	E 0	-.022% .728mV	0.1% 50mV

\*\* VOLTAGE MEASUREMENT ACCURACY \*\*

RANGE	ERROR/ OFFSET	ACTUAL RESULTS	TEST LIMITS
			0+/-
20V	E 0	.011% .450mV	0.1% 10mV
40V	E 0	.010% -1.800mV	0.1% 20mV
100V	E 0	.007% .750mV	0.1% 50mV



**PERFORMANCE VERIFICATION**

**\*\* CURRENT MEASUREMENT ACCURACY \*\***

RANGE	ERROR/ OFFSET	ACTUAL RESULTS	TEST LIMITS 0+/-
1E-1A	E 0	-.030% -4.128E-06A	0.3% 1E-4A
1E-2A	E 0	.070% 4.338E-08A	0.3% 1E-5A
1E-3A	E 0	.064% -3.384E-08A	0.3% 1E-6A
1E-4A	E 0	.038% -4.615E-09A	0.3% 1E-7A
1E-5A	E 0	.030% -3.682E-10A	0.3% 1E-8A
1E-6A	E 0	-.023% -1.813E-11A	0.5% 1E-9A
1E-7A	E 0	-.034% -8.227E-12A	0.5% 1E-10A
1E-8A	E 0	.651% -7.221E-13A	1.0% 1.5E-11A
1E-9A	E 0	.641% -2.149E-14A	1.0% 6E-12A

**\*\* CURRENT CONTROL ACCURACY \*\***

RANGE	ERROR/ OFFSET	ACTUAL RESULTS	TEST LIMITS 0+/-
1E-1A	E 0	.013% 1.146E-05A	0.3% 1E-4A
1E-2A	E 0	-.092% 7.652E-07A	0.3% 1E-5A
1E-3A	E 0	-.086% 1.053E-07A	0.3% 1E-6A
1E-4A	E 0	-.060% 8.185E-09A	0.3% 1E-7A
1E-5A	E 0	-.052% 1.133E-09A	0.3% 1E-8A
1E-6A	E 0	.006% 3.119E-11A	0.5% 1E-9A
1E-7A	E 0	.025% 1.435E-11A	0.5% 1E-10A
1E-8A	E 0	-.668% 4.998E-13A	1.0% 1.5E-11A
1E-9A	E 0	-.656% 4.661E-14A	1.0% 6E-12A

## PERFORMANCE VERIFICATION

### Note

Be sure to connect each 16347A-E SMU Calibrator correctly. The PV4141 program will detect a bad connection, and will display a "### Check Connection ###" message if a bad connection exists. This detect and display function, however, will occur only the first time a Calibrator is connected.

### 4-6. VS/VM TEST

To test the accuracy of the 4141B's Voltage Sources and Monitors at each range, press the 'VS/VM TEST' softkey when the MENU page is displayed. Connect the DVM to the 4141B's rear panel Vs1 and Vm1 terminals as shown in Figure 4-2. Press the 'NEXT' softkey to start the test.

When Vs1 and Vm1 are tested, follow the displayed instructions. Connect the DVM to the Vs2 and Vm2 terminals as shown in Figure 4-2 for Vs1 and Vm1.




Figure 4-2. VS/VM Test Setup

## PERFORMANCE VERIFICATION

When the VS/VM Test is finished, test results will be output as shown below.

### \*\* V<sub>m</sub> ACCURACY \*\*

V <sub>m1</sub> RANGE	ERROR/ OFFSET	ACTUAL RESULTS	TEST LIMITS 0+/-
2V	E 0	-.112% -.010mV	0.5% 10mV
20V	E 0	-.019% -1.500mV	0.2% 10mV

V <sub>m2</sub> RANGE	ERROR/ OFFSET	ACTUAL RESULTS	TEST LIMITS 0+/-
2V	E 0	-.168% -.169mV	0.5% 10mV
20V	E 0	-.018% -1.500mV	0.2% 10mV

### \*\* V<sub>s</sub> ACCURACY \*\*

V <sub>s1</sub> RANGE	ERROR/ OFFSET	ACTUAL RESULTS	TEST LIMITS 0+/-
20V	E 0	.007% .210mV	0.5% 10mV

V <sub>s2</sub> RANGE	ERROR/ OFFSET	ACTUAL RESULTS	TEST LIMITS 0+/-
20V	E 0	.006% 1.069mV	0.5% 10mV

### Note

The 16347A through E SMU Calibrators are not needed for the VS/VM Test, but will not affect the test results if connected to the 4141B during the V<sub>s</sub>/V<sub>m</sub> test.

## PERFORMANCE VERIFICATION

### 4-7. GNDU TEST

To test the accuracy of the 4141B's Ground Unit, press the 'GNDU TEST' softkey on the MENU page and follow the displayed instructions. Connect the 16347A to the 4141B, and connect the DVM to the 16347A as shown in Figure 4-1. During this test, all four SMUs force  $\pm 400\text{mA}$  to the GNDU, and the DVM measures the offset value. The PV4141 program then calculates the offset value as if  $\pm 500\text{mA}$  were forced to the GNDU, and uses the measured offset value and this calculated value to obtain and output measurement results. An example of GNDU test results is as follows.

```
-- GNDU ACCURACY --  
ACTUAL_    TEST  
RESUL_    LIMIT  
- .18mV    0 +/- 2mV
```

### 4-8. SMU BOARD REPLACEMENT

If an error message indicating a faulty SMU, such as the one below, is displayed, the 4141B can be repaired by replacing the faulty SMU board.

S10S20S31S40

This error message indicates that SMU3 is faulty. If any of the error messages shown below are displayed, however, the 4141B cannot be repaired by replacing an SMU.

S19S29S39S49, S11S20S30S41, S10S21S31S40

If any of these errors occur, contact the nearest HP Service office.

Replace SMU boards as follows:

#### WARNING

**TO PREVENT SHOCK HAZARDS, UNPLUG THE 4141B BEFORE YOU REMOVE ANY COVERS. REFER ALL REPAIRS TO EXPERIENCED SERVICE PERSONNEL ONLY.**

- (1) Turn off and unplug the 4141B.
- (2) Remove the top cover.
- (3) Remove the shielding plate. The instrument's interior will be visible, as shown in Figure 4-3. SMU 1 is the one closest to the LINE ON/OFF switch, SMU 4 the farthest.
- (4) Remove the faulty SMU board by lifting the green and black tabs on the ends of the board. Pull the SMU board halfway out of its slot and disconnect the cables from the 10-pin connector and the two SMU connectors. Pull the board out.

## PERFORMANCE VERIFICATION

- (5) Insert the new board about half way, reconnect all cables, then insert the board the rest of the way. Make sure the board is properly seated in the connectors on the mother board.

To order new SMU boards, order PN 04141-66505 from your nearest HP Service office.




Figure 4-3. SMU Board Removal







Part No. 04141-90000

Printed in JAPAN