


# User Manual

## T3VNA Vector Network Analyzers



---

# Copyright and Declaration

## Copyright

Teledyne LeCroy. All Rights Reserved.

## Trademark Information

**Teledyne Test Tools** is the registered trademark of **Teledyne LeCroy**.

## Declaration

- ◆ **Teledyne LeCroy** products are protected by patent law worldwide
- ◆ **Teledyne LeCroy** reserves the right to modify or change parts of or all the specifications or pricing policies at company's sole decision.
- ◆ Information in this publication replaces all previously corresponding material.
- ◆ Any way of copying, extracting or translating the contents of this manual is not allowed without the permission of **Teledyne LeCroy**.
- ◆ **Teledyne LeCroy** will not be responsible for losses caused by either incidental or consequential in connection with the furnishing, use or performance of this manual as well as any information contained.

## Product Certification

**Teledyne LeCroy** guarantees this product conforms to the national and industrial standards in China as well as the ISO9001: 2008 standard and the ISO14001: 2004 standard. Other international standard conformance certification is in progress.

---

# Safety Information

## General Safety Summary

Read the following precautions carefully to avoid any personal injuries, or damage to the instrument or products connected to it. Use the instrument only as specified.

Use **only** the power cord **supplied** for the instrument.

**Ground the instrument.** The instrument is grounded through the ground conductor of the power cord. To avoid electric shock, always connect to grounded outlets. Make sure the instrument is grounded correctly before connecting its input or output terminals.

**Connect the signal wire correctly.** To avoid damage, observe input polarity and maximum voltage/current ratings at all times.

**Observe all terminal ratings** and signs on the instrument to avoid fire or electric shock. Before connecting to the instrument, read the manual to understand the input/output ratings.

**Do not operate with suspected failures.** If you suspect that the instrument is damaged, contact the Teledyne LeCroy service department immediately.

**Do not operate in wet/damp conditions.**

**Do not operate in an explosive atmosphere.**

**Keep the surface of the instrument clean and dry.**

**Avoid touching exposed circuits or wires.** Do not touch exposed contacts or components when the power is on.

**Do not operate without covers.** Do not operate the instrument with covers or panels removed.

**Use only the fuse specified for the instrument.**

**Use proper over voltage protection.**

**Use anti-static protection.** Operate in an anti-static protected area. Ground measurement cable conductors before connecting to the instrument to discharge any static electricity before connecting the cables to the instrument.

**Observe ventilation requirements.** Ensure good ventilation. Check the vent and fan regularly to prevent overheating.

---

## Safety Terms and Symbols

The following terms may appear on the instrument:

**DANGER:** Direct injury or hazard may occur.

**WARNING:** Potential injury or hazard may occur.

**CAUTION:** Potential damage to instrument/property may occur.

The following symbols may appear on the instrument:



**CAUTION**  
Risk of  
injury or  
damage.  
Refer to  
manual.



**WARNING**  
Risk of  
electric  
shock or  
burn



Earth  
Ground  
Terminal



Protective  
Conductor  
Terminal



Frame or  
Chassis  
Terminal



ON/  
Standby  
Power



Alternating  
Current

## Measuring Terminal Ratings

**RF Input:** 50  $\Omega$ , Max +30 dBm,  $\pm 50$  VDC

No rated measurement category per IEC/EN 61010-031:2015. Measuring terminals on this product are not intended to be connected directly to mains.

## Operating Environment

**Temperature:** 0 °C to 50 °C

**Relative Humidity:** 90% RH up to 30 °C; derates to 50% at 50°C.

**Altitude:**  $\leq 3000$  m

**Use indoors only.**

**Pollution Degree 2.** Use in an operating environment where normally only dry, non-conductive pollution occurs. Temporary conductivity caused by condensation should be expected.

---

## AC Power

**Input Voltage & Frequency:** 100-240 V at 50/60/400 Hz

**Automatic AC selection.**

**Power Consumption:** 35 W maximum

**Mains Supply Connector:** CAT II per IEC/EN 61010-1:2015, instrument intended to be supplied from the building wiring at utilization points (socket outlets and similar).

## Fuse Type

100 V / 110 V : 1.25A / 250 V ('T' rated)

220 V / 230 V : 1.25A / 250 V ('T' rated)

## 1 General Inspection

Please check the instrument according to the following steps.

### 1. Inspect the shipping container.

Keep the shipping container and packaging material until the contents of the shipment have been completely checked and the instrument has passed both electrical and mechanical tests. It is always good practice to save the shipping container and packaging for use when returning the power supply to Teledyne LeCroy for service or calibration.

The consigner or carrier will be responsible for damage to the instrument resulting from shipping. Teledyne LeCroy will not provide free maintenance or replacement in this instance.

### 2. Inspect the instrument.

If the instrument is found to be damaged, defective or fails in electrical or mechanical tests, please contact the Teledyne LeCroy service department immediately.

### 3. Check the accessories.

Please check that you have received the accessories: Calibration Kit, Utility Kit, Power Cord, USB cable. If the accessories are incomplete or damaged, please contact Teledyne LeCroy immediately.

---

## Care

Do not store or leave the instrument in direct sunshine for extended periods of time.

**Note:** To avoid damage to the instrument, please do not leave it in a corrosive atmosphere.

## Cleaning

Regularly perform the following steps to clean the instrument.


1. Disconnect the instrument from all power sources, then clean it with a soft, damp cloth.
2. Remove loose dust on the outside of the instrument with a soft cloth. When cleaning the LCD, take care to avoid scratching it.

**Note:** To avoid damage to the surface of the instrument, please do not use any corrosive liquid or chemical cleanser. Make sure that the instrument is completely dry before restarting it to avoid short circuit or personal injury.



## End-of-Life Handling

The instrument is marked with this symbol to indicate that it complies with the



applicable European Union requirements to Directives 2012/19/EU and 2013/56/EU on Waste Electrical and Electronic Equipment (WEEE) and Batteries.

The product is subject to disposal and recycling regulations that vary by country and region. Many countries prohibit the disposal of waste electronic equipment in standard waste receptacles. For more information about proper disposal and recycling of your Teledyne LeCroy product, please visit [teledynelecroy.com/recycle](http://teledynelecroy.com/recycle).

---

# Contents

<b>Copyright and Declaration</b> .....	II
<b>Safety Information</b> .....	III
<b>General Safety Summary</b> .....	III
<b>Safety Terms and Symbols</b> .....	IV
<b>Measurement Category</b> .....	V
<b>Working Environment</b> .....	VI
<b>Ventilation Requirement</b> .....	VII
<b>General Care and Cleaning</b> .....	VII
<b>Chapter 1 Quick Start</b> .....	2
1.1 General Inspection .....	3
1.2 Appearance and Dimension .....	3
1.3 Preparing for Use .....	4
1.3.1 Adjust the Supporting Legs .....	4
1.3.2 Connect to AC Power Supply .....	4
1.4 Front Panel .....	5
1.4.1 Front Panel Function Keys .....	5
1.4.2 Front Panel Key Backlight .....	7
1.4.3 Using the Numeric Keyboard .....	7
1.4.4 Front Panel Connectors .....	8
1.5 Rear Panel .....	10
1.6 User Interface .....	12
1.7 Firmware Operation .....	14
1.7.1 Check System Information .....	14
1.7.2 Load Option .....	14
1.7.3 Firmware Upgrade .....	14
1.8 Touch Operation .....	14
1.9 Remote Control .....	15
1.10 Using Built-in Help .....	15
1.11 Using the Security Lock .....	16
1.12 Mode .....	16
<b>Chapter 2 Spectrum Analyzer</b> .....	17
2.1 Basic Settings .....	18
2.1.1 Frequency .....	18
2.1.2 Span .....	23

2.1.3	Amplitude .....	24
2.1.4	Auto Tune .....	28
2.2	Sweep and Functions .....	30
2.2.1	BW .....	30
2.2.2	Trace .....	32
2.2.3	Detect .....	34
2.2.4	Sweep .....	35
2.2.5	Trigger .....	37
2.2.6	Limit .....	38
2.2.7	TG (Tracking Generator) .....	39
2.2.8	Demod .....	42
2.3	Marker .....	44
2.3.1	Marker .....	44
2.3.2	Marker -> .....	47
2.3.3	Marker Fn .....	48
2.3.4	Peak .....	50
2.4	Measurement .....	53
2.4.1	Meas .....	53
2.4.2	Meas setup .....	54
Chapter 3	Vector Network Analyzer .....	64
3.1	Basic Settings .....	65
3.1.1	Frequency .....	65
3.1.2	Span .....	66
3.1.3	Amplitude .....	67
3.2	Sweep and Functions .....	68
3.2.1	BW .....	68
3.2.2	Trace .....	68
3.2.3	Sweep .....	71
3.2.4	TG .....	72
3.3	Marker .....	72
3.3.1	Marker .....	72
3.3.2	Peak .....	75
3.4	Measurement .....	76
3.4.1	Stimulus .....	76
3.4.2	Meas .....	76
3.4.3	Format .....	76
3.4.4	Scale .....	77
3.4.5	Trace .....	77
3.4.6	Calibration .....	77
Chapter 4	Distance-To-Fault Mode .....	80
4.1	Measurement .....	80
4.1.1	Disp Mode .....	80
4.1.2	Start Distance .....	80
4.1.3	Stop Distance .....	80
4.1.4	Unit .....	81



---

4.1.5	Velocity Factor .....	81
4.1.6	Cable Atten.....	82
4.1.7	Window .....	82
4.1.8	Calibration .....	82
Chapter 5	Modulation Analyzer .....	84
5.1	Basic Settings .....	85
5.1.1	Frequency .....	85
5.2	Measurement .....	85
5.2.1	Digital Modulation Analysis .....	85
5.2.2	Analog Modulation Analysis .....	89
5.3	Sweep and Functions .....	90
5.3.1	Trigger .....	90
5.3.2	Sweep .....	91
Chapter 6	System Settings .....	92
6.1	System .....	92
6.1.1	Language .....	92
6.1.2	Power On/Preset .....	92
6.1.3	Interface .....	93
6.1.4	Calibration .....	94
6.1.5	System Info .....	94
6.1.6	Date and Time .....	95
6.1.7	Self Test.....	96
6.2	Display .....	96
6.2.1	Grid Brightness .....	96
6.2.2	Screenshot .....	96
6.2.3	Touch Settings.....	97
6.2.4	Power Saving .....	98
6.2.5	Annotation .....	98
6.2.6	Display Line .....	98
6.3	File .....	99
6.3.1	Browser .....	99
6.3.2	Open/Load .....	99
6.3.3	Back .....	99
6.3.4	View Type .....	99
6.3.5	Save Type .....	99
6.3.6	Save .....	100
6.3.7	Create Folder .....	100
6.3.8	Operate .....	100
6.4	Shortcut Key .....	101
6.4.1	Preset .....	101
6.4.2	Couple .....	109
6.4.3	Help .....	110
6.4.4	Save .....	110
Chapter 7	Programming Overview .....	111
7.1	Remotely Operating the Analyzer .....	111

---

7.1.1	USB: Connecting the Analyzer via the USB Device port .....	111
7.1.2	LAN: Connecting the Analyzer via the LAN port .....	111
7.2	Build Communication .....	113
7.2.1	Build Communication Using VISA.....	113
7.2.2	Build Communication Using Sockets/Telnet .....	115
7.3	Remote Control Capabilities .....	116
7.3.1	User-defined Programming .....	116
7.3.2	Send SCPI Commands via NI MAX .....	116
7.3.3	Easy Spectrum Software.....	118
7.3.1	Web Control .....	119
Chapter 8	Service and Support .....	120
8.1	Service Summary .....	120
8.2	Troubleshooting .....	120
8.3	Contact Us .....	122

---

# Chapter 1 Quick Start

This chapter guides users to quickly get familiar with the appearance, dimensions, front/rear panel and the user interface, as well as announcements during the first use of the analyzer.

Subjects in this chapter:

- ◆ General Inspection
- ◆ Appearance and Dimension
- ◆ Preparing for Use
- ◆ Front Panel
- ◆ Rear Panel
- ◆ User Interface
- ◆ Firmware Operation
- ◆ Touch Operation
- ◆ Remote Control
- ◆ Using Built-in Help
- ◆ Using the Security Lock
- ◆ Mode

---

## 1.1 General Inspection

### 1. Inspect the shipping container

Keep the damaged shipping container or cushioning material until the contents of the shipment have been completely checked and the instrument has passed both electrical and mechanical tests.

The consigner or carrier will be responsible for damages to the instrument resulting from shipment.

**Teledyne LeCroy** will not provide free maintenance or replacement.

### 2. Inspect the instrument

If the instrument is found to be damaged, defective or fails in electrical or mechanical tests, please contact the Teledyne LeCroy service department immediately.

### 3. Check the accessories

Please check that you have received the accessories: Calibration Kit, Utility Kit, Power Cord, USB cable.

If the accessories are incomplete or damaged, please contact Teledyne LeCroy immediately.

## 1.2 Appearance and Dimension




Figure 1-1 Front View




Figure 1-2 Top View

---

## 1.3 Preparing for Use

### 1.3.1 Adjust the Supporting Legs

Adjust the supporting legs properly to use them as stands to tilt the analyzer upwards for stable placement as well as easier operation and observation of the instrument display.




Figure 1-3 before adjusting




Figure 1-4 after adjusting

### 1.3.2 Connect to AC Power Supply

The vector network analyzer accepts 100-240V, 50/60Hz or 100-120V 400Hz AC power supply. Please use the provided power cord to connect the instrument to the power source as shown in the figure below. Before powering on, make sure the analyzer is protected by a fuse.




Figure 1-5 Power Cord Connection

## 1.4 Front Panel




Figure 1-6 the Front Panel

Table 1-1 Front Panel Description

NO.	Description	NO.	Description
1	User Graphical Interface, touch support	7	RF Input, VNA port 2
2	Menu Control Keys	8	TG Output, VNA port 1
3	Function Keys	9	3.5 mm Earphone interface
4	Knob	10	USB Host
5	Numeric / Letter Keyboard	11	Power Switch
6	Arrow Keys		

### 1.4.1 Front Panel Function Keys




Figure 1-7 Function Keys area

Table 1-2 Function keys description

Control Keys	Description
<b>Frequency</b>	Set the parameters of frequency, and Peak→CF, CF→Step.
<b>Span</b>	Set the parameters of span, and X-scale (Log-Linear) setup.
<b>Amplitude</b>	Set the parameters of amplitude, including Ref Level, Attenuator, Preamp, etc.; and Correction setup.
<b>Auto Tune</b>	Scan the full span rapidly and move the biggest signal to center freq, and automatically sets the optimal parameters according to the signal.
Setting Keys	Description
<b>BW</b>	Set the parameters of RBW and VBW, Average Type (Log power, Power, Voltage), and Filter Type (-3 dB Gauss\ -6 dB EMI).
<b>Trace</b>	Select Trace, Trace setup and Trace math.
<b>Sweep</b>	Set the parameters of sweep, and EMI QPD Dwell Time.
<b>Detect</b>	Select the detector type for each trace independently.
<b>Trigger</b>	Select triggers in Free Trigger, Video Trigger and External Trigger.
<b>Limit</b>	Set the Pass\Fail Limit.
<b>TG</b>	Set the parameters of tracking generator. Including TG Level, TG Level offset Normalization setup. The backlight LED is on when TG source is working.
<b>Demod</b>	Set the demodulation parameters of the AM and FM for audio listening.
Marker Keys	Description
<b>Marker</b>	Set the Markers and Marker Table.
<b>Marker-&gt;</b>	Set other system parameters on the basis of the current marker's value.
<b>Marker Fn</b>	Special functions of the marker such as noise marker, N dB bandwidth measurement and frequency counter.
<b>Peak</b>	Search for the peak signal, peak search configuration and peak table.
Meas Keys	Description
<b>Meas</b>	In spectrum analyzer mode, selects the Advanced Measurement function. In non-spectrum analyzer mode, select corresponding settings.
<b>Meas Setup</b>	Set the measurement parameters.
System Keys	Description
<b>System</b>	Set the system parameters.
<b>Mode</b>	Select the working modes.
<b>Display</b>	Set the display parameters.
<b>File</b>	Use the file system and files.
Shortcut Keys	Description
<b>Preset</b>	Sets the system to certain status.
<b>Couple</b>	Set the parameters of some functions between auto and manual.
<b>Help</b>	Turn on the built-in help.
<b>Save</b>	Save Shortcut Key.

---

## 1.4.2 Front Panel Key Backlight

The on/off state and the color of the backlights of some keys at the front panel indicate the working state of the analyzer. The states are as listed below.

### 1. Power Switch

- ◆ Flash on and off alternatively, in a “breathing” state: indicate the unit is in stand-by.
- ◆ Constant on: indicates the instrument is in normal operating state.

### 2. Mode

When the function is **Spectrum Analyzer**, the backlight turns off. When in other modes, the backlight turns on.

### 3. TG

When the **TG** source is on, the backlight of **TG** turns on and turns off when the function is off.

## 1.4.3 Using the Numeric Keyboard

The analyzer provides a numeric keyboard at the front panel. The numeric keyboard supports English uppercase/lowercase characters, numbers and common symbols (including decimal point, #, space and +/-) and are mainly used to edit file or folder names and set parameters.




Figure 1-8 Numeric Keyboards

### 1. +/-

In number input, set the sign of number; in file input, switch in number and letter.

### 2. 1 A/a

In number input, enter number 1; in file input, switch between uppercase and lowercase letter.

### 3. . #

In number input, enter a decimal point. In English input, enter special characters.

### 4. Back

In parameter editing, press this key to delete the character on the left of the cursor.



---

5. **Esc**

- ◆ During parameter editing process, press this key to clear the inputs in the active function area and exit parameter input.
- ◆ When the instrument is in remote mode, use this key to return to local mode.

6. **Enter**

In parameter editing, the system will complete the input and insert a default unit for the parameter.

## 1.4.4 Front Panel Connectors




Figure 1-9 Front Panel Connectors (1)

### 1. Power Switch

Power on / Power down the instrument

### 2. USB Host

- ◆ The analyzer can serve as a “**host**” device to connect external USB devices. This interface is available for USB storage devices, wireless or wired mouse and keyboard.
- ◆ Read and write functions for an external USB storage device or store the contents currently displayed on the screen in the USB storage device in .png or .jpg or .bmp format.

### 3. Earphone Jack

The analyzer can demodulate AM and FM signals. Insert a 3.5 mm earphone into to the jack to acquire the audio output of the demodulated signal. You can turn on or off the earphone output and adjust the volume via **Demod** -> **Volume**.



#### CAUTION

Protect your hearing. Please turn the volume down to zero before using the earphone. Gradually turn the volume up to a comfortable level after inserting the earphone.

---




Figure 1-10 Front Panel Connectors (2)

#### 4. TG SOURCE, VNA PORT 1

- ◆ The **TG SOURCE** can be connected to a device-under-test (DUT) through a cable with a male N-type male connector.
- ◆ In the VNA mode, this port is used as the single port of S11 and the output port of S21.



#### CAUTION

To avoid damaging to the tracking generator, the reverse DC voltage cannot exceed 50 V

---

#### 5. RF INPUT, VNA PORT 2

- ◆ The RF INPUT can be connected to the DUT through a cable with a male N-type connector
- ◆ In the VNA mode, this port is used as the input port for S21 measurements.



#### CAUTION

To avoid damaging to the instrument, the RF input signal must meet the following: The DC voltage component and the maximum continuous power of the AC (RF) signal component cannot exceed 50 V and +30 dBm respectively.

---

## 1.5 Rear Panel




Figure 1-11 Rear Panel

### 1. Handle

Pull up the handle vertically for easy carrying of the instrument. When you do not need the handle, press it down.

### 2. USB Device Interface

The analyzer can serve as a “slave” device to connect external USB devices. Through this interface, a PC can be connected to control the analyzer.

### 3. LAN Interface

Through this interface, the analyzer can be connected to your local network (LAN) for remote control.

### 4. REF IN 10 MHz

The analyzer can use the internal or an external reference source.

- ◆ When a 10 MHz external clock signal is received through the **[10 MHz IN]** connector, this signal is used as the external reference source and “**Ext Ref**” is displayed in the status bar of the user interface. When the external reference is lost or not connected, the instrument switches to its internal reference source automatically and “**Ext Ref**” on the screen disappears.
- ◆ The **[10 MHz IN]** and **[10 MHz OUT]** connectors are usually used to build synchronization among multiple instruments.

### 5. REF OUT 10 MHz

The analyzer can use the internal or an external reference source.

- 
- ◆ When an internal reference source is used, the **[10 MHz OUT]** connector can output a 10 MHz clock signal generated by the analyzer. This signal can be used to synchronize other instruments.
  - ◆ The **[10 MHz OUT]** and **[10 MHz IN]** connectors are usually used to build synchronization among multiple instruments.

## **6. Trigger in**

In external trigger mode, the analyzer will update the trace scan after the Trigger In connector receives an external trigger signal that meets the trigger input specifications.

## **7. Security Lock Hole**

If needed, you can use a security lock(purchased separately) to lock the analyzer to a desired location.

## **8. AC Power Supply**

The analyzer accepts 100-240V, 50/60 or 100-120VA 400Hz power supply. Please use the power cord provided as accessories to connect the instrument.

## **9. Fuse**

Before power on, make sure the analyzer is protected by the proper input fuse.

## 1.6 User Interface




Figure 1-12 User Interface

Table 1-3 User Interface labels

NO.	Name	Description
1	Screen information Area	Area around the waveform display shows additional information
2	Ref	Reference level
3	UNCAL	When the sweep time is less than the auto couple time, the measure result may have decreased accuracy, The display will indicate uncalibrated using the letters "UNCAL"
4	EXT REF	Valid Ext 10 MHz reference clock detected indicator
5	Att	Attenuator Value
6	Day and time	System time
7	Pass/Fail status	Limit Pass/Fail status
8	Marker	Current active marker
9	Trace	Active trace
10	Marker instruction	Current marker, touch to open a new marker
11	Marker x value	Unit: frequency, frequency delta or time
12	State indication	Auto Tune: Automatically sets the optimal parameters according to the characteristics of the signal. Currently showing 'Waiting for Trigger'
13	Marker y value	Amplitude value or amplitude delta value

14	USB storage device identification	The identification is displayed when a USB flash drive is inserted	
15	Main menu touch logo	Clicking this button will bring up the main menu	
16	Menu title	Function of the current menu.	
17	Menu items	Menu items of the current function	
18	Operation status	Local is local mode, Remote is remote mode, Upgrade means the instrument is upgrading	
19	Sweep progress indication	Indicates the currently scanned frequency position	
20	Stop frequency	Stop frequency value	
21	Sweep time	Time duration of a single sweep	
22	Center frequency	Center frequency value	
23	Span	Span value	
24	VBW	Video bandwidth	
25	Start frequency	The first frequency of a sweep	
26	RBW	Resolution bandwidth	
27	Manually instructions	When it appears, this parameter is not automatically coupled but manually configured	
28	Touch assistant	Click to open the commonly used functions for measurement, such as peak search. Touch Assist can be moved to any position on the screen and it can be turned off in the DISPLAY menu	
29	Trace A\B\C\D status	Trace type:	Detect type:
30		C&W: Clear Write	P-PK: Positive peak
31		MaxH: Max Hold	N-PK: Positive peak
32		MinH: Min Hold	Samp: Sample
		View: View	Norm: Normal
		AVG: Video average.	AVG: average
			Q-PK: Quasi-peak
33	Correction	Indicates that there is a user-configured amplitude correction table being mathematically applied to the displayed trace data	
34	AM or FM	AM or FM demodulation activated	
35	PA	Enable or disable the Preamplifier	
36	FFT	Sweep mode is FFT	
37	Single or Continue	Sweep mode single or continuous	
38	Average type	Log power\Power\Voltage power	
39	Trigger type	Free\Video\External trigger	
40	Ref offset	34 : Ref offset identification ; 35 : Ref offset value	
41	Scale/Div	Scale value	
42	Scale type	Logarithm or linearity	
43	Limit line	Limit Pass/Fail level	
44	Trigger level	Video trigger level	
45	Display line	Reference display line	

---

## 1.7 Firmware Operation

### 1.7.1 Check System Information

Users can get the system information by press **System**->"System Info", including

- ◆ Product Model, Serial and Host ID
- ◆ Software Version and hardware Version
- ◆ Option Information

### 1.7.2 Load Option

Refer to the procedures below to activate the options you have purchased.

1. Press **System**->"System Info"->"Load Option"
2. Enter the license key in the onscreen window. Press **Enter** to confirm your input and terminate the license key input. Or
3. Load the .lic file provided by pressing **File**->"Load" from internal memory or USB stick.

The option will be enabled after rebooting.

### 1.7.3 Firmware Upgrade

Follow this procedure to update the instrument firmware:

1. Download the firmware package from an official Teledyne LeCroy website.
  2. Extract and copy the .ADS file into the root directory of an USB stick.
  3. Plug the USB stick into the USB Host connector. Press **System**->"System Info"-> "Firmware Update"; find the .ADS file in USB stick.
  4. Press the "Load", the analyzer will perform the update process automatically.
- ◆ The upgrade process will take several minutes. When the upgrade is completed, the machine will reboot.
  - ◆ Any interruption during the update process will result in update failure and system data loss. This is **not covered under the warranty** and the user will bear repair costs and shipping.
  - ◆ Do not remove the USB storage device until the update is finished.

## 1.8 Touch Operation

The analyzer has a 10.1 inch multi-touch screen and supports various gesture operations. Including:

- ◆ Press or click on the upper-right-corner of the screen to enter the main menu;
- ◆ Swipe up and down or left and right in the waveform area to change the X-axis center coordinate or Y-axis reference level;

- ◆ Perform two-points scaling in the waveform area to change the X-axis span;
- ◆ Click on a screen parameter or menu for parameter selection or editing;
- ◆ Open and drag the marker;
- ◆ Use auxiliary shortcuts to perform common operations.

You can turn the touch screen function on and off via **Display**->'Touch Settings'.

## 1.9 Remote Control

The analyzer supports communication with computers via USB and LAN interfaces. By using these interfaces, in combination with programming languages and/or NI-VISA software, users can remotely control the analyzer based on a SCPI (Standard Commands for Programmable Instruments) compliant command set, LabView and IVI (Interchangeable Virtual Instrument), to interoperate with other programmable instruments.

You can also remote monitor and control the analyzer in Web Browser or Easy Spectrum.

For more details, refer to the 'Programming Guide' or contact your nearest Teledyne LeCroy office.

## 1.10 Using Built-in Help

The built-in help system provides information about every function key at the front panel and every menu soft key.

- ◆ Press **Help** and the embedded help would show up.
- ◆ Click on the items in the contents tree on the left to navigate to any topics interested.
- ◆ Click the green back or forward arrow to go back or forward to the contents just read.
- ◆ Click the close sign button in the top right corner or press the Esc front-panel key to quit the help system.




Figure 1-13 help information



---

## 1.11 Using the Security Lock

If needed, you can use the Kensington style security lock (not supplied) to lock the Vector Network Analyzer to a fixed location. The method is as follows, align the lock with the lock hole and plug it into the lock hole vertically, turn the key clockwise to lock the Vector Network Analyzer and then pull the key out.




Figure 1-14 Security Lock

## 1.12 Mode

The analyzer offers a variety of operating modes that can be purchased separately. They can be selected via the **Mode** key:

- ◆ Spectrum Analyzer
- ◆ Vector Network Analyzer
- ◆ Distance-To-Fault
- ◆ Modulation Analyzer

Front panel key menus may be different in different modes. Different modes have their own Preset function.

---

## Chapter 2 Spectrum Analyzer

Press **Mode**, select 'Spectrum Analyzer' to enter spectrum analyzer mode.

The 'Spectrum Analyzer' mode is the default mode of the machine. In this mode, the **Mode** backlight does not light up; in other modes, the **Mode** backlight will light up.

This chapter introduces in detail the function keys and menu functions of the front panel in Spectrum Analyzer Mode.

Subjects in this chapter:

- ◆ Basic Settings
- ◆ Sweep and Functions
- ◆ Marker
- ◆ Measurement

---

## 2.1 Basic Settings

### 2.1.1 Frequency

Set the frequency-related parameters and functions of the analyzer. The sweep will restart every time the frequency parameters are modified.

The frequency range of a channel can be expressed by three parameters: Start Frequency, Center Frequency and Stop Frequency. If any of the parameters change, the others will be adjusted automatically in order to ensure the coupling relationship among them:

$$f_{\text{center}} = (f_{\text{start}} + f_{\text{stop}})/2, \text{ Where } f_{\text{span}} \text{ is the span.}$$
$$f_{\text{span}} = f_{\text{stop}} - f_{\text{start}}$$

#### 2.1.1.1 Center Frequency

Set the center frequency of the current sweep. The center frequency and span values are displayed at the bottom of the grid respectively.

- ◆ Modifying the center frequency will modify both the start frequency and stop frequency when the span is constant (except when the start frequency or stop frequency reaches the boundary).
- ◆ In Zero Span, the start frequency, stop frequency and center frequency are always the same value.

Table 2-1 Center Frequency

Parameter	Parameter
Default	Full Span/2
Range	Zero Span, 0 Hz - Full Span Nonzero Span, 50 Hz - (Full Span -50Hz)
Unit	GHz, MHz, kHz, Hz
Knob Step	Span > 0, step = Span/200, min 1 Hz Span = 0, step = RBW/100, min 1 Hz
Direction Key Step	Freq Step
Related to	Start Freq, Stop Freq

#### 2.1.1.2 Start Frequency

Set the start frequency of the current sweep. The start and stop frequencies are displayed at the bottom of the grid respectively.

- ◆ The span and center frequency vary with the start frequency when the Span does not reach the minimum. For more details, please refer to “Span”.
- ◆ In Zero Span, the start frequency, stop frequency and center frequency are always the same value.

Table 2-2 Start Frequency

Parameter	Explanation
Default	0 Hz
Range	Zero Span, 0 Hz - Full Span Nonzero Span, 0 Hz - (Full Span-100Hz)
Unit	GHz, MHz, kHz, Hz
Knob Step	Span > 0, step = Span/200, min 1 Hz Span = 0, step = RBW/100, min 1 Hz
Direction Key Step	Freq Step
Related to	Center Freq, Span

### 2.1.1.3 Stop Frequency

Set the stop frequency of the current sweep. The start and stop frequencies are displayed at the lower right sides of the grid respectively.

- ◆ The span and center frequency vary with the stop frequency. The change of the span will affect other system parameters. For more details, please refer to “**Span**”.
- ◆ In Zero Span, the start frequency, stop frequency and center frequency are always the same value.

Table 2-3 Stop Frequency

Parameter	Explanation
Default	Full Span
Range	Zero Span: 0 Hz - Full Span Nonzero Span: 100 Hz - Full Span
Unit	GHz, MHz, kHz, Hz
Knob Step	Span > 0, step = Span/200, min 1 Hz Span = 0, step = RBW/100, min 1 Hz
Direction Key Step	Freq Step
Related to	Center Freq, Span

### 2.1.1.4 Freq Offset

Set the frequency offset value to illustrate the frequency conversion between the measured device and the input of the vector network analyzer.

- ◆ This parameter does not affect any hardware settings of the vector network analyzer, but only changes the display values of center frequency, start frequency and stop frequency.
- ◆ To eliminate the frequency offset value, the frequency offset value can be set to 0 Hz.

Table 2-4 Freq Offset

Parameter	Explanation
Default	0 Hz
Range	-100GHz - 100GHz
Unit	GHz, MHz, kHz, Hz
Knob Step	Span > 0, Step = Span/200, min 1 Hz Span = 0, Step = RBW/100, min 1 Hz
Direction Key Step	Freq Step
Related to	Center Freq, Start Freq, Stop Freq

### 2.1.1.5 Freq Step

Setting the value of Freq Step will change the direction key step of center frequency, start frequency, stop frequency and frequency offset.

- ◆ At a fixed step change the value of the center frequency can reach the purpose of switching measurement channels rapidly and continuously.
- ◆ There are two kinds of frequency step modes : **Auto** and **Manual**. In Auto mode, the Freq step is 1/10 of the span in Non-zero span or equals the RBW while in Zero Span. In Manual mode, you can set the step using the numeric keys.

Table 2-5 Freq Step

Parameter	Explanation
Default	Full Span/10
Range	1Hz - Full Span
Unit	GHz, MHz, kHz, Hz
Knob Step	Span > 0, Step = Span/200, min 1 Hz Span = 0, Step = RBW/100, min 1 Hz
Direction Key Step	In 1-2-5 sequence
Related to	RBW, Span and related parameters

### 2.1.1.6 Signal Track

Turn on or off the signal tracking function. It is used to track the signal whose frequency is unstable and the instantaneous change of the amplitude is less than 3 dB. By marking cursor 1 on the measured signal, the change of the measured signal can be tracked and measured continuously.

The signal tracking process is shown in the following figure:




Figure 2-1 Signal Tracking Flow

- ◆ When Marker1 is on, turn on signal tracking, a point whose amplitude does not change more than 3 dB near Marker1 will be searched and marked, and the frequency at that point will be set to center frequency.
- ◆ When Marker1 is off, turn on signal tracking, Marker1 will be activated, and a peak search will be performed, and then the peak frequency will be set to center frequency.
- ◆ Signal tracking function is only available in sweep analysis. Signal tracking function is turned off in following cases:
  - ✓ Zero Span mode
  - ✓ Tracking Generator(TG) open
  - ✓ Traces are not updated, including single sweep mode or View mode.
  - ✓ Cont Peak function turned on
  - ✓ Other non-SA measurement modes

#### 2.1.1.7 Peak -> CF

Executes a peak search and sets the center frequency (CF) of the display to the frequency of the current peak. The function is invalid in Zero Span.




Figure 2-2 before Peak -> CF




Figure 2-3 after Peak -> CF

#### 2.1.1.8 CF -> Step

Set the current center frequency as the Freq Step. At this point, the Freq Step will switch to “**Manual**” mode automatically. This function is usually used in channel switching. For example, in harmonic measurement, firstly locate the signal at the center frequency (CF) of the display, and then execute

---

CF->Step. Next you can press the upward direction key continuously to measure each order of harmonic in sequence.

## 2.1.2 Span

Set the span of the analyzer. Any change of this parameter will affect the frequency parameters and restart the sweep.

### 2.1.2.1 Span

Set the frequency range of the current sweep. The center frequency and span are displayed at the bottom of the grid respectively.

- ◆ The start and stop frequency vary with the span when the center frequency is constant.
- ◆ In non-zero span mode, the span can be set down to 100 Hz and up to the full span described in Specifications. When the span is set to the maximum, the analyzer enters full span mode.
- ◆ Modifying the span in non-zero span mode may cause an automatic change in both Freq Step and RBW if they are in Auto mode. Besides, the change of RBW may influence VBW (in Auto VBW mode).
- ◆ Variation in the span, RBW or VBW would cause a change in the sweep time.

Table 2-6 Span

Parameter	Explanation
Default	Full Span
Range	0 Hz - Full Span
Unit	GHz, MHz, kHz, Hz
Knob Step	Span/200, min 1 Hz
Direction Key Step	In 1-2-5 sequence
Related to	Start Freq, Stop Freq, Freq Step, RBW, Sweep time

**Note:** 0 Hz is available only in zero span.

### 2.1.2.2 Full Span

Set the span of the analyzer to the maximum available frequency span.

### 2.1.2.3 Zero Span

Set the span of the analyzer to 0Hz. Both the start and stop frequencies will equal to center frequency and the horizontal axis will denote time. The analyzer measures the time domain characteristics of the amplitude of the corresponding frequency point of the input signal.

- ◆ The following functions are invalid in Zero span:
  - ✓ **Frequency**: Peak->CF and Signal Track;
  - ✓ **SPAN**: Zoom In and Zoom Out;
  - ✓ **Sweep**: Sweep Mode;



- ✓ **Marker->**: M->CF, M->CF step, M->Start Freq, M->Stop Freq,  $\Delta$ M->Span and  $\Delta$ M->CF;
- ✓ **Marker Fn**: Read Out(default option:  $\Delta$ Time);

#### 2.1.2.4 Zoom In

Set the span to half of its current value. At this point, the signal on the screen will be amplified to observe signal details.

#### 2.1.2.5 Zoom Out

Set the span to twice the current value. At this point, the signal on the screen will be reduced to gain more information about the nearby spectrum.

#### 2.1.2.6 Last Span

Set the span to the previous span setting.

#### 2.1.2.7 X-Scale

Set the scale type of X-axis to Linear (Lin) or Logarithmic (Log) scale.

In Log scale type, the frequency scale of X-axis is displayed in the logarithmic form, and Meas function is invalid.




Figure 2-4 Logarithmic X Scale

### 2.1.3 Amplitude

Set the amplitude parameters of the analyzer. Through modifying these parameters, signals under measurement can be displayed in a proper mode for easier observation and minimum error. Any

---

change of Ref Level, Attenuator Value, Preamp mode and Ref Offset will restart sweep.

### 2.1.3.1 Ref Level

Set the maximum power or voltage that can be currently displayed in the trace window. The value is displayed at the upper left corner of the screen grid.

The maximum reference (Ref) level available is affected by the maximum mixing level; input attenuation is adjusted under a constant maximum mixing level in order to fulfill the following condition:

$$Ref \leq ATT - PA - 20dBm, \text{ where } ATT = \text{Attenuation value}, PA = \text{Preamplifier value}$$

Table 2-7 Ref Level

Parameter	Explanation
Default	0 dBm
Range	-200 dBm to + 30 dBm, 1 dB steps
Unit	dBm, dBmV, dBuV, dBuA, V, W
Knob Step	In Log scale mode, step = Scale/10 In Lin scale mode, step = 0.1 dBm
Direction Key Step	In Log scale mode, step = Scale In Lin scale mode, step = 1 dBm
Related to	Attenuator, Preamp, Ref Offset

**Note:** the maximum reference level of different instrument models may be different, please refer to the data sheet.

### 2.1.3.2 Attenuator

Set the value for the internal attenuator of the RF input so that the largest signal is not distorted and small signals can pass through the mixer with low noise.

$$Ref \leq ATT - PA - 20dBm, \text{ where } ATT = \text{Attenuation value}, PA = \text{Preamplifier value}$$

Input attenuation can be set up to auto or manual mode.

- ◆ Auto mode: the attenuation value is automatically adjusted according to the state of preamplifier and the current reference level.
- ◆ The maximum input attenuation can be set to 31 dB. When the set parameters do not meet the above formula, you can adjust the reference level.

Table 2-8 Attenuator

Parameter	T3VNA1500	T3VNA3200
Default	20 dB	
Range	0 - 31 dB	0 - 50 dB
Unit	dB	
Knob Step	1 dB	
Direction Key Step	5 dB	
Related to	Preamp, Ref level	

**Note:** the maximum attenuator value of different instrument models may be different, please refer to the data sheet.

### 2.1.3.3 RF Preamp

Control the state of the internal preamplifier (PA) located in the RF input signal path. When the signal-under-measurement is small, turning on the preamplifier can reduce the displayed noise level and aid distinguishing small signals from the noise.

The corresponding icon “**PA**” will appear at the left side of the screen when the preamplifier is turned on.

### 2.1.3.4 Units

Set the unit of the Y-axis to dBm, dBmV, dBuV, dBuA, Volts (RMS) or Watts. Default is dBm.

The conversion relationships between units are as follows.

$$\text{dBm} = 10\lg\left(\frac{\text{Volts}^2}{R} \times \frac{1}{1\text{mW}}\right)$$

$$\text{dB}\mu\text{V} = 20\lg\left(\frac{\text{Volts}}{1\mu\text{V}}\right)$$

$$\text{dBmV} = 20\lg\left(\frac{\text{Volts}}{1\text{mV}}\right)$$

$$\text{Watts} = \frac{\text{Volts}^2}{R}$$

Where, R denotes the reference impedance. The default value is 50Ω and can be adjusted by pressing “**Correction -> RF input**”. The “75 Ω” impedance is just a numeric value, not a real impedance. Setting the RF input to 75 Ω will not change the actual input impedance. A 75 Ω feed-through adapter is required to match 75 Ω circuits to the 50 Ω input of the T3VNA.

### 2.1.3.5 Scale

Set the logarithmic units per vertical grid division on the display. This function is only available when the scale type is set to “**log**”.

- ◆ By changing the scale, the displayed amplitude range is adjusted.
- ◆ The Minimum range: Reference level –10 × current scale value.
- ◆ The Maximum range: The reference level.

Table 2-9 Scale/Div

Parameter	Explanation
Default	10 dB
Range	0.1 dB - 20 dB
Unit	dB
Knob Step	Scale $\geq$ 1, 1 dB, Scale $<$ 1, 0.1dB
Direction Key Step	1-2-5 sequence
Related to	Scale Type

### 2.1.3.6 Scale Type

Set the scale type of the Y-axis to Lin or Log. The default is Log.

- ◆ In Lin mode, the vertical Scale value cannot be changed. The Display area is set for reference level of 0%.
- ◆ In Log scale type, the Y-axis denotes the logarithmic coordinate. The value shown at the top of the grid is the reference level and each grid represents the scale value. The unit of Y-axis will automatically switch to the default unit (dBm) in Log scale type when the scale type is changed from Lin to Log.
- ◆ In Lin scale type, the Y-axis denotes the liner coordinate; the values shown at the top of the grid and the bottom of the grid are the reference level and 0 V. The scale setting function is invalid. The unit of Y-axis will automatically switch to the default unit (Volts) in Lin scale type when the scale type is charged from Log to Lin.

### 2.1.3.7 Ref Offset

Assign an offset to the reference level to compensate for gains or losses generated between the device under measurement and the analyzer.

The change of this value changes both the reference level readout and the amplitude readout of the marker; but does not impact the position of traces on the screen.

Table 2-10 Ref Offset

Parameter	Explanation
Default	0 dB
Range	-100 dB - 100 dB
Unit	dB
Knob Step	Not supported
Direction Key Step	Not supported
Related to	Ref Level

---

### 2.1.3.8 Correction

Correct the displayed amplitude to compensate for gains or losses from external devices such as antennas and cables. When using this function, you can view the correction data table and save or load the current correction data. When amplitude correction is enabled, both the trace and related measurement results will be mathematically corrected. Positive correction values are added to the measured values. Negative (-) correction values are subtracted from the measured values.

#### 1. RF Input

Set the input impedance for numeric voltage-to-power conversions. To measure a 75  $\Omega$  device, you should use a 75  $\Omega$  to 50  $\Omega$  adapters to connect the analyzer with the system-under-test and then set the input impedance to 75  $\Omega$ .

#### 2. Apply Correction

Enable or disable amplitude corrections. Default is Off. The analyzer provides four correction factors that can be created and edited separately, but they can be applied independently in any combination.

#### 3. Edit Correction factors

Table 2-11 Edit Correction table

Function	Explanation
Correction	Select the correction factor on or off.
Add Point	Add a point into correction table.
Point Num	Select a point to edit by point num.
Frequency	Edit the frequency value for the current selected point.
Amplitude	Edit the amplitude value for the current selected point.
Del Point	Delete the selected correction point.
Del All	Clear all data of the correction table.
Save/Load	Save or load correction data. You can save the current correction data into or load correction data from a specified file.

### 2.1.4 Auto Tune

The analyzer will search for signals automatically throughout the full frequency range and adjust the frequency and amplitude settings for optimum display of the strongest signal.

- ◆ In the process of auto search, The “**Auto Tune**” is shown in the status bar on the screen until the search is finished.
- ◆ Some parameters such as the reference level, scale, input attenuation and maximum mixing level may be changed during the auto search.




Figure 2-5 before Auto Tune



Figure 2-6 after Auto Tune

---

## 2.2 Sweep and Functions

### 2.2.1 BW

The bandwidth menu contains the RBW (Resolution Bandwidth), VBW (Video Bandwidth), average type and filter type. Filter type includes the EMI filter type that enables EMI measurement controls.

#### 2.2.1.1 Resolution Bandwidth

Set the resolution bandwidth in order to distinguish between signals which have frequency components that are near one another.

- ◆ Reducing the RBW will increase the frequency resolution, but will also increase the sweep time dramatically (Sweep Time is affected by a combination of RBW and VBW when the analyzer is in Auto mode).
- ◆ The frequency resolution ability is affected by RBW, RBW Filter shape factor, LO Phase noise, and LO Residual FM.
- ◆ RBW varies with the span (non-zero span) in Auto RBW mode.
- ◆ Under EMI filter, RBW can only be set to 200 Hz, 9 kHz, 120 kHz and 1 MHz with a 6dB shape factor.

Table 2-12 RBW

Parameter	Explanation
Default	1 MHz
Range	1 Hz - 1 MHz
Unit	MHz, kHz, Hz
Knob Step	in 1, 3, 10 sequence
Direction Key Step	in 1, 3, 10 sequence
Relation	Span, VBW, V/R Ratio, Sweep Time

**Notes:** RBW of above table is Gaussian filter type.

#### 2.2.1.2 Video Bandwidth

Set the video bandwidth in order to filter out the noise outside the video band.

- ◆ Reducing the VBW will smooth the trace and helps to highlight small signals from noise, but it will also increase the sweep time (Sweep Time is affected by a combination of RBW and VBW when it is in Auto mode).
- ◆ VBW varies with RBW when it is in Auto mode. While in Manual mode, VBW is not affected by Changes in the RBW.

Table 2-13 VBW

Parameter	Explanation
Default	1 MHz
Range (-3dB)	1 Hz - 3 MHz
Unit	MHz, kHz, Hz
Knob Step	in 1, 3 sequence
Direction Key Step	in 1, 3 sequence
Relation	RBW, V/R Ratio, Sweep Time

### 2.2.1.3 VBW / RBW Ratio

Set the ratio of VBW to RBW. This value is different while measuring different kinds of signals:

- ◆ Sine/Continuous Wave (CW) signals: Use 1 to 3 (for faster sweeps)
- ◆ Pulsed/transient signals: Use 10 (to reduce the influence on the amplitude of transient signals)
- ◆ Noise signals: Generally use 0.1 (to obtain the average of noises)

Table 2-14 V/R Ratio

Parameter	Explanation
Default	1
Range	0.001 - 1000
Unit	N/A
Knob Step	in 1, 3 sequence
Direction Key Step	in 1, 3 sequence
Relation	RBW, VBW

### 2.2.1.4 Average Type

Choose one of the following averaging types: log power (video), power (RMS), or voltage averaging. When trace average is on, the average type is shown on the left side of the display.

#### 1. Log Power

Select the logarithmic (decibel) scale for all filtering and averaging processes. This scale is "Video" because it is the most common display and analysis scale for the video signal within analyzer. This scale is excellent for finding Sine/CW signals near noise.

#### 2. Power Average

In this average type, all filtering and averaging processes work on the power (the square of the magnitude) of the signal, instead of its log or envelope voltage. This scale is best for real-time power measurement of complex signals.

#### 3. Voltage Average

In this Average type, all filtering and averaging processes work on the voltage of the envelope of the



signal. This scale is suitable for observing rise and fall behavior of AM or pulse-modulated signals such as radar and TDMA transmitters.

### 2.2.1.5 Filter

Set the RBW filter type. The analyzer supports two kinds of RBW filters: “**Gauss**” (-3 dB bandwidth) and “**EMI**” (-6 dB bandwidth).

When “**EMI**” is selected, resolution bandwidth can only be 200 Hz, 9 kHz, 120 kHz and 1 MHz  
“**Quasi-Peak**” detector is available only when “**EMI**” filter is turned on.

## 2.2.2 Trace

The sweep signal is displayed as a trace on the screen.

### 2.2.2.1 Select Trace

The analyzer allows for up to four traces to be displayed at the same time. Each trace has its own color (Trace A - Yellow, Trace B - Purple, Trace C - Light blue and Trace D - Green). All traces can have Parameters set independently. As a default the analyzer will choose Trace A and set the type of the trace as Clear Write.

### 2.2.2.2 Trace Type

Set the type of the current trace or disable it. The system calculates the sampled data using a specific operation method according to the trace type selected and displays the result. Trace types include Clear Write, Max Hold, Min Hold, View, Average and Blank. The corresponding icon of the trace type will be displayed in the status bar at the left of the screen, as shown in the figure below.




Figure 2-7 Trace Type

---

### 1. Clear Write

Erases any data previously stored in the selected trace, and display the data sampled in real-time of each point on the trace.

### 2. Max Hold

Retain the maximum level for each point of the selected trace. Update the data if a new maximum level is detected in successive sweeps. Max Hold is very effective when measuring events that may take successive scans to measure accurately. Some common applications include FM Deviation, AM NRSC, and frequency hopping or drift.

### 3. Min Hold

Display the minimum value from multiple sweeps for each point of the trace and update the data if a new minimum is generated in successive sweeps.

### 4. View

Freezes and holds the amplitude data of the selected trace. The trace data is not updated as the analyzer sweeps.

### 5. Blank

Disable the trace display and all measurements of this trace.

### 6. Average

Set the averages time of the selected trace.

More averages can reduce the noise and the influence of other random signals; thus highlighting the stable signal characteristics. The larger the number of averages the smoother the trace will be. Enabling averaging will take more time to collect the full spectral information because the analyzer needs to sweep the set average count. The displayed data is averaged in a first-in-first-out fashion.

Table 2-15 Average Times

Parameter	Explanation
Default	100
Range	1 - 999
Unit	N/A
Knob Step	1
Direction Key Step	5

#### 2.2.2.3 Math

Set the computational method of the math trace.

### 1. Output Z

The Math result is denoted by the Z variable and can be displayed by trace A, B, C, or D.

---

## 2. Input X, Y

Input X, Y can be applied to trace A, B, C, or D.

## 3. Calculation Type

The analyzer provides the calculation types as shown below:

- ◆ **Power Diff:**  $X - Y + \text{Offset} \rightarrow Z$
- ◆ **Power Sum:**  $X + Y + \text{Offset} \rightarrow Z$
- ◆ **Log Offset:**  $X + \text{Offset} \rightarrow Z$
- ◆ **Log Diff:**  $X - Y - \text{Ref} \rightarrow Z$

## 4. Offset value

Table 2-16 Offset value

Parameter	Explanation
Default	0 dB
Range	-100 dB - 100 dB
Unit	dB
Knob Step	1 dB
Direction Key Step	1 dB

## 2.2.3 Detect

The analyzer displays the sweep signal on the screen in the form of a trace. For each trace point, the analyzer always captures all the data within a specific time interval and processes (Peak, Average, etc.) the data using the detector currently selected, then it displays the processed data (a single data point) on the screen.

Select an appropriate detector type according to the actual application in order to ensure the accuracy of the measurement.

The available types are **Pos Peak**, **Neg Peak**, **Sample**, **Normal**, **Average** and **Quasi Peak**. The default is **Pos peak**.

### 1. Positive Peak

For each trace point, Positive Peak detector displays the maximum value of data sampled within the corresponding time interval.

### 2. Negative Peak

For each trace point, Negative Peak detector displays the minimum value of data sampled within the corresponding time interval.

### 3. Sample

For each trace point, Sample detector displays the transient level corresponding to the central time

---

point of the corresponding time interval. This detector type is applicable to noise or noise-like signal.

#### 4. Normal

Normal detector (also called ROSENFELL Detector) displays the maximum value and the minimum value of the sample data segment in turn: Odd-numbered data points display the maximum value and even-numbered data points display the minimum value. In this way, the amplitude variation range of the signal is clearly shown.

#### 5. Average

For each trace point, Average detector displays the average value of data sampled within the corresponding time interval.

#### 6. Quasi-Peak

Quasi-Peak (QP) detector, which is a weighted form of peak detector, is used for EMC pulse testing. The T3VNA QP detector is designed to follow CISPR-16 response specifications. For a single frequency point, the detector detects the peaks within the QP dwell time.

The peaks detected are weighted using a digital model that follows a defined response curve as well as the time constant specified in the CISPR 16 standards. The measurement time for QP is far longer than Peak Detector.

## 2.2.4 Sweep

Sets parameters about the Sweep functions, including sweep time, sweep times, sweep mode, etc.

### 2.2.4.1 Sweep Time

Sets the time needed for the analyzer to finish a sweep within the span range. The sweep time can be set in **“Auto”** or **“Manual”** mode and the default is **“Auto”**.

- ◆ In non-zero span, the analyzer selects the shortest sweep time on the basis of the current RBW and VBW settings if Auto is selected.
- ◆ Decreasing the sweep time will decrease measurement time. However, an error may be caused if the specified sweep time is less than the minimum sweep time in Auto coupling; at this point, **“UNCAL”** is shown in the status bar on the screen. Measurements taken with **“UNCAL”** showing may not meet the specifications of the instrument and can have significant error.

Table 2-17 Sweep Time

Parameter	T3VNA1500	T3VNA3200
Default	N/A	
Range	1 ms - 1.5 ks	1 ms - 1.5 ks
Quasi Peak Range	1 ms - 15 ks	
Unit	ks, s, ms, us	
Knob Step	Sweep time/100, min =1 ms	
Direction Key Step	in 1, 3 sequence	

---

#### 2.2.4.2 Sweep Rule

The analyzer provides two sweep time rules to meet the different sweep time requirements:

- ◆ **Speed:** Activates the default fast sweep time rule.
  - ◆ **Accuracy:** Activates the normal sweep time rule to ensure increased measurement accuracy.
- The Speed sweep time rule provides a fast measurement function that decreases the sweep time. While the Accuracy Sweep rule will increase the measurement accuracy.

#### 2.2.4.3 Sweep

Set the sweep mode in single or continuous, the default is continuous. The corresponding icon of the sweep will be displayed in the status bar at the left of the screen.

##### 1. Single

Set the sweep mode to “**Single**”. The number on the parameter icon denotes the current sweep times.

##### 2. Numbers

Set the sweeps times for a single sweep. In single sweep mode, the system executes the specified sweeps times and the number shown on the icon in the status bar at the left of the screen varies with the process of the sweep.

##### 3. Continue

Set the sweep mode to “Continue”. The character Cont on the parameter icon denotes the analyzer is sweeping continuously.

- ◆ If the instrument is in single sweep mode and no measurement function is enabled, press this key and the system will enter continuous sweep mode and sweep continuously if the trigger conditions are satisfied.
- ◆ If the instrument is in single sweep mode and a measurement function is on, press this key and the system will enter continuous sweep mode and measure continuously if the trigger conditions are satisfied.
- ◆ In continuous sweep mode, the system will send a trigger initialization signal automatically and enter the trigger condition judgment directly after each sweep.

Table 2-18 Sweep Times

Parameter	Explanation
Default	1
Range	1 - 99999
Unit	N/A
Knob Step	1
Direction Key Step	1

---

#### 2.2.4.4 Sweep Mode

Sweep mode includes auto mode, sweep mode and FFT mode.

##### 1. Auto

When the sweep mode is auto, the analyzer selects the sweep mode automatically between Sweep and FFT Mode in the shortest time.

##### 2. Sweep

True swept operation including point-by-point scanning. The Sweep mode is available when the RBW is in 30 Hz – 1 MHz.

##### 3. FFT

The FFT mode is only available when RBW is in 1 Hz - 10 kHz.

When the tracking generator (TG) is on, the sweep mode is forced to Sweep.

#### 2.2.4.5 QPD Dwell Time

Dwell time is the measurement time at a single frequency. QP detector gets its weighted envelope response during this dwell time. The longer dwell time is, the more effectively the QP detector responses to a single frequency, and the more accurate the QP detector envelope is.

Table 2-19 QPD Dwell Times

Parameter	Explanation
Default	50 ms
Range	0 s - 10 s
Unit	ks, s, ms, us
Knob Step	1 ms
Direction Key Step	1 ms

#### 2.2.5 Trigger

The trigger type can be Free Run, Video or External.

##### 2.2.5.1 Free Run

The trigger conditions are satisfied at any time and the analyzer generates trigger signals continuously.

##### 2.2.5.2 Video Trigger

A trigger signal will be generated when the system detects a video signal of which the voltage exceeds the specified video trigger level. Set the trigger level with the video trigger menu entry. At this point, the trigger level line (Trig Line) and value are displayed on the screen.

Table 2-20 Trigger Setup

Parameter	Explanation
Default	0 dBm
Range	-300 dBm - 50 dBm
Unit	dBm
Knob Step	1 dBm
Direction Key Step	10 dBm

### 2.2.5.3 External

In this mode, an external signal (TTL signal) is input from the [TRIGGER IN] connector at the rear panel and trigger signals are generated when this signal fulfills the specified trigger edge condition.

Set the trigger edge in external trigger to the rising (Pos) or falling (Neg) edge of the pulse.

## 2.2.6 Limit

The analyzer supports Pass/Fail test function. In this function, the measured curve will be compared with the pre-edited curve. If the related rules are met, the result is “**Pass**”, else the result is “**Fail**”.

### 2.2.6.1 Limit1

Enable or disable limit1.

### 2.2.6.2 Limit1 Edit

Edit the properties of limit1.

Table 2-21 Limit1 Edit Menu

Function	Explanation
Type	Select upper or lower limit type. The default value is Upper.
Mode	Select limit line or limit point. The default value is Line. Set the number of the point to be edited if you selected the point type, and the range is 1 - 100.
Add point	Add a new point for editing.
X-axis	Edit the X-axis value (frequency or time) of the current point.
Amplitude	Edit the amplitude of the current point or line.
Del Point	Delete the point whose number is selected in Mode.
Del All	Delete all the points.
Save/Load	Save or load the limit file.

---

### 2.2.6.3 Limit2

Enable or disable limit2.

### 2.2.6.4 Limit2 Edit

Edit the properties of limit2.

Table 2-22 Limit2 Edit Menu

Function	Explanation
Type	Select upper or lower limit type. The default value is Lower.
Mode	Select limit line or limit point. The default value is Line. Set the number of the point to be edited if you selected the point type, and the range is 1 - 100.
Add point	Add a new point for editing.
X-axis	Edit the X-axis value (frequency or time) of the current point.
Amplitude	Edit the amplitude of the current point or line.
Del Point	Delete the point whose number is selected in Mode.
Del All	Delete all points.
Save/Load	Save or load the limit file.

### 2.2.6.5 Test

Enable or disable the limit test function.

### 2.2.6.6 Setup

#### 1. Fail to stop

Turn on or off the Fail to stop function. If the function is on, the analyzer will stop sweep and retain the test result when the test result is "Fail".

#### 2. Buzzer

Turn on or off the buzzer. When the buzzer is on, it beeps when the test result is "Fail".

#### 3. X Axis

Set the X-axis to frequency or time domain. The default value is Freq.

Note that all the points of the current limit line will be deleted if the X-axis unit changes.

## 2.2.7 TG (Tracking Generator)

Set the parameters related to the tracking generator (TG) and normalize.



### 2.2.7.1 TG

The tracking generator is a signal source with an adjustable frequency and amplitude. When the TG is enabled, a signal with the same frequency of the current sweep signal will be output from the **[TG SOURCE]** connector at the front panel. The power of the signal can be set through the menu. The TG output frequency follows the analyzer sweep frequency. For example, if the sweep is set to scan from 1 MHz to 10 MHz, the TG output frequency will change from 1 MHz to 10 MHz in coordinated steps with the sweep. In Zero Span mode, the TG frequency will match the center frequency of the analyzer.

### 2.2.7.2 TG Level

Set the output power of the signal of the tracking generator.

Table 2-23 TG Level

Parameter	Explanation
Default	-20 dBm
Range	-20 dBm - 0 dBm
Unit	dBm
Knob Step	1 dBm
Direction Key Step	10 dBm

### 2.2.7.3 TG Level Offset

Assigns a certain offset to the output power of the TG when gains or losses occur between the TG output and external device in order to display the actual power value.

- ◆ This parameter only changes the readout of the TG output power, rather than the actual value.
- ◆ The offset could be either a positive (gain in the external output) or a negative (loss in the external output).

Table 2-24 TG Level Offset

Parameter	Explanation
Default	0 dB
Range	-200 dB - 200 dB
Unit	dB
Knob Step	1 dB
Direction Key Step	10 dB

### 2.2.7.4 Normalize

Normalization can eliminate errors in the TG Level. Before using this function, connect the **[TG SOURCE]** output terminal of the TG with the **[RF INPUT]** input terminal of the analyzer.

The reference trace can be stored by pressing the "Store Ref" button after the current sweep finished. Then the normalize function can be enabled. When normalization is enabled, the corresponding value

of the reference trace will be subtracted from the trace data after every sweep.

The reference trace must be stored before the normalize function can be used.




Figure 2-8 Normalize

#### 2.2.7.5 Store Ref

Before enable the normalize function, you should press the “Store Ref” button to store the data of Trace A to Trace D. Then Trace D is the reference trace.

- ◆ The tracking generator needs to be turned on first, and the reference trace can be saved only when the first screen is scanned.
- ◆ The normalization can be enabled only after the reference trace is stored.
- ◆ After you stored the reference trace and enabled the normalization, if you then change some parameters which will change the sweep frequency and sweep time, the "UNCAL" sign will be displayed in the upper left corner of the screen, indicating that the reference trace is no longer applicable to the new trace, and prompting you to save the reference trace again.

#### 2.2.7.6 Ref Trace

Set whether to display the reference trace or not. If “**View**” is selected, the reference trace saved (Trace D) will be shown in “View” type.

**Note:** When normalization is enabled, the unit of Y-axis is “dB” and will not be influenced by the definition in **AMPT->Units**. At this point, “(dB)” is displayed under the Y-axis scale in the user interface.

#### 2.2.7.7 Norm Ref Level

Adjust the vertical position of the trace on the screen by adjusting the reference level when normalization is enabled.

This operation differs from the **Ref Level** function in the **AMPT** menu. This parameter has no influence on the reference level of the analyzer.

Table 2-25 Reference level under normalization

Parameter	Explanation
Default	0 dB
Range	-200 dB - 200 dB
Unit	dB
Knob Step	1 dB
Direction Key Step	10 dB

### 2.2.7.8 Norm Ref Pos

Adjust the vertical position of the normalization reference level on the screen by adjusting the reference position when normalization is enabled.

- ◆ The function of this menu is similar to that of **Norm Ref Level**. When it is set to 0%, the normalization reference level is displayed at the bottom of the screen grid and at the top when it is set to 100%.

Table 2-26 TG reference position under normalization

Parameter	Explanation
Default	100%
Range	0 - 100%
Unit	100%
Knob Step	1%
Direction Key Step	10%

## 2.2.8 Demod

Press **Demod** at the front panel to enter the demodulation setting menu. Both AM and FM demodulations are available on the analyzer.

### 2.2.8.1 Demod (AM/FM)

Set the demodulation type to AM or FM or off. The default is off.

- ◆ The analyzer features an earphone jack and the demodulated signal can be output in audio frequency (AF) mode through the earphone. The frequency and intensity of AF denotes the frequency and amplitude of the signal respectively.
- ◆ A marker would be enabled automatically, place it at the desired frequency and set a demod time. The analyzer would demod at the marker frequency for the demod time, and then performs a normal sweep.
- ◆ Zero span and linear scale type amplitude can be used to see the time domain waveform of the modulated signal.

More demodulation analysis, please refer to AM/FM demodulation in Modulation Analyzer section.

---

### 2.2.8.2 Earphone

Set the status of the earphone. When it is on, the demodulated signal can be heard through the earphone during the demodulation. By default, it is off.

### 2.2.8.3 Volume

Set the volume of the earphone.

Table 2-27 Volume

Parameter	Explanation
Default	6
Range	0 - 10
Unit	N/A
Knob Step	1
Direction Key Step	1

### 2.2.8.4 Demod Time

Set the time for the analyzer to complete a signal demodulation after each sweep.

If the **Earphone** is set to "On", you will hear the demodulated signal through the earphone during the demodulation. A longer demod dwell time is recommended for demodulating audio signals.

Table 2-28 Demod time

Parameter	Explanation
Default	5 s
Range	5 ms - 1000 s
Unit	ks, s, ms, us
Knob Step	0 ms - 100 ms, step = 1 ms 100 ms - 1 s, step = 10 ms 1 s - 10 s, step = 100 ms 10 s - 100 s, step = 1 s 100 s - 1000 s, step = 10 s
Direction Key Step	In 1-2-5 step sequence

## 2.3 Marker

### 2.3.1 Marker

The marker appears as a rhombic sign (as shown below) for identifying points on a trace. You can easily read the amplitude, frequency and sweep time of the marked point on the trace.




Figure 2-9 Marker

- ◆ The analyzer allows for up to eight/four pairs of markers to be displayed at one time, but only one pair or a single marker is active every time.
- ◆ You can use the numeric keys, knob or direction keys to modify the desired frequency or time as well as view the readouts of different points on the trace.

#### 2.3.1.1 Select Marker

Select one of the eight markers. The default is Marker1. When a marker is selected, you can set its type, trace to be marked, readout type and other related parameters. The enabled marker will appear on the trace selected through the **Select Trace** option and the readouts of this marker are also displayed in the active function area and at the upper right corner of the screen.

Table 2-29 Marker parameters

Parameter	Explanation
Default	Center Frequency
Range	0 - Full Span
Unit	Readout = Frequency: GHz, MHz, kHz, Hz Readout = Time or Period: s, ms, us, ns, ps
Knob Step	Readout = Frequency, Step = Span/(Sweep Points - 1) Readout = Time or Period, Step = Sweep Time/(Sweep Points - 1)
Direction Key Step	Readout = Frequency, Step = Span/10 Readout = Time or Period, Step = Sweep Time/10

### 2.3.1.2 Select Trace

Select the trace to be marked by the current marker. Valid selections include A, B, C, or D.

### 2.3.1.3 Normal

One of the marker types. It is used to measure the X (Frequency or Time) and Y (Amplitude) values of a certain point on the trace. When selected, a marker with the number of the current marker (such as "1") appears on the trace.

- ◆ If no active marker exists currently, a marker will be enabled automatically at the center frequency of the current trace.
- ◆ You can use the numeric keys, knob or direction keys to move the marker. The readouts of the marker will be displayed at the upper right corner of the screen.
- ◆ The readout resolution of the X-axis (frequency or time) is related to the span. For higher readout resolution, reduce the span.

### 2.3.1.4 Delta

One of the marker types. It is used to measure the delta values of X (Frequency or Time) and Y (Amplitude) between the reference point and a certain point on the trace. When selected, a pair of markers appears on the trace: Fixed Related Marker (marked by a combination of the marker number and letter "+", such as "2+") and the Delta Marker (marked by the "Δ", such as "1Δ2").

- ◆ After the marker selects "Delta", the original marker will become the delta measurement marker, and the related marker of the incrementing sequence number will become the reference "fixed" marker
- ◆ The delta marker is in the "relative to" state, and its X-axis position can be changed; the related marker is in the "fixed" state by default (the X-axis and Y-axis positions are fixed), but the X-axis can be adjusted by changing to the "normal" state.
- ◆ The first row in the upper right corner of the trace area shows the frequency (or time) difference and amplitude difference between the two markers; the second row in the upper right corner of the trace area shows the X axis and amplitude value of the related marker.

### 2.3.1.5 Fixed

One of the marker types. When “Fixed” is selected, the X-axis and Y-axis of the marker will not change by the trace and can only be changed through the menu. The fixed marker is marked with "+".

After the marker selects “Delta”, the original marker will become the delta measurement marker, and the related marker of the incrementing sequence number will become the reference “fixed” marker

### 2.3.1.6 Off

Turn off the marker currently selected. The marker information displayed on the screen and functions based on the marker will also be turned off.

### 2.3.1.7 Relative To

“Relative to” is used to measure the delta values of X (Frequency or Time) and Y (Amplitude) between two markers which can mark on different traces.

After the marker selects “Delta”, the original marker will become the delta measurement marker, and the related marker of the incrementing sequence number will become the reference “fixed” marker

### 2.3.1.8 Marker Table

Enable or disable the Marker Table.

Display all the markers enabled on the lower portion of the screen, including marker number, trace number, marker readout type, X-axis readout and amplitude. Through this table you can view the measurement values of multiple points. The table allows for up to eight markers to be displayed at one time.




Figure 2-10 Marker table

---

## 2.3.2 Marker ->

### 1. M->CF

Set the center frequency of the analyzer to the frequency of the current marker.

- ◆ If the **Normal** marker is selected, the center frequency will be set to the frequency of the current marker.
- ◆ If the **Delta** or **Delta Pair** marker is selected, the center frequency will be set to the frequency of the Delta Marker.
- ◆ The function is invalid in Zero span.

### 2. M -> CF Step

Set the center frequency step of the analyzer to the frequency of the current marker.

- ◆ If the **Normal** marker is selected, the center frequency step will be set to the frequency of the current marker.
- ◆ If the **Delta** or **Delta Pair** marker is selected, the center frequency step will be set to the frequency of the Delta Marker.
- ◆ The function is invalid in Zero span.

### 3. M -> Start Freq

Set the start frequency of the analyzer to the frequency of the current marker.

- ◆ If the **Normal** marker is selected, the start frequency will be set to the frequency of the current marker.
- ◆ If the **Delta** or **Delta Pair** marker is selected, the start frequency will be set to the frequency of the Delta Marker.
- ◆ The function is invalid in Zero span.

### 4. M -> Stop Freq

Set the stop frequency of the analyzer to the frequency of the current marker.

- ◆ If the **Normal** marker is selected, the stop frequency will be set to the frequency of the current marker.
- ◆ If the **Delta** or **Delta Pair** marker is selected, the stop frequency will be set to the frequency of the Delta Marker.
- ◆ The function is invalid in Zero span.

### 5. M ->Ref Level

Set the reference level of the analyzer to the amplitude of the current marker.

- ◆ If the **Normal** marker is selected, the reference level will be set to the amplitude of the current marker.
- ◆ If the **Delta** or **Delta Pair** marker is selected, the reference level will be set to the amplitude of the Delta Marker.

### 6. ΔM->Span

Set the span of the analyzer to the frequency difference between the two markers in Delta marker type.

- ◆ If the **Normal** marker is selected, this function is invalid.



- 
- ◆ The function is invalid in Zero span.

## 7. $\Delta M \rightarrow CF$

Set the center frequency of the analyzer to the frequency difference between the two markers in **Delta** marker type.

- ◆ If the **Normal** marker is selected, this function is invalid.
- ◆ The function is invalid in Zero span.

## 2.3.3 Marker Fn

Special marker functions including Noise Marker, N dB BW and Freq Counter.

### 2.3.3.1 Select Marker

Select one of the eight markers (1, 2, 3, 4, 5, 6, 7 and 8) and the default is Marker1.

### 2.3.3.2 Noise Marker

Execute the Noise marker function for the selected marker and read the normalized noise power spectral density.

- ◆ If the current marker is “**Off**” in the Marker menu, pressing **Noise Marker** will first set it to Normal type automatically; then measure the average noise level at the marked point and normalize this value to 1 Hz bandwidth. During this process, certain compensation is always made on the basis of the detection and trace types. The measurement will be more precise if RMS Avg or Sample detection type is used.
- ◆ This function can be used for measuring the C/N ratio.

### 2.3.3.3 N dB BW

Enable the N dB BW measurement or set the value of N dB. The N dB BW denotes the frequency difference between two points that are located on both sides of the current marker and with N dB fall ( $N < 0$ ) or rise ( $N > 0$ ) in amplitude as shown in the figure on the next page.




Figure 2-11 N dB BW

When the measurement starts, the analyzer will search for the two points which are located at both sides of the current point with N dB fall or rise in amplitude and display the frequency difference between the two points in the active function area. "----" would be displayed if the search fails.

Table 2-30 N dB Noise

Parameter	Explanation
Default	-3 dB
Range	-100 dB to +100 dB
Unit	dB
Knob Step	0.1 dB
Direction Key Step	1 dB

#### 2.3.3.4 Freq Counter

Turn on or off the frequency counter. The frequency readout is accurate to 0.01 Hz.

- ◆ The function is valid only when selecting marker 1.
- ◆ If marker 1 is selected but not active, turning on the frequency counter will activate marker 1 Normal marker automatically.
- ◆ The frequency counter measures the frequency near the center frequency in Zero span. If the RBW is  $\geq 30\text{KHz}$ , the near center frequency is 30KHz. If the RBW is  $< 10\text{KHz}$ , the near center frequency is 10KHz. The RBW sequence is 1-3-10.

#### 2.3.3.5 Off

Turn off the noise marker, N dB BW measurement or Frequency Counter, but not the marker itself.

---

### 2.3.3.6 Read Out

Select a desired readout type for the X-axis for the marker. Different markers can use different readout types. This setting will change the readout type and affect the marker readings in the active function area and at the upper right corner of the screen, but will not change the actual value.

#### 1. Frequency

In this type, Normal marker shows the absolute frequency. Delta markers and Delta Pair markers show the frequency difference between the delta marker and reference marker. The default readout mode in non-zero span is **"Frequency"**.

**Note:** This type is invalid in Zero span.

#### 2. Period

In this type, the Normal marker shows the reciprocal of frequency; while Delta marker and Delta Pair marker show the reciprocal of frequency difference. When the frequency difference is zero, the reciprocal is infinite and 100 Ts is displayed.

**Note:** This type is invalid in Zero span.

#### 3. $\Delta$ Time

In this type, the Normal marker shows the time difference between the marker and the start of the sweep; while Delta marker and Delta Pair marker show the sweep time difference between the delta marker and reference marker.

The default readout mode in Zero span is  $\Delta$  Time.

## 2.3.4 Peak

Open the peak search setting menu and execute peak search.

### 2.3.4.1 Peak -> CF

Execute peak search and set the center frequency of the analyzer to the frequency of the peak.

### 2.3.4.2 Next Peak

Search for and mark the peak whose amplitude is closest to that of the current peak and which meets the peak search condition.

### 2.3.4.3 Next Left Peak

Search for and mark the nearest peak which is located at the left side of the current peak and meets the peak search condition.

---

#### 2.3.4.4 Next Right Peak

Search for and mark the nearest peak which is located at the right side of the current peak and meets the peak search condition.

#### 2.3.4.5 Peak Peak

Execute peak search and minimum search at the same time and mark the results with delta pair markers. Wherein, the result of peak search is marked with the delta marker and the result of minimum search is marked with the reference marker.

#### 2.3.4.6 Count Peak

Enable or disable continuous peak search. The default is Off. When enabled, the system will always execute a peak search automatically after each sweep in order to track the signal under measurement.

#### 2.3.4.7 Peak Table

Open the peak table (in the lower window) which lists the peaks (with frequency and amplitude) that meet the peak search condition. Up to 16 peaks can be displayed in the table.

#### 2.3.4.8 Search Config

Define the conditions of peak search for various peak searches. A real peak should meet the requirements of both the “**Peak Excursion**” and “**Peak Threshold**”.

##### 1. Peak Threshold

Assign a minimum for the peak amplitude. Peaks whose amplitudes are greater than the specified peak threshold are treated as real peaks.

Table 2-31 Peak Threshold

Parameter	Explanation
Default	-140 dBm
Range	-200 dBm - 200 dBm
Unit	dBm
Knob Step	1 dB
Direction Key Step	5 dB

##### 2. Peak Excursion

Set the excursion between the peak and the minimum amplitude on both sides of it. Peaks whose excursions are beyond the specified excursion are treated as real peaks.

---

Table 2-32 Peak Excursion

Parameter	Explanation
Default	15 dB
Range	0 dB - 200 dB
Unit	dB
Knob Step	1 dB
Direction Key Step	5 dB

### 3. Peak Type

Set the peak search condition. The available options are Maximum and Minimum.

---

## 2.4 Measurement

### 2.4.1 Meas

Provide optional measurement functions. When activated, the screen will be divided into two parts. The upper part is the measurement screen which displays traces, and the lower part is used to display measurement results.

#### 2.4.1.1 Channel Power

Measure the power and power density within the specified channel bandwidth. When this function is enabled, the span and resolution bandwidth are automatically adjusted to smaller values. Select **Channel Power** and press **Meas Setup** to set the corresponding parameters.

#### 2.4.1.2 ACPR (Adjacent Channel Power)

Measure the power of the main channel and adjacent channels as well as the power difference between the main channel and each of the adjacent channels. When this function is enabled, the span and resolution bandwidth of the analyzer are adjusted to smaller values automatically.

Select **ACPR** and press **Meas Setup** to set the corresponding parameters.

#### 2.4.1.3 Occupied BW (Occupied Bandwidth)

Integrates the power within the whole span and calculates the bandwidth occupied by this power according to the specified power ratio. The OBW function also indicates the difference (namely "Transmit Freq Error") between the center frequency of the channel under measurement and the center frequency of the analyzer. Select **Occupied BW** and press **Meas Setup** to set the corresponding parameters.

#### 2.4.1.4 T-Power (Time Domain Power)

The system enters Zero span and calculates the power within the time domain. The types of powers available include Peak, Average and RMS. Select **T-Power** and press **Meas Setup** to set the corresponding parameters.

#### 2.4.1.5 TOI (Third Order Intercept Point)

Automatic measurement of IP3 (Third Order Intercept Point), including the power of fundamental wave and the Third order in the power, and calculate the adjustable Intercept Point.

#### 2.4.1.6 Spectrum Monitor

Display the power of the swept spectrum as an intensity color map commonly referred to as a waterfall chart. Select **Spectrum Monitor** and press **Meas Setup** to set the corresponding parameters.

#### 2.4.1.7 CNR (Carrier to Noise Ratio)

Measure the power of the carrier and noise of the specified bandwidth and their ratio. Select **CNR** and press **Meas Setup** to set the corresponding parameters.

#### 2.4.1.8 Harmonics

The harmonic power and total harmonic distortion of carrier signal are measured. The maximum measurable harmonic is 10th harmonic. The fundamental wave amplitude of carrier signal must be greater than - 50 dBm, otherwise the measurement result is invalid. Select **Harmonics** and press **Meas Setup** to set the corresponding parameters.

#### 2.4.1.9 Meas Off

Turn off all the Meas functions.

### 2.4.2 Meas setup

#### 2.4.2.1 Channel Power




Figure 2-12 Channel Power

**Measurement Results:** Channel power and power spectral density.

- ◆ Channel Power: Power within the integration bandwidth.
- ◆ Power Spectral Density: Power (in dBm/Hz) normalized to 1Hz within the integration bandwidth.

**Measurement Parameters:** Center Freq, Integration BW, Span, Span power.

---

### 1. Center Freq

Set the center frequency, this center frequency which is the same with the center frequency of the analyzer. Modifying this parameter will change the center frequency of the analyzer.

### 2. Integration BW

Set the frequency width of the channel to be tested and the power of the channel is the power integral within this bandwidth. You can use the numeric keys, knob or direction keys to modify this parameter.

Table 2-33 Integration BW

Parameter	Explanation
Default	2 MHz
Range	100 Hz - Span
Unit	GHz, MHz, kHz, Hz
Knob Step	Integration BW/100, the minimum is 1 Hz
Direction Key Step	In 1-1.5-2-3-5-7.5 sequence

### 3. Span

Set the frequency range of the channel. This span which is the same with the span of the analyzer is the frequency range of the sweep. Modifying this parameter will change the span of the analyzer.

The channel power span is related to the integration bandwidth.

Table 2-34 Channel Power Span for Chan Power Measurement

Parameter	Explanation
Default	current span
Range	100 Hz - Span
Unit	GHz, MHz, kHz, Hz
Knob Step	Channel Power Span/100, the minimum is 1Hz
Direction Key Step	In 1-1.5-2-3-5-7.5 sequence

### 4. Span Power

Set the integrated bandwidth to the sweep span of the display. The channel power and power spectral density display on the screen simultaneously.



### 2.4.2.2 ACPR (Adjacent Channel Power)




Figure 2-13 ACPR

**Measurement Results:** Main CH Power, Left channel power and Right channel power.

- ◆ Main CH Power: Displays the power within the bandwidth of the main power
- ◆ Left channel power : Displays the power of left channel and the power difference between the left channel and the main channel (in dBc)
- ◆ Right channel power: Display the power of the right channel and the power difference between the right channel and the main channel(in dBc)

**Measurement parameter:** Center frequency, main channel bandwidth, adjacent channel bandwidth and channel spacing

#### 1. Center Freq

Set the center frequency. The center frequency is the same with the center frequency of the analyzer display. Modifying this parameter will change the center frequency of the analyzer.

#### 2. Main Channel

Set the bandwidth of the main channel and the power of the main channel is the power integral within this bandwidth.

Table 2-35 Main Channel

Parameter	Explanation
Default	1 MHz
Range	100 Hz - full span
Unit	GHz, MHz, kHz, Hz
Knob Step	Main Channel /10, the minimum is 1 Hz
Direction Key Step	In 1-1.5-2-3-5-7.5 Sequence

### 3. Adjacent Chn

Set the frequency width of the adjacent channels.

The adjacent channel bandwidth is related to the main channel bandwidth.

Table 2-36 Adjacent channel bandwidth

Parameter	Explanation
Default	1 MHz
Range	100 Hz - (full span - 2*100 Hz)
Unit	GHz, MHz, kHz, Hz
Knob Step	Adjacent Chn/10, the minimum is 1 Hz
Direction Key Step	In 1-1.5-2-3-5-7.5 Sequence

### 4. Adj Chn space

Set the difference between the center frequency of the main channel and the center frequency of the adjacent channels.

Adjusting this parameter will also adjust the distance between the upper/lower channel and the main channel.

Table 2-37 adjacent channel space

Parameter	Explanation
Default	3 MHz
Range	100 Hz - (full span - 100 Hz) /2
Unit	GHz, MHz, kHz, Hz
Knob Step	Adj Chn space /10, the minimum is 1 Hz
Direction Key Step	In 1-1.5-2-3-5-7.5 Sequence

#### 2.4.2.3 OBW (Occupied Bandwidth)




Figure 2-14 OBW

**Measurement Results:** occupied bandwidth and transmit frequency error.

- ◆ **Occupied Bandwidth:** Integrates the power within the whole span and then calculates the bandwidth occupied by the power according to the specified power ratio.
- ◆ **Transmit Frequency Error:** The difference between the center frequency of the channel and the center frequency of the analyzer.

#### 2.4.2.4 T-Power




Figure 2-15 T-Power

**Measurement Results:** T-Power

- ◆ T-Power: The power of the signal from the start line to the stop line.

**Measurement Parameter:** Center frequency, start line, stop line.

##### 1. Center Frequency

Set the center frequency, this center frequency which is the same with the center frequency of the analyzer. Modifying this parameter will change the center frequency of the analyzer.

##### 2. Start line

Set the left margin (in time unit) of T-Power measurement. The data calculated under this measurement is between the start line and stop line.

Table 2-38 start line

Parameter	Explanation
Default	0 s
Range	0 s - stop line
Unit	ks, s, ms, us, ns
Knob Step	Sweep time/751
Direction Key Step	In 1-1.5-2-3-5-7.5 Sequence

### 3. Stop line

Set the right margin (in time unit) of T-Power measurement. The data calculated under this measurement is between the start line and stop line.

Table 2-39 stop line

Parameter	Explanation
Default	900 us
Range	Start line - sweep time
Unit	ks, s, ms, us, ns
Knob Step	Sweep time /751
Direction Key Step	In 1-1.5-2-3-5-7.5 Sequence

#### 2.4.2.5 TOI




Figure 2-16 TOI

TOI is an automatic measurement. There are no user controlled parameters.

### 2.4.2.6 Spectrum Monitor




Figure 2-17 Spectrum Monitor

Display the power of spectrum of successive scans as a color map. Also known as a waterfall chart.

**Measurement Parameter:** Spectrogram, Restart.

1. **Spectrogram:** Sets the meas state of spectrum monitor.
2. **Restart:** clear the measurement and then restart it.

### 2.4.2.7 CNR




Figure 2-18 CNR

**Measurement Results:** C/N, Carrier Power, Noise Power.

- ◆ C/N: the ratio of Carrier Power to Noise Power.
- ◆ Carrier Power: the total power of the carrier bandwidth.
- ◆ Noise Power: the total power of the selected noise bandwidth.

**Measurement Parameter:** Carrier BW, Noise BW, Freq Offset.

### 1. Carrier BW

Set the bandwidth of the carrier to be measured.

Table 2-40 Carrier BW

Parameter	Explanation
Default	3 MHz
Range	$100 \text{ Hz} - (2 * \text{span} - 2 *  \text{Freq Offset}  - \text{Noise BW})$
Unit	GHz, MHz, kHz, Hz
Knob Step	Carrier BW /10, the minimum is 1 Hz
Direction Key Step	In 1-1.5-2-3-5-7.5 Sequence

### 2. Noise BW

Set the bandwidth of the noise to be measured.

Table 2-41 Noise BW

Parameter	Explanation
Default	3 MHz
Range	$100 \text{ Hz} - (2 * \text{span} - 2 *  \text{Freq Offset}  - \text{Carrier BW})$
Unit	GHz, MHz, kHz, Hz
Knob Step	Noise BW /10, the minimum is 1 Hz
Direction Key Step	In 1-1.5-2-3-5-7.5 Sequence

### 3. Freq Offset

Set the difference between carrier center frequency and noise center frequency.

Table 2-42 Freq Offset

Parameter	Explanation
Default	3 MHz
Range	$-(\text{span} - (\text{Carrier BW} + \text{Noise BW}) / 2) - (\text{span} - (\text{Carrier BW} + \text{Noise BW}) / 2)$
Unit	GHz, MHz, kHz, Hz
Knob Step	Freq Offset /10, the minimum is 1 Hz
Direction Key Step	In 1-1.5-2-3-5-7.5 Sequence

## 2.4.2.8 Harmonics




Figure 2-19 Harmonics

**Measurement Results:** each harmonic amplitude and total harmonic distortion of the carrier signal. The measurement can measure up to 10th harmonic.

### Measurement Parameter:

#### 1. Fundamental

Set the frequency of the fundamental waveform.

If the automatic mode is turned on, the fundamental waveform will be automatically found from the first scan.

If the automatic mode is turned off, the user can input the fundamental frequency manually.

#### 2. Freq Step

Set the harmonic step. In auto mode, the frequency of a harmonic is a multiple of the fundamental frequency.

#### 3. Harmonic Num

Set the total number of the harmonics to be measured.

Table 2-43 Harmonic Num

Parameter	Explanation
Default	10
Range	2 - 10
Unit	None
Knob Step	1
Direction Key Step	1

---

#### **4. Select Harmonic**

When "All" is selected, the trace shows the fundamental waveform and all harmonics in the sweep bandwidth.

When 1-10 is selected, the trace shows a zero span trace corresponding to the fundamental waveform or the measured harmonic.



---

# Chapter 3 Vector Network Analyzer

This chapter introduces in detail the function keys and menu functions of the front panel under the Vector Network Analyzer Mode.

Subjects in this chapter:

- ◆ Basic Settings
- ◆ Sweep and Functions
- ◆ Marker
- ◆ Measurement

---

## 3.1 Basic Settings

### 3.1.1 Frequency

#### 3.1.1.1 Center Freq

Set the center frequency of the current sweep.

Modifying the center frequency will modify both the start frequency and stop frequency when the span is constant (except when the start frequency or stop frequency reaches the boundary).

Table 3-1 Center Frequency

Parameter	Explanation
Default	755 MHz <sup>[1]</sup>
Range	10.00005 MHz - 1.49999995 GHz <sup>[2]</sup>
Unit	GHz, MHz, kHz, Hz
Knob Step	Span/200, min 1 Hz
Direction Key Step	Span/10, min 1 Hz
Related to	Start Freq, Stop Freq

#### 3.1.1.2 Start Freq

Set the start frequency of the current sweep. The start and stop frequencies are displayed at the bottom of the grid respectively.

Table 3-2 Start Freq

Parameter	Explanation
Default	10 MHz <sup>[3]</sup>
Range	10 MHz - 1.4999999 GHz <sup>[4]</sup>
Unit	GHz, MHz, kHz, Hz
Knob Step	Span/200, min 1 Hz
Direction Key Step	Span/10, min 1 Hz
Related to	Center Freq, Stop Freq

#### 3.1.1.3 Stop Freq

Set the stop frequency of the current sweep. The start and stop frequencies are displayed at the bottom of the grid respectively.

Table 3-3 Stop Freq

Parameter	Explanation
Default	1.5 GHz <sup>[5]</sup>
Range	10.0001 MHz - 1.5 GHz <sup>[6]</sup>
Unit	GHz, MHz, kHz, Hz
Knob Step	Span/200, min 1 Hz
Direction Key Step	Span/10, min 1 Hz
Related to	Start Freq, Center Freq

**Note:**

[1] - [6] Different models have different values. Please refer to the T3VNA Data Sheet.

## 3.1.2 Span

Switch to the Span Settings menu by pressing **Span** on the front panel. When entering the span menu, the “Span” is selected by default. Any change of this parameter will affect the frequency parameters and restart the sweep.

### 3.1.2.1 Span

Set the frequency range of the current sweep.

- ◆ The start and stop frequency vary with the span when the center frequency is constant.
- ◆ In vector network analysis mode, the minimum sweep span is 100 Hz, and zero span cannot be set.
- ◆ When the span is set to the maximum, the analyzer enters full sweep mode.

Table 3-4 Span

Parameter	Explanation
Default	Full Span
Range	100 Hz - Full Span
Unit	GHz, MHz, kHz, Hz
Knob Step	Span/200, min 1 Hz
Direction Key Step	In 1-2-5 sequence
Related to	Start Freq, Center Freq, Stop Freq

### 3.1.2.2 Full Span

Set the span of the analyzer to the maximum available frequency span.

### 3.1.2.3 Last Span

Set the span to the previous span setting.

---

### 3.1.3 Amplitude

Set the amplitude parameters of the analyzer. Through modifying these parameters, signals under measurement can be displayed in a proper mode for easier observation and minimum error.

#### 3.1.3.1 Auto Scale

Automatically adjust the grid scale and reference level of the currently selected trace to optimize the trace display.

#### 3.1.3.2 Auto Scale All

Automatically adjust the grid scale and reference level of all display traces to optimize the display of traces.

- ◆ After setting “Auto Scale All”, the grid scale and reference level of different traces may be different.
- ◆ In the left status bar of the screen, the grid scale and reference level of each trace are displayed below the trace mark.

#### 3.1.3.3 Scale

Set the vertical scale of each grid to adjust the range of amplitude that can currently be displayed. This value is also displayed in the left status bar of the screen.

Table 3-5 Scale/Div

Parameter	Explanation
Default	10 dB
Range	0.1 dB - 1000 dB
Unit	dB
Knob Step	0.1 dB - 1 dB, step = 0.01 dB 1 dB - 10 dB, step = 0.1 dB 10 dB - 100 dB, step = 1 dB 100 dB - 1000 dB, step = 10 dB
Direction Key Step	In 1-2-5 sequence

#### 3.1.3.4 Ref Level

Set the reference level to indicate the minimum value that the current grid can display. This value is also displayed in the left status bar of the screen.

Table 3-6 Ref Level

Parameter	Explanation
Default	0 dB
Range	-1000 dB - 1000 dB
Unit	dB
Knob Step	1 dB
Direction Key Step	10 dB

### 3.1.3.5 Ref Position

The vertical position of the currently selected trace in the screen can be adjusted by adjusting the reference position.

When set to 5, the reference level of the trace is in the middle of the screen, 0 is at the bottom of the screen grid, and 10 is at the top of the screen grid.

Table 3-7 Ref Position

Parameter	Explanation
Default	5 Div
Range	0 Div - 10 Div
Unit	Div
Knob Step	1 Div
Direction Key Step	1 Div

## 3.2 Sweep and Functions

### 3.2.1 BW

#### 3.2.1.1 IFBW

The VNA converts the received signal from its source to a lower intermediate frequency (IF). Reducing the IF receiver bandwidth reduces the effect of random noise on a measurement. However, narrower IF bandwidths cause longer sweep times.

The default value 10 kHz.

### 3.2.2 Trace

#### 3.2.2.1 Select Trace

Select the trace in order to set the corresponding trace parameters. You can also select the trace by clicking on the trace mark displayed in the left status bar of the screen. By default, track 1 is selected and opened.

---

When the trace is selected, the background color will appear on the trace mark of the left status bar on the screen.

- ◆ The number of traces that can be selected is affected by the "Num of Traces" parameter. For example, if you set the "Num of Traces" to 3, traces 1 through 3 can be selected.

### 3.2.2.2 Num of Traces

Set the upper limit of displayed trace numbers. Up to four traces can be displayed simultaneously in the screen window.

### 3.2.2.3 Display

Set the display content of the currently selected trace:

- Data  
Only display the measured data.
  - Memory  
Only display the memory trace. A [M] icon is displayed in the left status bar of the screen.
  - Data & Mem  
Display both the measured data and the memory trace. A [D&M] icon is displayed in the left status bar of the screen.
  - Trace Off  
Neither the measured data nor the memory trace is displayed.
- ◆ "Data -> Mem" operation is needed before trace can display memory data. If "Data -> Mem" is not performed first, the two options of "Memory" and "Data & Mem" are grey and not optional.

### 3.2.2.4 Data -> Mem

Store the measured data in memory.

After "Data -> Mem" is executed, the selected trace for which measured data is displayed is provided with an additional trace, called a memory trace, that temporarily stores measured data.

When selecting the trace to display "Memory" or "Data & Mem", the memory trace is displayed in the screen. The memory trace is slightly thinner than the data trace.

Memory trace can be used as a reference for the data trace.




Figure 3-1 data trace & memory trace

### 3.2.2.5 Trace Hold

#### 1. Max

Retain the maximum level for each point of the selected trace. Update the data if a new maximum level is detected in successive sweeps.

#### 2. Min

Display the minimum value from multiple sweeps for each point of the trace and update the data if a new minimum is generated in successive sweeps.

#### 3. Off

Erases any data previously stored in the selected trace, and display the data sampled in real-time of each point on the trace.

#### 4. Restart

When select max or min trace hold, the operation "Restart" can empty the trace data and restart the max or min trace hold.

### 3.2.2.6 Math

After "Data -> Mem" is executed, you can perform complex data math between the memory trace and measured data.

The following data math operations are available:

#### 1. Data/Mem

Divide the measured data by the data in the memory trace. This function can be used to evaluate the ratio of two traces (e.g., evaluating gain or attenuation).

---

## 2. Data\*Mem

Multiply the measured data by a memory trace.

## 3. Data-Mem

Subtract a memory trace from the measured data. This function can be used, for example, to subtract a vector error that has been measured and stored (e.g., directivity) from data subsequently measured on a device.

## 4. Data+Mem

Add the measured data and the data in the memory trace.

## 5. Off

Turn off the math operations.

- ◆ "Data -> Mem" must be performed first to select math operations.
- ◆ Trace math operations are mutually exclusive, that is, when a math function is applied to a trace, the last selected math function will be turned off.

### 3.2.2.7 Average

Turn on or off the average function of traces, and set the average times.

More averages can reduce the noise and the influence of other random signals; thus highlighting the stable signal characteristics. The larger the averages times is, the smoother the trace will be.

Table 3-8 Average Times

Parameter	Explanation
Default	100
Range	1 - 999
Unit	N/A
Knob Step	1
Direction Key Step	10

## 3.2.3 Sweep

### 3.2.3.1 Points

The number of points is the number of data items collected in one sweep.

- ◆ To obtain a higher trace resolution against the stimulus value, choose a larger value for number of points.
- ◆ To obtain higher throughput, keep the number of points to a smaller value within an allowable trace resolution.



- 
- ◆ To obtain higher measurement accuracy after calibration, perform calibration using the same number of points as in actual measurements.

Table 3-9 Points

Parameter	Explanation
Default	201
Range	101 - 751
Unit	N/A
Knob Step	1
Direction Key Step	50

### 3.2.3.2 Sweep

Set the sweep mode in single or continuous, the default is continuous.

#### 1. Single

Set the sweep mode to “Single”. Every time the “Single” key is pressed, a sweep is performed.

#### 2. Continue

Set the sweep mode to “Continue”. In continuous sweep mode, the system will automatically enter into next sweep directly after each sweep.

### 3.2.4 TG

Set the signal amplitude of **[PORT 1]** output.

## 3.3 Marker

### 3.3.1 Marker

The marker can be used in the following ways:

- Reading a measured value as numerical data (as an absolute value or a relative value from the reference point).
- Moving the marker to a specific point on the trace (marker search).
- Analyzing trace data to determine a specific parameter.

The analyzer is capable of displaying up to 4 markers including the reference marker on each trace. Each marker has a stimulus value (the value on the X-axis in rectangular display format) and one or two response value (the value on the Y-axis in rectangular display format). The Smith chart and polar formats each have two marker response values (log amplitude and phase). And the Phase format has two marker response values (phase and expanded phase) as well.

### 3.3.1.1 Select Trace

The same function as in **Trace** -> "Select Trace", please refer to section 3.2.2.1.

### 3.3.1.2 Select Marker

Select one of the four markers. The default is Marker1. When a marker is selected, you can set its type, trace to be marked and other related parameters. The enabled marker will appear on the trace selected through the **Select Trace** option and the readouts of this marker are also displayed in the active function area and at the upper right corner of the screen.

- ◆ The current active marker is a filling diamond mark, while the non-active marker is an unfilled diamond mark. On the left side of the current active marker in the upper right corner of the screen, the ">" sign appears.
- ◆ When marker R is opened, whether it is currently active or not, the upper right corner of the screen will display its reading.




Figure 3-2 Marker

### 3.3.1.3 Normal

The same function as in **Marker** -> "Normal" in Spectrum Analyzer Mode, please refer to section 2.3.1.3.

### 3.3.1.4 Delta

The same function as in **Marker** -> "Delta" in Spectrum Analyzer Mode, please refer to section 2.3.1.4.

### 3.3.1.5 Off

The same function as in **Marker** -> "Off" in Spectrum Analyzer Mode, please refer to section 2.3.1.6.

### 3.3.1.6 Discrete

Turning on discrete mode, a marker moves only between actual measurement points. When a specific marker stimulus value is specified as a numerical value, the marker is placed at the measurement point closest to the specified value. A marker placed between the interpolated points with the discrete mode off automatically moves to the nearest measurement point when the discrete mode is turned on.

Turning off discrete mode, the marker can move from one actual measurement point to another. Because it is interpolated, it can also move in the space between measurement points.

### 3.3.1.7 Couple

When Marker Couple is on, Markers are set up and moved in coupled operation on all traces.

When Marker Couple is off, Markers are set up and moved independently from each trace.




Figure 3-3 Marker Couple is ON




Figure 3-4 Marker Couple is OFF

### 3.3.1.8 All Off

Turn off all the markers of all traces.

## 3.3.2 Peak

### 3.3.2.1 Select Trace

The same function as in **Trace** -> "Select Trace", please refer to section 3.2.2.1.

### 3.3.2.2 Select Marker

The same function as in **Marker** -> "Select Marker", please refer to section 3.3.1.2.

### 3.3.2.3 Peak

Search the greatest measured value of the trace.

### 3.3.2.4 Valley

Search the smallest measured value of the trace.

---

## 3.4 Measurement

### 3.4.1 Stimulus

Set the stimulus conditions, including the sweep range and the number of points. In **Frequency**, **Span** and **Sweep** menu, there are corresponding settings parameters.

### 3.4.2 Meas

Select S11 or S21 as the current measurement item. This value is also displayed in the status bar on the left side of the screen.

### 3.4.3 Format

Set the display type of measurement result, enter “Format” submenu, and select the corresponding display type. This value is also displayed in the status bar on the left side of the screen.

#### 1. Log Mag

The trace represents the logarithmic magnitude of the measurement result, unit: dB.

#### 2. Phase

The trace represents the phase of the measurement result, displayed in range from  $-180^{\circ}$  to  $+180^{\circ}$ , as well as the expanded phase, can be displayed above  $+180^{\circ}$  and below  $-180^{\circ}$ . Unit: degrees ( $^{\circ}$ ).

#### 3. Group Delay

The trace represents the transmission delay of the signal through the DUT. Unit: seconds (s).

#### 4. Smith

The Smith chart format is used to display impedances based on the reflection measurement data of the DUT. In this format, traces are plotted at the same spots as in the polar format. The Smith chart format allows users to select one of the following five data groups for displaying the marker response values.

- Linear magnitude and phase ( $^{\circ}$ )
- Log magnitude and phase ( $^{\circ}$ )
- Real and imaginary parts
- Resistance (ohm), Reactance (ohm), and inductance (H) or capacitance (F)
- Conductance (S), susceptance (S), and capacitance (F) or inductance (H)

#### 5. Polar

In the polar format, traces are drawn by expressing the magnitude as a displacement from the origin (linear) and phase in an angle counterclockwise from the positive X-axis. This data format does not have a stimulus axis, so frequencies must be read by using the marker. The polar format allows users to select one of the following three data groups for displaying the marker response values.

- Linear magnitude and phase (°)
- Log magnitude and phase (°)
- Real and imaginary parts

## 6. Lin Mag

The trace represents the linear magnitude of the measurement result, units: 1.

## 7. SWR

The trace represents  $(1+p) / (1-p)$ , where  $p$  is the reflection coefficient, units: 1.

### 3.4.4 Scale

Press the “Scale” key to open the **Amplitude** menu.

### 3.4.5 Trace

Press the “Trace” key to open the **Trace** menu.

### 3.4.6 Calibration

Set calibration related items. The calibration status is displayed in the upper left corner of the screen.

The calibration status and display are as follows:

No calibration data	--- (displayed in gray)
Calibrated	Cor (displayed in blue)
Correction Off	Off (displayed in gray)
Need to re-calibrate	C? (displayed in blue)

**Note:** The calibration status is shown as “C?” which indicates that the scan frequency range is different from the time of calibration. Users need to re-calibrate in the current scan frequency range.

When performing calibration, the calibration wizard pops up. Please follow the calibration wizard to perform calibration. After completing the calibration step, the calibration data is automatically saved as user calibration data. Turn on the calibration switch and the error correction function will be enabled.




Figure 3-5 Calibration Wizard

---

### 3.4.6.1 Correction

Turn the calibration on or off.

### 3.4.6.2 Calibrate

#### 1. 1-Port Cal

Calibrate with the specified physical calibration kit, with connections of an OPEN standard, a SHORT standard, and a LOAD standard to the **[Port 1]**. This calibration effectively eliminates the frequency response reflection tracking error, directivity error, and source match error from the test setup in a reflection test using that port.

This function is only available when the measurement item is S11.

Calibration data is saved as user calibration data.

#### 2. Response Through

When operating, connect the port 1 and port 2 of the analyzer with an optional Through Adapter. The normalization operation moves the measurement reference plane to both ends of the Through Adapter. This function is only available when the measurement item is S21. Enter the normalized submenu to make the appropriate selection.

### 3.4.6.4 Cal Kit

Specify the calibration kit used for mechanical calibration.

- Supplied Calibration Kit: Type-N 50Ω 4.5 GHz Cal Kit (Calibration Kit supplied with the T3VNA)
- 85032F: Type-N 50Ω 9 GHz Cal Kit (KeySight)
- 85032B/E
- User

Before executing calibration, you need to select a calibration kit.

If you use a calibration kit other than a predefined one, you need to define it. If the connector type of the standard of the calibration kit you use has polarity (the distinction between male and female), you need to change the standard class definition of the calibration kit depending on the standard you actually use.

### 3.4.6.5 Port Extensions

When extending the calibrated plane to other planes (i.e. port extension) instead of the standard calibration process, the port extension function can be used to compensate for the delay (phase shift) caused by fixtures and other possible losses.

---

## 1. Extensions

Port extensions mathematically compensate data for any known phase shift/delay and amplitude errors caused by fixtures or additional circuit elements that cannot be removed by calibration. Common examples include test fixturing that is required to use a particular circuit element or device.

When port extensions are enabled, the “P” icon will be displayed near the calibration status in the upper-left portion of the screen. The default setting is Close (off).

## 2. Delay Port1

Set the delay of Port1 extension.

The relationship between Port Delay and Port Length is as follows:

$$\text{Port Length} = \text{Port Delay} * c0 * \text{Velocity Factor, where } c0=299792458\text{m/s}$$

## 3. Length Port1

Set the length of Port1 extension.

## 4. Delay Port2

Set the delay of Port2 extension.

## 5. Length Port2

Set the length of Port2 extension.

## 6. Auto Open Port1

Automatically calculate the delay and length of Port1.

### 3.4.6.6 System Z0

Set the System characteristic impedance (Z0).

### 3.4.6.7 Velocity Factor

Set the velocity factor of the cable to be measured relative to the speed of light in vacuum. Make sure that the velocity factor of the cable to be measured conforms to the reality.

Table 3-10 Velocity Factor

Parameter	Explanation
Default	0.66
Range	0.1 - 1
Unit	N/A
Knob Step	0.01
Direction Key Step	In 1-2-5 sequence



---

# Chapter 4 Distance-To-Fault Mode

This chapter introduces in detail the function keys and menu functions of the front panel under the Distance-To-Fault Mode.

## 4.1 Measurement

### 4.1.1 Disp Mode

Entering "Disp Mode" sub-menu, then choose from the following three types of display. This value is also displayed in the status bar on the left side of the screen.

- ◆ Return Loss
- ◆ VSWR
- ◆ Reflection Coefficient

All three forms reflect the matching condition of the entire cable.

Table 4-1 Return Loss (RL), VSWR, and Reflection Coefficient ( )

Parameter	Conversion relationship
RL	$RL = -20 * \log_{10}( \Gamma )$
VSWR	$VSWR = (1 +  \Gamma )/(1 -  \Gamma )$

### 4.1.2 Start Distance

Set the starting distance for DTF.

The range of this distance is limited by the minimum resolution.

Table 4-2 Start Distance

Parameter	Explanation
Default	0.00 m
Range	0.00 m - (Stop Distance – 0.2) m
Unit	m, feet
Knob Step	0.1 m
Direction Key Step	In 1-2-5 sequence(Unit: m)

### 4.1.3 Stop Distance

Set the stopping distance for DTF.

The range of this distance is limited by the velocity factor and is proportional to the velocity factor.

When the velocity factor is 1, the length that can be measured is the maximum.

Selecting the appropriate frequency span (= start freq – stop freq) is not as obvious as it may seem. The resolution and maximum distance range are dependent upon the span, the number of frequency data points and the velocity factor of the cable. Therefore, the frequency span must be chosen carefully.

There is a constraint that limits the frequency range:

$$\text{Maximum Distance (meters)} = \frac{7.68 \times 10^{10} \times \text{velocity factor}}{\text{Start freq} - \text{stop freq (Hz)}}$$

The wider the span is, the smaller the maximum distance that can be measured. In another words, long distance measurements require small span settings.

Meanwhile, there is also a relationship between resolution and the span.

$$\text{Resolution (meters)} = \frac{1.5 \times 10^8 \times \text{velocity factor}}{\text{Start freq} - \text{stop freq (Hz)}}$$

The wider the span, the smaller the resolution; wider frequency sweeps improve the resolution of DTF measurements.

Table 4-3 Stop Distance

Parameter	Explanation
Default	34.00 m
Range	0.2 m - 34.00 m
Unit	m, feet
Knob Step	0.1 m
Direction Key Step	In 1-2-5 sequence(Unit: m)

#### 4.1.4 Unit

Set the display units for the fault point distance, including the following two units. This value is also displayed in the status bar on the left side of the screen.

- ◆ Meter
- ◆ Feet

The default unit is "Meter".

#### 4.1.5 Velocity Factor

Set the velocity factor of the cable to be measured with respect to the speed of light in a vacuum. Make sure that the velocity factor of the cable to be measured matches the actual value. Otherwise, the position of the positioning point obtained from the measurement does not meet the actual requirements.

This value is also displayed in the status bar on the left side of the screen.

Table 4-4 Velocity Factor

Parameter	Explanation
Default	0.66
Range	0.1 - 1
Unit	N/A
Knob Step	0.01
Direction Key Step	In 1-2-5 sequence

### 4.1.6 Cable Atten

Set the attenuation factor of the cable-under-test. It is used to compensate the amplitude of peaks in different positions. The DTF calculates the peaks by the final receiving data which has been attenuated by the cable, thus the amplitude of peaks cannot show exactly where the mismatch position is. So the cable atten is used to compensate by length.

Table 4-5 Cable Atten

Parameter	Explanation
Default	0.00 dB/m
Range	0.00 dB/m - 5.00 dB/m
Unit	dB/m

### 4.1.7 Window

Set the window function used in DTF.

The use of a non-rectangular window function can improve the side lobe effect of the analysis. The vertical axis is more accurate, but the horizontal axis resolution is reduced.

In the sub-menu, the following three settings can be selected.

- ◆ Off
- ◆ Rectangular
- ◆ Hamming

The default state is "Off"; this value is also displayed in the status bar on the left side of the screen.

Table 4-6 Window function properties

Win-type	Expression	Main lobe width
Rectangular	$0 \leq k \leq M, \omega[k] = 1; , \omega[k] = 0$	$4\pi/N$
Hamming	$0 \leq k \leq M, \omega[k] = 0.54 - 0.46 \cos\left(\frac{2\pi k}{M}\right); \text{else, } \omega[k] = 0$	$8\pi/N$

### 4.1.8 Calibration

Set calibration related items. The calibration status is displayed in the upper left corner of the screen.

The calibration status and display are as follows:

---

No calibration data	---	(displayed in gray)
Calibrated	Cor	(displayed in blue)
Need to re-calibrate	C?	(displayed in blue)

**Note:** The calibration status is shown as “C?” which indicates that the scan frequency range is different from the time of calibration. Users need to re-calibrate in the current scan frequency range.

### 1. Correction

Turn on or off the calibration.

### 2. Calibrate

Calibrating with the specified mechanical calibration requires three loads: open, short, and match. Calibration data is saved as user calibration data.

### 3. Cal kit

Specify the calibration kit used for mechanical calibration.

---

# Chapter 5 Modulation Analyzer

This chapter introduces in detail the function keys and menu functions of the front panel under the Modulation Analyzer Mode.

This mode enables modulation analysis of incoming signals. Modulation types are as follows:

- AM analog modulation
- FM analog modulation
- ASK digital modulation
- FSK digital modulation
  - 2FSK, 4FSK, 8FSK, 16FSK
- MSK digital modulation
- PSK digital modulation
  - BPSK, QPSK, 8PSK, DBPSK, DQPSK, D8PSK, Pi/4 DQPSK, Pi/8 D8PSK, OQPSK
- QAM digital modulation
  - 16QAM, 32QAM, 64QAM, 128QAM, 256QAM

**Meas** menu may be different in different modulation types.

The modulation type can be re-selected by pressing the **Meas** key.

Subjects in this chapter:

- ◆ Basic Settings
- ◆ Measurement
- ◆ Sweep and Functions

---

## 5.1 Basic Settings

### 5.1.1 Frequency

Switch to the Frequency Settings menu by pressing **Frequency** on the front panel. When entering the frequency menu, the “Center Freq” is selected by default.

#### 5.1.1.1 Center Freq

Set the modulated carrier frequency.

Table 5-1 Center Freq

Parameter	Explanation
Default	100 MHz
Range	Full Span
Unit	GHz, MHz, kHz, Hz
Knob Step	Freq Step/10
Direction Key Step	Freq Step

#### 5.1.1.2 Freq Step

Setting the value of Freq Step will change the direction key step and knob step of the center frequency.

Table 5-2 Freq Step

Parameter	Explanation
Default	10 kHz
Range	1 Hz - 100 MHz
Unit	GHz, MHz, kHz, Hz
Knob Step	Freq Step/10, min 1 Hz
Direction Key Step	In 1-2-5 sequence

## 5.2 Measurement

### 5.2.1 Digital Modulation Analysis

When ASK, FSK, MSK, PSK or QAM modulation type is selected, digital modulation analysis is carried out.

#### 5.2.1.1 Format

Select the modulation format.

---

### 5.2.1.2 Symbol Rate

Set the symbol rate of the signal to be analyzed. Press **Meas Setup**, then select "Symbol Rate", you can input the symbol rate and change the symbol rate by the knob.

Table 5-3 Symbol Rate

Parameter	Explanation
Default	10 ksps
Range	1 ksps - 2.5 Msps
Unit	Msps, ksps, sps
Knob Step	Symbol Rate/10
Direction Key Step	In 1-2-5 sequence

### 5.2.1.3 Points/Symbol

Set the points/symbol of the modulated signal.

### 5.2.1.4 Meas Length

Set the number of symbols which will be used in calculating the measurement. As the length is longer, the range for statistics is bigger, and the measure time is longer.

Table 5-4 Meas Length

Parameter	Explanation
Default	128
Range	16 - 4096
Unit	1
Knob Step	1
Direction Key Step	Current value of Meas Length

### 5.2.1.5 Filter Setup

After entering into the "Filter Setup" sub-menu, you can choose the relative parameters of filters.

#### 1. Measure Filter

- ◆ Sqrt Nyquist
- ◆ Nyquist
- ◆ Gauss
- ◆ Half Sine
- ◆ Off

#### 2. Reference Filter

- ◆ Sqrt Nyquist
- ◆ Nyquist

- ◆ Gauss
- ◆ Half Sine
- ◆ Off

**Note: The rule of common filter type selected**

Transmitter Filter	Measure Filter	Reference Filter
Sqrt Nyquist	Sqrt Nyquist	Nyquist
Nyquist	Off	Nyquist
Gauss	Off	Gauss
Half Sine	Off	Half Sine

### 3. Filter Alpha/BT

- ◆ For Sqrt Nyquist and Nyquist filter settings, you can set the alpha parameter. It can be set the same as the transmitter.
- ◆ For a Gauss filter, use the BT parameter. It can be set the same as the transmitter.

Table 5-5 Filter Parameter

Parameter	Explanation
Default	0.35
Range	0 - 1
Unit	1
Knob Step	0.01
Direction Key Step	0.1

### 4. Filter Length

Set the symbols number of the filter selected. It can be set the same as the transmitter.

Table 5-6 Filter Length

Parameter	Explanation
Default	64
Range	2 - 128
Unit	1
Knob Step	1
Direction Key Step	5

#### 5.2.1.6 Statistic

##### 1. Statistic

Turn on the statistical function, the measurement result will show the maximum and minimum of statistics. Turn off the statistical function, the measurement result will only show the real-time measurement value. Statistical function is turned off by default.



---

## 2. Avg

Open and close the average option for the measurement result. It can set the average number. When the Avg Number is set to off, the column title "Average" in numerical results view will be changed to "Current". The "Average" measurement result will be stable if the average number is set to larger values.

Table 5-7 Avg Number

Parameter	Explanation
Default	10
Range	1 - 1000
Unit	1
Knob Step	1
Direction Key Step	10

## 3. Restart Meas

After this function is performed, the statistics will be cleared and restarted. If the average function is turned on, the average calculation of measurement results will be cleared and restarted as well.

### 5.2.1.7 Trace

The displayed data and format in the measurement windows can be set in **Trace** menu.

#### 1. Select Trace

Select the trace in order to set the corresponding trace parameters. You can also select the trace by clicking on the trace mark displayed in the left status bar of the screen.

#### 2. Num of Traces

Set the upper limit of displayed trace numbers. Up to four traces can be displayed simultaneously in the screen window.

#### 3. Layout

Select the layout of the screen windows. The layout types are as follows:

- Single
- Stacked 2
- Grid 1,2
- Grid 2x2

#### 4. Data

Select the displayed data of the trace.

#### 5. Format

Select the displayed format of the trace.

---

## 6. Copy to

Copy the currently selected trace to another trace.

## 7. Properties

Eye Length

Set the length of the Eye diagram.

Symbol Table

Display the demodulation digital symbols (binary or hex).

## 5.2.2 Analog Modulation Analysis

When AM or FM modulation type is selected, analog modulation analysis is carried out.

### 5.2.2.1 IFBW

After entering into the mode AM or FM modulation analysis, set the intermediate frequency bandwidth (IFBW).

Press **Meas Setup**, you can set the "IFBW" again.

It specifies the IFBW of the signal to be analyzed. The measurement accuracy will be impacted if this value isn't set precisely. The IFBW should be as narrow as possible to improve the S/N ratio.

For AM modulation analysis, the IFBW should be larger than twice the modulation frequency. For FM modulation analysis, the IFBW should be larger than twice the sum of the deviation frequency and the modulation frequency.

Table 5-8 IFBW

Parameter	Explanation
Default	1.2 MHz
Range	1.2 MHz, 960 kHz, 600 kHz, 480 kHz, 300 kHz, 240 kHz, 120 kHz, 96 kHz, 60 kHz
Unit	MHz, kHz
Knob Step	Change to the next enumeration value
Direction Key Step	Change to the next enumeration value

### 5.2.2.2 EqLFP

After entering into the mode AM modulation analysis or FM modulation analysis, set the equivalent low pass filter (EqLFP).

Press **Meas Setup**, you can set the "EqLFP" again.

It specifies the EqLFP bandwidth of the signal to be analyzed. The measurement accuracy will be impacted if this value isn't set precisely. The EqLFP is an additional low pass filter. It can conveniently

---

measure the lower modulation frequency signal. The EqLPF bandwidth should be as narrow as possible to improve the S/N ratio, but also need to be larger than the modulation frequency.

Table 5-9 EqLPF

Parameter	Explanation
Default	IFBW/6
Range	Off, IFBW/6, IFBW/20, IFBW/60, IFBW/200, IFBW/600, IFBW/2000
Unit	kHz、Hz

### 5.2.2.3 Average

Open and close the average option for the measurement result. It can set the average number. When the Avg Number is set to off, the column title "Average" in numerical results view will be changed to "Current". The "Average" measurement result will be stable if the average number is set to larger values.

Table 5-10 Avg Number

Parameter	Parameter
Default	10
Range	1 - 1000
Unit	1
Knob Step	1
Direction Key Step	10

### 5.2.2.4 Restart Meas

After this function is performed, the statistics will be cleared and restarted. If the average function is turned on, the average calculation of measurement results will be cleared and restarted as well.

## 5.3 Sweep and Functions

### 5.3.1 Trigger

Press **Trigger** to open the menu. The analyzer will begin a sweep only when the selected trigger conditions are met. A trigger event is defined as the point at which your trigger source signal meets the specified trigger level.

- ◆ Free Run: New sweep starts as soon as possible after the current sweep ends.
- ◆ RF Trigger: Activates the trigger condition that starts the next sweep if the detected RF envelops voltage rises to a level set by the RF trigger level.
- ◆ External: The trigger event is the rising or falling edge of the external trigger signal.

---

### 5.3.2 Sweep

Select "single" or "continue" type for sweep. Press **Sweep** in the menu. When "single" sweep type is selected a new sweep will take place immediately after the 'single' sweep button is pressed if the sweep trigger event is met. The sweep will not take place if the trigger event is not met.

- ◆ Single Sweep
- ◆ Continue Sweep

---

# Chapter 6 System Settings

## 6.1 System

### 6.1.1 Language

The analyzer supports a multi-language menu, Chinese and English built-in help and popup messages. Press this key to select the desired display language.

### 6.1.2 Power On/Preset

#### 6.1.2.1 Power On

Set the power on setting to Default, Last or User.

- ◆ **Def:** Load the default settings, for more details please refer to Table 6-3.
- ◆ **Last:** When Last is selected, instrument settings before the last power-off are recalled automatically at power on.
- ◆ **User:** If power on is set to user, the device will recall the specified configuration after power on.

#### 6.1.2.2 Preset

Set the preset type to Default, Last or User.

- ◆ **Def:** Loads the default settings, for more details please refer to Table 6-3.
- ◆ **Last:** Loads the last power-off settings.
- ◆ **User:** Loads the specified user configuration type.

#### 6.1.2.3 User Config

Save the current instrument settings as user-defined setting into the internal non-volatile memory.

#### 6.1.2.4 Factory Reset

When **Factory Reset** is selected, the device will recall the initial config.

#### 6.1.2.5 Reset & Clear

When **Reset & Clear** is selected, the device will recall the initial config and all user data and settings will be erased.

#### 6.1.2.6 Power on Line

Set whether the instrument will start automatically after power-on. Default does not automatically start.

## 6.1.3 Interface

The analyzer supports communications through LAN and USB as standard remote computer control interfaces.

### 6.1.3.1 LAN

Configure the related parameters of the LAN connection as "Static" or "DHCP". As a default, the IP config is DHCP.

- ◆ Statically setting LAN parameters requires pressing the "Apply" button to make LAN parameters effective.
- ◆ When "DHCP" is pressed, the LAN parameters are dynamically allocated.

The LAN status icon will be displayed in the upper right corner of the screen if the cable is connected.




Figure 6-1 LAN Config

### 6.1.3.2 GPIB

GPIB is not supported on the T3VNA product family.

### 6.1.3.3 Web Server

Set web page parameters to use VNC.

#### 1. Port

The port number can be set to 5900-5999. When the port number is set beyond the range, a prompt pops up at the bottom of the screen, and the port number is automatically set to the maximum or minimum value.

After modifying the port number, VNC needs to be reopened.

---

## 2. Password

Set the password for login VNC.

## 3. View Only

Set whether the analyzer is in view-only mode on VNC.

When the view-only mode is turned on, the analyzer can only be viewed and cannot be operated on VNC. When the view-only mode is turned off, the analyzer can be viewed and operated simultaneously on VNC.

After modifying the view-only mode, VNC needs to be restarted.

## 6.1.4 Calibration

### 6.1.4.1 Auto Cal

Set whether to turn on the auto calibration or not and turn off by default. When Auto Cal is turned on, the analyzer will process self-calibration according to the temperature difference. Half an hour after startup, the device will query temperature every minute. If the temperature difference is greater than 2°, the device will be self-calibrated.

## 6.1.5 System Info

### 6.1.5.1 System Info

- Product Model, Serial and HOST ID
- Software Version and Hardware Version
- Option Information

System Info

Product Info:

Model	T3VNA1500
Serial	T0101XCAC2R0006
Host ID	B302B010183A4781

Version:

SW1	01.2.1.2.2R0
SW2	20190308-1
SW3	000000C9
HW	01.01.00

Option:

AMK	Sta: On	Valid: Permanent
EMI	Sta: On	Valid: Permanent
TG	Sta: On	Valid: Permanent
DMA	Sta: On	Valid: Permanent
AMA	Sta: On	Valid: Permanent
DTF	Sta: On	Valid: Permanent
VNA	Sta: On	Valid: Permanent

Figure 6-2 System Info

### 6.1.5.2 Load Option

Press “Load Option” and then enter the sequence code in the pop-up box to load the options. Options can also be loaded by loading License files in **File** ->”Open/Load”.




Figure 6-3 Load Option

### 6.1.5.3 Firmware Update

Press “Firmware Update” and you will enter into the **File** menu. Then you can select \*.ADS file from memory to upgrade firmware. After firmware upgrade, the machine will restart.




Figure 6-4 Firmware Update

### 6.1.5.4 System Message

Display system alarms and warnings.

## 6.1.6 Date and Time

Set system time, and the display status and display format of system time. System time can be set to "ymd", "mdy" or "dmy" formats.

System time is displayed in "ymd" format in the middle of the status bar by default.



---

## 6.1.7 Self Test

### 1. Screen Test

Test whether the screen has any pixel defects by displaying five colors: White, Red, Green, Blue and Black. Press 'Preset' key to switch the screen color and press '←' key to exit the test.

### 2. Keyboard Test

Enter the keyboard test interface. Press the function keys at the front panel one-by-one and observe whether the corresponding key is checked. If not, an error may have occurred in that key. To exit the test, press '←' four times.

### 3. LCD Test

If the keys at the front panel are transparent, when the key is pressed, the corresponding backlight will turn on when testing it.

### 4. Touch Test

Test whether the touch screen has any defects by touching the test button at specific spots on screen.

## 6.2 Display

Control the display of the screen.

### 6.2.1 Grid Brightness

Control the display grid brightness.

Table 6-1 Grid brightness

Parameter	Explanation
Default	30%
Range	0 - 100%
Unit	None
Knob Step	1%
Direction Key Step	1%

### 6.2.2 Screenshot

Toggle between normal and inverse color for images of the display saved to storage.

The color of traces is not inversed in inverse mode.




Figure 6-5 Inverse color Screenshot

## 6.2.3 Touch Settings

You can turn on or off touch screen settings and touch assistance.

Touch assistance can be moved to any position on the screen after the touch screen settings are opened.




Figure 6-6 Touch assistance

---

## 6.2.4 Power Saving

After setting the power saving, the screen backlight can be turned off when there is neither touch screen operation nor button operation for a certain period of time. The screen backlight will be turned on after a touch screen operation or button operation.

## 6.2.5 Annotation

If turn on the annotation function, you can add annotations on the screen.



Figure 6-7 Annotation

Typical operation sequence is:

- ◆ Turn on the annotation function: you could activate the annotation function in the Display menu, or toggle the status of the function using the touch assistant.
- ◆ Edit text: Click the input area to invoke the virtual keyboard. Use the virtual keyboard or the keys in the Edit area on the front panel to enter text. During the editing, you could change the color and size of the text using the color label and font size label respectively. Moreover, you could change the size of the input area by dragging the two-way arrows on the top and right.
- ◆ (Optional) Add or delete annotation by clicking the plus sign button and cross sign button. You could add as many as ten annotations. When you delete the last one, it was not really deleted. In fact, the annotation function is turned off.
- ◆ Finish editing: click Enter or Esc button on the virtual keyboard to close the keyboard. Now you could click in the blank space of the annotation widget and drag it to any places on the screen. Click the tick button, only the text would be visible and an annotation is successfully added.

If you want to change one of the annotations, click the text and you could repeat the operation above. Notice that if you change the mode of the analyzer or shut off the analyzer, all the annotations would be removed. Toggling the status of the annotation function won't do that, however.

## 6.2.6 Display Line

Open or Close Display Line or move the location. The display line can be used as a reference for reading.

Table 6-2 Display Line

Parameter	Explanation
Default	0 dBm
Range	REF Level + REF Offset – 10*Scale/Div - REF Level + ref Offset
Unit	dBm
Knob Step	1
Direction Key Step	Scale/Div

## 6.3 File

### 6.3.1 Browser

Browser type including “Dir” and “File”,

**Dir:** When selected, use the knob or direction keys to change the highlighted directory.

**File:** When selected, use the knob or direction keys to switch among files or sub-folders under the current directory.

### 6.3.2 Open/Load

Open the selected folder or load the selected file.

### 6.3.3 Back

If there is a previous directory, return to it.

### 6.3.4 View Type

Select the type of file to be browsed. Include: “All Type”, “STA”, “TRC”, “COR”, “CSV”, “LIM”, “PIC” (JPG /BMP /PNG).

### 6.3.5 Save Type

Select the type of file to be saved. The corresponding storage data of various types of files are:

#### 1. STA(Status)

STA files can be used to save and recall the instrument configuration. They are saved in ASCII format, which is human readable.

#### 2. TRC(Trace)

TRC files store the active (visible) trace data and scaling factors that were in place when the data was saved. They are saved in ASCII format, which is human readable.

**Note:** When you first recall trace files, the instrument will adjust the display parameters (horizontal and vertical scaling, for example) to match the settings used during data collection. The trace data will not

---

change, even if you adjust the parameters.

### **3. COR(Correction)**

COR files store the data used to mathematically adjust the displayed input signal based on external factors (Cable loss, Amplifier/Antenna gain, etc.). They are saved in ASCII format, which is human readable.

### **4. CSV(Comma-Separated Variable)**

CSV files store instrument configuration (scaling, units, etc.) and raw data (amplitude and frequency values) in ASCII format, commonly viewed in spreadsheet programs like Microsoft® Excel®. This file type is human readable.

### **5. LIM(limit)**

LIM files store the line or point data used to configure and display lines used for visual indication of a user-defined limit. They are saved in ASCII format, which is human readable.

### **6. BMP(Bitmap) /JPG(JPEG) /PNG**

Picture files capture the display of the instrument (screenshot) as an image file. All of the details of the display are captured exactly, so what you see on the display is in the file. These are readable using image programs like Microsoft® Paint®.

## **6.3.6 Save**

Save file in current directory, the file type is set in 'Save Type'.

If there is an external memory, it will be saved to the external memory first.

Also used to set the save type is the **Save** shortcut, which can be used to quickly save the files.

## **6.3.7 Create Folder**

Create a new folder in current directory.

## **6.3.8 Operate**

### **1. Browser**

Browse files or directories; use the knob or direction keys to select the corresponding item.

### **2. Open/Load**

Open the selected folder or load the selected file.

### **3. Back**

Return to previous directory

### **4. Select All**

---

Select all the files and folders in the current directory.

#### 5. Cut

Cut the Selected file or folder, and delete the primary one after paste.

#### 6. Copy

Copy the Selected file or folder for paste.

#### 7. Paste

Paste the file cut or copied before into the current.

#### 8. Delete

Delete the selected file or directory.

#### 9. Rename

Rename the selected file or folder.

## 6.4 Shortcut Key

### 6.4.1 Preset

Recall the preset setting and restore the analyzer to a specified status.

- ◆ Press **System** -> "Pwr On/Preset" -> "Preset" to select "Def", "Last" or "User".
- ◆ Press **Preset** to load the factory settings listed in the following table (except items marked with "\*\*") or Last settings or User-defined settings.
- ◆ Different modes have their own Presets. The following table shows the initial default state of the Spectrum Analyzer Mode.

Table 6-3 Default Preset of Spectrum Analyzer Mode

Parameter	Default
<b>Frequency</b>	
Center Freq	750 MHz
Start Freq	0 Hz
Stop Freq	1.5 GHz
Freq Offset	0 Hz
Freq Step	Auto, Span /10
Signal Track	Off
<b>Span</b>	
Span	1.5 GHz
X Scale	Linear

<b>Amplitude</b>	
Ref Level	0 dBm
Attenuator	Auto, 20 dB
Preamp	Off
Units	dBm
Scale/Div	10 dB
Scale Type	Log
Ref Offset	0 dBm
Corrections	Off
RF Input	50 $\Omega$
Apply Corrections	Off
Correction x	Off
Correction x data	Null
<b>BW</b>	
RBW	Auto, 1MHz
VBW	Auto, 1MHz
VBW/RBW	1
Avg Type	Log Pwr
Filter	Gauss
<b>Sweep</b>	
Sweep Time	Auto
Sweep Rule	Speed
Sweep	Continue
Sweep Mode	Auto
Numbers	1
QPD Dwell Time	50 ms
<b>Trig</b>	
Trigger Type	Free Run
Video Trigger	0 dBm
External Trigger	Rising
<b>TG</b>	
TG	Off
TG Level	-20 dBm
TG Lvl Offset	0 dB
Normalize	Off
Norm Ref Lvl	0 dB
Norm Ref Pos	100%
Ref Trace	Blank
<b>Trace</b>	
Select Trace	A
Trace Type of Trace A	Clear Write

Avg Times	100
Output Z	C
Input X	A
Input Y	B
Constant	0 dB
Math Type	Off
<b>Detect</b>	
Select Trace	A
Detect Type of Trace A	Pos Peak
<b>Limit</b>	
Limit1	Off, Limit Upper, 0 dBm
Limit2	Off, Limit Lower, -100 dBm
Test	Stop
Fail to stop	Off
Buzzer	Off
X Axis	Freq
<b>Demod</b>	
Demod Mode	Off
Earphone	Off
Volume	6
Demod Time	5.00 s
<b>Marker</b>	
Select Marker	1
Select Trace	A
Marker Type	Normal
Relative To	2
Marker Table	Off
<b>Marker Fn</b>	
Select Marker	1
Marker Fn	Off
N dB BW	-3 dB
Read Out	Frequency
Freq Counter	Off
<b>Peak</b>	
Cont Peak	Off
Peak Table	Off
Peak Threshold	-140 dBm
Peak Excursion	15 dB
Peak Type	Max
Sort By	Ampt
<b>Mode</b>	



Mode	Spec Analyzer
<b>Measure</b>	
Meas Type	Off
<b>Measure Setup</b>	
<b>Channel Power</b>	
Center Freq	750 MHz
Integration BW	2 MHz
Span	1.5 GHz
<b>ACPR</b>	
Center Freq	750 MHz
Main Channel	1 MHz
Adjacent Chn	1 MHz
Adj Chn Space	3 MHz
<b>Occupied BW</b>	
Method	%
dBc	26
%	99
<b>T-Power</b>	
Center Freq	750 MHz
Start Line	0 s
Stop Line	60.6 us
<b>Spectrum Monitor</b>	
Spectrogram	Run
<b>CNR</b>	
Carrier BW	3 MHz
Noise BW	3 MHz
Freq Offset	3 MHz
<b>Harmonics</b>	
Fundamental	Auto
Freq Step	Auto
Harmonic Num	10
Select Harmonic	All
<b>System**</b>	
Language	English
Power On	Def
Preset	Def
Power on Line	Disable
IP Config	DHCP
Auto Cal	Close
Time Date	On
Set Format	ymd

<b>Display**</b>	
Grid Brightness	30%
Screenshot	Normal
Touch	On
Touch Assistant	On
Power Saving	Always On
Annotation	Off
Display Line	Off, 0 dBm

Table 6-4 Default Preset of Vector Network Analyzer Mode

Parameter	Default
<b>Frequency</b>	
Center Freq	750.05 MHz
Start Freq	100 kHz
Stop Freq	1.5 GHz
<b>Span</b>	
Span	1.4999 GHz
<b>Amplitude</b>	
Scale/Div	10 dB
Ref Level	0 dBm
Ref Position	5 Div
<b>BW</b>	
IFBW	10 kHz
<b>Sweep</b>	
Points	201
Sweep Time	0 s
Sweep	Continue
<b>Trace</b>	
Select Trace	1
Num of Traces	1
Display	Data
Trace Hold	Off
Math	Off
Average	Off
Avg Times	100
<b>Marker</b>	
Select Trace	1
Select Marker	1
Marker Type	Normal
Discrete	Off
Couple	On

<b>Peak</b>	
Select Trace	1
Select Marker	1
<b>Measure</b>	
Meas	S11
Format	Log Mag
<b>Calibration</b>	
Correction	Off
System Z0	50
Velocity Factor	0.66
<b>Port Extensions</b>	
Extensions	Off
Delay Port1	0 ps
Length Port1	0 mm
Delay Port2	0 ps
Length Port2	0 mm

Table 6-5 Default Preset of Distance-To-Fault Mode

Parameter	Default
<b>Frequency</b>	
Center Freq	750.05 MHz
Start Freq	100 kHz
Stop Freq	1.5 GHz
<b>Span</b>	
Span	1.4999 GHz
<b>Amplitude</b>	
Ref Level	0
Scale/Div	10
<b>Sweep</b>	
Sweep	Continue
<b>Trace</b>	
Display	Data
Average	On
Avg Times	10
<b>Marker</b>	
Select Marker	1
Marker Type	Normal
Cont Peak	Off
Cont Valley	Off
Discrete	Off
<b>Peak</b>	

Select Marker	1
<b>Measure</b>	
Start Distance	0 m
Stop Distance	30.39 m
Unit	Meters
Velocity Factor	0.66
Cable Atten	0 dBm
Window	Hamming
<b>Calibration</b>	
Correction	On

Table 6-6 Default Preset of Modulation Analyzer Mode

Parameter	Default
<b>Measure</b>	
Meas Type	QAM
<b>Analog Modulation</b>	
<b>Frequency</b>	
Center Freq	100 MHz
Freq Step	10 kHz
<b>Span</b>	
Span	13.08083 MHz
<b>Amplitude</b>	
Attenuator	Auto, 20 dB
Preamp	Off
<b>BW</b>	
EQBW	100 kHz
Window	Flat Top
<b>Sweep</b>	
Sweep	Continue
<b>Trig</b>	
Trigger Type	Free Run
Video Trigger	0 dBm
External Trigger	Rising
<b>Trace</b>	
Select Trace	A
Num of Trace	2
Layout	Grid 1,2
Data of Trace A	Time
Data of Trace B	Spec
<b>Marker</b>	
Select Trace	A

Select Marker	1
Marker Type	Normal
Relative To	2
Couple	Off
<b>Meas Setup</b>	
IFBQ	Auto, 1.2 MHz
EqLPF	Auto, 200 kHz
Average	Off
Avg Times	10
<b>Digital Modulation</b>	
<b>Frequency</b>	
Center Freq	100 MHz
Freq Step	10 kHz
<b>Span</b>	
Span	31.25 kHz
<b>Amplitude</b>	
Attenuator	Auto, 20 dB
Preamp	Off
Ref Level of Trace A	1.5
Scale/Div of Trace A	0.3
Ref Level of Trace B	0 dBm
Scale/Div of Trace B	10 dB
Ref Level of Trace D	1.5
Scale/Div of Trace D	0.3
<b>BW</b>	
EQBW	100 kHz
Window	Flat Top
<b>Sweep</b>	
Sweep	Continue
<b>Trig</b>	
Trigger Type	Free Run
Video Trigger	0 dBm
External Trigger	Rising
<b>Trace</b>	
Select Trace	A
Num of Trace	4
Layout	Grid 2x2
Data of Trace A	IQ Meas Time
Format of Trace A	Constellation
Data of Trace B	Spec
Format of Trace B	Log Mag

Data of Trace C	Syms/Errs
Format of Trace C	Log Mag
Data of Trace D	IQ Meas Time
Format of Trace D	I-Eye
<b>Properties</b>	
Eye Length	2
Symbol Table	Hex
<b>Marker</b>	
Select Trace	A
Select Marker	1
Marker Type	Normal
Relative To	2
Couple	Off
<b>Meas Setup</b>	
Format	16QAM
Symbol Rate	10 ksps
Points/Symbol	4
Meas Length	128
<b>Filter Setup</b>	
Meas Filter	Sqrt Nyquist
Ref Filter	Nyquist
Alpha/BT	0.35
Filter Length	64
<b>Statistic</b>	
Statistic	Off
Average	Off
Avg Times	10

## 6.4.2 Couple

Set related parameters according to the coupling relationship.

Auto all: Set Related parameters automatically according to the coupling relationship.

### 1. Freq step

Freq step has a coupling relationship with RBW at the zero span. When in none-zero mode, Freq step has coupling relationship with Span. Please refer to the introduction of the "Freq Step".

### 2. Attenuation

Input attenuation has a coupling relationship with Ref Level and the preamp. Please refer to introduction of "amplitude".

---

### 3. RBW

RBW has a coupling relationship with the span. Please refer to the introduction of the "Resolution Bandwidth".

### 4. VBW

VBW has a coupling relationship with the span. Please refer to the introduction of "VBW".

### 5. Sweep time

Sweep time has a coupling relationship with RBW, VBW and span. Please refer to the introduction of "Sweep Time".

### 6. Mode Couple

Some of the basic parameters are allowed to be set up in coupled operation between different modes. If the Center Freq is set to On in one mode, it applies to all other modes that support center freq setting so that you can switch between any of these modes while center freq will be unchanged. When press All Off, all of the mode couple switches are set to Off.

## 6.4.3 Help

The Help button has been implemented. The full instructions on the Help button use is covered in section 1.10.

## 6.4.4 Save

Quickly save a file, according to **File**->'Save Type' settings.

By default, pressing **Save** will save screenshots in .PNG format.

If there is an external memory, it will be saved to the external memory first.

---

# Chapter 7 Programming Overview

The T3VNA Series analyzer features LAN and USB Device interfaces. By using a computer with these interfaces, and a suitable programming language (and/or NI-VISA software), users can remotely control the analyzer based on SCPI (Standard Commands for Programmable instruments) command set, LabView and IVI (Interchangeable Virtual Instrument), to interoperate with other programmable instruments.

This chapter introduces how to build communication between the analyzer and a controller computer with these interfaces.

## 7.1 Remotely Operating the Analyzer

The analyzer provides both the USB and LAN connection which allows you to set up a remote operation environment with a controller computer. A controller computer could be a personal computer (PC) or a minicomputer. Some intelligent instruments also function as controllers.

### 7.1.1 USB: Connecting the Analyzer via the USB Device port

Refer to the following steps to finish the connection via USB-Device:

1. Install NI-VISA on your PC for USB-TMC driver.
2. Connect the analyzer USB Device port to a PC with a USB A-B cable.
3. Switch on the analyzer



Figure 7-1 USB Device

The analyzer will be detected automatically as a new USB hardware.

### 7.1.2 LAN: Connecting the Analyzer via the LAN port

Refer to the following steps to finish the connection via LAN:

1. Install NI-VISA on your PC for VXI driver. Or without NI-VISA, using socket or telnet in your PC's Operating System.
2. Connect the analyzer to PC or the local area network with a LAN cable
3. Switch on the analyzer





Figure 7-2 LAN

4. Press button on the front panel **System**→Interface→LAN to enter the LAN Config function menu.
5. Select the IP Config between Static and DHCP
  - ◆ DHCP: the DHCP server in the current network will assign the network parameters automatically (IP address, subnet mask, gate way) for the analyzer.
  - ◆ Static: you can set the IP address, subnet mask, gate way manually. Press Apply.




Figure 7-3 LAN Config

The analyzer will be detected automatically or manually as a new LAN point.

### 7.1.3 GPIB is not supported on the T3VNA series.

---

## 7.2 Build Communication

### 7.2.1 Build Communication Using VISA


NI-VISA includes a Run-Time Engine version and a Full version. The Run-Time Engine version provides NI device drivers such as USB-TMC, VXI, GPIB, etc. The full version includes the Run-Time Engine and a software tool named NI MAX that provides a user interface to control the device.

You can get NI-VISA full version from:

<http://www.ni.com/download/>.

After download you can follow the steps below to install it:


1. Double click the visa\_full.exe, dialog shown as below:




2. Click Unzip, the installation process will automatically launch after unzipping files. If your computer needs to install .NET Framework 4, its setup process will auto start.




3. The NI-VISA installing dialog is shown above. Click Next to start the installation process.



4. Set the install path, default path is “C:\Program Files\National Instruments\”, you can change it. Click Next, dialog shown as above.



5. Click Next twice, in the License Agreement dialog, select the “I accept the above 2 License Agreement(s).”, and click Next, dialog shown as below:



6. Click Next to run installation.



Now the installation is complete, reboot your PC.

## 7.2.2 Build Communication Using Sockets/Telnet

Through the LAN interface, VXI-11, Sockets and Telnet protocols can be used to communicate with the analyzer. VXI-11 is provided in NI-VISA, while Sockets and Telnet are commonly included in PC's OS initially.

Socket LAN is a method used to communicate with the analyzer over the LAN interface using the Transmission Control Protocol/Internet Protocol (TCP/IP). A socket is a fundamental technology used for computer networking and allows applications to communicate using standard mechanisms built into network hardware and operating systems. The method accesses a port on the analyzer from which bidirectional communication with a network computer can be established.

Before you can use sockets LAN, you must select the analyzer's sockets port number to use:

- ◆ **Standard mode:** Available on port 5025. Use this port for programming.
- ◆ **Telnet mode:** The telnet SCPI service is available on port 5024.

## 7.3 Remote Control Capabilities

### 7.3.1 User-defined Programming

Users can use SCPI commands to program and control the analyzer. For details, refer to the introductions in “**Programming Examples**”.


### 7.3.2 Send SCPI Commands via NI MAX

Users can control the analyzer remotely by sending SCPI commands via NI-MAX software. NI\_MAX is National Instruments Measurement and Automation Explorer. It is an executable program that enables easy communication to troubleshoot issues with instrumentation.


#### 7.3.2.1 Using USB

Run NI MAX software.

1. Click “Device and interface” at the upper left corner of the software;
2. Find the “USBTMC” device symbol



3. Click “Open VISA Test Panel” option button, then the following interface will appear.
4. Click the “Input/Output” option button and click the “Query” option button in order to view the operation information.




**Note:** The “\*IDN?” command (known as the Identification Query) returns the instrument manufacturer, instrument model, serial number, and other identification information.

### 7.3.2.2 Using LAN


Select “Add Network Device”, and select “VISA TCP/IP Resource” as shown:

Run NI MAX software.


1. Click “Device and interface” at the upper left corner of the software;
2. Find the “Network Devices” symbol, click “Add Network Devices”;




1. Select Manual Entry of LAN instrument, select Next, and enter the IP address as shown. Click Finish to establish the connection:




**Note:** Leave the LAN Device Name BLANK or the connection will fail.




2. After a brief scan, the connection should be shown under Network Devices:



3. Right-click on the product and select Open NI-VISA Test Panel:



4. Click "Input/Output" option button and click "Query" option button. If everything is OK, you will see the Read operation information returned as shown below.




### 7.3.3 Easy Spectrum Software

Users can control the analyzer remotely by Easy Spectrum. PC software Easy Spectrum is an easy-to-use, PC-Windows-based remote control tool for Teledyne LeCroy's analyzer. You can download it from Teledyne LeCroy's website. To connect the analyzer via the USB/LAN port to a PC, you need install the NI VISA first.

It is able to be used as:


- ◆ A monitor to display and control the trace scans simultaneously with the analyzer;
- ◆ A file maker to get user defined Limit/Correction files, and load them to the analyzer;
- ◆ An EMI receiver perform EMI Pre-compliance test including pre-scan, peak search, final scan and report generating.

For the further description of the software, please refer to the online help embedded in this software.



### 7.3.4 Web Control

With the embedded web server, the analyzer can be controlled through LAN from a web browser\* on PC and mobile terminals, without any extra driver be installed. This provides remote controlling and monitoring capabilities. Screenshot and firmware update are also supported.



\*Web browser with HTML5 supported like Google Chrome or Firefox are recommended.



---

# Chapter 8 Service and Support

## 8.1 Service Summary

**Teledyne LeCroy** warrants that the products that it manufactures and sells will be free from defects in materials and workmanship for a period of three years (accessories for a period of one year) from the date of shipment from an authorized Teledyne LeCroy distributor. If the product proves defective within the respective period, **Teledyne LeCroy** will provide repair or replacement as described in the complete warranty statement.

To arrange for service or obtain a copy of the complete warranty statement, please contact your nearest Teledyne LeCroy sales and service office. Except as provided in this summary or the applicable warranty statement, **Teledyne LeCroy** makes no warranty of any kind, express or implied, including without limitation the implied warranties of merchantability and fitness for a particular purpose. In no event shall **Teledyne LeCroy** be liable for indirect, special or consequential damages.

## 8.2 Troubleshooting

Before calling **Teledyne LeCroy**, or returning an analyzer for service, perform the quick checks listed below. This check may eliminate the problem.

If the problem remains still, please contact **Teledyne LeCroy** and provide your device information in the back of the analyzer.

### 1. The Power Switch is still dark after power on:

- (1) Check that the power is correct / working.
- (2) Check the power cord has been connected correctly
- (3) Check the power fuse. If a new fuse needs to be installed, please use the specified fuse.

### 2. The analyzer's screen is still dark (no display) after power on:

- (1) Check whether the fan is running while the screen is dark, maybe the LCD cable is loose?
- (2) Check whether the fan is not running while screen is dark, maybe it has failed to start up?

Do not disassemble the instrument, contact **Teledyne LeCroy**.

### 3. The keys are unresponsive or gives a wrong response:

- (1) Press all the keys at the front panel to check if all of them are normal after power on.
- (2) Press **System** -> **Self Test** -> **Key Test** to check if all the keys are working properly.
- (3) If a key is not working, the numeric keyboard connection might be loose or the numeric keyboard is broken.

Do not disassemble the instrument by yourself and contact **Teledyne LeCroy**.

---

#### 4. The spectrum lines on the screen do not update for a long period of time:

- (1) Check whether the screen is locked; if so, press **Esc** to unlock it.
- (2) Verify whether all the trigger conditions have been met and whether there is a valid trigger signal inputting.
- (3) Check whether the analyzer is in single sweep mode.
- (4) Check whether the current sweep time is too long.

#### 5. Wrong measurement results or poor precision:

To calculate the system errors and check the measurement results and precision, refer to the introductions in “**Specifications**”. To reach these specifications, please:

- (1) Check whether all the external devices are successfully connected and are working normally.
- (2) Get some knowledge of the signal under measurement and set appropriate instrument parameters.
- (3) Make measurements under proper conditions; for example, warm-up the instrument appropriately and operate the instrument under the specified environment temperature.
- (4) Calibrate the instrument regularly to reduce or avoid errors that might occur over time.

If you need a specific calibration after the stated calibration period, contact **Teledyne LeCroy** or get paid calibration service from authorized measurement agencies.

#### 6. System Messages:

The instrument may display prompt messages, error messages or state messages according to the current working status. These messages are displayed to help you to use the instrument correctly rather than instrument failures.

#	User system message	Message on screen
<b>System message description(1-199)</b>		
1	SWT_OOR	Sweep time out of range
2	RBW_OOR	RBW out of range
19	PEAK_UNFOUND	No peak found, please change the search config
20	IMD_FREQ_OOR	Frequency of intermodulation products is out of range
21	AUTO_FAIL	No peak found
22	EXT_REF_PLUG_IN	EXT ref plug in
23	EXT_REF_PLUG_OUT	EXT ref plug out
150	LAN_PLUG_IN	Ethernet cable plug in
151	LAN_PLUG_OUT	Ethernet cable plug out
152	IP_CONFLICT	IP address conflict
153	IP_INVALID	IP address invalid
154	NETM_INVALID	Netmask address invalid
155	GWAY_INVALID	Gateway address invalid
<b>Device error(600-799)</b>		
605	LIC_INVALID	License invalid
606	ADC_ERROR	Warning, ADC overload

---

## 8.3 Contact Us

### Teledyne LeCroy (US Headquarters)

700 Chestnut Ridge Road  
Chestnut Ridge, NY. USA  
10977-6499

**Phone:** 800-553-2769 or 845-425-2000

**Fax Sales:** 845-578-5985

**Email Sales:** [contact.corp@teledynelecroy.com](mailto:contact.corp@teledynelecroy.com)

**Email Support:** [support@teledynelecroy.com](mailto:support@teledynelecroy.com)

(Oscilloscopes, Waveform Generators, Signal Integrity)

**Web Site:** <http://teledynelecroy.com/>

**Phone Support:** 1-800-553-2769

### Teledyne LeCroy (European Headquarters)

#### Teledyne LeCroy GmbH

Im Breitspiel 11c  
D-69126 Heidelberg, Germany

**Phone:** + 49 6221 82700

**Fax:** +49 6221 834655

**Fax Sales:** +49 6221 834655

**Fax Service:** +41 22 719 22 99

**Email Sales:** [contact.gmbh@teledynelecroy.com](mailto:contact.gmbh@teledynelecroy.com)

**Email Service:** [service.gmbh@teledynelecroy.com](mailto:service.gmbh@teledynelecroy.com)

**Email Support:** [tlc.t3.appsupport.eu@teledyne.com](mailto:tlc.t3.appsupport.eu@teledyne.com)

**Web Site:** <http://teledynelecroy.com>

**Phone Service:** +49 6221 8270 85

**Phone Support:** +49 6221 8270 28

Teledyne LeCroy information about EU RoHS, China RoHS and the EU WEEE directive can be found at the website below.

<http://teledynelecroy.com/recycle>

# ABOUT TELEDYNE TEST TOOLS



## Company Profile

Teledyne LeCroy is a leading provider of oscilloscopes, protocol analyzers and related test and measurement solutions that enable companies across a wide range of industries to design and test electronic devices of all types. Since our founding in 1964, we have focused on creating products that improve productivity by helping engineers resolve design issues faster and more effectively. Oscilloscopes are tools used by designers and engineers to measure and analyze complex electronic signals in order to develop high-performance systems and to validate electronic designs in order to improve time to market.

The Teledyne Test Tools brand extends the Teledyne LeCroy product portfolio with a comprehensive range of test equipment solutions. This new range of products delivers a broad range of quality test solutions that enable engineers to rapidly validate product and design and reduce time-to-market. Designers, engineers and educators rely on Teledyne Test Tools solutions to meet their most challenging needs for testing, education and electronics validation.

## Location and Facilities

Headquartered in Chestnut Ridge, New York, Teledyne Test Tools and Teledyne LeCroy has sales, service and development subsidiaries in the US and throughout Europe and Asia. Teledyne Test Tools and Teledyne LeCroy products are employed across a wide variety of industries, including semiconductor, computer, consumer electronics, education, military/aerospace, automotive/industrial, and telecommunications.

Distributed by:

## Teledyne LeCroy (US Headquarters)

700 Chestnut Ridge Road  
Chestnut Ridge, NY. USA  
10977-6499

**Phone:** 800-553-2769 or 845-425-2000

**Fax Sales:** 845-578-5985

**Email Sales:** [contact.corp@teledynelecroy.com](mailto:contact.corp@teledynelecroy.com)

**Email Support:** [support@teledynelecroy.com](mailto:support@teledynelecroy.com)  
(Oscilloscopes, Waveform Generators, Signal Integrity)

**Web Site:** <http://teledynelecroy.com/>

**Phone Support:** 1-800-553-2769

## Teledyne LeCroy (European Headquarters)

### Teledyne LeCroy GmbH

Im Breitspiel 11c  
D-69126 Heidelberg, Germany

**Phone:** + 49 6221 82700

**Fax:** +49 6221 834655

**Fax Sales:** +49 6221 834655

**Fax Service:** +41 22 719 22 99

**Email Sales:** [contact.gmbh@teledynelecroy.com](mailto:contact.gmbh@teledynelecroy.com)

**Email Service:** [service.gmbh@teledynelecroy.com](mailto:service.gmbh@teledynelecroy.com)

**Email Support:** [tlc.t3.appsupport.eu@teledyne.com](mailto:tlc.t3.appsupport.eu@teledyne.com)

**Web Site:** <http://teledynelecroy.com>

**Phone Service:** +49 6221 8270 85

**Phone Support:** +49 6221 8270 28

[teledynelecroy.com](http://teledynelecroy.com)



© 2018 Teledyne Test Tools a brand and trademark of Teledyne LeCroy Inc. All rights reserved. Specifications, prices, availability and delivery subject to change without notice. Product brand or brand names are trademarks or requested trademarks of their respective holders.

T3 stands for Teledyne Test Tools.

931999 Rev2