



- Accessories
- To connect the Zero Smog TL to one or two WT or WX soldering stations (please note: WX connecting cable T0058764710 needed)
- Enables cost-efficient and synchronized usage of devices - the fume extraction unit works only while the operator is soldering
- Quick and easy set-up

### WT HUB

Product no.: T0058768767

|  |     |
|--|-----|
| Dimensions L x W x H (mm)                      | --- |
| Dimensions L x W x H (inches)                  | --- |
| Weight (approx.) in kg                         | --- |
| Voltage  | --- |
| Power  | --- |
| Channels                                       | --- |
| Temperature range (depends on tool) °C         | --- |
| Temperature range (depends on tool) °F         | --- |
| Temperature accuracy °C                        | --- |
| Temperature accuracy °F                        | --- |
| Temperature accuracy for hot air °C            | --- |
| Temperature accuracy for hot air °F            | --- |
| Temperature stability °C                       | --- |
| Temperature stability °F                       | --- |
| Equipotential bonding socket                   | --- |
| Display  | --- |
| Additional vacuum pump                         | --- |
| Max. hot air flow rate l/min (depends on tool) | --- |
| Capacity l/min                                 | --- |
| Max. vacuum                                    | --- |
| Interface                                      | --- |