


# **Agilent 16048A Test Leads**

## **Operation and Service Manual**

**Fourth Edition**

**Agilent Technologies Japan, Ltd.**

Agilent PN 16048-90001



**Agilent Technologies**

**March 2000**

Printed in: Japan

---

## Notices

The information contained in this document is subject to change without notice.

This document contains proprietary information that is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent of the Agilent Technologies.

Agilent Technologies Japan, Ltd.

Component Test PGU-Kobe

1-3-2, Murotani, Nishi-Ku, Kobe-shi, Hyogo, 651-2241 Japan

Copyright © 1990, 1998, 1999, 2000 Agilent Technologies Japan, Ltd.

---

## Manual Printing History

The manual's printing date and part number indicate its current edition. The printing date changes when a new edition is printed. (Minor corrections and updates that are incorporated at reprint do not cause the date to change.) The manual part number changes when extensive technical changes are incorporated.

|               |   |
|---------------|---|
| 1990          | First Edition (part number: 16048-90000)  |
| November 1998 | Second Edition (part number: 16048-90001) |
| August 1999   | Third Edition (part number: 16048-90001)  |
| March 2000    | Fourth Edition (part number: 16048-90001) |

---

## Safety Summary

The following general safety precautions must be observed during all phases of operation, service, and repair of this instrument. Failure to comply with these precautions or with specific WARNINGS elsewhere in this manual may impair the protection provided by the equipment. In addition it violates safety standards of design, manufacture, and intended use of the instrument.

Agilent Technologies assumes no liability for the customer's failure to comply with these requirements.

---

### NOTE

16048A comply with INSTALLATION CATEGORY I and POLLUTION DEGREE 2 in IEC61010-1. 16048A are INDOOR USE product.

---

- Ground The Instrument

To avoid electric shock hazard, the instrument chassis and cabinet must be connected to a safety earth ground by the supplied power cable with earth blade.

- DO NOT Operate In An Explosive Atmosphere

Do not operate the instrument in the presence of flammable gasses or fumes. Operation of any electrical instrument in such an environment constitutes a definite safety hazard.

- Keep Away From Live Circuits

Operating personnel must not remove instrument covers. Component replacement and internal adjustments must be made by qualified maintenance personnel. Do not replace components with the power cable connected. Under certain conditions, dangerous voltages may exist even with the power cable removed. To avoid injuries, always disconnect power and discharge circuits before touching them.

- DO NOT Service Or Adjust Alone

Do not attempt internal service or adjustment unless another person, capable of rendering first aid and resuscitation, is present.

- DO NOT Substitute Parts Or Modify Instrument

Because of the danger of introducing additional hazards, do not install substitute parts or perform unauthorized modifications to the instrument. Return the instrument to a Agilent Technologies Sales and Service Office for service and repair to ensure that safety features are maintained.

- Dangerous Procedure Warnings

Warnings, such as the example below, precede potentially dangerous procedures throughout this manual. Instructions contained in the warnings must be followed.

---

**WARNING**

---

**Dangerous voltages, capable of causing death, are presenting this instrument. Use extreme caution when handling, testing, and adjusting this instrument.**

---

## Certification

Agilent Technologies certifies that this product met its published specifications at the time of shipment from the factory. Agilent Technologies further certifies that its calibration measurements are traceable to the United States National Institute of Standards and Technology, to the extent allowed by the Institution's calibration facility, or to the calibration facilities of other International Standards Organization members.

---

## Warranty

This Agilent Technologies instrument product is warranted against defects in material and workmanship for a period corresponding to the individual warranty periods of its component products. Instruments are warranted for a period of one year. Fixtures and adapters are warranted for a period of 90 days. During the warranty period, Agilent Technologies Company will, at its option, either repair or replace products that prove to be defective.

For warranty service or repair, this product must be returned to a service facility designated by Agilent Technologies. Buyer shall prepay shipping charges to Agilent Technologies and Agilent Technologies shall pay shipping charges to return the product to Buyer. However, Buyer shall pay all shipping charges, duties, and taxes for products returned to Agilent Technologies from another country.

Agilent Technologies warrants that its software and firmware designated by Agilent Technologies for use with an instrument will execute its programming instruction when properly installed on that instrument. Agilent Technologies does not warrant that the operation of the instrument, or software, or firmware will be uninterrupted or error free.

---

## Limitation of Warranty

The foregoing warranty shall not apply to defects resulting from improper or inadequate maintenance by Buyer, Buyer-supplied software or interfacing, unauthorized modification or misuse, operation outside the environmental specifications for the product, or improper site preparation or maintenance.

---

### IMPORTANT

No other warranty is expressed or implied. Agilent Technologies specifically disclaims the implied warranties of merchantability and fitness for a particular purpose.

---

---

## Exclusive Remedies

The remedies provided herein are buyer's sole and exclusive remedies. Agilent Technologies shall not be liable for any direct, indirect, special, incidental, or consequential damages, whether based on contract, tort, or any other legal theory.

---

## Assistance

Product maintenance agreements and other customer assistance agreements are available for Agilent Technologies products.

For any assistance, contact your nearest Agilent Technologies Sales and Service Office. Addresses are provided at the back of this manual.

---

## Safety Symbol

General definitions of safety symbols used on the instrument or in manuals are listed below.



Instruction Manual symbol: the product is marked with this symbol when it is necessary for the user to refer to the instrument manual.

---

### WARNING

**This warning sign denotes a hazard. It calls attention to a procedure, practice, condition or the like, which, if not correctly performed or adhered to, could result in injury or death to personnel.**

---

### CAUTION

This Caution sign denotes a hazard. It calls attention to a procedure, practice, condition or the like, which, if not correctly performed or adhered to, could result in damage to or destruction of part or all of the product.

---

### NOTE

Note denotes important information. It calls attention to a procedure, practice, condition or the like, which is essential to highlight.

---



---

## Contents

|   |    |
|---|----|
| <b>1. Operation</b>                                     |    |
| Product Description .....                               | 10 |
| Specifications .....                                    | 11 |
| Typical Characteristics .....                           | 12 |
| Compensation for Fixture Residual Impedance Error ..... | 13 |
| <b>2. Service</b>                                       |    |
| Maintenance .....                                       | 16 |





---

# 1

## Operation

This operating note provides complete information on the 16048A Test Leads. The 16048A is shown pictorially in Figure 1-1, its physical dimensions are given in Table 1-1, and typical characteristics related to offset error are given in Table 1-2. To order additional copies of this operating note, use the part number listed on the rear cover.

## Product Description

The 16048A consists of a direct attachment, 4-terminal pair type fixture which is equipped with four BNC (m) terminated-coaxial test leads. These test leads are used to attach user-fabricated test fixtures. DC bias levels of up to  $\pm 40\text{V}$  can be applied to the 16048A. Cable length is 1 meter. The 16048A is shown in Figure 1-1.

Figure 1-1

### Product Overview



## Specifications

Table 1-1

Specifications of the 16048A

|                   |   |
|-------------------|---|
| Function:         | For use with 4 terminal-pair LCR Meters and Impedance Analyzers.  |
| Connector Type:   | BNC male  |
| Cable Length:     | Approximately 1m  |
| Maximum Voltage:  | ± 40V peak max. (AC+DC)   |
| Weight:           | 315 g   |
| Safety Standards: | EN61010-1:1993 +A2:1995<br>IEC61010-1:1990 +A1:1992 +A2:1995<br>CSA C22.2 No.1010.1:1992<br><br>INSTALLATION CATEGORY I<br>POLLUTION DEGREE 2<br>INDOOR USE |


# Typical Characteristics

Table 1-2 Typical Characteristics

| Incremental error at freq. ≥1 MHz          |   |
|--|---|
| Parameter reading error (%)                | Offset value for D                            |
| $\pm 5 \times \left(\frac{f}{10}\right)^2$ | $\pm 0.02 \times \left(\frac{f}{10}\right)^2$ |

**NOTE** f is the measurement frequency in megahertz. The incremental errors calculated from the equation in the table for measurements at frequencies above 1 MHz are additive.

Figure 1-2



## **Compensation for Fixture Residual Impedance Error**

The 16048A has inherent stray capacitance, residual inductance, and residual resistance that affect the accuracy of measured values. To compensate for, or negate, these residuals to minimize measurement error, the instrument's Open/Short compensation procedure should be performed. The procedure is given in the instrument's operating manual.

Operation

**Compensation for Fixture Residual Impedance Error**

---

## **2 Service**

## Maintenance

An exploded view of the 16048A (for parts identification) is shown in Figure 2-1. Do not disassemble any further than shown. Maintenance consists principally of cleaning contacts and replacing worn or damaged parts. Take special care when cleaning contacts. To order parts, use the Agilent Technologies part numbers listed in Table 2-1. If a faulty part is located in an assembly that cannot be disassembled, order the next higher assembly or return the whole device to the nearest Agilent Technologies Sales/Service Office for repair or replacement.



Figure 2-1 Parts Identification




Table 2-1

Parts Identification

| Reference | Agilent Part No.         | Qty. | Description   | Note      |
|-----------|--------------------------|------|---------------|-----------|
| 1         | *                        | 4    | SLEEVE        |           |
| 2         | *                        | 4    | NUT           |           |
| 3         | *                        | 4    | NUT           |           |
| 4         | *                        | 4    | WASHER        |           |
| 5         | *                        | 4    | WASHER        |           |
| 6         | 2360-0192                | 2    | SCREW         |           |
| 7         | *                        | 1    | COVER-BOTTOM  |           |
| 8         | *                        | 4    | INSULATOR     |           |
| 9         | *                        | 2    | CONNECTOR-BNC |           |
| 10        | *                        | 2    | CONNECTOR-BNC |           |
| 11        | 2200-0103                | 1    | SCREW         |           |
| 12        | 2190-0206                | 1    | WASHER        |           |
| 13        | 16047-40000              | 1    | STOPPER       |           |
| 15        | 16048-04000              | 1    | COVER-TOP     |           |
| 16        | 1400-0719                | 2    | TIE RAP       |           |
| 17        | *                        | 1    | GROMMET       |           |
| 18        | *                        | 1    | CABLE         |           |
| 19        | *                        | 1    | BUSHING       |           |
| 21        | 2360-0115                | 1    | SCREW         |           |
| 22        | 3050-0010                | 1    | WASHER        |           |
| 23        | 16021-50021              | 1    | CABLE CRAMP   |           |
| 24        | 16021-50022              | 1    | CABLE CRAMP   |           |
| 25        | *                        | 4    | BOOT-BNC      |           |
| 26        | *                        | 4    | SLEEVE        |           |
| 27        | *                        | 4    | SLEEVE        |           |
| 28        | *                        | 4    | INSULATOR     |           |
| 29        | 1250-0089                | 4    | CONTACT       |           |
| 30        | 1250-0052                | 4    | CONNECTOR-BNC |           |
|           | 16048-60010 <sup>a</sup> | 1    | TEST LEAD     | 1 thru 30 |

| Reference | Agilent Part No. | Qty. | Description             | Note       |
|-----------|------------------|------|-------------------------|------------|
| 31        | 1250-0118        | 4    | CONNECTOR-BNC<br>FEMALE |            |
| 32        | 2360-0115        | 2    | SCREW                   | 1 thru 30  |
| 33        | 16032-10021      | 1    | PLATE                   |            |
| 34        | 2190-0016        | 4    | WASHER                  |            |
| 35        | 2950-0001        | 4    | NUT                     |            |
| 36        | 16032-10022      | 1    | PLATE                   |            |
| 37        | 16032-60001      | 1    | BNC BRACKET             | 31 thru 36 |

a. Agilent internal-only part number.

\*: Not separately replaceable.



## REGIONAL SALES AND SUPPORT OFFICES

*For more information about Agilent Technologies test and measurement products, applications, services, and for a current sales office listing, visit our web site: <http://www.agilent.com/find/tmdir>. You can also contact one of the following centers and ask for a test and measurement sales representative.*

11/29/99

### **United States:**

Agilent Technologies  
Test and Measurement Call Center  
P.O.Box 4026  
Englewood, CO 80155-4026  
(tel) 1 800 452 4844

(fax) (61 3) 9272 0749  
(tel) 0 800 738 378 (New Zealand)  
(fax) (64 4) 802 6881

### **Canada:**

Agilent Technologies Canada Inc.  
5150 Spectrum Way  
Mississauga, Ontario  
L4W 5G1  
(tel) 1 877 894 4414

### **Asia Pacific:**

Agilent Technologies  
24/F, Cityplaza One, 1111 King's Road,  
Taikoo Shing, Hong Kong  
(tel) (852)-3197-7777  
(fax) (852)-2506-9284

### **Europe:**

Agilent Technologies  
Test & Measurement  
European Marketing Organization  
P.O.Box 999  
1180 AZ Amstelveen  
The Netherlands  
(tel) (31 20) 547 9999

### **Japan:**

Agilent Technologies Japan Ltd.  
Call Center  
9-1, Takakura-Cho, Hachioji-Shi,  
Tokyo 192-8510, Japan  
(tel) (81) 426 56 7832  
(fax) (81) 426 56 7840

### **Latin America:**

Agilent Technologies  
Latin American Region Headquarters  
5200 Blue Lagoon Drive, Suite #950  
Miami, Florida 33126  
U.S.A.  
(tel) (305) 267 4245  
(fax) (305) 267 4286

### **Australia/New Zealand:**

Agilent Technologies Australia Pty Ltd  
347 Burwood Highway  
Forest Hill, Victoria 3131  
(tel) 1-800 629 485 (Australia)