

Errata

Title & Document Type: 5326B/27B Timer Counter DVM Operating and Service Manual

Manual Part Number: 05326-90043

Revision Date: February 1975

About this Manual

We've added this manual to the Agilent website in an effort to help you support your product. This manual provides the best information we could find. It may be incomplete or contain dated information, and the scan quality may not be ideal. If we find a better copy in the future, we will add it to the Agilent website.

HP References in this Manual

This manual may contain references to HP or Hewlett-Packard. Please note that Hewlett-Packard's former test and measurement, life sciences, and chemical analysis businesses are now part of Agilent Technologies. The HP XXXX referred to in this document is now the Agilent XXXX. For example, model number HP8648A is now model number Agilent 8648A. We have made no changes to this manual copy.

Support for Your Product

Agilent no longer sells or supports this product. You will find any other available product information on the Agilent Test & Measurement website:

www.agilent.com


Search for the model number of this product, and the resulting product page will guide you to any available information. Our service centers may be able to perform calibration if no repair parts are needed, but no other support from Agilent is available.



Agilent Technologies

OPERATING AND SERVICE MANUAL

**TIMER
COUNTER
DVM
5326B/5327B**



HEWLETT  PACKARD

CERTIFICATION

The Hewlett-Packard Company certifies that this instrument was thoroughly tested and inspected and found to meet its published specifications when it was shipped from the factory. The Hewlett-Packard Company further certifies that its calibration measurements are traceable to the U.S. National Bureau of Standards to the extent allowed by the Bureau's calibration facilities, or to the calibration facilities of other International Standards Organization members.

WARRANTY AND ASSISTANCE

This Hewlett-Packard product is warranted against defects in materials and workmanship. This warranty applies for one year from the date of delivery. Hewlett-Packard will repair or replace products which prove to be defective during the warranty period provided they are returned to Hewlett-Packard. No other warranty is expressed or implied. We are not liable for consequential damages.

Service contracts or customer assistance agreements are available for Hewlett-Packard products that require maintenance and repair on-site.

For any assistance, contact your nearest Hewlett-Packard Sales and Service Office. Addresses are provided at the back of this manual.

5326B/5327B
TIMER/COUNTER/DVM
OPERATING AND SERVICE MANUAL

SERIAL PREFIX:

5326B-1428A
5327B-1428A

This manual applies to Model 5326B having serial prefix 1428A and HP Model 5327B having serial prefix 1428A.

SERIAL PREFIXES NOT LISTED

For serial prefixes above 1428A, a "Manual Supplement" sheet is included with this manual. For serial prefixes below 1428A, refer to Section VII of this manual.

NOTE

For 5326B's with serial prefixes earlier than 1128A, a separate manual is required. Order "Model 5326A/B 50 MHz Timer/Counter-DVM Operating and Service Manual." See NOTE above Table 7-1 on page 7-3.

Copyright HEWLETT-PACKARD COMPANY 1972
5301 STEVENS CREEK BLVD., SANTA CLARA, CALIF. 95050

Printed: FEB 1975

MANUAL PART NO. 05326-900 /3
MICROFICHE PART NO. 05326-90044

PRINTED IN U.S.A.

HEWLETT  PACKARD

TABLE OF CONTENTS

Section		Page
I	GENERAL INFORMATION	1-1
	1-1. Description	1-1
	1-4. Identification	1-1
	1-6. Applications	1-1
	1-8. Options	1-1
II	INSTALLATION	2-1
	2-1. Introduction	2-1
	2-3. Unpacking and Inspection	2-1
	2-5. Storage and Shipment	2-1
	2-8. Rack Installation	2-1
	2-10. Power Connection	2-1
	2-13. Remote Programming, Option 002	2-2
	2-15. Front Panel Controls	2-2
	2-19. Remote Programming Requirements	2-2
	2-22. Remote Programming Procedure	2-2
	2-24. Function Selection Programming	2-3
	2-27. Time Base Selection Programming	2-3
	2-29. Voltmeter Programming	2-3
	2-31. Trigger Level Programming	2-3
	2-34. Sample Rate Adjustment	2-3
	2-36. Remote Programming, Option 004	2-3
	2-38. Front Panel Controls	2-3
	2-40. Remote Programming Requirements	2-3
	2-43. Remote Programming Procedure	2-4
	2-45. Function Selection Programming	2-4
	2-48. Time Base Selection Programming	2-4
	2-50. Signal Conditioning Programming	2-4
	2-54. Trigger Level Programming	2-5
	2-57. Sample Rate Adjustment	2-5
	2-59. Sample Rate Disable-Computer Inhibit	2-5
	2-62. Blanking Defeat	2-5
III	OPERATION	3-1
	3-1. Introduction	3-1
	3-3. Operating Modes	3-1
	3-5. Totalizing Mode	3-1
	3-7. Frequency Modes	3-1
	3-9. Period Modes	3-1
	3-13. Time Interval Modes	3-1
	3-17. Digital Voltmeter Measurements	3-2
	3-20. Ratio	3-2
	3-23. Marker Outputs	3-2
	3-25. Hysteresis	3-2
	3-28. Time Interval Compensation	3-3
	3-30. Accuracy	3-3
IV	THEORY OF OPERATION	4-1
	4-1. Introduction	4-1
	4-3. Logic Symbols	4-1
	4-6. Gating and Logic	4-1
	4-8. Integrated Circuit Operation	4-2
	4-9. JK Master-Slave Flip-Flop	4-2
	4-11. Time-Base Decade	4-2
	4-13. Open-Collector Gate	4-2
	4-15. Logic Levels	4-3

TABLE OF CONTENTS (Continued)

Section		Page
IV	THEORY OF OPERATION (Continued)	
	4-17. Overall Counter Operation	4-3
	4-22. Frequency Modes	4-4
	4-24. Period Modes	4-4
	4-27. Time Interval Modes	4-4
	4-30. DVM Mode	4-1
V	MAINTENANCE	5-1
	5-1. Introduction	5-1
	5-3. Assembly Designations	5-1
	5-5. Test Equipment	5-1
	5-7. Assembly Connection Identification	5-1
	5-9. In-Cabinet Performance Check	5-1
	5-12. Instrument Cover Removal	5-1
	5-14. Repair	5-1
	5-15. Printed Circuit Component Replacement	5-1
	5-17. Replacing Integrated Circuits	5-2
	5-19. Adjustments	5-2
VI	REPLACEABLE PARTS	6-1
	6-1. Introduction	6-1
	6-4. Ordering Information	6-1
VII	OPTIONS AND MANUAL CHANGES	7-1
	7-1. Introduction	7-1
	7-3. Options	7-1
	7-5. Option 001, 8-Digit Display	7-1
	7-7. Option 002, Remote Programming	7-1
	7-9. Option 003, Digital Recorder Output	7-1
	7-11. Option 004, Extended Remote Programming	7-1
	7-13. Option 010, Temperature Compensated Oscillator	7-1
	7-15. Option 011, Oven Oscillator	7-1
	7-17. Field Installation of Options	7-1
	7-18. Installation of Option 001, 8th Digit	7-1
	7-20. Installation of Option 002, Remote Programming	7-2
	7-22. Installation of Option 003, Digital Recorder Output	7-2
	7-24. Installation of Option 004, Extended Remote Programming	7-2
	7-26. Installation of Option 010 and 011, Oscillator Assemblies	7-2
	7-28. Manual Changes	7-3
	7-30. Newer Instruments	7-3
	7-32. Older Instruments	7-3
VIII	SCHEMATIC DIAGRAMS	8-1
	8-1. General	8-1

LIST OF TABLES

Table	Page
1-1. Equipment Supplied	1-1
1-2. Accessories Available	1-1
1-3. Specifications	1-2
2-1. 115/230 Volt Conversion	2-2
3-1. Self-Check	3-8
4-1. Truth Table	4-2
4-2. Logic Levels	4-3
5-1. Assembly Identification	5-1
5-2. Recommended Test Equipment	5-2
5-3. In-Cabinet Performance Check	5-3
5-4. Adjustments	5-9
5-5. D.P. and Annunicator Troubleshooting	5-11
5-6. Frequency, D.P., and Annunicator Troubleshooting	5-12
5-7. DVM, D.P., and Annunicator Troubleshooting	5-13
6-1. Replaceable Parts, Standard Instruments	6-3
6-2. Replaceable Parts, Options	6-20
6-3. Manufacturers Code List	6-24
7-1. Manual Backdating Changes	7-3
7-2. A18 (05327-60009) Replaceable Parts	7-6
7-3. A18 (05327-60029) Replaceable Parts	7-7
7-4. A7 (05327-60004) Replaceable Parts	7-12

LIST OF FIGURES


Figure	Page
1-1. Model 5326B/5327B Timer Counter DVM	1-0
3-1. Hysteresis Offset	3-3
3-2. Hysteresis Compensation	3-3
3-3. Measurement Accuracy	3-4
3-4. Front Panel Controls and Indicators	3-5
3-5. Rear Panel Controls and Connectors	3-7
3-6. Frequency A Measurements	3-10
3-7. Frequency C Measurements	3-11
3-8. Period Measurements	3-12
3-9. Ratio Measurements	3-13
3-10. Time Interval Measurements	3-14
3-11. Digital Voltmeter and Read A Level, Read B Level Measurements	3-15
3-12. Totalize Measurements	3-16
4-1. Gate Symbols and Logic Comparisons	4-1
4-2. JK Flip-Flop	4-2
4-3. Time-Base Decode 1820-0412	4-2
4-4. Open-Collector Gate 1820-0327	4-2
4-5. Functional Block Diagram	4-3
4-6. Frequency A Model Flow Diagram	4-5
4-7. Frequency C Model Flow Diagram	4-5

LIST OF FIGURES (Continued)


Figure		Page
4-8.	Period Mode Flow Diagram	4-6
4-9.	Period Average Mode Flow Diagram	4-6
4-10.	Time Interval Mode Flow Diagram	4-7
4-11.	Time Interval Average Mode Flow Diagram	4-7
4-12.	DVM Model Flow Diagram	4-8
4-13.	Instrument Timing Diagram	4-9
6-1.	Panel Designations	6-2
7-1.	A18 Prescaler Board Assembly (Series 1040A) (5327B Only) Schematic Diagram	7-8
7-2.	A18 Prescaler Board Assembly (Series 1116A) (5327B Only) Schematic Diagram	7-9
7-3.	A18 (05327-60009) Component Locator	7-10
7-4.	A18 (05327-60029) Component Locator	7-11
7-5.	A7 Function Control Assembly (Series 1040A) Schematic Diagram	7-13
7-6.	A7 Function Control Assembly (05327-60004) Component Locator	7-14
8-1.	Schematic Diagram Notes	8-2
8-2.	Integrated Circuit Diagrams	8-3
8-3.	Model 5327B Front and Rear Panels	8-10
8-4.	Model 5327B Top Internal View	8-11
8-5.	A1 Attenuator Assembly	8-13
8-6.	A2, A3 Amplifier Trigger Assembly	8-15
8-7.	A4 Oscillator Assembly	8-17
8-8.	A5 Time Base Control Assembly	8-19
8-9.	A6 Sample Rate Assembly	8-21
8-10.	A7 Function Control Assembly	8-29
8-11.	A8 Display Support Assembly	8-31
8-12.	A9 Display Assembly Standard Instrument and Option 001	8-33
8-13.	A10 Right Readout Assembly	8-35
8-14.	A11 Left Readout Assembly	8-37
8-15.	A12 Voltmeter Input Amplifier Assembly	8-39
8-16.	A13 Voltmeter V to F Converter Assembly	8-41
8-17.	A14 Voltmeter Display Control Assembly	8-43
8-18.	A15, A16 Regulator Interconnect Board Assembly	8-45
8-19.	A17 Input C Amplifier Assembly (5326B Only)	8-47
8-20.	A18 Prescaler Board Assembly (5327B Only)	8-49
8-21.	Option 002, Remote Programming Cable Assembly and Rear Panel Connector Assembly	8-51
8-22.	Option 004, Remote Programming Cable Assembly and J10 Option 003, Digital Recorder Cable Assembly	8-53
8-23.	A1 Option 004 Programmable Attenuator Assembly	8-55
8-24.	Options 010, 011, and A16 Interconnect Circuit Board	8-57
8-25.	Interconnection Diagram	Insert

Model 5326/27B
General Information


Figure 1-1. HP Model 5326B/5327B Timer/Counter/DVM



MODEL 5326B



MODEL 5327B



POWER CORD

SECTION I GENERAL INFORMATION

1-1. DESCRIPTION

1-2. The Hewlett-Packard Model 5326B/5327B are frequency counters that have a variety of functions. The basic difference between the two models is the addition of the prescaler assembly in the 5327B. This assembly increases the upper frequency limit from 50 MHz to 500 MHz. The 5326B uses a high-sensitivity, 50-ohm input amplifier in place of the prescaler.

1-3. The instrument measures frequency, period, period average, time interval, time interval average, and ratio. The DVM (digital voltmeter) portion of the instrument measures dc voltages up to 1000 volts and provides a direct readout of the voltage and polarity of the counter's trigger levels. The model features a 7-digit display (8 digits optional), 1M ohm and 50-ohm inputs, display storage, and blanking for insignificant digits in the display. Decimal point and unit readouts are displayed automatically with each operating selection. Two independent input channels are provided for time interval measurements. Each input channel has an attenuator, trigger slope selector, level control, ac-dc coupling, and an oscilloscope marker output. Table 1-3 lists the electrical and mechanical specifications.

1-4. IDENTIFICATION

1-5. Hewlett-Packard uses a two-section serial number mounted on the rear panel. Earlier instruments use an 8-digit serial number (000-00000). The first three digits are a serial prefix number; the last five digits refer to the specific instrument. Later instruments use a 9-digit serial number (0000A0000). The first four digits are the serial prefix and the last five digits refer to the specific instrument. If the serial prefix of your instrument differs from that listed on the title page of this manual, there are differences between this manual and your instrument. Lower serial prefixes are documented in Section VII, and higher serial prefixes are covered with manual change sheets included with the manual. If the change sheet is missing, contact the nearest Hewlett-Packard Sales and Service Office listed on the inside rear cover of this manual.

1-6. APPLICATIONS

1-7. The 5326B/5327B Counters are particularly adaptable to timing measurements such as pulse width, pulse repetition frequency, and propagation delay. The time interval average mode measures time interval on repetitive signals with resolution better than one nanosecond. When used with micro wave

test systems, group delay, phase, and level measurements can be performed.

1-8. OPTIONS

1-9. The instrument can be ordered with the following options: Option 001, 8-digit display; Option 002, remote programming; Option 003, digital recorder outputs; Option 004, remote programming for all signal input conditions; Option 010, temperature compensated oscillator; Option 011, HP 10544A oven oscillator.

Table 1-1. Equipment Supplied

Description	HP Part No.
Detachable Power Cord, 7.5 ft. (231 cm) long)	8120-1378
Rack Mounting Kit	05326-60046

Table 1-2. Accessories Available

Description	HP Part No.
Digital Recorders	5050B, 5055A
Interconnect Cable, Digital Recorder, 6 ft (183 cm)	562A-16C
50-ohm BNC to BNC Coaxial Cable, 4 ft (122 cm)	10503-6001
Circuit Board Extender, 15-pin (two required)	5060-0049
Input Amplifier Circuit Board Extender	10532-60001
Circuit Board Extender, 18-pin	5060-2041
Extender Board Kit; includes two 5060-0049, and one each 5060-2041, and 10532-60001	10532A

Table 1-3. Specifications

INPUT CHANNELS A AND B	
<p>Range: dc coupled: 0 to 50 MHz ac coupled: 20 Hz to 50 MHz</p> <p>Sensitivity: 0.1 V rms sine wave 0.3 V p-p pulse 8 ns minimum pulse width Sensitivity can be decreased by 10 or 100 times, using the ATTENUATOR switch.</p> <p>Impedance: 1 MΩ shunted by less than 25 pF.</p> <p>Dynamic Input Voltage Range: 0.1 to 3 V rms ac times attenuator setting, ±5 Vdc times attenuator setting.</p> <p>Trigger Level: PRESET to center triggering about 0 V or variable over the range of -3 V to +3 V times attenuator setting. Trigger threshold band ±1.0 mV, referred to input at maximum frequency.</p> <p>Overload Protection: 250 V rms on all attenuator settings, except 25 V rms on XI above 50 kHz.</p> <p>Slope: Independent selection of positive or negative slope.</p> <p>Channel Inputs: Common or separate lines.</p> <p>Marker Outputs: Rear panel BNC's DTL pulse, low for approximately 2 μs after trigger point for A and B channels.</p>	<p>Sensitivity: 5 mV rms. Impedance: 50Ω nominal. Maximum Input: 5 volts rms; 7.5 volts peak. Trigger Level: 0 volts.</p> <p style="text-align: center;">CAUTION Do not exceed voltage specification or damage will occur.</p> <p style="text-align: center;">START (Totalizing and Scaling)</p> <p>Range: 0 to 10 MHz. Factor: 1 to 10³ selectable in decade steps. Output: Rear panel TIME BASE BNC. Display: Channel A input divided by scaling factor.</p> <p style="text-align: center;">FREQUENCY</p> <p>Range: 0 to 50 MHz (5326B), 0 to 550 MHz (5327B). Input: Channel A; Channel C for direct and for prescaled (switchable). Channel A provides triggered frequency measurement. Gate Times: 0.1 μs to 10 s in decade steps. Accuracy: ±1 count displayed* ± time base accuracy Display: kHz, MHz, or GHz with positioned decimal point.</p> <p style="text-align: center;">TIME INTERVAL</p> <p>Range: 0.1 μs to 10³ seconds. Input: Channel A and B; can be common or separate. Frequency Counted: 10 MHz to 0.1 Hz selectable in decade steps Accuracy: ±1 count ± time base accuracy ± trigger error.** Display: μs, ms, seconds, or 10's of seconds with positioned decimal point.</p> <p>*When prescaled by 10, ±1 count displayed is ±10 counts of the input signal. **For any waveshape, trigger error is less than</p> $\frac{0.0025}{\text{Signal Slope (V } \mu\text{s)}} \mu\text{s}$
INPUT CHANNEL C	
<p>5327B</p> <p>Range: direct: 0 to 50 MHz, dc coupled prescaled: 0 to 550 MHz, dc coupled.</p> <p>Sensitivity: direct: 15 mV rms. prescaled: 25 mV rms.</p> <p>Impedance: 50Ω nominal.</p> <p>Maximum Input: 3.5 volts rms; 5 volts peak.</p> <p>Trigger Level: 0 volts.</p>	
<p>5326B</p> <p>Range: 0 to 50 MHz, dc coupled.</p>	

Table 1-3. Specifications (Continued)

TIME INTERVAL AVERAGE	RATIO																																								
<p>Range: 0.15 ns to 10 seconds.</p> <p>Intervals Averaged: 1 to 10⁶ selectable in decade steps.</p> <p>Input: START - Channel A; STOP - Channel B can be separate or common.</p> <p>Frequency Counted: 10 MHz.</p> <p>Accuracy: \pm time base accuracy \pm 2 ns (trigger error** \pm 100 ns) $\sqrt{\text{intervals averaged}}$</p> <p>Dead Time: Minimum time between STOP (Channel B trigger) and START (Channel A trigger): 150 ns.</p> <p>Display: ns, μs with positioned decimal point.</p> <p>Read A; Read B Display: (Model 5326B and 5327B only). Trigger level of Channel A or B, displayed to hundredths of a volt. Effective trigger level is display times attenuator setting.</p>	<p>Display: (Any input Function) F_{EXT} times MULTIPLIER (M) M = 1 to 10⁶ (10 to 10⁶ when prescaling) selectable in decade steps.</p> <p>Range: Input Function: see appropriate function section. F_{EXT} (external Oscillator Input) 100 Hz to 10 MHz.</p> <p>Model: Any input function.</p> <p>Accuracy: Accuracy of selected input function \pm trigger error of F_{EXT}.</p>																																								
PERIOD	INTEGRATING DIGITAL VOLTMETER																																								
<p>Range: 0 to 10 MHz.</p> <p>Input: Channel A.</p> <p>Frequency Counted: 10 MHz to 0.1 Hz selectable in decade steps.</p> <p>Accuracy: \pm 1 count \pm time base accuracy \pm trigger error.***</p> <p>Display: μs, ms, seconds, 10's of seconds with positioned decimal point.</p>	<p>Technique: Voltage-to-frequency conversion</p> <p>Voltage Ranges: Manual selection.</p> <table border="1"> <thead> <tr> <th>Range</th> <th>Resolution</th> <th>Input Impedance</th> </tr> </thead> <tbody> <tr> <td>(Vdc)</td> <td>(1 sec integration time)</td> <td></td> </tr> <tr> <td>10</td> <td>100 μV</td> <td>10 MΩ</td> </tr> <tr> <td>100</td> <td>1 mV</td> <td>10 MΩ</td> </tr> <tr> <td>1000</td> <td>10 mV</td> <td>10 MΩ</td> </tr> </tbody> </table> <p>Input: Single ended.</p> <p>Polarity: Automatic polarity detection.</p> <p>Overrange: 25% overrange on 10 V and 100 V ranges with full accuracy.</p> <p>Overload Protection: 1100 Vdc all ranges.</p> <p>Accuracy: After 10 minutes warm-up (within 90-day calibration period), time base set to 1 sec</p> <table border="1"> <thead> <tr> <th>Range</th> <th>Stability</th> <th>Linearity</th> <th>Zero Offset</th> <th>Counter</th> </tr> <tr> <td></td> <td>(% of Reading)</td> <td>(% of Range)</td> <td>(% of Range)</td> <td></td> </tr> </thead> <tbody> <tr> <td>10V</td> <td>\pm0.04%</td> <td>\pm0.01%</td> <td>\pm0.01%</td> <td>\pm1 count</td> </tr> <tr> <td>100 V</td> <td>\pm0.04%</td> <td>\pm0.01%</td> <td>\pm0.01%</td> <td>\pm1 count</td> </tr> <tr> <td>1000 V</td> <td>\pm0.08%</td> <td>\pm0.01%</td> <td>\pm0.01%</td> <td>\pm1 count</td> </tr> </tbody> </table>	Range	Resolution	Input Impedance	(Vdc)	(1 sec integration time)		10	100 μ V	10 M Ω	100	1 mV	10 M Ω	1000	10 mV	10 M Ω	Range	Stability	Linearity	Zero Offset	Counter		(% of Reading)	(% of Range)	(% of Range)		10V	\pm 0.04%	\pm 0.01%	\pm 0.01%	\pm 1 count	100 V	\pm 0.04%	\pm 0.01%	\pm 0.01%	\pm 1 count	1000 V	\pm 0.08%	\pm 0.01%	\pm 0.01%	\pm 1 count
Range	Resolution	Input Impedance																																							
(Vdc)	(1 sec integration time)																																								
10	100 μ V	10 M Ω																																							
100	1 mV	10 M Ω																																							
1000	10 mV	10 M Ω																																							
Range	Stability	Linearity	Zero Offset	Counter																																					
	(% of Reading)	(% of Range)	(% of Range)																																						
10V	\pm 0.04%	\pm 0.01%	\pm 0.01%	\pm 1 count																																					
100 V	\pm 0.04%	\pm 0.01%	\pm 0.01%	\pm 1 count																																					
1000 V	\pm 0.08%	\pm 0.01%	\pm 0.01%	\pm 1 count																																					
PERIOD AVERAGE																																									
<p>Range: 0 to 10 MHz.</p> <p>Periods Averaged: 1 to 10⁶ selectable in decade steps.</p> <p>Input: Channel A.</p> <p>Frequency Counted: 10 MHz.</p> <p>Accuracy: \pm time base accuracy \pm 1 count displayed* \pm trigger error***</p> <p>Display: ns, μs, with positioned decimal point</p>	<p>***Trigger error is less than \pm0.3% of one period - periods averaged for signals with 40 dB or better signal-to-noise ratio and 100 mV rms amplitude.</p>																																								

Table 1-3. Specifications (Continued)


Operating Temperature: 10°C to 40°C, -80% RH.

Measurement Time:

1 msec	2 digits	} Decimal points automatically displayed
10 msec	3 digits	
100 msec	4 digits	
1 sec	5 digits	
10 sec	6 digits	

Response: <100 μs for full accuracy with a step function input.

AC Noise Rejection: Infinite for multiples of (meas-time) 5. See graph for Normal Mode Rejection below.



TIME BASE

Crystal Frequency: 10 MHz.

Stability: Aging Rate: <3 parts in 10⁶ mo.
Temperature: <±2.5 parts in 10⁶, 0° to 50°C.
Line Voltage: <±1 part in 10⁶ for 10% line variation

Short-term Fluctuation: Typically <5 parts in 10⁶ rms (typical) one-second average (at constant temperature).

Oscillator Output: 10 MHz, TTL type output levels, 50Ω series impedance at rear panel BNC.

External Input: 100 Hz to 10 MHz; 1 V rms into 1kΩ.

Time Base Output: Negative pulses, +3 V to 0 V (open circuit), typically 100 ns wide. In START, output frequency is INPUT A divided by TIME BASE MULTIPLIER switch setting. Available at rear panel BNC.

Gate Output: TTL level pulses; low while gate open, high while gate closed. Available at rear panel BNC.

GENERAL

Display: 7 digits (8 optional).

Blanking: Suppresses display of unwanted zeros left of the most significant digit.

Display Storage: Holds reading between samples. Rear panel switch overrides storage.

Sample Rate: FAST position: Continuously variable from less than 100 μs to approximately 20 ms. NORM position: Continuously variable from less than 20 ms to approximately 5 seconds. HOLD position: Display can be held indefinitely.

Overflow: Neon indicates when display range is exceeded.

Operating Temperature: 0° to 50°C (see DVM Temperature Range).

Power Requirements: 115 or 230 volts ±10%, 50 to 60 Hz, 70 watts maximum.

Weight: Net, 16 lb. (7.4 kg). Shipping, 18 lb. 16 oz. (8.7 kg).

Accessories Furnished: Power Cord, 7 ft. Rack Mount Kit.

DIMENSIONS




Table 1-3. Specifications (Continued)

ACCESSORIES AVAILABLE	
HP 10503A, 50-ft BNC Cable, 4 ft (122 cm).	
HP 10532A, Extender Board Kit containing 2 ea. 15-pin extender 5060-0049, 1 ea. 18-pin extender 5060-2041, and 1 ea. Amplifier Extender, 10532-60001.	
HP 10542A, Remote Programming Interface enables interfacing between the 5326 5327 Series counter with Option 004 and 40-bit Output Register. Includes two (2) 7-bit Digital-to-Analog Converters for level controls and decoding for time base and function selector.	
HP Cable 562A-16C, 6 ft (183 cm) to connect 5326 5327 Series with Option 003 to HP 5050B or 5055A Digital Recorder.	
OPTIONS	
Option 001: 8-digit display.	
Option 002: Remote Programming.	
Controls: All front panel controls are single line programmable except: SEP-COM (separate-common) switch; the check function is programmable. FAST NORM Mode. Input Attenuators. AC/DC Input Signal Coupling	
Control Signal: Single line control using either contact closure to ground or DTL drive on all lines except trigger levels which are analog programmed (± 3 Vdc).	
Connector: Rear panel connector: HP 1251-0085; Amphenol 57-40500-375. (36-pin blue ribbon.) Mating connector: HP 1251-0084; Amphenol 57-30500-375 (not supplied).	
Option 003: Digital output (for numerals and polarity only).	
Code: 4-line 1-2-4-8 BCD, "1" state high, "0" state ± 0.25 V at -1 mA; "1" state: ± 5 V open circuit, 2.5 k Ω source impedance nominal.	
Print Command: ± 5 V to 0 V, de coupled; occurs at end of gate.	
Storage: Buffer storage is provided so BCD output is constant while next measurement is being made.	
Inhibit Input: Inhibits gate when instrument's cycle time is less than the time required for external equipment to interrogate BCD outputs. Positive inhibit ± 5 Vdc.	
Connector: Rear panel connector: HP 1251-0087; Amphenol 57-40500-375 (50-pin blue ribbon). Mating connector: HP 1251-0086; Amphenol 57-30500-375 (not supplied).	
Option 004: Remote Programming including all signal input conditions.	
Controls: All front panel controls are programmable except FAST NORM Mode.	
Control Signal: Single line control using either contact closure to ground or DTL drive on all lines except trigger levels which are analog programmable (± 3 Vdc).	
Connector: Rear panel connector: HP 1251-0087; Amphenol 57-40500-375 (50-pin blue ribbon). Mating Connector: HP 1251-0086; Amphenol 57-30500-375 (not supplied).	
Option 010 Temperature Compensated Oscillator: Aging Rate: $\pm 1 \times 10^{-6}$ month. Temperature Stability (0° to 50 °C): $\pm 5 \times 10^{-6}$. Short Term Fluctuation (1 sec avg): $\pm 1 \times 10^{-6}$ rms (typical). Warm-Up: room temp crystal. Line Voltage (10% change): $\pm 5 \times 10^{-6}$.	
Option 011 HP 10544A Oven Oscillator: Aging Rate: $\pm 5 \times 10^{-7}$ day. Temperature Stability (0° to 50 °C): $\pm 5 \times 10^{-6}$. Short Term Fluctuation (1 sec avg): $\pm 1 \times 10^{-6}$ rms. Warm-Up: $\pm 5 \times 10^{-6}$ in 15 min. Line Voltage (10% change): $\pm 5 \times 10^{-6}$.	

SECTION II

INSTALLATION

2-1. INTRODUCTION

2-2. This section contains information for unpacking, inspection, repacking, storage, and installation. The instructions for remote programming are also given in this section.

2-3. UNPACKING AND INSPECTION

2-4. If the shipping carton is damaged, as that the carrier's agent be present when the instrument is unpacked. Inspect the instrument for damage (scratches, dents, broken knobs, etc.). If the instrument is damaged or fails to self-check (Self-Check Procedures, Table 3-1), notify the carrier and nearest Hewlett-Packard Sales and Service Office immediately (offices are listed at the back of this manual). Retain the shipping carton and padding material for the carrier's inspection. The sales and service office will arrange for the repair or replacement of your instrument without waiting for the claim against the carrier to be settled.

2-5. STORAGE AND SHIPMENT

2-6. **PACKAGING.** To protect valuable electronic equipment during storage or shipment always use the best packaging methods available. Your Hewlett-Packard Sales and Service Office can provide packing material such as that used for original factory packaging. Contract packaging companies in many cities can provide dependable custom packaging on short notice. Here are two recommended packaging methods:

a. **RUBBERIZED HAIR.** Cover painted surfaces of instrument with protective wrapping paper. Pack instrument securely in strong corrugated container (350 lb/sq. in. bursting test) with 2-inch rubberized hair pads placed along all surfaces of the instrument. Insert fillers between pads and container to ensure a snug fit.

b. **EXCELSIOR.** Cover painted surfaces of instrument with protective wrapping paper. Pack instrument in strong corrugated container (350 lb/sq. in. bursting test) with a layer of excelsior about six inches thick packed firmly against all surfaces of the instrument.

2-7. **ENVIRONMENT.** Conditions during storage and shipment should normally be limited as follows:

- Maximum altitude: 25,000 feet.
- Minimum temperature: -40°F (-40°C).
- Maximum temperature: $+167^{\circ}\text{F}$ ($+75^{\circ}\text{C}$).

2-8. RACK INSTALLATION

2-9. The counter is ready for bench operation as shipped from the factory. Additional parts necessary for rack mounting are packaged with the instrument. To convert to rack installation, proceed as follows:

- Remove tilt stand.
- Remove feet (press the foot-release button, slide foot toward center of instrument, and lift off).
- Remove adhesive-backed trim strips at front end of sides.
- Attach filler strip along bottom edge of front panel using two screws on outer edges of filler strip. Omit the center screw.
- Attach flanges to front end of sides (larger corner notch toward bottom of instrument). Instrument is now ready to mount in standard rack.

CAUTION

Ambient temperature in rack during operation should not exceed 104°F (40°C). Be sure instrument position in rack permits adequate air circulation and that nearby equipment does not discharge hot air directly on the instrument.

2-10. POWER CONNECTION

2-11. **LINE VOLTAGE.** The counter may be operated from either 115 or 230 volt ($\pm 10\%$) power lines with frequencies from 50 to 60 Hz. A slide switch on the rear panel permits quick conversion for operation from either voltage. Insert a narrow-blade screwdriver in the switch slot and slide the switch to the right for 230 volt operation ("230" marking exposed) or to the left for 115 volt operation ("115" marking exposed). The counter is supplied with a 115 volt fuse; be sure to change this fuse for 230 volt operation, see Table 2-1.

CAUTION

Before plugging instrument to ac power line be sure slide switch is properly positioned.

Table 2-1. 115/230 Volt Conversion

Line Voltage Conversion	115 Volt	230 Volt
Slide Switch	Left (115)	Right (230)
AC Line Fuse	1.50 Ampere (Slow-Blow) (HP 2110-0304)	0.8 Ampere (Slow-Blow) (HP 2110-0020)

2-12. **POWER CABLE.** The counter is equipped with a detachable 3-wire power cable. Proceed as follows for installation.

a. Connect plug (3-socket connector) to ac line jack at rear of instrument.

b. Connect plug (2-blade with round grounding pin) to 3-wire (grounded) power outlet. Exposed portions of instrument are grounded through the round pin on the plug for safety; when only 2-blade outlet is available, use connector adapter (HP Part No. 1251-0048), then connect short wire from side of adapter to ground.

2-13. REMOTE PROGRAMMING, OPTION 002

2-14. The following paragraphs describe remote programming requirements for the counter with Option 002. See Paragraph 2-36 for Option 004 programming.

2-15. Front Panel Controls

2-16. The following front-panel controls are programmable:

- a. FUNCTION
- b. TIME BASE MULTIPLIER
- c. DVM RANGE
- d. CHECK function
- e. SLOPE
- f. SAMPLE RATE and HOLD
- g. LEVEL controls
- h. Input Selector (5327B only)
- i. RESET

2-17. The following front-panel controls are NOT programmable:

- a. AC/DC
- b. SEP-COM
- c. FAST NORM
- d. ATTN

2-18. The trigger level controls may be remotely programmed or the front-panel LEVEL controls may be used. It is possible to program the LEVEL controls without programming the remainder of the front-panel controls. When remote programming is used, the LEVEL controls must be set to PRESET. Display time may be remotely programmed and/or the front-panel controls may be used.

2-19. Remote Programming Requirements

2-20. All lines may be controlled by TTL or DTL signals or contact closure to ground when the unit is being remotely programmed; except the trigger levels which are programmed by an analog level (if programmed) and the display time line (Hold), J10 pin 35, which should NOT be pulled up to +5 V by less than 200Ω while programming.

2-21. When the unit is NOT being programmed (EXT line high), all the lines should be left open or pulled up to +5 V by not less than 5kΩ, except the trigger levels, which should be open circuited.

2-22. Remote Programming Procedure

2-23. In order to remotely program the counter, the following must be done:

- a. Set FUNCTION switch to any function by START or STOP.
- b. Ground the EXT line at rear-panel REMOTE PROGRAM connector (J10(17)). Ground is available at J10(36).
- c. Select the desired function.
- d. Select the desired time base.
- e. Select the desired voltmeter range, if using DVM.
- f. Select the slope (+ or -) for CHANNEL A and B. This is accomplished by grounding the Slope line for (-) and leaving it open for (+). Slope A line is J10(28). Slope B line is J10(29).
- g. Select the trigger level for input signal.
- h. Adjust the display time.
- i. Manual reset is available by grounding (<7 V) pin 34. Check is available by grounding pin 14.

2-24. Function Selection Programming

2-25. To program the desired function, ground (<.7 V) the proper line at J10 as follows:

STOP	Pin 32
START	Pins 1 and 32
PERIOD AVERAGE	Pin 2
T.L. AVG.	Pin 3
T.L. A to B	Pin 4
PERIOD	Pin 5
FREQ. A	Pin 6
FREQ. C DIRECT	Pin 7
FREQ. C PRESCALE	Pins 7 and 18
READ A LEVEL	Pin 8
READ B LEVEL	Pin 9
DVM	Pin 10

2-26. Programming READ A or READ B automatically selects a 10 ms time base and a 10 V DVM range. If a program line for time base must be used, select 10 ms only (pin 24). When switching between START and STOP, do not remove the ground from pin 32.

2-27. Time Base Selection Programming

2-28. To program the Time Base, ground (<.7 V) the proper line at J10 as follows:

.1 μ s/1	Pin 19
1 μ s/10	Pin 20
10 μ s/10 ²	Pin 21
.1 ms/10 ³	Pin 22
1 ms/10 ⁴	Pin 23
10 ms/10 ⁵	Pin 24
.1 s/10 ⁶	Pin 25
1 s/10 ⁷	Pin 26
10 s/10 ⁸	Pin 27

2-29. Voltmeter Programming

2-30. When using the DVM mode, the time base should be programmed to 10 ms, .1 s, or 1 s. To program the voltmeter range, ground (<.7 V) the proper line at J10 as follows:

10 V	Pin 11
100 V	Pin 12
1000 V	Pin 13

2-31. Trigger Level Programming

2-32. To program the trigger level, the LEVEL controls must be set to PRESET. Select the trigger level by placing a dc voltage between -3.0 and +3.0 volts on the level input line (Level A = J10 pin 30, Level B = J10 pin 31). This voltage, times the attenuator setting, is the trigger level. Preset is programmed by leaving the pin open on contact closure to ground. Grounding is preferable if noise exists on the remote programming line.

2-33. The front-panel LEVEL controls may be used manually if programming of the trigger levels is undesirable. Also, note the AC/DC and ATTEN switches on the front-panel must be set manually, as they are NOT programmable.

2-34. Sample Rate Adjustment

2-35. Adjusting the display time can be accomplished in several ways:

a. Manually adjust the display time by using the front-panel SAMPLE RATE controls.

b. Set the SAMPLE RATE control cw and the FAST/NORM/HOLD switch to NORM and connect a 1 megohm pot in series with a 1.5k ohm resistor from +5 V to pin 35. This will give a display time range of about 10 ms to 5 sec. If a shorter time is desired, set the FAST/NORM/HOLD switch to FAST, which gives a range of about 50 μ s to 10 ms.

c. Set the SAMPLE RATE control cw in FAST and hold the Hold line (pin 35) to ground for the desired display time. The display will continue for about 100 μ s after the ground is released.

2-36. REMOTE PROGRAMMING, OPTION 004

2-37. The following paragraphs describe remote programming requirements for the counter with Option 004.

2-38. Front Panel Controls

2-39. All front-panel controls are programmable, except the FAST/NORM/HOLD switch. The trigger level controls may be remotely programmed, or the front-panel LEVEL controls may be used. It is possible to program the front-panel LEVEL controls without programming the remainder of the front-panel controls. When remote programming the trigger levels, the LEVEL controls must be set to PRESET. The display time may be remotely programmed and/or the front-panel controls may be used.

2-40. Remote Programming Requirements

2-41. All lines may be controlled by TTL or DTL signals or contact closure to ground when the unit is being remotely programmed: except the trigger levels

Model 5326/27B
Installation

which are programmed by an analog level (if programmed) and the display time line (Hold), J10 pin 16, which should NOT be pulled up to +5 V by less than 200Ω while programming.

2-42. When the unit is NOT being programmed (EXT line high), all the lines should be left open or pulled up to +5 V by not less than 5kΩ, except the trigger levels, which should be open circuited.

2-43. Remote Programming Procedure

2-44. In order to remotely program the counter, the following must be done:

- a. Set FUNCTION switch to any position but START or STOP.
- b. Ground the EXT line at rear-panel REMOTE PROGRAM connector (J1034). Ground is available at J10(1, 2, 15).
- c. Select the desired function.
- d. Select the desired time base.
- e. Select the voltmeter range, if using DVM.
- f. Select the signal conditioning.
- g. Select the trigger level for input signal.
- h. Adjust the display time.
- i. Manual reset is available by ground (<.7 V) pin 17. Check is available by grounding pin 37.

2-45. Function Selection Programming

2-46. To program the desired function, ground (<.7 V) the proper line at J10 as follows:

STOP	Pin 19
START	Pins 46, 19
PERIOD AVG A	Pin 47
T.I. AVG.	Pin 45
T.I. A to B	Pin 44
PERIOD	Pin 43
FREQ. A	Pin 42
FREQ. C DIRECT	Pin 41
FREQ. C PRESCALE (5327B only)	Pin 33
READ A LEVEL	Pin 48
READ B LEVEL	Pin 49
DVM	Pin 50

2-47. Programming READ A or READ B automatically selects a 10 ms time base and a 10 V DVM range. If a program line for time base must be used, select 10 ms only (pin 24). When switching between START and STOP, do not remove the ground from pin 19.

2-48. Time Base Selection Programming

2-49. To program the time base, ground (<.7 V) the proper line at J10 as follows:

.1 μs/1	Pin 28
1 μs/10	Pin 29
10 μs/10 ²	Pin 27
.1 ms/10 ³	Pin 26
1 ms/10 ⁴	Pin 25
10 ms/10 ⁵	Pin 24
.1 s/10 ⁶	Pin 30
1 s/10 ⁷	Pin 31
10 s/10 ⁸	Pin 32

2-50. Voltmeter Programming

2-51. When using the DVM mode, the time base should be programmed to 10 ms, .1 s, or 1 s. To program the voltmeter range, ground (<.7 V) the proper line at J10 as follows:

10 V	Pin 40
100 V	Pin 39
1000 V	Pin 38

2-52. Signal Conditioning Programming

2-53. Program the input conditions by grounding the proper line as follows:

CONDITION	LINE J10	INPUT
AC/DC A	11	AC = H DC = L
SLOPE A	23	+ = H - = L
ATTENUATOR A	13, 14	13 - H, 14 - H = X1 13 - L, 14 - H = X10 13 - H, 14 - L = X100
AC/DC B	7	AC = H DC = L
SLOPE B	22	+ = H - = L
ATTENUATOR B	9, 10	9 - H, 10 - H = X1 9 - L, 10 - H = X10 9 - H, 10 - L = X100
SEP/COM	6	COM = L, SEP = H
CHECK	37	CHK = L

2-54. Trigger Level Programming

2-55. To program the trigger level, the LEVEL controls must be set to PRESET. Select the trigger level by placing a dc voltage between -3.0 and $+3.0$ volts on the level input line (Level A = J10 pin 21, Level B = J10 pin 20). This voltage, time the attenuator setting, is the trigger level. Preset is programmed by leaving the pin open or contact closure to ground. Grounding is preferable if noise exists on the remote programming line.

2-56. The front-panel LEVEL controls may be used manually if programming of the trigger levels is undesirable.

2-57. Sample Rate Adjustment

2-58. Adjusting the display time can be accomplished in several ways:

a. Manually adjust the display time by using the front-panel SAMPLE RATE controls.

b. Set the SAMPLE RATE control cw and the FAST NORM HOLD switch to NORM and connect a 1 megohm pot in series with a 1.5k ohm resistor from $+5$ V to pin 16. This will give a display time range of about 10 ms to 5 sec. If a shorter time is desired, set the FAST NORM HOLD switch to FAST, which gives a range of about 50 μ s to 10 ms.

c. Set the SAMPLE RATE control cw in FAST and hold the Hold line (pin 16) to ground for the desired display time. The display will continue for about 100 μ s after the ground is released.

2-59. Sample Rate Disable-Computer Inhibit

2-60. The sample rate disable line is used only with the start command to initiate a totalizing measurement. The sample rate disable command disables auto reset and enables continuous plus and minus transfer commands.

2-61. The computer inhibit command (when Low) inhibits the main gate from opening. This command may be sent from a computer to prevent the counter from making any further measurements. It may also be used as an external sample rate signal, since the command would determine the time between measurements. Auto reset and print command signals are not disabled by computer inhibit.

NOTE

DO NOT ground or otherwise program any of the remote programming lines if the unit is not being operated remotely (EXT line HIGH - not programmed remotely). The line should be left open or, at worst, be pulled up to $+5$ V by a source impedance of not less than 5 k Ω .

2-62. BLANKING DEFEAT

2-63. This counter is designed to blank insignificant zeros (zeros to left of data). When blanking occurs, the digital recorder output for the blanked columns is BCD 15 (HHHH). To use this instrument with a digital-analog converter, it is necessary to defeat the blanking feature by repositioning the two jumpers on the A9 Display board. Move the jumpers to position 2, as shown in A9 Component Locator (Section VIII). This connects pin 10 of A9U17 and A9U18 to $+5$ V. Also, lift the pin 1 lead of A8U2 and connect pin 1 to ground (available at U2 pin 7).

SECTION III OPERATION

3-1. INTRODUCTION

3-2. Section III contains the operating information required to obtain the most effective performance from the instrument. This includes a general description of the operating modes, the function of all controls and indicators, a self-check procedure, and setup procedures for making basic measurements.

3-3. OPERATING MODES

3-4. The following paragraphs describe the operating modes of totalize, frequency, period, time interval, ratio, and DVM.

3-5. Totalize Mode

3-6. START and STOP positions on the FUNCTION selector allow manual opening and closing of the counter's main gate. When the switch is in the START position, the counter does not measure frequency, but instead, counts the number of times the signal passes through the trigger point. The input signal, connected to the front-panel CHANNEL A jack, is divided by the MULTIPLIER switch setting prior to counting. For example, when the MULTIPLIER switch is set to the 1 position, every pulse is counted. When the switch is set to 10^3 , the counter registers every thousandth pulse. When the FUNCTION switch is set to STOP, the counter stops totalizing and holds the displayed count until the RESET switch is pressed or the MULTIPLIER switch setting is changed. If the FUNCTION switch is again set to START before a reset is generated, the count continues to totalize from the previously displayed value. With the FUNCTION switch set to START, the scaled input signal is available at the rear-panel TIME BASE OUTPUT jack. The unit indicators and decimal points are blanked during the totalize mode. The C light is on (in START), indicating counting is taking place.

3-7. Frequency Modes

3-8. Three frequency modes are available in the 5327B: Frequency A, Frequency C prescaled, and Frequency C direct. (The prescale operation is not included in the 5326B.) In the Frequency A mode, the input signal connects to the high impedance CHANNEL A input jack and can be conditioned with the LEVEL, SLOPE, and ATTEN controls. In the Frequency C modes, the input signal is connected to the INPUT C jack (50 ohm), located on the rear panel. The signal is not conditioned by any front-panel controls but may be counted either directly (50 MHz) or

by prescaling (550 MHz), depending on the setting of the Input Selector switch. The INPUT C of the 5326B model counts the signal directly.

3-9. Period Modes

3-10. The period and period average modes allow single period measurements or multiple period averages to be made with input frequencies into CHANNEL A of up to 10 MHz. These modes are useful for making low frequency measurements where maximum resolution is desired.

3-11. For single period measurements, the MULTIPLIER switch scales the time base frequency and selects the placement of the decimal point and determines the resolution of the measurement.

3-12. The period average mode is used for increased resolution and reduced inaccuracies. For example, if 10^2 period averaging is selected, the counter will display the average of 100 periods with the proper decimal point. In this example, trigger error is 100 times less than in a single period measurement.

3-13. Time Interval Modes

3-14. Two modes of time interval measurements can be selected: time interval and time interval average. The time interval modes measure the time between points on a single waveform or between separate input signals; thus, pulse width and phase differences can be measured. Separate slope and level controls allow variable triggering levels on either the + or - slope. Marker A and B outputs are available at the rear panel to intensity-modulate an HP 180A oscilloscope. The markers indicate the trigger point of the counter's input circuits and provide a visual means of adjusting the trigger points to measure the time interval between any two points and are useful to about 100 kHz.

3-15. In time interval measurements, Channel A opens the main gate and Channel B closes the main gate. While the main gate is open, the internal oscillator, divided by the setting of the MULTIPLIER switch, is totalized by the counter and readout on the display. The less the division factor, the more pulses of the internal oscillator there are to count and, therefore, the better the resolution and accuracy.

3-16. With time interval average, the main gate is open for the number of time intervals selected by the MULTIPLIER switch. The internal oscillator pulses (not divided) are totalized only during the individual time intervals. Once Channel B triggers, there must

be a time lapse of 150 ns before Channel A can trigger. Averaging of time intervals results in increased resolutions and reduced inaccuracies. For a further explanation of theory, refer to Paragraph 4-45 and Figure 4-9.

3-17. Digital Voltmeter Measurements

3-18. Three modes of voltmeter measurements can be selected: READ A LEVEL, READ B LEVEL, and DVM. In the READ A and B modes, the digital voltmeter indicates the trigger level of the input amplifiers. The trigger level is equal to the DVM reading times the attenuator setting. In the DVM mode, dc levels up to 1000 V can be applied. Three ranges are provided: 10 V, 100 V, and 1000 V. The 10 V and 100 V ranges have 25% over-ranging with full accuracy. Maximum input voltage any any range is 1100 V. Resolution of the DVM with a 1-second integration time is 100 μ V on the 10 V range, 1 mV on the 100 V range, and 10 mV on the 1000 V range. Since there is no over-range indicator, ranges should be changed whenever a 12.5 V readout is obtained on the 10 V range or 125 V readout on the 100 V range.

3-19. The READ A LEVEL and READ B LEVEL modes automatically select a 10 ms time base and a 10 V range. In the DVM mode, the counter displays the proper decimal point and annunciator when the time base is 10 ms, .1 s, or 1 s. A longer integration time does not result in increased accuracy.

3-20. Ratio

3-21. The counter may be used to measure the ratio of two signals in either the frequency or period mode. By setting the rear-panel OSC INT-EXT switch to EXT, the counter will accept an external signal (F_{ext}) for use as the internal oscillator. This frequency should be 100 Hz to 10 MHz at 1 V rms minimum to 5 V peak maximum. A second signal (F_A), applied to either INPUT A or C jack, is used as the comparator signal.

The MULTIPLIER switch controls the resolution of the display. For a ratio of frequencies, the Ratio = $\frac{F_A}{F_{ext}} = \frac{\text{DISPLAYED NUMBER}}{\text{MULTIPLIER SETTING}}$. For a ratio of periods (P), the Ratio =

$$\frac{P_A}{P_{ext}} = \frac{F_{ext}}{F_A} = \frac{\text{DISPLAYED NUMBER}}{\text{MULTIPLIER SETTING}}$$

3-22. Disregard the units and decimal point; also, ignore any zeros to the left of the most significant digit. It makes no difference which signal is higher in frequency, as long as the two frequencies are within the specifications of their respective channels.

3-23. MARKER OUTPUTS

3-24. Two marker output jacks are mounted on the counter's rear panel. These outputs provide a negative-going 2 μ s pulse (approx.) at DTL levels each time the input signal passes through the trigger point of Channel A or B. The pulses may be used to trigger other circuits or may be applied to the Z axis of an HP 180 Oscilloscope. When using the pulses to intensity modulate an oscilloscope, note that the actual trigger point is the leading edge of the pulse. The marker's pulse width determines the upper frequency limit of the input signal. The pulses overlap on the oscilloscope trace when the period of the signal is less than the pulse width.

3-25. HYSTERESIS

3-26. Each input channel has a small amount of hysteresis (about 100 mV). If the SLOPE switch is set to "+," the trigger pulse occurs at the top of the hysteresis "window." If the SLOPE switch is set to "-", the pulse occurs on the bottom line of the window. In other words, the signal must pass through the entire hysteresis window before a trigger pulse is generated.

3-27. When measuring frequency or period, the counter positions the hysteresis band around zero (see Figure 3-1). This assumes a waveform with no dc component and the counter's LEVEL control is in the PRESET position. The input amplifier then yields maximum input sensitivity for both positions of the SLOPE switch. The preset introduces no measurement error, since the trigger point is repetitive from cycle to cycle. The trigger point is point A for + slope and point B for - slope.

3-28. Time Interval Compensation

3-29. In the time interval modes and READ A/READ B modes only, both input amplifiers have an automatic compensation network that keeps the trigger level at the same potential when switching from positive to negative slope (see Figure 3-2). The window shifts upward to accomplish this. There is the possibility, therefore, that if Point A is near the top of the signal, switching to negative slope will place a portion of the window outside the signal (C). In such case, there would be no triggering. When switching from time interval to frequency, or vice versa, the trigger point shifts by half the hysteresis band.

Figure 3-1. Hysteresis Offset





Figure 3-2. Hysteresis Compensation



3-30. ACCURACY

3-31. **FREQUENCY MEASUREMENTS.** The basic counter accuracy is determined by two factors. One factor is the aging rate of the 10 MHz crystal standard in the time base (less than 3 parts in 10^7 per month). A second factor is the inherent error of ± 1 count of the display's least significant digit, which is present in all electronic counters. This error is due to phasing between the timing pulse that operates the electronic gate and the pulses that pass through the gate to the counting assembly. The chart in Figure 3-3 shows the error possible for frequency and period measurements.

3-32. The formula for determining the actual frequency is given as follows:

$$\text{error} = \pm \left(\frac{1}{f_1 \times \text{gate length (sec)}} \right) \pm E$$

The expression
$$\frac{1}{f_1 \times \text{gate length (sec)}}$$

equals the ± 1 count ambiguity, where f_1 equals measured frequency (Hz) and gate length equals the selected gate time in seconds. E equals the time base accuracy (monthly drift rate of the individual time base times the number of months since calibration, frequency change due to ambient temperature change, absolute off-set at standardization, and line voltage effects).

3-33. An example of frequency error calculation is as follows:

$$f_1 = 3 \text{ McHz } (3 \times 10^6 \text{ Hz})$$

gate length = .1 sec (1×10^{-1})

$$E = 3 \text{ parts in } 10^7 \text{ per month times 2 months} \\ = 6 \text{ parts in } 10^7$$

$$\text{error} = \frac{1}{3 \times 10^6} \pm \frac{6}{10^7}$$

$$= 3.3 \times 10^{-7} \pm 6 \times 10^{-8} = 3.9 \times 10^{-7}$$

or 3.9 parts in 10^6

3-34. **PERIOD MEASUREMENTS.** There are three factors contributing to the accuracy of period measurements:

- The aging rate of the 10 MHz crystal standard.
- The ± 1 count ambiguity.
- The trigger error for one period.

Assuming a signal-to-noise ratio of 40 dB, the trigger error is less than 0.3% at rate sensitivity. A general formula for finding the percentage error to be expected under various conditions is as follows:

$$A = 100 \left(\pm \frac{f_2}{nf_1} \pm \frac{e}{n} \pm E \right)$$

A = Accuracy in percent

f_1 = Time base frequency counted

f_2 = Frequency of input signal (Hz)

n = Number of periods averaged

e = 3×10^{-3} (trigger error for one period, 40 dB S/N at rated sensitivity.)

E = time base accuracy (monthly drift rate of individual time base times the number of months since calibration, absolute value of off-set at standardization, frequency change due to ambient temperature change, and line voltage effects). A plot of the above formula is shown in Figure 3-3.

Figure 3-3. Measurement Accuracy





Figure 3-4. Front Panel Controls and Indicators




1. **SAMPLE RATE control.** Applies primary power. Works in conjunction with FAST NORM/HOLD switch to control interval between measurements.
 - a. **FAST** - Varies display time from $<100 \mu\text{s}$ to $>20 \text{ ms}$. STORAGE switch (rear panel) must be ON to use this mode.
 - b. **NORM** - Varies display time from $<20 \text{ ms}$ to $>5 \text{ seconds}$.
 - c. **HOLD** - Holds display indefinitely.
2. **RESET Switch.** Resets display and internal count to zero and starts new measurement.
3. **RANGE - DVM INPUT.** Input jack and range switch for de integrating digital voltmeter. Maximum input level is 1100 volts.
4. **FUNCTION selector.** Selects mode of operation. Blue lettering matches corresponding blue lettering on TIME BASE/MULTIPLIER switch.
 - a. **STOP, START** - Used for totalize mode to manually open and close counter's main gate and to turn scaled output on and off. Frequency input range is 0 to 10 MHz.
 - b. **PERIOD AVG A** - Sets counter to measure period of signal applied to CHANNEL A input. Use MULTIPLIER switch to select; number of periods to be averaged. Input frequency range is 0 to 10 MHz.
 - c. **T.I. AVG A to B** - Sets counter to measure average time interval, A to B. Channel A starts interval and Channel B stops the interval. Use MULTIPLIER selector to set number of time intervals to be averaged. Time interval input range is 150 ps to 10 sec; there must be a 150 ns deadtime between intervals.
 - d. **T.I. A to B** - Sets counter to measure time interval A to B. Channel A starts measurement and Channel B stops the measurement. T.I. input range is 0.1 μs to 10⁷ sec. The internal time base frequency is divided by the setting of the MUTLIPLIER switch and totalized for subsequent display. The more cycles of the oscillator frequency that are counter during A to B time, the better the resolution. There must be 150 ns deadtime between Channel B and Channel A trigger points.
 - e. **PERIOD A** - Sets counter to measure a single period of the signal applied to CHANNEL A input. Use MUTLIPLIER switch to set counted internal oscillator frequency and therefore the desire resolution. Frequency input range is 0 to 10 MHz.
 - f. **FREQ A** - Sets counter to measure frequency applied to CHANNEL A input. Use TIME BASE switch to set gate time and resolution. Frequency input range is 0 to 50 MHz.

Figure 3-4. Front Panel Controls and Indicators (Continued)

- g. **FREQ C** - Similar to **FREQ A**, except sets counter to measure frequency applied to **INPUT C** jack. 50-ohm input impedance. 3.5 V rms to 5 V peak maximum input. Frequency range is 0 to 550 MHz prescaled or 0 to 50 kHz direct. On the 5326B, the frequency range is 0 to 50 MHz. See **INPUT C**.
- h. **READ A LEVEL** - Sets counter to measure trigger voltage of **LEVEL A** control. Trigger level = DVM readout times **ATTEN** setting. See **TIME BASE/MULTIPLIER** switch.
- i. **READ B LEVEL** - Same as **READ A LEVEL** for **LEVEL B** control.
- j. **DVM** - Sets counter to measure dc voltage applied to **DVM INPUT** jack. Use **TIME BASE/MULTIPLIER** switch to select integration time and resolution.
5. **TIME BASE/MULTIPLIER** switch. The function of the switch changes with each mode of operation:
- a. **TOTALIZE** - Determines scaling factor for input signal prior to counting.
 - b. **PERIOD AVG A** - Selects number of periods to be averaged.
 - c. **T.I. AVG A to B** - Selects number of time intervals to be averaged.
 - d. **T.I. A to B** - Selects scaling factor for internal oscillator signal.
 - e. **PERIOD A** - Selects scaling factor for internal oscillator signal.
 - f. **FREQ A and FREQ C** - Sets gate time.
 - g. **READ A LEVEL and READ B LEVEL**. Not operative. 10 ms integration time is automatically selected.
 - h. **DVM** - Selects DVM integrating time. Decimal point and measurement units are displayed for 10 ms, .1 s, and 1 s settings only.
6. **SLOPE** switch. Permits triggering on positive or negative slope of input signal.
7. **AC-DC** switch. Selects direct or capacitor coupling for input signal. Minimum input frequency on AC setting is 20 Hz.
8. **ATTEN** switch. Selects attenuation for input signal. Used in conjunction with **LEVEL** control to set input triggering point. Maximum input: 250 V rms on all ranges except 25 V rms on X1 range above 50 kHz. Recommended input is 0.1 V rms to 2 V rms times **ATTEN** setting.
9. **LEVEL** control. Used in conjunction with **ATTEN** switch to determine voltage at which triggering occurs. With X1 attenuator setting, level is variable ± 3 V; on X10, ± 30 V; and X100, ± 300 V.
10. **Input jacks**. Input jacks to Channels A and B. Input impedance is 1 M Ω shunted by less than 25 pF. By using a 10 to 1 divider probe, input impedance can be increased to 10 M Ω .
11. **Trigger lamps** adjacent to input jacks indicate when amplifier triggering occurs.
12. **CHK-SEP-COM** switch. (Check-separate-common)
- a. **CHK** - Connects internal 10 MHz time base to Channels A and B circuitry to check that unit is functioning. No indication in T.I. or T.I. Avg; ignore displayed digits in period average.
 - b. **COM-SEP** - Connects A and B inputs in parallel when set to **COM** position. When applying two separate inputs, set switch to **SEP**. When set to **COM**, input impedance is 500 k Ω shunted with less than 50 pF.
13. **C (count) light**. Lights when counter's main gate is open. For short-duration gate times, the annunciator circuits include a 50 ms one-shot MV to allow a visible flash of the C light.
14. * (asterisk). Indicates that proper units are not displayed with combination of function-time base selection. To interpret display, add a zero to the right of least significant digit displayed on the counter.

Figure 3-5. Rear Panel Controls and Connectors



1. STORAGE switch. When set to ON, provides display storage while new measurement is being made. In OFF position, allows continuous display of counting process.
2. OSC INT-EXT switch. In INT position, selects normal counter operation using internal time base. In EXT position, permits use of external time base.
3. OSC jack. With INT-EXT switch set to INT, provides 10 MHz, >3 V p-p output (no load), 50 Ω series impedance. With INT-EXT switch set to EXT, allows external time base input of 100 Hz to 10 MHz at 1 V rms (5 V peak maximum).
4. TIME BASE OUTPUT jack. Provides negative going $> +3$ V to 0 V pulses (open circuit), >50 ns wide. In START, frequency output is Channel A input frequency divided by MULTIPLIER setting.
5. MARKER A and B jacks. Provides marker outputs to intensity modulate HP 180 Oscilloscopes. Markers begin coincident with channel trigger points.
6. GATE jack. Provides >2.4 V output (open circuit) for external use. Has 50 Ω series resistance. Output is low when counter main gate is open and high when gate is closed.
7. INPUT C (5327B). 50-ohm input for 0 to 50 MHz frequency measurements. Has decoupling and sensitivity of 5 mV rms sine wave. Trigger level is zero volts. Maximum input is ± 5 volts referenced to ground (DO NOT EXCEED).
8. AC LINE. IEC type with offset pin connected to chassis.
9. AC LINE FUSE. 1.50 A at 115 V, 800 mA at 230 V.
10. 115/230 volt switch. Insert narrow screwdriver and slide switch to show desired voltage.
11. DIGITAL RECORDER connector (Option 003 only). 50-pin connector for digital recorder interconnection.
12. REMOTE PROGRAM connector (Option 002 only). 36-pin connector to allow remote control of counter modes and functions.
13. REMOTE PROGRAM connector (Option 004 only). 50-pin connector to allow remote control of counter modes and functions.

Table 3-1. Self-Check

		Time Interval Average Self Check		
		MULTIPLIER	DISPLAY	ANNUNCIATOR
1.	Set SAMPLE RATE control slightly clockwise out of OFF.			
2.	Set FAST/NORM/HOLD switch to NORM.	1	.0	μs
		10	.00	μs
		10 ²	.000	μs
3.	Set FUNCTION switch to STOP.	10 ³	.0	ns
		10 ⁴	.00	ns
		10 ⁵	.000	ns
4.	Set MULTIPLIER selector to 1.	10 ⁶	.0000	ns
		10 ⁷	.00000	ns
		10 ⁸	.000000	ns
5.	Set CHK-SEP-COM switch to CHK.			
6.	Press RESET and check that counter's right hand column displays a 0 and all other digits are blanked.			
7.	Set FUNCTION switch to START and check that counter totalizes and C light is on. Check that OF light goes on as display overflows. Set TIME BASE/MULTIPLIER to each position and check that counter totalizes in each position.			
8.	Set FUNCTION switch to STOP. Check that C light goes out and display is held.			
9.	Set FUNCTION to PERIOD AVG A. Set MULTIPLIER as shown in table below and check for proper display.			
Time Interval and Period Self-Check				
		MULTIPLIER	DISPLAY	ANNUNCIATOR
		1*	.1 ± 1 count	μs
		10	0	μs
		10 ²	.00	ms
		10 ³	.0	ms
		10 ⁴	0	ms
		10 ⁵	.00	s
		10 ⁶	.0	s
		10 ⁷	0	s
		10 ⁸	0	*
Period Average Self-Check				
MULTIPLIER	DISPLAY	ANNUNCIATOR		
1	.1	μs		
10	.10	μs		
10 ²	.100	μs		
10 ³	100.0	ns		
10 ⁴	100.00	ns		
10 ⁵	100.000	ns		
10 ⁶	100.0000	ns		
10 ⁷ Standard	00.00000	ns OF		
10 ⁷ Option 001	100.00000	ns		
10 ⁸ Standard	0.000000	ns OF		
10 ⁸ Option 001	00.000000	ns OF		
NOTE				
Digits noted are for reference, actual display may differ by several counts.				
10.	Set FUNCTION to T.I. AVG A to B. Set MULTIPLIER as shown in table below and check for proper display.			
Frequency A Self Check				
TIME BASE	DISPLAY	ANNUNCIATOR		
.1 μs	.01	±1 count GHz		
1 μs	10	±1 count MHz		
10 μs	10.0	±1 count MHz		
.1 ms	10.00	±1 count MHz		
1 ms	10.000	±1 count MHz		
10 ms	10000.0	±1 count kHz		
.1 s	10000.00	±1 count kHz		
1 s	0000.000	±1 count kHz OF		
	10000.000	±1 count kHz (Option 001)		
10 s	000.0000	±1 count kHz OF		
	0000.0000	±1 count kHz OF (Opt. 001)		

11. Set FUNCTION to T. I. A to B. Rotate MULTIPLIER switch as shown in the following table (Step 12) and check for proper display.
12. Set FUNCTION to PERIOD A. Set MULTIPLIER switch as shown in the following table and check for proper display.


*NOTE: For Time Interval Self-Check, display is .0 μs for MULTIPLIER setting of 1.

13. Set FUNCTION to FREQ A. Set TIME BASE switch as shown in table below and check for proper display.

Table 3-1. Self-Check (Continued)

Step	DVM Self-Check (with DVM Input Shorted)
14. Set FUNCTION to READ A LEVEL. Rotate CHANNEL A LEVEL to PRESET. Display should read 1.00 V ±1 count.	TIME BASE/ MULTIPLIER 10 ms .1s 1s
15. Rotate CHANNEL A LEVEL control clockwise and check that display varies from at least -3.0 to +3.0 V.	10 V RANGE .00 V ±1 count .000 V ±1 count .0000 V ±1 count
16. Repeat steps 14 and 15 for READ B LEVEL.	100 V RANGE .0 V ±1 count .00 V ±1 count .000 V ±10 counts
17. Set FUNCTION to DVM. Set TIME BASE and RANGE switch as shown in Table below and check for proper readout. Short DVM input terminals.	1000 V RANGE 0 V ±1 count .0 V ±1 count .00V ±10 counts

Figure 3-6. Frequency A Measurements




1. Set SAMPLE RATE control slightly clockwise out of OFF.
2. Set FAST/NORM/HOLD switch to NORM.
3. Set FUNCTION switch to FREQ A.
4. Set TIME BASE switch for desired gate time.
5. Set CHK-SEP-COM switch to SEP.
6. Set CHANNEL A LEVEL control to desired trigger level or to PRESET to trigger at zero volts.
7. Set ATTEN switch to match input signal amplitude.
8. Set AC-DC switch to AC or DC.
9. Connect input signal (0 to 50 MHz) to CHANNEL A input jack.
10. Adjust SAMPLE RATE control for convenient measurement interval.

NOTE

When the input signal is removed from CHANNEL A or the signal level is insufficient to trigger Channel A, the count light (C) will not cycle. This is normal for this counter and does not indicate a malfunction.

Figure 3-7. Frequency C Measurements



1. Set SAMPLE RATE control slightly clockwise out of OFF.
2. Set FAST NORM HOLD switch to NORM.
3. Set FUNCTION switch to **FREQ C**.
4. Set TIME BASE switch for desired resolution.
5. Set CHK-SEP-COM switch to **SEP**.
6. Set Input Selector switch to **DIRECT**.
7. Connect input signal (0 to 50 MHz, 15 V peak maximum, 15 mV rms minimum) to **INPUT C** connector (rear panel). Input impedance is 50Ω nominal.

8. Adjust SAMPLE RATE control for convenient measurement interval.


NOTE

For frequencies from 0 to 550 MHz with minimum levels of 25 mV rms, connect signal to **INPUT C** jack and place input selector switch in **PRESCALE** position.

CAUTION

Damage will occur if Input C voltage specifications are exceeded.

Figure 3-8. Period Measurements




Period

1. Set SAMPLE RATE control slightly clockwise out of OFF.
2. Set FAST/NORM/HOLD switch to NORM.
3. Set FUNCTION switch to PERIOD A.
4. Set MULTIPLIER switch for desired resolution.
5. Set CHK-SEP-COM switch to SEP.
6. Set CHANNEL A LEVEL control to desired trigger level or to PRESET to trigger at zero volts.
7. Set ATTEN switch to match input signal's amplitude.
8. Set AC-DC switch to AC or DC.
9. Connect input signal (0 to 10 MHz) to CHANNEL A input jack.
10. Adjust SAMPLE RATE control for a convenient interval between measurements.

Period Average


1. Set SAMPLE RATE control slightly clockwise out of OFF.
2. Set FAST/NORM/HOLD switch to NORM.
3. Set FUNCTION switch to PERIOD AVG A.
4. Set MULTIPLIER switch to number of periods to be averaged.
5. Set CHK-SEP-COM switch to SEP.
6. Set CHANNEL A LEVEL control to desired trigger level or to PRESET to trigger at zero volts.
7. Set ATTEN switch to match input signal amplitude.
8. Set AC-DC switch to AC or DC.
9. Connect input signal (0 to 10 MHz) to CHANNEL A input jack.
10. Adjust SAMPLE RATE control for convenient measurement interval.

Figure 3-9. Ratio Measurements



1. Set SAMPLE RATE control slightly clockwise out of OFF.
2. Set FAST/NORM/HOLD switch to NORM.
3. Set FUNCTION switch to FREQ A or FREQ C, direct or prescaled.
4. Set MULTIPLIER switch to desired dividing factor for F_{ext} .
5. Set CHK-SEP-COM switch to SET.
6. Set CHANNEL A LEVEL control to desired trigger level or to PRESET to trigger at zero volts.
7. Set ATTEN switch to match input amplitude.
8. Set AC-DC switch to AC or DC.
9. Connect F_A (0 to 50 MHz) to CHANNEL A input jack or F_C to INPUT C.
10. Set CSC INT-EXT switch to EXT. Connect F_{ext} to OSC jack. F_{ext} can be 100 Hz to 10 MHz 1 V rms (min) to 5 V peak maximum.
11. Adjust SAMPLE RATE control for convenient measurement interval.
12. Ratio = $\frac{F_A \text{ or } F_C}{F_{ext}} \cdot \frac{DISPLAY}{MULTIPLIER}$ Disregard units and decimal point.

Figure 3-10. Time Interval Measurements



Single Time Interval

1. Set SAMPLE RATE control slightly clockwise out of OFF.
2. Set FAST/NORM/HOLD switch to NORM.
3. Set FUNCTION switch to T.I. A to B.
4. Set MULTIPLIER switch for desired resolution.
5. If start-stop signals are from a common source, connect signal to CHANNEL A input and set CHK-SEP-COM switch to COM. If start-stop signals are from separate sources, connect start signal to CHANNEL A input and stop signal to CHANNEL B input and CHK-SEP-COM switch to SEP.
6. Set CHANNEL A SLOPE switch to + for triggering on positive slope of signal or to - for triggering on negative slope of signal.
7. Set CHANNEL A LEVEL and ATTEN switches to start measurement at desired voltage level. Select AC or DC coupling. For frequencies below 100 kHz, use MARKER A OUTPUT jack on rear panel to display starting point on an oscilloscope.
8. Set CHANNEL B, AC-DC, LEVEL, SLOPE, and ATTEN controls to stop measurement at desired level. For frequencies below 100 kHz, use MARKER B OUTPUT to display stopping point on oscilloscope.
9. Adjust SAMPLE RATE control for convenient measurement interval.

NOTE

There must be at least 150 ns between the STOP pulse (Channel B trigger) and the next START pulse (Channel A trigger).


Time Interval Average

1. Set SAMPLE RATE control slightly clockwise out of OFF.
2. Set FAST/NORM/HOLD switch to NORM.
3. Set FUNCTION switch T.I. AVG A.
4. Set MULTIPLIER switch to number of time intervals to be averaged.
5. If start-stop signals are from a common source, connect signal to CHANNEL A input and set CHK-SEP-COM switch to COM. If start-stop signals are from separate sources, connect start signal to CHANNEL A input and stop signal to CHANNEL B input and CHK-SEP-COM switch to SEP.
6. Set CHANNEL A SLOPE switch to + for triggering on positive slope of signal or to - for triggering on negative slope of signal.
7. Set CHANNEL A, LEVEL, and ATTEN to start the measurement at desired voltage level. Select AC or DC coupling. For frequencies below 100 kHz, use MARKER A OUTPUT jack on rear panel to display starting point on oscilloscope.
8. Set CHANNEL B, AC-DC, LEVEL, SLOPE, and ATTEN to stop the measurement at desired level. For frequencies below 100 kHz, use MARKER B OUTPUT to display stopping point on oscilloscope.
9. Adjust SAMPLE RATE control for convenient measurement interval.

NOTE

STOP to START delay must be >150 ns and input range should not be 10 MHz x $\frac{M}{N}$ (M and N integers).

Figure 3-11. Digital Voltmeter and Read A Level, Read B Level Measurements




DVM

1. Set SAMPLE RATE control slightly clockwise out of OFF.
2. Set FAST/NORM/HOLD switch to NORM.
3. Set FUNCTION switch to DVM.
4. Set TIME BASE to 10 ms, .1 s, or 1 s. (1 s setting gives maximum resolution.)
5. Set RANGE switch to match input voltage. Do not exceed 1100 V peak input.
6. If DVM display is 12.5 V on the 10 V scale or 125 V on the 100 V scale, over-ranging has occurred and the next highest range setting should be used.

Read A and Read B Levels

1. Set SAMPLE RATE control slightly clockwise out of OFF.
2. Set FAST/NORM/HOLD switch to NORM.
3. Set FUNCTION switch to READ A LEVEL or READ B LEVEL.
4. TIME BASE is automatically selected for 10 ms integration time.
5. Trigger level is equal to DVM reading X ATTEN setting. To set trigger level, adjust LEVEL control until DVM indicates desired level.

Figure 3-12. Totalize Measurements



1. Set SAMPLE RATE control slightly clockwise out of OFF.
2. Set FAST/NORM/HOLD switch to NORM.
3. Set FUNCTION switch to STOP.
4. Set MULTIPLIER switch to input signal scaling factor.
5. Set CHK-SEP-COM switch to SEP.
6. Set LEVEL control to desired trigger level or to PRESET for triggering at zero volts.
7. Set ATTEN switch to match input signal's amplitude.
8. Set AC-DC switch to AC or DC.
9. Connect input signal (0 to 10 MHz) to CHANNEL A input jack.
10. Set FUNCTION switch to START.

NOTE

A scaled output of the input signal is available at the rear-panel TIME BASE OUTPUT BNC. The division is determined by the MULTIPLIER switch setting.

SECTION IV THEORY OF OPERATION

4-1. INTRODUCTION

4-2. This section discusses the general operating principles of the instrument. Assembly description is covered in more detail in Section VIII, opposite each schematic diagram. Logic fundamentals are explained in Paragraphs 4-3 through 4-16.

4-3. LOGIC SYMBOLS

4-4. Two states exist in the binary system, 1 and 0. In positive logic, the 1 state is more positive than the 0 state. High (H) and low (L) are used to represent the 1 and 0 levels. **HIGH ALWAYS REPRESENTS THE MORE POSITIVE LEVEL, WHETHER IT BE POSITIVE OR NEGATIVE LOGIC.**


4-5. A circle at the input line of a logic symbol indicates that a low activates the function. Figure 4-1B shows that a low at both inputs produces

a high output. A circle at the output line of a logic symbol indicates a low when activated, as shown in Figure 4-1C.

4-6. Gating and Logic

4-7. Figure 4-1A represents a basic AND gate. The output is high if all inputs are high. An AND gate may have two or more inputs. Figure 4-1D represents a basic OR gate. The OR gate output is high if one or more of its inputs is high. An OR gate with a circle on the output is called a NOR gate. An AND gate with a circle on the output is called a NAND gate. An EXCLUSIVE NOR (Figure 4-1E) has two inputs; and the output will be low if one, but not both, of the inputs is high. The output will be high if the inputs are both low or both high.

Figure 4-1. Gate Symbols and Logic Comparisons



4-8. INTEGRATED CIRCUIT OPERATION

4-8. JK Master-Slave Flip-Flop

4-10. The JK master-slave flip-flop is basically a bistable multivibrator. With simultaneous high inputs to J and K, before the clock pulse, Q and \bar{Q} will change states after the clock pulse. Refer to Figure 4-2 and Table 4-1. This circuit triggers on the trailing edge (negative transition) of the clock pulse. The set (S) and reset (R) inputs operate as follows: when a low is applied to set input, \bar{Q} goes low and Q goes high; when a low is applied to reset input, Q goes low and \bar{Q} goes high. Set or reset can override all other inputs at any time.

Figure 4-2. JK Flip-Flop





Table 4-1. Truth Table

t_n		$t_n + 1$		t_n Before clock pulse
J	K	Q	\bar{Q}	$t_n + 1$ = After clock pulse
L	L	Q_n	\bar{Q}_n	If J = L and K = L, then Q and \bar{Q} will not change from what they were before the clock pulse.
H	L	H	L	If J = H and K = L, then Q will be H and \bar{Q} will be L after the clock pulse.
L	H	L	H	If J = L and K = H, then Q will be L and \bar{Q} will be H after a clock pulse.
H	H	\bar{Q}_n	Q_n	If J = H and K = H before the clock pulse, then after the clock pulse Q and \bar{Q} will change states.

4-11. Time-Base Decade

4-12. In the reset state, Carry Output (CO) (see Figure 4-3) is high and, if the Gate input (G) is low, Gated Output (GO) is low. Ten pulses on the Gate input produce a negative transition at the Gated Output. If the G input is high, GO is open-circuited regardless of the count. The Carry Output gives a positive transition after 10 pulses.


Figure 4-3. Time-Base Decade 1620-0412



4-13. Open-Collector Gate

4-14. The output of an open-collector gate can be paralleled with gates of the same type to perform a wire-OR function, as shown in Figure 4-4. When the outputs are tied to the same line, any one of the gates can pull the line low without damaging itself.

Figure 4-4. Open-Collector Gate 1620-0327



4-16. Logic Levels

4-16. This counter uses three types of logic: TTL (transistor-transistor logic), ECL (emitter-coupled logic), and DTL (diode-transistor logic). See Table 4-2 for specific logic levels.

Table 4-2. Logic Levels

Type	H (Min)	L (Max)	Trigger	Supply
ECL	-1.7 V	-1.1 V	-1.2 V	5.0 V
TTL	2.4 V	0.4 V	1.5 V	5.0 V
DTL	2.6 V	0.4 V	1.5 V	5.0 V

4-17. OVERALL COUNTER OPERATION


4-18. The signal connected to CHANNEL A is conditioned by the front-panel switches of the Attenuator Assembly (Figure 4-5). These switches set the operating conditions for trigger level, coupling, and

the required slope. The Input Amplifier converts the signal into narrow pulses for more efficient usage throughout the counter. In the 5327B, INPUT C provides an alternate path through the Prescaler Assembly, which divides the signal by 10 or passes it directly to the Function Control Assembly. The path taken is determined by the setting of the front-panel Input Selector switch.

4-19. The Function Control accepts both the input signal and the 10 MHz internal oscillator pulses and routes them in accordance with the mode of operation being used. One of these signals is sent to the Time Base Assembly, which divides the signal as determined by the front panel TIME BASE MULTIPLIER switch. The first and last pulse of the divided signal controls the length of time the main gate is open. During this time, the other signal is sent directly to the main gate for totalizing in the decade counters and is subsequently displayed. The synchronizer prevents the main gate from opening until an input signal is present.

4-20. The sample rate circuits control the interval between measurements. When the main gate closes, these circuits provide a delay, as controlled by the

Figure 4-5. Functional Block Diagram



front panel SAMPLE RATE controls. When the sample rate period has elapsed, a reset pulse is generated to reset the counter and start a new measurement.

4-21. The signal to be counted, either the internal oscillator or input signal, passes through the main gate to the decade counters. The buffer storage registers store the BCD count before it is translated into a decimal equivalent and displayed on the front panel. Also displayed on the front panel are the units of measurement and the decimal point. The left and right readout assemblies contain the unit indicators and the logic necessary to position the decimal point.

4-22. Frequency Modes

4-23. Frequency is defined as the number of periodic events per unit of time. The counter, therefore, measures an unknown signal (COUNT) for a known length of time (Figures 4-6 and 4-7). The 10 MHz internal oscillator provides the known time and controls the opening of the main gate. The Time Base Assembly divides the oscillator frequency by powers of 10 to open the main gate from 10⁻² seconds to 10 seconds. The longer the gate is open, the more pulses of the unknown frequency are counted and, therefore, the better the resolution and accuracy.

4-24. Period Modes

4-25. In the Period Mode, the main gate is open for the period of the input signal (Figure 4-8). The Time Base dividers scale the 10 MHz oscillator signal by powers of 10 from 1 to 10⁶, as determined by the MULTIPLIER switch. This oscillator signal (COUNT) is counted during the gate time (period) by the decade counters and is subsequently displayed.

4-26. In the Period Average Mode, the MULTIPLIER switch selects the number of periods to be averaged (Figure 4-9). The Time Base dividers count the

number of periods selected with the switch and holds the main gate open until this count is complete. The Decade Counter totalizes the oscillator pulses while the main gate is open.

4-27. Time Interval Modes

4-28. In the Time Interval Mode (Figure 4-10), Channel A signal controls the start of the measurement, while Channel B signal stops the measurement. The two signals control the state of the arming flip-flop, which, in turn, enables the Clock Gate to pass oscillator pulses to the Time Base Divider. The oscillator signal is scaled, congruent with the setting of the MULTIPLIER switch, before it is passed through the main gate to the counting assemblies.

4-29. For the Time Interval Average measurements (Figure 4-11), the setting of the MULTIPLIER switch determines the number of intervals that are averaged. The oscillator signal is counted directly for the duration of each, individual time interval that is being averaged. Once the Time Base Divider totalizes the number of selected intervals, the main gate closes and the measurement is displayed. See Page 8-27 for timing diagrams and a technical description.

4-30. DVM Mode

4-31. The DVM input connects to voltmeter Input Amplifier A12 (Figure 4-1), which provides attenuation for the range selection. The output of A12 connects to Voltage-to-Frequency Converter A13. The V-to-F converter supplies a pulse-train output, whose frequency is proportional to the magnitude of the input signal. This output feeds through the main gate for subsequent counting by the decade counters. In the DVM mode, the front-panel TIME BASE switch selects the integrating time. When reading the triggering level of A or B channel, the 10 V range and 10 ms integration time are automatically selected.

Figure 4-6. Frequency A Mode Flow Diagram




Figure 4-7. Frequency C Mode Flow Diagram




Figure 4-8. Period Mode Flow Diagram




Figure 4-9. Period Average Mode Flow Diagram




Figure 4-10. Time Interval Mode Flow Diagram




Figure 4-11. Time Interval Average Mode Flow Diagram




Figure 4-12. DVM Mode Flow Diagram





Figure 4-13. Instrument Timing Diagram



SECTION V MAINTENANCE

5-1. INTRODUCTION

5-2. This section gives maintenance and service information. Included is a table of assemblies, recommended test equipment, in-cabinet performance checks, which may be used to verify proper counter operation, and adjustments.

5-3. ASSEMBLY DESIGNATIONS

5-4. Table 5-1 lists the designations, name, and Hewlett-Packard part number of assemblies used in this instrument.

5-5. TEST EQUIPMENT

5-6. Test equipment recommended for maintaining and checking performance is listed in Table 5-2. Test equipment having equivalent characteristics may be substituted for the equipment listed.

Table 5-1. Assembly Identification

Assembly	Description	HP Part No.
A1	Attenuator	05326-60047
A1	Attenuator (Option 004)	05327-60034
A2	Input Amplifier	05326-60004
A3	Input Amplifier	05326-60004
A4	Oscillator	05326-60002
A4	TCXO (Option 010)	05327-60036
A4	Oven Oscillator (Opt. 011)	10544-60011
A5	Time Base Control	05326-60005
A6	Sample Rate	05326-60013
A7	Function Control	05327-60031
A8	Display Support	05326-60009
A9	Display	05326-60008
A9	Display (Option 001)	05326-60025
A10	Right Readout	05327-60008
A11	Left Readout	05327-60007
A12	Voltmeter Input Amplifier	05326-60016
A13	Voltmeter V-F Converter	05326-60017
A14	DVM Logic	05326-60015
A15	Regulator	05327-60020
A16	Interconnect	05327-60027
A17	Input C Amp (532613)	05326-60031
A18	Prescaler (532713)	05327-60033

5-7. ASSEMBLY CONNECTION IDENTIFICATION

5-8. Throughout the manual, connections to printed circuit assemblies are referred to in abbreviated form. For example, connection to A3, pin 10 is A3(10).

5-9. IN-CABINET PERFORMANCE CHECK

5-10. GENERAL. The performance check (Table 5-3) and test card can be used to verify proper operation of all circuits of the counter and may also be used:

- a. As part of an incoming inspection check of instrument specifications.
- b. Periodically, for instruments used in systems where maximum reliability is important.
- c. As part of a procedure to locate defective circuits.
- d. After any repairs or adjustments and before returning instrument to regular service.
- e. As a permanent record of instrument maintenance performed, because the test record pages are perforated and may be removed.

5-11. VARIABLE LINE VOLTAGE. During the test (Table 5-3), the counter should be connected to a variable voltage source, so the line voltage may be varied $\pm 10\%$ from nominal (115 or 230 Vac).

5-12. INSTRUMENT COVER REMOVAL.

5-13. To remove top or bottom cover, remove the four screws that secure cover to instrument. Slide cover toward rear of instrument and lift off. To replace cover, reverse procedure.

WARNING

115/230 VAC AND +175 VDC SUPPLY WIRES ARE EXPOSED WHEN EITHER TOP OR BOTTOM COVER IS REMOVED. USE EXTREME CAUTION DURING TROUBLESHOOTING, ADJUSTMENT, OR REPAIR. AVOID DAMAGE TO INSTRUMENT BY REMOVING POWER BEFORE REMOVING OR REPLACING COVERS, ASSEMBLIES, OR COMPONENTS.

5-14. REPAIR

5-15. Printed Circuit Component Replacement

5-16. Component lead holes in the circuit boards have plated-through walls to ensure good electrical contact between conductors on opposite sides of the board. To prevent damage to the plating and the replacement component, apply heat sparingly, and work carefully.

5-17. Replacing Integrated Circuits

5-18. Following are two recommended methods of replacing integrated circuits.

a. **SOLDER GOBBLER.** This is the best method. Solder is removed from board by a soldering iron with a hollow tip connected to a vacuum source.

b. **CLIP-OUT.** This method should be used as a last resort only. Clip the leads as close to the base as possible. With a soldering iron and long nose pliers, carefully remove the wires from each hole. Then clean the holes.

5-19. ADJUSTMENTS

5-20. The adjustments in Table 5-4 are in the order they should be performed but should not be done unless.

a. A trouble has been repaired which would affect these values.

b. The instrument does not meet all specifications while performing the check in Table 5-3 (In-Cabinet Performance Checks).

Table 5-2. Recommended Test Equipment

Instrument Type	Required Characteristics	Recommended Type
Frequency Standard	1 MHz Output	HP 107AR
Oscilloscope	50 MHz Bandwidth	HP 180A
Vertical Plug-In	50 mV/cm Sensitivity	HP 1801A
Time Base Plug-In	50 MHz Bandwidth	HP 1820A
Test Oscillator (two required)	10 Hz to 10 MHz at 5 volts peak-to-peak	HP 651B
Audio Oscillator	2 Hz to 100 kHz at 100 mV rms	HP 202C
HF Signal Generator	50 kHz to 50 MHz at 3 V rms	HP 606B
VHF Signal Generator	10 MHz to 480 MHz	HP 658F
Frequency Doubler	240 - 550 MHz	HP 10575A
Pulse Generator	10 MHz repetition rate, 8 ns pulse width, 0.3 volts peak-to-peak output	HP 216A
Electronic Counter	0.1 Hz to 10 MHz Frequency Measurements	HP 5245L
Variable Line Transformer	103 to 127 V rms and 206 to 254 V rms	Electronic Power Stat 3PF116 (115V); 3PF216 (230V)
Voltage Standard	10 to 1000 volts, 0.01% accuracy	HP 741B
Digital Recorder	Print Rate: 10 lines/sec. Data Input: +8421 BCD parallel entry, accepts 1 = +5 V, 0 = +0.25 V. Accepts negative going +5 to 0 V print command	HP 5055A
DC Voltmeter	0 to 200 Vdc, 1% accuracy	HP 412A
AC VTVM	0 to 250 Vac	HP 400F
RF Voltmeter	1 mV to 3 V	HP 3406A

Table 5-3. In-Cabinet Performance Check

1. TIME BASE STABILITY AND OUTPUT

a. Set counter controls as follows:

SAMPLE RATE Mid position
 FAST/NORM/HOLD NORM
 FUNCTION FREQ A
 TIME BASE/MULTIPLIER 10s
 SLOPE A
 AC/DC DC
 ATTEN X1
 CHK-SEP-COM SEP
 LEVEL PRESET
 STORAGE ON
 OSC INT

NOTE

Allow one-hour warm-up before proceeding to step b.

- b. Connect 1 MHz frequency standard to CHANNEL A input.
- c. A counter display of 000,0000 (1000,0000 Option 001) indicates that counter time base frequency is exactly 10 MHz. The offset between counter time base and 1 MHz frequency standard can be determined by subtracting 10 MHz from the indicated oscillator frequency.

COUNTER DISPLAY	A4 OSCILLATOR FREQUENCY
999,9950 kHz	10 000 950 Hz
999,9960	10 000 940
999,9970	10 000 930
999,9980	10 000 920
999,9990	10 000 910
1 000,0000	10 000 900
1 000,0010	9 999 990
1 000,0020	9 999 980
1 000,0030	9 999 970
1 000,0040	9 999 960
1 000,0050	9 999 950

- d. Record frequency offset on test card. For long-term stability, operate the counter continuously for at least one month. Measure frequency offset at one-month intervals.
- e. To calibrate the counter time base to the frequency standard, perform time-base adjustment in Table 5-4.

NOTE

Temperature must be held constant or compensation for temperature difference must be made whenever a frequency difference is recorded. Unless a record of the temperature and date of last calibration is available, the frequency offset should not be considered drift or aging rate of the 10 MHz crystal.

- f. To check time base stability vs. line voltage variations, connect variable transformer to counter power cord. Vary line voltage $\pm 10\%$ and record frequency difference on test card; it should be ≤ 1 part in 10^7 .
- g. To check time base stability vs. temperature, vary counter operating temperature between 0 and 50°C. Record frequency difference on test card; it should be < 2.5 parts in 10^6 .

Table 5-3. In-Cabinet Performance Check (Continued)

- h. Connect oscilloscope vertical input to OSC jack on counter rear panel. Use 10:1 probe at OSC jack.
- i. Oscilloscope should display 10 MHz nominal at > 2.4 volts peak-to-peak amplitude. Record on test card.

2. DISPLAY, DECIMAL POINTS, AND DIVIDERS

Proper operation is verified in the Self-Check procedures in Table 3-1. Record on test card.

3. FREQUENCY RESPONSE AND SENSITIVITY

CHANNEL A

- a. Set counter controls as in 1a., except TIME BASE to 1s and AC/DC switch to AC.
- b. Connect a BNC T connector to CHANNEL A jack. Connect sine wave test oscillator output to T connector. Connect oscilloscope's vertical input to T connector to monitor input signal amplitude, use a 50-ohm feedthrough at oscilloscope BNC.
- c. Adjust test oscillator from 20 Hz to 50 MHz, maintaining 100 mVrms input amplitude. Counter should properly display all frequencies in this range. Record on test card.
- d. Set audio oscillator frequency to 2 Hz. Counter should not count. Switch AC/DC switch to DC. Counter should count input signal.
- e. Connect a BNC T connector to Z axis input of oscilloscope. Connect counter MARKER A and B outputs to T connector.
- f. Adjust test oscillator output for 1000 Hz at 8 volts peak-to-peak indication.
- g. Set CHANNEL A LEVEL to PRESET and check that oscilloscope marker is at 0 volts.
- h. Set CHANNEL A SLOPE to +. Vary CHANNEL A LEVEL control and check that marker is variable over at least -3.0 to +3.0 volts on the positive slope of waveform.
- i. Set CHANNEL A SLOPE to -. Vary CHANNEL A LEVEL control and check that marker dot is variable over at least -3.0 to +3.0 volts on the negative slope of waveform. Record on test card.
- j. Set CHK-SEP-COM switch on COM and repeat marker test for CHANNEL B. Record on test card.
- k. Set FUNCTION selector to READ A LEVEL. Set LEVEL A to PRESET. Display should be .00 V ± 1 count.
- l. Rotate LEVEL A control clockwise just out of PRESET. Readout should be negative display of 3.00 volts or greater. Gate light should flash.
- m. Rotate LEVEL A control clockwise and check that readout decreases, crosses zero (polarity sign changes) and displays +3.00 volts or greater in the full clockwise position. Record on test card.
- n. Set FUNCTION selector to READ B LEVEL, and repeat step K through M for Channel B. Record on test card.

INPUT C (for 5327B, perform all steps; for 5326B perform steps a and f thru h).

- a. Disconnect oscilloscope and input to CHANNEL A. Remove 50 Ω feedthrough and connect cable to INPUT C jack.
- b. Set FUNCTION selector to FREQ C, TIME BASE to 1s, and input selector to PRESCALE.

Table 5-3. In-Cabinet Performance Check (Continued)

- c. Use the set of frequency generators (Table 5-2) necessary to cover the input frequency from 0 to 550 MHz, while maintaining 25 mV rms input levels. Adjust TIME BASE switch as necessary for best display.
- d. Check for stable count within stability of oscillator. Record on test card.
- e. For 5327B, set input selector switch to DIRECT.
- f. Set FUNCTION selector to FREQ C and TIME BASE to 1s.
- g. Use the set of frequency generators necessary to cover the input frequency from 0 to 50 MHz, while maintaining 15 mV rms input level for the 5327B or 5 mV rms for the 5326B. Adjust TIME BASE switch as necessary for best display.
- h. Check for stable count within stability of oscillator. Record on test card.

4. PULSE OPERATION

- a. Set counter controls as follows:

FUNCTION	FREQ A
TIME BASE	1 s
SLOPE A	+
AC/DC (A)	AC
ATTEN (A)	X1
LEVEL (A)	PRESET
CHK-SEP-COM	SEP
STORAGE	ON
OSC	INT

- b. Connect BNC T connector to oscilloscope vertical input. Connect pulse generator to T. Connect CHANNEL A input to T connector, using 50Ω feedthrough at the counter input.
- c. Adjust pulse generator output for 10 MHz repetition rate, 15 ns pulse width at 0.3 volts peak-to-peak indication on oscilloscope.
- d. Check that counter displays the repetition rate, count light flashes, and trigger A lamp is on. Record on test card.
- e. Remove input connection from CHANNEL A input jack. Remove 50Ω feedthrough and connect cable to INPUT C jack. Set FUNCTION selector to FREQ C. Set input selector switch to DIRECT.
- f. Check that counter displays repetition rate and count lamp flashes. Record on test card.
- g. Repeat above check for 10 kHz.

5. PERIOD AND PERIOD AVERAGE

- a. Set counter controls as in step 1a. with FUNCTION to PERIOD A and MULTIPLIER to 10³ or as needed. Set audio oscillator to 2 Hz at 100 mVrms.
- b. Connect oscillator to CHANNEL A input, using BNC T. Connect oscilloscope to T, using 50Ω feedthrough at oscilloscope BNC.
- c. Vary audio and test oscillator frequency from 2 Hz to 10 MHz, maintaining 100 mVrms input amplitude. Vary MULTIPLIER as needed to maintain meaningful display with change of frequency. Counter should properly display the period of the frequencies in this range within accuracy spec of the instrument. Record on test card.
- d. Set FUNCTION switch to PERIOD AVG A and repeat step c. Record on test card.

Table 5-3. In-Cabinet Performance Check (Continued)

6. TIME INTERVAL AND TIME INTERVAL AVERAGE

a. Set counter controls as follows:

SAMPLE RATE	Mid-position
FAST/NORM/HOLD	NORM
FUNCTION	T. I. A to B
MULTIPLIER	1
SLOPE A	+
SLOPE B	-
AC/DC (A and B)	AC
ATTEN (A and B)	X1
LEVEL (A and B)	PRESET
CHK-SEP-COM	COM

b. Connect test oscillator to CHANNEL A input. Set oscillator for 1 MHz output at 300 mVrms. Observe display of $5 \mu s \pm 1$ count \pm trigger error. Record on test card.

c. Set FUNCTION to T. I. AVG and MULTIPLIER to 10^4 . Set signal source to < 2 MHz. * Counter should display one half the period of the input signal

$$\pm 2 \text{ ns} \pm \frac{\text{trigger error} \pm 100 \text{ ns}^{**}}{\sqrt{\text{number of intervals averaged}}}$$

7. TOTALIZE

a. Set counter controls as follows:

FUNCTION	START
MULTIPLIER	1
CHK-SEP-COM	CHK

b. Check that display totalizes, count light (C) is on and trigger A and B lamps light. Record on test card.

c. Using 10:1 divider probe, connect oscilloscope vertical input to TIME BASE OUTPUT jack on counter rear panel.

d. Check that oscilloscope indicates 10 MHz negative going pulses at least 3 volts peak-to-peak, typically > 30 nsec at 50% point \pm . Set MULTIPLIER switch to 10 and observe 1 MHz output pulses, typically 100 nsec.

e. Disconnect oscilloscope from TIME BASE OUTPUT jack and connect TIME BASE OUTPUT to 5245L Electronic Counter input. Set 5245L for frequency measurements.

f. Set MULTIPLIER as follows, and check for proper counter display. Record on test card.

<u>MULTIPLIER</u>	<u>5245 DISPLAY</u>
1	10 MHz
10	1 MHz
10^2	100 kHz
10^3	10 kHz
10^4	1 kHz
10^5	100 Hz
10^6	10 Hz
10^7	1 Hz
10^8	.1 Hz

*2 MHz must NOT be exact or display will be ambiguous.

** ± 1 count.

Table 5-3. In-Cabinet Performance Check (Continued)

8. RATIO

- a. Set counter controls as follows:

FUNCTION	FREQ A
MULTIPLIER	10 ⁴
SLOPE A	*
AC/DC	AC
ATTEN	X1
CHK-SEP-COM	SEP
LEVEL A	PRESET
OSC (rear panel)	EXT

- b. Connect test oscillator to OSC jack, using BNC T. Connect oscilloscope to T connector, using 50Ω feedthrough at oscilloscope BNC. Set oscillator output for 10 MHz at 1 Vrms.
- c. Connect BNC T connector to counter's CHANNEL A jack. Connect second test oscillator to T connector. Connect second channel of dual channel oscilloscope vertical input to T connector, using 50Ω feedthrough at oscilloscope BNC. Set variable oscillator for 100 kHz at 100 mVrms display on oscilloscope.
- d. Check that counter displays 100. Disregard units and decimal point. Record on test card.
- e. Repeat test using 100 Hz into OSC jack and 100 kHz into CHANNEL A. Set MULTIPLIER to 10⁴. Display should be ratio of two input frequencies X 10⁴ (approximately 10⁹). Disregard decimal point and units. Record on test card.

9. GATE OUTPUT AND SAMPLE RATE

- a. Disconnect setup.
- b. Set counter controls as follows:

FUNCTION	FREQ A
TIME-BASE	1 ms
CHK-SEP-COM	CHK
FAST/NORM/HOLD	FAST
SAMPLE RATE	max c/w

- c. Using 10:1 divider probe, connect oscilloscope vertical input to GATE output and observe positive pulses $\geq 2.4V$ with a pulse width of $< 100 \mu s$. Record on test card.
- d. Slowly rotate SAMPLE RATE clockwise and observe that the pulse width increases.
- e. Set the TIME BASE switch to 10 ms and rotate the SAMPLE RATE fully clockwise. Observe that the pulse width is $> 20 ms$. Record on test card.
- f. Set FAST/NORM/HOLD to NORM and turn SAMPLE RATE fully counterclockwise, just out of OFF. Observe the positive pulse width is $< 20 ms$. Record on test card.
- g. Slowly rotate the SAMPLE RATE clockwise, observing an increase in the pulse width.
- h. Set TIME BASE to 1s and rotate SAMPLE RATE fully clockwise. Verify that the time between flashes of the count (C) lamp is greater than 5 seconds. Record on test card.
- i. Set FUNCTION to START and check that gate output is TTL Low ($< 0.4V$).
- j. Set FUNCTION to STOP and verify that gate output is TTL High ($> 2.4V$).

Table 6-3. In-Cabinet Performance Check (Cont'd)

10. DIGITAL VOLTMETER

- a. Set counter controls as follows and allow for 10-minute warmup (with covers on).

SAMPLE RATE Mid-position
FAST-NORM-HOLD NORM
FUNCTION DVM
TIME BASE 1s
RANGE 10V

- b. Set voltage standard for +10.000 volt output. Connect voltage standard to DVM input jack.
c. Check that counter display is +10.000 volts ±7 counts.
d. Reverse voltage standard polarity and check for counter display of -10.000 volts ±7 counts.
e. Set counter RANGE switch to 100V. Set voltage standard for +100.00 volts output. Check that counter display of +100.00 volts ±7 counts.
f. Reverse voltage standard polarity and check for counter display of -100.00 volts ±7 counts.
g. Set counter RANGE switch to 1000V. Set voltage standard for +990.0 volts output. Counter display should be +990.0 ±11 counts.

CAUTION

**DO NOT REVERSE VOLTAGE STANDARD POLARITY.
DAMAGE TO THE STANDARD MAY OCCUR.**

- h. Set counter RANGE switch to 10V. Counter display should be 12.500 ±1 count.
i. Set voltage standard for 12.490 volt output. Counter display should be 12.490 ±7 counts.
j. Connect a 1 MΩ, 1/4W, 1% resistor in series with the red DVM INPUT jack.
k. Set voltage standard for 10 volts output. Counter display should be 9.090 ±17 counts.
l. Set RANGE switch to 100V. Counter display should be 9.09V ±22 counts.
m. Short DVM input terminals. Set RANGE switch as follows and check for proper readout.

RANGE SWITCH	READOUT
10V	000 ±2 counts
100V	.00 ±2 counts
1000V	.0 ±2 counts

11. DIGITAL RECORDER (Option 003)

- a. Set counter controls as follows:

FUNCTION FREQ A
TIME BASE 1s
COM-SEP-CHK CHK
FAST-NORM-HOLD NORM
SAMPLE RATE Mid-position

- b. Connect oscilloscope to J9(18). Observe oscilloscope display a print command (drop from >2.4V to <0.4V) immediately after the C lamp goes out.
c. Connect jumper from J9(25) to J9(22).
d. Check that counter's main gate is inhibited. C light does not flash, and no print command pulses are generated.
e. Verify proper output by connecting a 5055A printer on J9. Printed output should agree with counter display. Logic probe or voltmeter may be used to verify that output logic levels agree with instrument display. Record on test card.

Table 5-4. Adjustments

1. POWER SUPPLY A15

- a. Connect counter line cord to variable power transformer. Monitor output voltage with AC VTVM. Adjust transformer for 117 volt indication on VTVM.
- b. Turn counter SAMPLE RATE control clockwise out of OFF.
- c. Connect VTVM to A15 Pin 7 and adjust A15R10 for +16.5 V.
- d. Connect VTVM to A15 Pin 6 and adjust A15R13 for -16.5 V.

2. SENSITIVITY AND OFFSET A2, A3

- a. Connect a BNC T connector to CHANNEL A input jack.
- b. Connect test oscillator output to T connector.
- c. Connect oscilloscope vertical input to T connector, using 50Ω feedthrough at oscilloscope input BNC.
- d. Connect counter MARKER A output to oscilloscope Z-axis input.
- e. Adjust test oscillator for 1 kHz output at 100 mV rms.
- f. Set counter controls as follows:

FUNCTION	FREQ A
CHK-SEP-COM	SEP
ATTEN	X1
AC-DC	DC
LEVEL	PRESET
- g. Set SLOPE A switch to - and + positions and observe marker position on oscilloscope waveform.
- h. On Input Amplifier board A2, adjust A2R2 SENS pot until + and - marker positions have a symmetrical offset about the zero volt axis for + and - slope switch positions.
- i. Adjust test oscillator for 1 kHz output at 200 mV rms.
- j. Set counter FUNCTION switch to T. A to B
- k. On Input Amplifier, adjust A2R24 TRIG LEVEL pot until markers are at 0 volts for both + and - SLOPE switch positions.
- l. Repeat procedure for CHANNEL B input (Amplifier Board A3).

3. OPTION 004 ATTENUATOR A1

Set:

TIME BASE	0.1 sec.
AC/DC	DC
SEP/COM	SEP
ATTEN A-B	X10

- a. Using an HP 112A or equivalent, measure voltage at CHANNEL A jack.
- b. Adjust R56 for ± 1 mV reading.
- c. Measure voltage at CHANNEL B jack.
- d. Adjust R9 for ± 1 mV reading.
- e. Set A and B attenuators to X100 position.
- f. Measure voltage at CHANNEL B jack.
- g. Adjust R32 for ± 1 mV reading.
- h. Measure voltage at CHANNEL A jack.
- i. Adjust R33 for ± 1 mV reading.

4. OSCILLATOR A4

- a. Connect 1 MHz frequency standard to CHANNEL A jack.
- b. Set counter controls as follows:

CHK-SEP-COM	SEP
FUNCTION	FREQ A
TIME BASE	10s
SAMPLE RATE	slightly clockwise out of OFF
- c. Remove top cover.
- d. Using insulated tuning tool, adjust A4C3 until display indicates all zeros with cover on. (Wait 10 seconds between adjustments for counter to make measurement.)

NOTE

For standard instruments without Option 001, the counter display will overflow; however, all digits are valid.

5. PRESCALER ADJUSTMENTS A18 (5327B)

- a. Set counter controls as follows:

FUNCTION	FREQ C
TIME BASE	0.1s
Input Selector	PRESCALE

Table 5-4. Adjustments (Continued)

- b. With no input signal applied, adjust R3 offset pot for 0 V on U2 pin 4.
- c. Adjust R10 bias pot for 0.65 \pm 0.05 V on U2 pin 3.
- d. Adjust R27 bias pot for 0.9 \pm 0.05 V on U3 pin 3.
- e. Check that the previously adjusted voltage on U2 pin 3 is correct. If voltage has shifted, adjust R10 for proper reading and recheck U3 pin 3.
- f. Set HP VHF Signal Generator and doubler for 550 MHz at 1 V rms. Measure the output with an HP 3406A RF Voltmeter using a 50 Ω termination at the probe. Connect signal source to INPUT C of counter.
- g. Reduce output level until counter's display becomes unstable. Adjust R3 for a stable display. Repeat this procedure until unable to obtain a stable reading. Increase signal level until display just becomes stable.
- h. Disconnect input and connect to voltmeter; reading should be 25 mV or less. Check other frequencies within the band.
- i. Set input selector switch to DIRECT.
- j. Change input signal to 50 MHz at 15 mV. Counter should display 50 MHz.

6. V-to-F CONVERTER AND ATTENUATOR
A12, A13

- a. Set counter controls as follows:

SAMPLE RATE slightly clockwise out of OFF
RANGE 10 V
FUNCTION DVM
TIME BASE 1s
- b. Connect a jumper lead across the DVM INPUT terminals.
- c. On Voltmeter Input Amplifier Assembly, adjust A12R31 ("ZERO" pot) for \pm 1.0000 V \pm 1 count display.
- d. Disconnect jumper and connect DC Standard to DVM INPUT terminals. Set DC Standard for \pm 10 V output.
- e. On V-to-F Converter Assembly, adjust A13R16 ("+" pot) for \pm 10.0000 V \pm 2 counts.

- f. Reverse polarity of the DC standard.
- g. Adjust A13R15 ("-" pot) for -10.0000 V \pm 2 counts.
- h. Set counter RANGE switch to 100 V.
- i. Set DC Standard for \pm 100 volt output.
- j. On Voltmeter Input Amplifier Assembly, adjust A12R21 ("100 V" pot) for \pm 100.000 volts \pm 2 counts on display.
- k. Reverse polarity of DC Standard and check that display is -100.000 volts \pm 2 counts. If not, adjust A12R21 and repeat steps i., j., and k., until A12R21 setting gives display of \pm 100.000 V \pm 2 counts and -100.000 V \pm 2 counts.
- l. Set counter RANGE switch to 1000 V.

CAUTION

Do not reverse polarity of voltage standard when 990 volts is applied. Damage to the voltage standard may occur.

- m. Set DC Standard for \pm 990 volts output.
- n. On A12, adjust R24 (1000 V pot) for \pm 990.00 \pm 2 counts on display.

7. INPUT C AMPLIFIER A17 (5326B)

- a. Set counter controls as follows:

FUNCTION FREQ C
TIME BASE 0.1s
- b. Set HP 606B HF Signal Generator (or equivalent) for 50 MHz at 500 mV rms. Measure the output signal of 606B with an HP 411A RF Millivoltmeter, using a 50 Ω termination. Connect signal source to INPUT C of counter.
- c. Reduce output level until counter's display becomes unstable. Adjust R11 for a stable display. Repeat this procedure until unable to obtain a stable reading. Increase the signal level until display just becomes stable.
- d. Disconnect input and connect to voltmeter, reading should be less than 5 mV. Check other frequencies within the band.

Table 5-5. D.P. and Annunciator Troubleshooting

Function Switch	Multiplier Switch	r	μ	m	s	.	Decimal						
							10^1	10^2	10^3	10^4	10^5	10^6	
Period AVG A	1		x		x								x
	10		x		x							x	
	10^2		x		x						x		
	10^4	x			x								x
	10^6	x			x								
	10^7	x			x								
	10^8	x			x								
	10^9	x			x								
	10^{10}	x			x								
T.I. AVG A to B	1		x		x								x
	10		x		x								
	10^2		x		x								
	10^4	x			x								x
	10^6	x			x								
	10^8	x			x								
	10^{10}	x			x								
	10^{11}	x			x								
	10^{12}	x			x								
T.I. A to B	1		x		x								x
	10		x		x								
	10^2			x	x								
	10^4			x	x								x
	10^6			x	x								
	10^8				x								
	10^{10}				x								
	10^{12}				x								
	10^{14}				x								
Period A	1		x		x								x
	10		x		x								
	10^2			x	x								
	10^4			x	x								x
	10^6			x	x								
	10^8				x								
	10^{10}				x								
	10^{12}				x								
	10^{14}				x								

Table 5-6. Frequency, D.P., and Annunciator Troubleshooting

Function Switch	Multiplier Switch	G	k	M	Hz	Decimal					
						10 ¹	10 ²	10 ³	10 ⁴	10 ⁵	10 ⁶
Freq. A	1	x			x					x	
	10			x	x						
	10 ²			x	x						x
	10 ³			x	x					x	
	10 ⁴			x	x				x		
	10 ⁵		x		x						x
	10 ⁶		x		x					x	
	10 ⁷		x		x				x		
	10 ⁸		x		x			x			
Freq. C DIRECT	1	x			x					x	
	10			x	x						
	10 ²			x	x						x
	10 ³			x	x					x	
	10 ⁴			x	x				x		
	10 ⁵		x		x						x
	10 ⁶		x		x					x	
	10 ⁷		x		x				x		
	10 ⁸		x		x			x			
Freq. C PRESCALE	1	x			x						x
	10	x			x					x	
	10 ²			x	x						
	10 ³			x	x						x
	10 ⁴			x	x					x	
	10 ⁵		x		x						
	10 ⁶		x		x						x
	10 ⁷		x		x					x	
	10 ⁸		x		x				x		

Table 5-7. DVM, D.P., and Annunciator Troubleshooting

Function Switch	Multiplier Switch	G	k	M	Hz	V	Decimal													
							10 ¹	10 ²	10 ³	10 ⁴	10 ⁵	10 ⁶								
Read A Level	1																			
	10						x													
	10 ²						x													
	10 ³						x													
	10 ⁴						x													
	10 ⁵						x													
	10 ⁶						x													
	10 ⁷						x													
	10 ⁸						x													
DVM	1																			
	10																			
	10 ²																			
	10 ³																			
	10 ⁴																			
	10 ⁵						x													
	10 ⁶						x													
	10 ⁷						x													
10 ⁸																				

SECTION VI REPLACEABLE PARTS

6-1. INTRODUCTION

6-2. This section contains information for ordering replacement parts. Table 6-1 lists parts in alphabetical order of their reference designators and indicates the description and HP Part Number of each part, together with any applicable notes. The table includes the following information.

- a. Description of part (see abbreviations below).
- b. Typical manufacturer of the part in a five-digit code; see list of manufacturers in Table 6-2.
- c. Manufacturer's part number.
- d. Total quantity used in the instrument (TQ column).

6-3. Miscellaneous parts are listed at the end of Table 6-1.

6-4. ORDERING INFORMATION

6-5. To obtain replacement parts, address order of inquiry to your local Hewlett-Packard Sales and Service Office (see lists at rear of this manual for addresses). Identify parts by their Hewlett-Packard part numbers.

6-6. To obtain a part that is not listed, include:

- a. Instrument model number.
- b. Instrument serial number.
- c. Description of the part.
- d. Function and location of the part.

REFERENCE DESIGNATORS							
A	assembly	F	fuse	MP	mechanical part	U	integrated circuit
B	board	FL	filter	P	plug	V	vacuum tube, vacuum
BT	battery	IC	integrated circuit	Q	transistor	WB	wave probe, cable
C	capacitor	J	jack	R	resistor	VR	voltage regulator
CP	coupler	K	relay	RT	thermistor	W	wire
CR	crystal	L	inductor	S	switch	X	socket
DL	delay line	LS	loud speaker	T	transformer	Y	crystal
DS	device signaling (diagnostic)	M	motor	TR	terminal board	Z	board cavity
L	miscellaneous part	MK	microphone	TP	test point		network

ABBREVIATIONS							
A	amplitude	B	bandwidth	N/O	normally open	RMO	rack mount only
ACC	automatic frequency control	BDW	bandwidth	NOM	nominal	RMS	root mean square
AMP	amplifier	BEX	hexagonal	NPO	negative-positive-positive	RWS	reverse-winding
DFO	beat frequency oscillator	BIG	binary		(to temperature coefficient)		voltage
DFCU	direct current supply	BR	board (8)	NPV	negative-positive	S/W	slow flow
DH	data head	BZ	board (8)		negative	SC	see with
DF	bandpass		board (8)	NPV	negative-positive	SCB	see with
DLS	drum	IF	intermediate frequency	NPR	not recommended for	SECT	section
DWO	backward wave oscillator	IMFG	improvised		field replacement	SEMRON	semiconductor
		INCD	incandescent	NSH	not separably	SI	silicon
		INCL	included		replaceable	SH	silver
		INS	insulated	OND	order by description	SL	slide
		INT	internal	OH	oval head	SPG	spring
		K	kilo- (1000)	OX	oxide	SP1	special
		LH	left hand	P	peak	SSI	stainless steel
		LPS	linear taper	PC	printed circuit	SC	split ring
		LK WASH	lock washer	PE	permeable to 12	ST1	steel
		LTK	logarithmic taper		tarad	TA	tactile
		LPF	low pass filter	PH 10RZ	phosphor bronze	TD	time delay
		M	mil (10 ⁻³)	PH1	Phillips	TLG	thread
		MEG	mega- (10 ⁶)	PV	peak-to-peak voltage	THD	through
		MEY ELM	metal film	PNP	positive-negative-positive	TI	titanium
		MET OX	metal oxide		positive	TO1	tolerance
		MFR	manufacturer	P O	part of	TRM	trimmer
		MHZ	mega hertz	POLY	polyethylene	TRT	traveling wave tube
		MISA1	monetary	PURC	purchase		micro- (10 ⁻⁶)
		MOM	monetary	POS	positions	U	micro- (10 ⁻⁶)
		MOS	metal oxide substrate	POT	potentiometer	VAR	variable
		MTC	mounting	PP	peak-to-peak	VDCW	dc working volts
		MY	"mylar"	PT	point	W	with
		N	nano- (10 ⁻⁹)	PV	peak-to-peak voltage	W	with
		N C	normally closed	REC1	rectifier	WV	working reverse
		NE	new	RF	radio frequency	WV	voltage
		NET	nickel plate	RH	round head or	WW	with wound
					right hand	W O	without

01194-14

Figure 6-1. Panel Designations




Table 6-1. Replaceable Parts, Standard Instruments

Reference Designation	HP Part Number	Qty	Description	Mfr Code	Mfr Part Number
A1	05326-60047	1	ATTENUATOR ASSY (SERIES 1224A) (LOADED ON 0632620047 BLANK BOARD)	2848C	05326-60047
			NOTE 1 A1R26 & A1R26 APE NOT INCLUDED WHEN A1 IS ORDERED UNDER A1R26 & R26 SEPARATELY		
A1C1	0160-2244	2	CIFXD CER 3.0*7-0.25 PF 500VDCM	2848C	0160-2244
A1C2	0160-0939	2	CIFXD MICA 430 PF 5X 100 VOLCM	2848C	0160-0939
A1C3	0160-0378	2	CIFXD MICA 27PF 5X	72136	FDH15E270J55
A1C4	0160-0161	4	CIFXD MY 0.01 UF 10X 200VDCM	56289	152P10352-PT5
A1C5	0160-2140	2	CIFXD CER 470 PF +80-20X 1000VDCM	9141E	TYPE R
A1C6	0160-2930	19	CIFXD CER 0.01 UF +80-20X 100VDCM	9141E	TA
A1C7	0160-2197	2	CIFXD MIL 10 PF 5X	72136	FDM15C100J3C
A1C8	0160-2146	2	CIFXD CER 0.02 UF +80-20X 100VDCM	9141E	TA
A1C9	0160-2930		CIFXD CER 0.01 UF +80-20X 100VDCM	9141E	TA
A1C10	0160-2244		CIFXD CER 3.0*7-0.25 PF 500VDCM	2848C	0160-2244
A1C11	0160-0939		CIFXD MICA 430 PF 5X 300 VOLCM	2848C	0160-0939
A1C12	0160-0378		CIFXD MICA 27PF 5X	72136	FDH15E270J55
A1C13	0160-0161		CIFXD MY 0.01 UF 10X 200VDCM	56289	152P10352-PT5
A1C14	0160-2140		CIFXD CER 470 PF +80-20X 1000VDCM	9141E	TYPE R
A1C15	0160-2930		CIFXD CER 0.01 UF +80-20X 100VDCM	9141E	TA
A1C16	0160-2197		CIFXD MICA 10 PF 5X	72136	FDM15C100J3C
A1C17	0160-2146		CIFXD CER 0.02 UF +80-20X 100VDCM	9141E	TA
A1CR1	1910-0016	24	DIODE GE 60 MV	2848C	1910-0016
A1CR2	1910-0016		DIODE GE 60 MV	2848C	1910-0016
A1CR3	1901-0376	6	DIODE SILICON 35V	2848C	1901-0376
A1CR4	1901-0376		DIODE SILICON 35V	2848C	1901-0376
A1CR6	1902-0041	4	DIODE BREAKDOWN 5.11V 5X	0471J	5210939-98
A1CR7	1902-0041		DIODE BREAKDOWN 5.11V 5X	0471J	5210939-98
A1CR9	1910-0016		DIODE GE 60 MV	2848C	1910-0016
A1CR10	1901-0376		DIODE SILICON 35V	2848C	1901-0376
A1CR11	1901-0376		DIODE SILICON 35V	2848C	1901-0376
A1CR13	1902-0041		DIODE BREAKDOWN 5.11V 5X	0471J	5210939-98
A1CR14	1902-0041		DIODE BREAKDOWN 5.11V 5X	0471J	5210939-98
A1O51	2140-0047	2	LAMP NEON GLOW 0.6 MILLIAMPS	0860E	AIC
A1O52	-0047		LAMP NEON GLOW 0.6 MILLIAMPS	0860E	AIC
A1J1	1251-0472	2	CONNECTOR IPE 12 CONTACTS	7178E	252-06-30-300
A1J2	1251-0472		CONNECTOR IPE 12 CONTACTS	7178E	252-06-30-300
A1J3	1250-1163	2	CONNECTOR IPE BNC INPUT	2848C	1250-1163
A1J4	1250-1163		CONNECTOR IPE BNC INPUT	2848C	1250-1163
A1Q1	1855-0334	2	STRIP FET DUAL N-CHANNEL	1785E	DN377
A1Q2	1855-0334		STRIP FET DUAL N-CHANNEL	1785E	DN377
A1R1	0683-2235	4	REFXD COMP 22K OHM 5% 1/4W	01121	CR 2235
A1R2	0683-9145	4	REFXD COMP 910K OHM 5% 1/4W	01121	CR 9145
A1R3	0683-1015	21	REFXD COMP 100 OHM 5% 1/4W	01121	CR 1015
A1R4	0767-0047	2	REFXD COMP 9100 OHM 2% 1/4W	2848C	0767-0047
A1R5	0767-0073	4	REFXD COMP 110K OHM 2% 1/4W	2848C	0767-0073
A1R6	0683-1055	4	REFXD COMP 1 MEG OHM 5% 1/4W	01121	CR 1055
A1R7	0767-0073		REFXD COMP 110K OHM 2% 1/4W	2848C	0767-0073
A1R8	0683-2215	8	REFXD COMP 220 OHM 5% 1/4W	01121	CR 2215
A1R9	0683-4715	8	REFXD COMP 470 OHM 5% 1/4W	01121	CR 4715
A1R10	0683-1055		REFXD COMP 1 MEG OHM 5% 1/4W	01121	CR 1055
A1R11	0683-3325	19	REFXD COMP 3300 OHM 5% 1/4W	01121	CR 3325
A1R12	0683-4715		REFXD COMP 470 OHM 5% 1/4W	01121	CR 4715
A1R13	0683-4715		REFXD COMP 470 OHM 5% 1/4W	01121	CR 4715
A1R14	0683-2225	24	REFXD COMP 2.2K OHM 5% 1/4W	01121	CR 2225
A1R15	0683-2225		REFXD COMP 2.2K OHM 5% 1/4W	01121	CR 2225
A1R16	0683-2235		REFXD COMP 22K OHM 5% 1/4W	01121	CR 2235
A1R17	0683-9145		REFXD COMP 910K OHM 5% 1/4W	01121	CR 9145
A1R18	0683-1015		REFXD COMP 100 OHM 5% 1/4W	01121	CR 1015
A1R19	0767-0047		REFXD COMP 9100 OHM 2% 1/4W	2848C	0767-0047
A1R20	0767-0073		REFXD COMP 110K OHM 2% 1/4W	2848C	0767-0073
A1R21	0683-1055		REFXD COMP 1 MEG OHM 5% 1/4W	01121	CR 1055
A1R22	0767-0073		REFXD COMP 110K OHM 2% 1/4W	2848C	0767-0073
A1R23	0683-2215		REFXD COMP 220 OHM 5% 1/4W	01121	CR 2215
A1R24	2100-3228	2	REVAR COMP 10K OHM 20% LIN 1/2W (SEE NOTE 1 ABOVE)	2848C	2100-3228
A1R25	0683-1055		REFXD COMP 1 MEG OHM 5% 1/4W	01121	CR 1055
A1R26	2100-3228		REVAR COMP 10K OHM 20% LIN 1/2W (SEE NOTE 1 ABOVE)	2848C	2100-3228
A1R27	0683-4715		REFXD COMP 470 OHM 5% 1/4W	01121	CR 4715

See Introduction to this section for ordering information

Model 5326/27B
Replaceable Parts

Table 6-1. Replaceable Parts, Standard Instruments (Cont'd)

Reference Designation	HP Part Number	Qty	Description	Mfr Code	Mfr Part Number
A1E2P	0683-1125		WOUND COMP 220K OHM 5% 1/4W	01121	CR 2225
A1E2S	0683-2225		WOUND COMP 222K OHM 5% 1/4W	01121	CR 2225
A1E30	0683-2225		WOUND COMP 222K OHM 5% 1/4W	01121	CR 2225
A1E31	0683-1005	6	WOUND COMP 10 OHM 5% 1/4W	01121	CR 1005
A1E32	0683-1005		WOUND COMP 10 OHM 5% 1/4W	01121	CR 1005
A1E33	0683-1005		WOUND COMP 10 OHM 5% 1/4W	01121	CR 1005
A1E34	0683-1005		WOUND COMP 10 OHM 5% 1/4W	01121	CR 1005
A1S1	3101-1554	1	SWITCHESIDE DPDT POSITION	7848F	3101-1554
A1S2	3101-1554	2	SWITCHESIDE DPDT POSITION	7848F	3101-1554
A1S3	3101-1554		SWITCHESIDE DPDT POSITION	7848F	3101-1554
A1S4	3101-1554	4	SWITCHESIDE DPDT MINIATURE	7848E	3101-1554
A1S5	3101-1554	2	SWITCHESIDE DPDT	7848C	3101-1554
A1S6	3101-1554		SWITCHESIDE DPDT	7848C	3101-1554
A1S7	3101-1554		SWITCHESIDE DPDT MINIATURE	7848E	3101-1554
A1S8			PART OF 626		
A1S9			PART OF 626		
A2	05326-20004	2	INPUT AMPLIFIER ASSY (SERIES 072) (LOADED ON 05326-20004 BLANK BOARD)	7848C	05326-20004
A2C1	0160-2930		CEFRD CER 0.01 UF +80-20% 100VDCW	9141E	TA
A2C2	0160-2930		CEFRD CER 0.01 UF +80-20% 100VDCW	9141E	TA
A2C3	0160-2930		CEFRD CER 0.01 UF +80-20% 100VDCW	9141E	TA
A2C4	0160-0197	1	CEFRD ELECT 2.2 UF 10% 200VDCW	9628S	150222PAC,0A,0A,0A
A2C5	0160-0197		CEFRD ELECT 2.2 UF 10% 200VDCW	9628S	150222PAC,0A,0A,0A
A2C6	0160-0197	4	CEFRD MY 0.001 UF 10% 200VDCW	9628S	150222PAC,0A,0A,0A
A2C7	0170-0055	6	CEFRD MY 0.1UF 20% 200VDCW	9628S	150222PAC,0A,0A,0A
A2C8	0160-2930		CEFRD CER 0.01 UF +80-20% 100VDCW	9141E	TA
A2C9	0160-2930		CEFRD CER 0.01 UF +80-20% 100VDCW	9141E	TA
A2C10	1502-0049	3	DIODE BREAKDOWN 0.14V 5T	04713	15020049-100
A2C11	1510-0014		DIODE 0.14V 5T	2848C	1510-0014
A2C12	1001-0040	28	DIODE SILICON 50 MA 30 WV	07263	10010040
A2C13	1010-0016		DIODE 0.14V 5T	2848C	1010-0016
A2C14	1001-0040		DIODE SILICON 50 MA 30 WV	07263	10010040
A2L1	0140-0144		COIL FWD HF 47 UH	2848D	0140-0144
A2L2	0100-2256	4	COIL CHOK 0.47 UH 10%	2848D	0100-2256
A2L3	0140-0144		COIL FWD HF 47 UH	2848D	0140-0144
A2L4	9140-0144		COIL FWD HF 4.7 UH	2848C	9140-0144
A2L5	9100-2255		COIL/CHOK 0.47 UH 10%	2848C	9100-2255
A2L6	9140-0144		COIL FWD HF 4.7 UH	2848C	9140-0144
A2L7	9140-0144		COIL FWD HF 4.7 UH	2848C	9140-0144
A2L8	9140-0142	4	COIL FWD HF 2.20 UH 10%	6142	054436-048
A2L9	9140-0144		COIL FWD HF 4.7 UH	2848C	9140-0144
A2L10	9140-0144		COIL FWD HF 4.7 UH	2848C	9140-0144
A2Q1	1854-0092	25	1STRSE PNP	60131	18540092
A2Q2	1853-0015	20	1STRSE PNP	60131	18530015
A2Q3	1853-0015		1STRSE PNP	60131	18530015
A2Q4	1854-0345	6	1STRSE PNP	60131	18540345
A2Q5	1854-0345		1STRSE PNP	60131	18540345
A2Q6	1853-0015		1STRSE PNP	60131	18530015
A2Q7	1853-0015		1STRSE PNP	60131	18530015
A2Q8	1854-0092		1STRSE PNP	60131	18540092
A2Q9	1853-0015		1STRSE PNP	60131	18530015
A2Q10	1853-0015		1STRSE PNP	60131	18530015
A2Q11	1853-0015		1STRSE PNP	60131	18530015
A2Q12	1853-0015		1STRSE PNP	60131	18530015
A2Q13	1853-0015		1STRSE PNP	60131	18530015
A2Q14	1854-0092		1STRSE PNP	60131	18540092
A2Q15	1854-0071	23	1STRSE PNP (SELECTED FROM 1857051)	2848C	1854-0071
A2Q16	1854-0092		1STRSE PNP	60131	18540092
A2Q17	1854-0092		1STRSE PNP	60131	18540092
A2Q18	1854-0345	4	1STRSE PNP	60131	18540345
A2Q19	1854-0092		1STRSE PNP	60131	18540092
A2Q20	1854-0071		1STRSE PNP (SELECTED FROM 1857051)	2848C	1854-0071
A2R1	0683-2225	3	WOUND COMP 220K OHM 5% 1/4W	01121	CR 2225
A2R2	7100-2520	4	WOUND COMP 50 OHM 5% 1/4W	01121	CR 2520
A2R3	0683-2225		WOUND COMP 220 OHM 5% 1/4W	01121	CR 2225
A2R4	0683-2405	2	WOUND COMP 24 OHM 5% 1/4W	01121	CR 2405
A2R5	0683-1425	5	WOUND COMP 3600 OHM 5% 1/4W	01121	CR 1425
A2R6	0683-1015		WOUND COMP 100 OHM 5% 1/4W	01121	CR 1015
A2R7	0683-1025	7	WOUND COMP 1000 OHM 5% 1/4W	01121	CR 1025
A2R8	0683-1025	10	WOUND COMP 1000 OHM 5% 1/4W	01121	CR 1025

See introduction to this section for ordering information

Table 6-1. Replaceable Parts, Standard Instruments (Cont'd)

Reference Designation	HP Part Number	Qty	Description	Mfr Code	Mfr Part Number
A2K5	0650-1111	5	REFUR COMP 100 OHM 5% 1/2W	2848C	0650-1111
A2K10	0650-1101	5	REFUR COMP 150 OHM 5% 1/2W	2848C	0650-1101
A2K11	0650-1175	5	REFUR COMP 100 OHM 5% 1/2W	2848C	0650-1175
A2K12	0650-1175	5	REFUR COMP 60 OHM 5% 1/2W	2848C	0650-1175
A2K13	0650-1175	2	REFUR COMP 33 OHM 5% 1/2W	2848C	0650-1175
A2K14	0650-1525	11	REFUR COMP 1500 OHM 5% 1/2W	01121	CR 1525
A2K15	0650-5180	5	REFUR COMP 2K OHM 5% 1/2W	2848C	0650-5180
A2K16	0650-5175		REFUR COMP 100 OHM 5% 1/2W	2848C	0650-5175
A2K17	0650-1101		REFUR COMP 150 OHM 5% 1/2W	2848C	0650-1101
A2K18	0650-1025		REFUR COMP 1000 OHM 5% 1/2W	01121	CR 1025
A2K19	0650-1111		REFUR COMP 100 OHM 5% 1/2W	2848C	0650-1111
A2K20	0650-1015		REFUR COMP 100 OHM 5% 1/2W	01121	CR 1015
A2K21	0650-1025		REFUR COMP 1000 OHM 5% 1/2W	01121	CR 1025
A2K22	0650-1025		REFUR COMP 3000 OHM 5% 1/2W	01121	CR 1025
A2K23	0650-2225		REFUR COMP 222K OHM 5% 1/2W	01121	CR 2225
A2K24	2100-2521	2	MEMBR FILM 2000 OHM 10% 1/2W	2848C	2100-2521
A2K25	0650-2225		REFUR COMP 222K OHM 5% 1/2W	01121	CR 2225
A2K26	0650-1015		REFUR COMP 100 OHM 5% 1/2W	01121	CR 1015
A2K27	0650-1015		REFUR COMP 100 OHM 5% 1/2W	01121	CR 1015
A2K28	0650-6815	5	REFUR COMP 680 OHM 5% 1/2W	01121	CR 6815
A2K29	0650-6815		REFUR COMP 680 OHM 5% 1/2W	01121	CR 6815
A2K30	0650-6725	5	REFUR COMP 670 OHM 5% 1/2W	01121	CR 6725
A2K31	0650-1015	2	REFUR COMP 100 OHM 5% 1/2W	01121	CR 1015
A2K32	0650-1015	6	REFUR COMP 100 OHM 5% 1/2W	01121	CR 1015
A2K33	0650-1015		REFUR COMP 100 OHM 5% 1/2W	01121	CR 1015
A2K34	0650-1015		REFUR COMP 100 OHM 5% 1/2W	01121	CR 1015
A2K35	0650-1015		REFUR COMP 100 OHM 5% 1/2W	01121	CR 1015
A2K36	0650-1015		REFUR COMP 100 OHM 5% 1/2W	01121	CR 1015
A2K37	0650-2225		REFUR COMP 222K OHM 5% 1/2W	01121	CR 2225
A2K38	0650-1025		REFUR COMP 1000 OHM 5% 1/2W	01121	CR 1025
A2K39	0650-2225		REFUR COMP 222K OHM 5% 1/2W	01121	CR 2225
A2K40	0650-2225		REFUR COMP 222K OHM 5% 1/2W	01121	CR 2225
A2K41	0650-1025		REFUR COMP 1000 OHM 5% 1/2W	01121	CR 1025
A2K42	0650-1025		REFUR COMP 1000 OHM 5% 1/2W	01121	CR 1025
A2K43	0650-1015	2	REFUR COMP 100 OHM 5% 1/2W	01121	CR 1015
A2K44	0650-1015	2	REFUR COMP 300 OHM 5% 1/2W	01121	CR 1015
A2K45	0650-1115		REFUR COMP 110 OHM 5% 1/2W	01121	CR 1115
A2K46	0650-1025		REFUR COMP 1000 OHM 5% 1/2W	01121	CR 1025
A2K47	0650-1065	2	REFUR COMP 10M OHM 5% 1/2W	01121	CR 1065
A2K48	0650-2055	2	REFUR COMP 2 MEGOHM 5% 1/2W	01121	CR 2055
A2K49	0650-2715	5	REFUR COMP 270 OHM 5% 1/2W	01121	CR 2715
A2K50	0650-2715		REFUR COMP 270 OHM 5% 1/2W	01121	CR 2715
A201	1820-0192	2	INTEGRATED CIRCUIT:IC1 INPUT NOR GATE	04713	MC1004P
A202	1820-0192	1	INTEGRATED CIRCUIT:IC1 INPUT NOR GATE	04713	MC1004P
A			SAME AS A2 USE PREFIX A3		
A4	05326-40002	1	OSCILLATOR ASSY (SERIES 1032) (LOADED ON 06326-20002 BLANK BOARD)	2848C	05326-40002
A4L1	0110-0161		REFUR MY 0.01 UF 10% 200VDC	56285	150P1055-115
A4L2	0110-0162		REFUR ELECT 2.2 UF 10% 20VDC	56285	150D2255C/0A2-015
A4C3	0121-0075	1	CEVAR CER 200 PF 100VDC	2848C	0121-0075
A4C4	0110-2564	1	CEVAR CER 10 PF 5% 100VDC	25602	0110-2564
A4C5	0110-2930	1	CEVAR CER 0.01 UF 10% 200VDC	29312	TA
A4L1	0110-2576	1	CEVAR CER 100 OHM 10%	2848C	0110-2576
A401	1820-0192	1	157FREQ PNP	40131	2848C
A4F1	0650-4017	1	REFUR MET FILM 100 OHM 1% 1/2W	2848C	0650-4017
A4F2	0650-1025		REFUR COMP 1000 OHM 5% 1/2W	01121	CR 1025
A4F3	0650-1015		REFUR COMP 100 OHM 5% 1/2W	01121	CR 1015
A4F4	0650-1015		REFUR COMP 100 OHM 5% 1/2W	01121	CR 1015
A401	1820-0192		INTEGRATED CIRCUIT:IC1 INPUT NOR GATE	04713	MC1004P
A4Y1	0410-0405	1	CRYSTAL QUARTZ 10 MHZ	2848C	0410-0405
A5	05326-40005	1	TIME BASE CONTROL ASSY (SERIES 1121) (LOADED ON 05326-20005 BLANK BOARD)	2848C	05326-40005
A5C1	0110-0162		REFUR ELE T 2.2 UF 10% 20VDC	56285	150D2255C/0A2-015

See Introduction to this section for ordering information

Model 5326/27B
 Replaceable Parts

Table 6-1. Replaceable Parts, Standard Instruments (Cont'd)

Reference Designation	HP Part Number	Qty	Description	Mfr Code	Mfr Part Number
A5C2	0160-0177	1	CERD CAP 1.0 UF 20% 25VDC	56285	1%10C5000P2A2005
A5C3	0160-0291	2	CERD ELECT 1.0 UF 10% 25VDC	56285	1%10C5000P2A2005
A5C4	0160-2150	5	CERD MICA 33 PF 5% 50VDC	2848C	0160-2150
A5C5	0160-2204	7	CERD MICA 100PF 5%	2848C	0160-2204
A5CP1	1501-0040		DIODESILICON 50 MA 30 WV	07263	1%10D00
A5Q1	1854-0092		1STRRESI NPN	2848C	1854-C071
A5Q2	1854-0092		1STRRESI NPN	2848C	1854-C071
A5Q3	1854-0071		1STRRESI NPNSELECTED FROM 283704	2848C	1854-C071
A5Q4	1854-0071		1STRRESI NPNSELECTED FROM 283704	2848C	1854-C071
A5Q5	1854-0071		1STRRESI NPNSELECTED FROM 283704	2848C	1854-C071
A5Q6	1854-0071		1STRRESI NPNSELECTED FROM 283704	2848C	1854-C071
A5R1	0683-1035		REFR COMP 10K OHM 5% 1/4W	01121	0683-1035
A5R2	0683-1035		REFR COMP 10K OHM 5% 1/4W	01121	0683-1035
A5R3	0683-1105	4	REFR COMP 51 OHM 5% 1/4W	01121	0683-1105
A5R4	0683-1125		REFR COMP 1500 OHM 5% 1/4W	01121	0683-1125
A5R5	0683-4715		REFR COMP 470 OHM 5% 1/4W	01121	0683-4715
A5R6	0683-1125		REFR COMP 1500 OHM 5% 1/4W	01121	0683-1125
A5R7	0683-1225	2	REFR COMP 1200 OHM 5% 1/4W FACTORY SELECTED VALUE	01121	0683-1225
A5R8	0683-1025		REFR COMP 1000 OHM 5% 1/4W	01121	0683-1025
A5R9	0683-1025		REFR COMP 1000 OHM 5% 1/4W	01121	0683-1025
A5R10	0683-2215		REFR COMP 220 OHM 5% 1/4W	01121	0683-2215
A5R11	0683-6815		REFR COMP 68K OHM 5% 1/4W	01121	0683-6815
A5R12	0683-1325		REFR COMP 1300 OHM 5% 1/4W	01121	0683-1325
A5R13	0683-1325		REFR COMP 1300 OHM 5% 1/4W	01121	0683-1325
A5R14	0683-1325		REFR COMP 1300 OHM 5% 1/4W	01121	0683-1325
A5R15	0683-1325		REFR COMP 1300 OHM 5% 1/4W	01121	0683-1325
A5R16	0683-1025		REFR COMP 1000 OHM 5% 1/4W	01121	0683-1025
A5R17	0683-1025		REFR COMP 1000 OHM 5% 1/4W	01121	0683-1025
A5R18	0683-2225		REFR COMP 22K OHM 5% 1/4W	01121	0683-2225
A5R19	0683-2225		REFR COMP 22K OHM 5% 1/4W	01121	0683-2225
A5R20	0683-5105		REFR COMP 51 OHM 5% 1/4W	01121	0683-5105
A5R21	0683-5105		REFR COMP 51 OHM 5% 1/4W	01121	0683-5105
A5U1	1820-0412	7	INTEGRATED CIRCUITDECADE DIVIDER	2848C	1820-C412
A5U2	1820-0412		INTEGRATED CIRCUITDECADE DIVIDER	2848C	1820-C412
A5U3	1820-0412		INTEGRATED CIRCUITDECADE DIVIDER	2848C	1820-C412
A5U4	1820-0412		INTEGRATED CIRCUITDECADE DIVIDER	2848C	1820-C412
A5U5	1820-0054	4	IC6TTL QUAD 2-INPUT NAND GATE	01297	1820-C054
A5U6	1820-0412		INTEGRATED CIRCUITDECADE DIVIDER	2848C	1820-C412
A5U7	1820-0412		INTEGRATED CIRCUITDECADE DIVIDER	2848C	1820-C412
A5U8	1820-0412		INTEGRATED CIRCUITDECADE DIVIDER	2848C	1820-C412
A5U9	1820-0413	2	IC6TTL DECADE DIVIDER 12.5 MHZ MIN.	2848C	1820-C413
A5U10	1820-0174	1	IC6TTL HEX INVERTER	01297	1820-C017
AL	05326-00013	1	SAMPLE RATE ASSY (SERIES 12248) (MOUNTED ON 05326-20012 PLANK BOARD)	2848C	05326-00013
A6C1	0160-2201	1	CERD MICA 51 PF 5%	2848C	0160-2201
A6C2	0160-0154	1	CERD MICA 250PF 5% 50VDC	2848C	0160-0154
A6C3	0160-0228	3	CERD ELECT 22 UF 10% 25VDC	56285	1%10C5000P2A2005
A6C4	0160-0166	1	CERD MY 0.001 UF 10% 200VDC	56285	1%10C5000P2A2005
A6C5	0160-0153	1	CERD MICA 82 PF 5%	2848C	0160-0153
A6C6	0160-0153		CERD MY 0.001 UF 10% 200VDC	56285	1%10C5000P2A2005
A6C7	0160-2159	2	CERD MICA 33 PF 5% 50VDC FACTORY SELECTED PART	2848C	0160-2159
A6C8	0160-0153		CERD MY 0.001 UF 10% 200VDC	56285	1%10C5000P2A2005
A6C9	0160-0291		CERD ELECT 1.0 UF 10% 25VDC	56285	1%10C5000P2A2005
A6C10	0160-0161		CERD MY 0.01 UF 10% 200VDC	56285	1%10C5000P2A2005
A6C11	0160-0114	6	CERD ELECT 5.0 UF 10% 10% 25VDC	2848C	0160-0114
A6C12	0160-0114		CERD ELECT 5.0 UF 10% 10% 25VDC	2848C	0160-0114
A6CP1	1501-0040		DIODESILICON 50 MA 30 WV	07263	1%10D00
A6CP2	1501-0040		DIODESILICON 50 MA 30 WV	07263	1%10D00
A6CP3	1501-0016		DIODEGE 60 WV	2848C	1501-0016
A6CP4	1501-0016		DIODEGE 60 WV	2848C	1501-0016
A6CP5	1501-0040		DIODESILICON 50 MA 30 WV	07263	1%10D00
A6CP6	1501-0040		DIODESILICON 50 MA 30 WV	07263	1%10D00
A6CP7	1501-0040		DIODESILICON 50 MA 30 WV	07263	1%10D00
A6CP8	1501-0040		DIODESILICON 50 MA 30 WV	07263	1%10D00
A6CP9	1501-0016		DIODEGE 60 WV	2848C	1501-0016
A6CP10	1501-0040		DIODESILICON 50 MA 30 WV	07263	1%10D00
A6CP11	1501-0040		DIODESILICON 50 MA 30 WV	07263	1%10D00
A6Q1	1854-0071		1STRRESI NPNSELECTED FROM 283704	2848C	1854-C071
A6Q2	1854-0071		1STRRESI NPNSELECTED FROM 283704	2848C	1854-C071

See introduction to this section for ordering information

Table 6-1. Replaceable Parts, Standard Instruments (Cont'd)

Reference Designation	HP Part Number	Qty	Description	Mfr Code	Mfr Part Number
AR01	1P74-0071	7	INTERSE MINISELECTED FROM 2617041	2848C	1P74-0071
AR02	1P74-0009		INTERSE MIN	PG131	28705
AR03	1P74-0071		INTERSE MINISELECTED FROM 2617041	2848C	1P74-0071
AR04	1P74-0071		INTERSE MINISELECTED FROM 2617041	2848D	1P74-0071
AR05	1P74-0215		INTERSE MIN	EG131	281564
AR06	1P74-0071	1	INTERSE MINISELECTED FROM 2617041	2848D	1P74-0071
AR07	1P74-0071		INTERSE MINISELECTED FROM 2617041	2848C	1P74-0071
AR08	1P74-0071		INTERSE MINISELECTED FROM 2617041	2848C	1P74-0071
AR09	1P74-0009		INTERSE MIN	PG131	28705
AR10	1P74-0071		INTERSE MINISELECTED FROM 2617041	2848D	1P74-0071
AR11	1P74-0071	11	INTERSE MINISELECTED FROM 2617041	2848D	1P74-0071
AR12	CG83-1015		REFRD COMP 100 OHM 5% 1/4W	01121	CB 1015
AR13	CG83-1525		REFRD COMP 1500 OHM 5% 1/4W	01121	CB 1525
AR14	CG83-1125		REFRD COMP 1100 OHM 5% 1/4W	01121	CB 1125
AR15	CG83-1035		REFRD COMP 100 OHM 5% 1/4W	01121	CB 1035
AR16	CG83-1035	6	REFRD COMP 100 OHM 5% 1/4W	01121	CB 1035
AR17	CG83-5125		REFRD COMP 5100 OHM 5% 1/4W	01121	CB 5125
AR18	CG83-1035		REFRD COMP 100 OHM 5% 1/4W	01121	CB 1035
AR19	CG83-1525		REFRD COMP 1500 OHM 5% 1/4W	01121	CB 1525
AR20	CG83-1015		REFRD COMP 100 OHM 5% 1/4W	01121	CB 1015
AR21	CG83-2025	5	REFRD COMP 2000 OHM 5% 1/4W	01121	CB 2025
AR22	CG83-2735		REFRD COMP 270 OHM 5% 1/4W	01121	CB 2735
AR23	CG83-1125		REFRD COMP 1100 OHM 5% 1/4W	01121	CB 1125
AR24	CG83-3525		REFRD COMP 3500 OHM 5% 1/4W	01121	CB 3525
AR25	CG83-1035		REFRD COMP 100 OHM 5% 1/4W	01121	CB 1035
AR26	CG83-1525	8	REFRD COMP 1500 OHM 5% 1/4W	01121	CB 1525
AR27	CG83-5125		REFRD COMP 5100 OHM 5% 1/4W	01121	CB 5125
AR28	CG83-3525		REFRD COMP 3500 OHM 5% 1/4W	01121	CB 3525
AR29	CG83-1525		REFRD COMP 1500 OHM 5% 1/4W	01121	CB 1525
AR30	CG83-1035		REFRD COMP 100 OHM 5% 1/4W	01121	CB 1035
AR31	CG83-2735	3	REFRD COMP 270 OHM 5% 1/4W	01121	CB 2735
AR32	CG83-3525		REFRD COMP 3500 OHM 5% 1/4W	01121	CB 3525
AR33	CG83-2025		REFRD COMP 2000 OHM 5% 1/4W	01121	CB 2025
AR34	CG83-2735		REFRD COMP 270 OHM 5% 1/4W	01121	CB 2735
AR35	CG83-1035		REFRD COMP 100 OHM 5% 1/4W	01121	CB 1035
AR36	CG83-1525	1	REFRD COMP 1500 OHM 5% 1/4W	01121	CB 1525
AR37	CG83-2025		REFRD COMP 2000 OHM 5% 1/4W	01121	CB 2025
AR38	CG83-1025		REFRD COMP 100 OHM 5% 1/4W	01121	CB 1025
AR39	CG83-1125		REFRD COMP 1100 OHM 5% 1/4W	01121	CB 1125
AR40	CG83-1525		REFRD COMP 1500 OHM 5% 1/4W	01121	CB 1525
AR41	CG83-1035	2	REFRD COMP 100 OHM 5% 1/4W	01121	CB 1035
AR42	CG83-1035		REFRD COMP 100 OHM 5% 1/4W	01121	CB 1035
AR43	CG83-0475		REFRD COMP 400 OHM 5% 1/4W	01121	CB 0475
AR44	CG83-1035		REFRD COMP 100 OHM 5% 1/4W	01121	CB 1035
AR45	CG83-1035		REFRD COMP 100 OHM 5% 1/4W	01121	CB 1035
AR46	CG83-475	7	REFRD COMP 470 OHM 5% 1/4W	01121	CB 475
AR47	CG83-1525		REFRD COMP 1500 OHM 5% 1/4W	01121	CB 1525
AR48	CG83-1035		REFRD COMP 100 OHM 5% 1/4W	01121	CB 1035
AR49	CG83-475		REFRD COMP 470 OHM 5% 1/4W	01121	CB 475
AR50	CG83-1035		REFRD COMP 100 OHM 5% 1/4W	01121	CB 1035
AR51	1P7C-0054	1	IC: TTL QUAD 2-INPT NAND GATE	0129*	SN7400N
AR52	1P7C-0272		IC: TTL TYPE C 1/2	04711	MC1022P
AR53	1P7C-0054		IC: TTL TRIPLE 3-INPT PLS NAND GATE	1704C	SN7410N
AR54	1P7C-0054		IC: TTL QUAD 2-INPT NAND GATE	0129*	SN7400N
AR55	1P7C-0326		IC: TTL QUAD 2-INPT NOR GATE	04713	SN7402N
AR56	1P7C-0147	6	IC: TTL TRIPLE 3-INPT NOR GATE	04713	MC1007P
A7	05327-00031	1	BOARD ASSY:FUNCTION CONTROL (SERIES 112A) (LOADED ON 05327 20004 BLANK BOARD)	2848D	05327-00031
A7C1	0160 2306	1	C. FXD MICA 27 PF 5%	2848D	0160 2306
A7C2	0160 0042	1	C. FXD TR 47 PF 5% 500VDCW	2848H	TYPE GA
A7C3	0160 2160	1	C. FXD MICA 33 PF 5% 300VDCW	2848D	0160 2160
A7C4	1501-0535	2	DIODE HYBRID HVT CARRIER	2848C	1501-0535
A7K1	0683-1125	4	REFRD COMP 1100 OHM 5% 1/4W	01121	CB 1125
A7K2	0683-1825	6	REFRD COMP 1800 OHM 5% 1/4W	01121	CB 1825
A7K3	0683-1825		REFRD COMP 1800 OHM 5% 1/4W	01121	CB 1825
A7K4	0683-1025		REFRD COMP 1000 OHM 5% 1/4W	01121	CB 1025

See introduction to this section for ordering information

Model 6326/27B
Replaceable Parts

Table 6-1. Replaceable Parts, Standard Instruments (Cont'd)

Reference Designation	HP Part Number	Qty	Description	Mfr Code	Mfr Part Number
A7K1	0683-1127	5	REFR COMP 500 OHM 5% 1/4W	G1121	CR 1125
A7K2	0683-2227		REFR COMP 2.2K OHM 5% 1/4W	G1121	CR 2225
A7K3	0683-1127		REFR COMP 100 OHM 5% 1/4W	G1121	CR 1125
A7K4	0683-2227		REFR COMP 2.2K OHM 5% 1/4W	G1121	CR 2225
A7K5	0683-1127		REFR COMP 100 OHM 5% 1/4W	G1121	CR 1125
A7K10	0683-1125	5	REFR COMP 100 OHM 5% 1/4W	G1121	CR 1125
A7K11	0683-1027		REFR COMP 1000 OHM 5% 1/4W	G1121	CR 1025
A7K12	0683-1127		REFR COMP 100 OHM 5% 1/4W	G1121	CR 1125
A7K13	0683-1125		REFR COMP 100 OHM 5% 1/4W	G1121	CR 1125
A7K14	0683-1125		REFR COMP 100 OHM 5% 1/4W	G1121	CR 1125
A7K15	0683-1015	5	REFR COMP 100 OHM 5% 1/4W	G1121	CR 1015
A7K16	0683-1115		REFR COMP 510 OHM 5% 1/4W	G1121	CR 1115
A7K17	0683-1015		REFR COMP 100 OHM 5% 1/4W	G1121	CR 1015
A7K18	0683-1015		REFR COMP 100 OHM 5% 1/4W	G1121	CR 1015
A7K19	0683-1025		REFR COMP 1000 OHM 5% 1/4W	G1121	CR 1025
A7K20	0683-1125	5	REFR COMP 100 OHM 5% 1/4W	G1121	CR 1125
A7K21	0683-1027		REFR COMP 1000 OHM 5% 1/4W	G1121	CR 1025
A7K22	0683-1015		REFR COMP 100 OHM 5% 1/4W	G1121	CR 1015
A7K23	0683-1115		REFR COMP 510 OHM 5% 1/4W	G1121	CR 1115
A7K24	0683-1115		REFR COMP 150 OHM 5% 1/4W	G1121	CR 1115
A7K25	0683-2415	5	REFR COMP 240 OHM 5% 1/4W	G1121	CR 2415
A7K26	0683-1025		REFR COMP 1000 OHM 5% 1/4W	G1121	CR 1025
A7K27	0683-1115		REFR COMP 510 OHM 5% 1/4W	G1121	CR 1115
A7K28	0683-1115		REFR COMP 510 OHM 5% 1/4W	G1121	CR 1115
A7K29	0683-1115		REFR COMP 750 OHM 5% 1/4W	G1121	CR 1115
A7K30	0683-1115	5	REFR COMP 100 OHM 5% 1/4W	G1121	CR 1115
A7U1	1E2C-0102		INTEGRATED CIRCUIT—K FLIP FLUP	G4713	MC1011P
A7U2	1E2C-0489		ICELC	2848C	1E2C-0485
A7U3	1E2C-0167		ICELC TRIPLE 3-INPT NOR GATE	G4713	MC1007P
A7U4	1E2C-0102		INTEGRATED CIRCUIT—K FLIP FLUP	G4713	MC1011P
A7U5	1E2C-0440	1	ICELC DUAL 8V 1/2	G4713	MC1016P
A7U6	1E2C-0167		ICELC TRIPLE 3-INPT NOR GATE	G4713	MC1007P
A7U7	1E2C-0489		ICELC	2848C	1E2C-0485
A7U8	1E2C-0114		ICELC QUAD LINE RECEIVER	G4713	MC102CP
A7U9	1E2C-0489		ICELC	2848C	1E2C-0485
A7U10	1E2C-0201	1	ICELC QUAD EXCL OR GATE	G4713	MC1038P
A7U11	1E2C-0145		IC DIGITAL QUAD 2 INPT NOR GATE	2848D	1E2C-0145
A7U12	1E2C-0489		ICELC	2848C	1E2C-0485
A7U13	1E2C-0257		ICELC DUAL 3-IN 1 INPT OR/AND GATE	G4713	MC1028P
A7U14	1E2C-0809		ICELC QUAD LINE RECEIVER	G4713	MC1011P
A7U15	1E2C-0808	1	ICELC DUAL 3 INPT 3 OUT NOR GATE	G4713	MC1011P
A7U35	1200-0474		SOCKET IC 14 PIN	2848D	1200-0474
AP	0E326-80005	1	DISPLAY SUPPORT ASSY (SERIES 544) (LOADED ON 0E326 20000 BLANK BOARD)	2848C	0E326-80005
APC1	0140-1910	1	CAPAC CER 0.01 UF +40-208 100VDCM	7141E	TA
APC2	0140-2155		CAPAC MICA 30 PF 5% 100VDCM	7848C	0140-1155
APC4	1501-0040	1	DIODE SIGNALON 50 MA 30 WV	G7263	1501-0040
APC5	1510-0016		DIODE SIG 20 WV	2848C	1510-0016
APC6	1510-0016		DIODE SIG 20 WV	2848C	1510-0016
APC7	1501-0040		DIODE SIGNALON 50 MA 30 WV	G7263	1501-0040
APJ1	1251-2035		CONNECTORPC EDGE 12 X 153 30 CONTACT	71705	252-15-30-100
APQ1	1E54-0092	1	TSTRESI RPN	R0131	263563
APQ2	1E54-0092		TSTRESI RPN	R0131	263563
APQ3	1E54-0365		TSTRESI RPN	R0131	26441C
APQ4	1E54-0365		TSTRESI RPN	R0131	26441C
APQ5	1E54-0365		TSTRESI RPN	R0131	26441C
APQ6	1E54-0365	1	TSTRESI RPN	R0131	26441C
APQ7	1E54-0365		TSTRESI RPN	R0131	26441C
APQ8	1E54-0365		TSTRESI RPN	R0131	26441C
APQ9	1E54-0052		TSTRESI RPN	R0131	263563
APQ10	1E54-0052		TSTRESI RPN	R0131	263563
APQ11	1E54-0092	7	TSTRESI RPN	R0131	263563
APR1	0683-1125		REFR COMP 100 OHM 5% 1/4W	G1121	CR 1125
APR2	0683-1045		REFR COMP 100K OHMS 5% 1/4W	G1121	CR 1045
APR3	0683-1045		REFR COMP 100K OHMS 5% 1/4W	G1121	CR 1045
APR4	0683-1025		REFR COMP 1000 OHM 5% 1/4W	G1121	CR 1025
APR5	0683-1255	6	REFR COMP 1.2 MEGOHM 5% 1/4W	G1121	CR 1255
APR6	0683-1255		REFR COMP 1.2 MEGOHM 5% 1/4W	G1121	CR 1255
APR7	0683-1255		REFR COMP 1.2 MEGOHM 5% 1/4W	G1121	CR 1255
APR8	0683-1255		REFR COMP 1.2 MEGOHM 5% 1/4W	G1121	CR 1255
APR9	0683-1255		REFR COMP 1.2 MEGOHM 5% 1/4W	G1121	CR 1255

See introduction to this section for ordering information

Table 6-1. Replaceable Parts, Standard Instruments (Cont'd)

Reference Designation	HP Part Number	Qty	Description	Mfr Code	Mfr Part Number		
ANF10	0683-1255	1	REFRD COMP 1.2 MEGOHM 5% 1/4W	C1121	CR 1255		
ANF11	0683-2425		REFRD COMP 2500 OHM 5% 1/4W	C1121	CR 2425		
ANF12	0683-1015		REFRD COMP 100 OHM 5% 1/4W	C1121	CR 1015		
ANF13	0683-1025		REFRD COMP 1000 OHM 5% 1/4W	C1121	CR 1025		
ANF14	0683-2715		REFRD COMP 270 OHM 5% 1/4W	C1121	CR 2715		
APF15	0683-4725	1	REFRD COMP 4700 OHM 5% 1/4W	01121	CR 4725		
APF16	0683-1025		REFRD COMP 1000 OHM 5% 1/4W	01121	CR 1025		
APF17	0683-4725		REFRD COMP 4700 OHM 5% 1/4W	C1121	CR 4725		
APF18	0683-5115		REFRD COMP 510 OHM 5% 1/4W	C1121	CR 5115		
APF19	0683-1045		REFRD COMP 100K OHMS 5% 1/4W	C1121	CR 1045		
APR20	0683-1045	1	REFRD COMP 100K OHMS 5% 1/4W	C1121	CR 1045		
APR21	0683-2725		REFRD COMP 2700 OHM 5% 1/4W	C1121	CR 2725		
APR22	0683-5115		REFRD COMP 510 OHM 5% 1/4W	C1121	CR 5115		
APR23	0683-1045		REFRD COMP 100K OHMS 5% 1/4W	C1121	CR 1045		
APR24	0683-2725		REFRD COMP 2700 OHM 5% 1/4W	C1121	CR 2725		
APR25	0683-1535	1	REFRD COMP 15K OHM 5% 1/4W	01121	CR 1535		
APR26	0683-2225		REFRD COMP 2.2K OHM 5% 1/4W	01121	CR 2225		
ARU1	1820-0096		3	IC6016 QUAD 2-INPUT GATE	C4713	MC6039P	
ARU2	1820-0107		1	IC6016 HEX INVERTER	C4713	MC6039P	
ARU3	1820-0143		1	INTEGRATED CIRCUIT-AC COUPLED JK T/F	C4713	MC1027P	
APU4	1820-0102	1	INTEGRATED CIRCUIT-2-K FLIP FLOP	C4713	MC1013P		
APU5	1820-0102		INTEGRATED CIRCUIT-2-K FLIP FLOP	C4713	MC1013P		
APU6	1820-0102		INTEGRATED CIRCUIT-2-K FLIP FLOP	C4713	MC1013P		
AV	05326-6000B 05326-60025 OH	1	DISPLAY ASSY (SERIES 1312A) (LOADED ON 05326-2000B BLANK BOARD)	2848C 2848C	05326-6000B 05326-60025		
A9D51	1970-0042	7	TUBENUMERICAL INDICATOR SOCKETTUBE FOR 5700 SERIES	B3594	B-5750-5		
A9D52	1970-0042			B3594	SR 207		
A9D53	1970-0042	8	TUBENUMERICAL INDICATOR SOCKETTUBE FOR 5700 SERIES	B3594	B-5750-5		
A9D54	1970-0042			B3594	SR 207		
A9D55	1970-0042	1	TUBENUMERICAL INDICATOR SOCKETTUBE FOR 5700 SERIES	B3594	B-5750-5		
A9D56	1970-0042			B3594	SR 207		
A9D57	1970-0042	1	TUBENUMERICAL INDICATOR SOCKETTUBE FOR 5700 SERIES	B3594	B-5750-5		
A9D58	1970-0042			B3594	SR 207		
A9R1	0683-1025	8	REFRD COMP 1000 OHM 2% 1/4W	C1121	CR 1025		
A9R2	0698-8431			2848C	0698-8431		
A9R3	0683-1025			C1121	CR 1025		
A9R4	0698-8431			2848C	0698-8431		
A9R5	0698-8431			2848C	0698-8431		
A9R6	0698-8431			2848C	0698-8431		
A9R7	0698-8431			2848C	0698-8431		
A9R8	0698-8431			2848C	0698-8431		
A9R9	0698-8431			2848C	0698-8431		
A9R10	0683-1005			C1121	CR 1005		
A9R11	0698-8431	2848C	0698-8431				
A9R12	0683-1005	C1121	CR 1005				
A9U1	1820-0275	1	IC6016 TTL QUAD 2-INPUT UP TRANS.	C4713	MC1039P		
A9U2	1820-0119			2848C	1820-0119		
A9U3	1820-0119	6	IC6016 BLANKING DECADE COUNTER	2848C	1820-0119		
A9U4	1820-0119			2848C	1820-0119		
A9U5	1820-0119			2848C	1820-0119		
A9U6	1820-0119			2848C	1820-0119		
A9U7	1820-0119			2848C	1820-0119		
A9U8	1820-0116			7	IC14-BIT BUFF STORE GATED OUTF	2848C	1820-0116
A9U9	1820-0116					2848C	1820-0116
A9U10	1820-0116	2848C	1820-0116				
A9U11	1820-0116	2848C	1820-0116				
A9U12	1820-0116	2848C	1820-0116				
A9U13	1820-0116	2848C	1820-0116				

See Introduction to this section for ordering information.

FOR THIS INSTRUMENT, 1820-0275 ARE DIRECTLY INTERCHANGEABLE WITH 1820-0119 WHEN USED FOR U3 THRU U7.

Table G-1. Replaceable Parts, Standard Instruments (Cont'd)

Reference Designation	HP Part Number	Qty	Description	Mfr Code	Mfr Part Number
A4014	1820-0116		IC14-PER PUFF STEER GATED GUIS	2848C	1820-0116
A4015	1820-0116		IC14-PER PUFF STEER GATED GUIS	2848C	1820-0116
A4017	1820-0092	1	INTEGRATED CIRCUIT DECODER-DIVIDER	2848C	1820-0092
A4018	1820-0092	2	INTEGRATED CIRCUIT DECODER-DIVIDER	2848C	1820-0092
A4019	1820-0092		INTEGRATED CIRCUIT DECODER-DIVIDER	2848C	1820-0092
A4020	1820-0092		INTEGRATED CIRCUIT DECODER-DIVIDER	2848C	1820-0092
A4021	1820-0092		INTEGRATED CIRCUIT DECODER-DIVIDER	2848C	1820-0092
A4022	1820-0092		INTEGRATED CIRCUIT DECODER-DIVIDER	2848C	1820-0092
A4023	1820-0092		INTEGRATED CIRCUIT DECODER-DIVIDER	2848C	1820-0092
A4024	1200-0477	1	SOCKET	2848C	1200-0477
A4025	1200-0477		SOCKET	2848C	1200-0477
A10	05327-6000B	1	RIGHT HEADOUT ASSY (SERIES 1104A, REV. B) (LOADED ON 05327-2000B BLANK BOARD)	2848C	05327-6000B
	05326-00009	2	BRACKET HEADOUT	2848C	05326-00009
	05327-6000B	1	INDICATOR MASK (U, N, S, I)	2848C	05327-6000B
	05326-00009	1	INDICATOR MASK (V, K, G, I)	2848C	05326-00009
	05326-00010	1	INDICATOR MASK (R, K, G, I)	2848C	05326-00010
	05330-40002	2	BLOCK ANNUNCIATOR	2848C	05330-40002
A10C1	1501-004C		DIODE SILICON 50 MA 30 WV	07263	1501008
A10C2	1501-004C		DIODE SILICON 50 MA 30 WV	07263	1501008
A10D51	2140-0313	14	LAMP NEON GLOW FROSTED 1.9 MILLIAMPS	08804	C2A-B
A10D52	2140-0313		LAMP NEON GLOW FROSTED 1.9 MILLIAMPS	08804	C2A-B
A10D53	2140-0313		LAMP NEON GLOW FROSTED 1.9 MILLIAMPS	08804	C2A-B
A10D54	2140-0313		LAMP NEON GLOW FROSTED 1.9 MILLIAMPS	08804	C2A-B
A10D55	2140-0313		LAMP NEON GLOW FROSTED 1.9 MILLIAMPS	08804	C2A-B
A10D56	2140-0313		LAMP NEON GLOW FROSTED 1.9 MILLIAMPS	08804	C2A-B
A10D57	2140-0313		LAMP NEON GLOW FROSTED 1.9 MILLIAMPS	08804	C2A-B
A10D58	2140-0313		LAMP NEON GLOW FROSTED 1.9 MILLIAMPS	08804	C2A-B
A10D59	2140-0313		LAMP NEON GLOW FROSTED 1.9 MILLIAMPS	08804	C2A-B
A10E1	1854-0074		TRANSISTOR NPN	80131	2A705
A10E2	1854-0074		TRANSISTOR NPN	80131	2A705
A10E3	1854-0074		TRANSISTOR NPN	80131	2A705
A10E4	1854-0074		TRANSISTOR NPN	80131	2A705
A10E5	1854-0074		TRANSISTOR NPN	80131	2A705
A10E6	1854-0074	10	TRANSISTOR NPN	2848C	1854-0074
A10E7	1854-0074		TRANSISTOR NPN	2848C	1854-0074
A10E8	1854-0074		TRANSISTOR NPN	2848C	1854-0074
A10E9	1854-0074		TRANSISTOR NPN	2848C	1854-0074
A10E10	1854-0074		TRANSISTOR NPN	2848C	1854-0074
A10E11	1854-0074		TRANSISTOR NPN	2848C	1854-0074
A10E12	1854-0074		TRANSISTOR NPN	2848C	1854-0074
A10E13	1854-0074		TRANSISTOR NPN	2848C	1854-0074
A10F1	0683-5125		RESISTOR COMP 5100 OHM 5% 1/4W	01121	CR 5125
A10F2	0683-5125		RESISTOR COMP 5100 OHM 5% 1/4W	01121	CR 5125
A10F3	0683-5125		RESISTOR COMP 5100 OHM 5% 1/4W	01121	CR 5125
A10F4	0683-3025		RESISTOR COMP 3000 OHM 5% 1/4W	01121	CR 3025
A10F5	0683-3025		RESISTOR COMP 3000 OHM 5% 1/4W	01121	CR 3025
A10F6	0683-2025		RESISTOR COMP 2000 OHM 5% 1/4W	01121	CR 2025
A10F7	0683-3025		RESISTOR COMP 3000 OHM 5% 1/4W	01121	CR 3025
A10F8	0683-5135	6	RESISTOR COMP 51K OHM 5% 1/4W	01121	CR 5135
A10F9	0683-5135		RESISTOR COMP 51K OHM 5% 1/4W	01121	CR 5135
A10G1	1820-0274	12	IC10TL QUAD 2-INPT OR GATE	2848C	1820-0274
A10G2	1820-0274		IC10TL QUAD 2-INPT OR GATE	2848C	1820-0274
A10G3	1820-0274		IC10TL QUAD 2-INPT OR GATE	2848C	1820-0274
A10G4	1820-0274		IC10TL QUAD 2-INPT OR GATE	2848C	1820-0274
A10G5	1820-0310	1	IC10TL TRIPLE 3-INPT NAND GATE	04713	SC6910PK
A10G6	1820-0273	4	IC10TL QUAD 2-INPT AND GATE	2848C	1820-0273
A10G7	1820-0273		IC10TL QUAD 2-INPT AND GATE	2848C	1820-0273
A10G8	0610 0207		STANDOFF PRESS IN	2848C	0610 0207
A11	05327-60007	1	LEFT HEADOUT ASSY (SERIES 1104A, REV. A) (LOADED ON 05327-20007 BLANK BOARD)	2848C	05327-60007

See introduction to this section for ordering information

Table 6-1. Replaceable Parts, Standard Instruments (Cont'd)

Reference Designation	HP Part Number	Qty	Description	Mfr Code	Mfr Part Number
A11C1	05326-0000V		BRACKET/REAR CUT	2848C	05326-0000V
	05326-0000Z	1	INDICATOR MASK	2848C	05326-0000Z
	05326-00011	1	INDICATOR MASK (EXT., C, OFF)	2848C	05326-00011
	05330-4000Z		PLUG/ANNUNCIATOR	2848C	05330-4000Z
	0160-2200	1	LEAD WIRE 43 PF 5K	7213E	0160-2200
A11D1	2140-0313		LAMP/NEON GLW FROSTED 1.5 MILLIAMPS	0860F	C2A-B
A11D2	2140-0313		LAMP/NEON GLW FROSTED 1.5 MILLIAMPS	0860F	C2A-B
A11D3	2140-0313		LAMP/NEON GLW FROSTED 1.5 MILLIAMPS	0860F	C2A-B
A11D4	2140-0313		LAMP/NEON GLW FROSTED 1.5 MILLIAMPS	0860F	C2A-B
A11D5	2140-0313		LAMP/NEON GLW FROSTED 1.5 MILLIAMPS	0860F	C2A-B
A11Q1	1854-0071		TSTRISI NPPISELECTED FROM 2N3702J	2848C	1854-0071
A11Q2	1854-0474		TSTRISI NPN	2848C	1854-0474
A11Q3	1854-0474		TSTRISI NPN	2848C	1854-0474
A11Q4	1854-0474		TSTRISI NPN	2848C	1854-0474
A11Q5	1854-0474		TSTRISI NPN	2848C	1854-0474
A11Q6	1854-0474		TSTRISI NPN	2848C	1854-0474
A11R1	0683-2035	1	REFRD COMP 20K OHM 5K 1/4W	0112J	CR 2035
A11R2	0683-1035		REFRD COMP 10K OHM 5K 1/4W	0112J	CR 1035
A11R3	0683-5125		REFRD COMP 5100 OHM 5K 1/4W	0112J	CR 5125
A11R4	0683-5135		REFRD COMP 51K OHM 5K 1/4W	0112J	CR 5135
A11R5	0683-2025		REFRD COMP 2000 OHM 5K 1/4W	0112J	CR 2025
A11R6	0683-5135		REFRD COMP 51K OHM 5K 1/4W	0112J	CR 5135
A11R7	0683-5125		REFRD COMP 5100 OHM 5K 1/4W	0112J	CR 5125
A11R8	0683-5135		REFRD COMP 51K OHM 5K 1/4W	0112J	CR 5135
A11R9	0683-5125		REFRD COMP 5100 OHM 5K 1/4W	0112J	CR 5125
A11R10	0683-1525		REFRD COMP 1500 OHM 5K 1/4W	0112J	CR 1525
A11R11	0683-1025		REFRD COMP 1000 OHM 5K 1/4W	0112J	CR 1025
A11R12	0683-5125		REFRD COMP 5100 OHM 5K 1/4W	0112J	CR 5125
A11R13	0683-5135		REFRD COMP 51K OHM 5K 1/4W	0112J	CR 5135
A11U1	1820-0054		IC/DTL QUAD 2-INPT NAND GATE	0129E	58740CN
A11U2	1820-0274		IC/DTL QUAD 2-INPT OR GATE	2848C	1820-0274
A11U3	1820-0274		IC/DTL QUAD 2-INPT OR GATE	2848C	1820-0274
A11U4	1820-0274		IC/DTL QUAD 2-INPT OR GATE	2848C	1820-0274
A11U5	1820-0327	1	IC/DTL QUAD 2-INPT NAND GATE	0471J	587401N
A11U6	1820-0274		IC/DTL QUAD 2-INPT OR GATE	2848C	1820-0274
A11U7	1820-0274		IC/DTL QUAD 2-INPT AND GATE	2848C	1820-0274
A11U8	1820-0274		IC/DTL QUAD 2-INPT OR GATE	2848C	1820-0274
	0610 0207		STANDOFF PRESS IN	2848C	0610 0207
A1Z	05326-60016	1	VOLTMETER INPUT AMPLIFIER ASSY (SERIES LOAD)	2848C	05326-60016
			(EQUIPPED ON 05326-20016 BLANK DISPLAY)		
A12C1	0160-2930		REFRD CER 0.01 UF +80-20% 100VDCW	9141E	1A
A12C2	0160-2307	1	REFRD MICA 47 PF 5K	2848C	0160-2307
A12C3	0160-2930		REFRD CER 0.01 UF +80-20% 100VDCW	9141E	1A
A12C4	0160-2930		REFRD CER 0.01 UF +80-20% 100VDCW	9141E	1A
A12CR2	1901-0376		DIODE/SILICON 35V	2848C	1901-0376
A12CR3	1901-0376		DIODE/SILICON 35V	2848C	1901-0376
A12CR4	1902-3083	1	DIODE/GERMANIUM 6.3V 2T	2848C	1902-3083
A12CR5	1402-0049		DIODE/GERMANIUM 6.19V 5K	0471J	521093N-122
A12CR6	1901-0040		DIODE/SILICON 40 MA 30 WV	0276J	190102E
A12K1	0490-0853	1	RELAY/EL OHM 1500 VDC	2848C	0490-0853
A12K2			NOT ASSIGNED		
A12K3	0490-0764	4	RELAY/REED 0.1 AMP	2848C	0490-0764
A12K4	0490-0764		RELAY/REED 0.1 AMP	2848C	0490-0764
A12K5	0490-0764		RELAY/REED 0.1 AMP	2848C	0490-0764
A12K6	0490-0764		RELAY/REED 0.1 AMP	2848C	0490-0764
A12Q1	1853-0099	1	TSTRISI PNP	8013J	28526
A12Q2			NOT ASSIGNED		
A12Q3	1853-0020	7	TSTRISI NPPISELECTED FROM 2N3702J	2848C	1853-0020
A12Q4	1853-0020		TSTRISI NPPISELECTED FROM 2N3702J	2848C	1853-0020
A12Q5	1853-0020		TSTRISI NPPISELECTED FROM 2N3702J	2848C	1853-0020
A12Q6	1853-0020		TSTRISI NPPISELECTED FROM 2N3702J	2848C	1853-0020
A12Q7	1853-0049	1	TSTRISI FEET M-CHANNEL DUAL	2848C	1853-0049
A12Q8	1854-0087	2	TSTRISI NPN	8013J	285417
A12Q9	1854-0087		TSTRISI NPN	8013J	285417
A12Q10	1853-0036	1	TSTRISI PNP	8013J	285306
A12P3	0698-7618	14	REFRD FLM 888K OHM 1.0% 1/4W	2848C	0698-7618
A12P4	0698-7618		REFRD FLM 888K OHM 1.0% 1/4W	2848C	0698-7618
A12P5	0686-3045	3	REFRD COMP 300K OHM 5K 1/2W	0112J	CR 3045
A12P6	0698-7618		REFRD FLM 888K OHM 1.0% 1/4W	2848C	0698-7618

See introduction to this section for ordering information

Model 5326/27B
Replaceable Parts

Table 6-1. Replaceable Parts, Standard Instruments (Cont'd)

Reference Designation	HP Part Number	Qty	Description	Mfr Code	Mfr Part Number
A1287	0650-7618		REFR FILM BRKR OHP 1.00 175W	2850C	0650-7618
A1288	0650-7618		REFR FILM BRKR OHP 1.00 175W	2850C	0650-7618
A1289	0650-1045		REFR COMP 100K OHP 5E 175W	01121	0650-1045
A12810	0650-7618		REFR FILM BRKR OHP 1.00 175W	2850C	0650-7618
A12811	0650-7618		REFR FILM BRKR OHP 1.00 175W	2850C	0650-7618
A12812	0650-7618		REFR FILM BRKR OHP 1.00 175W	2850C	0650-7618
A12813	0650-1045		REFR COMP 100K OHP 5E 175W	01121	0650-1045
A12814	0650-7618		REFR FILM BRKR OHP 1.00 175W	2850C	0650-7618
A12815	0650-7618	1	REFR FILM BRKR OHP 1.00 175W	2850C	0650-7618
A12816	0650-7618		REFR FILM BRKR OHP 1.00 175W	2850C	0650-7618
A12817	0757-0426	1	REFR MET FILM 110K OHP 1E 175W	2850C	0757-0426
A12818	0650-7618		REFR FILM BRKR OHP 1.00 175W	2850C	0650-7618
A12819	0650-7618		REFR FILM BRKR OHP 1.00 175W	2850C	0650-7618
A12820	0650-1152	1	REFR MET FILM 110K OHP 1E 175W	2850C	0650-1152
A12821	2100-2503	2	WVAR CAPRET 20K OHP 10E TYPE P	2850C	2100-2503
A12822	0650-7618		REFR FILM BRKR OHP 1.00 175W	2850C	0650-7618
A12823	0650-7618		REFR FILM BRKR OHP 1.00 175W	2850C	0650-7618
A12824	2100-2503		WVAR CAPRET 20K OHP 10E TYPE P	2850C	2100-2503
A12825	0650-7618	1	REFR FILM BRKR OHP 1.00 175W	01121	0650-7618
A12826	0650-7618		REFR COMP 100K OHP 5E 175W	01121	0650-7618
A12827	0650-1925		REFR COMP 100K OHP 5E 175W	01121	0650-1925
A12828	0650-1645	1	REFR COMP 100K OHP 5E 175W	01121	0650-1645
A12829	0650-1642		REFR MET FILM 22K OHP 1E 175W	2850C	0650-1642
A12830	0650-1136	2	REFR MET FILM 175K OHP 1E 175W	2850C	0650-1136
A12831	2100-2531	1	WVAR CAPRET 50K OHP 10E TYPE P 175W	2850C	2100-2531
A12832	0650-1136		REFR MET FILM 175K OHP 1E 175W	2850C	0650-1136
A12833	0650-1015		REFR COMP 10K OHP 5E 175W	01121	0650-1015
A12834	0650-1645		REFR COMP 100K OHP 5E 175W	01121	0650-1645
A1281	1820-0223	4	INTEGRATED CIRCUIT OPERATIONAL AMPL	2850C	1820-0223
A13	05327-00017	1	MULTIMETER VHF CONVERTER ASSY (SERIES 1012A) INSTALLED ON C5326-00017 PLANK BOARD	2850C	05327-00017
A13C1	0160-0197		CERAM ELECT 222 OF 10E 200VDC	2850C	1501-0197
A13C2	0160-0197		CERAM ELECT 222 OF 10E 200VDC	2850C	1501-0197
A13C3	0160-0197		CERAM ELECT 222 OF 10E 200VDC	2850C	1501-0197
A13C4	0160-0197		CERAM ELECT 222 OF 10E 200VDC	2850C	1501-0197
A13C5	0160-2150		CERAM MICA 33 PF 5E	2850C	0160-2150
A13C6	0160-2150		CERAM MICA 33 PF 5E	2850C	0160-2150
A13C7	0160-253C		CERAM CAP 0.01 OF 500-20E 100VDC	2850C	1A
A13C8	0160-0055		CERAM MICA 33 PF 5E	2850C	15010402
A13C9	0160-2150		CERAM MICA 33 PF 5E	2850C	0160-2150
A13C10	0160-0055		CERAM MICA 33 PF 5E	2850C	15010402
A13C11	0160-2150		CERAM MICA 33 PF 5E	2850C	0160-2150
A13C12	0160-2245	1	CERAM CAP 5.1 OF 100VDC	2850C	1501-0055
A13C13	1501-0040	2	DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C14	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C15	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C16	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C17	1501-0179	5	DIODES 1N4001 50 MA 50 WV	07503	1501-0179
A13C18	1501-0179		DIODES 1N4001 50 MA 50 WV	07503	1501-0179
A13C19	1501-0179		DIODES 1N4001 50 MA 50 WV	07503	1501-0179
A13C20	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C21	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C22	1501-0179		DIODES 1N4001 50 MA 50 WV	07503	1501-0179
A13C23	1501-0179		DIODES 1N4001 50 MA 50 WV	07503	1501-0179
A13C24	1501-0179		DIODES 1N4001 50 MA 50 WV	07503	1501-0179
A13C25	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C26	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C27	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C28	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C29	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C30	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C31	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C32	1501-0179		DIODES 1N4001 50 MA 50 WV	07503	1501-0179
A13C33	1501-0179		DIODES 1N4001 50 MA 50 WV	07503	1501-0179
A13C34	1501-0179		DIODES 1N4001 50 MA 50 WV	07503	1501-0179
A13C35	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C36	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C37	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C38	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C39	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C40	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C41	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C42	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C43	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C44	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C45	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C46	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C47	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C48	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C49	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C50	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C51	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C52	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C53	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C54	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C55	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C56	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C57	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C58	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C59	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C60	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C61	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C62	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C63	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C64	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C65	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C66	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C67	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C68	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C69	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C70	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C71	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C72	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C73	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C74	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C75	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C76	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C77	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C78	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C79	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C80	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C81	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C82	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C83	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C84	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C85	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C86	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C87	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C88	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C89	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C90	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C91	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C92	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C93	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C94	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C95	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C96	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C97	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C98	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C99	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C100	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C101	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C102	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C103	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C104	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C105	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C106	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C107	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C108	1501-0040		DIODES 1N4001 50 MA 50 WV	07503	1501-0040
A13C109	1501-0040		DIODES 1N		

Table 6-1. Replaceable Parts, Standard Instruments (Cont'd)

Reference Designation	HP Part Number	Qty	Description	Mfr Code	Mfr Part Number
A1361	C757-0421		REFLECT FILM 225 OHM SE 175W	2848C	0757-0421
A1364	G683-1525		REFLECT COAT 1500 OHM SE 175W	C1121	CP 1525
A1365	G683-2225		REFLECT COAT 2225 OHM SE 175W	C1121	CP 2225
A1366	G683-2125		REFLECT COAT 2125 OHM SE 175W	C1121	CP 2125
A1367	G683-1160		REFLECT FILM 1160 OHM SE 175W FACTORY SELECTED PART	2848C	G683-1160
A1368	C757-0158	2	REFLECT FILM 75 OHM SE 175W	2848C	C757-0158
A1369	C757-0198		REFLECT FILM 75 OHM SE 175W	2848C	C757-0198
A13610	G683-1160		REFLECT FILM 1160 OHM SE 175W FACTORY SELECTED PART	2848C	G683-1160
A13611	G683-7610	5	REFLECT FILM 1275 OHM SE 175W	2848C	G683-7610
A13612	C757-0186	2	REFLECT FILM 50 OHM SE 175W	2848C	C757-0186
A13613	C757-0186		REFLECT FILM 50 OHM SE 175W	2848C	C757-0186
A13614	G683-7610		REFLECT FILM 1275 OHM SE 175W	2848C	G683-7610
A13615	2100-2705		REFLECT COAT 1K OHM SE 175W	2848C	2100-2705
A13616	2100-2705		REFLECT COAT 1K OHM SE 175W	2848C	2100-2705
A13617	G683-7610		REFLECT FILM 1275 OHM SE 175W	2848C	G683-7610
A13618	G683-1325		REFLECT COAT 1300 OHM SE 175W	C1121	CP 1325
A13621	G683-7610		REFLECT FILM 1275 OHM SE 175W	2848C	G683-7610
A13624	G683-2225		REFLECT COAT 2225 OHM SE 175W	C1121	CP 2225
A13627	G683-2225		REFLECT COAT 2225 OHM SE 175W	C1121	CP 2225
A13628	G683-7125		REFLECT COAT 7100 OHM SE 175W	C1121	CP 7125
A13629	G683-1325		REFLECT COAT 1300 OHM SE 175W	C1121	CP 1325
A13630	G683-1025		REFLECT COAT 1000 OHM SE 175W	C1121	CP 1025
A13631	G683-1915		REFLECT COAT 190 OHM SE 175W	C1121	CP 1915
A13632	G683-6815		REFLECT COAT 680 OHM SE 175W	C1121	CP 6815
A13633	G683-1025		REFLECT COAT 1000 OHM SE 175W	C1121	CP 1025
A13634	G683-1615	2	REFLECT COAT 160 OHM SE 175W	C1121	CP 1615
A13635	G683-1615		REFLECT COAT 160 OHM SE 175W	C1121	CP 1615
A13636	G683-1615		REFLECT COAT 160 OHM SE 175W	C1121	CP 1615
A13637	G683-2125		REFLECT COAT 2125 OHM SE 175W	C1121	CP 2125
A13638	G683-1025		REFLECT COAT 1000 OHM SE 175W	C1121	CP 1025
A13639	G683-6725		REFLECT COAT 6700 OHM SE 175W	C1121	CP 6725
A13640	G683-1915		REFLECT COAT 190 OHM SE 175W	C1121	CP 1915
A13641	G683-1325		REFLECT COAT 1300 OHM SE 175W	C1121	CP 1325
A1301	1820-0221		INTEGRATED CIRCUIT (OPERATIONAL AMPL.)	2848C	1820-0221
A1302	1820-0222		INTEGRATED CIRCUIT (OPERATIONAL AMPL.)	2848C	1820-0222
A1303	1820-0223		INTEGRATED CIRCUIT (OPERATIONAL AMPL.)	2848C	1820-0223
A1304	1820-0212		IC (DUAL QUAD LINE RECEIVER)	G4711	MC1012
A1305	1820-0213	1	IC (DUAL QUAD LINE RECEIVER)	G4711	MC1013
A1306	1820-0276	1	INTEGRATED CIRCUIT (DIGITAL)	G4711	MC1016
A1307	1820-0165		IC (DIGITAL QUAD 2-INPUT AND GATE)	2848C	1820-0165
A1308	1820-0209	1	INTEGRATED CIRCUIT (DIGITAL)	2848C	1820-0209
A14	05326-0001*	1	MULTIFUNCTION DISPLAY CONTROL ASSY SERIES 5326-1 ELECTRIC IN 5326-0001 REAR PANEL	2848C	05326-0001*
A1401	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1402	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1403	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1404	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1405	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1406	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1407	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1408	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1409	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1410	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1411	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1412	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1413	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1414	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1415	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1416	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1417	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1418	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1419	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1420	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1421	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1422	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1423	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1424	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1425	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1426	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1427	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1428	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1429	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1430	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1431	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1432	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1433	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1434	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1435	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1436	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1437	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1438	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1439	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1440	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1441	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1442	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1443	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1444	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1445	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1446	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1447	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1448	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1449	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1450	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1451	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1452	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1453	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1454	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1455	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1456	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1457	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1458	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1459	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1460	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1461	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1462	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1463	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1464	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1465	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1466	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1467	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1468	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1469	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1470	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1471	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1472	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1473	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1474	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1475	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1476	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1477	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1478	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1479	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1480	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1481	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1482	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1483	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1484	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1485	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1486	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1487	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1488	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1489	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1490	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1491	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1492	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1493	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1494	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1495	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1496	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1497	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1498	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1499	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1500	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1501	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1502	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1503	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1504	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1505	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1506	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1507	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1508	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1509	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1510	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1511	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1512	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1513	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1514	1510-0016		CONNECTOR 60 WIV	2848C	1510-0016
A1515	1510-0016				

Table 6-1. Replaceable Parts, Standard Instruments (Cont'd)

Reference Designation	HP Part Number	Qty	Description	Mfr Code	Mfr Part Number
A16	06327 60020	1	BOARD ASSY POWER SUPPLY (SERIES 147RA) (ELECTED BY 05126-10020 PLANK BOARD)	28480	06327 60020
	0510-0207 2200-0145	1	NOTICATIVE 4-40 X 0.188 IN SCREW PAN HC POZI GR 4-40 X 0.438	2848C 0001C	0510-C207 LPI
	5040-C409	1	SPACER/SHEILD	2848C	5040-C409
A15C1	0160-0163	1	CAPAC MY 0.033 UF 10% 200VDCM	56285	152-3352-PI5
A15C2	0160-0114		CAPAC ELECT 4.0 UF +100-10% 25VDCM	2848C	0160-C114
A15C3	0160-0114		CAPAC ELECT 4.0 UF +100-10% 25VDCM	2848C	0160-C114
A15C4	0160-0114		CAPAC ELECT 4.0 UF +100-10% 25VDCM	2848C	0160-C114
A15C5	0160-0114		CAPAC ELECT 4.0 UF +100-10% 25VDCM	2848C	0160-0114
A15C6	0160-3878	26	CAPAC CER 1000 PF 20% 100VDCM	80031	LV2055878102M
A15C7	0160-3878		CAPAC CER 1000 PF 20% 100VDCM	80031	LV2055878102M
A15C8	0160-3277	2	CAPAC CER 0.01 UF 20% 50VDCM	96733	02048103M
A15C9	0160-3277		CAPAC CER 0.01 UF 20% 50VDCM	96733	05048103M
A15CR1	1502-3002	2	DIODE BREAKDOWN 2.37V 5% DIODE BREAKDOWN 2.37V 5%	28480	1502-3002
A15CR2	1502-0551	2	DIODE BREAKDOWN 16.11V 5% DIODE BREAKDOWN 16.11V 5%	28480	1502-0551
A15CR3	1502-0551		DIODE BREAKDOWN 16.11V 5% DIODE BREAKDOWN 16.11V 5%	28480	1502-0551
A15CR4	1502-3002		DIODE BREAKDOWN 2.37V 5% DIODE BREAKDOWN 2.37V 5%	28480	1502-3002
A15CR5	1501-C079		DIODE SILICON 50 MA 30 WV	07263	16G1088
A15CR6	1502-3094	4	DIODE BREAKDOWN 15.11V 2% DIODE BREAKDOWN 15.11V 2%	28480	1502-3094
A15CR7	1502-3094		DIODE BREAKDOWN 15.11V 2% DIODE BREAKDOWN 15.11V 2%	28480	1502-3094
A15CR8	1501-0040		DIODE SILICON 50 MA 30 WV	07263	16G1088
A15CR9	1502-3094		DIODE BREAKDOWN 15.11V 2% DIODE BREAKDOWN 15.11V 2%	28480	1502-3094
A15CR10	1502-3094		DIODE BREAKDOWN 15.11V 2% DIODE BREAKDOWN 15.11V 2%	28480	1502-3094
A15CR11	1502-3394	1	DIODE BREAKDOWN 17.5 V 2% DIODE BREAKDOWN 17.5 V 2%	28480	1502-3394
A15CR12	1502-3425	1	DIODE BREAKDOWN 17.5 V 2% DIODE BREAKDOWN 17.5 V 2%	28480	1502-3425
A15CR13	1501-0033	2	DIODE SILICON 100MA 180MV	07263	FD3165
A15CR14	1501-0033		DIODE SILICON 100MA 180MV	07263	FD3165
A15CR15	1501-0044	4	DIODE SILICON 20MA/1V	2848C	1501-C044
A15CR16	1501-0044		DIODE SILICON 20MA/1V	28480	1501-0044
A15CR17	1501-0044		DIODE SILICON 20MA/1V	28480	1501-0044
A15CR18	1501-0044		DIODE SILICON 20MA/1V	28480	1501-0044
A15F1	2110 0487	1	FUSE 1/20 AMP	2848C	2110 0487
A15Q1	1854-C300	1	TSTRISE NPN	2848C	1854-C300
A15Q2	1205-0018	2	HEAT SINK SEMICONDUCTOR	0582C	703-18
A15Q3	1853-0073	1	TSTRISE PNP	28480	1853-C073
A15Q4	1205-0018		HEAT SINK SEMICONDUCTOR	0582C	703-18
A15Q5	1854-0039	1	TSTRISE NPN	00131	763053
A15Q6	1205-0033	2	HEAT SINK SEMICONDUCTOR	0582C	707-C2
A15Q7	1853-0012	1	TSTRISE PNP	80111	7625044
A15Q8	1205-0033		HEAT SINK SEMICONDUCTOR	0582C	707-C8
A15Q9	1854-0232	1	TSTRISE NPN (SELECTED FROM 2N3440)	28480	1854-C232
A15Q10	1205-0061	1	HEAT SINK SEMICONDUCTOR	0582C	709-C8
A15Q11	1853-0020		TSTRISE NPN (SELECTED FROM 2N3702)	28480	1853-C020
A15R1	1854-0071		TSTRISE NPN (SELECTED FROM 2N3704)	28480	1854-C071
A15R2	1854-0474		TSTRISE NPN	28480	1854-0474
A15R3	1854-0071		TSTRISE NPN (SELECTED FROM 2N3704)	28480	1854-C071
A15R4	1853-0020		TSTRISE NPN (SELECTED FROM 2N3702)	28480	1853-C020
A15R5	0683-2735		REFRAC COMP 27K OHM 5% 1/4W	01121	CR 2735
A15R6	0683-1015		REFRAC COMP 100 OHM 5% 1/4W	01121	CR 1015
A15R7	0683-1015		REFRAC COMP 100 OHM 5% 1/4W	01121	CR 1015
A15R8	0683-3925		REFRAC COMP 3900 OHM 5% 1/4W	01121	CR 3925
A15R9	0683-3925		REFRAC COMP 3900 OHM 5% 1/4W	01121	CR 3925
A15R10	0683-6477	1	REFRAC COMP 87 OHM 5% 1/2W	01121	CR 8765
A15R11	0683-6815		REFRAC COMP 680 OHM 5% 1/4W	01121	CR 6815
A15R12	0683-6815		REFRAC COMP 680 OHM 5% 1/4W	01121	CR 6815
A15R13	0683-1325	2	REFRAC COMP 1300 OHM 5% 1/4W	01121	CR 1325
A15R14	2100-2053	2	REFRAC COMP 200 OHM 30% LIN 1/8W	28480	2100-2053
A15R15	0683-6815		REFRAC COMP 680 OHM 5% 1/4W	01121	CR 6815
A15R16	0683-6815		REFRAC COMP 680 OHM 5% 1/4W	01121	CR 6815
A15R17	2100-2093		REFRAC COMP 200 OHM 30% LIN 1/8W	28480	2100-2093
A15R18	0683-1125		REFRAC COMP 1300 OHM 5% 1/4W	01121	CR 1125
A15R19	0683-0275	4	REFRAC COMP 2.7 OHM 5% 1/4W	01121	CR 2765
A15R20	0683-0275		REFRAC COMP 2.7 OHM 5% 1/4W	01121	CR 2765
A15R21	0683-0275		REFRAC COMP 2.7 OHM 5% 1/4W	01121	CR 2765
A15R22	0683-0275		REFRAC COMP 2.7 OHM 5% 1/4W	01121	CR 2765
A15R23	0683-0275		REFRAC COMP 2.7 OHM 5% 1/4W	01121	CR 2765
A15R24	1261-3206	2	SOCKET, MINIATURE SINGLE	00770	2 331272 7

See Introduction to this section for ordering information

Table 6-1. Replaceable Parts, Standard Instruments (Cont'd)

Reference Designation	HP Part Number	Qty	Description	Mfr Code	Mfr Part Number
A16	05327-0007	1	BOARD ASSY CONNECTOR (SERIES 1224A) (LOADED ON 05327-2001 BLANK BOARD)	28480	05327-0007
A16C1	0180-0197	1	CERAM ELECT 4000 PF 475-10X 15VDCW	28285	0180-0197
A16C2	0180-0197	1	CERAM ELECT 4000 PF 475-10X 15VDCW	28285	0180-0197
A16C3	0180-0197	1	CERAM ELECT 1500 PF 475-10X 250VDCW	28285	0180-0197
A16C4	0180-0197	2	CERAM ELECT 1500 PF 475-10X 250VDCW	28285	0180-0197
A16C5	0180-0197	2	CERAM ELECT 1500 PF 475-10X 250VDCW	28285	0180-0197
A16C6	0180-0204	1	CERAM MICA 100PF 5X	28285	0180-0204
A16C8	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C9	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C10	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C11	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C12	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C13	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C14	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C15	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C16	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C17	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C18	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C19	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C20	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C21	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C22	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C23	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C24	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C25	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C26	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C27	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C28	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C29	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C30	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C31	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C32	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C33	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C34	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C35	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C36	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C37	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C38	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C39	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C40	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C41	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C42	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C43	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C44	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C45	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C46	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C47	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C48	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C49	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C50	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C51	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C52	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C53	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C54	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C55	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C56	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C57	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C58	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C59	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C60	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C61	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C62	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C63	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C64	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C65	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C66	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C67	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C68	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C69	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C70	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C71	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C72	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C73	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C74	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C75	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C76	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C77	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C78	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C79	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C80	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C81	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C82	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C83	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C84	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C85	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C86	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C87	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C88	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C89	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C90	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C91	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C92	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C93	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C94	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C95	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C96	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C97	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C98	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C99	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16C100	1510-0016	1	DIODE 1N4001	28480	1510-0016
A16D	05326-0001	1	BOARD ASSY INPUT C AMPLIFIER (SERIES 1312A) 5326 ONLY (LOADED ON 05326-2001 BLANK BOARD)	28480	05326-0001
A17C1	0180-0197	1	CERAM ELECT 2.2 UF 10X 20VDCW	28285	0180-0197
A17C2	0180-0197	1	CERAM ELECT 2.2 UF 10X 20VDCW	28285	0180-0197
A17C3	0180-0204	4	CERAM CER FEED-THRU 500G PF 180-JOB	28480	0180-0204
A17C4	0180-0204	4	CERAM CER FEED-THRU 500G PF 180-JOB	28480	0180-0204
A17C5	0180-0106	2	CERAM CER 1000 PF 20X 100VDCW	28480	0180-0106
A17C6	0180-0106	2	CERAM ELECT 60 UF 20X 25VDCW	28480	0180-0106
A17C7	0180-0106	1	CERAM CER 1000 PF 20X 100VDCW	28480	0180-0106
A17C8	0180-0106	1	CERAM ELECT 60 UF 20X 25VDCW	28480	0180-0106
A17C9	0180-0045	2	CERAM CER FEED-THRU 10 PF 5X 500VDCW	28480	0180-0045
A17C10	0180-0045	2	CERAM CER FEED-THRU 10 PF 5X 500VDCW	28480	0180-0045
A17C11	0180-0045	1	CERAM CER FEED-THRU 10 PF 5X 500VDCW	28480	0180-0045
A17C12	0180-0045	1	CERAM CER FEED-THRU 10 PF 5X 500VDCW	28480	0180-0045
A17C13	0180-0045	1	CERAM CER FEED-THRU 10 PF 5X 500VDCW	28480	0180-0045
A17C14	1501-0047	2	DIODE JUNCTION SILICON 20PIV	28480	1501-0047
A17C15	1501-0047	2	DIODE JUNCTION SILICON 20PIV	28480	1501-0047
A17C16	1512-0009	1	DIODE TUNNEL GERMANIUM 35372	01801	1512-0009

See Introduction to this section for ordering information

Table 6-1. Replaceable Parts, Standard Instruments (Cont'd)

Reference Designation	HP Part Number	Qty	Description	Mfr Code	Mfr Part Number
A17J1	1250-0836	2	CONNECTOR, FPC SUB-MINIATURE	58251	50-051-0000
A17L1	9100-2255	1	COIL CHOKER 100 OHM 10%	55600	1027-24
A17L2	9100-2260	1	COIL CHOKER 100 OHM 10%	55142	04-4416-3K
A17L3	9140-0142	1	COIL CHOKER 200 OHM 10%	52142	04-4416-4P
A17L4	9100-2256	1	COIL CHOKER 0.25 OHM 10%	13015	04-4426-3K
A17G1	1851-0015	1	TESTER, PAP	80131	JA1840
A17G2	1851-0015	1	TESTER, PAP	80131	JA1840
A17G3	1854-0092	1	TESTER, NPN	80131	JA3561
A17G4	1854-0345	1	TESTER, NPN	80131	JA5175
A17H1	0760-0012	1	REFRD MET OF 50 OHM 5% 1/4W	28480	0760-0012
A17K2	0683-0093	1	REFRD COMP 100K OHMS 5% 1/4W	28480	0758-0093
A17K3	0683-1045	1	REFRD COMP 100K OHMS 5% 1/4W	01121	CP 1045
A17K4	0683-7515	1	REFRD COMP 750 OHM 5% 1/4W	01121	CB 7515
A17K5	0683-1515	1	REFRD COMP 150 OHM 5% 1/4W	01121	CB 1515
A17K6	0683-1825	1	REFRD COMP 1800 OHM 5% 1/4W	01121	CB 1825
A17K7	0683-1825	1	REFRD COMP 1800 OHM 5% 1/4W	01121	CB 1825
A17K8	0683-1825	1	REFRD COMP 1800 OHM 5% 1/4W	01121	CB 1825
A17K9	0683-1825	1	REFRD COMP 1800 OHM 5% 1/4W	01121	CB 1825
A17K10	0683-2215	1	REFRD COMP 220 OHM 5% 1/4W	01121	CB 2215
A17K11	2100-2633	2	RYVAR CAPMET 1P OHM 10% LHM 1/2W	28480	2100-2633
A17K12	0683-2015	3	REFRD COMP 200 OHM 5% 1/4W	01121	CB 2015
A17K13	0683-2015	3	REFRD COMP 200 OHM 5% 1/4W	01121	CB 2015
A17K14	0683-1515	1	REFRD COMP 150 OHM 5% 1/4W	01121	CB 1515
A17K15	0683-5105	1	REFRD COMP 51 OHM 5% 1/4W	01121	CB 5105
A17K16	0683-7515	1	REFRD COMP 750 OHM 5% 1/4W	01121	CB 7515
A17K17	0683-1045	1	REFRD COMP 100K OHMS 5% 1/4W	01121	CP 1045
A17K18	0683-1225	1	REFRD COMP 1200 OHM 5% 1/4W	01121	CB 1225
A17K19	0683-1625	1	REFRD COMP 1600 OHM 5% 1/4W	01121	CB 1625
A17K21	0683-3153	1	REFRD MET FILM 315K OHM 1% 1/8W	28480	0650-3153
A17K22	0757-0284	1	REFRD MET FILM 150 OHM 1% 1/8W	28480	C157-C284
A17K23	0757-0280	1	REFRD MET FILM 1K OHM 1% 1/8W	28480	0757-0280
A17K24	0683-4715	1	REFRD COMP 470 OHM 5% 1/4W	01121	CB 4715
A17K25	0683-5615	1	REFRD COMP 560 OHM 5% 1/4W	01121	CB 5615
A17K26	0757-0416	1	REFRD MET FILM 511 OHM 1% 1/8W	28480	0757-0416
A17U1	1858-0004	1	TESTER, ANALYZER, NPN, LOGIC, DIFF. AMPL.	28480	1858-0004
A17U2	1820-0147	1	SELECT TRIPLE 3-INPUT NUR GATE	04711	MC1007P
	05326-00031	1	DIFFERENTIAL	28480	05326-00031
A1H	05327-60033	1	BOARD ASSY HIGH SENSITIVITY PRESCALE	28480	05327-60033
			(SERIES 1-4881)		
			INCLUDED ON 05327-24033 BLANK BOARD		
A18C1	0160-0278	1	REFRD ELECT 22 UF 10% 150VDC	56285	150D22E45015H2-DY5
A18C2	0160-2045	3	REFRD CER FEED-THRU 5000 PF 100-20%	28480	0160-2045
A18C3	0160-3878	3	REFRD CER 0.01 UF 10% 100VDC	72967	8121-8112-K7R-103M
A18C4	0160-2045	3	REFRD CER FEED-THRU 5000 PF 100-20%	28480	0160-2045
A18C5	0160-0278	1	REFRD ELECT 22 UF 10% 150VDC	56285	150D22E45015H2-DY5
A18C6	0160-3878	1	REFRD CER 0.01 UF 10% 100VDC	72967	8121-8112-K7R-103M
A18C7	0160-3878	1	REFRD CER 1000 PF 10% 100VDC	80031	CV2055K7F102M
A18C8	0160-3878	1	REFRD CER 1000 PF 10% 100VDC	80031	CV2055K7F102M
A18C9	0160-3878	1	REFRD CER 1000 PF 10% 100VDC	80031	CV2055K7F102M
A18C10	0160-3878	1	REFRD CER 1000 PF 10% 100VDC	80031	CV2055K7F102M
A18C11	0160-3878	1	REFRD CER 1000 PF 10% 100VDC	80031	CV2055K7F102M
A18C12	0160-3878	1	REFRD CER 1000 PF 10% 100VDC	80031	CV2055K7F102M
A18C13	0160-3878	1	REFRD CER 1000 PF 10% 100VDC	80031	CV2055K7F102M
A18C14	0160-3878	1	REFRD CER 1000 PF 10% 100VDC	80031	CV2055K7F102M
A18C15	0160-3878	1	REFRD CER 1000 PF 10% 100VDC	80031	CV2055K7F102M
A18C16	0160-3878	1	REFRD CER 1000 PF 10% 100VDC	80031	CV2055K7F102M
A18C17	0160-3878	1	REFRD CER 1000 PF 10% 100VDC	80031	CV2055K7F102M
A18C18	0160-3878	1	REFRD CER 1000 PF 10% 100VDC	80031	CV2055K7F102M
A18C19	0160-3878	1	REFRD CER 1000 PF 10% 100VDC	80031	CV2055K7F102M
A18C20	0160-3878	1	REFRD CER 1000 PF 10% 100VDC	80031	CV2055K7F102M
A18C21	0160-3878	1	REFRD CER 1000 PF 10% 100VDC	80031	CV2055K7F102M
A18C22	0160-3878	1	REFRD CER 1000 PF 10% 100VDC	80031	CV2055K7F102M
A18C23	0160-3878	1	REFRD CER 1000 PF 10% 100VDC	80031	CV2055K7F102M
A18C24	0160-3878	1	REFRD CER 1000 PF 10% 100VDC	80031	CV2055K7F102M
A18C25	0160-3878	1	REFRD CER 1000 PF 10% 100VDC	80031	CV2055K7F102M
A18C26	0160-3878	1	REFRD CER 1000 PF 10% 100VDC	80031	CV2055K7F102M
A18C27	0160-3878	1	REFRD CER 1000 PF 10% 100VDC	80031	CV2055K7F102M
A18C28	0160-3878	1	REFRD CER 0.01 UF 10% 100VDC	72967	8121-8112-K7R-103M
A18C29	0160-3878	1	REFRD CER 1000 PF 10% 100VDC	80031	CV2055K7F102M
A18C41	1501-0050	2	DIODE, 1N4001, 200 MA AT 1V	07263	1DA 610R
A18C42	1501-0050	2	DIODE, 1N4001, 200 MA AT 1V	07263	1DA 610R

See introduction to this section for ordering information

Table 6-1. Replaceable Parts, Standard Instruments (Cont'd)

Reference Designation	HP Part Number	Qty	Description	Mfr Code	Mfr Part Number
A18CP3	1501-0040		DIODE SILICON 50 MA 30 WV	07263	1CG1088
A18CP4	1501-0040		DIODE SILICON 50 MA 30 WV	07263	1CG1088
A18CP5	1501-0040		DIODE SILICON 50 MA 30 WV	07263	1CG1088
A18CP6	1501-0040		DIODE SILICON 50 MA 30 WV	07263	1CG1088
A18F1	2110-0436	2	FUSE 1/160 AMP 125V	2848C	2110-0436
A18F2	2110-0436		FUSE 1/160 AMP 125V	2848C	2110-0436
A18J1	1250-0816		CONNECTOR 4P SUB-MINIATURE	5829E	50-051-0000
A18L1	9100-1788	2	CELL CHOKI	02114	VR200-1C/48
A18L2	9100-1788		CELL CHOKI	02114	VR200-1C/48
A18Q1	1854-0345		TRANSISTOR NPN	80131	282174
A18Q2	1854-0092		TRANSISTOR NPN	80131	282174
A18R1	0683-1025		REFRD COMP 1000 OHM 5% 1/4W	01121	CR 1025
A18R2	0698-5556	2	REFRD COMP 560 OHM 5% 1/4W	2848D	0698-5556
A18R3	2100-2413		REVAR FLM 1K OHM 10% LIN 1/2W	2848C	2100-2413
A18R4	0683-1025		REFRD COMP 1000 OHM 5% 1/4W	01121	CR 1025
A18R5	0698-3378	5	REFRD CARBON 51 OHM 5% 1/8W	2848C	0698-3378
A18R6	0698-3378		REFRD CARBON 51 OHM 5% 1/8W	2848C	0698-3378
A18R7	0698-3111	5	REFRD COMP 30 OHM 5% 1/8W	2848D	0698-3111
A18R8	0783-1025		REFRD COMP 1000 OHM 5% 1/4W	01121	CR 1025
A18R9	0683-1015		REFRD COMP 200 OHM 5% 1/4W	01121	CR 2015
A18R10	2100-2413	2	REVAR FLM 200 OHM 10% LIN 1/2W	2848D	2100-2413
A18R11	0698-6283	2	REFRD COMP 10 OHM 5% 1/8W	01121	RR 1005
A18R12	0683-1505	2	REFRD COMP 15 OHM 5% 1/4W	01121	CR 1505
A18R13	0698-3374	4	REFRD CARBON 20 OHM 5% 1/8W	2848D	0698-3374
A18R14			NOT ASSIGNED		
A18R15	0698-3180		REFRD COMP 2K OHM 5% 1/8W	2848C	0698-3180
A18R16	0698-3378		REFRD CARBON 51 OHM 5% 1/8W	2848C	0698-3378
A18R17	0698-3374		REFRD CARBON 20 OHM 5% 1/8W	2848D	0698-3374
A18R18	0683-4315	5	REFRD COMP 430 OHM 5% 1/4W	01121	CR 4315
A18R19	0698-5180		REFRD COMP 2K OHM 5% 1/8W	2848D	0698-5180
A18R20	0698-3111		REFRD COMP 30 OHM 5% 1/8W	2848D	0698-3111
A18R21	0698-5556		REFRD COMP 560 OHM 5% 1/8W	2848C	0698-5556
A18R22	0698-4131	4	REFRD COMP 56 OHM 5% 1/8W	2848D	0698-4131
A18R23	0698-4131		REFRD COMP 56 OHM 5% 1/8W	2848C	0698-4131
A18R24	0698-3111		REFRD COMP 30 OHM 5% 1/8W	2848C	0698-3111
A18R25	0683-1025		REFRD COMP 1000 OHM 5% 1/4W	01121	CR 1025
A18R26	0683-1015		REFRD COMP 200 OHM 5% 1/4W	01121	CR 1015
A18R27	2100-2413		REVAR FLM 200 OHM 10% LIN 1/2W	2848D	2100-2413
A18R28	0698-6283		REFRD COMP 10 OHM 5% 1/8W	01121	RR 1005
A18R29	0698-5177	2	REFRD COMP 820 OHM 5% 1/8W	2848D	0698-5177
A18R30	0698-5177		REFRD COMP 820 OHM 5% 1/8W	2848D	0698-5177
A18R31	0683-1505		REFRD COMP 15 OHM 5% 1/4W	01121	CR 1505
A18R32			NOT ASSIGNED		
A18R33	0698-3374		REFRD CARBON 20 OHM 5% 1/8W	2848C	0698-3374
A18R34	0698-5073	1	REFRD COMP 1.6K OHM 5% 1/8W	01121	RR 1625
A18R35	0698-3378		REFRD CARBON 51 OHM 5% 1/8W	2848C	0698-3378
A18R36	0698-3111		REFRD COMP 30 OHM 5% 1/8W	2848D	0698-3111
A18R37	0698-3378		REFRD CARBON 51 OHM 5% 1/8W	2848C	0698-3378
A18R38	0698-3374		REFRD CARBON 20 OHM 5% 1/8W	2848D	0698-3374
A18R39	0683-4315		REFRD COMP 430 OHM 5% 1/4W	01121	CR 4315
A18R40	0698-4131		REFRD COMP 56 OHM 5% 1/8W	2848D	0698-4131
A18R41	0698-5563	1	REFRD CARBON 180 OHM 5% 1/8W	2848C	0698-5563
A18R42	0698-4131		REFRD COMP 56 OHM 5% 1/8W	2848C	0698-4131
A18R43	0698-3111		REFRD COMP 30 OHM 5% 1/8W	2848D	0698-3111
A18R44	0698-3113		REFRD CARBON 100 OHM 5% 1/8W	2848D	0698-3113
A18R45			NOT ASSIGNED		
A18R46	0683-1025		REFRD COMP 1000 OHM 5% 1/4W	01121	CR 1025
A18R47	0683-1505	1	REFRD COMP 15 OHM 5% 1/4W	01121	CR 1505
A18R48	0683-8215	1	REFRD COMP 820 OHM 5% 1/4W	01121	CR 8215
A18R49	0683-1025		REFRD COMP 1000 OHM 5% 1/4W	01121	CR 1025
A18R50	0683-4315		REFRD COMP 430 OHM 5% 1/4W	01121	CR 4315
A18R51	0683-4131		REFRD COMP 430 OHM 5% 1/4W	01121	CR 4131
A18R52	0683-4315		REFRD COMP 430 OHM 5% 1/4W	01121	CR 4315
A18R53			NOT ASSIGNED		
A18U1	5088-7602	1	IC LIMITER	2848C	5088-7602
A18U2	1826-0084	1	IC LINEAR	2848D	1826-0084
A18U3	OR		IC LINEAR		
A18U4	1826 0161	1	IC LINEAR	2848D	1826 0161
A18U5	1820 0736	1	IC DIGITAL	2848D	1820 0736
A18U6	OR				
A18U7	1820 0668	1	IC DUAL BINARY	2848D	1820 0668
A18U8	1820 0714	1	IC DIGITAL BINARY DIVIDER	2848D	1820 0714
A18U9	1820 0489	1	IC ECL	2848D	1820 0489
A18U10	1821 0001	2	TRANSISTOR ARRAY 51 NPN	02735	CA3046
A18U11	1821 0001		TRANSISTOR ARRAY 51 NPN	02735	CA3046

See Introduction to this section for ordering information

Table 6-1. Replaceable Parts, Standard Instruments (Cont'd)

Reference Designation	HP Part Number	Qty	Description	Mfr Code	Mfr Part Number
A1809	1820-0807	1	1000V LOAD CENTER RCP CASE	05717	ML101021
			CHASSIS PARTS		
B1	3150-0015	1	FILTER PATE	2888C	3150-0015
B1	3150-0010	1	MOTOR DRIVEN PULL	2888C	3150-0010
B1	3150-0015	1	FAN FILTERER AXIAL 2-1/2" DIAM	0487C	2 1/2" FPF 1.5"
B1	5212A-1.5	1	BRACKET CLEAN	2888C	5-12A-1.5P
C1	016C-1051	1	CHASSIS 2 X 0.005 OF 20V 250VAC	56285	250127A-100
F1	2110-0010	1	FUSE 0.5A 250V 510W-100	75517	3150-FCC1
F1	2110-0104	1	FUSE CARTRIDGE 1.5 AMP 250V 510W-100	7150C	MDR-1-127A
F1	1400-0014	1	FUSE HOLDER CENTRAL 100 POST TYPE	75517	147014
J1	1510-0075	1	PENDING FUSE ASSEMBLY	2888C	1510-0075
J1	1510-0074	1	PENDING POST ASSEMBLY RIG INSULATOR	2888C	1510-0074
J2	1250-1251	1	CONNECTOR PNC MOUNT JACK	28931	2893154-1
J3	1250-1251	1	CONNECTOR PNC MOUNT JACK	28931	2893154-1
J4	1250-1251	1	CONNECTOR PNC MOUNT JACK	28931	2893154-1
J5	1250-1251	1	CONNECTOR PNC MOUNT JACK	28931	2893154-1
J6	1250-1251	1	CONNECTOR PNC MOUNT JACK	28931	2893154-1
J8	1250-1251	1	CONNECTOR PNC MOUNT JACK	28931	2893154-1
J11	1250-0212	1	CONNECTOR JACK CHASSIS PNC	55712	30405-1
P1	5060-0105	2	CONNECTOR CONTACTS	2888C	5060-0105
Q1	1850-0211	1	TESTER PAD	61597	11P-3
Q1	05327-20024	2	HEAT SINK FOR Q1 AND Q2	2888C	05327-20024
Q2	1850-0520	1	TESTER NPN	2888C	1850-0520
Q2	05327-20024	2	HEAT SINK FOR Q1 AND Q2	2888C	05327-20024
R1	2100-0561	1	PIVOT CORN 1 PEGCORP 100 TO CLOD 124W	2888C	2100-0561
R1	00180-67401	2	PAID ASSY	2888C	00180-67401
S1			PART OF R1		
S2	3101-1554	2	SWITCHESIDE OPT C.A. 125V AC/DC (FAST-NORM-TRIG)	2888C	3101-1554
S3	3101-1216	1	SWITCH PUSHBUTTON SPST (ON-1)	62385	65-1014
S4	3101-1554	1	SWITCHESIDE OPT 0.5A 125V AC/DC (TRIG)	2888C	3101-1554
S5	05327-20018	1	SWITCH ASSYFUNCTION (WIREDE)	2888C	05327-20018
S6	05327-20020	1	SWITCH ASSYFUNCTION (WIREDE)	2888C	05327-20020
S7	05327-20017	1	SWITCH ASSYFUNCTION (WIREDE)	2888C	05327-20017
S7	3101-1554	1	SWITCHESIDE OPT MINIATURE (C-3)	2888C	3101-1554
S8	3101-1554	1	SWITCHESIDE OPT MINIATURE (C-3)	2888C	3101-1554
S9	3101-1216	1	SWITCHESIDE OPT (SELECTOR 125V 30V)	62385	11A-1.5A
T1	5100-1020	1	TRANSFORMER POWER	2888C	5100-1020
			OTHER CABINET PARTS		
	0470-0114	12	TABLETYRANTRANE 1-1/2" IN HIGH	67471	1534M11-2
	1450-0010	1	STAND FEET	2888C	1450-0010
	5000-0010	2	TRIMSECT	2888C	5000-0010
	5060-0124	2	FRAME ASSY 1 X 11SECT	2888C	5060-0124
	5060-0117	2	FEET ASSY 1W	2888C	5060-0117
	05327-00001	1	PANEL FRONT	2888C	05327-00001
	05327-00012	1	PANEL FRONT	2888C	05327-00012
	05327-00004	1	INSULATOR	2888C	05327-00004
	05327-00011	1	PLATE FRONT 0.5" LONG 0.9" COVER	2888C	05327-00011
	05327-00016	1	WINDOW (03228)	2888C	05327-00016
	05327-00006	1	WINDOW (03208)	2888C	05327-00006
	7170-1254	1	TRAEHANA (HP LOGO)	2888C	7170-1254
			PRINTED CABINET PARTS		
	05327-00004	1	COVER FRONT (OPT 1554)	2888C	05327-00004
	05327-00013	1	COVER FRONT	2888C	05327-00013
	05327-00007	1	PANEL FRONT PANEL THIN (OPT ABS X05)	2888C	05327-00007
	05327-00007	1	PANEL FRONT FRONT TRIM (05327) STANDARD	2888C	05327-00007
	05327-00026	1	PANEL FRONT FRONT TRIM (05327) STANDARD	2888C	05327-00026
	05327-00025	1	PANEL FRONT FRONT TRIM (STANDARD)	2888C	05327-00025
	05327-00007	1	PANEL FRONT FRONT PANEL THIN (OPT ABS X05)	2888C	05327-00007
	05327-00024	1	SIDE COVER STANDARD COLOR	2888C	05327-00024
	05327-00021	2	SIDE COVER OPT X05	2888C	05327-00021
	05327-00022	1	TOP COVER (OPT 1554)	2888C	05327-00022

See Introduction to this section for ordering information.

Table 6-1. Replaceable Parts, Standard Instruments (Cont'd)

Reference Designation	HP Part Number	Qty	Description	Mfr Code	Mfr Part Number
	05326-00030	1	TOP COVER STANDARD COVER	2848C	05326-00030
	05326-00029	2	PIEDMONT MOUNTING PLATE (25x1)	2848C	05326-00029
	05326-00028	1	PIEDMONT MOUNTING PLATE (25x1)	2848C	05326-00028
	05326-00046	1	PIEDMONT MOUNTING PLATE (25x1)	2848C	05326-00046
	2170-0012	1	SCREWSET FLAT HD PH 1/8 x 1/2 x 1/8	2848C	2170-0012
	2510-0047	5	SCREW PAN HD PH 1/8 x 1/2 x 0.5125 1/8	0000C	2510-0047
	1020-0706	1	BRACKET LEFT	2848C	1020-0706
	1020-0707	1	BRACKET RIGHT	2848C	1020-0707
	05326-00092	1	STRIP FILLER GRAY	2848C	05326-00092
			INTERNAL AND OTHER PARTS		
	0370 0104	2	KNOB BLK BAR W/ARROW 1/4" SHAFT (FUNCTION FUNCTION 5326B)	2848D	0370 0104
	0340 0134	2	INSULATOR BINDING POST RED	2848D	0340 0134
	0340 0733	2	INSULATOR BINDING POST BLACK	2848D	0340 0733
	0340 0766	1	INSULATOR TRANSISTOR	2848D	0340 0766
	0370 0104	1	KNOB BLK BAR W/ARROW 1/4" SHAFT (TIME BASE)	2848D	0370 0104
	0370 0163	1	KNOB BAR BLK 0.000" DIA (FUNCTION 5327B)	2848D	0370 0163
	1200 0147	1	BUSHING TRANSISTOR	2848D	1200 0147
	01821 67-31	2	KNOB TRIGGER LEVEL	2848D	01821 67401
	05326-20046	1	FLAORID LAMP (REAR PANEL CONNECTOR)	2848C	05326-20046
	05326-00032	1	CABLE ASSY POWER	2848C	05326-00032
	05326-00021	1	CABLE ASSY VOLT METER	2848C	05326-00021
	05326-00019	2	SCALE DVM JACKS WHITE	2848C	05326-00019
	05326-00018	1	CHASSIS	2848C	05326-00018
	05326-00010	1	SHIELDING PIP	2848C	05326-00010
	05326-00011	1	CABLE ASSY PRESCALER	2848C	05326-00011
	05326-00033	1	ADAPTER CONNECTOR	2848C	05326-00033
	5040-0345	4	INSULATOR DVM JACKS JADE GRAY	2848C	5040-0345
	6170-1176	1	CABLE ASSY AC POWER CORD	7050 J	6170-1176
	5060-0109	5	CONNECTOR IS CONTACTS	2848C	5060-0109
	5040-0170	5	GRID PLUG-IN PC BOARD	2848C	5040-0170

See Introduction to this section for ordering information

Model 5326/27B
 Replaceable Parts

Table 6-2. Replaceable Parts, Options (Cont'd)

Reference Designation	HP Part Number	Qty	Description	Mfr Code	Mfr Part Number
A117	1251-0472		CONNECTOR PCB CONTACTS	717M	1251-0472-100
A118	125C-1163		CONNECTOR PCB INPUT	724C	125C-1163
A119	125G-1163		CONNECTOR PCB INPUT	724C	125G-1163
A181	0400-0199	1	DELAY REED ASSY 1.00 OHM 12VDC	724D	0400-0199
A182	0450-0159		DELAY REED ASSY 1.00 OHM 12VDC	724C	0450-0159
A183	0450-0159		DELAY REED ASSY 1.00 OHM 12VDC	724C	0450-0159
A184	0450-0159		DELAY REED ASSY 1.00 OHM 12VDC	724C	0450-0159
A185	0450-0159		DELAY REED ASSY 1.00 OHM 12VDC	724C	0450-0159
A186	1854-0016	1	TESTER NIB	7C111	1854-0016
A187	1853-0001	1	TESTER INDICATED PCB FROM 261124E	724C	1853-0001
A188	1854-0215	6	TESTER NIB	7C111	1854-0215
A189	1854-0215		TESTER NIB	7C111	1854-0215
A190	1853-0016	4	TESTER NIB	7C111	1853-0016
A191	1853-0016		TESTER NIB	7C111	1853-0016
A192	1854-0215		TESTER NIB	7C111	1854-0215
A193	1854-0215		TESTER NIB	7C111	1854-0215
A194	1853-0016		TESTER NIB	7C111	1853-0016
A195	1853-0016		TESTER NIB	7C111	1853-0016
A196	1854-0215		TESTER NIB	7C111	1854-0215
A197	1854-0215		TESTER NIB	7C111	1854-0215
A198	1853-0016		TESTER NIB	7C111	1853-0016
A199	1853-0016		TESTER NIB	7C111	1853-0016
A200	0250-0121	2	REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A201	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A202	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A203	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A204	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A205	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A206	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A207	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A208	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A209	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A210	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A211	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A212	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A213	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A214	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A215	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A216	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A217	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A218	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A219	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A220	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A221	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A222	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A223	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A224	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A225	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A226	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A227	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A228	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A229	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A230	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A231	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A232	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A233	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A234	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A235	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A236	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A237	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A238	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A239	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A240	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A241	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A242	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A243	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A244	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A245	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A246	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A247	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A248	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A249	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A250	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A251	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121
A252	0250-0121		REED CORE 120 OHM 5E 12VDC	724C	0250-0121

Continued on next page

See introduction to this section for ordering information

Table 6-3. Manufacturer Code List

Mfr. No.	Manufacturer Name	Address	Zip Code
00000	No M/F Description for this Mfg Number		
00000	U.S.A. Common	Any Supplier of U.S.A.	
00770	AMP Inc.	Harrisburg, Pa.	77106
01121	Allen Bradley Co.	Milwaukee, Wis.	53204
01205	Texas Instruments Inc. Semi. Comp. Div.	Dallas, Tex.	75231
02114	Ferroxcube Corp.	Saugerties, N.Y.	12477
02735	RCA Solid State & Receiving Tube Div.	Somerville, N.J.	08876
03508	G.E. Co. Semiconductor Prod. Dept.	Syracuse, N.Y.	13201
04713	Motorola Semiconductor Prod. Inc.	Phoenix, Ariz.	85008
04870	P M Motor Co.	Westchester, Ill.	60156
05820	Wakefield Engineering Inc.	Wakefield, Mass.	01880
07263	Fairchild Camera & Inst. Corp. Semicon. Div.	Mountain View, Calif.	94040
09806	G.E. Co. Miniature Lamp Dept.	Cleveland, Ohio	44112
12040	National Semiconductor Corp.	Danbury, Conn.	06810
12574	Gulton Ind. Inc. Data System Div.	Albuquerque, N.M.	87108
13019	Aircro Supply Co. Inc.	Wichita, Kans.	67213
14655	Cornell Dublier Elect. Div. Federal Pacific Elect. Co.	Newark, N.J.	07105
17856	Biliconix Inc.	Sunnyvale, Calif.	94086
24031	Specialty Connector Co. Inc.	Indianapolis, Ind.	46227
28480	Electro-Pneum. Co. Corporate HQ	Your Nearest HP Office	
56280	Sprague Electric Co.	N. Adams, Mass.	01247
70003	Belden Corp.	Chicago, Ill.	60644
71400	Bussman Mfg. Div. McGraw-Edison Co.	St. Louis, Mo.	63017
71785	Cinch Mfg. Co. Div. TRW Inc.	Elk Grove Village, Ill.	
72136	Electro Motive Mfg. Co. Inc.	Willimantic, Conn.	06226
72082	Eric Technological Prod. Inc.	Erie, Pa.	16512
75915	Littlefuse Inc.	Des Plaines, Ill.	60016
76530	Cinch Monomark Mfgs Div. TRW Inc.	City of Industry, Calif.	91746
78488	Stackpole Carbon Co.	St. Marys, Pa.	15857
80031	Mopco Div. Sessions Check Co.	Morristown, N.J.	07060
80131	Electronic Industries Association	Washington, D.C.	20006
82142	Aircro Speer Elect. Comp.	Du Bois, Pa.	15801
82380	Switchcraft Inc.	Chicago, Ill.	60630
83594	Burroughs Corp. Elect. Comp. Div.	Plainsfield, N.J.	07061
85471	Boyd A.B. Co.	San Francisco, Calif.	94103
91418	Radio Materials Co.	Chicago, Ill.	60646
95712	Bendix Corp. The Microwave Device Div.	Franklin, Ind.	46131
96733	San Fernando Elect. Mfg. Co.	San Fernando, Calif.	91341
98201	Sonlectro Corp.	Mamaroneck, N.Y.	10544
99800	Delevy & Electronics Corp.	E. Aurora, N.Y.	14052

SECTION VII

OPTIONS AND MANUAL CHANGES

7-1. INTRODUCTION

7-2. This section contains information necessary to adapt this manual to older instruments. Also included are installation procedures for available options. Refer to Section II for remote programming requirements.

7-3. OPTIONS

7-4. Options 001 through 004, 010 and 011 are available for the 5326B and 5327B Models. The purpose of each option is described in the following paragraphs.

7-5. Option 001, 8-Digit Display

7-6. Option 001 is the addition of an eighth digit to the display assembly. This addition becomes the most significant digit and extends the counter's resolution at higher frequencies. The digit is always blanked if the reading is "0". Option 001 consists of A9 Display Assembly 05326-60025 in place of 05326-60008.

7-7. Option 002, Remote Programming

7-8. Option 002 allows the counter to be computer controlled from a 36-pin connector on the counter's rear panel. Programming instructions are given in Section II. A schematic diagram is included in Section VII.

7-9. Option 003, Digital Recorder Output

7-10. The data displayed on the counter's front panel can be permanently recorder by connecting a printer to the counter via Option 003. The necessary signals are coupled from A9 Display Assembly to an HP 5055A or 5050B Digital Recorder through J9 on the counter's rear panel (also, see Table 1-1 for specifications and Section VIII for pin references).

7-11. Option 004, Extended Remote Programming

7-12. This option is similar to Option 002 except it includes the remote programming of the AC/DC, SEP-COM-CHK, FAST/NORM, and ATTEN switches. Remote programming of the attenuator board is achieved by connecting the DTL input lines in parallel with the front panel switches (connected at cable points 1 through 8). When the counter is being externally controlled, the A COM line goes high. This high turns off diodes CR6, 18, 2, 3, 15, 30, 31, and 1, and disables the front panel switches.

7-13. Option 010 Temperature Compensated Oscillator

7-14. Option 010 consists of a Temperature Compensated Oscillator (TCXO) (05327-60036) in place of Oscillator Assembly A4 (05326-60002). This option is available for 5326B instruments with Serial Prefix 1240A and above and 5327B instruments with prefix 1224A and above. The TCXO is not field repairable.

7-15. Option 011 Oven Oscillator

7-16. Option 011 consists of an HP Oven Oscillator (10544-60011) in place of Oscillator Assembly A4 (05326-60002). This option is available for 5326B instruments with Serial Prefix 1240A and above and 5327B instruments with prefix 1224A and above. The oven oscillator is not field repairable, for replacement or repair, order rebuilt assembly 10544-60511.

7-17. FIELD INSTALLATION OF OPTIONS

7-18. Installation of Option 001, 8th Digit

7-19. Parts required to install this option are:

1820-0110 Decade Counter U8
1820-0116 Buffer Storage U16
1820-0092 Decoder Driver U24
1970-0042 Display Tube DS8

a. Remove right and left readout boards, A10 and A11.

b. Remove two screws holding display tube shield and remove shield.

c. Remove display board A9 and display support board A8 from the counter by pulling up on the display support board A8. Separate A8 from A9.

d. Install parts on A9 as shown in the component location photo on Figure 8-12 of this manual, and plug in place.

e. Clip out resistor R10. Install blanking jumper as per schematic and Paragraph 2-62.

f. Perform Self-Check in Table 3-1. Especially note that the OF (overflow) lamp lights when the left-most digit changes from 9 to 0.

7-20. Installation of Option 002, Remote Programming

7-21. To install remote programming capability in units not so equipped, order remote cable assembly HP Part No. 05327-60013, two 4-40 x 1/4-inch machine screws, and one 6-32 x 3/4-inch machine screw with hex nut.

a. Remove the plate covering the lower opening in the rear panel for Option 002.

b. The rear-panel interconnect board containing the wiring for the rear-panel BNC's and switches must be removed. To accomplish this, remove the nuts holding the rear-panel BNC's.

c. Remove two screws holding P1A, and 1 1/2-inch-long, black, pressure connector to the motherboard A16.

d. Remove side covers and six screws holding rear panel. Loosen one side frame. Pull rear panel away from the instrument.

e. Remove the rear-panel interconnect board from the instrument and separate it from P1A by removing two screws.

f. Feed the pressure connector through the hole in rear-panel and mount rear-panel connector J10, with screws removed earlier. Position J10 with pin 1 near the side frame.

g. Assemble the rear-panel interconnect board and the new 5-inch-long pressure connector P1 with three 6-32 x 3/4-inch screws and hex nuts. Be certain that proper contact is made between interconnect board and P1.

h. Attach P1 to the motherboard using four 4-40 x 1/4-inch screws. Do not tighten screws. Route cables as shown in the top internal photo of instrument, Figure 8-4.

CAUTION

SCREWS LONGER THAN 1/4-INCH WILL DAMAGE P1.

i. Gently reinstall rear panel. Install BNC lock nuts so that the board is still moveable.

j. Observe the alignment of the connector in the motherboard. Tighten the four screws holding P1 to the motherboard, making sure to maintain proper contact.

k. Check contact alignment of P1 with motherboard and with the rear-panel interconnect board. If necessary, loosen the screws in P1 and shift slightly to obtain proper terminal contact.

l. Tighten BNC lock nuts and reassemble instrument.

m. Run a complete performance check on the unit to verify that remote programming is working properly.

7-22. Installation of Option 003, Digital Recorder Output

7-23. Order digital recorder cable assembly HP Part Number 05326-60012.

a. Remove the plate covering the upper opening in the rear panel.

b. Remove right and left readout boards A10 and A11. Remove two screws holding the display tube shield and remove shield. Remove display support board A8 and the display board A9 by pulling up on A8.

c. Feed the two connectors of the recorder cable through the rear panel and mount J9 on the rear panel, using the screws previously removed. Position J9 so pin 1 is near the side frame.

d. Slide the connectors on the A9 Board. The connector with the long wires attaches to J1 and is positioned so that pin 1 is toward the front of the instrument. The other connector attaches to J2, and pin 1 is toward the rear of the instrument.

e. Position the P1 cable so it passes between A8 and A11, completely clearing A8. Reinstall A8 and A9.

f. Route the cable around T1 and in front of A8 assembly.

g. Reassemble unit and run a proof-of-performance check of the digital output to verify that the option is installed properly.

7-24. Installation of Option 004, Extended Remote Programming

7-25. Field installation of Option 004 is not available.

7-26. Installation of Option 010 and 011, Oscillator Assemblies

7-27. Remove the standard oscillator A4 and insert the option into the XA4 connector. The Option 011 assembly must be mounted to the interconnect board with two 6 x 32, 1/4-inch screws. Place the fiber washers on the underside of the board.

7-20. MANUAL CHANGES

7-29. This manual applies directly to Models 5326B and 5327B that have serial prefixes 1428A (see Paragraph 1-4).

7-30. NEWER INSTRUMENTS

7-31. As changes are made, newer instruments may have serial prefixes that are not listed in this manual. The manual for these instruments are supplied with a manual change sheet, containing the required information. If this sheet is missing, contact the nearest Hewlett-Packard Sales and Service Office for information.

7-32. Older Instruments

7-33. To adapt this manual to instruments having a serial prefix prior to 1428A, perform the backdating that applies to your instrument serial prefix as listed in Table 7-1 below.

NOTE

For 5326B's with serial prefixes earlier than 1128A, a separate manual is required. Order "Model 5326A/B 50 MHz Timer/Counter/DVM Operating and Service Manual," HP Part Number 05326-00030.

Table 7-1. Manual Backdating Changes

5326B	5327B	Change
1312A	1312A	12
1240A	1248A	1,12
.....	1224A	1,2,12
1224A	1,3,5,12
.....	1220A	1,2,3,4,12
1208A	1,3,4,5,12
.....	1140A	1,2,3,4,5,12
.....	1132A	1,2,3,4,5,6,8,12
1140A	1,3,4,5,8,12
1136A	1,3,4,5,8,9,12
1128A	1,3,4,5,7,8,9,10,12
See	1116A	1,2,3,4,5,6,8,9,10,12
Above	1104A	1,2,3,4,5,6,8,9,10,11,12

CHANGE 1

Page 6-9, Table 6-1:
Change A9R2, R4-9 and R11 to "0683-7525"
Change board series number to 1224A.

Page 6-14, Table 6-1:
Change A15R1 to "0683-2035, R:FXD COMP
20K OHM 5% 1/4W 01121 CB 2035."

Change A15R6 to "0686-1505 R:FXD COMP
15 OHM 5% 1/4W 01121 EB 1505."

Delete "A15F1 2110-460 FUSE: 1.32 AMP."

Delete "A15XF1 1400-0110 FUSE HOLDER."

Page 8-45, Figure 8-18:

Change A15 R1 to "20K."

Change A15 R6 to "15 OHM."

Delete F1. Q8 emitter connects directly to XA15 (1.A).

Change board series number to 1224A.

CHANGE 2

Page 1-2, Table 1-3:

Under INPUT CHANNEL, C RANGE:
change to "1 kHz - 50 MHz, ac coupled."
Change sensitivity to direct "5 mV rms pre-
scaled 100 mV rms."

Page 6-16, Table 6-1:

Replace parts listing for A18 (05327-60033)
with Table 7-2 (parts list for 05327-60009) and
Table 7-3 (parts list for 05327-60029). Instru-
ments with series prefix 1224 and below could
have either the 05327-60009 or 05327-60029
boards installed.

Page 8-48, Figure 8-20:

Replace A18 schematic diagram with Figure
7-1 (05327-60009) and Figure 7-2 (05327-
60029). Instruments with serial prefix 1224
and below could have either board installed.
Replace A18 component locator with Figure 7-3
(05327-60009) and Figure 7-4 (05327-60029).

Page 6-18, Table 6-1:

Add "A19 05327-60032 Protection Board."
Add "A19 05327-20032 Blank Board."
Add "A19C1,2 0180-0228 C:FXD TANT 22 UF
10% 15 V."
Add "A19CR1,2 1901-0050 DIODE:
SILICON."
Add "A19F1 2110-0436 FUSE: 0.1 AMP."
Add "19J1 1250-1408 CONNECTOR:RF
SUBMINIATURE."
Add "A19J1 1250-1835 CONNECTOR:RF
SUBMINIATURE."
Add "A19XF1A/B 1251-3205 SOCKET:
MINIATURE (2)."

CHANGE 3

Page 1-1, Paragraph 1-9:

Pages 7-1 and 7-2, Paragraphs 7-13 through
7-15, 7-26, and 7-27: Delete reference to
Options 010 and 011 oscillators. Options 010
and 011 were available for 5326B instru-
ments with Serial Prefix 1240A and above
and for 5327B with Serial Prefix 1224A and
above.

Page 6-6, Table 6-1:
Delete A6R41. Change board series to 1132A.

Page 8-24, Figure 8-9:
On schematic, delete A6R44. A6C10 connects directly to A6C2.

Page 6-9, Table 6-1:
Change A9 series number to 1224A.
Delete A9R11, A9R12, A9XDS8, A9XU8, 16 and 24.

Page 8-33, Figure 8-12:
Change Note 3 to read R10 is wired to B for Option 001.

Page 6-15, Table 6-1:
Delete A16C3, A16CR18, A16Q3, A16R4, A16R5, A16R6, A16R7, A16R8, and A16U1.

Page 8-57, Figure 8-25:
Delete schematic diagram and component locator.

Page 6-7, Table 6-1:
Delete parts list for A7 (05327-60001) and replace with Table 7-4 (parts list for A7, 05327-60004).

Page 8-29, Figure 8-10:
Replace A7 schematic with Figure 7-5 (schematic for A7 05327-60004). Replace component locator with Figure 7-6.

CHANGE 4

Page 6-3, Table 6-1:
Change A1 part number to 05326-60003.
Change A1R24 and R26 to 2100-2905.

Page 6-19, Table 6-1:
Change 05326-00032 Rear Panel to 05326-00004.
Add 05326-00012 Plate:Connector, Short (J10 Cover).
Add 05326-20028 Board:Blank (Rear Panel Interconnect).
Delete 05326-00033 Adapter:Connector.
Delete 05326-20046 Board, Rear Panel Connector.

CHANGE 5

Page 6-18, Table 6-1:
Delete A19 and all A19 listed parts.

Pages 7-7 and 7-8, Figures 7-1 and 7-2:
Delete A19 protection board from Schematic diagrams.

Page 1-2, Table 1-3:
Under INPUT CHANNEL, C Maximum Input, change to "5 Volt-rms; 7.5 volts peak."

CHANGE 6

Some instruments with serial prefix 1208 and below have standard colors of light gray panels with blue textured cabinet. For replacement, order Option X95 parts listed in Section VI.

CHANGE 7

Pages 6-15 and 6-16, Table 6-1:
Change A17CR3 to "1912-0007."
Change A17Q4 to "1854-0092."
Change "A17R21 to 0683-3625 R:FXD COMP 3600 OHM 5% 1/4W 01121 CB 3625."
Change A17R22 to "0683-1515 R:FXD COMP 150 OHM 5% 1/4W 01121 CB 1515."
Change A17R23 to "0683-1026 R:FXD 1000 OHM 5% 1/4W 01121 CB 1026."
Change A17R26 to "0683-5615 R:FXD COMP 560 OHM 5% 1/4W 01121 CB 5615."
Delete "05326-00031 SHIELD: NOISE."
Change board series to "1128A."

Page 8-47, Figure 8-19:
Change A17R21 to "3600 OHMS."
Change A17R26 to "560 OHMS."
Change A17CR3 to "1912-0007."
Change A17Q4 to "1854-0092."
Change board series to "1128."

CHANGE 8

Page 6-14, Table 6-1:
Delete A15C8 and description.
Change board series to "1132A."

Page 8-45, Figure 8-18:
Delete A15C8.

CHANGE 9

Page 6-18, Table 6-1:
Change T1 part number to 9100-2888.

Page 6-14, Table 6-1:
Change A15CR15-18 to "1901-0040."
Change A15R17, 18 to "0683-0395 R:FXD 3.9 OHM 5% 1/4W 01121 CB 3995."
Change Board series numbers to "1040A."

Page 8-45, Figure 8-18:
Change A15R17, 18 to 3.9 OHM.
Change A15CR15-18 to "1901-0040."
Change Board series to "1040A."

Page 7-11, Table 7-4:
Change A7C2 to "0160-0333 C:FXD MICA 15 PF 5% 500 VDCW 00853 RDM15C15013C."
Change A7 Board Series to 1040A.

Page 8-20, Figure 8-10:
Change A7C2 to 15 PF.

Page 6-7, Table 6-1:
Change A6R19 to "0685-2025 R: FXD
COMP 2000 OHM 5% 1/4W 01121 CB 2025."
Change A6 Board Series Number to 1036A.

CHANGE 10

Page 6-14, Table 6-1:
Change part number of A16 Board Assembly
Connector to read 05327-60006, Series Number
1104A. Change 05327-20027 blank board to
05327-20006.

Page 8-45, Figure 8-18, A16 schematic:
Change A16 part number from 05327-60027
to 05327-60006.

CHANGE 11

Table 6-1:
Change part numbers to read:

COVER-SIDE 3x11	5000-0729, 2 ea.
COVER-TOP	05325-00008, 1 ea.
INSULATOR (Q1&Q2)	0340-0162, 1 ea.

NOTE

If replacement of any of the above
parts is required, replace with new
parts listed in Table 6-1.

CHANGE 12

Page 6-14, Table 6-1:
Change A15F1 from 2110-0487 (1/20 A) to
2110-0460 (1/32 A).
Change A15R6 from 0698-5470 (8.2 OHM)
to 0686-1305 (13 OHM); MFR PART NO.
EB 82G5 to EB 1305.
Change A15XF1 from 1251-3205 Qty 2 to
1400-0110 Qty 1; Change description from
SOCKET, MINIATURE, SINGLE to
BODY: FUSEHOLDER; Change MFR
CODE from 00779 to 71400; Change MFR
PART NO. from 2-331272-7 to "P/O HWA
FUSEHOLDER."
Change A15 board series from 1428A to
1312A.

Page 8-45, Figure 8-18, A15 Schematic
Diagram:
Change A15F1 value from 1/20A to 1/32A.
Change A15R6 value from 8.2 ohm to 13 ohm.
Change board series from 1428A to 1312A.

Model 5326/27B
Options and Manual Changes

Table 7-2. A18 (05327-60009) Replaceable Parts

Reference Designation	HP Part Number	Qty	Description	Mfr Code	Mfr Part Number
A18	05327-60009	1	PRE-CALIBRATED 1514015 104901 (EQUIVALENT ON 05327-20009 PLANS 004901)	28600	05327-60009
A18C1	1050-0062 0160-0197	2	WASH REFLAT, DAMPEN CERD ELECT 2.2 UF 10% 20VDCW	01000 56785	0100 150025950704-007
A18C2	0160-0975		CERD CER 0.001 UF 20% 25VDCW	12574	5584-001-98
A18C3	0160-0106		CERD ELECT 60 UF 20% 50VDCW	28600	0160-0106
A18C4	0160-0575		CERD CER 0.001 UF 20% 25VDCW	12574	5584-001-98
A18C5	0160-0106		CERD ELECT 60 UF 20% 50VDCW	28600	0160-0106
A18C7	0160-0575		CERD CER 0.001 UF 20% 25VDCW	12574	5584-001-98
A18C8	0160-0275	2	CERD NICA 100 PF 1R	28600	0160-0275
A18C9	0160-0975		CERD CER 0.001 UF 20% 25VDCW	12574	5584-001-98
A18C10	0160-0575		CERD CER 0.001 UF 20% 25VDCW	12574	5584-001-98
A18C11	0160-0197		CERD ELECT 2.2 UF 10% 20VDCW	56785	150025950704-007
A18C12	0160-0197		CERD ELECT 2.2 UF 10% 20VDCW	56785	150025950704-007
A18C13	0160-2069	6	CERD CER 1000-THRU 5000 PF +50-20% CERD CER 1000-THRU 5000 PF +50-20%	28600 28600	0160-2069 0160-2069
A18C14	0160-2069		DIODE BIPOLAR 1N4148 10V 5% DIODE BIPOLAR 1N4148 10V 5%	28600 03500	1902-1002 1N4148 5P10
A18C15	1902-1002 1912-0007 1902-1068	2	DIODE BIPOLAR 1N4148 10V 5% DIODE BIPOLAR 1N4148 10V 5%	28600	1902-1068
A18J1	1250-0836		CONNECTOR 50P-MINIATURE	56781	50-053-0000
A18J2	9100-2251	2	COIL FERRO 0.22 OHM 10%	28600	9100-2251
A18J3	1854-0015		RESISTOR 10K	80131	28600
A18J4	1854-0092		RESISTOR 10K	80131	28600
A18J5	1854-0092		RESISTOR 10K	80131	28600
A18K1	2100-2633		RYVAR CERMET 1K OHM 10% 1/2W	28600	2100-2633
A18K2	2100-2633		RYVAR FILM 2000 OHM 10% 1/2W	28600	2100-2633
A18K3	0683-1015		REFR COMP 51 OHM 5% 1/4W	01121	CR 1025
A18K4	0683-1015		REFR COMP 51 OHM 5% 1/4W	01121	CR 1025
A18K5	0683-1065		REFR COMP 100K OHM 5% 1/4W	01121	CR 1065
A18K6	0683-1025		REFR COMP 1000 OHM 5% 1/4W	01121	CR 1025
A18K7	0683-1075		REFR CARBON 51 OHM 5% 1/4W	28600	0683-1075
A18K8	0683-1815		REFR COMP 100 OHM 5% 1/4W	01121	CR 1815
A18K9	0683-1825		REFR COMP 1000 OHM 5% 1/4W	01121	CR 1825
A18K10	0683-2215		REFR COMP 220 OHM 5% 1/4W	01121	CR 2215
A18K11	0683-1825		REFR COMP 1000 OHM 5% 1/4W	01121	CR 1825
A18K12	0683-1825		REFR COMP 1000 OHM 5% 1/4W	01121	CR 1825
A18K13	0683-1825		REFR COMP 1000 OHM 5% 1/4W	01121	CR 1825
A18K14	0683-2015		REFR COMP 200 OHM 5% 1/4W	01121	CR 2015
A18K15	0683-2015		REFR COMP 200 OHM 5% 1/4W	01121	CR 2015
A18K16	0683-1025		REFR COMP 1000 OHM 5% 1/4W	01121	CR 1025
A18K17	0683-1515	2	REFR COMP 150 OHM 5% 1/4W	01121	CR 1515
A18K18	0683-4315		REFR COMP 430 OHM 5% 1/4W	01121	CR 4315
A18K19	0683-3315		REFR COMP 330 OHM 5% 1/4W	01121	CR 3315
A18K20	0683-8205	2	REFR COMP 82 OHM 5% 1/4W	01121	CR 8205
A18K21	0683-1015		REFR COMP 51 OHM 5% 1/4W	01121	CR 1015
A18K22	0683-2025		REFR COMP 2000 OHM 5% 1/4W	01121	CR 2025
A18K23	0683-1315		REFR COMP 130 OHM 5% 1/4W	01121	CR 1315
A18K24	0683-2405		REFR COMP 24 OHM 5% 1/4W	01121	CR 2405
A18J1	5088-7002		IC LIMITER	28600	5088-7002
A18Q7	5088-7001		IC AMP AND TRIG	28600	5088-7001
A18Q3	1820-0736		IC DIGITAL	28600	1820-0736
A18Q4	1820-0736	1	IC DIGITAL QUINARY DIVIDER	28600	1820-0736
A18Q5	1820-0489		IC FET	28600	1820-0489
A18Q6	1820-0167		IC FET TRIPLE 3-INPUT NOR GATE	04714	IC1007P
A18Q7	1858-0004		5STR ARRAYS 1 NPN DUAL DIFF. AMPL.	28600	1858-0004
A18K02	1251-1556	45	CONNECTOR SINGLE CONTACT	00779	2-110608-8

See introduction to this section for ordering information

Figure 7-1. A18 Prescaler Board Assembly (53278 Only)




Figure 7-2. A18 Prescaler Board Assembly (5327B Only)




Figure 7-3. A18 (05327-60009) Component Locator





Figure 7-4. A18 (U5327-60029) Component Locator



Model 5326/27B
Options and Manual Changes

Table 7-4. A7 (05327-60004) Replaceable Parts

Reference Designation	HP Part Number	Qty	Description	Mfr Code	Mfr Part Number
A7	05327-60004	1	BOARD ASSY(FUNCTION CONTROL (SERIES 1040A; REV. C) (LOADED ON 05327-70004 BLANK BOARD)	28480	05327-60004
ATC1			NOT ASSIGNED		
ATC2	0160-0333	1	CIFRD MICA 15+/-0.5 PF 30V1K'W	00853	ADM15C15003C
ATC3	0160-2327	5	CIFRD CER 1000 PF 20% .00VDCW	96733	B1048X102M
ATCA	0160-2327		CIFRD CER 1000 PF 20% 100VDCW	96733	B1048X102M
ATCB	0160-2327		CIFRD CER 1000 PF 20% 100VDCW	96733	B1048X102M
ATCC	0160-2327		CIFRD CER 1000 PF 20% 100VDCW	96733	B1048X102M
ATCD	0160-2327		CIFRD CER 1000 PF 20% 100VDCW	96733	B1048X102M
ATCE	1854-0215		TSTR151 NPN	80131	2M1404
ATF1	1854-0215		TSTR151 NPN	80131	2M1904
ATG1	1854-0009		TSTR151 NPN	80131	2M709
ATG2	1854-0009		TSTR151 NPN	80131	2M709
ATG3	1854-0009		TSTR151 NPN	80131	2M709
ATG4	1854-0009		TSTR151 NPN	80131	2M709
ATG5	1854-0009		TSTR151 NPN	80131	2M709
ATG6	0683-1125	7	RIFRD COMP 1100 OHM 5% 1/4W	01121	CB 1125
ATG7	0683-1825	10	RIFRD COMP 1800 OHM 5% 1/4W	01121	CB 1825
ATG8	0683-1825		RIFRD COMP 1800 OHM 5% 1/4W	01121	CB 1825
ATG9	0683-1525		RIFRD COMP 1500 OHM 5% 1/4W	01121	CB 1525
ATG10	0683-3925	4	RIFRD COMP 3900 OHM 5% 1/4W	01121	CB 3925
ATG11	0683-2225		RIFRD COMP 2.2K OHM 5% 1/4W	01121	CB 2225
ATG12	0683-1125		RIFRD COMP 1100 OHM 5% 1/4W	01121	CB 1125
ATG13	0683-2225		RIFRD COMP 2.2K OHM 5% 1/4W	01121	CB 2225
ATG14	0683-3325		RIFRD COMP 3300 OHM 5% 1/4W	01121	CB 3325
ATG15	0683-3325		RIFRD COMP 3300 OHM 5% 1/4W	01121	CB 3325
ATG16	0683-1525		RIFRD COMP 1500 OHM 5% 1/4W	01121	CB 1525
ATG17	0683-3325		RIFRD COMP 3300 OHM 5% 1/4W	01121	CB 3325
ATG18	0683-1525		RIFRD COMP 1500 OHM 5% 1/4W	01121	CB 1525
ATG19	0683-1525		RIFRD COMP 1500 OHM 5% 1/4W	01121	CB 1525
ATG20	0683-1015		RIFRD COMP 100 OHM 5% 1/4W	01121	CB 1015
ATG21	0683-5115	4	RIFRD COMP 510 OHM 5% 1/4W	01121	CB 5115
ATG22	0683-3015		RIFRD COMP 300 OHM 5% 1/4W	01121	CB 3015
ATG23	0683-3015		RIFRD COMP 300 OHM 5% 1/4W	01121	CB 3015
ATG24	0683-2015	5	RIFRD COMP 200 OHM 5% 1/4W	01121	CB 2015
ATG25	0683-2725	3	RIFRD COMP 2700 OHM 5% 1/4W	01121	CB 2725
ATG26	0683-7515	3	RIFRD COMP 750 OHM 5% 1/4W	01121	CB 7515
ATG27	0683-4715		RIFRD COMP 470 OHM 5% 1/4W	01121	CB 4715
ATG28	0683-1125		RIFRD COMP 1100 OHM 5% 1/4W	01121	CB 1125
ATG29	0683-4725		RIFRD COMP 4.7K OHM 5% 1/4W	01121	CB 4725
ATG30	0683-1125		RIFRD COMP 1100 OHM 5% 1/4W	01121	CB 1125
ATG31	0683-1125		RIFRD COMP 1100 OHM 5% 1/4W	01121	CB 1125
ATG32	0683-4715		RIFRD COMP 470 OHM 5% 1/4W	01121	CB 4715
ATG33	0683-1015		RIFRD COMP 100 OHM 5% 1/4W	01121	CB 1015
ATG34	0683-1125		RIFRD COMP 1100 OHM 5% 1/4W	01121	CB 1125
ATU1	1820-0102	4	INTEGRATED CIRCUIT(J-K FLIP FLOP	04713	MC1011P
ATU2	1820-0489	5	IC1ECL	28480	1820-0489
ATU3	1820-0147		IC1ECL TRIPLE 3-INPT NOR GATE	04713	MC1007P
ATU4	1820-0440	1	IC1ECL DUAL 1S F/F	04713	MC101CP
ATU5	1820-0147		IC1ECL TRIPLE 3-INPT NOR GATE	04713	MC1007P
ATU6	1820-0469		IC1ECL	28480	1820-0469
ATU7	1820-0212	2	IC1ECL QUAD LINE RECEIVER	04713	MC1020P
ATU8	1820-0489		IC1ECL	28480	1820-0489
ATU9	1820-0145	2	IC1DIGIT1. QUAD 2-INPT NOR GATE	28480	1820-0145
ATU10	1820-0489		IC1ECL	28480	1820-0489
ATU11	1820-0252	1	IC1ECL DUAL 3-4 INPT OR/NOR GATE	04713	MC1026P
ATU12	1820-0200	1	IC1ECL QUAD EXCL. OR GATE	04713	MC 1030P

See Introduction to this section for ordering information

Figure 7-5. A7 Function Control Assembly





Figure 7-6. A7 (05327-60004) Component Locator



SECTION VIII

SCHEMATIC DIAGRAMS

8-1. GENERAL

8-2. This section contains the following:

- a. Schematic diagram notes.
- b. Schematics.
- c. Component locators.
- d. IC outline drawings.
- e. Waveforms.
- f. Simplified block diagrams.
- g. Theory of operation.
- h. Troubleshooting.

Figure B-1. Schematic Diagram Notes




Figure B-2. Integrated Circuit Diagrams




Figure 8-2. Integrated Circuit Diagrams (Continued)




Figure B-2. Integrated Circuit Diagrams (Continued)




Figure 8-2. Integrated Circuit Diagrams (Continued)




Figure 6-2. Integrated Circuit Diagrams (Continued)




Figure 8-2. Integrated Circuit Diagrams (Continued)




Figure 8-2. Integrated Circuit Diagrams (Continued)




Figure 0-3. Model 5327B Front and Rear Panels






Figure B-4. Model 5327B Top Internal View



A1 ATTENUATOR OPERATION

Attenuator Assembly A1 consists of two input attenuator channels. Since the channels are identical, only Channel A will be described. Channel A input signals are routed through J3 to the attenuator network. When ATTEN switch S2 is set to X1, the full input signal is fed to the gate of Q1A. With the ATTEN switch in X10, R2, R5, C1, and C3 serve as a 10:1 voltage divider. In the X100 position, the 100:1 divider consists of R2, R4, C1, and C2. R3 provides damping.



When AC/DC switch S4 is set to AC, C4 is in series with the signal path. CR3 and CR4 limit the input amplitude to Q1A to approximately 15.8 volts. R7 and R8 provide current limiting. C5 compensates Q1A input capacitance.

Q1A and Q1B form a differential amplifier connected as source followers. The outputs are fed to A2 via pins 5 and 6 of J1. LEVEL potentiometer R24 determines the trigger level on Q1B gate. The trigger level can be preset to zero volts or varied from -3 to +3 volts; or with the LEVEL control set to PRESET, an external trigger level can be applied at J10 to AJ1(D) for remote programming. Diodes CR6 and CR7 develop 5 volts for the input protection and level pots. R12 adds symmetry to the voltage range of R24. R11 lowers the impedance of Q1B gate circuit to limit stray charges and false triggering. R10 and C8 form a filter to prevent noise from triggering the differential amplifier.

When SLOPE switch S5 is set to -, a ground is supplied via CR2 to J1 pin A. This sets amplifier trigger A2 to trigger on the negative slope of the input signal. When remote programming is used, J1(C) is held high to disable the SLOPE switches and the CHK switch.

COM-SEP/CHK switch S1 connects inputs A and B in parallel when set to COM and grounds J2(C) via CR1 for the check mode.

A1 contains trigger lights DS1 and DS2 and current limiters R1 and R2. CR1, CR2, and CR9 eliminate interaction of the remote programming signals.



- NOTES**
- REFERENCE DESIGNATIONS WITHIN THIS ASSEMBLY ARE ABBREVIATED. ADD ASSEMBLY NUMBER TO ABBREVIATION FOR COMPLETE DESCRIPTION.
 - UNLESS OTHERWISE INDICATED: RESISTANCE IN OHMS, CAPACITANCE IN PICOFARADS.

REFERENCE DESIGNATIONS

A1
C1-17
CR1-4,6,7
9-11,13,14
DS1,2
J1-4
Q1,2
R1-34
S1-9

TABLE OF ACTIVE COMPONENTS

REFERENCE DESIGNATIONS	HP PART NUMBERS
CR1,2,9	1910-0016
CR3,4,10,11	1901-0376
CR6,7,13,14	1902-0041
Q1,2	1655-0334

COMPLETE PARTS LIST FOR THIS ASSEMBLY IS LOCATED ON PAGE 63

Figure 8-5. A1 Attenuator Assembly
8-13

A2, A3 AMPLIFIER/TRIGGER OPERATION

Two input amplifier assemblies are provided: A2 for Channel A and A3 for Channel B. Since the assemblies are identical, only one will be described. The input signal and the trigger level are received from A1 via P2(5) and P2(6) respectively. Potentiometer R2 is adjusted to cancel out offset voltages due to imbalances in the circuit.

The differential amplifier (Q1 and Q8) serves to clip a small window out of the input signal waveform. The outputs of Q1 and Q8 drive another differential amplifier Q2 and Q6. Q2 and Q6 inject a current drive input to differential Schmitt trigger Q3, Q4, Q5, and Q7.

Q3 and Q7 are common base amplifiers, which present a low input impedance and high output impedance to Q4 and Q5. This arrangement allows for greater high-speed operation of Q4 and Q5. C2 and R15 reduce the hysteresis of the Schmitt trigger to give greater reliability at the high frequencies. Two out-of-phase signals from this circuit are routed to Q9 and Q10. The output levels shift from approximately +0.8 to +0.5 volts.

The SLOPE switch on A1 drives U1D(11) low for a +slope selection and U1A(3) low for a -slope selection. This allows either the in-phase signal or the out-of-phase signal to be switched to Q13 via Q10 and Q12 for +slope or via Q9 and Q11 for -slope.

The differentiator circuit consists of Q13 and feedback network L8 and R32. The circuit develops 10 ns pulses at the collector of Q13. CR3 and CR4 bias Q13 so that the collector circuit is compatible with ECL output driver U2B.

U2A(6) drives trigger-lamp driver Q16, Q17, Q18, Q19, and Q20. The circuit consists of RS FF Q16-Q17 and one-shot Q19-Q20. When U2A(6) is low, Q16 turns off and Q17 turns on. With Q17 on, Q18 cuts off to drive P1(1) high, which will light the trigger lamp DS1 on A1. As C8 charges, Q20 base goes positive. When Q20 base is approximately ground potential, the one-shot fires to turn off Q19 and Q17.

The marker circuit, Q15 and Q14, is a pulse stretcher that provides a low marker output at P1(12, N). When the input amplifier circuits trigger, U2B(8) provides a positive spike to Q14 base to drive Q14 collector below ground and allow CR5 to conduct. This makes the charge on C6 more positive. When U2B(8) returns to logical zero (approximately -1.6 V), Q14 is back biased and turns off, allowing Q15 to turn on to drive the marker output line low. After C6 has discharged through R36, Q14 turns on again, Q15 turns off, and the marker output line returns to the high state.

During the check mode, A1P1(C) is held high to disable U2B and enable U2A. With U2B disabled, the marker pulses are inhibited. With U2A enabled, the 10 MHz check signal at P1(4,D) connects to the amplifier output line P1(5,E).

A2 TROUBLESHOOTING

When tracing the signal through the amplifier assembly, a good starting point is the collector of Q1, test point 4. With a sine wave input and the LEVEL control set to zero, this waveform should always resemble a square wave, due to the action of the Schmitt Trigger. A second check would be test point 6. If no signal is available there, check the slope gates of U1 and transistors Q9-Q12. Make use of the waveforms that are provided on this page. Once the problem is confined to a general area, use dc voltage checks to pinpoint the trouble.

Model 5326 27B
Schematic Diagrams

Part of Figure 8-6. Input Amplifier Assembly




Figure 8-5
A1 ATTENUATOR ASSEMBLY
(See Page 8-13)

MORE DATA UNDER FOLD

A2 (A3) INPUT AMPLIFIER ASSEMBLY 100374-000C41 (NOTE 1) SERIES 972





Figure 8-6. A2, A3 Amplifier/Trigger Assembly

A4 OSCILLATOR OPERATION

The 10 MHz oscillator assembly consists of oscillator U1A, buffer U1B, and level shifter Q1. U1A operates like an amplifier with positive feedback. The positive feedback path is from the noninverted output of U1A(6) through 10 MHz crystal Y1, trimmer capacitor C3, and C4 to U1A(4). Negative feedback is used to establish the input bias for U1A. The negative feedback path consists of R1 and R2. The inverted output of U1A(5) connects to buffer U1B(10). The buffer provides isolation between the oscillator and the output. The outputs of U1B(8) and (9) switch from approximately 3.5 to 4.25 volts. When one output is 3.5 volts, the other output is 4.25 volts. Level shifter Q1 converts the output of U1B to an approximate square wave of 0 to +4 volts.

Model 5326/27B
Schematic Diagrams

Part of Figure 8-7. A4 Oscillator Assembly





Figure 8-6
A2, A3 AMPLIFIER/TRIGGER ASSEMBLY
(See Page 8-15)



NOTES

- 1 REFERENCE DESIGNATIONS WITHIN THIS ASSEMBLY ARE ABBREVIATED ADD ASSEMBLY NUMBER TO ABBREVIATION FOR COMPLETE DESCRIPTION.
- 2 UNLESS OTHERWISE INDICATED: RESISTANCE IN OHMS, CAPACITANCE IN PICOFARADS, INDUCTANCE IN MICROHENRIES
- 3 ASTERISK (*) INDICATES SELECTED COMPONENT, AVERAGE VALUES SHOWN

REFERENCE DESIGNATIONS

A4
C1-5
L1
Q1
R1-4
U1
Y1

TABLE OF ACTIVE COMPONENTS

REFERENCE DESIGNATIONS	HP PART NUMBERS
Q1	1650-0158 2N2635
U1	1820-0142
Y1	0410-0405

Figure 8-7. A4 Oscillator Assembly

Part of Figure 8-8. Time Base Control Assembly

A5 TIME BASE OPERATION

This assembly contains 8 decade dividers, which are controlled by TIME BASE switch S5. The input signal is 10 MHz for the frequency mode. For the totalize and period-average modes, the decade dividers receive INPUT A signals.

When a particular decade receives a gate-enable signal the corresponding gated output line is enabled. For example, if S5 is set to .1 second U1(6) is grounded. This gates the divided signal out on U1(5). The gated outputs are connected together on a common line to C5. C5 differentiates the high to low transitions into approximately 100 ns pulses at U5C(8). When S5 is set to .1 μ s, the input signal bypasses the decade dividers and passes through U10D and U5D. The output of U5C feeds through U10C to A7 and also through U10E to the rear-panel TIME BASE OUTPUT jack J6.

Q1 and Q2 form an ECL to TTL translator. When the main gate opens (low is main-gate enable), Q2 turns on the start one-shot Q3/Q4. During short gate-length times, this holds the gate lamp enable line low for approximately 50 ms to extend the time the gate lamp is on. When Q1 collector goes high, a low is developed


at U10F(12) and routed to the GATE OUT jack J5.

U5A and U5B select either the internal or external oscillator signal. When S7 is set to EXT, the internal oscillator signal is inhibited and the external oscillator signal passes through Schmitt trigger Q5 and Q6 to U5B and XA5(13).


A5 TROUBLESHOOTING

When troubleshooting the Time Base Dividers, place the FUNCTION switch to START and CHK SEP COM to CHK. Step the TIME BASE switch through each position and note the counter's display. When the counter stops totalizing, check for a low on pin 6 of the selected decade. If the counter does not totalize for any position of the TIME BASE switch, the problem is in the circuitry of U10B, U10C, or U5C. Before the gated output is sent to the A7 Function Selector, it is differentiated by C5 and R18. This produces extremely sharp pulses, which are best observed when the gate time is 0.1 μ s (TIME BASE switch).

To check the operation of the Gate Lamp one-shot, check for waveform 5 and 6 with SAMPLE RATE switch to NORM. The Collector of Q3 should be Low for about 50 ms regardless of the gate time.





A5 TIME BASE CONTROL ASSEMBLY (05326-6000) (NOTE 1) SERIES 972 REV A



NOTES

- REFERENCE DESIGNATIONS WITHIN THIS ASSEMBLY ARE ABBREVIATED. ADD ASSEMBLY NUMBER TO ABBREVIATION FOR COMPLETE DESCRIPTION.
- UNLESS OTHERWISE INDICATED, RESISTANCE IN OHMS, CAPACITANCE IN PICOFARADS.
- WHEN CHANGING POSITIONS OF 55, RESET SIGNAL IS GENERATED IN HALF POSITIONS OF 55AF.
- ASTERISK (*) INDICATES SELECTED COMPONENT AVERAGE VALUE SHOWN.

REFERENCE DESIGNATIONS			TABLE OF ACTIVE COMPONENTS	
NO PREFIX	AS	A16	REFERENCE DESIGNATIONS	HP PART NUMBERS
			CR1	1901-0040
			Q1,2	1854-0092
				2N3563
J4-6	C1-5		Q3-5	1854-0071
PI	CR1		U1-4,6-B	1820-0412/0413
		J1	U5	1820-0054
	Q1-6			5N7400N
	R11-21		U7	1820-0413
55,7	11-10		U10	1820-0174
				5N7404N



COUNTER CONTROLS:
(except as noted)
Use settings of A2 Assembly
DC VOLTAGES:
Set counter controls as stated.
Disconnect input signal. Push RESET.

All waveforms taken with 10:1 divider probe; ground lead is connected to ground side of C1. A5 is mounted on extender board.

OSCILLOSCOPE CONTROLS:
(except as noted)
Use settings of A2 Assembly

Figure 8-8. A5 Time Base Control Assembly

A6 SAMPLE RATE OPERATION

The sample-rate circuits determine interrogation rates for the input signal and provide several functions for the various operating modes. These functions include generating reset, transfer, print command, and main-gate inhibit signals. In addition, the circuits receive computer inhibit, printer inhibit, and manual reset signals. The circuits also serve to control storage and display-hold functions.

As an example of operation, assume the following operating conditions: STORAGE to ON, SAMPLE RATE to FAST, no printer inhibit, no computer inhibit, no manual reset, and main gate open. At the end of the gate time, Pin 17 goes high, which sets inhibit flip-flop U2. This sends a signal to U6C to generate a high inhibit at U6B(9). In addition, a low is generated at Q4 collector to trigger the sample rate one-shot if no printer inhibit is present at U5B(6). The display time starts at this point, and the high at U5C(10) generates a low at U1D(11). The resulting high on U1C(8) turns on Q6, giving a low at the collector, which is the print command. Also at this time, the low on U1B(6) activates U4C through differentiator C5 to generate the positive and negative transfer signals at pins T and K, respectively.

When the sample rate one-shot is set, U1B(6) goes low to turn off Q7, allowing the +5 V supply and R41 - R1 to charge C4 for the display time. C3 is also connected for the NORM position. R1 varies the display time by varying the time required to bring Q8 base to a sufficient plus value to trigger Schmitt Trigger Q8 through Q10. This gives a high at U1A(1). The reset will be delayed until there is no print inhibit. U1A(3) will go low, generating a high at U3B(6), which is fed out at A6(16). The negative reset at U3C(8) is fed out at pin 9 in addition to being used to reset the sample rate one-shot.

The positive reset is used on A6 after passing through level shifter CR7 and CR8. The positive reset turns on Q1 and applies an ECL high to clear U2 and also turns on Q2, which maintains inhibit approximately 200 ns after the end of the reset pulse. At this time, the inhibit goes low and the main-gate circuits are free to function.

Q11 circuitry is a reset one-shot that ensures a sufficiently long reset pulse. The reset pulse width is approximately 40 μs or 400 μs, as determined by the FAST/NORM switch. For NORM sample rates, S2 switches C10 in parallel with C8. The sample rate disable line (pins 10, L) is low during START mode and maintains continuous transfer through CR3 and prohibits main-gate inhibit through U4B in addition to holding down Q8 base through CR2. This prevents the reset from being generated.

When STORAGE is OFF, U5A is activated to maintain transfer through CR4. The manual reset (pin 3) holds the reset one-shot in the ON state as long as the RESET button is depressed (reset low). It also maintains the transfer during the same time to clear the display. In addition, it turns on the main-gate inhibit, even if the main gate is open. The manual reset signal is low if the RESET button is depressed or if the TIME BASE or FUNCTION switch is between positions. (No reset is generated between start and stop positions.)

A6 TROUBLESHOOTING

Troubleshooting the Sample Rate board is best accomplished when the board is in a static state. The procedure given below examines each section separately when the circuit is in a working, but static, condition. Perform the tests in the order listed. The schematic shows the circuit levels after RESET is pushed. These levels should be used as a reference.

NOTE

Do not use an input signal when performing the tests below.

MAIN GATE INHIBIT, PRINT COMMAND DRIVER, and SAMPLE RATE ONE-SHOT. Before troubleshooting, perform the procedure below.

FUNCTION switch	FREQ A
TIME BASE switch	1 s
SAMPLE RATE switch	HOLD
SLOPE switch	*
CHK SEP COM	SEP
STORAGE switch	ON
LEVEL control	full cw
Push RESET	
LEVEL	full ccw

(Note that trigger lamp fires)

The purpose of this procedure is to set these circuits to the point immediately after the main gate closes. Varying the LEVEL control triggers a pulse to open the main gate for 1-second, and pin 17 goes Low during the gate time. U2 sets when the gate closes (positive transition) and remains set with the SAMPLE RATE switch set to HOLD. Once U2 sets, check for a Low on U5C(8). This generates a High on U1C(8) and a Low on U1D(6). Check that U4C(8) pulses High and Q6 collector sets Low. The main gate inhibit line at U6B(9) should now be High. The collector of Q7 is not now affected.

SAMPLE RATE INHIBIT. The sample rate inhibit gates are controlled by the FUNCTION and STORAGE switches and by a print inhibit signal. With the controls set as above, check for the levels shown on the schematic.

SCHMITT TRIGGER. The Schmitt Trigger and Q7 should be checked by using an input signal. Set the counter controls as listed under the waveforms. In waveform five, the repetition rate of the pulses changes with gate time, but pulse width remains the same. Pulse width changes with the SAMPLE RATE controls, but not spacing.





Figure 8-8
A5 TIME BASE CONTROL ASSEMBLY
(See Page 8-19)

Model 5326-2713
Schematic Diagrams



MORE DATA UNDER THIS FOLD





Figure 8-9. A6 Sample Rate Assembly

A7 FUNCTION CONTROL OPERATION

This assembly contains the gating, flip-flops, one-shots, and translators necessary to interconnect the oscillator, time base, and input channel signals to the time base and decade counting assemblies. Table 1 lists the functional interconnections for each function of the counter.

An example of the operation in the FREQ A mode will explain the typical circuit operation. This will be expanded to the other functions. Assuming the start of a new measurement, main gate inhibit (pin 17) has just gone low (at the end of the display time). Upon the arrival of the first subsequent channel A input, channel A flip-flop sets, making U5B(9) High. Upon the next leading edge of the oscillator signal (pin 7, TTL levels; U8B(4) ECL levels), U6B sets and arms the oscillator gate U3A. The gated oscillator signal is then connected to the time base input one-shot U4, which generates 50 ns. negative-going pulses to the time base input (pin 11).

The time base will return a pulse upon receipt of the 1st and Nth pulse delivered from pin U (N = multiplier setting on front panel). The 1st pulse arriving at pin V is translated from TTL to ECL by U8 and then goes on to toggle (set) main gate flip-flop U1. This opens the main gate (U13B), and the decade counting assembly counts the signal (in this case, input A — see Table 1). Upon the arrival of the 2nd time base output pulse, U1 toggles closed, shutting main gate U13B and signaling A6 to start the display cycle (pin 18). A6 returns a High MINH (pin 17) and the main gate flip-flop U1, synchronizer U5, and ITB one-shot U4 are locked closed at the end of the display. MINH goes low and the cycle repeats.

In the period mode, the main gate F-F U1 is toggled by the input A signal so that it is set for exactly one period of A. The counted signal is the oscillator divided by the MULTIPLIER switch setting.

In period average, the input A signal goes to the time base, which generates a pulse on the 1st and Nth pulse. These pulses toggle the main gate, and the oscillator is counted during N periods of A.

In START, the main gate is held open and the input signal, which is scaled by the time base, is counted. The FREQ C operation is the same as FREQ A, except that the input synchronizer U5B is held on by U10. IC's U2, 3, 7, 8, 9, 10, and 12 are combination TTL/ECL translators and data switches. The function inputs (FREQ A, FREQ C, etc) are TTL, low true and are pulled up by internal 10k-ohm pullups on the translators. U8(3) is the check signal to Amplifier A2 and A3. In normal it is low; while in check, it is high with negative 10 ns pulses at 10 MHz.

In time interval, the operation is similar to period, but U1 is set continuously. MGATE OUT (pin 18) is now controlled by the output of U5B. The following explanation describes how the synchronizer U5A and B works in a time interval mode.

Assuming a display cycle has just been completed, the flip-flops formed by U11 and U6 and U5 sections have been reset. Two conditions can occur.

First — if a channel A signal occurs before a B signal, the A signal will set the channel A flip-flop before the B sets the B flip-flop (see Timing Diagram). When the first leading edge of the oscillator occurs after the A F-F is set, U5B is set, opening the clock gate and instructing A6

that the measurement has started (pin 18). The oscillator signal goes to the time base and is divided, returns, and is set out through the main gate to A8 for subsequent display. When the B signal occurs, the leading edge of the next clock pulse sets U5A, closing the clock gate.

Table 1. Functional Interconnections

FUNCTION	MGFF TOGGLE	TO DCA	ITB
STOP	0	OTB	0
START	1	OTB	1A
FREQ A	OTB	1A	GOSC'
FREQ C	OTB	1C	GOSC'
DVM·RA·RB	OTB	IV	GOSC'
PERIOD	1A	OTB	GOSC'
T.I.	1	OTB	GOSC'
T.I. AVG.	OTB	GOSC'	STI

DCA - Decade Counting Assembly
 GOSC' - Gated Oscillator
 1A - Input A Signal
 1C - Input C Signal
 ITB - Input to Time Base
 IV - DVM V-F Converter Output
 OTB - Output of Time Base
 STI - Synchronized Time Interval

The U5A Q low signal goes back to U6(11) and waits about 50 ns for the falling edge of the oscillator. At this point, U6(10) goes high, resetting the A and B flip-flops, putting lows at the D input of U5A and B. When the clock pulse again rises positive, U6(13) goes low (about the 10 ns after the clock edge) and U5A and B are closed to the "cleared" state.

Second — if a B signal occurs before an A, U5A would be set first, and no counting would occur. Also, it would take about 150 ns for U5A to complete the resetting described above; so if an A signal occurred during this time, it would be ignored. If the B-to-A delay is >150 ns, the A signal would start the interval as described above.

With time interval averaging, the input synchronizers work the same way, but the oscillator (not divided) is counted for the duration of each individual time interval that is being averaged. The first input A signal sets flip-flop U5B, which enables U3A to gate an oscillator pulse to the time base dividers. The dividers are now set to zero, from their previous reset-to-nine state. During this time, a channel B signal was received to complete the first time interval; but this first interval is not counted, since the main gate was closed. The time base output pulse enables the main gate to pass clock pulses for the duration of the time interval. After N intervals, the time base returns a pulse to close the main gate.

Part of Figure 8-10. A7 Function Control Assembly






Figure 8-9
 A6 SAMPLE RATE ASSEMBLY
 (See Page 8-21)

Model 5326/27B
 Schematic Diagrams

Part of Figure 8-10. A7 Function Control Assembly




MORE DATA UNDER THIS FOLD




Part of Figure 8-10. A7 Function Control Assembly
 FREO A Flow Diagram

Model 5826-27B
 Schematic Diagrams

Period Flow Diagram
Part of Figure 8-10. A7 Function Control Assembly




5-10-3



Time Interval Average Flow Diagram
 Part of Figure 8-10. A7 Function Control Assembly

Model 5326 27B
 Schematic Diagrams

DVM Flow Diagram
Part of Figure 8-10, A7 Function Control Assembly







Figure 8-10. A7 Function Control Assembly

A8 DISPLAY SUPPORT OPERATION

The display support assembly A8 serves to interconnect the display assembly A9 with the interconnect assembly A16. In addition, A8 contains a high-speed decade counter, decimal point drivers, and blanking (logic) circuits.

The high-speed decade consists of four JK flip-flops U3 through U6. The line receiver, Q2 and Q9, serves to reduce noise levels on the signal from A7 prior to driving U3(6, 9). U3 divides by two and the combination of U4 through U6 divides by five. The decade supplies BCD outputs to A9 via J1(5, 4, 2, 3) for the 10th display tube. The D output is also used as the carry input to the next decade counter on A9. Q1 translates the positive TTL reset signal to ECL levels to reset the high-speed decade to zero.

Decimal point drivers Q3 through Q8 work in conjunction with logic circuits on A11 to light the proper decimal points. R15 and R17 provide operating bias for Q3 through Q8. R19, R20, and R23 are current limiters. R2 and R3 provide 87.5 volts pre-bias for the OFF decimal points. R5 through R10 connect the off decimals to the pre-bias voltage to eliminate background glow.

As an example of operation, when a ground is received at P1(S) from A11, Q5 conducts. With Q5 on, decimal point enable line 3 (DP3) is pulled to ground to light the decimal point on A9DS4(10th). Also with P1(S) low, U1D(1) is high to unblank A9 U4. When U1D(1) goes high, U1B(6) and U1A(3) are also high to unblank A9U3 and U2. This unblanks A9DS4, DS3, and DS2. DS5 and DS6 remain blanked. DS1 is never blanked, and DS7 and DS8 (Option 001) will always be blanked.

CR2 and CR3 are included for use with the digital recorder Option 003. When overflow occurs, P1(M) and J1(15) go low. CR2 and CR3 cause J1(4 and R) to also go low. When J1(15, 14, R) are low, the recorder will print a zero on the annunciator line. R21 and R24 are pull-up resistors.

A8 TROUBLESHOOTING

High Speed Decade

If a problem in the High-Speed Decade is not readily apparent when checking for the correct waveforms, a step-through method may be preferable. Set the counter as follows:

1. MULTIPLIER switch to 10⁵.
2. CHK/SEP/COM switch to CHK.
3. FUNCTION switch to START.
4. Press RESET.

The High-Speed Decade has four output lines that are binary weighted DCBA. Release the RESET button and note the counter's display. A typical problem is as follows: The display counts 1...2...3...0...1...2...3...0. When the display reads "0," set the FUNCTION switch to STOP and check the C line for a Low (refer to the table below). Check the input lines of the IC, since their levels depend on the state of other IC's in the circuit (note U4 pin 3 and U6 pin 13). The levels given below are ECL.

	A	B	C	D
DISPLAY	U3(13)	U4(1)	U5(1)	U6(1)
1	L	H	H	H
2	H	L	H	H
3	L	L	H	H
4	H	H	L	H
5	L	H	L	H
6	H	L	L	H
7	L	L	L	H
8	H	H	H	L
9	L	H	H	L
10	H	H	H	H
11	REPEATS			

Decimal Point and Blanking

Before testing the decimal point and blanking circuitry, set the CHK/SEP/COM switch to SEP and disconnect the input signal.

DECIMAL POINT. To check the decimal point circuitry, set FUNCTION switch to PERIOD AVG and position the TIME BASE switch to pull the required D.P. line Low.


LINE	MULTIPLIER POSITION	DRIVER
D.P.0	1	Q8
D.P.1	10	Q7
D.P.2	10 ²	Q6
D.P.3	10 ³	Q5
D.P.4	10 ⁴	Q4
D.P.5	10 ⁵	Q3

BLANKING. To check the blanking circuitry, set the FUNCTION switch to PERIOD AVG and MULTIPLIER switch to 1. All digits, except the first one, should now be blanked. If another digit is lit, check that line at A8J1 for a High level, which indicates a problem on that line.

Figure 8-10
A7 FUNCTION CONTROL ASSEMBLY

(See Page 8-29)


Part of Figure 8-11. A8 Display Support Assembly



← MORE DATA UNDER THIS FOLD

COUNTER CONTROLS:
 Use settings of A2 Assembly
DC VOLTAGES:
 Set counter controls as stated.
 Disconnect input signal.
 Push RESET.
 HE, LE - ECL Levels
 H, L - TTL Levels

OSCILLOSCOPE CONTROLS:
 VOLTS/CM05 V/cm
 TIME/CM2 μs/cm
 SWEEP MODE AUTO
 TRIGGER INT
 SLOPE ↑



- NOTES**
- REFERENCE DESIGNATIONS WITHIN THIS ASSEMBLY ARE ABBREVIATED AND ASSEMBLY NUMBER TO ABBREVIATION FOR COMPLETE DESCRIPTION.
 - UNLESS OTHERWISE INDICATED, RESISTANCE IN OHMS, CAPACITANCE IN PICOFARADS.

REFERENCE DESIGNATIONS

A8	A9
C1-2	J1-2
C11-4	F1
J1	
Q1-11	
R1-26	
U1-E	

TABLE OF ACTIVE COMPONENTS

REFERENCE DESIGNATIONS	HP PART NUMBERS
CR1-4	1901-0040
CR2-3	1910-0006
Q1-2, 9-11	854-0092
	2N3263
Q3-6	654-0362
	2N4410
U1	1870-0057
	MC846P
U2	1870-0307
	MC856P
U3	1870-C143
	MC1027
U4-6	1870-C102
	MC1035P

Figure 8-11. A8 Display Support Assembly

A0 DISPLAY ASSEMBLY OPERATION

Display assembly A0 contains decade counters U2 through U7, buffer storage units U0 through U15, BCD to decimal converters U17 through U23, and display tubes DS1 through DS7.

U1 translates the ECL data from A8 into TTL levels for use by circuits on A0. Each translator of U1 is noninverting. The D output at U1(15) is the counted signal divided by 10 and is used as the input to 10¹ decade U2.

Decade counters U2 through U7 count the number of input pulses while the main gate is open. Each decade provides a 8421 BCD output to the corresponding buffer storage unit. When pin 14 (reset) goes High, the decades reset to zero if pin 10 is High; the decades reset to 15 (blank) if pin 10 is Low. The ECL decade on A8 never blanks. U7 and U8 (Option 001) always blank. The last decade supplies an overflow output at pin 8 when the count exceeds the capacity.

Buffer storage units U0 through U15 receive the BCD outputs of the decades. When the counter operates in the storage-on mode, data is transferred when a low transfer pulse arrives at pin 5 of the buffers. When the transfer line is high, the buffers will store the data to allow a continuous display while a new measurement is being made. During storage-off or totalize mode, BCD data is continuously fed from the buffers to the decoders. The buffers also supply 8421 BCD outputs to A0 J1 and J2 for further distribution to JB when Option 003 is included.

Decoder drivers U17 through U23 receive the 8421 BCD data and provide a decoded decimal output to light the corresponding numeral on the display tube. The terminal for an illuminated numeral will be approximately +2 volts whereas an extinguished numeral is typically +100 volts. The decimal point terminal (14) of the display tube is ≈ 5 volts when lit and about 87.5 volts when extinguished.

A0 TROUBLESHOOTING

The A0 Display Assembly may be set up for troubleshooting with either of two methods. A highly accurate oscillator may be used for a front-panel input signal. Any difference in count from the input signal is then immediately obvious on the display. Check for the proper signal division of the decade counter in previous column. As an alternate method, place the CHK SEP COM switch in CHK and the FUNCTION switch in START. Allow the count to totalize until the problem occurs; then, set the FUNCTION switch to STOP. Use the TIME BASE switch to adjust the rate of counting. When the problem appears, check the circuitry of that column.

Start by checking the Buffer Storage outputs (U0-U15) for the BCD code of the number that should be displayed, rather than what is displayed (see Table 1). Check that the Buffer Storage code pulls the proper decimal line low on the BCD-to-Decimal Decoder.

Table 1

DISPLAYED DIGIT	BUFFER STORAGE BCD (TTL)			
	8	4	2	1
0	H	H	H	H
1	H	H	H	L
2	H	H	L	H
3	H	H	L	L
4	H	L	H	H
5	H	L	L	L
6	H	L	L	H
7	H	L	L	L
8	L	H	H	H
9	L	H	H	L
Blank	L	L	L	L

Model 5326/2713
Schematic Diagrams

Part of Figure 8-12. A0 Display Assembly (Option 001)




Figure 8-11
A8 DISPLAY SUPPORT ASSEMBLY

(See Page 8-31)

MORE DATA UNDER THIS FOLD





Figure 8-12. A9 Display Assembly Standard Instrument and Option 001

A10 RIGHT READOUT OPERATION



The right readout contains DTL logic to provide the proper measurement units for a given setting of the front-panel controls. A10 logic is negative true, and a low (≈ 0.8 volts) to the emitter of any driver transistor will light the given neon. When a DTL high is applied on the emitters, the transistor is reverse biased to turn off the neon lamps. The voltage dividers provide a reference of 2 V (nominal) to the bases of the drivers, when no annunciators are on.

Selecting a function mode and time base pulls a pair of these lines low, activating a gate. This low on the gate output will forward bias the driver transistor to turn on the annunciator lamp. For example, selection of frequency and 1 ms makes the output of U4D(11) low, turning on Q9 to light DS5. Q10 also turns on, lighting DS6.

The asterisk (*) annunciator (DS8) is activated when the counter is in the time interval or period mode and the time base is 10s. An asterisk indicates the proper units are not displayed.

A10 TROUBLESHOOTING

Select the specific function mode and time base combination that is faulty. Check the gate that is common to the two lines. For instance, when using frequency and a 1 ms gate time, check U4D; when using .1 μ s, U3A becomes the common gate. Refer to Table 5-5 for the proper annunciator lighting conditions.



- NOTES
- 1 REFERENCE DESIGNATIONS WITHIN THIS ASSEMBLY ARE ABBREVIATED. ADD ASSEMBLY NUMBER TO ABBREVIATION FOR COMPLETE DESCRIPTION.
 - 2 UNLESS OTHERWISE INDICATED: RESISTANCE IN OHMS.

REFERENCE DESIGNATIONS

A10
CR1, 2
DS1-9
P1
Q1-13
R1-9
U1-7

TABLE OF ACTIVE COMPONENTS

REFERENCE DESIGNATIONS	HP PART NUMBERS
CR1, 2	1901-0040
Q1-3	1654-0009 2N709
Q4-13	1654-0474 2N5551
U1-4	820-C274 MC1608
U5	1620-0310 MC662
U6, 7	1620-0273

Figure 8-13. A10 Right Readout Assembly

A11 LEFT READOUT OPERATION

The left readout contains DTL logic to select the proper decimal point corresponding to the TIME BASE SETTING. It also contains the switch common drivers for the time base, function, and amplifier common lines (for remote programming), a storage circuit and lamp for the overflow signal, the gate light, and the EXT light.

The overflow signal from the +10 output of A9U7 (U8, Option 001) enters through pin M and is differentiated by C2 and R1. Q1 turns on momentarily to set flip-flop U1A&D. During the transfer pulse, the information at U1A&D is transferred to the overflow storage flip-flop U1B&C. The overflow condition drives U1C(8) low to turn Q2 on and light overflow lamp DS1. The next reset pulse clears flip-flop U1A&D; however, U1B&C are not reset until the transfer pulse arrives. With storage off, transfer is on continuously.

A low at pin L turns on Q3 to light the count lamp, DS2. Similarly, a low at pin A lights the EXT lamp and opens the common lines for the TIME BASE, FUNCTION, and SLOPE switches. This disables these controls to allow remote programming of the unit.

Decimal selection and resultant blanking are accomplished by the negative logic AND gates. For any pair of low inputs, a specific decimal point line is held low, lighting the decimal point. There are a number of combinations for each decimal; therefore, the output of each AND gate is paralleled to give a wired OR configuration (any output low = all low).

A11 TROUBLESHOOTING

Select the specific function mode and time base combination that is faulty. Check the gate that is common to the two lines. Refer to Table 5-5 for the proper annunciator lighting conditions.

To check the overflow circuits, set the FUNCTION switch to START and select a fast gate time. When the most significant digit on the counter's display changes from 9 to 0, both flip-flops in the overflow circuit should set. As an initial test, check U2 for a High on pin 13. The second flip-flop (U1B and U1C) should have a Low on pin 8 and a High on pin 6.

In any mode other than START, the -TRANSFER line pulses Low, rather than being held Low. If the OF light does not turn off at the end of the display time, check that the -RESET pulse clears flip-flop U1A&D.





Figure 8-14. A11 Left Readout Assembly



A12 VOLTMETER INPUT AMPLIFIER OPERATION

This board contains a unity-gain input amplifier that serves to buffer the voltage-to-frequency converter (A13) from the voltmeter input terminals. This provides a low impedance output to A13 while maintaining the high input impedance. The amplifier features high input impedance (typically 10 M Ω). Dynamic input voltage range is in excess of 12.5 V. Circuits are included to fully protect the stage from over voltage. To maintain the high input impedance, care should be taken not to damage the protective coating or the printed circuit board by heat or scratches.

The DC voltage input is fed into the board through pins B, 2, and goes through R5, R9, R13 for the 10 volt range or the R3-R24 resistor string for the other two ranges.

Selecting the 10 V position on S4 grounds the base of Q1 to energize K1 and apply the input signal directly to the gate of Q7A. Switching to 100 V grounds the base of Q3 to energize K3. The base of Q1 is pulled high (through a resistor on another board) to turn off Q1 and deenergize K1. The 1000 V position activates Q4 and K4, so that Q7A sees only the drop across R20-R24 and R15. During the "Read A Level" or "Read B Level" modes, Q5-K6 or Q6-K5 are activated to read the trigger level of Channel A or B.

The amplifier consists of a pair of matched FET's (Q7) and one operational amplifier (U1) in a feedback arrangement. Q8 and Q9 are constant current sources due to the constant voltage developed across CR4. The bootstrap circuit CR5 and Q10 develop a constant voltage between the gate and source of the FET's, to provide thermal stability. Q7A and Q7B are matched to ensure that a voltage difference between both gates will appear at the corresponding source terminals. Any voltage difference between the gates is amplified in U1 and fed back to Q7B until the voltage difference becomes zero. CR2 and CR3 provide overload protection for Q7A and B by conducting at voltage differences greater than 0.7 volts.




NOTES

1. REFERENCE DESIGNATIONS WITHIN THIS ASSEMBLY ARE ABBREVIATED. ADD ASSEMBLY NUMBER TO ABBREVIATION FOR COMPLETE DESCRIPTION.
2. UNLESS OTHERWISE INDICATED: RESISTANCE IN OHMS; CAPACITANCE IN PICOFARADS.

TABLE OF ACTIVE COMPONENTS

REFERENCE DESIGNATIONS	HP PART NUMBERS
CR2,3	1901-0376
CR4	1902-3083
CR5	1902-C049
CR6	1901-0040
Q1	1850-C039
C3-E	1853-0020
Q7	1855-0049
Q8,9	1854-0087
Q10	1853-0036
U1	2N2906 820-02 LM301A



RELAY TRUTH TABLE

RANGE	RELAY ENERGIZED					
	K1	K3	K4	K5	K6	
10V	x					
100V		x				
1000V			x			
READ A					x	
READ B						x

REFERENCE DESIGNATIONS

NO PREFIX	A-2
J1	C1-4 CR2-6 K1,3-4 Q1,3-10 R3-34 U1

NOT USED CR1, R2, G2, R1, R2
CR2K C-1

Figure 8-15. A12 Voltmeter Input Amplifier Assembly

A13 VOLTAGE TO FREQUENCY CONVERTER OPERATION

This assembly converts the output from the unity gain amplifier on A12 to a control signal that opens the clock gate U7A. When the main gate A7U11B opens, the decade counters will count a signal whose frequency is proportional to the DVM input voltage. This is accomplished by establishing two reference voltages for U4A/B switching circuitry and integrating the input signal to generate a ramp function. The time required for the ramp function to go from one reference level to the other is proportional to the input voltage. A reference current is switched into the integrator via CR5 or CR6. This returns the integrator to its original reference level, where the cycle starts again. During the time the reference current is turned on to return the integrator to the original reference, clock pulses appear at the DVM output on Pin 3 of U7A.

This process continues during the integrating time selected by the time base switch. At the end of this time, the decade counters contain a count that indicates the input voltage on the DVM. Q1 and Q2 are constant current sources for CR1 and CR4. This develops extremely stable voltages across CR1 and CR4.

Q3 and Q4 are output transistors connected in feedback arrangement which keeps pins 2 of U1 and U2 at the same level as the voltage on the reference diode. This supplies constant currents through the resistive networks connected to U2(2) and U1(2). R15 and R16 adjust the magnitude of this current. R10 and R7 are factory selected according to the exact value of CR4 and CR1.

When the DVM input is negative, the negative reference current is switched through diode CR5 into the summing node of the integrator U3 pin 2. This operation is controlled by the digital part of the assembly. If pin 2 of U5A is high and pin 1 is low (A=1), diode CR7 is back biased to route Q3 current through CR5 into the summing node of the integrator. The summing node is at virtual ground.

In a similar way, the positive reference current switches through CR6 to the summing node of the integrator, when U5B pin 12 is low and pin B is high (B=1). This is used for a positive voltage at the DVM input.

U4 is a quad comparator with ECL output levels. U4A gives a high output if the output of U3(V2) is greater than -0.7 V and U4B pin 4 is low if V2 is less than -1.8 V. These threshold levels are set by CR11 and R29, 31, 32. U4C and D differentiate the clock input after it passes through the divide-by-8 circuit consisting of U8, Q5, and R24. U4D generates a negative going 100 ns pulse on each positive transition of the 125 kHz clock at the collector of Q5. U4C generates a positive going 100 ns pulse on each negative transition of the 125 kHz clock. Differentiating occurs through C11 and R33.

U6 and U5 are connected as two master-slave flip-flops. U6A is the master and U5A the slave. Data from U4A is stored and clocked for the negative reference current control, e.g., A will be high for a certain duty cycle, which is proportional to the applied negative voltage at input terminal 14, R.

U6B and U5B control the positive reference current in much the same way as U6A and U5A to evaluate input signals with a positive polarity. U7B and C detect polarity and Q10 translates the output of U7B to DTL levels. Q10 is conducting for negative polarity.

Model 5326/27B
Schematic Diagrams

Part of Figure 8-16, A13 Voltmeter V to F Converter Assembly






Figure 8-16
A13 VOLTMETER INPUT AMPLIFIER ASSEMBLY

(See Page 8-39)

← MORE DATA UNDER THIS FOLD

8-41



NOTES

1. REFERENCE DESIGNATIONS WITHIN THIS ASSEMBLY ARE ABBREVIATED. ADD ASSEMBLY NUMBER TO ABBREVIATION FOR COMPLETE DESCRIPTION.
2. UNLESS OTHERWISE INDICATED: RESISTANCE IN OHMS, CAPACITANCE IN PICOFARADS.
3. ASTERISK (*) INDICATES SELECTED COMPONENT AVERAGE VALUES SHOWN.
4. R7 AND R10 ARE SELECTED FROM ONE OF THE FOLLOWING FOUR VALUES: 31.6K, 61.9K, 19.6K OR OPEN.

REFERENCE DESIGNATIONS

NO PREFIX	A13
C1-11,13	
Q1-10	
R1-41	
U1-8	

C12 DELETED
R19,20,22,23,25,26 DELETED

TABLE OF ACTIVE COMPONENTS

REFERENCE DESIGNATIONS	HP PART NUMBERS
CR1,4	1902-0680
CR7	1901-0325
CR2,3,9-11	1901-0040
CR6,6,8,12,13	1901-0179
Q1,10	1854-0071
Q2	1853-0020
Q3	1853-0056
	2N4342
Q4	1853-0081
Q5	1854-0009
	2N709
C6-9	1824-0092
	2N3263
U1-3	1820-0223
	MC14399
U4	1820-0212
	MC102CP
U5	1820-0213
	MC1014P
U6	1820-0276
	MC1033P
U7	1820-0148
	MC102CP
U8	1820-0109

TRUTH TABLE

VOLTMEETER INPUT	V2 OUTPUT OF OP AMP U2(6)		AFTER CLOCK PULSE		
	A	B	A	B	P
NEGATIVE	$V_2 > -0.7V$		H	L	L
	$-0.7V > V_2 > -1.6V$		L	L	H
POSITIVE	$-1.6V > V_2$		L	H	H

H = +0.75V, L = -1.60V

Figure 8-16. A13 Voltmeter V to F Converter Assembly


A14 VOLTMETER DISPLAY CONTROL OPERATION



This board activates the "volts", "+", or "-" annunciators, provides the 1 MHz required by A13, and selects the decimal point for three settings of the time base switch.

U3A and B gates the polarity information into the polarity flip-flop U3C, D (H=+ polarity). This information is transferred into buffer storage U2A and B by gates U2C and D when the "transfer data" line is enabled (low = enable).

Gates U5C and D activate either the + or - front panel lamp when the unit is in the DVM, READ A, or READ B mode. The volts annunciator is activated by U5B whenever the mode is DVM, READ A, or READ B and when the time base is 10 ms, 100 ms, or 1 sec. U5A removes the ground from the DVM range switch when not in the DVM mode. U6D sets the time base to 10 ns when the READ A or READ B mode is selected.

U4, U7, and U6C select the correct decimal point for the various combinations of time base and range switch settings. CR6, 7, 4, and 5 are installed to alleviate fan-out (IC loading) problems.





- NOTES**
1. REFERENCE DESIGNATIONS WITHIN THIS ASSEMBLY ARE ABBREVIATED. ADD ASSEMBLY NUMBER TO ABBREVIATION FOR COMPLETE DESCRIPTION.
 2. UNLESS OTHERWISE INDICATED: RESISTANCE IN OHMS, CAPACITANCE IN PICOFARADS.

REFERENCE DESIGNATIONS

NC PREFIX	A14	A16
S4	CR1-7 R1-6 U1-7	CR15

TABLE OF ACTIVE COMPONENTS

REFERENCE DESIGNATIONS	HP PART NUMBERS
A14	
CR1-7	1910-0016
U1	1820-C413
U2,3	1820-0094
U4,5,7	MC 846P
U6	1820-0274
	1820-0273
	MC 1806P
A16	
CR15	1901-0040

Figure 8-17. A14 Voltmeter Display Control Assembly

A15-A16 POWER SUPPLY OPERATION

The power supply provides +175, +16.5 V and +5 V. Transformer T1 has a 115/220 primary and secondaries with open circuit voltages of 181 V at the red leads, 21 V at the orange, and 18.6 V between the green leads, with the winding center tapped to ground.

A15 CR6-9 comprise a full-wave bridge whose output is fed to filter C3 and bleeder R3. Q5 is a series pass regulator. A constant reference voltage is developed across CR11 and CR 2 through resistor R1. When the output voltage at XA15(1, A) decreases, Q5 increases conduction to increase the output voltage. Q8 is a current limiter that senses the voltage drop across R6. Output current above approximately 60 mA turns on Q8 and shunts base current from Q5, tending to turn Q5 off and limit the current. C1 adds oscillation stability to the regulator.

For the +16.5 V supplies, the orange leads of T1 connect to half wave rectifier CR4 and filter C4. Q1 is a series pass regulator and Q9 performs the same function as CR11&CR12 in the 175 V supply except that R10 provides a means to adjust the output. Assume that a Q1 base current is flowing through R2 and Q6. The resulting Q1 collector current establishes a voltage at the output, which is divided across R9, R10, and R11. If the voltage at the wiper of R10 is greater than that across CR9, Q9 will be turned on, shunting base current from Q1. This will tend to turn off Q1 and lower the regulated voltage. Thus, varying R10 establishes the largest output voltage that can exist before Q9 turns on to cut back Q1. Resistors R17, R18, and diodes CR15-18 provide current limit action at 160 mA similar to the +175 V supply.

Q6 is a preregulator that gives the circuit better line regulation and lower ripple than the Zener diodes of the 175 V supply. With CR1 as a reference, Q6 is a constant current circuit that maintains a Q1 base current independent of variations of the input (line voltage changes and ripple). R4 is needed to establish the current through CR1. The -16.5 V supply is complementary. The 5 V supplies are also complementary and only the + will be discussed.

The output from the T1 green leads is fed through full wave rectifier CR10 and CR11 into filter C1. It then passes through over-load current limiter R1 and into the series pass regulator Q1, to the 5 V output at Q1C. Q3 is a driver for Q1 and has approximately 5.75 V on its base, developed across CR6 and CR5 by the current from the 16.5 V supply through R7. If the voltage at the emitter 5.1 V, Q3 is turned on providing base current to turn on Q1, raising the output voltage. Q3 turns off when its emitter gets above 5.1 V. C2 is the output filter to maintain a low output impedance at high frequencies.

CR2 clamps the output at 6 V to provide protection for the IC's in case the 16.5 V or 175 V line should momentarily short to the 5 V line. CR5 provides thermal compensation for Q3.


Note that the 16.5 V supply is needed for operation of the 5 V supply. If the + or - 16.5 V supply fails, the corresponding 5 V supply will be inoperative.

Figure 8-17
A14 VOLTMETER DISPLAY CONTROL ASSEMBLY




(See Page 8-43)

Model 5326/27B
Schematic Diagrams

Part of Figure 8-18, A15, A16 Regulator/Interconnect Board Assembly



← MORE DATA UNDER THIS FOLD



- NOTES
- 1 REFERENCE DESIGNATIONS WITHIN THIS ASSEMBLY ARE ABREVIATED. ADD ASSEMBLY NUMBER TO ABBREVIATION FOR COMPLETE DESCRIPTION.
 - 2 UNLESS OTHERWISE INDICATED RESISTANCE IN OHMS, CAPACITANCE IN MICROFARADS.
 - 3 A15 Q1-5 HAVE HEAT SINK.
 - 4 ASTERISK (*) INDICATES SELECTED COMPONENT, AVERAGE VALUES SHOWN.
 - 5 CR16 AND CR17 ARE 3-JUNCTION SILICON DIODES.

REFERENCE DESIGNATIONS

NO PREFIX	A15	A16
Q1		
C1	C1-7	C1-5
	CR1-18	CR4-13,
		16,17
F1		
J8, J11	F1	
P2		
Q1, 2	Q1-10	
Q1, 9	RI-18	RI-5
T1		
W3		

TABLE OF ACTIVE COMPONENTS

REFERENCE DESIGNATIONS	HP PART NUMBERS
NO PREFIX	
Q1	1853-0255
C2	1854-0420
A15	
CR1, 4	1902-3002
CR2, 3	1902-0581
CR5, 6, 10-18	1901-0040
CR6, 7, 9, 10	1902-1084
CR11	1902-3394
CR12	1902-3429
CR13, 14	1901-0053
Q1	1854-0300
Q2	1853-0073
Q3	1854-0039
	2N3055
Q4	1853-0012
	2N2904A
Q5	1854-0232
Q6, 10	1853-0020
Q7, 9	1854-0071
Q8	1854-0474
A16	
CR4, 5	1901-0045
CR6-9	1901-0029
CR10-13	1901-0460
CR16, 17	

Figure 8-18. A15, A16 Regulator/Interconnect Board Assembly

A17 INPUT C AMPLIFIER OPERATION

The input amplifier performs two functions: it provides a channel for increased sensitivity and it produces narrow pulses for efficient usage by other counter circuits. The amplifier is not controlled by any front-panel switches.

The input signal is dc coupled into a 50 ohm input impedance (R1) and is fed into the input amplifier, which is protected by R2, CR1, and CR2. Current source U1Q5 feeds the balanced differential amplifier U1Q3, Q4. The twin outputs are loaded by R10 and peaking coil L2. The signal flows to another amplifier circuit, whose outputs control the triggering of the tunnel diode, CR3. The diode is biased for maximum sensitivity with R11. When the diode fires, it produces fast rise and fall times on the input signal.

High-impedance emitter followers (Q1, Q2) ac couple the signal to the single-ended differential amplifier of Q3 and Q4. The short time constants of C9, R18, and C12, R23 differentiate the signal into narrow spikes of about 16 ns. The output circuit of C11, R22, and L4 approaches resonance at high frequencies for improved gain.

The signal is then fed to the one-shot multivibrator U2. The one-shot output goes High (U2, pin 4) when the input goes low. The output goes Low again after about 12 ns, when the level changes have propagated through the gates in a domino effect.

SENSITIVITY ADJUSTMENT


- a. Set counter controls as follows:



FUNCTION FREQ C
TIME BASE 0.1 S

- b. Set HP 606B HPF Signal Generator (or equivalent) for 50 MHz at 500 mV rms. Measure the output signal of 606B with an HP 411A RF Millivoltmeter, using a 50Ω termination. Connect signal source to INPUT C of counter.

- c. Reduce output level until counter's display becomes unstable. Adjust R11 for a stable display. Repeat this procedure until unable to obtain a stable reading. Increase the signal level until display just becomes stable.

- d. Disconnect input and connect to voltmeter, reading should be less than 5 mV. Check other frequencies within the band.





- NOTES**
- REFERENCE DESIGNATIONS WITHIN THIS ASSEMBLY ARE ABBREVIATED. ADD ASSEMBLY NUMBER TO ABBREVIATION FOR COMPLETE DESCRIPTION.
 - UNLESS OTHERWISE INDICATED: RESISTANCE IN OHMS, CAPACITANCE IN PICOFARADS, INDUCTANCE IN MICROHENRIES

TABLE OF ACTIVE COMPONENTS

REFERENCE DESIGNATIONS	HP PART NUMBERS
CR1,2	1901-0047
CR3	1912-0009
Q1,2	1853-0015
Q3	1854-0092
Q4	1854-0345
U1	1858-0004
U2	1820-0147

REFERENCE DESIGNATIONS

A1
C1-13
CR1-3
L1-4
Q1-4
R1-19,
21-26
U1,2

Figure 8-19. A17 Input C Amplifier Assembly (5326B Only)

A18 PRESCALER OPERATION

The prescaler board serves as a direct amplifier-trigger or as a divide-by-ten amplifier-trigger, with the function controlled by a front-panel input selector switch. With the switch in the PRESCALE position, the circuit performs as follows:

The signal is fed into the 50Ω input of J1. CR1, CR2, and U1 provide protection above 3.5 V rms or 5 V peak. There is about 2 dB loss through U1. The signal is passed to U2 amplifier, which is biased for sensitivity by R3. U3 amplifies the differential input and shapes the signal into a square wave. U4 and U5 combine to divide the signal by ten and Q2 translates the signal from EEC1 to ECL levels before presenting it to the data switch.

The direct signal, also from U3(U3), bypasses the divider network and is sent to the data switch through the level translator Q1. The setting of the INPUT SELECTOR switch determines whether the data switch will accept the direct or prescaled signal. Pin 2 of U6 is High for direct and Low for prescaled. U9 shapes the positive, square-shaped pulses into narrow spikes before sending the signal to A7 Function board. U7, U8, and U10 (a production option) are constant-current sources for the amplifier circuits.

A18 TROUBLESHOOTING

Before troubleshooting the circuits, check the input protection fuse. If problem is in direct mode only, check Q1 and U6. If problem is in pre-scale mode only, check U4, U5, U6, and Q2. If a problem is found in the amplifiers (U2 and U3), remove the input signal and check the dc voltages supplied by the constant-current sources U7 and U8.





Figure 8-20. A18 Prescaler Board Assembly (5327B Only)



OPTION 002 REMOTE PROGRAMMING

See Section II for programming information.

Function	J10 Pin No.	Wire Color	W2P1 Pin No.	Circuit Board Terminals	Level	
Start	1	Brn	B12	A16(14)	L = Start Open = Stop	
Period Avg A	2	Red	B11	A16(13)	L = Enable	
Time Intvl Avg	3	Orn	B10	A16(16)	↑ ↓	
Time Intvl	4	Yel	B2	A16(15)		
Period	5	Grn	B3	A16(17)		
Freq A	6	Blu	B8	A16(18)		
Freq C	7	Vio	B13	A16(12)		
Read A Level	8	Gra	C5	A16(21)		
Read B Level	9	Wht	C3	A16(22)		
DVM	10	Wht-Blk	C1	A16(20)		
10 V Enable	11	Wht-Brn	C11	A16(9)		
100 V Enable	12	Wht-Red	C6	A16(8)		
1000 V Enable	13	Wht-Orn	C4	A16(7)	L = Enable	
Check	14	Wht-Yel	B15	XA3(13)	L = Check	
Gate Out	15	Wht-Grn	A9	XA5(F)	H = Gate Closed L = Gate Open	
Computer Inhibit	16	Wht-Blu	C9	XA6(14)	L = Inhibit	
Ext	17	Wht-Vio	A4	XA11(A)	H = Int L = Ext	
Freq C × 10	18	Wht-Grn	(W2P2)	A16(34)	L = Enable	
.1 μs/1	19	Wht-Blk-Brn	B1	A16(30)	↑ ↓	
1 μs/10 ¹	20	Wht-Blk-Red	B9	A16(31)		
10 μs/10 ²	21	Wht-Blk-Orn	B6	A16(28)		
.1 ms/10 ³	22	Wht-Blk-Yel	B7	A16(29)		
1 ms/10 ⁴	23	Wht-Blk-Grn	B5	A16(26)		
10 ms/10 ⁵	24	Wht-Blk-Blu	C15	A16(27)		
.1 s/10 ⁶	25	Wht-Blk-Vio	C13	A16(24)		
1 s/10 ⁷	26	Wht-Blk-Gra	C14	A16(25)		
10 s/10 ⁸	27	Wht-Blk-Red	B4	A16(23)		L = Enable
Slope A	28	Wht-Brn-Orn	C12	XA2(13,P)		L = Minus Open = Plus
Slope B	29	Wht-Brn-Yel	B14	XA3(13,P)	L = Minus Open = Plus	

Function	J10 Pin No.	Wire Color	W2P1 Pin No.	Circuit Board Terminals	Level
A Trig Level	30	Wht-Brn-Grn	C10	XA2(1,A)	+3 V to -3 V
B Trig Level	31	Wht-Brn-Blu	C2	XA3(1,A)	+3 V to -3 V
Sample Rate Disable	32	Wht-Brn-Vio	C7	A16(11)	L = Disable
Print Command	33	Wht-Brn-Grn	C8	XA6(S)	L = Causes Print
Manual Reset	34	Wht-Red-Orn	A5	A16(6)	L = Reset
Sample Rate Hold	35	Wht-Red-Yel	A2	A16(4)	L = Maintain Display
Ground	36	Blk	A10	Ground	

Logic levels (Input) H = +2.0 V, L = +0.8 V (Output) H = +2.4 V, L = +0.4 V



NOTES

1. IN STANDARD INSTRUMENT, ONLY W2PIA IS WIRED




Figure 8-21. Option 002, Remote Programming Cable Assembly and Rear Panel Connector Assembly

OPTION 003, DIGITAL RECORDER OUTPUT

Option 003 includes cable assembly W1 and rear panel connector J9. The counter (A9 Display Assembly) provides +8421 BCD and control line inputs and outputs for use with a printer or other data storage devices.

The annunciator lines (J9-17, 18, 42, and 43) supply overflow, plus, and minus outputs as follows:

FUNCTION	BCD
	8 4 2 1
Overflow	L L L L
+	H L H L
-	H L H H

When the print command line at J9(48) goes low, it indicates that the counter has completed a measurement and the data output may be interrogated. When the inhibit line is held High, the data output is maintained. The line must go high less than 30 μ s after the print command goes low. The +5 V reference line (J9-25) has a 1K source impedance and is used for data level references. The 0 volt or ground reference connects to J9(24, 50).



OPTION 004, EXTENDED REMOTE PROGRAMMING

See Section II for remote programming information.

Option 004 Pin Connections

Function	J10 Pin No.	Wire Color	W2P1 Pin No.	Circuit Board Terminals	Level
Ground	1	Blk			
Ground	2	Blk			
-16.5 V Output	3	Orn			
+16.5 V Output	4	Yel			
+5 V Output	5	Grn			
Sep-Corn	6	Blu		A1 Cable Point 4	
Ac-Dc Chan B	7	Vio		A1 Cable Point 7	
No connection	8	Grn			
X10 Atten B	9	Wht		A1 Cable Point 5	
X100 Atten B	10	Wht-Blk		A1 Cable Point 6	
Ac-Dc Chan A	11	Wht-Brn		A1 Cable Point 8	
No connection	12	Wht-Red			
X10 Atten A	13	Wht-Orn		A1 Cable Point 2	
X100 Atten A	14	Wht-Yel		A1 Cable Point 3	

Function	J10 Pin No.	Wire Color	W2P1 Pin No.	Circuit Board Terminals	Level
Ground	15	Blk	A10		
Sample Rate Hold	16	Wht-Blu	A2	A16(4)	L = Maintain Disable
Manual Reset	17	Wht-Vio	A5	A16(6)	L = Reset
Print Command	18	Wht-Gra	C8	XA6(S)	L = Causes Print
Sample Rate Disable	19	Wht-Blk-Brn	C7	A16(11)	L = Disable
Trig Level B	20	Wht-Blk-Red	C2	XA3(1, A)	+3 V to -3 V
Trig Level A	21	Wht-Blk-Orn	C10	XA2(1, A)	+3 V to -3 V
Slope B	22	Wht-Blk-Yel	B14	XA3(13, P)	L = Minus Open = Plus
Slope A	23	Wht-Blk-Grn	C12	XA2(13, P)	L = Minus Open = Plus
10 ms/10 ³	24	Wht-Blk-Blu	C15	A16(27)	L = Enable
1 ms/10 ⁴	25	Wht-Blk-Vio	B5	A16(26)	
.1 ms/10 ⁵	26	Wht-Blk-Gra	B7	A16(29)	
10 μs/10 ²	27	Wht-Brn-Red	B6	A16(28)	
.1 μs/1	28	Wht-Brn-Orn	B1	A16(30)	
1 μs/10	29	Wht-Brn-Yel	B9	A16(31)	
.1 s/10 ⁶	30	Wht-Brn-Grn	C13	A16(24)	
1 s/10 ⁷	31	Wht-Brn-Blu	C14	A16(25)	
10 s/10 ⁸	32	Wht-Brn-Vio	B4	A16(23)	
Freq C + 10	33	Wht-Brn-Gra	W2P2	A16(34)	L = Enable
Ext	34	Wht-Red-Orn	A4	XA11(A)	H = Int L = Ext
Computer Inhibit	35	Wht-Red-Yel	C9	XA6(4)	L = Inhibit
Gate Output	36	Wht-Red-Grn	A9	XA5(F)	H = Gate Closed L = Gate Open
Check	37	Wht-Red-Blu	B15	XA3(B)	L = Check
1000 V Enable	38	Wht-Red-Vio	C4	A16(7)	L = Enable
100 V Enable	39	Wht-Red-Gra	C6	A16(8)	
10 V Enable	40	Wht-Orn-Yel	C11	A16(9)	
Freq C	41	Wht-Orn-Grn	B13	A16(12)	
Freq A	42	Wht-Orn-Blu	B8	A16(18)	
Period	43	Wht-Orn-Vio	B3	A16(17)	
Time Intvl	44	Wht-Orn-Gra	B2	A16(15)	
Time Intvl Avg	45	Wht-Yel-Grn	B10	A16(16)	L = Enable
Start	46	Wht-Yel-Blu	B12	A16(14)	L = Start Open = Stop
Period Avg	47	Wht-Yel-Vio	B11	A16(13)	L = Enable
Read A Level	48	Wht-Yel-Gra	C5	A16(21)	L = Enable
Read B Level	49	Wht-Grn-Blu	C3	A16(22)	L = Enable
DVM	50	Wht-Grn-Vio	C1	A16(20)	L = Enable



- NOTES
1. IN STANDARD INSTRUMENT, ONLY W2PIA IS WIRED
 2. OUTPUT FROM COLUMN B IS AVAILABLE ONLY WHEN OPTION 001 IS ADDED

40227 © 218

Figure 8-22. Option 004, Remote Programming Cable Assembly and J10 Option 003, Digital Recorder Cable Assembly

A1 OPTION 004 OPERATION

The remote programmable attenuator board attenuates the input signal and routes it to the amplifier boards. The signals from inputs A and B are routed through identical paths.

In the X1 position K2 is closed and the signal is routed directly to K4, which is open with ac coupling and closed with dc. R30 provides the 1 MΩ input impedance. R34, R38, and C7 compensate for high frequency roll-off and also limit the input current to Q1A. Diodes CR25 and CR27 limit the voltage at the input of Q1A to ±5.8 V. Q1A operates as a source follower with a high input impedance and a low output impedance to the amplifier boards. Q1B operates as a source follower, supplying the amplifiers with the dc trigger-level voltage generated either by R49, CR32, and CR33, or from an external analog input (J10). R46, R44, R42, and C13 filter the trigger-level voltage.

In the X1 position, K2 and K4 are closed providing a direct path for the input signal to the gate of Q13A. In the X10 position, K2 is open and diodes CR7 and CR9 are turned on, shorting R16 to ground. R12, R14, and R16 form the dc attenuator. The ac (high frequency) attenuator is formed by C1 and stray capacitance in the circuit.

In the X100 position, K2 is open, CR7 and CR9 are off, and CR21 and CR23 are turned on. C3 and R28 are thus connected to ground. R12, R14, and R28 form the dc portion of the attenuator, while C1, C3, and stray capacitance form the high frequency portion of the attenuator.

The circuitry to drive AC/DC relay K3, and SEP/COM relay K1 is provided by U3 A&C. U3's output is at HTL levels (+12 V, +1.5 V) and thus is sufficient to drive the relays directly. U3's input is at DTL levels and is compatible with remote programming levels. K2 is driven by Q7 and is open when CR7 and CR9 or CR21 and CR23 are on.

Diode pairs CR7 and CR9 are driven by emitter followers Q3 and Q6, which, in turn, are driven by HTL gates U2D and U2C. U2's power supply, consisting of Q1 and Q2, is +8.9 V and -5.6 V rather than the usual +15 V and 0 V. This special bias moves the HTL input threshold to +1.9 V, rather than the normal +7.5 V. U2D can now be driven by DTL gate U1B. The output swing of U2D is +9 V to -4 V, providing the diode quad CR7 and CR9 with positive turn-on and turn-off signals. R9 is adjusted to minimize the offset voltage of the quad.

ADJUSTMENTS

Set:
 TIME BASE 0.1 sec.
 AC/DC DC
 SEP/COM SEP
 ATTEN A/B X10

1. Using an HP 412A or equivalent, measure voltage at CHANNEL A jack.
2. Adjust R56 for <+1 mV reading.
3. Measure voltage at CHANNEL B jack.
4. Adjust R9 for <+1 mV reading.
5. Set A and B attenuators to X100 position.
6. Measure voltage at CHANNEL B jack.
7. Adjust R32 for <+1 mV reading.
8. Measure voltage at CHANNEL A jack.
9. Adjust R33 for <+1 mV reading.

Part of Figure 8-23. Option 004 Programmable Attenuator Assembly




Figure 8-22
 OPTION 004, REMOTE PROGRAMMING CABLE ASSEMBLY
 AND J10 OPTION 003, DIGITAL RECORDER CABLE ASSEMBLY

(See Page 8-53)

← MORE DATA UNDER THIS FOLD

OPTION 004 PROGRAMMABLE ATTENUATOR ASSEMBLY 105227-60014KNGTE 11 SERIES 10404

NOTES

- REFERENCE DESIGNATIONS WITHIN THIS ASSEMBLY ARE ABBREVIATED. ADD ASSEMBLY NUMBER TO ABBREVIATION FOR COMPLETE DESCRIPTION.
- UNLESS OTHERWISE INDICATED: RESISTANCE IN OHMS, CAPACITANCE IN PICOFARADS, INDUCTANCE IN MICROHENRIES.

REFERENCE DESIGNATIONS

A1 OPT 004	
C1-14	CR1-36
DS1-2	J1-4
K1-5	Q1-14
R1-56	S1-9
U1-4	

CABLE POINT	WIRE COLOR	DESTINATION
1	GRN	+5V
2	WHT-ORN	J10131
3	WHT-YEL	J10147
4	BLU	J10161
5	WHT	J10191
6	WHT-BLK	J10101
7	VIO	J10171
8	WHT-BRN	J10111

REFERENCE DESIGNATIONS	HP PART NUMBERS
CR1-3, 6, 15, 18, 30, 31	1910-0016
CR4	1902-0029
CR5	1901-0037
CR7, 8, 23, 24	1906-0024
CR9, 10, 21, 22	1906-0025
CR11-14, 16, 17, 19, 20, 29, 36	1901-0040
CR25-28	1901-0376
CR32-35	1907-0041
Q1	1854-0039
Q2	1853-0001
Q3, 4, 7, 8, 11, 12	1854-0215
Q5, 6, 9, 10	1853-0036
Q13, 14	1855-0334
U1	1820-0274
U2, 4	1820-0287
U3	1820-0625




Figure 8-23. A1 Option 004 Programmable Attenuator Assembly





Figure 8-24. Options 010, 011, and A16 Interconnect Circuit Board




Figure 8-25
5326B/5327B INTERCONNECT DIAGRAM

MANUAL CHANGES

MANUAL DESCRIPTION

INSTRUMENT:	5326B/5327B Timer-Counter-DVM Operating and Service Manual
SERIAL PREFIX:	5326B/5327B-1428A
DATE PRINTED:	FEB 1975
HP PART NO:	05326-90043
MICROFICHE NO:	05326-90044

CHANGE DATE: May 6, 1980

(This change supersedes all earlier dated changes)

- Make all changes listed as ERRATA.
- Check the following table for your instrument's serial prefix or serial number and make listed changes to manual.

IF YOUR INSTRUMENT HAS SERIAL PREFIX OR SERIAL NUMBER	MAKE THE FOLLOWING CHANGES TO YOUR MANUAL	IF YOUR INSTRUMENT HAS SERIAL PREFIX OR SERIAL NUMBER	MAKE THE FOLLOWING CHANGES TO YOUR MANUAL
1640A (5327B Only)	1	1620A03737 & Up (5326B) 1620A01351 & Up (5327B)	1,2,3,4,5,6
1644A (5327B Only)	1,2	1620A	1,2,3,4,5,6,7
1644A (5326B Only)	2	1644A	1,2,3,4,5,6,7,8
1604A (5327B Only)	1,2,3	1936A	1,2,3,4,5,6,7,8,9
1612A (5326B/27B)	1,2,3,4	■ 2012A (5326B Only)	1 through 10
1620A (5326B/27B)	1,2,3,4,5	■ See Note 1 (5327B)	1 through 10

■ NEW OR REVISED ITEM

- **NOTE 1** — Model 5327B Instruments with Serial Numbers 1644A01590, 1936A01594, 1936A01595, 1936A01599, 1936A01600, and 1936A01602 also incorporate CHANGE 10.

The following Service Notes are available from your local HP Sales and Service Office.

Service Note No.	Description
5326ABC/5327ABC-3	Input Attenuator Noise Solution
5326ABC/5327ABC-4	Extra Insulation for the + and -5 Vol. Regulators
5326ABC/5327ABC-5	Field Installation of Option 011
5326ABC/5327ABC-6	Field Installation of Option 040 (Temperature Compensated Crystal Oscillator)
5326ABC/5327ABC-7	Added Protection for the +175 Volt Power Supply
5326ABC/5327ABC-8	Display Tube Driver Warning
5326ABC/5327ABC-9B	Added Protection to the +175 Volt Fuse

ERRATA

Page 1-3, Table 1-3, "INTEGRATING DIGITAL VOLTMETER" Accuracy:
Under Zero Offset (10V range) change $\pm 10.01\%$ to $\pm 0.01\%$.

Page 5-10, Table 5-4, Steps 5C and d:
Change $0.65 \pm 0.05V$ to $0.9 \pm 0.05V$ at A18U2(3).
Change $0.90 \pm 0.05V$ to $0.8 \pm 0.05V$ at A18U3(3).

Page 6-13, Table 6-1, Replaceable Parts:
Change A13R8 and A13R9 from 0757-0398 (75 OHM) to 0757-0384; 20 OHM
FACTORY SELECTED VALUE, MFR Part No. 0757-0384.

Page 6-15, Table 6-1, Replaceable Parts:
Change A16R7 from 0698-3153 (3830 OHM) to 0698-3155, 4630 ohms.

Page 1-5, Table 1-3, Specifications:
Change Option 011 Short-Term Fluctuation (1 s avg) to $<1 \times 10^{-10}$ rms.

3N-5295-5695-3700-5829-5840-5870-6413-6424-6602-6998-7004-7071/7983-8249/8296/9151/10=10437



ERRATA (Cont'd)

Page 6-17, Table 6-1:

Change A18R20, A18R30 from 0608-5177 (820 OHM) to 0608-5103, 430 OHM.
Add "FACTORY SELECTED VALUE" to description.

Page 6-18, Table 6-1:

Change 1200-0147 to 1200-0081 in "HP Part Number" and "Mfr Part Number" columns and "Qty" to 2.

Page 8-35, Figure 8-13, A10 Schematic:

Disconnect A10Q13 emitter from junction of A10P1(U), A10U6A(2), and A10U3B(4).
Add A10P1(17), mark "VOLTS FROM XA14(. .)", and connect to A10Q13 emitter.

Change SERIES number of A16 circuit board to 1428A on various pages where portions of A16 appear in this manual. This includes the Table of Replaceable Parts.

Page 8-41, Figure 8-16, A13 Schematic:

Change A13R8 and A13R9 from 75 to 20 ohms.

Change heading in TRUTH TABLE to read "V2 = OUTPUT OF OP AMP U3(6)" in place of U2(6).

Page 8-44, A15 Component Locator:

Replace with attached Figure 1.

Page 7-2, Paragraph 7-21:

Add the following sentence, "An HP Part No. 05326-00033 adapter plate will also be required for mounting 36-pin remote programming connector J10.

Page 6-17, Table 6-1:

Add A18L3; 05303-80001, 1, COIL, FXD, RF PEAKING, 28480, 05303-80001.

Add "FACTORY SELECTED" to A18R34 and A18R42 "Description".

With these changes A18 assembly 05327-80033 is "SERIES 1428A".

Page 8-49, Figure 8-20, A18 schematic:

Add asterisk (*) adjacent to A18R22, A18R23, A18R20, A18R30, and A18R40.

In Table 6-1 for these resistors add "FACTORY SELECTED VALUE" to description.

Add A18L3 in series with A18U3(13) output line. Output circuit trace is cut and one end of A18L3 is connected to the junction of A18U3(13) and A18R34. The other end of A18L3 is connected to the junction of A18R44 and the coil from A18R42.

Change series number at top of A18 schematic diagram to "SERIES 1428A".

Change dc voltages at A18U2(3) from 0.65V to 0.9V and voltage at A18U3(3) from 0.9V to 0.8 volts.

Page 8-57, Figure 8-24, Schematic:

Change A16R7 from 3830 to 4630 ohms.

Change SERIES at top of schematic from 1224 to 1428.

Page v, List of Figures and Page 8-53, Figure 8-22:

Change caption to read "Option 004, J14 Remote Programming Cable Assembly and Option 003, J9 Digital Recorder Cable Connections".

Page 1-4, Table 1-3, Specifications:

Delete paragraph pertaining to "Short-Term Fluctuation" under "Time Base" heading.

Page 8-55, Figure 8-23, Option 004 Schematic:

Add the following NOTE:

NOTE

SERVICING THIS ASSEMBLY IS ACCOMPLISHED BY REMOVING THE BOARD FROM THE FRONT PANEL AND MATING IT TO THE AMPLIFIER BOARDS, WHICH HAVE BEEN ELEVATED USING TWO 15 PIN EXTENDER BOARDS (HP PART NO. 5060-0049). THIS ALLOWS ACCESS TO BOTH SIDES OF THE ASSEMBLY. RE-ATTACHING GREEN WIRE TO CABLE PT 1 IS NECESSARY TO ALLOW FRONT PANEL CONTROL.




Figure 1. A15 Regulator Board Assembly
05327-60020 Series 1312A or
1428A Component Locator

ERRATA (Cont'd)

Page 5-5, 4. PULSE OPERATION:

In step a, set LEVEL (A) to "SLIGHTLY +" in place of PRESET.

Change step c to read "Adjust pulse generator for positive output for 10 MHz repetition rate, 15 ms pulse width for 0.3 volts peak-to-peak indication on oscilloscope."

Change step d to read "Adjust counter LEVEL A control until counter triggers and counts. Check that counter displays the repetition rate, count light flashes, and trigger A lamp is ON. Record on test card."

Page 6-18, Table 6-1, Replaceable CHASSIS PARTS:

Change Q1 from 1853-0233 to 1853-0356 in "HP" and "Mfr" part number columns.

Change Q2 from 1854-0420 to 1854-0625 in "HP" and "Mfr" part number columns.

NOTE - THE ABOVE TRANSISTORS FOR Q1 AND Q2 ARE RECOMMENDED FOR REPLACEMENT IN ALL INSTRUMENTS. THE HIGHER WATTAGE RATING OF THESE TRANSISTORS WILL IMPROVE INSTRUMENT RELIABILITY.

Page 8-45, Figure 8-18, TABLE OF ACTIVE ELEMENTS:

Change Q1 from 1853-0233 to 1853-0356 and Q2 from 1854-0420 to 1854-0625.

Page 6-16, Table 6-1, A16 (05327-00027) Replaceable Parts:

Change A16XA2 thru XA5, XA8, XA12 thru XA15, and XA18 from 1251-1886 to 1251-2035; Mfr Code to 28480; Mfr Part Number 1251-2035.

Change A16XA6, XA7, XA10, and XA11 from 1251-2134 to 1251-2026; Mfr Code 28480; Mfr Part Number 1251-2026.

Page 6-21, Table 6-2, Replacement Parts, Options:

Change A1C7 and C8 from HP Part Number 0140-0149 to 0160-3533; Mfr Code to 28480; Mfr Part Number to 0160-3533.

CHANGE 1 (1640A) (5327B ONLY)

Page 5-10, Table 5-4, Paragraph 5 Prescaler Adjustments:

Change paragraph 5-g to read as follows: "Reduce output level until counter's display becomes unstable. Alternately adjust A18R3 and A18R53 for a stable display. Repeat procedure until unable to obtain a stable display. Increase signal level until display just becomes stable and make any final adjustments of A18R3 and A18R53."

Page 6-16, Table 6-1, A18 Replaceable Parts (Series 1640):

Add A18C30; 0160-3878; CAPACITOR-FXD 0.01 μ F 20% 100 VDCW CER; 28480; 0160-3878.

Change R18R22 and A18R23 from 0698-4131 (56 ohms) to 0698-3111; RESISTOR-FXD 30 OHM 5% .125W CC; 01121; BB3005.

Change A18R29 and A18R30 from 0698-5103 (430 ohms) to 0698-5177; RESISTOR-FXD 820 OHM 5% .125W CC; 01121; BB8215.

Change A18R34 from 0698-8073 (1600 ohms) to 0698-5178; RESISTOR-FXD 1500 OHMS 5% .125W CC; 01121; BB1525.

Add A18R53; 2100-2633; RESISTOR VAR 1000 OHMS 10% COMP SIDE ADJ; 30983; ET50X102.

Add A18R54 and A18R55; 0698-3374; RESISTOR-FXD 20 OHM 5% .125W CC; 01121; BB2005.

Add A18R56; 0698-6283; RESISTOR-FXD 10 OHMS 5%; .125W CC; 01121; BB1005.

CHANGE 1 (1540A) (5327B ONLY) (Cont'd)

Page 8-49, Figure 8-20, A18 Prescaler Assembly Schematic:

Add A18C30 (.01 μ F) between common and the "+5V" end of A18R34.

Add A18R53 (1000 ohms) variable resistor between +5.2V and -5.2V. Connect junction of A18C30 and A18R34 to arm of A18R53 in place of "+5V" as shown on schematic diagram.

Change value of A18R34 from 1600 to 1500 ohms.

Change A18R22 and A18R23 from 56 to 30 ohms.

Change A18R29 and A18R30 from 430 to 820 ohms.

Add A18R54 (20 ohms) in series between A18U2 pin 11 and the junction of A18R23, A18R30, and A18U3 pin 5.

Add A18R55 (20 ohms) in series between A18U2 pin 14 and the junction of A18R22, A18R29, and A18U3 pin 4.

Add asterisk (*) adjacent to A18R54 and A18R55.

Add A18R56 (10 ohms) in series between A18U1 pin 2 and the junction of A18U2 pin 5 and A18R6.

Change "SERIES" number at top of schematic to "1540".

CHANGE 2 (1544A)

Page 1-5, Table 1-3, Specifications for OPTIONS:

Add to Option 001: 8-digit display. "Part of standard instrument; discontinued as an Option".

Add to Option 003: Digital Output (for numerals and polarity only). "Discontinued as an Option and included as part of the standard instrument."

Delete Option 010 Temperature Compensated Oscillator. This Option is discontinued and is no longer available.

Page 7-1, Options and Manual Changes:

Paragraph 7-14, delete second sentence.

Paragraph 7-18, Add - "Part of Standard Instrument; Discontinued as an Option."

Paragraph 7-22, Add - "Part of Standard Instrument; Discontinued as an Option."

Page 6-9, Table 6-1, A9 Replaceable Parts:

Replace A9 table for 05326-60008 with table for 05226-60025 A9 on page 6-20 of Table 6-2.

Pgs 6-21, Table 6-2:

Add parts for Option 003 as part of standard instrument.

The 5326B/5327B Timer-Counter-DVM is furnished less the RACK MOUNTING KIT described in this manual. If ordered at the same time as the instrument, the RACK MOUNTING KIT described in the manual is available as Option 908 at additional cost. If not ordered with an instrument, the RACK MOUNTING KIT is available under HP Part No. 05326-60046. Disregard any manual references stating the instrument is supplied with a rack mounting kit.

Page 6-18, Table 6-1, Chassis Replaceable Parts:

Change XF1 fuseholder from 1400-0084 to the following recommended replacement for all instruments. Add the following parts on Page 6-18 under CHASSIS PARTS:

XF1; 2110-0465; FUSEHOLDER BAYONET CAP; 75915; 345003-020

XF1; 2110-0470; FUSEHOLDER BODY UL/IEC; 75915; 345003-019

XF1; 2950-0054; NUT FUSEHOLDER MTG 1/2-28; 28480; 2950-0054

CHANGE 3 (1604A FOR 5327B)

Pages 6-16 and 6-17, Table 6-1, A18 (05327-60033) Replaceable Parts:

Change A18 from SERIES 1540 to SERIES 1604.

Add A18R57; 0698-3113; RESISTOR FXD 100 OHM 5% .125W CC; 01121; BB1015.

Page 8-49, Figure 8-20, A18 Schematic Diagram:

Change SERIES 1540 at top of schematic to SERIES 1604.

Add 100 ohm resistor R57 in series with +5V input to pin 10 of SCHMITT TRIGGER A18U3.

CHANGE 4 (1612A)

Page 6-12, Table 6-1, A13 (05326-60017) Replaceable Parts:

Change A13 to SERIES 1612 in "Description" column.

Change A13R8 and A13R9 from 0757-0384 (20 Ω) to 0698-3436; R: FXD FLM 38.3 OHM 1% 1/8W; 28480; 0698-3436, Factory Selected Value.

Add A13R42; R: FXD COMP 100K OHM 5% 1/4W; 01121; CB1045.

NOTE: Some instruments with serial prefixes below 1612A have A13R42 added on circuit board assembly A13.

Page 8-41, Figure 8-16, A13 Schematic Diagram:

Change SERIES, at top of schematic, to 1612.

Change A13R8 and A13R9 from 20 to 38.3 ohms.

Add A13R42 resistor (100K) between the base of A13Q1 and the base of A13Q2.

CHANGE 5 (1620A)

Page 6-6, Table 6-1, A6 (05326-60013) Replacement Parts:

Change A6 series number to 1620.

Change A6C8 from 0160-0153 (.001 UF) to 0160-0289; CAPACITOR-FXD, 1800 PF 10% 200WVDC POLYE; 56289; 292P12292.

Add A6C13; 0180-1735; CAPACITOR-FXD .22 UF 10% 35WVDC TANT; 56289; 150D224X0035A2.

Page 8-21, Figure 8-9, A6 (05326-60013) Schematic Diagram:

Change series number, at top of diagram, from 1132 to 1620.

Change A6C8 from 1000 to 1800 pF.

Add A6C13 capacitor (.22 UF) between circuit board common and junction of A6R12, A6U4B(5), A6CR2 and A6CR3. The positive side of the capacitor goes to the SAMPLE RATE DIVISABLE line from connector pins 10L and the negative side to circuit board common. Add C13 in REFERENCE DESIGNATIONS table.

Pages 6-7 and 6-8, Table 6-1, A7 (05327-60031) Replacement Parts:

Change A7 series number from 1312A to 1620.

Change A7R15 from 0683-1015 (100 Ω) to 0683-3915; RESISTOR; FXD, 390 OHM 5%, .25W CC; 01121; CB 3915.

Change A7R16 from 0683-5115 (510 Ω) to 0683-1525; RESISTOR, FXD, 1500 OHM 5%, .25W CC; 01121; CB 5115.

Page 8-29, Figure 8-10, A7 (05327-60031) Schematic Diagram:

Change series number, at top of schematic, from 1312A to 1620.

Change A7R15 from 100 to 390 ohms.

Change A7R16 from 510 to 1500 ohms.

Pages 6-15 and 6-16, Table 6-1, A17 (05326-60031) Replacement Parts:

NOTE - This change will be found in some instruments with serial prefixes prior to 1620A.

Change A17 from series 1312A to series 1620.

Change A17R21 from 0698-3153 (3830 Ω) to 0757-0933; RESISTOR, FXD, 2400 OHM 2% .125W F TUBULAR; 24546; C4-1/8-TO-2401-G. *FACTORY SELECTED VALUE.

Page 8-47, Figure 8-19, A17 (05326-60031) Schematic Diagram:

Change series number, at top of schematic, from "SERIES 1312A, REV. C" to "SERIES 1620".

Change A17R21 from 3830 to 2400 ohms.

Add asterisk (*) and "NOTE 3" adjacent to A17R21 in schematic.

Add following note to table of "NOTES":

3. RESISTOR A17R21 SELECTED TO SET DC LEVEL OF A17Q4 COLLECTOR BETWEEN -.80V and -.85V. MINIMUM VALUE FOR A17R21 IS 2000 OHMS.

**CHANGE 6 (5320B Serial No. 1020A03730 or higher)
(5327B Serial No. 1020A01351 or higher)**

NOTE – NOT ALL INSTRUMENTS WITH THE ABOVE SERIAL NUMBERS THAT HAVE OPTION 004 EXTENDED REMOTE PROGRAMMING WILL HAVE A SERIES 1020 CIRCUIT BOARD FOR A1.

Page 6-21, Table 6-2, Replaceable Parts for Option 004,
Change A1 (05327-60034) series number from 1224A to 1020.

Add capacitors A1C15, A1C16; 0160-3878; CAPACITORS-FXD 1000PF 20% 100VDC CER;
28480; 0160-3878.

Page 8-55, Figure 8-23, A1 (05327-60018) Schematic Diagram:
Change series number, at top of diagram, to 1020.

Add A1C15 and A1C16 capacitors (1000 pF) to A1 diagram. Connect both capacitors between the A COM line from A1J1(C) in upper right corner, and circuit board common.

Change capacitor listing from C1-14 to C1-16 in table of REFERENCE DESIGNATIONS.

CHANGE 7 (1020A) (5320B/5327B)

Page 6-18, Table 6-1, Chassis Replaceable Parts:
Add the following under CHASSIS PARTS:

XF1; 2110-0564; FUSEHOLDER BODY; 28480; 2110-0564.

XF1; 2110-0565; FUSEHOLDER CAP; 28480; 2110-0565.

XF1; 2110-0569; NUT FUSEHOLDER MTG, PLASTIC HEX; 28480; 2110-0569.

Delete 2110-0465, Fuseholder Cap; 2110-0470, Fuseholder Body; and 2850-0054, Fuseholder Mtg.
Deleting these three parts negates part of Change 2.

Pages 6-11 and 6-12, Table 6-1, A12 (05326-60013) Replaceable Parts:
Change A12 series number from 1048A to 1820.

Delete A12Q1 transistor 1850-0099 and change description to NOT ASSIGNED.

Add A12Q11 and A12Q12; 1854-0071; TRANSISTOR-SI NPN; 28480; 1854-0071.

Add A12R35; 0683-1825; R: FXD 1.8KΩ 5% 1/4W; 01121; CB1825.

Add A12R36; 0683-3925; R: FXD 3.9KΩ 5% 1/4W; 01121; CB3925.

Add A12R37; 0683-1035; R: FXD 10KΩ 5% 1/4W; 01121; CB1035.

Page 8-39, Figure 8-15, A12 (05326-60016) Schematic Diagram:
Change series number at top of diagram from 1048A to 1820.

Delete transistor A12Q1.

Add A12Q11, A12Q12, and resistors A12R35 through A12R37 in place of A12Q1 as shown in the partial diagram in Figure 2.




Figure 2. A12 Voltmeter Input Amplifier Assembly Changes

CHANGE B (1844A)

Page B-6, Table B-1, A4 OSCILLATOR ASSY REPLACEABLE PARTS:

Change A4 from 05326-60002 to 05326-60052; OSCILLATOR ASSY (SERIES 1844); 28480; 05326-60052.

Change A4 components to those given in attached Table 1.

Page B-16, Part of Figure B-7, Component Locator:

Change A4 component locator illustration to the new illustration given in attached Figure 3.

Page B-17, Figure B-7, A4 Schematic Diagram:

Change A4 schematic diagram to the new diagram in attached Figure 4.

Serial Prefix Numbers of 5326B/5327B Counters which have the 05326-60052 oscillators change to 1844A. The 05326-60052 Oscillator Assembly is the recommended replacement for A4 in all 5326B/5327B Instruments.

Table 1. A4 Replaceable Parts – A4 Oscillator Assembly 05326-60052 (Series 1844)

<u>REF. DESIG.</u>	<u>HP PART NO.</u>	<u>DESCRIPTION</u>
A4C1	0121-0059	CAPACITOR-VAR 2-8 PF 350VDCW
A4C2	0160-2257	CAPACITOR-FXD CER 10PF 5% 500VDCW
A4C3	0160-3878	CAPACITOR-FXD CER 1000PF 20% 100VDCW
A4C4	0121-0061	CAPACITOR-VAR CER 5.5-18 PF 350VDCW
A4C5	0160-3879	CAPACITOR-FXD CER 0.01 UF 20% 100VDCW
A4C6	0180-0197	CAPACITOR-FXD TANT 2.2UF 10% 20VDCW
A4C7	0160-0161	CAPACITOR-FXD POLYE 0.01UF 10% 200VDCW
A4L1	9100-2276	COIL-MLD 100UH 10% Q=50
A4Q1	1853-0015	TRANSISTOR-SI PNP FT=600 MHz 200MW
A4Q2	1853-0015	TRANSISTOR-SI PNP FT=600 MHz 200MW
A4R1	0683-3015	RESISTOR-FXD FC 300Ω 5% .25W
A4R2	0683-1525	RESISTOR-FXD FC 1500Ω 5% .25W
A4R3	0683-2715	RESISTOR-FXD FC 270Ω 5% .25W
A4R4	0683-1525	RESISTOR-FXD FC 1500Ω 5% .25W
A4R5	0683-3905	RESISTOR-FXD FC 39 5% .25W
A4R6	0683-1525	RESISTOR-FXD FC 1500Ω 5% .25W
A4R7	0683-5105	RESISTOR-FXD FC 51Ω 5% .25W
A4U1	1820-1224	IC ECL TRIPLE 2-INPUT LINE RCVR MC 10216P
A4Y1	0140-0405	CRYSTAL 10 MHz

CHANGE 9 (1936A)

Page 6-3, Table 6-1, Replaceable Parts:

Change A1 (05326-60047) series number from 1224A to 1936.

Change A151 from 3101-1598 to 3101-2383; SWITCH-SL DP3T MINTR 0.5A 125VAC PC; 28480; 3101-2383.

Change A152 and S3 from 3101-1595 to 3101-2383; SWITCH-SL DP3T MINTR 0.5A 125VAC PC; 28480; 3101-2383.

Change A154 and S7 from 3101-1596 to 3101-2334; SWITCH-SL DPDT MINTR 0.5A 125VAC PC; 28480; 3101-2334.

Change A155 and S6 from 3101-1594 to 3101-2334; SWITCH-SL DPDT MINTR 0.5A 125VAC PC; 28480; 3101-2334.

Page 6-21, Table 6-2, Replaceable Parts (Option 004):

Change A1 (05327-60034) series number from 1620 to 1936.

Change A151 through S3 from 3101-1598 to 3101-2383; SWITCH-SL DP3T MINTR 0.5A 125VAC PC; 28480; 3101-2383.

Change A154, S5, S8, and S9 from 3101-1596 to 3101-2334; SWITCH-SL DPDT MINTR 0.5A 125VAC PC; 28480; 3101-2334.

Page 8-13, Figure 8-5, A1 (05326-60047) Schematic Diagram:

Change A1 series number from 1224 to 1936.

Page 8-55, Figure 8-23, A1 (05327-60034) Schematic Diagram:

Change A1 series number from 1620 to 1936.

NOTE — The above switches are recommended replacements in all 5326B and 5327B counters.

■ **CHANGE 10**

■ Page 1-3, and Page 3-4:

Under "PERIOD AVERAGE" add:

Measurement errors as large as one period may occur due to coherence between the measured signal and the time base. The error can be reduced by averaging over larger samples.




FIGURE 3. 05326-6005 10 MHz OSCILLATOR ASSY (SERIES 1844)




FIGURE 4. A4 (05326-60052) SCHEMATIC DIAGRAM

HP MANUAL CHANGES

MAKE ALL CORRECTIONS IN YOUR MANUAL ACCORDING TO ERRATA.

MANUAL TITLE: 5326B/27B

Check the following table for your instrument serial prefix and make any indicated changes to the manual:

MANUAL PRINTED/ February, 1975

MANUAL PART NO: 05326-90043

*New or revised items.

CHANGE DATE: 14th December 1976

SERIAL PREFIX	MAKE CHANGE	SERIAL PREFIX	MAKE CHANGE	SERIAL PREFIX	MAKE CHANGE
1544U	1	1651U (27B)	1-3		
1645U(5327B only)	1-2				
1651U (27B)	1,3				

ERRATA

Page 6-19, Table 6-1
Add : To internal and other parts:- 05326-0031 Shield : Amplifier

Page 6-15 Table 6-1
Change : A17C5, 7, 10, 13 to part no. 0160-2327 C FXD 1000pF 100V

Page 6-6 Table 6-1
Change : A5C4 to part no. 0160-0179 C FXD 33pF 5%

Page 6-9 Table 6-1
Change : A5C5 to part no. 0160-3070 C FXD 100pF 5%

Page 6-9, Table 6-1
Change : A9R2, 4-9, 11 to part no. 0757-0440 R FXD 7.5K ohm 1% 1/4W

Page 6-6, Table 6-1
Change : A5U1-U4, U6-U8 to part no. 1820-0413 Int. Cct Divider

Page 6-18, Table 6-1
Change : 05326-00032 to 05326-60049 Panel Rear

The 5326B/27B is furnished less the RACK MOUNTING KIT described in the manual. If ordered at the same time as the instrument, the RACK MOUNTING KIT described in the manual is available as Option 908 at additional cost. If not ordered with an instrument, the RACK MOUNTING KIT is available under HP Part No. 05326-60046. Disregard any manual references stating the instrument is supplied with a rack mounting kit.

Page 1-3, Table 1-3, "INTEGRATING DIGITAL VOLTMETER" Accuracy:
Under Zero Offset (10V Range) change $\pm 10.01\%$ to $\pm 0.01\%$

Page 5-10, Table 5-4. Steps 5c and d:
Change : $0.65 \pm .05V$ to $0.9 \pm .05V$ at A18U2(3).
Change : $0.90 \pm .05V$ to $0.8 \pm .05V$ at A18U3(3).

Page 6-13, Table 6-1:
Change : A13R8 and A13R9 from 0757-0398 (75 OHM) to 0757-0384; 20 OHM
FACTORY SELECTED VALUE.

Page 6-15, Table 6-1
Change : A16R7 from 0698-3153 (3830 OHM) to 0698-3155, 4630 OHMS.

Page 6-17, Table 6-1
Change : A18R29, A18R30 from 0698-5177 (820 OHM) to 0698-5103, 430 OHM.
Add : "FACTORY SELECTED VALUE" to description.

Page 6-19, Table 6-1
Change : 1200-0147 to 1200-0081 in "HP Part Number" and "Mfr Part Number" columns and "Qty" to 2.

Page 8-35, Figure 8-13, A16 Schematic:
Disconnect A10Q13 emitter from junction of A10P1(U), A10U6A(2), and A10U3B(4)
Add : A10P1(17), mark "VOLTS FROM XA14(R)", and connect to A10Q13 emitter.

Change SERIES number of A16 circuit board to 1428A on various pages where portions of A16 appear in this manual. This includes the Table of Replaceable Parts.

Page 8-41, Figure 8-16, A13 Schematic:
Change : A13R8 and A13R9 from 75 to 20 ohms.
Change : heading in TRUTH TABLE to read "V2 = OUTPUT OF OP AMP U3(6)" in place of U2(6).

Page 8-44, A15 Component Locator:
Replace with attached Figure 1.

Page 7-2, Paragraph 7-21:
Add the following sentence, "An HP Part No. 05326-00033 adapter plate will also be required for mounting 36-pin remote programming connector J10."

Page 6-17, Table 6-1
Add : A18L3; 05303-80001, 1 COIL, FXD, RF PEAKING, 28480, 05303-80001.
Add : "FACTORY SELECTED" to A18R34 add A18R42 "Description".
With these changes A18 assembly 05327-60033 is "SERIES 1428A"

Page 8-49, Figure 8-20, A18 schematic:
Add : asterisk(*) adjacent to A18R22, A18R23, A18R29, A18R30, and A18R40.
In Table 6-1 for these resistors add "FACTORY SELECTED VALUE" to description.

Add A18L3 in series with A18U3(13) output line. Output circuit trace is cut and one end of A18L3 is connected to the junction of A18U3(13) and A18R34. The other end of A18L3 is connected to the junction of A18R44 and the coil from A18R42.

Change series number at top of A18 schematic diagram to "SERIES 1428A"

Change dc voltages at A18U2(3) from 0.65V to 0.9V and voltage at A18U3(3) from 0.9V to 0.8 volts.

Page 8-57, Figure 8-24, Schematic:
Change : A16R7 from 3830 to 4630 ohms.
Change : SERIES at top of schematic from 1244 to 1428.

Page v, List of Figures and Page 8-53, Figure 8-22:
Change : caption to read "Option 004, J10 Remote Programming Cable Assembly and Option 003, J9 Digital Recorder Cable Connections".

Page 1-4, Table 1-3, Specifications:
Delete : paragraph pertaining to "Short-Term Fluctuation " under "Time Base" heading

Page 8-55, Figure 8-23, Option 004 Schematic:
Add : the following NOTE:

NOTE

SERVICING THIS ASSEMBLY IS ACCOMPLISHED BY REMOVING THE BOARD FROM THE FRONT PANEL AND MATING IT TO THE AMPLIFIER BOARDS, WHICH HAVE BEEN ELEVATED USING TWO 15 PIN EXTENDER BOARDS (HP PART NO. 5060-0049). THIS ALLOWS ACCESS TO BOTH SIDES OF THE ASSEMBLY. RE-ATTACHING GREEN WIRE TO CABLE PT 1 IS NECESSARY TO ALLOW FRONT PANEL CONTROL.

Page 5-5, 4. PULSE OPERATION:

In step a. set LEVEL (A) to "SLIGHTLY +" in place of PRESET
Change : step c to read "Adjust pulse generator for positive output for 10 MHz repetition rate, 15 ms pulse width for 0.3 volts peak-to-peak indication on oscilloscope"

Change : step d to read "Adjust counter LEVEL A control until counter triggers and counts. Check that counter displays the repetition rate, count light flashes, and trigger A lamp is ON. Record on test card".

Model No. 5326/27B

05326-90043

CHANGE 1

Page 1-5, Table 1-3, Specifications for OPTIONS

Add to Option 001: 8 digit display. "Part of standard instrument; discontinued as an Option."

Add to Option 003: Digital Output (for numerals and polarity only).

"Discontinued as an Option and included as part of the standard instrument."

Page 1-5, Table 1-3, Specifications for OPTIONS

Delete Option 010 Temperature Compensated Oscillator. This Option is discontinued and is no longer available.

Page 7-1, Options and Manual Changes:

Paragraph 7-14, Delete second sentence

Paragraph 7-18, Add - "Part of Standard Instrument; Discontinued as an Option"

Paragraph 7-22, Add - "Part of Standard Instrument; Discontinued as an Option".

Page 6-9, Table 6-1, A9 Replaceable Parts:

Replace A9 Table for 05326-60008 with table for 05326-60025 A9 on Page 6-18 of Table 6-2.

Page 6-20, Table 6-2

Add parts for Option 003 as part of standard instrument.

CHANGE 2 (1645U) (5327B ONLY)

Page 5-10, Table 5-4, Paragraph 5 Prescaler Adjustments:

Change paragraph 5-g to read as follows: "Reduce output level until counter's display becomes unstable. Alternately adjust A18R3 and A18R53 for a stable display. Repeat procedure until unable to obtain a stable display. Increase signal level until display just becomes stable and make any final adjustments of A18R3 and A18R53."

Page 6-15, Table 6-1, A18 Replaceable Parts

Change A18R34 from 0698-8073 (1600 Ohms) to 0698-5178; RESISTOR-FXD
1500 OHMS 5% .125W CC

Add A18R53; 2100-2633; RESISTOR VAR 1000 OHMS 10% COMP SIDE ADJ

Add A18R54 and A18R55; 0698-3374; RESISTOR-FXD 20 OHM 5% .125W CC

Add A18R56; 0698-6283; RESISTOR-FXD 10 OHMS 5% .125W CC

Page 6-16, Table 6-1, A18 Replaceable Parts

Add A18C30; 0160-3879; CAPACITOR-FXD 0.01 μ F 20% 100 VDCW CER

Change A18R22 and A18R23 from 0698-4131 (56 ohms) to 0698-3111; RESISTOR-FXD
30 OHM 5% .125W CC

Change A18R29 and A18R30 from 0698-5103 (430 Ohms) to 0698-5177;
RESISTOR-FXD 820 OHM 5% .125W CC

Model No. 5326/27B

05326-90043

Page 6-16 and 6-17, Table 6-1, A18 (05327-60033) Replaceable Parts:
Add A 18R57; 0698-3113; RESISTOR FXD 100 OHM 5% .125W CC

Page 6-21, Table 6-2

Add A1C15; 0160-3878; C Fxd 0.001 μ F 100VDC.

Page 8-49, Figure 8-20, A18 Prescaler Assembly Schematic:

Add A18C30 (0.01 μ F) between common and the "+5V" end of A18R34.

Add A18R53 (1000 Ohms) variable resistor between +5.2V and -5.2V. Connect junction of A18C30 and A18R34 to arm of A18R53 in place of "+5V" as shown on schematic diagram.

Change value of A18R34 from 1600 to 1500 ohms.

Change A18R22 and A18R23 from 56 to 30 ohms.

Change A18R29 and A18R30 from 430 to 820 ohms.

Add A18R54 (20 ohms) in series between A18U2 pin 11 and the junction of A18R23, A18R30 and A18U3 pin 5.

Add A18R55 (20 ohms) in series between A18U2 pin 14 and the junction of A18R22, A18R29, and A18U3 pin 4.

Add asterisk (*) adjacent to A18R54 and A18R55.

Add A18R56 (10 ohms) in series between A18U1 pin 2 and the junction of A18U2 pin 5 and A18R6.

Change "SERIES" number at top of schematic to "1645U".

Add 100 ohm resistor R57 in series with +5V input to pin 10 of SCHMITT TRIGGER A18U3.

*** CHANGE 3

Page 6-6, Table 6-1

Change A6C8 to Part No. 0160-0299 C. FXD 0.0018 μ F 200V.

Add A6C13 Part No. 0180-1735 C. FXD .22 μ F 35V.

Page 6-8, Table 6-1

Change A7R15 to Part No. 0683-3915 R. FXD 390 ohms 5% .25WT.

Change A7R16 to Part No. 0683-1525 R. FXD 1.5Kohms 5% .25WT.

Page 6-15, Table 6-1

Change A16R7 to Part No. 0698-3155 R. FXD 4.63K ohms 1% .125W.

Page 6-16, Table 6-1

Change A17R21* to Part No. 0698-3150 R. FXD 2.37K ohms 1% (now select on test).

Page 8-21, Figure 8-9

Change C8 to 0.0018.

Add C13 (connected pin 5 of U4B to ground).

Page 8-29, Figure 8-10

Change R15 to 380.

Change R16 to 1500.

Model No. 5326/27B

05326-90043

Page 8-47, Figure 8-19

Change R21 to 2370 and asterisk to indicate select a Test.

Change Voltage at collector of Q4 to read 0.80V → 0.85V.

Page 8-57, Figure 8-24

Change R7 to 4630.