


Site Master™

S331D/S332D

Cable and Antenna Analyzer

Site Master is the preferred cable and antenna analyzer of wireless providers, contractors and installers.



Color display option shown

Programming Manual



WARRANTY

The Anritsu product(s) listed on the title page is (are) warranted against defects in materials and workmanship for one year from the date of shipment.

Anritsu's obligation covers repairing or replacing products which prove to be defective during the warranty period. Buyers shall prepay transportation charges for equipment returned to Anritsu for warranty repairs. Obligation is limited to the original purchaser.

Anritsu is not liable for consequential damages.

LIMITATION OF WARRANTY

The foregoing warranty does not apply to Anritsu connectors that have failed due to normal wear. Also, the warranty does not apply to defects resulting from improper or inadequate maintenance by the Buyer, unauthorized modification or misuse, or operation outside the environmental specifications of the product. No other warranty is expressed or implied, and the remedies provided herein are the Buyer's sole and exclusive remedies.

TRADEMARK ACKNOWLEDGEMENTS

Site Master is a trademark of Anritsu Company.

NOTICE

Anritsu Company has prepared this manual for use by Anritsu Company personnel and customers as a guide for the proper installation, operation, and maintenance of Anritsu Company equipment and computer programs. The drawings, specifications, and information contained herein are the property of Anritsu Company, and any unauthorized use or disclosure of these drawings, specifications, and information is prohibited; they shall not be reproduced, copied, or used in whole or in part as the basis for manufacture or sale of the equipment or software programs without the prior written consent of Anritsu Company.

UPDATES

Updates to this manual, if any, may be downloaded from the Anritsu internet site at: <http://www.us.anritsu.com>.

Table of Contents

PROGRAMMING OVERVIEW	5
GENERAL DESCRIPTION	5
CABLING	5
SERIAL COMMUNICATION PARAMETERS	5
COMMUNICATIONS ERROR CHECKING	5
PARAMETER VALIDATION	5
ENTERING REMOTE MODE	6
EXITING REMOTE MODE	6
LIFETIME OF CHANGES TO SITE MASTER OPERATING PARAMETERS	6
WRITE CYCLE LIMITATION OF EEPROM	6
DOCUMENTATION CONVENTIONS	6
<i>Numeric Representation:</i>	6
<i>Bit Positions:</i>	6
CONTROL BYTE DESCRIPTIONS	7
SETUP SYSTEM – CONTROL BYTE #1 (01H)	7
SET SITE MASTER VNA FREQUENCY – CONTROL BYTE #2 (02H)	7
SELECT MEASUREMENT MODE – CONTROL BYTE #3 (03H)	8
SET CELL MASTER VNA SCALE – CONTROL BYTE #4 (04H)	8
SET SITE MASTER VNA MARKER – CONTROL BYTE #5 (05H)	9
SET SITE MASTER VNA SINGLE LIMIT – CONTROL BYTE #6 (06H)	10
SET DTF PARAMETER – CONTROL BYTE #7 (07H)	10
SET TIME/DATE – CONTROL BYTE #8 (08H)	11
SET TRACE NAME (REFERENCE NUMBER) – CONTROL BYTE #9 (09H)	12
SERIAL PORT ECHO ON/OFF – CONTROL BYTE #10 (0AH)	12
SITE MASTER VNA SINGLE SWEEP MODE ON/OFF – CONTROL BYTE #11 (0BH)	12
WATCH-DOG TIMER ON/OFF – CONTROL BYTE #12 (0CH)	13
SEQUENCE SITE MASTER CALIBRATION – CONTROL BYTE #13 (0DH)	13
SET SITE MASTER VNA DATA POINTS – CONTROL BYTE #14 (0EH)	14
SET SITE MASTER CALIBRATION MODE – CONTROL BYTE #15 (0FH)	14
STORE SWEEP TRACE – CONTROL BYTE #16 (10H)	14
OBSOLETE: RECALL SWEEP TRACE – CONTROL BYTE #17 (11H)	15
SAVE SYSTEM SETUP – CONTROL BYTE #18 (12H)	22
RECALL SYSTEM SETUP – CONTROL BYTE #19 (13H)	23
OBSOLETE: QUERY SYSTEM STATUS – CONTROL BYTE #20 (14H)	23
TRIGGER SELF-TEST – CONTROL BYTE #21 (15H)	30
READ FAIL COUNTER – CONTROL BYTE #22 (16H)	30
CLEAR FAIL COUNTERS – CONTROL BYTE #23 (17H)	31
QUERY TRACE NAMES – CONTROL BYTE #24 (18H)	31
DELETE SWEEP TRACE – CONTROL BYTE #25 (19H)	31
OBSOLETE: UPLOAD SPA SWEEP TRACE – CONTROL BYTE #26 (1AH)	31
QUERY SWEEP MEMORY – CONTROL BYTE #27 (1BH)	35
OBSOLETE: UPLOAD SITE MASTER SWEEP TRACE – CONTROL BYTE #28 (1CH)	35
QUERY SYSTEM STATUS – CONTROL BYTE #29 (1DH)	38
SELECT PRINTER TYPE – CONTROL BYTE #30 (1EH)	49
SELECT DTF WINDOWING – CONTROL BYTE #31 (1FH)	50
SET SITE MASTER VNA TRACE MATH – CONTROL BYTE #32 (20H)	50
RECALL SWEEP TRACE – CONTROL BYTE #33 (21H)	51
SET SITE MASTER VNA TRACE OVERLAY – CONTROL BYTE #34 (22H)	66
SET SPA A/B TRACE – CONTROL BYTE #35 (23H)	66
UPLOAD SWEEP TRACE – CONTROL BYTE #36 (24H)	66
GET OPTIONS – CONTROL BYTE #37 (25H)	80
QUERY POWER LEVEL – CONTROL BYTE #39 (27H)	80

SET POWER METER UNITS – CONTROL BYTE #40 (28H)	81
POWER METER RELATIVE MODE ON/OFF – CONTROL BYTE #41 (29H).....	81
POWER METER OFFSET MODE ON/OFF – CONTROL BYTE #42 (2AH).....	81
POWER METER ZERO MODE ON/OFF – CONTROL BYTE #43 (2BH)	82
POWER METER RMS AVERAGING ON/OFF – CONTROL BYTE #44 (2CH)	82
POWER METER CENTER FREQUENCY AND SPAN SETUP – CONTROL BYTE #45 (2DH)	82
TRIGGER SWEEP – CONTROL BYTE #48 (30H).....	83
TRIGGER SWEEP – CONTROL WORD (AA30H)	83
SWEEP DATA ECHO ON/OFF – CONTROL BYTE #49 (31H)	83
CHECK BATTERY STATUS – CONTROL BYTE #50 (32H)	84
SET SPA MINIMUM SWEEP TIME – CONTROL BYTE #53 (35H)	84
SET TRIGGER POSITION – CONTROL BYTE #54 (36H).....	85
SET VIDEO TRIGGER LEVEL – CONTROL BYTE #55 (37H).....	85
AUTOMATICALLY SAVE RUNTIME SETUP – CONTROL BYTE #64 (40H)	85
DOWNLOAD SAVED SETUP – CONTROL BYTE #65 (41H).....	86
UPLOAD SETUP – CONTROL BYTE #66 (42H)	100
READ PARAMETER LIMITS – CONTROL BYTE #67 (43H)	115
QUERY SAVED SETUPS – CONTROL BYTE #68 (44H).....	126
ENTER REMOTE MODE – CONTROL BYTE #69 (45H).....	127
ENTER REMOTE MODE IMMEDIATELY – CONTROL BYTE #70 (46H)	128
WRITE PROTECT SETUP – CONTROL BYTE #71 (47H).....	128
CLEAR SETUP MEMORY LOCATION – CONTROL BYTE #72 (48H).....	129
WRITE SIGNAL STANDARDS – CONTROL BYTE #78 (4EH)	129
RECALL SIGNAL STANDARDS – CONTROL BYTE #79 (4FH).....	130
WRITE CUSTOM CABLE – CONTROL BYTE #80 (50H).....	130
RECALL CUSTOM CABLE – CONTROL BYTE #81 (51H).....	131
WRITE ANTENNA – CONTROL BYTE #82 (52H)	131
RECALL ANTENNA – CONTROL BYTE #83 (53H)	132
SET FIELD STRENGTH MEASUREMENT – CONTROL BYTE #84 (54H).....	132
SET CHANNEL POWER – CONTROL BYTE #85 (55H).....	133
READ CHANNEL POWER – CONTROL BYTE #86 (56H).....	133
SET ADJACENT CHANNEL POWER RATIO (ACPR) – CONTROL BYTE #87 (57H)	134
READ ADJACENT CHANNEL POWER (ACPR) – CONTROL BYTE #88 (58H)	134
READ SIGNAL STANDARD NAME – CONTROL BYTE #89 (59H).....	135
MEASURE OCC BW % OF POWER – CONTROL BYTE #96 (60H)	135
MEASURE OCC BW dB DOWN – CONTROL BYTE #97 (61H).....	135
SET BIAS TEE FUNCTION - CONTROL BYTE #98 (62H)	136
SET SPECTRUM ANALYZER START/STOP FREQUENCY – CONTROL BYTE #99 (63H)	136
SET SPECTRUM ANALYZER CENTER FREQ./SPAN – CONTROL BYTE #100 (64H).....	137
SET SPECTRUM ANALYZER SCALE – CONTROL BYTE #101 (65H).....	137
SET SPECTRUM ANALYZER MARKER – CONTROL BYTE #102 (66H)	137
SET SPECTRUM ANALYZER SINGLE LIMIT – CONTROL BYTE #103 (67H).....	138
SET SPECTRUM ANALYZER PEAK HOLD – CONTROL BYTE #105 (69H).....	138
OBSOLETE: SET SPECTRUM ANALYZER RESOLUTION BANDWIDTH – CONTROL BYTE #106 (6AH)	138
OBSOLETE: SET SPECTRUM ANALYZER VIDEO BANDWIDTH – CONTROL BYTE #107 (6BH).....	139
SET SPECTRUM ANALYZER SWEEP MODE – CONTROL BYTE #108 (6CH)	139
SET SPECTRUM ANALYZER MARKER TO PEAK – CONTROL BYTE #109 (6DH).....	140
SET SPECTRUM ANALYZER MARKER TO CENTER – CONTROL BYTE #110 (6EH)	140
OBSOLETE: SET SPECTRUM ANALYZER ATTENUATION – CONTROL BYTE #111 (6FH)	140
SET SITE MASTER VNA SEGMENTED LIMIT LINES – CONTROL BYTE #112 (70H)	140
SET SPECTRUM ANALYZER MULTIPLE LIMIT – CONTROL BYTE #113 (71H).....	141
SET RETURN SPECTRUM ANALYZER SWEEP TIME – CONTROL BYTE #114 (72H).....	142
SET REFERENCE LEVEL OFFSET – CONTROL BYTE #115 (73H)	143
SET SPECTRUM ANALYZER IMPEDANCE – CONTROL BYTE #116 (74H).....	143
READ MARKER VALUE – CONTROL BYTE #117 (75H)	143
SET SWEEP AVERAGING – CONTROL BYTE #118 (76H).....	144

FIELD INSTACAL – CONTROL BYTE #120 (78H)	144
READ INSTACAL MODULE ASCII SERIAL NUMBER – CONTROL BYTE #124 (7CH)	145
SET SITE MASTER MARKER (PEAK/VALLEY) – CONTROL BYTE #129 (81H)	145
SET / RESET SPECTRUM ANALYZER EXTERNAL REFERENCE – CONTROL BYTE #133 (85H)	145
CHECK SPECTRUM ANALYZER EXTERNAL REFERENCE – CONTROL BYTE #134 (86H)	146
SET SA PREAMP STATE (ON/OFF/AUTO) – CONTROL BYTE #136 (88H)	146
SET SPECTRUM ANALYZER UNITS – CONTROL BYTE #140 (8CH)	146
SET SPECTRUM ANALYZER RESOLUTION BANDWIDTH – CONTROL BYTE #141 (8DH)	147
SET SPECTRUM ANALYZER VIDEO BANDWIDTH – CONTROL BYTE #142 (8EH)	147
SET SPECTRUM ANALYZER ATTENUATION – CONTROL BYTE #143 (8FH)	147
SET AM/FM DEMODULATION – CONTROL BYTE #145 (91H)	148
SET BAUD RATE – CONTROL BYTE #197 (C5H)	149
SET LANGUAGE – CONTROL BYTE #198 (C6H)	149
QUERY TIME – CONTROL BYTE #208 (D0H)	149
READ MAIN SERIAL NUMBER – CONTROL BYTE #221 (DDH)	149
READ ASCII SERIAL NUMBER – CONTROL BYTE #225 (E1H)	150
GPS POWER – CONTROL BYTE #237 (EDH)	150
READ GPS POSITION – CONTROL BYTE #238 (EEH)	150
AUTOMATIC CAL DISABLE – CONTROL BYTE #241 (F1H)	151
INSTACAL MODULE CHARACTERIZATION – CONTROL BYTE #242 (F2H)	151
RECALL SWEEP TRACE – CONTROL BYTE #243 (F3H)	151
SET SITE MASTER VNA EXTENDED FREQUENCY – CONTROL BYTE #244 (F4H)	152
EXIT REMOTE MODE – CONTROL BYTE #255 (FFH)	152
SET T1 TRANSMISSION LEVEL – CONTROL WORD (A001H)	153
SET T1/E1 CLOCK SOURCE – CONTROL WORD (A002H)	153
SET T1/E1 PATTERN – CONTROL WORD (A003H)	153
SET T1/E1 ERROR INSERT TYPE/VALUE – CONTROL WORD (A004H)	154
SET T1/E1 FRAMING MODE – CONTROL WORD (A005H)	154
START AND STOP T1/E1 MEASUREMENT – CONTROL WORD (A006H)	155
INSERT ERROR FOR T1/E1 MEASUREMENT – CONTROL WORD (A007H)	155
GET T1/E1 PATTERN – CONTROL WORD (A008H)	155
GET T1/E1 FRAME SYNC STATUS – CONTROL WORD (A009H)	155
GET T1/E1 PATTERN SYNC STATUS – CONTROL WORD (A00AH)	156
GET T1/E1 CARRIER STATUS – CONTROL WORD (A00BH)	156
GET T1/E1 ERROR TYPE AND NUMBER – CONTROL WORD (A00CH)	156
SET T1/E1 LINE CODING OPTIONS – CONTROL WORD (A00DH)	157
SET E1 IMPEDANCE OPTIONS – CONTROL WORD (A00EH)	157
READ T1/E1 VOLTS PEAK-TO-PEAK – CONTROL WORD (A00FH)	158
SET T1/E1 RECEIVE INPUT CONFIGURATION OPTIONS – CONTROL WORD (A013H)	158
SET T1/E1 MEASUREMENT DURATION – CONTROL WORD (A014H)	158
SET T1/E1 DATA LOGGING – CONTROL WORD (A015H)	159
READ T1/E1 dBDSX – CONTROL WORD (A016H)	159
READ T1/E1 FREQUENCY – CONTROL WORD (A017H)	159
READ T1/E1 FREQUENCY CAL – CONTROL WORD (A018H)	160
SET T1/E1 FREQUENCY CAL – CONTROL WORD (A019H)	160
CONFIGURE DS0/E0 CHANNEL TESTS – CONTROL WORD (A01AH)	160
READ DS0/E0 LEVEL AND FREQUENCY – CONTROL WORD (A01BH)	160
SET DS0/E0 LEVEL AND FREQUENCY – CONTROL WORD (A01CH)	161
SELECT SPA/POWER METER SIGNAL STANDARD – CONTROL WORD (A103H)	161
SELECT SPA/POWER METER CHANNEL – CONTROL WORD (A104H)	161
READ EXTERNAL MODULE NAME – CONTROL WORD (A201H)	161
READ EXTERNAL MODULE SERIAL NUMBER – CONTROL WORD (A202H)	162
READ EXTERNAL MODULE FREQUENCY RANGE – CONTROL WORD (A203H)	162
READ MODULE FAIL COUNTER – CONTROL WORD (A204H)	163
CLEAR MODULE FAIL COUNTER – CONTROL WORD (A205H)	163
PERFORM TRANSMISSION MODE CALIBRATION – CONTROL WORD (A301H)	163

TURN OFF TRANSMISSION MODE CALIBRATION – CONTROL WORD (A302H)	164
GET SIGNAL STANDARD NAME – CONTROL WORD (A501H)	164
SET SIGNAL STANDARD LINK DIRECTION – CONTROL WORD (A502H)	164
PERFORM NOISE DIODE CAL – CONTROL WORD (A505H)	164
SET BIAS T VOLTAGE – CONTROL WORD (A506H).....	164
SELECT FUNCTION IN IA MEASUREMENT MODE – CONTROL WORD (A700H)	165
SPECTROGRAM: SET SWEEP INTERVAL – CONTROL WORD (A721H).....	165
SPECTROGRAM: SET TIME SPAN OF MEASUREMENT – CONTROL WORD (A722H)	165
SPECTROGRAM: TURN ON/OFF AUTO SAVE – CONTROL WORD (A723H)	166
SPECTROGRAM: GET TRACE NAME – CONTROL WORD (A724H)	166
SPECTROGRAM: RECALL TRACE – CONTROL WORD (A725H).....	166
REMOTE SELF TEST – CONTROL WORD (AA15H)	167
PARAMETER DEFINITIONS	171
PROGRAMMING EXAMPLES.....	172
EXAMPLES IN C:	172
EXAMPLE IN VISUAL BASIC.....	178
SIGNAL STANDARDS	180

Programming Overview

Warning: The Anritsu Site Master Serial Port Commands are not backward compatible with earlier Site Master Models.

This programming menu is written exclusively for Anritsu Site Master model S331D, S332D, S311D, and S312D. It is intended for firmware 5.00 and above. For information on firmware upgrade, please contact your local Anritsu service center.

General Description

The Site Master must first be set into “remote” mode for communication with a computer. Remote mode differs from normal repetitive sweep and single-sweep modes. During remote mode, the Site Master suspends normal operations and attends to the serial port. The front panel display indicates when the Site Master is in remote mode.

Once in remote mode, you send a series of control bytes and associated data to the Site Master. These control byte sequences command the Site Master to perform various functions and activities. The serial port supports virtually all features accessible from the keypad. The only exception is the printer, which requires connection to the same 9 pin connector on the Site Master rear panel.

To complete the communication session, send the control byte to exit remote mode. Site Master resumes normal operations. You may also exit the remote mode by using the ESCAPE/CLEAR key.

Cabling

Serial communications take place via the 9 pin connector on the back of the Site Master. The Site Master is a DTE-type serial device and therefore requires a “null modem” cable for communication with a computer, which is also a DTE device. We provide a suitable cable with your Site Master. (Anritsu part number 800-441)

Serial Communication Parameters

When turned on, the Site Master communicates at a default baud rate of 9600. It uses no parity bits, 8 data bits, and 1 stop bit (N-8-1). No hardware handshaking is used. The Set Baud Rate serial command Control Byte #197 (C5h) can be used to change the baud rate to other common baud rates. It can be reset by turning the Cell Master off.

Communications Error Checking

Since there is no hardware handshaking, byte level error handling must be done by the controlling program. The expected number of response bytes for each control byte (listed in the control byte description section of this manual) works well for responses coming from the Site Master. For data streams going to the Site Master, the “watch dog timer” protects against interrupted transmissions by aborting a control byte sequence if the inter-byte time limit is exceeded.

Parameter Validation

The Site Master validates input parameters for each control byte sequence. If the input parameters are out of range or invalid, the Site Master notifies the computer by sending Parameter Error Byte #224 (E0h). The Site Master discards the received data and waits for the next control byte.

Entering Remote Mode

Send the Enter Remote Mode Byte #69 (45h) to the Site Master to enter remote mode at the end of a sweep. Send the Enter Remote Mode Immediately byte #70 (46h) to enter remote mode in the middle of a sweep.

The Site Master's serial port buffer is one byte wide. No internal buffer exists, so waiting for the unit's response is essential. If the Site Master is not in remote, sending a second byte overwrites the original byte commanding it to go into remote. If you send control byte #69, you must wait until the end of the sweep. If you send control byte #70, the unit will enter remote mode as soon as it receives the byte. Note that this means that data stored for the current sweep may be incomplete.

Once you receive the response string from Site Master, you are in remote mode.

Exiting Remote Mode

Send the Exit Remote control byte #255 (FFh) to the Site Master. Site Master sends a response byte of 255 (FFh) then exits remote mode. Remote mode can also be exited by pressing the ESCAPE/CLEAR key.

Lifetime of Changes to Site Master Operating Parameters

System parameters changed during remote mode remain changed for normal operation. They are not automatically written to the non-volatile EEPROM. Turning off power erases the changed settings.

If you want the changes saved, you must save the change to one of the setup memories. Use either the run-time setup (location 0, which holds the power-on defaults) or one of the nine saved setups. See control byte #18 (12h) for details.

Write Cycle Limitation of EEPROM

The EEPROM, used to store calibrations, setups and traces has a guaranteed lifetime of at least 100,000 write cycles and an unlimited number of read cycles. The write cycle limitation is for a specific location. For example, you can store setup #1 100,000 times and setup #2 100,000 times, etc.

It is for this reason we do not automatically store the changed system parameters to EEPROM. Instead, we provide a means of changing the operating parameters independent of this limitation.

Be aware of the EEPROM write cycle limitation when programming the Site Master. Keep the number of write cycles to a minimum.

Documentation Conventions

Through this manual the following conventions will be observed:

Numeric Representation:

Hexadecimal numbers are represented with the suffix h. For example, the decimal number 255 is represented in hexadecimal as FFh.

Binary numbers are represented with the suffix b. For example, the decimal number 2 is represented in binary as 10b.

Decimal numbers are represented with the prefix # when referring to a control byte (command byte) and without a prefix or suffix in all other cases.

Bit Positions:

When enumerating bits in a byte, bit 0 will always be the least significant bit (LSB).

Control Byte Descriptions

Setup System – Control Byte #1 (01h)

Description: Sets system status flags and switches. The current value of the flags can be obtained by executing command #29, Query System Setup, and parsing the values from the appropriate bytes. The Site Master acts on the entire byte. So, the state of each of the bits must be defined every time the command is issued. See control byte #29 (1Dh) response bytes 170 (VNA modes) and 275 and 276 (Spectrum Analyzer mode) for current Site Master configuration.

Bytes to Follow: 2 bytes

1) Status Byte 1

bit 0: Fixed CW Mode On/Off (1b = On, 0b = Off)

bit 1: Not Used

bit 2: LCD Back Light On/Off (1b = On, 0b = Off)

bit 3: Measurement Unit Metric/English (0b = English, 1b = Metric)¹

bits 4-7: Not Used

2) Status Byte 2

bit 0: RBW Coupling (to span) (1b = Auto 0b = Manual)

bit 1: VBW Coupling (to RBW) (1b = Auto 0b = Manual)

bit 2: Not Used

bits 3-4: Logarithmic Amplitude Units (00b = dBm 01b = dBV 10b = dBmV 11b = dBuV)

bits 5-6: Detection Algorithm (00b = Positive Peak 01b = RMS Average

10b = Negative Peak 11b = Sampling Mode)

bit 7: Attenuation Coupling (to ref level) (1b = Auto 0b = Manual)

Site Master Returns: 1 byte

1) 255 (FFh) Operation Complete Byte

238 (EEh) Time-out Error

Set Site Master VNA Frequency – Control Byte #2 (02h)

Description: Sets the Site Master frequency range. Start and stop frequencies are given in terms of 1 Hz steps. (e.g. 1000.3 MHz would be sent as 1000300000 = 1,000,300,000 Hz.)

Valid range is 25 MHz – 4000 MHz.

Low end is extended to 2 MHz with option 2; and high end is extended to 6000 MHz with option 16.

See control byte #29 (1Dh) response bytes 28 to 35 for current Site Master start and stop frequencies.

This command handles frequency up to 4 GHz. If option 16 is present, then higher frequency can be entered using the command Set Site Master VNA Extended Frequency whose control byte is #244 (F4h).

Bytes to Follow: 8 bytes

1) Start Frequency (Highest byte)

2) Start Frequency

3) Start Frequency

4) Start Frequency (Lowest byte)

5) Stop Frequency (Highest byte)

6) Stop Frequency

7) Stop Frequency

8) Stop Frequency (Lowest byte)

¹ Set the Metric/English flag to the proper value before sending distance information.

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error : Invalid frequency range
 - 238 (EEh) Time-out Error
-

Select Measurement Mode – Control Byte #3 (03h)

Description: Sets the measurement mode of the Site Master. The response byte will not be sent until the mode change is complete.

See control byte #29 (1Dh) response byte 3 for the current Site Master measurement mode.

Bytes to Follow: 1 byte

- 1) Measurement Mode
 - 00h: RL Frequency
 - 01h: SWR Frequency
 - 02h: Cable Loss Frequency
 - 10h: RL Distance
 - 11h: SWR Distance
 - 30h: Spectrum Analyzer Mode
 - 31h: Transmission Mode
 - 39h: Channel Scanner Mode
 - 3Bh: Interference Analyzer Mode
 - 3Ch: CW Signal Generator Mode
 - 40h: Power Monitor Mode (Option 29 Only)
 - 41h: Power Monitor Mode (Option 5)
 - 42h: High Accuracy Power Meter Mode
 - 60h: T1 Tester Mode (Option 50 Only)
 - 70h: E1 Tester Mode (Option 50 Only)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error : Invalid measurement mode
 - 238 (EEh) Time-out Error:
-

Set Cell Master VNA Scale – Control Byte #4 (04h)

Description: Sets the top and bottom value of current measurement mode.

Return Loss:

Unit is dB/1000.

Maximum value sent is 60000 which represents 60.00 dB,

Minimum value sent is 0 which represent 0.00 dB,

SWR:

Unit is 1/1000 (of ratio)

Maximum value sent is 65530 which represents 65.50

Minimum value sent is 1000 which represents 1.00

Cable Loss:

Unit is dB/1000.

Maximum value sent is 30000 which represents 30.00 dB,

Minimum value sent is 0 which represent 0.00 dB,

See control byte #29 (1Dh) response bytes 36 to 43 for current Cell Master scaling.

Bytes to Follow: 8 bytes

- 1) Scale Start (Highest byte)
- 2) Scale Start
- 3) Scale Start
- 4) Scale Start (Lowest byte)
- 5) Scale Stop (Highest byte)
- 6) Scale Stop
- 7) Scale Stop
- 8) Scale Stop (Lowest byte)

Cell Master Returns: 1 byte

- 255 (FFh): Operation Complete Byte
 - 224 (E0h): Parameter Error - Invalid scale range
 - 238 (EEh): Time-out Error
-

Set Site Master VNA Marker – Control Byte #5 (05h)

Description: Sets an individual marker position and status in the current measurement mode.

The Site Master sets the position of a marker by its relative position on the graph. The lowest position is 0 at the start frequency (or distance). The highest position is the data point number at the stop frequency (or distance). For example, for a resolution of 130, the first frequency is at position 0. The last frequency is at 129.

To calculate the data point from a frequency (or distance) do the following:

point = (resolution – 1) * (marker freq – start freq) / (stop freq – start freq)

See control byte #29 (1Dh) response bytes 44 to 55 for current frequency markers.

See control byte #29 (1Dh) response bytes 138 to 149 for current distance markers.

See control byte #29 (1Dh) response byte 162 for current marker on/off status.

Bytes to Follow: 5 bytes

- 1) Marker Number (01h = marker 1, 02h = marker 2, 03h = marker 3, 04h = marker 4, 05h = marker 5, 06h = marker 6)
- 2) Marker Line On/Off (01h = On, 00h = Off)
- 3) Marker Delta On/Off (01h = On, 00h = Off) ²
- 4) Marker Value (Higher byte)
- 5) Marker Value (Lower byte)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error : Invalid marker, marker status, or marker position
 - 238 (EEh) Time-out Error
-

² This byte is not applicable for markers 5 and 6. It will be ignored by the Site Master.

Set Site Master VNA Single Limit – Control Byte #6 (06h)

Description: Sets the position and On/Off Status of the Single Limit Line for the VNA modes. See control byte #103 to set the single limit for the spectrum analyzer mode.

The single limit is a single, horizontal line. It can be set to On/Off in any Site Master mode. If Limit Beep is set to ON, the Site Master will give an error beep when sweep data appears above the limit line in SWR or Return Loss mode, or when sweep data appears below the limit line in Cable Loss mode.

The single limit and multiple limit types are mutually exclusive. That is, setting the single limit ON automatically turns multiple limit lines OFF. See control byte #112 (70h) for information about multiple limits.

See control byte #29 (1Dh) response bytes 56-59, and byte 164 for current Site Master configuration.

Bytes to Follow: 6 bytes

- 1) Limit Line On/Off (01h = On, 00h = Off)
- 2) Beep at Limit On/Off (01h = On, 00h = Off)
- 3) Limit Value (Highest byte)
- 4) Limit Value
- 5) Limit Value
- 6) Limit Value (Lowest byte)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
224 (E0h) Parameter Error : Invalid limit status, limit beep status, or limit value
238 (EEh) Time-out Error

Notes:

Return Loss & Cable Loss:

- Limit should be sent as (dB * 1000)
- Maximum value sent is 60000 which represents 60.00 dB
- Minimum value sent is 0 which represents 0.0 dB

SWR:

- Limit is in **thousandths** (of ratio), so it should be sent as (ratio * 1000)
- Maximum value sent is 65530 which represents 65.53
- Minimum value sent is 1000 which represents 1.00

Set DTF Parameter – Control Byte #7 (07h)

Description: Sets Distance to Fault parameters.

Be aware using this control byte. The distance to fault parameters are all inter-related. Consequently, the control byte must change all of those parameters at the same time to properly set them.

Please refer to the Site Master User's Guide for a detailed explanation of the factors influencing proper selection of DTF parameters.

Give Start & Stop Distances in hundred-thousandths of meter or foot (12.34 m would be sent as 1234000)

Relative Propagation Velocity is in hundred-thousandths (a Relative Propagation Velocity of 0.850 will be sent as 85000)

Cable Loss is in hundred-thousandths of dB/m or dB/ft (-0.345 dB/m would be sent as 34500)

See control byte #29 (1Dh) response bytes 130-137 (Distance), 150-157 (Propagation Velocity & Cable Loss) for current Site Master configuration.

Bytes to Follow: 16 bytes

- 1) Start Distance (Highest byte)
- 2) Start Distance
- 3) Start Distance
- 4) Start Distance (Lowest byte)
- 5) Stop Distance (Highest byte)
- 6) Stop Distance
- 7) Stop Distance
- 8) Stop Distance (Lowest byte)
- 9) Relative Propagation Velocity (Highest byte)
- 10) Relative Propagation Velocity
- 11) Relative Propagation Velocity
- 12) Relative Propagation Velocity (Lowest byte)
- 13) Cable Loss (Highest byte)
- 14) Cable Loss
- 15) Cable Loss
- 16) Cable Loss (Lowest byte)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
- 224 (E0h) Parameter Error : Parameter(s) out of range
- 238 (EEh) Time-out Error
- 254 (FEh): Internal Error

Set Time/Date – Control Byte #8 (08h)

Description: Sets the current time and date.

This Time/Date is stamped into all stored sweeps (for users' reference).

The Site Master stores bytes as ASCII text. Recommended time form is “hh:mm:ss” (hour:minute:sec).

Recommended date format is “mm/dd/yyyy” (month/day/year).

The current time setting can be found by using control byte #33 to recall trace 0 and examining response bytes 31-38.

The current date setting can be found by using control byte #33 to recall trace 0 and examining response bytes 21-30.

Bytes to Follow: 7 bytes

- 1) Hour
- 2) Minute
- 3) Month
- 4) Day
- 5) Year (Highest byte)
- 6) ear (Lowest byte)
- 7) Daylight Saving (01h = On, 00h = Off)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
- 238 (EEh) Time-out Error

Set Trace Name (Reference Number) – Control Byte #9 (09h)

Description: Stores a Reference Number with the sweep trace.

The reference number is also known as the trace name. It is any combination of 16 letters, numbers and the characters “-“, “;“, “.” and “+”. This command stores a trace name with the sweep trace.

The current reference number is found by recalling trace 0 and examining response bytes 39 to 54.

Bytes to Follow: 16 bytes (ASCII text string)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
- 238 (EEh) Time-out Error

Serial Port Echo On/Off – Control Byte #10 (0Ah)

Description: Sets the serial port echo mode On/Off.

Serial Port Echo Mode uses the **single sweep** mode (see control byte #11 (0Bh)). At the end of each sweep cycle, the Site Master sends a Sweep Complete Byte #192 (C0h) to the serial port.

This mode activates once the Site Master exits from the remote mode. Serial Port Echo status can't be saved to or recalled from saved setups. Cycling power resets the Serial port echo status to Off.

The Serial Port Echo Mode allows run-time handshaking between the Site Master and computer by doing the following:

- 1) Enter remote mode. Set Serial Port Echo Mode On. Exit remote mode.
- 2) The Site Master sweeps once and then sends the Sweep Complete Byte.
- 3) After you receive it. Enter remote mode. Recall sweep 0 (last sweep trace in RAM).
- 4) Exit remote mode. Send Sweep Triggering Byte #48 (30h) and wait for the next sweep cycle.
- 5) Repeat steps 2-4

Bytes to Follow: 1 byte

- 1) Serial Port Echo Status
- 00h : Off
- 01h : On

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
- 224 (E0h) Parameter Error : Invalid serial port echo status
- 238 (EEh) Time-out Error

Site Master VNA Single Sweep Mode On/Off – Control Byte #11 (0Bh)

Description: Enables or disables the Single Sweep Mode during Site Master VNA modes of operation. For Single Sweep Mode during the Spectrum Analyzer mode of operation see control byte #108 (6Ch)

Single Sweep Mode activates once the Site Master exits from the remote mode.

When the Site Master returns to local mode, the Site Master stops sweeping, waits for either the Run/Hold Key of the Site Master keypad or triggering byte #48 (30h).

Site Master also checks for the Enter Remote byte #69 (45h) at the end of each sweep. If present in the buffer, Site Master returns to remote mode.

Bytes to Follow: 1 byte

- 1) Single Sweep Mode Status
 - 00h : Off
 - 01h : On

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error : Invalid single sweep mode status
 - 224 (E0h) Incompatible Measurement Mode (i.e. Spectrum Analyzer)
 - 238 (EEh) Time-out Error
-

Watch-Dog Timer On/Off – Control Byte #12 (0Ch)

Description: Enables or disables the Watch-dog timer. Default is Disabled.

The Site Master incorporates a watch-dog timer for higher reliability in serial communication. In selected control bytes (see control byte summary), the Site Master checks for the time interval between each byte received from the computer. If the time interval exceeds the set time limit (0.5 sec), the Site Master notifies the computer by sending Time-out Byte #238 (EEh). The Site Master discards the data it just received and then waits for the next control byte sequence.

Bytes to Follow: 1 byte

- 1) Watch-dog timer On/Off
 - 00h = Off
 - 01h = On

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error : Invalid watch-dog timer status
-

Sequence Site Master Calibration – Control Byte #13 (0Dh)

Description: Initiates a calibration step.

The Site Master must be calibrated to give accurate measurements.

The command sequence must be sent in correct order. i.e. Open -> Short -> Load. You can also abort the calibration by command – “Abort” before the command - “Load” is sent. Once command - “Load” is sent, calibration is completed, and the old calibration data is lost.

This command is designed to be executed step by step: open, short, load. Issuing any other command during this command sequence will cause undesired results.

Bytes to Follow: 1 byte

- 1) Calibration Step to trigger
 - 01h = Open
 - 02h = Short
 - 03h = Load
 - 04h = Not Used
 - 05h = Abort

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
- 224 (E0h) Error : Invalid Cal operation or Cal Incomplete
- 238 (EEh) Time-out Error

- 2) 240 (F0h): Calibration Step Complete Byte³
-

Set Site Master VNA Data Points – Control Byte #14 (0Eh)

Description: Set number of measurement data points for Site Master VNA modes.

Bytes to Follow: 1 byte

- 1) Number of Data Points
 - 00h = 130 Points
 - 01h = 259 Points
 - 02h = 517 Points

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error : Invalid number of data points
 - 238 (EEh) Time-out Error
-

Set Site Master Calibration Mode – Control Byte #15 (0Fh)

Description: Set the Site Master calibration mode to OSL Cal (standard) or FlexCal.

Bytes to Follow: 1 byte

- 1) Calibration Mode
 - 00h = OSL Calibration (standard)
 - 01h = FlexCal Calibration

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error : Invalid calibration mode
 - 238 (EEh) Time-out Error
-

Store Sweep Trace – Control Byte #16 (10h)

Description: Saves current trace to the next available memory location. Trace name can be set using control byte #9, “Set Trace Name (Reference Number)” before executing this command.

Bytes to Follow: 0 bytes

Site Master Returns: 5 bytes

- 1-4) Time/Date Stamp (In long integer format)
 - 5) Operation result:
 - 255 (FFh) Operation Complete Byte
 - 224 (E0h) Out of memory (Memory full)
 - 238 (EEh) Time-out Error
-

³ This byte is returned only after the instrument is finished with its sweep. Not right away.

OBSOLETE: Recall Sweep Trace – Control Byte #17 (11h)

This command exists for backward compatibility with the S33xC models. Features new to the S33xD models are not available here. To access the new features use Control Byte #33 (21h).

Description: Queries the Site Master for sweep trace data.

NOTE: Before you can recall a sweep stored in non-volatile memory (trace numbers 1-200) you must build a trace table in the Site Master's RAM. Use Control Byte #24 to build the trace table. Since the trace table exists in RAM, Control Byte #24 must be executed every time the Site Master's power is cycled.

Bytes to Follow: 1 byte

- 0 = Last sweep trace before entering remote mode (sweep trace in RAM)
- 1- 200 = Specific saved sweep number (stored sweeps in Flash memory)

Site Master Returns:

- 1-2) # of following bytes (total length - 2)
- 3-4) Not Used
- 5-11) Model Number (7 bytes in ASCII)
- 12-15) Software Version (4 bytes ASCII)
- 16) Measurement Mode⁴
- 17-20) Time/Date (in Long Integer⁵)
- 21-30) Date in String Format (mm/dd/yyyy)
- 31-38) Time in String Format (hh:mm:ss)
- 39-54) Reference number stamp (16 bytes in ASCII)
- 55-56) # data points (130, 259, 517 or 400)

For all "Site Master Modes" :

- 57) Start Frequency⁶ (Highest byte)
- 58) Start Frequency
- 59) Start Frequency
- 60) Start Frequency (Lowest byte)
- 61) Stop Frequency (Highest byte)
- 62) Stop Frequency
- 63) Stop Frequency
- 64) Stop Frequency (Lowest byte)
- 65) Minimum Frequency Step Size (Highest byte)
- 66) Minimum Frequency Step Size
- 67) Minimum Frequency Step Size
- 68) Minimum Frequency Step Size (Lowest byte)
- 69) Scale Top⁷ (Highest byte)
- 70) Scale Top
- 71) Scale Top
- 72) Scale Top (Lowest byte)
- 73) Scale Bottom (Highest byte)
- 74) Scale Bottom
- 75) Scale Bottom
- 76) Scale Bottom (Lowest byte)
- 77) Frequency Marker 1⁸ (Highest byte)
- 78) Frequency Marker 1 (Lowest byte)

⁴ Refer to Control Byte #3 "Select Measurement Mode" for detailed value.

⁵ Time/Date long integer representation is in seconds since January 1, 1970

⁶ Frequency units are Hz

⁷ See Control Byte #4 "Set Site Master Scale" for data format

⁸ marker point = (# of data points - 1) * (marker freq - start freq) / (stop freq - start freq) where # of data points can be found in bytes 55-56, start freq is in bytes 57-60, and stop freq is in bytes 61-64.

- 79) Frequency Marker 2 (Highest byte)
- 80) Frequency Marker 2 (Lowest byte)
- 81) Frequency Marker 3 (Highest byte)
- 82) Frequency Marker 3 (Lowest byte)
- 83) Frequency Marker 4 (Highest byte)
- 84) Frequency Marker 4 (Lowest byte)
- 85) Frequency Marker 5 (Highest byte)
- 86) Frequency Marker 5 (Lowest byte)
- 87) Frequency Marker 6 (Highest byte)
- 88) Frequency Marker 6 (Lowest byte)
- 89) Single Limit⁹ (Highest byte)
- 90) Single Limit
- 91) Single Limit
- 92) Single Limit (Lowest byte)
- 93) Multiple Limit Segment # (1)
- 94) Multiple Limit Segment Status
- 95) Multiple Limit Start X¹⁰ (Highest byte)
- 96) Multiple Limit Start X
- 97) Multiple Limit Start X
- 98) Multiple Limit Start X (Lowest byte)
- 99) Multiple Limit Start Y (Highest byte)
- 100) Multiple Limit Start Y (Lowest byte)
- 101) Multiple Limit End X (Highest byte)
- 102) Multiple Limit End X
- 103) Multiple Limit End X
- 104) Multiple Limit End X (Lowest byte)
- 105) Multiple Limit End Y (Highest byte)
- 106) Multiple Limit End Y (Lowest byte)
- 107-162) Repeat bytes 93-106 for segments 2-5
- 163) Start Distance¹¹ (Highest byte)
- 164) Start Distance
- 165) Start Distance
- 166) Start Distance (Lowest byte)
- 167) Stop Distance (Highest byte)
- 168) Stop Distance
- 169) Stop Distance
- 170) Stop Distance (Lowest byte)
- 171) Distance Marker 1¹² (Highest byte)
- 172) Distance Marker 1 (Lowest byte)
- 173) Distance Marker 2 (Highest byte)
- 174) Distance Marker 2 (Lowest byte)
- 175) Distance Marker 3 (Highest byte)
- 176) Distance Marker 3 (Lowest byte)
- 177) Distance Marker 4 (Highest byte)
- 178) Distance Marker 4 (Lowest byte)
- 179) Distance Marker 5 (Highest byte)
- 180) Distance Marker 5 (Lowest byte)
- 181) Distance Marker 6 (Highest byte)
- 182) Distance Marker 6 (Lowest byte)
- 183) Relative Propagation Velocity¹³ (Highest byte)

⁹ See Control Byte #6 “Set Site Master Single Limit” for data format.

¹⁰ See Control Byte #112 “Set Site Master Segmented Limit Lines” for data format.

¹¹ Distance data uses units 1/100,000m (or feet)

¹² Marker Point = (# data points – 1) * (marker dist – start dist) / (stop dist – start dist)

Where # of data points can be found in bytes 55-56, start dist is in bytes 163-166, and stop dist is in bytes 167-170.

- 184)Relative Propagation Velocity
 185)Relative Propagation Velocity
 186)Relative Propagation Velocity (Lowest byte)
 187)Cable Loss¹⁴ (Highest byte)
 188)Cable Loss
 189)Cable Loss
 190)Cable Loss (Lowest byte)
 191)Status Byte 1: (0b = Off , 1b = On)
 (LSB) bit 0 : Marker 1 On/Off
 bit 1 : Marker 2 On/Off
 bit 2 : Marker 3 On/Off
 bit 3 : Marker 4 On/Off
 bit 4 : Marker 5 On/Off
 bit 5 : Marker 6 On/Off
 bits 6-7 : Not Used
 192)Status Byte 2: (0b = Off, 1b = On)
 (LSB) bit 0 : Not Used
 bit 1 : Marker 2 Delta On/Off
 bit 2 : Marker 3 Delta On/Off
 bit 3 : Marker 4 Delta On/Off
 bits 4-7 : Not Used
 193)Status Byte 3: (0b = Off , 1b = On)
 (LSB) bit 0 : Single Limit On/Off
 bit 1: CW On/Off
 bit 2-3 : Not Used
 bit 4 : InstaCal On/Off¹⁵
 bit 5 : Cal On/Off
 bit 6 : Limit Type (0b = Single; 1b = Multiple)
 bit 7 : Unit of Measurement (1b = Metric, 0b = English)
 194)Status Byte 4:
 (LSB) bit 0 - 1 : DTF Windowing Mode
 bit: 1 0
 | |
 0 0 - Rectangular (No Windowing)
 0 1 - Nominal Side Lobe
 1 0 - Low Side Lobe
 1 1 - Minimum Side Lobe
 bits 2 – 7 : Not Used
 195-228) Not Used
 229-1268) Sweep Data (130 points * 8 bytes/point = 1040 bytes)
 229-2300) Sweep Data (259 points * 8 bytes/point = 2072 bytes)
 229-4364) Sweep Data (517 points * 8 bytes/point = 4136 bytes)
 8 bytes for each data point
 1. gamma¹⁶ MSB
 2. gamma
 3. gamma
 4. gamma LSB
 5. phase¹⁷ MSB
 6. phase
 7. phase

¹³ Relative Propagation Velocity uses units 1/100,000

¹⁴ Cable Loss uses units 1/100,000 dB/m or 1/100,000 dB/ft.

¹⁵ Bits (4,5) are as follows: (0,0) = Cal Off, (0,1) = OSL Cal (1,1) = InstaCal On, (1,0) = Impossible.

¹⁶ Gamma data uses 1/1000 units.

¹⁷ Phase data uses 1/10 degree unit.

8. phase LSB

Note: $\text{return loss} = -20 * (\log(\text{gamma}) / \log(10))$
 $\text{VSWR} = (1 + \text{gamma}) / (1 - \text{gamma})$
phase compares the reflected to the incident (reference)

For Spectrum Analyzer Mode:

- 57) Start Frequency¹⁸ (Highest byte)
- 58) Start Frequency
- 59) Start Frequency
- 60) Start Frequency (Lowest byte)
- 61) Stop Frequency (Highest byte)
- 62) Stop Frequency
- 63) Stop Frequency
- 64) Stop Frequency (Lowest byte)
- 65) Center Frequency (Highest byte)
- 66) Center Frequency
- 67) Center Frequency
- 68) Center Frequency (Lowest byte)
- 69) Frequency Span (Highest byte)
- 70) Frequency Span
- 71) Frequency Span
- 72) Frequency Span (Lowest byte)
- 73) Minimum Frequency Step Size (Highest byte)
- 74) Minimum Frequency Step Size
- 75) Minimum Frequency Step Size
- 76) Minimum Frequency Step Size (Lowest byte)
- 77) Ref Level¹⁹ (Highest byte)
- 78) Ref Level
- 79) Ref Level
- 80) Ref Level (Lowest byte)
- 81) Scale per div²⁰ (Highest byte)
- 82) Scale per div
- 83) Scale per div
- 84) Scale per div (Lowest byte)
- 85) Frequency Marker 1²¹ (Highest byte)
- 86) Frequency Marker 1 (Lowest byte)
- 87) Frequency Marker 2 (Highest byte)
- 88) Frequency Marker 2 (Lowest byte)
- 89) Frequency Marker 3 (Highest byte)
- 90) Frequency Marker 3 (Lowest byte)
- 91) Frequency Marker 4 (Highest byte)
- 92) Frequency Marker 4 (Lowest byte)
- 93) Frequency Marker 5 (Highest byte)
- 94) Frequency Marker 5 (Lowest byte)
- 95) Frequency Marker 6 (Highest byte)
- 96) Frequency Marker 6 (Lowest byte)
- 97) Single Limit²² (Highest byte)
- 98) Single Limit
- 99) Single Limit

¹⁸ Frequency in Hz

¹⁹ Value sent as (Value in dBm * 1000) + 270,000

²⁰ Value sent as (Value * 1000)

²¹ Value sent as data point on display. $\text{Freq} = (\text{Point} * \text{Span} / (\text{Total Data Points} - 1)) + \text{Start Freq}$

²² Value sent as (value in dBm * 1000) + 270,000

- 100) Single Limit (Lowest byte)
- 101) Multiple Upper Limit 1 Start X (Frequency in Hz) (Highest byte)
- 102) Multiple Upper Limit 1 Start X (Frequency in Hz)
- 103) Multiple Upper Limit 1 Start X (Frequency in Hz)
- 104) Multiple Upper Limit 1 Start X (Frequency in Hz) (Lowest byte)
- 105) Multiple Upper Limit 1 Start Y (Power Level²³) (Highest byte)
- 106) Multiple Upper Limit 1 Start Y (Power Level)
- 107) Multiple Upper Limit 1 Start Y (Power Level)
- 108) Multiple Upper Limit 1 Start Y (Power Level) (Lowest byte)
- 109) Multiple Upper Limit 1 End X (Frequency in Hz) (Highest byte)
- 110) Multiple Upper Limit 1 End X (Frequency in Hz)
- 111) Multiple Upper Limit 1 End X (Frequency in Hz)
- 112) Multiple Upper Limit 1 End X (Frequency in Hz) (Lowest byte)
- 113) Multiple Upper Limit 1 End Y (Power Level) (Highest byte)
- 114) Multiple Upper Limit 1 End Y (Power Level)
- 115) Multiple Upper Limit 1 End Y (Power Level)
- 116) Multiple Upper Limit 1 End Y (Power Level) (Lowest byte)
- 117-260) Multiple Upper Limits 2-5, Multiple Lower Limits 1-5 (see bytes 101-116 for format)
- 261) RBW Setting (Frequency in Hz) (Highest byte)
- 262) RBW Setting (Frequency in Hz)
- 263) RBW Setting (Frequency in Hz)
- 264) RBW Setting (Frequency in Hz) (Lowest byte)
- 265) VBW Setting (Frequency in Hz) (Highest byte)
- 266) VBW Setting (Frequency in Hz)
- 267) VBW Setting (Frequency in Hz)
- 268) VBW Setting (Frequency in Hz) (Lowest byte)
- 269) OCC BW Method (0b if % of power, 1b = dB down)
- 270) OCC BW % Value²⁴ (Highest byte)
- 271) OCC BW % Value
- 272) OCC BW % Value
- 273) OCC BW % Value (Lowest byte)
- 274) OCC BW dBc²⁵ (Highest byte)
- 275) OCC BW dBc
- 276) OCC BW dBc
- 277) OCC BW dBc (Lowest byte)
- 278) Attenuation²⁶ (Highest byte)
- 279) Attenuation
- 280) Attenuation
- 281) Attenuation (Lowest byte)
- 282-297) Antenna Name (16 bytes in ASCII)
- 298) Status Byte 1: (0b = Off , 1b = On)
 - (LSB) bit 0 : Marker 1 On/Off
 - bit 1 : Marker 2 On/Off
 - bit 2 : Marker 3 On/Off
 - bit 3 : Marker 4 On/Off
 - bit 4 : Marker 5 On/Off
 - bit 5 : Marker 6 On/Off
 - bits 6-7 : Not Used
- 299) Status Byte 2: (0b = Off , 1b = On)
 - (LSB) bit 0 : Not Used
 - bit 1 : Marker 2 Delta On/Off

²³ Value sent as (value in dBm * 1000) + 270,000

²⁴ % value is 0-99

²⁵ dBc value 0 – 120 dBc

²⁶ Value sent as (value in dB * 1000)

- bit 2 : Marker 3 Delta On/Off
- bit 3 : Marker 4 Delta On/Off
- bits 4-7: Not Used
- 298) Status Byte 3: (0b = Off, 1b = On)
 - (LSB) bit 0 : Antenna Factor Correction On/Off
 - bits 1-2 : Detection Alg (00b = pos. peak 01b = average 10b = neg. peak)
 - bits 3-4 : Amplitude Units (00b = dBm 01b = dBV 10b = dBmV 11b = dBuV)
 - bit 5 : Channel Power On/Off
 - bit 6 : Adjacent Channel Power On/Off
 - bit 7 : Not Used
- 299) Status Byte 4²⁷
 - (0b = Off/Beep if data is BELOW line, 1b = On/Beep if data is ABOVE line)
 - (LSB) bit 0 : Limit Type (0b = Single, 1b = Multiple)
 - bit 1 : Not Used
 - bit 2 : Single Limit On/Off
 - bit 3 : Single Limit Beep Level ABOVE/BELOW
 - bit 4 : Multiple Limit Upper Segment 1 Status On/Off
 - bit 5 : Multiple Limit Upper Segment 1 Beep Level ABOVE/BELOW²⁸
 - bit 6 : Multiple Limit Upper Segment 2 Status On/Off
 - bit 7 : Multiple Limit Upper Segment 2 Beep Level ABOVE/BELOW
- 300) Status Byte 5
 - (0b = Off/Beep if data is below line, 1b = On/Beep if data is above line)
 - (LSB) bit 0 : Multiple Limit Upper Segment 3 Status On/Off
 - bit 1 : Multiple Limit Upper Segment 3 Beep Level ABOVE/BELOW
 - bit 2 : Multiple Limit Upper Segment 4 Status On/Off
 - bit 3 : Multiple Limit Upper Segment 4 Beep Level ABOVE/BELOW
 - bit 4 : Multiple Limit Upper Segment 5 Status On/Off
 - bit 5 : Multiple Limit Upper Segment 5 Beep Level ABOVE/BELOW
 - bit 6 : Multiple Limit Lower Segment 1 Status On/Off
 - bit 7 : Multiple Limit Lower Segment 1 Beep Level ABOVE/BELOW²⁹
- 303) Status Byte 6
 - (0b = Off/Beep if data is BELOW line, 1b = On/Beep if data is ABOVE line)
 - (LSB) bit 0 : Multiple Limit Lower Segment 2 Status On/Off
 - bit 1 : Multiple Limit Lower Segment 2 Beep Level ABOVE/BELOW
 - bit 2 : Multiple Limit Lower Segment 3 Status On/Off
 - bit 3 : Multiple Limit Lower Segment 3 Beep Level ABOVE/BELOW
 - bit 4 : Multiple Limit Lower Segment 4 Status On/Off
 - bit 5 : Multiple Limit Lower Segment 4 Beep Level ABOVE/BELOW
 - bit 6 : Multiple Limit Lower Segment 5 Status On/Off
 - bit 7 : Multiple Limit Lower Segment 5 Beep Level ABOVE/BELOW
- 304) Status Byte 7
 - bits 0-6: Number of sweeps to average (1-25, 1 implies no averaging)
 - bit 7: Not Used
- 305) Reference Level Offset ³⁰(Highest byte)
- 306) Reference Level Offset
- 307) Reference Level Offset
- 308) Reference Level Offset (Lowest byte)
- 309-338) Not Used
- 339-1938) Sweep Data (400 points * 4 bytes/point= 1600 bytes)
 - 4 bytes for each data point

²⁷ For bits 2 and 0, 00=no limit, 10=single limit, 01=multiple limit, 11=multiple limit.

²⁸ Upper limits always trigger an error beep if data is ABOVE the limit segment, for example, this bit is always 1b.

²⁹ LOWER limits always trigger an error beep if data is BELOW the limit segment, for example, this bit is always 0b.

³⁰ Value sent as (value in dBm * 1000) + 270,000

1. dBm³¹ MSB
2. dBm
3. dBm
4. dBm LSB

For T1 Tester / E1 Tester Mode:

- 57) Receive Input (00h: Terminate, 01h: Bridged, 02h: Monitor)
- 58) Framing Mode
(T1 Mode: 01h: ESF, 02h: D4SF)
(E1 Mode: 03h: PCM30, 04h: PCM30CRC, 05h: PCM31, 06h: PCM31CRC)
- 59) Line Coding (01h: B8ZS, 02h: AMI, 03h: HDB3)
- 60) Tx Level (Valid for T1 Only) (01h: 0 dB, 02h: -7.5 dB, 03h: -15 dB)
- 61) Clock Source (00h: External, 01h: Internal)
- 62) Error Insert Type (00h: Frame Error, 01h: BPV, 02h: Bit Errors, 04h: RAI, 05h: AIS)
- 63) Loop Code (Valid for T1 Only) (00h: CSU, 01h: NIU, 02h: User 1, 03h: User 2)
- 64) Loop Type (Valid for T1 Only) (00h: In Band, 01h: Data Link)
- 65) CRC Method (Valid for T1 Only) (00h: ANSI CRC, 01h: Japanese CRC)
- 66) Display Type (00h: Histogram, 01h: Raw Data)
- 67) Impedance (Valid for E1 Only) (01h: 75 Ω, 02h: 120 Ω)
- 68) Pattern (Higher byte)
- 69) Pattern (Lower byte) (01h: PRBS-9, 02h: PRBS-11, 03h: PRBS-15, 04h: PRBS-20(O.151),
05h: PRBS-20(O.153), 06h: PRBS-23, 07h: QRSS, 08h: 1 in 8, 09h: 2 in 8, 0Ah: 3 in 8, 0Bh:
All Ones, 0Ch: All Zeros, 0Dh: T1-DALY, 0Eh: User Defined)
- 70) Pattern Invert Status (00h: Non-Inverted, 01h: Inverted)
- 71) Insert Bit Error Value (1-1000) (Highest byte)
- 72) Insert Bit Error Value
- 73) Insert Bit Error Value
- 74) Insert Bit Error Value (Lowest byte)
- 75) Insert BPV Error Value (1-1000) (Highest byte)
- 76) Insert BPV Error Value
- 77) Insert BPV Error Value
- 78) Insert BPV Error Value (Lowest byte)
- 79) Insert Frame Error Value (1-1000) (Highest byte)
- 80) Insert Frame Error Value
- 81) Insert Frame Error Value
- 82) Insert Frame Error Value (Lowest byte)
- 83) Measurement Duration (Highest byte)
- 84) Measurement Duration
- 85) Measurement Duration
- 86) Measurement Duration (Lowest byte) (00h: Manual, 01h: 3 min, 02h: 15 min, 03h: 30 min,
04h: 1 hr, 05h: 3 hrs, 06h: 6 hrs, 07h: 12 hrs, 08h: 1 day, 09h: 2 days)
- 87) Histogram Resolution (Highest byte)
- 88) Histogram Resolution
- 89) Histogram Resolution
- 90) Histogram Resolution (Lowest byte) (00h: Auto, 01h: 1 sec, 02h: 15 sec, 03h: 30 sec, 04h: 45
sec, 05h: 1 min, 06h: 15 min, 07h: 30 min, 08h: 45 min, 09h: 60 min)
- 91) Frame Sync Status (00h: In Sync, 01h: Out-of-Sync)
- 92) Pattern Sync Status (00h: In Sync, 01h: Out-of-Sync)
- 93) Carrier Status (00h: In Sync, 01h: Out-of-Sync)
- 94) Rx Alarms (bit 0: Receiving AIS, bit 1: Receiving RAI, bit 2: Receiving E1 MMF error)
- 95 – 98) BPV Error Count
- 99 – 102) CRC Error Count
- 103 – 106) Frame Error Count
- 107 – 110) LOF Error Count

³¹ Value sent as (value in dBm * 1000) + 270,000

- 111 – 114) E Bit Error Count (E1 Only)
- 115 – 118) Errored Seconds
- 119 – 122) Bit Count
- 123 – 126) Bit Errors
- 127) User Defined Pattern (convert to binary for pattern) (Highest byte)
- 128) User Defined Pattern
- 129) User Defined Pattern
- 130) User Defined Pattern (Lowest byte)
- 131 – 138) Measurement Start Time String (ASCII string: “HH:MM:SS”)
- 139 – 150) Reserved
- 151 – 158) Measurement Stop Time String (ASCII string: “HH:MM:SS”)
- 159 – 170) Reserved
- 171 – 181) Elapsed Time String (ASCII string: “DD,HH:MM:SS”)
- 182 – 189) Bit Error Rate String (ASCII string in engineering format: x.xxE-xx)
- 190 – 689) 100 data points with 5 bytes for each data point.
 - 1st byte has information about Carrier Loss, Frame Loss, BPV and CRC
 - Following 4 bytes corresponds to the Bit Error Count
 - Break down of the 1st byte :

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Not Used	Not Used	Not Used	Carrier Loss	Frame Loss	BPV Error	CRC / E- Bit Error	Any Error

690 – 800) Not Used

Site Master Returns (For invalid sweeps/empty stored sweep locations): 11 bytes
 1-2) Number of following bytes (9 bytes for invalid sweep recall)
 3-4) Model # (unsigned integer, 14h for Site Master S33xD)
 5-11) Extended Model # (7 bytes in ASCII)

Site Master Returns (Invalid sweep location): 1 byte
 1) 224 (E0) Parameter Error: Invalid sweep location

Save System Setup – Control Byte #18 (12h)

Description: Saves current system setup parameters to a specific setup store location.

The Site Master saves all parameters described in Query System Status - Control Byte #29 (1Dh), (except Serial Port Echo Status) to the specified store location. Store location 0 is the run-time setup of the Site Master. It holds the power-on defaults of the Site Master.

Bytes to Follow: 1 byte

- 1) Location to save system setup parameters:
 - 0 – 10 for SWR Mode, Return Loss Mode, Cable Loss Mode and DTF Mode
 - 0 – 5 for Spectrum Analyzer Mode (S332D only)
 - 0 – 5 for Power Meter Mode (with Option 29 only)
 - 0 – 5 for T1/E1 Modes (with Option 50 only)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
- 224 (E0h) Parameter Error : Invalid store location
- 238 (EEh) Time-out Error

Recall System Setup – Control Byte #19 (13h)

Description: Recalls system setup parameters from a specific store location. Storage locations depend on the measurement mode of the current setup. When the current mode is Spectrum Analyzer, Spectrum Analyzer setups (1-5) can be recalled. When the current mode is one of the Site Master VNA modes (SWR, RL, CL, DTF), one of the 10 VNA mode setups can be recalled. When the current mode is T1/E1, one of the T1/E1 setups can be recalled (1-5).

The Site Master recalls all parameters described in Query System Status - Control Byte #29 (1Dh), (except Serial Port Echo Status) from the specified store location. The recalled setup does **not** automatically become the power-on runtime setup when exiting remote. Therefore, a call to #29 will not display the parameters in that setup.

You may want to save the recalled setup as the run-time setup by saving it to setup location 0 (which holds the power-on runtime setup). See control byte #18 (12h) for details.

Bytes to Follow: 1 byte

- 1) Location from which to recall system setup parameters:
 - 0 = Run time setup for all measurement modes
 - 1 – 10 = Saved setups for Site Master VNA modes SWR, RL, CL, DTF
 - 1 – 5 = Saved setups for Spectrum Analyzer mode (S332D only)
 - 1 – 5 = Saved setups for Power Meter mode (with Option 29 only)
 - 1 – 5 = Saved setups for T1/E1 modes (with Option 50 only)
 - 254 = Default setup, current mode
 - 255 = Default setup, all modes

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
- 224 (E0h) Parameter Error : Invalid store location or no saved setup
- 227 (E3h) Frequency Mismatch Error
- 238 (EEh) Time-out Error

OBSOLETE: Query System Status – Control Byte #20 (14h)

This command exists for backward compatibility with the S33xC models. Features new to the S33xD models are not available here. To access the new features use Control Byte #29 (1Dh).

Description: Queries the Site Master for current system settings.

The current state of the Site Master represents the state after the last successful remote control operation. For example, change the start frequency to another valid frequency while in remote mode, then execute control byte #20. The new start frequency will be returned in bytes 4-7, even though no sweep has been performed with that frequency.

Bytes to Follow: 0 bytes

Site Master Returns: 434 bytes

- 1) Measurement Mode³²
- 2) Site Master Mode Data Points (Higher byte)
- 3) Site Master Mode Data Points (Lower byte)
- 4) Start Frequency (Frequency in Hz) (Highest byte)
- 5) Start Frequency
- 6) Start Frequency
- 7) Start Frequency (Lowest byte)
- 8) Stop Frequency (Frequency in Hz)³⁴ (Highest byte)
- 9) Stop Frequency

³² Refer to Control Byte #3 “Select Measurement Mode” for valid measurement modes.

- 10) Stop Frequency
- 11) Stop Frequency (Lowest byte)
- 12) Scale Start (Highest byte)³³
- 13) Scale Start
- 14) Scale Start
- 15) Scale Start (Lowest byte)
- 16) Scale Stop (Highest byte)
- 17) Scale Stop
- 18) Scale Stop
- 19) Scale Stop (Lowest byte)
- 20) Frequency Marker 1 (Higher byte)³⁴
- 21) Frequency Marker 1 (Lower byte)
- 22) Frequency Marker 2 (Higher byte)
- 23) Frequency Marker 2 (Lower byte)
- 24) Frequency Marker 3 (Higher byte)
- 25) Frequency Marker 3 (Lower byte)
- 26) Frequency Marker 4 (Higher byte)
- 27) Frequency Marker 4 (Lower byte)
- 28) Frequency Marker 5 (Higher byte)
- 29) Frequency Marker 5 (Lower byte)
- 30) Frequency Marker 6 (Higher byte)
- 31) Frequency Marker 6 (Lower byte)
- 32) Site Master Single Limit (Highest byte)³⁵
- 33) Site Master Single Limit
- 34) Site Master Single Limit
- 35) Site Master Single Limit (Lowest byte)
- 36) Multiple Limit Segment # (1)
- 37) Multiple Limit Segment Status (0h = Off, 01h = On)
- 38) Multiple Limit Segment Start X (Highest byte)³⁶
- 39) Multiple Limit Segment Start X
- 40) Multiple Limit Segment Start X
- 41) Multiple Limit Segment Start X (Lowest byte)
- 42) Multiple Limit Segment Start Y (Higher byte)
- 43) Multiple Limit Segment Start Y (Lower byte)
- 44) Multiple Limit Segment End X (Highest byte)
- 45) Multiple Limit Segment End X
- 46) Multiple Limit Segment End X
- 47) Multiple Limit Segment End X (Lowest byte)
- 48) Multiple Limit Segment End Y (Higher byte)
- 49) Multiple Limit Segment End Y (Lower byte)
- 50-105) Repeat bytes 36 – 49 for segments 2 - 5
- 106) Start Distance (Highest byte)³⁷
- 107) Start Distance
- 108) Start Distance
- 109) Start Distance (Lowest byte)
- 110) Stop Distance (Highest byte)
- 111) Stop Distance
- 112) Stop Distance
- 113) Stop Distance (Lowest byte)

³³ See “Set Site Master Scale” Control Byte #4 for data format.

³⁴ Marker Point = (# data points – 1) * (marker freq – start freq) / (stop freq – start freq)

Where # of data points can be found in bytes 2-3, start freq is in bytes 4-7, and stop freq is in bytes 8-11.

³⁵ See Control Byte #6, “Set Site Master Single Limit” for data format.

³⁶ See Control Byte #112, “Set Site Master Segmented Limit Lines” for data format.

³⁷ Distance data uses units 1/100,000 m or 1/100,000 ft

- 114) Distance Marker 1 (Higher byte)³⁸
- 115) Distance Marker 1 (Lower byte)
- 116) Distance Marker 2 (Higher byte)
- 117) Distance Marker 2 (Lower byte)
- 118) Distance Marker 3 (Higher byte)
- 119) Distance Marker 3 (Lower byte)
- 120) Distance Marker 4 (Higher byte)
- 121) Distance Marker 4 (Lower byte)
- 122) Distance Marker 5 (Higher byte)
- 123) Distance Marker 5 (Lower byte)
- 124) Distance Marker 6 (Higher byte)
- 125) Distance Marker 6 (Lower byte)
- 126) Relative Propagation Velocity (Highest byte)³⁹
- 127) Relative Propagation Velocity
- 128) Relative Propagation Velocity
- 129) Relative Propagation Velocity (Lowest byte)
- 130) Cable Loss (Highest byte)⁴⁰
- 131) Cable Loss
- 132) Cable Loss
- 133) Cable Loss (Lowest byte)
- 134) Spectrum Analyzer Mode Data Points (Higher byte)
- 135) Spectrum Analyzer Mode Data Points (Lower byte)
- 136) Spectrum Analyzer Start Frequency⁴¹ (Highest byte)
- 137) Spectrum Analyzer Start Frequency
- 138) Spectrum Analyzer Start Frequency
- 139) Spectrum Analyzer Start Frequency (Lowest byte)
- 140) Spectrum Analyzer Stop Frequency (Highest byte)
- 141) Spectrum Analyzer Stop Frequency
- 142) Spectrum Analyzer Stop Frequency
- 143) Spectrum Analyzer Stop Frequency (Lowest byte)
- 144) Spectrum Analyzer Center Frequency (Highest byte)
- 145) Spectrum Analyzer Center Frequency
- 146) Spectrum Analyzer Center Frequency
- 147) Spectrum Analyzer Center Frequency (Lowest byte)
- 148) Spectrum Analyzer Frequency Span (Highest byte)
- 149) Spectrum Analyzer Frequency Span
- 150) Spectrum Analyzer Frequency Span
- 151) Spectrum Analyzer Frequency Span (Lowest byte)
- 152) Spectrum Analyzer Minimum Frequency Step Size (Highest byte)
- 153) Spectrum Analyzer Minimum Frequency Step Size
- 154) Spectrum Analyzer Minimum Frequency Step Size
- 155) Spectrum Analyzer Minimum Frequency Step Size (Lowest byte)
- 156) Ref Level (Highest byte)⁴²
- 157) Ref Level
- 158) Ref Level
- 159) Ref Level (Lowest byte)
- 160) Scale per div (Highest byte)⁴³
- 161) Scale per div

³⁸ Marker Point = (# data points – 1) * (marker dist – start dist) / (stop dist – start dist)

Where # of data points can be found in bytes 2-3, start dist is in bytes 106-109, and stop dist is in bytes 110-113.

³⁹ Relative Propagation Velocity uses units 1/100,000.

⁴⁰ Cable loss uses units 1/100,000 dB/m or 1/100,000 dB/ft.

⁴¹ Frequency unit is Hz.

⁴² Value sent as (value in dBm * 1000) + 270,000)

⁴³ Value sent as (value * 1000)

- 162) Scale per div
- 163) Scale per div (Lowest byte)
- 164) Spectrum Analyzer Frequency Marker 1 (Higher byte)⁴⁴
- 165) Spectrum Analyzer Frequency Marker 1 (Lower byte)
- 166) Spectrum Analyzer Frequency Marker 2 (Higher byte)
- 167) Spectrum Analyzer Frequency Marker 2 (Lower byte)
- 168) Spectrum Analyzer Frequency Marker 3 (Higher byte)
- 169) Spectrum Analyzer Frequency Marker 3 (Lower byte)
- 170) Spectrum Analyzer Frequency Marker 4 (Higher byte)
- 171) Spectrum Analyzer Frequency Marker 4 (Lower byte)
- 172) Spectrum Analyzer Frequency Marker 5 (Higher byte)
- 173) Spectrum Analyzer Frequency Marker 5 (Lower byte)
- 174) Spectrum Analyzer Frequency Marker 6 (Higher byte)
- 175) Spectrum Analyzer Frequency Marker 6 (Lower byte)
- 176) Spectrum Analyzer Single Limit (Highest byte)⁴⁵
- 177) Spectrum Analyzer Single Limit
- 178) Spectrum Analyzer Single Limit
- 179) Spectrum Analyzer Single Limit (Lowest byte)
- 180) Multiple Upper Limit 1 Start X (Frequency in Hz) (Highest byte)
- 181) Multiple Upper Limit 1 Start X (Frequency in Hz)
- 182) Multiple Upper Limit 1 Start X (Frequency in Hz)
- 183) Multiple Upper Limit 1 Start X (Frequency in Hz) (Lowest byte)
- 184) Multiple Upper Limit 1 Start Y (Power Level) (Highest byte)⁴⁶
- 185) Multiple Upper Limit 1 Start Y (Power Level)
- 186) Multiple Upper Limit 1 Start Y (Power Level)
- 187) Multiple Upper Limit 1 Start Y (Power Level) (Lowest byte)
- 188) Multiple Upper Limit 1 End X (Frequency in Hz) (Highest byte)
- 189) Multiple Upper Limit 1 End X (Frequency in Hz)
- 190) Multiple Upper Limit 1 End X (Frequency in Hz)
- 191) Multiple Upper Limit 1 End X (Frequency in Hz) (Lowest byte)
- 192) Multiple Upper Limit 1 End Y (Power Level) (Highest byte)⁴⁷
- 193) Multiple Upper Limit 1 End Y (Power Level)
- 194) Multiple Upper Limit 1 End Y (Power Level)
- 195) Multiple Upper Limit 1 End Y (Power Level) (Lowest byte)
- 196-339) Multiple Upper Limits 2-5, Multiple Lower Limits 1-5 (see bytes 180-195 for format)
- 340) RBW Setting (Highest byte)⁴⁸
- 341) RBW Setting
- 342) RBW Setting
- 343) RBW Setting (Lowest byte)
- 344) VBW Setting (Highest byte)⁴⁹
- 345) VBW Setting
- 346) VBW Setting
- 347) VBW Setting (Lowest byte)
- 348) OCC BW Method⁵⁰
- 349) OCC BW % Value (Highest byte)⁵¹

⁴⁴ Value sent as data point on the display. Equivalent frequency = (point * span / (# data points – 1)) + start frequency.

⁴⁵ Value sent as (value in dBm * 1000) + 270000

⁴⁶ Value sent as (value in dBm * 1000) + 270000

⁴⁷ Value sent as (value in dBm * 1000) + 270000

⁴⁸ 0000h = 10kHz, 0001h = 30kHz, 0002h = 100kHz, 0003h = 1MHz

⁴⁹ 0000h = 100Hz, 0001h = 300Hz, 0002h = 1kHz, 0003h = 3kHz,

0004h = 10kHz, 0005h = 30kHz, 0006h = 100kHz, 0007h = 300kHz

⁵⁰ 00h = % of power, 01h = dB down

⁵¹ 0 – 99%

- 350) OCC BW % Value
- 351) OCC BW % Value
- 352) OCC BW % Value (Lowest byte)
- 353) OCC BW dBc (Highest byte)⁵²
- 354) OCC BW dBc
- 355) OCC BW dBc
- 356) OCC BW dBc (Lowest byte)
- 357) Attenuation (Highest byte)⁵³
- 358) Attenuation
- 359) Attenuation
- 360) Attenuation (Lowest byte)
- 361) Antenna Index (0-14)
- 362-377) Antenna Name (16 bytes in ASCII)
- 378) Status Byte 1: (0b = Off, 1b = On)
 - (LSB) bit 0 : Site Master Marker 1 On/Off
 - bit 1 : Site Master Marker 2 On/Off
 - bit 2 : Site Master Marker 3 On/Off
 - bit 3 : Site Master Marker 4 On/Off
 - bit 4 : Site Master Marker 5 On/Off
 - bit 5 : Site Master Marker 6 On/Off
 - bits 6- 7 : Not Used
- 379) Status Byte 2: (0b = Off, 1b = On)
 - (LSB) bit 0 : Not Used
 - bit 1 : Site Master Marker 2 Delta On/Off
 - bit 2 : Site Master Marker 3 Delta On/Off
 - bit 3 : Site Master Marker 4 Delta On/Off
 - bits 4-7: Not Used
- 380) Status Byte 3: (0b = Off, 1b = On)
 - (LSB) bit 0 : Spectrum Analyzer Mode Marker 1 On/Off
 - bit 1 : Spectrum Analyzer Mode Marker 2 On/Off
 - bit 2 : Spectrum Analyzer Mode Marker 3 On/Off
 - bit 3 : Spectrum Analyzer Mode Marker 4 On/Off
 - bit 4 : Spectrum Analyzer Mode Marker 5 On/Off
 - bit 5 : Spectrum Analyzer Mode Marker 6 On/Off
 - bits 6 - 7 : Not Used
- 381) Status Byte 4: (0b = Off, 1b = On)
 - (LSB) bit 0 : Not Used
 - bit 1 : Spectrum Analyzer Mode Marker 2 Delta On/Off
 - bit 2 : Spectrum Analyzer Mode Marker 3 Delta On/Off
 - bit 3 : Spectrum Analyzer Mode Marker 4 Delta On/Off
 - bits 4-7: Not Used
- 382) Status Byte 5: (0b = Off, 1b = On)
 - (LSB) bit 0 : Site Master Limit Type (0b = Single, 1b = Multiple)
 - bit 1 : Site Master Limit Beep ON/OFF
 - bit 2 : FREQ-SWR Multiple Limit Segment 1 Status On/Off
 - bit 3 : FREQ-SWR Multiple Limit Segment 2 Status On/Off
 - bit 4 : FREQ-SWR Multiple Limit Segment 3 Status On/Off
 - bit 5 : FREQ-SWR Multiple Limit Segment 4 Status On/Off
 - bit 6 : FREQ-SWR Multiple Limit Segment 5 Status On/Off
 - bit 7 : Not Used
- 383) Status Byte 6: (0b = Off, 1b = On)
 - (LSB) bits 0-1: Not Used
 - bit 2 : FREQ-RL Multiple Limit Segment 1 Status On/Off

⁵² 0 – 120 dBc

⁵³ 00h = 0dB, 01h = 10dB, 02h = 20dB, 03h = 30dB, 04h = 40dB, 05h = 50dB

- bit 3 : FREQ-RL Multiple Limit Segment 2 Status On/Off
bit 4 : FREQ-RL Multiple Limit Segment 3 Status On/Off
bit 5 : FREQ-RL Multiple Limit Segment 4 Status On/Off
bit 6 : FREQ-RL Multiple Limit Segment 5 Status On/Off
bit 7 : Not Used
- 384) Status Byte 7: (0b = Off, 1b = On)
(LSB) bits 0-1: Not Used
bit 2 : FREQ-CL Multiple Limit Segment 1 Status On/Off
bit 3 : FREQ-CL Multiple Limit Segment 2 Status On/Off
bit 4 : FREQ-CL Multiple Limit Segment 3 Status On/Off
bit 5 : FREQ-CL Multiple Limit Segment 4 Status On/Off
bit 6 : FREQ-CL Multiple Limit Segment 5 Status On/Off
bit 7 : Not Used
- 385) Status Byte 8: (0b = Off, 1b = On)
(LSB) bits 0-1: Not Used
bit 2 : DIST-SWR Multiple Limit Segment 1 Status On/Off
bit 3 : DIST-SWR Multiple Limit Segment 2 Status On/Off
bit 4 : DIST-SWR Multiple Limit Segment 3 Status On/Off
bit 5 : DIST-SWR Multiple Limit Segment 4 Status On/Off
bit 6 : DIST-SWR Multiple Limit Segment 5 Status On/Off
bit 7 : Not Used
- 386) Status Byte 9: (0b = Off, 1b = On)
(LSB) bits 0-1: Not Used
bit 2 : DIST-RL Multiple Limit Segment 1 Status On/Off
bit 3 : DIST-RL Multiple Limit Segment 2 Status On/Off
bit 4 : DIST-RL Multiple Limit Segment 3 Status On/Off
bit 5 : DIST-RL Multiple Limit Segment 4 Status On/Off
bit 6 : DIST-RL Multiple Limit Segment 5 Status On/Off
bit 7 : Not Used
- 387) Status Byte 10: (0b = Off/Beep if data is BELOW line ,
1b = On/Beep if data is ABOVE line)
(LSB) bit 0 : SPA Limit Type (0b = Single, 1b = Multiple)
bit 1 : SPA Single Limit Beep On/Off
bit 2 : SPA Single Limit Status On/Off
bit 3 : SPA Single Limit Beep Level ABOVE/BELOW
bit 4 : SPA Multiple Limit Upper Segment 1 Status On/Off
bit 5 : SPA Multiple Limit Upper Segment 1 Beep Level ABOVE/BELOW⁵⁴
bit 6 : SPA Multiple Limit Upper Segment 2 Status On/Off
bit 7 : SPA Multiple Limit Upper Segment 2 Beep Level ABOVE/BELOW
- 388) Status Byte 11 : (0b = Off/Beep if data is BELOW line ,
1b = On/Beep if data is ABOVE line)
(LSB) bit 0 : SPA Multiple Limit Upper Segment 3 Status On/Off
bit 1 : SPA Multiple Limit Upper Segment 3 Beep Level ABOVE/BELOW
bit 2 : SPA Multiple Limit Upper Segment 4 Status On/Off
bit 3 : SPA Multiple Limit Upper Segment 4 Beep Level ABOVE/BELOW
bit 4 : SPA Multiple Limit Upper Segment 5 Status On/Off
bit 5 : SPA Multiple Limit Upper Segment 5 Beep Level ABOVE/BELOW
bit 6 : SPA Multiple Limit Lower Segment 1 Status On/Off
bit 7 : SPA Multiple Limit Lower Segment 1 Beep Level ABOVE/BELOW⁵⁵
- 389) Status Byte 12 : (0b = Off/Beep if data is BELOW line ,
1b = On/Beep if data is ABOVE line)
(LSB) bit 0 : SPA Multiple Limit Lower Segment 2 Status On/Off
bit 1 : SPA Multiple Limit Lower Segment 2 Beep Level ABOVE/BELOW

⁵⁴ Beep level is always 1b for upper segmented limit line

⁵⁵ Beep level is always 0b for lower segmented limit line

- bit 2 : SPA Multiple Limit Lower Segment 3 Status On/Off
 - bit 3 : SPA Multiple Limit Lower Segment 3 Beep Level ABOVE/BELOW
 - bit 4 : SPA Multiple Limit Lower Segment 4 Status On/Off
 - bit 5 : SPA Multiple Limit Lower Segment 4 Beep Level ABOVE/BELOW
 - bit 6 : SPA Multiple Limit Lower Segment 5 Status On/Off
 - bit 7 : SPA Multiple Limit Lower Segment 5 Beep Level ABOVE/BELOW
- 390) Status Byte 13:
 (LSB) bits 0 - 1 : DTF Windowing Mode
 bit: 1 0
 | |
 0 0 - Rectangular (No Windowing)
 0 1 - Nominal Side Lobe
 1 0 - Low Side Lobe
 1 1 - Minimum Side Lobe
 bits 2 - 7 : Not Used
- 391) Status Byte 14: (0b = Off, 1b = On)
 (LSB) bit 0 : Fixed CW Mode On/Off
 bit 1 : Site Master Cal On/Off
 bit 2 : LCD Back Light On/Off
 bit 3 : Measurement Unit Metric/English (0b = English, 1b = Metric)
 bit 4 : InstaCal On/Off
 bits 5 -7 : Not Used
- 392) Status Byte 15: (0b = Off, 1b = On)
 (LSB) bit 0 : Antenna Factors Correction On/Off
 bit 1 : Not Used
 bit 2 : SPA Cal Status On/Off
 bits 3-4 : Amplitude Units (00b = dBm 01b = dBV 10b = dBmV 11b = dBuV)
 bits 5-6 : Detection alg (00b = pos. peak 01b = average 10b = neg. peak, 11b= sampling mode)
 bit 7 : Not Used
- 393) Status Byte 16: (0b = Off, 1b = On)
 (LSB) bit 0: Serial Port Echo Status On/Off
 bit 1: Return Sweep Time On/Off
 bit 2: RBW Coupling (1b = auto, 0b = manual)
 bit 3: VBW Coupling (1b = auto, 0b = manual)
 bit 4: Attenuation Coupling (1b = auto, 0b = manual)
 bit 5: Channel Power On/Off
 bit 6: Adjacent Channel Power On/Off
 bit 7: Not Used
- 394) Printer Type⁵⁶
- 395) Current Language
 (0 = English, 1 = French, 2 = German, 3 = Spanish, 4 = Chinese, 5 = Japanese)
- 396) LCD Contrast Value (0-255)
- 397) RTC battery ⁵⁷(Higher byte)
- 398) RTC battery (Lower byte)
- 399) PC board revision ⁵⁸(Higher byte)
- 400) PC board revision (Lower byte)
- 401) Reference Level Offset⁵⁹ (Highest byte)
- 402) Reference: Level Offset
- 403) Reference Level Offset
- 404) Reference Level Offset (Lowest byte)

⁵⁶ See Control Byte #30 for supported printers.

⁵⁷ Value sent as Volts * 10. For example, 2.7V = 27.

⁵⁸ This value is for internal use only.

⁵⁹ Value sent as (value in dBm * 1000) + 270,000

Trigger Self-Test – Control Byte #21 (15h)

Description: Triggers a self test on the Site Master.

Bytes to Follow: 0 bytes

Site Master Returns: 12 bytes

- 1) Self-test report: (0b = Fail, 1b = Pass)
(LSB) bit 0 : Phase Lock Loop
bit 1 : Integrator
bit 2 : Battery
bit 3 : Temperature
bit 4 : EEPROM read/write
bit 5 : RTC Battery
bits 6- 7 : Not Used
- 2) Self-test report: (0b = Fail, 1b = Pass)
(LSB) bit 0 : Spectrum Analyzer Lock
bits 1–7 : Not Used
- 3) Battery Voltage (Higher byte)
- 4) Battery Voltage (Lower byte)
- 5) Temperature (Higher byte)
- 6) Temperature (Lower byte)
- 7) Lock Fail Counter (Higher byte)
- 8) Lock Fail Counter (Lower byte)
- 9) Integrator Fail Counter (Higher byte)
- 10) Integrator Fail Counter (Lower byte)
- 11) Spectrum Analyzer Lock Fail Counter (Higher byte)
- 12) Spectrum Analyzer Lock Fail Counter (Lower byte)

Notes:

Battery Voltage in 1/10th of a Volt (e.g. 124 = 12.4 Volts)

Temperature in 1/10th of degree Celsius (e.g. 362 = 36.2 °C) or degree Fahrenheit (e.g. 934 = 93.4 °F), depending on the current measurement unit (Metric or English) selected

Read Fail Counter – Control Byte #22 (16h)

Description: Reads the Fail Counter. Values are integer numbers of failures.

Bytes to Follow: 0 bytes

Site Master Returns: 8 bytes

- 1) Value of SM Lock Fail Counter (Higher byte)
 - 2) Value of SM Lock Fail Counter (Lower byte)
 - 3) Value of Integration Fail Counter (Higher byte)
 - 4) Value of Integration Fail Counter (Lower byte)
 - 5) Value of SA Lock Fail Counter (Higher byte)
 - 6) Value of SA Lock Fail Counter (Lower byte)
 - 7) Value of SA Fatal Error Counter (Higher byte)
 - 8) Value of SA Fatal Error Counter (Lower byte)
-

Clear Fail Counters – Control Byte #23 (17h)

Description: Resets the Lock Fail Counters, Integrator Fail Counter and spectrum analyzer Fatal Error Counter.

Bytes to Follow: 0 bytes

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
-

Query Trace Names – Control Byte #24 (18h)

Description: Returns a list of all saved traces.

Bytes to Follow: 0 bytes

Site Master Returns: 3 + (41 x number of save traces) bytes

- 1-2) # of saved traces

For each trace:

- 1-2) Trace Index
- 3) Measurement Mode (refer to Control Byte #3)
- 4-21) Date/Time in string format (“MM/DD/YYYYHH:MM:SS”)
- 22-25) Date/Time as Unsigned Long Integer (Seconds Since January 1, 1970)
- 26-41) Trace Name (16 bytes)

- 255 (FFh) Operation Complete Byte
-

Delete Sweep Trace – Control Byte #25 (19h)

Description: Delete single trace or all stored sweep traces in Site Master.

Bytes to Follow: 1 byte

- 1) 0 - Delete all traces
X - Delete single trace #X

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
-

OBSOLETE: Upload SPA Sweep Trace – Control Byte #26 (1Ah)

This command exists for backward compatibility with the S33xC models. Features new to the S33xD models are not available here. To access the new features use Control Byte #36 (24h).

Description: Uploads a spectrum analyzer sweep trace to Site Master.

For data formats, refer to the footnotes listed beside the return bytes.

Bytes to Follow: 1921 bytes

- 1-2) # of following bytes (1919)
- 3) Measurement Mode⁶⁰
- 4-7) Time/Date (long integer format⁶¹)
- 8-17) Date in String Format (mm/dd/yyyy)

⁶⁰ See Control Byte #3 “Select Measurement Mode” for measurement modes.

⁶¹ Time/Date long integer representation is in seconds since January 1, 1997.

- 18-25) Time in String Format (hh:mm:ss)
- 26-41) Reference Number/Trace Name (16 bytes in ASCII)
- 42-43) # data points (400)
- 44) Start Frequency (in Hz) (Highest byte)
- 45) Start Frequency (in Hz)
- 46) Start Frequency (in Hz)
- 47) Start Frequency (in Hz) (Lowest byte)
- 48) Stop Frequency (in Hz) (Highest byte)
- 49) Stop Frequency (in Hz)
- 50) Stop Frequency (in Hz)
- 51) Stop Frequency (in Hz) (Lowest byte)
- 52) Center Frequency (in Hz) (Highest byte)
- 53) Center Frequency (in Hz)
- 54) Center Frequency (in Hz)
- 55) Center Frequency (in Hz) (Lowest byte)
- 56) Frequency Span (in Hz) (Highest byte)
- 57) Frequency Span (in Hz)
- 58) Frequency Span (in Hz)
- 59) Frequency Span (in Hz) (Lowest byte)
- 60) Ref Level⁶² (Highest byte)
- 61) Ref Level
- 62) Ref Level
- 63) Ref Level (Lowest byte)
- 64) Scale per div⁶³ (Highest byte)
- 65) Scale per div
- 66) Scale per div
- 67) Scale per div (Lowest byte)
- 68) Marker 1⁶⁴ (Higher byte)
- 69) Marker 1 (Lower byte)
- 70) Marker 2 (Higher byte)
- 71) Marker 2 (Lower byte)
- 72) Marker 3 (Higher byte)
- 73) Marker 3 (Lower byte)
- 74) Marker 4 (Higher byte)
- 75) Marker 4 (Lower byte)
- 76) Marker 5 (Higher byte)
- 77) Marker 5 (Lower byte)
- 78) Marker 6 (Higher byte)
- 79) Marker 6 (Lower byte)
- 80) Single Limit⁶⁵ (Highest byte)
- 81) Single Limit
- 82) Single Limit
- 83) Single Limit (Lowest byte)
- 84) Multiple Upper Limit 1 Start X (Frequency in Hz) (Highest byte)
- 85) Multiple Upper Limit 1 Start X (Frequency in Hz)
- 86) Multiple Upper Limit 1 Start X (Frequency in Hz)
- 87) Multiple Upper Limit 1 Start X (Frequency in Hz) (Lowest byte)
- 88) Multiple Upper Limit 1 Start Y (Power Level) (Highest byte)
- 89) Multiple Upper Limit 1 Start Y (Power Level)
- 90) Multiple Upper Limit 1 Start Y (Power Level)

⁶² Value sent as (value in dBm * 1000) + 270,000

⁶³ Value sent as (value * 1000)

⁶⁴ Marker values are sent as # of data point on display.

See Control Byte #102, "Set Spectrum Analyzer Marker" for calculation of data point.

⁶⁵ All amplitude values are sent as (value in dBm * 1000) + 270,000

- 91) Multiple Upper Limit 1 Start Y (Power Level) (Lowest byte)
- 92) Multiple Upper Limit 1 End X (Frequency in Hz) (Highest byte)
- 93) Multiple Upper Limit 1 End X (Frequency in Hz)
- 94) Multiple Upper Limit 1 End X (Frequency in Hz)
- 95) Multiple Upper Limit 1 End X (Frequency in Hz) (Lowest byte)
- 96) Multiple Upper Limit 1 End Y (Power Level) (Highest byte)
- 97) Multiple Upper Limit 1 End Y (Power Level)
- 98) Multiple Upper Limit 1 End Y (Power Level)
- 99) Multiple Upper Limit 1 End Y (Power Level) (Lowest byte)
- 100-243) Multiple Upper Limits 2-5, Multiple Lower Limits 1-5 (see bytes 84-99 for format)
- 244) RBW Setting⁶⁶ (Highest byte)
- 245) RBW Setting
- 246) RBW Setting
- 247) RBW Setting (Lowest byte)
- 248) VBW Setting⁶⁷ (Highest byte)
- 249) VBW Setting
- 250) VBW Setting
- 251) VBW Setting (Lowest byte)
- 252) OCC BW Method (00h = % of power, 01h = dB down)
- 253) OCC BW % Value (0-99) (Highest byte)
- 254) OCC BW % Value (0-99)
- 255) OCC BW % Value (0-99)
- 256) OCC BW % Value (0-99) (Lowest byte)
- 257) OCC BW dBc (0-120) (Highest byte)
- 258) OCC BW dBc (0-120)
- 259) OCC BW dBc (0-120)
- 260) OCC BW dBc (0-120) (Lowest byte)
- 261) Attenuation⁶⁸ (Highest byte)
- 262) Attenuation
- 263) Attenuation
- 264) Attenuation (Lowest byte)
- 265-280) Antenna Name (16 bytes in ASCII)
- 281) Status Byte 1: (0b = Off, 1b = On)
 - (LSB) bit 0 : Marker 1 On/Off
 - bit 1 : Marker 2 On/Off
 - bit 2 : Marker 3 On/Off
 - bit 3 : Marker 4 On/Off
 - bit 4 : Marker 5 On/Off
 - bit 5 : Marker 6 On/Off
 - bits 6-7: Not Used
- 282) Status Byte 2: (0b = Off, 1b = On)
 - (LSB) bit 0 : Not Used
 - bit 1 : Marker 2 Delta On/Off
 - bit 2 : Marker 3 Delta On/Off
 - bit 3 : Marker 4 Delta On/Off
 - bits 4-7: Not Used
- 283) Status Byte 3: (0b = Off, 1b = On)
 - (LSB) bit 0 : Antenna Factor Correction On/Off
 - bits 1-2 : Detection alg (00b = pos. peak 01b = average 10b = neg. peak)
 - bits 3-4 : Amplitude Units (00b = dBm 01b = dBV 10b = dBmV 11b = dBuV)
 - bit 5 : Channel Power On/Off
 - bit 6 : Adjacent Channel Power Ratio On/Off

⁶⁶ Valid frequencies (in Hz) are 10,000 30,000 100,000 1,000,000

⁶⁷ Valid frequencies (in Hz) are 100, 300, 1,000 3,000 10,000 30,000 100,000 300,000

⁶⁸ Value sent as (value * 1000)

- bit 7: Not Used
- 284) Status Byte 4
 (0b = Off/Beep if data is BELOW line, 1b = On/Beep if data is ABOVE line)
 (LSB) bit 0 : Limit Type (0b = Single, 1b = Multiple)
 bit 1 : Single Limit On/Off
 bit 2 : Single Limit Beep Level (0b = beep when data is below line 1b = above)
 bit 3 : Not Used
 bit 4 : Multiple Limit Upper Segment 1 Status On/Off
 bit 5 : Multiple Limit Upper Segment 1 Beep Level ABOVE/BELOW
 bit 6 : Multiple Limit Upper Segment 2 Status On/Off
 bit 7 : Multiple Limit Upper Segment 2 Beep Level ABOVE/BELOW
- 285) Status Byte 5
 (0b = Off/Beep if data is BELOW line, 1b = On/Beep if data is ABOVE line)
 (LSB) bit 0 : Multiple Limit Upper Segment 3 Status On/Off
 bit 1 : Multiple Limit Upper Segment 3 Beep Level ABOVE/BELOW
 bit 2 : Multiple Limit Upper Segment 4 Status On/Off
 bit 3 : Multiple Limit Upper Segment 4 Beep Level ABOVE/BELOW
 bit 4 : Multiple Limit Upper Segment 5 Status On/Off
 bit 5 : Multiple Limit Lower Segment 5 Beep Level ABOVE/BELOW
 bit 6 : Multiple Limit Lower Segment 1 Status On/Off
 bit 7 : Multiple Limit Lower Segment 1 Beep Level ABOVE/BELOW
- 286) Status Byte 6
 (0b = Off/Beep if data is BELOW line, 1b = On/Beep if data is ABOVE line)
 (LSB) bit 0 : Multiple Limit Lower Segment 2 Status On/Off
 bit 1 : Multiple Limit Lower Segment 2 Beep Level ABOVE/BELOW
 bit 2 : Multiple Limit Lower Segment 3 Status On/Off
 bit 3 : Multiple Limit Lower Segment 3 Beep Level ABOVE/BELOW
 bit 4 : Multiple Limit Lower Segment 4 Status On/Off
 bit 5 : Multiple Limit Lower Segment 4 Beep Level ABOVE/BELOW
 bit 6 : Multiple Limit Lower Segment 5 Status On/Off
 bit 7 : Multiple Limit Lower Segment 5 Beep Level ABOVE/BELOW
- 287) Status Byte 7
 (LSB) bits 0-6: Number of Sweeps to Average (1-25, 1 implies no averaging)
 bit 7 : Not Used
- 288) Reference Level Offset⁶⁹ (Highest byte)
- 289) Reference Level Offset
- 290) Reference Level Offset
- 291) Reference Level Offset (Lowest byte)
- 292-321) Not Used
- 322-1921) Sweep Data (400 points * 4 bytes/point = 1600 bytes)
 4 bytes for each data point
 1. dBm⁷⁰ (Highest byte)
 2. dBm
 3. dBm
 4. dBm (Lowest byte)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
- 224 (E0h) Parameter Error: Not enough bytes transferred
- 225 (E1h) Memory Error: Not enough memory to store data
- 238 (EEh) Time-out Error

⁶⁹ Value sent as (Value in dBm * 1000) + 270,000

⁷⁰ Value sent as (Value in dBm * 1000) + 270,000

Query Sweep Memory – Control Byte #27 (1Bh)

Description: Queries Site Master for percentage of memory that is available for trace storage.

Bytes to Follow: 0 bytes

Site Master Returns: 1 byte

- 1) % of memory currently available (0 to 100)
-

OBSOLETE: Upload Site Master Sweep Trace – Control Byte #28 (1Ch)

This command exists for backward compatibility with the S33xC models. Features new to the S33xD models are not available here. To access the new features use Control Byte #36 (24h).

Description: Uploads a Site Master Mode sweep trace to the Site Master.

Bytes to Follow: 1255, 2287, or 4351 Bytes (depending on resolution)

- 1-2) # of following bytes
- 3) Measurement Mode⁷¹
- 4-7) Time/Date (in Long Integer)
- 8-17) Date in String Format (mm/dd/yyyy)
- 18-25) Time in String Format (hh:mm:ss)
- 26-41) Reference number stamp (16 ASCII bytes)
- 42-43) # of data points
- 44) Start Frequency (Highest byte)
- 45) Start Frequency
- 46) Start Frequency
- 47) Start Frequency (Lowest byte)
- 48) Stop Frequency (Highest byte)⁷⁴
- 49) Stop Frequency
- 50) Stop Frequency
- 51) Stop Frequency (Lowest byte)
- 52) Minimum Frequency Step Size (Highest byte)
- 53) Minimum Frequency Step Size
- 54) Minimum Frequency Step Size
- 55) Minimum Frequency Step Size (Lowest byte)
- 56) Scale Top (Highest byte)⁷²
- 57) Scale Top
- 58) Scale Top
- 59) Scale Top (Lowest byte)
- 60) Scale Bottom (Highest byte)
- 61) Scale Bottom
- 62) Scale Bottom
- 63) Scale Bottom (Lowest byte)
- 64) Frequency Marker 1 (Higher byte)⁷³
- 65) Frequency Marker 1 (Lower byte)
- 66) Frequency Marker 2 (Higher byte)
- 67) Frequency Marker 2 (Lower byte)
- 68) Frequency Marker 3 (Higher byte)
- 69) Frequency Marker 3 (Lower byte)
- 70) Frequency Marker 4 (Higher byte)
- 71) Frequency Marker 4 (Lower byte)

⁷¹ See Control Byte #3 “Set Measurement Mode” for available measurement modes.

⁷² See Control Byte #4, “Set Site Master Scale” for data format.

⁷³ Marker point = (Number of data points – 1) * (marker freq – start freq) / (stop freq – start freq)

- 72) Frequency Marker 5 (Higher byte)
- 73) Frequency Marker 5 (Lower byte)
- 74) Frequency Marker 6 (Higher byte)
- 75) Frequency Marker 6 (Lower byte)
- 76) Single Limit Line Value (Highest byte)⁷⁴
- 77) Single Limit Line Value
- 78) Single Limit Line Value
- 79) Single Limit Line Value (Lowest byte)
- 80) Multiple Limit Segment # (1)
- 81) Multiple Limit Segment Status (00h = Off, 01h = On)
- 82) Multiple Limit Start X (Highest byte)⁷⁵
- 83) Multiple Limit Start X
- 84) Multiple Limit Start X
- 85) Multiple Limit Start X (Lowest byte)
- 86) Multiple Limit Start Y (Higher byte)
- 87) Multiple Limit Start Y (Lower byte)
- 88) Multiple Limit End X (Highest byte)
- 89) Multiple Limit End X
- 90) Multiple Limit End X
- 91) Multiple Limit End X (Lowest byte)
- 92) Multiple Limit End Y (Higher byte)
- 93) Multiple Limit End Y (Lower byte)
- 94-149) Repeat bytes 80-93 for segments 2-5
- 150) Start Distance (Highest byte)⁷⁶
- 151) Start Distance
- 152) Start Distance
- 153) Start Distance (Lowest byte)
- 154) Stop Distance (Highest byte)
- 155) Stop Distance
- 156) Stop Distance
- 157) Stop Distance (Lowest byte)
- 158) Distance Marker 1 (Higher byte)⁷⁷
- 159) Distance Marker 1 (Lower byte)
- 160) Distance Marker 2 (Higher byte)
- 161) Distance Marker 2 (Lower byte)
- 162) Distance Marker 3 (Higher byte)
- 163) Distance Marker 3 (Lower byte)
- 164) Distance Marker 4 (Higher byte)
- 165) Distance Marker 4 (Lower byte)
- 166) Distance Marker 5 (Higher byte)
- 167) Distance Marker 5 (Lower byte)
- 168) Distance Marker 6 (Higher byte)
- 169) Distance Marker 6 (Lower byte)
- 170) Relative Propagation Velocity (Highest byte)⁷⁸
- 171) Relative Propagation Velocity
- 172) Relative Propagation Velocity
- 173) Relative Propagation Velocity (Lowest byte)
- 174) Cable Loss (Highest byte)⁷⁹
- 175) Cable Loss

⁷⁴ See Control Byte #6, “Set Site Master Single Limit” for data format

⁷⁵ See Control Byte #112, “Set Site Master Segmented Limit Lines” for data format.

⁷⁶ Distance data uses units 1/100,000m or 1/100,000 ft

⁷⁷ Marker point = (# of data points – 1) * (marker dist – start dist) / (stop dist – start dist)

⁷⁸ Relative Propagation Velocity uses units 1/100,000

⁷⁹ Cable Loss uses units 1/100,000 dB/m or 1/100,000 dB/ft

- 176) Cable Loss
- 177) Cable Loss (Lowest byte)
- 178) Status Byte 1: (0b = Off, 1b = On)
- (LSB) bit 0 : Marker 1 On/Off
 - bit 1 : Marker 2 On/Off
 - bit 2 : Marker 3 On/Off
 - bit 3 : Marker 4 On/Off
 - bit 4 : Marker 5 On/Off
 - bit 5 : Marker 6 On/Off
 - bits 6-7 : Not Used
- 179) Status Byte 2: (0b = Off, 1b = On)
- (LSB) bit 0 : Marker 2 Delta On/Off
 - bit 1 : Marker 3 Delta On/Off
 - bit 2 : Marker 4 Delta On/Off
 - bits 3-7: Not Used
- 180) Status Byte 3: (0b = Off, 1b = On)⁸⁰
- (LSB) bit 0 : Single Limit On/Off
 - bit 1: CW On/Off
 - bits 2-3: Not Used
 - bit 4 : InstaCal On/Off
 - bit 5 : Cal On/Off
 - bit 6 : Limit Type (0b = Single; 1b = Multiple)
 - bit 7 : Unit of measurement (1b = Metric, 0b = English)
- 181) Status Byte 4:
- (LSB) bit 0 - 1 : DTF Windowing Mode
 - bit: 1 0
 - | |
 - 0 0 - Rectangular (No Windowing)
 - 0 1 - Nominal Side Lobe
 - 1 0 - Low Side Lobe
 - 1 1 - Minimum Side Lobe
 - bits 2 - 7 : Not Used
- 182-215) Not Used
- 216-1255) Sweep Data (130 points * 8 bytes/point= 1040 bytes)
- 216-2287) (259 points * 8 bytes/point= 2072 bytes)
- 216-4351) (517 points * 8 bytes/point= 4136 bytes)
- 8 bytes for each data point
1. Gamma⁸¹ MSB
 2. Gamma
 3. Gamma
 4. Gamma LSB
 5. Phase⁸² MSB
 6. Phase
 7. Phase
 8. Phase LSB

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
- 224 (E0h) Parameter Error: Not enough bytes transferred
- 225 (E1h) Memory Error: Not enough memory to store data
- 238 (EEh) Time-out Error

⁸⁰ Bits (4,5) are as follows: (0,0)=Cal Off, (0,1)=OSL Cal, (1,0) = Impossible, (1,1) = InstaCal

⁸¹ Gamma data uses 1/1000 units.

⁸² Phase data uses 1/10 degree unit.

Notes:

return loss = $-20 * (\log(\text{Gamma}) / \log(10))$

VSWR = $(1+\text{Gamma})/(1-\text{Gamma})$

Phase compares the reflected to the incident (reference)

Query System Status – Control Byte #29 (1Dh)

This command is new to the S33xD. Use it instead of Control Byte #20 to access the new features.

Description: Queries the Site Master for current system settings. Unlike Control Byte #20, this command returns only data that is valid for the active mode, plus system settings, such as the defined printer.

The current state of the Site Master represents the state after the last successful remote control operation. For example, change the start frequency to another valid frequency while in remote mode, then execute control byte #29. The new start frequency will be returned in the defined bytes, even though no sweep has been performed with that frequency.

Bytes to Follow: 0 bytes

Site Master Returns:

For All Modes:

- 1) Number of Following Bytes (Higher byte)
- 2) Number of Following Bytes (Lower byte)
- 3) Measurement Mode⁸³
- 4) Printer Type⁸⁴
- 5) Current Language
(00h = English, 01h = French, 02h = German, 03h = Spanish, 04h = Chinese, 05h = Japanese)
- 6) LCD Contrast Value (0-255)
- 7) Date Format
(00h = MM/DD/YYYY, 01h = DD/MM/YYYY, 02h = YYYY/MM/DD)
- 8) RTC battery⁸⁵ (Higher byte)
- 9) RTC battery (Lower byte)
- 10) PC Board Revision⁸⁶ (Higher byte)
- 11) PC Board Revision (Lower byte)
- 12-13) Digital Mother Board ID. Beginning with motherboard 64968, the hardware includes a 9-bit digital ID port. The digital ID will be used together with the PC Board Revision (mother board ID voltage) to identify the board and “dash” number. For boards prior to 64968, bytes 12 and 13 will be 0
- 14-25) Not Used

For Site Master VNA Modes:

- 26) Site Master VNA Mode Data Points (Higher byte)
- 27) Site Master VNA Mode Data Points (Lower byte)
- 28) VNA Start Frequency⁸⁷ (Highest byte)
- 29) VNA Start Frequency
- 30) VNA Start Frequency
- 31) VNA Start Frequency (Lowest byte)
- 32) VNA Stop Frequency⁸⁸ (Highest byte)
- 33) VNA Stop Frequency
- 34) VNA Stop Frequency

⁸³ Refer to Control Byte #3 “Select Measurement Mode” for valid measurement modes.

⁸⁴ See Control Byte #30 for supported printers.

⁸⁵ Value sent as Volts * 10. For example, 2.7 V = 27.

⁸⁶ This value is for internal use only.

⁸⁷ Frequency is scaled by the frequency scale factor specified in bytes 218-219.

⁸⁸ Frequency is scaled by the frequency scale factor specified in bytes 218-219.

- 35) VNA Stop Frequency (Lowest byte)
- 36) VNA Scale Start (Highest byte)⁸⁹
- 37) VNA Scale Start
- 38) VNA Scale Start
- 39) VNA Scale Start (Lowest byte)
- 40) VNA Scale Stop (Highest byte)
- 41) VNA Scale Stop
- 42) VNA Scale Stop
- 43) VNA Scale Stop (Lowest byte)
- 44) VNA Frequency Marker 1 (Higher byte)⁹⁰
- 45) VNA Frequency Marker 1 (Lower byte)
- 46) VNA Frequency Marker 2 (Higher byte)
- 47) VNA Frequency Marker 2 (Lower byte)
- 48) VNA Frequency Marker 3 (Higher byte)
- 49) VNA Frequency Marker 3 (Lower byte)
- 50) VNA Frequency Marker 4 (Higher byte)
- 51) VNA Frequency Marker 4 (Lower byte)
- 52) VNA Frequency Marker 5 (Higher byte)
- 53) VNA Frequency Marker 5 (Lower byte)
- 54) VNA Frequency Marker 6 (Higher byte)
- 55) VNA Frequency Marker 6 (Lower byte)
- 56) Site Master VNA Single Limit (Highest byte)⁹¹
- 57) Site Master VNA Single Limit
- 58) Site Master VNA Single Limit
- 59) Site Master VNA Single Limit (Lowest byte)
- 60) VNA Multiple Limit Segment # (1)
- 61) VNA Multiple Limit Segment Status (0h = Off, 01h = On)
- 62) VNA Multiple Limit Segment Start X (Highest byte)⁹²
- 63) VNA Multiple Limit Segment Start X
- 64) VNA Multiple Limit Segment Start X
- 65) VNA Multiple Limit Segment Start X (Lowest byte)
- 66) VNA Multiple Limit Segment Start Y (Higher byte)
- 67) VNA Multiple Limit Segment Start Y (Lowest byte)
- 68) VNA Multiple Limit Segment End X (Highest byte)⁹³
- 69) VNA Multiple Limit Segment End X
- 70) VNA Multiple Limit Segment End X
- 71) VNA Multiple Limit Segment End X (Lowest byte)
- 72) VNA Multiple Limit Segment End Y (Higher byte)
- 73) VNA Multiple Limit Segment End Y (Lowest byte)
- 74-129) Repeat bytes 60 – 73 for segments 2 - 5
- 130) Start Distance (Highest byte)⁹⁴
- 131) Start Distance
- 132) Start Distance
- 133) Start Distance (Lowest byte)
- 134) Stop Distance (Highest byte)
- 135) Stop Distance
- 136) Stop Distance

⁸⁹ See “Set Site Master VNA Scale” Control Byte #4 for data format.

⁹⁰ Marker Point = (# data points – 1) * (marker freq – start freq) / (stop freq – start freq)
Where # of data points can be found in bytes 2-3, start freq is in bytes 4-7, and stop freq is in bytes 8-11.

⁹¹ See Control Byte #6, “Set Site Master VNA Single Limit” for data format.

⁹² See Control Byte #112, “Set Site Master VNA Segmented Limit Lines” for data format. Frequency is scaled by the frequency scale factor specified in bytes 218-219.

⁹³ Frequency is scaled by the frequency scale factor specified in bytes 218-219.

⁹⁴ Distance data uses units 1/100,000m or 1/100,000 ft

137. Stop Distance (Lowest byte)
 138. Distance Marker 1 (Higher byte)⁹⁵
 139. Distance Marker 1 (Lower byte)
 140. Distance Marker 2 (Higher byte)
 141. Distance Marker 2 (Lower byte)
 142. Distance Marker 3 (Higher byte)
 143. Distance Marker 3 (Lower byte)
 144. Distance Marker 4 (Higher byte)
 145. Distance Marker 4 (Lower byte)
 146. Distance Marker 5 (Higher byte)
 147. Distance Marker 5 (Lower byte)
 148. Distance Marker 6 (Higher byte)
 149. Distance Marker 6 (Lower byte)
 150. Relative Propagation Velocity (Highest byte)⁹⁶
 151. Relative Propagation Velocity
 152. Relative Propagation Velocity
 153. Relative Propagation Velocity (Lowest byte)
 154. Cable Loss (Highest byte)⁹⁷
 155. Cable Loss
 156. Cable Loss
 157. Cable Loss (Lowest byte)
 158. Average Cable Loss⁹⁸ (Highest byte)
 159. Average Cable Loss
 160. Average Cable Loss
 161. Average Cable Loss (Lowest byte)
 162. Status Byte 1: (0b = Off, 1b = On)
 (LSB) bit 0 : Site Master Marker 1 On/Off
 bit 1 : Site Master Marker 2 On/Off
 bit 2 : Site Master Marker 3 On/Off
 bit 3 : Site Master Marker 4 On/Off
 bit 4 : Site Master Marker 5 On/Off
 bit 5 : Site Master Marker 6 On/Off
 bits 6-7 : Not Used
 163. Status Byte 2: (0b = Off, 1b = On)
 (LSB) bit 0 : Not Used
 bit 1 : Site Master Marker 2 Delta On/Off
 bit 2 : Site Master Marker 3 Delta On/Off
 bit 3 : Site Master Marker 4 Delta On/Off
 bits 4-7: Not Used
 164. Status Byte 3: (0b = Off, 1b = On)
 (LSB) bit 0 : Site Master Limit Type (0b = Single, 1b = Multiple)
 bit 1 : Site Master Limit Beep On/Off
 bit 2 : FREQ-SWR Multiple Limit Segment 1 Status On/Off
 bit 3 : FREQ-SWR Multiple Limit Segment 2 Status On/Off
 bit 4 : FREQ-SWR Multiple Limit Segment 3 Status On/Off
 bit 5 : FREQ-SWR Multiple Limit Segment 4 Status On/Off
 bit 6 : FREQ-SWR Multiple Limit Segment 5 Status On/Off
 bit 7 : Site Master Single Limit Status On/Off
 165. Status Byte 4: (0b = Off, 1b = On)
 (LSB) bits 0-1: Not Used

⁹⁵ Marker Point = (# data points - 1) * (marker dist - start dist) / (stop dist - start dist)

Where # of data points can be found in bytes 2-3, start dist is in bytes 106-109, and stop dist is in bytes 110-113.

⁹⁶ Relative Propagation Velocity uses units 1/100,000.

⁹⁷ Cable loss uses units 1/100,000 dB/m or 1/100,000 dB/ft.

⁹⁸ Average Cable Loss is dB * 1000.

- bit 2: FREQ-RL Multiple Limit Segment 1 Status On/Off
 - bit 3: FREQ-RL Multiple Limit Segment 2 Status On/Off
 - bit 4: FREQ-RL Multiple Limit Segment 3 Status On/Off
 - bit 5: FREQ-RL Multiple Limit Segment 4 Status On/Off
 - bit 6: FREQ-RL Multiple Limit Segment 5 Status On/Off
 - bit 7: Not Used
166. Status Byte 5: (0b = Off, 1b = On)
- (LSB) bits 0-1: Not Used
 - bit 2: FREQ-CL Multiple Limit Segment 1 Status On/Off
 - bit 3: FREQ-CL Multiple Limit Segment 2 Status On/Off
 - bit 4: FREQ-CL Multiple Limit Segment 3 Status On/Off
 - bit 5: FREQ-CL Multiple Limit Segment 4 Status On/Off
 - bit 6: FREQ-CL Multiple Limit Segment 5 Status On/Off
 - bit 7: Not Used
167. Status Byte 6: (0b = Off, 1b = On)
- (LSB) bits 0-1: Not Used
 - bit 2 : DIST-SWR Multiple Limit Segment 1 Status On/Off
 - bit 3 : DIST-SWR Multiple Limit Segment 2 Status On/Off
 - bit 4 : DIST-SWR Multiple Limit Segment 3 Status On/Off
 - bit 5 : DIST-SWR Multiple Limit Segment 4 Status On/Off
 - bit 6: DIST-SWR Multiple Limit Segment 5 Status On/Off
 - bit 7 : Not Used
168. Status Byte 7: (0b = Off, 1b = On)
- (LSB) bits 0-1: Not Used
 - bit 2: DIST-RL Multiple Limit Segment 1 Status On/Off
 - bit 3: DIST-RL Multiple Limit Segment 2 Status On/Off
 - bit 4: DIST-RL Multiple Limit Segment 3 Status On/Off
 - bit 5: DIST-RL Multiple Limit Segment 4 Status On/Off
 - bit 6: DIST-RL Multiple Limit Segment 5 Status On/Off
 - bit 7: Not Used
169. Status Byte 8:
- (LSB) bits 0 - 1 : DTF Windowing Mode
 - bit: 1 0
 - | |
 - 0 0 - Rectangular (No Windowing)
 - 0 1 - Nominal Side Lobe
 - 1 0 - Low Side Lobe
 - 1 1 - Minimum Side Lobe
 - bit 2: Serial Port Echo Status On/Off
 - bits 3 – 7 : Not Used
170. Status Byte 9: (0b = Off, 1b = On)
- (LSB) bit 0 : Fixed CW Mode On/Off
 - bit 1 : Site Master VNA Cal On/Off
 - bit 2 : LCD Back Light On/Off
 - bit 3 : Measurement Unit Metric/English (0b = English, 1b = Metric)
 - bit 4 : InstaCal On/Off
 - bits 5-6: Not Used
 - bit 7 : Cal Mode (0b = OSL Cal, 1b = FlexCal)
171. VNA Signal Standard⁹⁹ (Higher byte)
172. VNA Signal Standard (Lower byte)
- 173-196. VNA Signal Standard Name, 24 bytes of ASCII
- 197-217. VNA Cable Name, 21 bytes of ASCII
218. Frequency Scale Factor¹⁰⁰ (Higher byte)

⁹⁹ Index into Standard List (use control byte #89 to retrieve the ASCII string name). “No Standard” sent as FFFEh

¹⁰⁰ Frequency Scale Factor is in number of Hz.

219. Frequency Scale Factor (Lower byte)
220-300) Not Used

For Spectrum Analyzer Mode/Transmission Mode (Option 21):

- 26) Spectrum Analyzer Mode Data Points (Higher byte)
- 27) Spectrum Analyzer Mode Data Points (Lower byte)
- 28) Spectrum Analyzer Start Frequency¹⁰¹ (Highest byte)
- 29) Spectrum Analyzer Start Frequency
- 30) Spectrum Analyzer Start Frequency
- 31) Spectrum Analyzer Start Frequency (Lowest byte)
- 32) Spectrum Analyzer Stop Frequency¹⁰² (Highest byte)
- 33) Spectrum Analyzer Stop Frequency
- 34) Spectrum Analyzer Stop Frequency
- 35) Spectrum Analyzer Stop Frequency (Lowest byte)
- 36) Spectrum Analyzer Center Frequency¹⁰³ (Highest byte)
- 37) Spectrum Analyzer Center Frequency
- 38) Spectrum Analyzer Center Frequency
- 39) Spectrum Analyzer Center Frequency (Lowest byte)
- 40) Spectrum Analyzer Frequency Span¹⁰⁴ (Highest byte)
- 41) Spectrum Analyzer Frequency Span
- 42) Spectrum Analyzer Frequency Span
- 43) Spectrum Analyzer Frequency Span (Lowest byte)
- 44) Spectrum Analyzer Minimum Frequency Step Size (Highest byte)
- 45) Spectrum Analyzer Minimum Frequency Step Size
- 46) Spectrum Analyzer Minimum Frequency Step Size
- 47) Spectrum Analyzer Minimum Frequency Step Size (Lowest byte)
- 48) Ref Level (Highest byte)¹⁰⁵
- 49) Ref Level
- 50) Ref Level
- 51) Ref Level (Lowest byte)
- 52) Scale per div (Highest byte)¹⁰⁶
- 53) Scale per div
- 54) Scale per div
- 55) Scale per div (Lowest byte)
- 56) Spectrum Analyzer Frequency Marker 1 (Higher byte)¹⁰⁷
- 57) Spectrum Analyzer Frequency Marker 1 (Lower byte)
- 58) Spectrum Analyzer Frequency Marker 2 (Higher byte)
- 59) Spectrum Analyzer Frequency Marker 2 (Lower byte)
- 60) Spectrum Analyzer Frequency Marker 3 (Higher byte)
- 61) Spectrum Analyzer Frequency Marker 3 (Lower byte)
- 62) Spectrum Analyzer Frequency Marker 4 (Higher byte)
- 63) Spectrum Analyzer Frequency Marker 4 (Lower byte)
- 64) Spectrum Analyzer Frequency Marker 5 (Higher byte)
- 65) Spectrum Analyzer Frequency Marker 5 (Lower byte)
- 66) Spectrum Analyzer Frequency Marker 6 (Higher byte)
- 67) Spectrum Analyzer Frequency Marker 6 (Lower byte)
- 68) Spectrum Analyzer Single Limit (Highest byte)¹⁰⁸

¹⁰¹ Scaled by Frequency Scale Factor (bytes 321-322)

¹⁰² Scaled by Frequency Scale Factor (bytes 321-322)

¹⁰³ Scaled by Frequency Scale Factor (bytes 321-322)

¹⁰⁴ Scaled by Frequency Scale Factor (bytes 321-322)

¹⁰⁵ Value sent as (value in dBm * 1000) + 270,000)

¹⁰⁶ Value sent as (value * 1000)

¹⁰⁷ Value sent as data point on the display. Equivalent frequency = (point * span / (# data points - 1)) + start frequency.

- 69) Spectrum Analyzer Single Limit
- 70) Spectrum Analyzer Single Limit
- 71) Spectrum Analyzer Single Limit (Lowest byte)
- 72) SPA Multiple Upper Limit 1 Start X¹⁰⁹ (Highest byte)
- 73) SPA Multiple Upper Limit 1 Start X
- 74) SPA Multiple Upper Limit 1 Start X
- 75) SPA Multiple Upper Limit 1 Start X (Lowest byte)
- 76) SPA Multiple Upper Limit 1 Start Y (Power Level) (Highest byte)¹¹⁰
- 77) SPA Multiple Upper Limit 1 Start Y (Power Level)
- 78) SPA Multiple Upper Limit 1 Start Y (Power Level)
- 79) SPA Multiple Upper Limit 1 Start Y (Power Level) (Lowest byte)
- 80) SPA Multiple Upper Limit 1 End X¹¹¹ (Highest byte)
- 81) SPA Multiple Upper Limit 1 End X
- 82) SPA Multiple Upper Limit 1 End X
- 83) SPA Multiple Upper Limit 1 End X (Lowest byte)
- 84) SPA Multiple Upper Limit 1 End Y (Power Level) (Highest byte)¹¹²
- 85) SPA Multiple Upper Limit 1 End Y (Power Level)
- 86) SPA Multiple Upper Limit 1 End Y (Power Level)
- 87) SPA Multiple Upper Limit 1 End Y (Power Level) (Lowest byte)
- 88-231) SPA Multiple Upper Limits 2-5, SA Multiple Lower Limits 1-5 (see bytes 72-87 for format)
- 232) RBW Setting (Highest byte)¹¹³
- 233) RBW Setting
- 234) RBW Setting
- 235) RBW Setting (Lowest byte)
- 236) VBW Setting (Highest byte)¹¹⁴
- 237) VBW Setting
- 238) VBW Setting
- 239) VBW Setting (Lowest byte)
- 240) OCC BW Method¹¹⁵
- 241) OCC BW % Value (Highest byte)¹¹⁶
- 242) OCC BW % Value
- 243) OCC BW % Value
- 244) OCC BW % Value (Lowest byte)
- 245) OCC BW dBc (Highest byte)¹¹⁷
- 246) OCC BW dBc
- 247) OCC BW dBc
- 248) OCC BW dBc (Lowest byte)
- 249) Attenuation (Highest byte)
- 250) Attenuation
- 251) Attenuation
- 252) Attenuation (Lowest byte)
- 253) Antenna Index(0-14)
- 254-269) Antenna Name (16 bytes in ASCII)
- 270) Status Byte 1: (0b = Off , 1b = On)
(LSB) bit 0 : Spectrum Analyzer Mode Marker 1 On/Off

¹⁰⁸ Value sent as (value in dBm * 1000) + 270000

¹⁰⁹ Scaled by Frequency Scale Factor (bytes 321-322)

¹¹⁰ Value sent as (value in dBm * 1000) + 270000

¹¹¹ Scaled by Frequency Scale Factor (bytes 321-322)

¹¹² Value sent as (value in dBm * 1000) + 270000

¹¹³ RBW frequency sent in Hz.

¹¹⁴ VBW frequency sent in Hz.

¹¹⁵ 00h = % of power, 01h = dB down

¹¹⁶ 0 – 99%

¹¹⁷ 0 – 120 dBc

- bit 1 : Spectrum Analyzer Mode Marker 2 On/Off
 - bit 2 : Spectrum Analyzer Mode Marker 3 On/Off
 - bit 3 : Spectrum Analyzer Mode Marker 4 On/Off
 - bit 4 : Spectrum Analyzer Mode Marker 5 On/Off
 - bit 5 : Spectrum Analyzer Mode Marker 6 On/Off
 - bits 6 - 7 : Not Used
- 271) Status Byte 2: (0b = Off, 1b = On)
- (LSB) bit 0 : Transmission Mode Cal Status On/Off (Option 21)
 - bit 1 : Spectrum Analyzer Mode Marker 2 Delta On/Off
 - bit 2 : Spectrum Analyzer Mode Marker 3 Delta On/Off
 - bit 3 : Spectrum Analyzer Mode Marker 4 Delta On/Off
 - bit 4 : Pre Amp Mode (0b = Manual, 1b = Auto)
 - bit 5 : Pre Amp Status On/Off
 - bit 6 : Dynamic Attenuation On/Off
 - bit 7 : Normalization On/Off
- 272) Status Byte 3: (0b = Off/Beep if data is BELOW line ,
1b = On/Beep if data is ABOVE line)
- (LSB) bit 0 : SPA Limit Type (0b = Single, 1b = Multiple)
 - bit 1 : SPA Single Limit Beep On/Off
 - bit 2 : SPA Single Limit Status On/Off
 - bit 3 : SPA Single Limit Beep Level ABOVE/BELOW
 - bit 4 : SPA Multiple Limit Upper Segment 1 Status On/Off
 - bit 5 : SPA Multiple Limit Upper Segment 1 Beep Level ABOVE/BELOW¹¹⁸
 - bit 6 : SPA Multiple Limit Upper Segment 2 Status On/Off
 - bit 7 : SPA Multiple Limit Upper Segment 2 Beep Level ABOVE/BELOW
- 273) Status Byte 4: (0b = Off/Beep if data is BELOW line ,
1b = On/Beep if data is ABOVE line)
- (LSB) bit 0 : SPA Multiple Limit Upper Segment 3 Status On/Off
 - bit 1 : SPA Multiple Limit Upper Segment 3 Beep Level ABOVE/BELOW
 - bit 2 : SPA Multiple Limit Upper Segment 4 Status On/Off
 - bit 3 : SPA Multiple Limit Upper Segment 4 Beep Level ABOVE/BELOW
 - bit 4 : SPA Multiple Limit Upper Segment 5 Status On/Off
 - bit 5 : SPA Multiple Limit Upper Segment 5 Beep Level ABOVE/BELOW
 - bit 6 : SPA Multiple Limit Lower Segment 1 Status On/Off
 - bit 7 : SPA Multiple Limit Lower Segment 1 Beep Level ABOVE/BELOW¹¹⁹
- 274) Status Byte 5: (0b = Off/Beep if data is BELOW line ,
1b = On/Beep if data is ABOVE line)
- (LSB) bit 0 : SPA Multiple Limit Lower Segment 2 Status On/Off
 - bit 1 : SPA Multiple Limit Lower Segment 2 Beep Level ABOVE/BELOW
 - bit 2 : SPA Multiple Limit Lower Segment 3 Status On/Off
 - bit 3 : SPA Multiple Limit Lower Segment 3 Beep Level ABOVE/BELOW
 - bit 4 : SPA Multiple Limit Lower Segment 4 Status On/Off
 - bit 5 : SPA Multiple Limit Lower Segment 4 Beep Level ABOVE/BELOW
 - bit 6 : SPA Multiple Limit Lower Segment 5 Status On/Off
 - bit 7 : SPA Multiple Limit Lower Segment 5 Beep Level ABOVE/BELOW
- 275) Status Byte 6: (0b = Off, 1b = On)
- (LSB) bit 0 : Antenna Factors Correction On/Off
 - bit 1 : Bias Tee On/Off (Option 10)
 - bit 2 : SPA Cal Status On/Off
 - bits 3-4 : Amplitude Units (Log) - 00b = dBm 01b = dBV 10b = dBmV 11b = dBuV
(Linear) – 00b = Watts 01b = Volts
 - bits 5-6 : Detection Alg (00b = pos. peak 01b = RMS Averaging 10b = neg. peak 11b =
Sampling Mode)

¹¹⁸ Beep level is always 1b for upper segmented limit line

¹¹⁹ Beep level is always 0b for lower segmented limit line

- bit 7 : Units Type (0b = Log 1b = Linear)
- 276) Status Byte 7: (0b = Off, 1b = On)
 (LSB) bit 0: Serial Port Echo Status On/Off
 bit 1: Return Sweep Time On/Off
 bit 2: RBW Coupling (1b = Auto, 0b = Manual)
 bit 3: VBW Coupling (1b = Auto, 0b = Manual)
 bit 4: Attenuation Coupling (1b = Auto, 0b = Manual)
 bit 5: Channel Power On/Off
 bit 6: Adjacent Channel Power On/Off
 bit 7: Occupied BW Measurement On/Off
- 277) Reference Level Offset¹²⁰ (Highest byte)
- 278) Reference Level Offset
- 279) Reference Level Offset
- 280) Reference Level Offset (Lowest byte)
- 281) External Reference Frequency¹²¹
- 282) Signal Standard¹²² (Higher byte)
- 283) Signal Standard (Lower byte)
- 284) Channel Selection¹²³ (Higher byte)
- 285) Channel Selection (Lower byte)
- 286) Trigger Type¹²⁴
- 287) Interference Analysis Frequency¹²⁵ (Highest byte)
- 288) Interference Analysis Frequency
- 289) Interference Analysis Frequency
- 290) Interference Analysis Frequency (Lowest byte)
- 291) Trigger Position (0 – 100%)
- 292) Min Sweep Time (in μ s) (Highest byte)
- 293) Min Sweep Time (in μ s)
- 294) Min Sweep Time (in μ s)
- 295) Min Sweep Time (in μ s) (Lowest byte)
- 296) Video Trigger Level¹²⁶ (Highest byte)
- 297) Video Trigger Level
- 298) Video Trigger Level
- 299) Video Trigger Level (Lowest byte)
- 300) Status Byte 8
 (LSB) bit 0: Input Power Status (1b = Input Power Too High, 0b = Input Power Ok)
 bit 1: Reserved
 bits 2-7: Not Used
- 301) Status Byte 9
 (LSB) bits 0-6: Number of sweeps to average (1-25, 1 implies averaging OFF)
 bit 7: Not Used
- 302) Status Byte 10: (0b = Off, 1b = On)
 (LSB) bits 0-1: Trace Math Operation (00b = A only, 01b = A-B, 10b = A+B)
 bit 2: Max Hold On/Off
 bit 3: Min Hold On/Off
 bits 4-7: Not Used
- 303) Impedance (00h = 50 Ω , 0Ah = 75 Ω Anritsu Adapter, 0Ch = 75 Ω Other Adapter)
- 304) Impedance Loss¹²⁷ (Higher byte)

¹²⁰ Value sent as (value in dBm * 1000) + 270,000

¹²¹ 1 byte in MHz (i.e. 20 = 20MHz)

¹²² Index into Standard List (use control byte #89 to retrieve the ASCII string name). “No Standard” sent as FFFEh

¹²³ “No Channel” is sent as FFFEh

¹²⁴ Trigger Type – 00h = Single, 01h = Free Run, 02h = Video, 03h = External

¹²⁵ Scaled by Frequency Scale Factor (bytes 321-322)

¹²⁶ Value sent as (value in dBm * 1000) + 270,000

¹²⁷ Value sent as (value in dB * 1000), valid values are 0 to 20 dB

- 305) Impedance Loss (Lower byte)
- 306) AM/FM Demod Type¹²⁸
- 307) AM/FM Demod Status (01h = On, 00h = Off)
- 308) AM/FM Demod Volume (0 to 100)
- 309) AM/FM Demod Frequency¹²⁹ (Highest byte)
- 310) AM/FM Demod Frequency
- 311) AM/FM Demod Frequency
- 312) AM/FM Demod Frequency (Lowest byte)
- 313) AM/FM Demod Time (in ms) (Highest byte)
- 314) AM/FM Demod Time (in ms)
- 315) AM/FM Demod Time (in ms)
- 316) AM/FM Demod Time (in ms) (Lowest byte)
- 317) SSB BFO Offset¹³⁰ (Highest byte)
- 318) SSB BFO Offset
- 319) SSB BFO Offset
- 320) SSB BFO Offset (Lowest byte)
- 321) Frequency Scale Factor¹³¹ (Higher byte)
- 322) Frequency Scale Factor (Lower byte)
- 323) Frequency Range Minimum¹³² (Highest byte)
- 324) Frequency Range Minimum
- 325) Frequency Range Minimum
- 326) Frequency Range Minimum (Lowest byte)
- 327) Frequency Range Maximum¹³³ (Highest byte)
- 328) Frequency Range Maximum
- 329) Frequency Range Maximum
- 330) Frequency Range Maximum (Lowest byte)
- 331) Marker Type¹³⁴
- 332-355) Signal Standard Name, 24bytes of ASCII
- 356-400) Not Used

For Power Meter Mode (Both option 5 and narrow band):

- 26) Power Meter Start Freq¹³⁵ (Highest byte)
- 27) Power Meter Start Freq
- 28) Power Meter Start Freq
- 29) Power Meter Start Freq (Lowest byte)
- 30) Power Meter Stop Freq¹³⁶ (Highest byte)
- 31) Power Meter Stop Freq
- 32) Power Meter Stop Freq
- 33) Power Meter Stop Freq (Lowest byte)
- 34) Power Meter Center Freq¹³⁷ (Highest byte)
- 35) Power Meter Center Freq
- 36) Power Meter Center Freq
- 37) Power Meter Center Freq (Lowest byte)
- 38) Power Meter Span¹³⁸ (Highest byte)

¹²⁸ AM/FM Demod Type: 00h = FM-Wide Band, 01h = FM-Narrow Band, 02h = AM, 03h = SSB Lower, 04h = SSB Upper

¹²⁹ Scaled by Frequency Scale Factor (bytes 321-322)

¹³⁰ Value sent as ((value in Hz) – 10,000)

¹³¹ In number of Hz

¹³² Scaled by Frequency Scale Factor (bytes 321-322)

¹³³ Scaled by Frequency Scale Factor (bytes 321-322)

¹³⁴ 00h = Regular Marker, 01h = Noise Marker

¹³⁵ Scaled by Frequency Scale Factor (bytes 59-60)

¹³⁶ Scaled by Frequency Scale Factor (bytes 59-60)

¹³⁷ Scaled by Frequency Scale Factor (bytes 59-60)

- 39) Power Meter Span
- 40) Power Meter Span
- 41) Power Meter Span (Lowest byte)
- 42) Signal Standard¹³⁹ (Higher byte)
- 43) Signal Standard (Lower byte)
- 44) Channel Selection¹⁴⁰ (Higher byte)
- 45) Channel Selection (Lower byte)
- 46) Power Meter Offset (Highest byte)
- 47) Power Meter Offset
- 48) Power Meter Offset
- 49) Power Meter Offset (Lowest byte)
- 50) Power Meter Relative (Highest byte)¹⁴¹
- 51) Power Meter Relative
- 52) Power Meter Relative
- 53) Power Meter Relative (Lowest byte)
- 54) Power Meter Status (00h = Off, 01h = On)
- 55) Power Meter Unit (00h = Watts, 01h = dBm)
- 56) Power Meter Relative Status (00h = Off, 01h = On)
- 57) Power Meter Offset Status (00h = Off, 01h = On)
- 58) Power Meter RMS Averaging Level (00h = Off, 01h = Low, 02h = Medium, 03h = High)
- 59) Frequency Scale Factor¹⁴² (Higher byte)
- 60) Frequency Scale Factor (Lower byte)
- 61) Frequency Range Minimum¹⁴³ (Highest byte)
- 62) Frequency Range Minimum
- 63) Frequency Range Minimum
- 64) Frequency Range Minimum (Lowest byte)
- 65) Frequency Range Maximum¹⁴⁴ (Highest byte)
- 66) Frequency Range Maximum
- 67) Frequency Range Maximum
- 68) Frequency Range Maximum (Lowest byte)
- 69) Zero Status (00h = Off, 01h = On)
- 70) Zero Value¹⁴⁵ (Highest byte)
- 71) Zero Value
- 72) Zero Value
- 73) Zero Value (Lowest byte)
- 74-97) Signal Standard Name, 24 bytes of ASCII
- 98-120) Not Used

For T1 Mode (Option 50):

- 26) T1 Receive Input (00h: Terminate, 01h: Bridged, 02h: Monitor)
- 27) T1 Framing Mode (01h: ESF, 02h: D4SF)
- 28) T1 Line Coding (01h: B8ZS, 02h: AMI)
- 29) T1 Clock Source (00h: External, 01h: Internal)
- 30) T1 Tx Level (01h: 0 dB, 02h: -7.5 dB, 03h: -15 dB)
- 31) T1 Error Insert Type (00h: Frame Error, 01h: BPV, 02h: Bit Errors, 04h: RAI, 05h: AIS)
- 32) T1 Loop Code (00h: CSU, 01h: NIU, 02h: User 1, 03h: User 2)
- 33) T1 CRC Method (00h: ANSI CRC, 01h: Japanese CRC)

¹³⁸ Scaled by Frequency Scale Factor (bytes 59-60)

¹³⁹ Index into Standard List (use control byte #89 to retrieve the ASCII string name). “No Standard” sent as FFFEh

¹⁴⁰ “No Channel” is sent as FFFEh

¹⁴¹ Value as ((value in dBm * 1000) + 100)

¹⁴² In number of Hz

¹⁴³ Scaled by Frequency Scale Factor

¹⁴⁴ Scaled by Frequency Scale Factor

¹⁴⁵ Value sent as ((value in dBm * 1000) + 100)

- 34) T1 Loop Type (00h: In Band, 01h: Data Link)
- 35) T1 Pattern (Higher byte)
- 36) T1 Pattern (Lower byte) 01h: PRBS-9, 02h: PRBS-11, 03h: PRBS-15, 04h: PRBS-20(O.151), 05h: PRBS-20(O.153), 06h: PRBS-23, 07h: QRSS, 08h: 1 in 8, 09h: 2 in 8, 0Ah: 3 in 8, 0Bh: All Ones, 0Ch: All Zeros, 0Dh: T1-DALY, 0Eh: User Defined)
- 37) T1 Pattern Invert Status (00h: Non-Inverted, 01h: Inverted)
- 38) T1 Display Type (00h: Histogram, 01h: Raw Data)
- 39) T1 Impedance
- 40 - 55) First User Defined Loop Code Down (16 bytes)
- 56 - 71) Second User Defined Loop Code Down (16 bytes)
- 72 - 87) First User Defined Loop Code Up (16 bytes)
- 88 - 103) Second User Defined Loop Code Up (16 bytes)
- 104 - 135) User Defined Pattern (32 bytes)
- 136) T1 1st User Defined Loop Up (Higher byte)
- 137) T1 1st User Defined Loop Up (Lower byte)
- 138) T1 2nd User Defined Loop Up (Higher byte)
- 139) T1 2nd User Defined Loop Up (Lower byte)
- 140) T1 1st User Defined Loop Down (Higher byte)
- 141) T1 1st User Defined Loop Down (Lower byte)
- 142) T1 2nd User Defined Loop Down (Higher byte)
- 143) T1 2nd User Defined Loop Down (Lower byte)
- 144) T1 User Defined Pattern (Highest byte)
- 145) T1 User Defined Pattern
- 146) T1 User Defined Pattern
- 147) T1 User Defined Pattern (Lowest byte)
- 148) T1 Bit Error Insert Value (1-1000) (Higher byte)
- 149) T1 Bit Error Insert Value (Lower byte)
- 150) T1 Frame Error Insert Value (1-1000) (Higher byte)
- 151) T1 Frame Error Insert Value (Lower byte)
- 152) T1 BPV Error Insert Value (1-1000) (Higher byte)
- 153) T1 BPV Error Insert Value (Lower byte)
- 154) T1 Graph Resolution¹⁴⁶
- 155) T1 Measurement Duration¹⁴⁷
- 156) T1 Voltage Measurement Scale (00h = Vpp, 01h = dBdsx)
- 157) T1 Auto Framing Mode (00h = fixed framing, >00h = auto framing mode)
- 158 – 240) Not Used

For E1 Mode (Option 50):

- 26) E1 Receive Input (00h: Terminate, 01h: Bridged, 02h: Monitor)
- 27) E1 Framing Mode (03h: PCM30, 04h: PCM30CRC, 05h: PCM31, 06h: PCM31CRC)
- 28) E1 Line Coding (02h: AMI, 03h: HDB3)
- 29) E1 Clock Source (00h: External, 01h: Internal)
- 30) E1 Tx Level
- 31) E1 Error Insert Type (00h: Frame Error, 01h: BPV, 02h: Bit Errors, 04h: RAI, 05h: AIS)
- 32) E1 Loop Code
- 33) E1 CRC Method
- 34) E1 Loop Type
- 35) E1 Pattern (Highest byte)
- 36) E1 Pattern (Lowest byte) (01h: PRBS-9, 02h: PRBS-11, 03h: PRBS-15, 04h: PRBS-20(O.151), 05h: PRBS-20(O.153), 06h: PRBS-23, 07h: QRSS, 08h: 1 in 8, 09h: 2 in 8, 0Ah: 3 in 8, 0Bh: All Ones, 0Ch: All Zeros, 0Dh: T1-DALY, 0Eh: User Defined)

¹⁴⁶ Graph Resolution: 00h: Auto, 01h: 1 sec, 02h: 15 sec, 03h: 30 sec, 04h 45 sec, 05h 1 min, 06h: 15 min, 07h: 30 min, 08h: 45 min, 09h: 60 min

¹⁴⁷ Measurement Duration: 00h: Manual, 01h: 3 min, 02h: 15 min, 03h: 30 min, 04h: 1 hr, 05h: 3 hrs, 06h: 6 hrs, 07h: 12 hrs, 08h: 1 day, 09h: 2 days

- 37) E1 Pattern Invert (00h: Non-Inverted, 01h: Inverted)
- 38) E1 Display Type (00h: Histogram, 01h: Raw Data)
- 39) E1 Impedance (01h: 75 Ω , 02h: 120 Ω)
- 40 - 55) First User Defined Loop Code Down (16 bytes)
- 56 - 71) Second User Defined Loop Code Down (16 bytes)
- 72 - 87) First User Defined Loop Code Up (16 bytes)
- 88 - 103) Second User Defined Loop Code Up (16 bytes)
- 104 - 135) User Defined Pattern (32 bytes)
- 136) E1 1st User Defined Loop Up (Highest byte)
- 137) E1 1st User Defined Loop Up (Lowest byte)
- 138) E1 2nd User Defined Loop Up (Highest byte)
- 139) E1 2nd User Defined Loop Up (Lowest byte)
- 140) E1 1st User Defined Loop Down (Highest byte)
- 141) E1 1st User Defined Loop Down (Lowest byte)
- 142) E1 2nd User Defined Loop Down (Highest byte)
- 143) E1 2nd User Defined Loop Down (Lowest byte)
- 144) E1 User Defined Pattern (Highest byte)
- 145) E1 User Defined Pattern
- 146) E1 User Defined Pattern
- 147) E1 User Defined Pattern (Lowest byte)
- 148) E1 Bit Error Insert Value (1-1000) (Higher byte)
- 149) E1 Bit Error Insert Value (Lower byte)
- 150) E1 Frame Error Insert Value (1-1000) (Higher byte)
- 151) E1 Frame Error Insert Value (Lower byte)
- 152) E1 BPV Error Insert Value (1-1000) (Higher byte)
- 153) E1 BPV Error Insert Value (Lower byte)
- 154) E1 Graph Resolution¹⁴⁸
- 155) E1 Measurement Duration¹⁴⁹
- 156) E1 Voltage Measurement Scale (00h = Vpp, 01h = dBdsx)
- 157-240) Not Used

Select Printer Type – Control Byte #30 (1Eh)

Description: Select Printer Type.

Bytes to Follow: 1 byte

- 1) Printer ID
 - 0 – Epson Stylus Models
 - 1 – Epson LQ Models
 - 2 – Citizen PN Models
 - 3 – NEC Superscript Models
 - 4 – NEC Silentwriter Models
 - 5 – Seiko DPU 411, 414 Models
 - 6 – Canon BJC 50
 - 7 – Canon BJC 80
 - 8 – Canon BJC 250
 - 9 – Canon BJC 4400
 - 10 – HP DJ 300 Series
 - 11 – HP DJ 400 Series
 - 12 – HP DJ 500 Series

¹⁴⁸ Graph Resolution: 00h: Auto, 01h: 1 sec, 02h: 15 sec, 03h: 30 sec, 04h 45 sec, 05h 1 min, 06h: 15 min, 07h: 30 min, 08h: 45 min, 09h: 60 min

¹⁴⁹ Measurement Duration: 00h: Manual, 01h: 3 min, 02h: 15 min, 03h: 30 min, 04h: 1 hr, 05h: 3 hrs, 06h: 6 hrs, 07h: 12 hrs, 08h: 1 day, 09h: 2 days

- 13 – HP DJ 600 Series
- 14 – HP DJ 800 Series
- 15 – HP DJ 1120
- 16 – HP LJ 6L, 6P, 4000
- 17 – Epson Esc/P Compatible
- 18 – Epson Esc/P2 Compatible
- 19 – Epson Esc/P Raster Compatible
- 20 – HP PCL3 Compatible

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
-

Select DTF Windowing – Control Byte #31 (1Fh)

Description: Select DTF Windowing Methods.

DTF windowing allows you to make a trade off between side lobe height and resolution.

Bytes to Follow: 1 byte

- 1) Windowing Method
 - 00h = Rectangular (finest resolution, highest side lobes)
 - 01h = Nominal Side Lobe (balance between resolution and side lobes)
 - 02h = Low Side Lobe
 - 03h = Minimum Side Lobe

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error: Invalid DTF Windowing Method
 - 238 (EEh) Time-out Error
-

Set Site Master VNA Trace Math – Control Byte #32 (20h)

Description: Setup trace math operation and trace for VNA modes.

Bytes to Follow: 2 bytes

- 1) Trace Math Operation
 - 00h = Off
 - 01h = Addition
 - 02h = Subtraction
- 2) Trace on which to Perform Math Operation (1 to 200)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error: Invalid Trace Math Operation
 - 238 (EEh) Time-out Error
-

Recall Sweep Trace – Control Byte #33 (21h)

This command is new to the S33xD. Use it, instead of Control Byte #17, to access the new features.

Description: Queries the Site Master for sweep trace data.

NOTE: Before you can recall a sweep stored in non-volatile memory (trace numbers 1-200) you must build a trace table in the Site Master's RAM. Use Control Byte #24 to build the trace table. Since the trace table exists in RAM, Control Byte #24 must be executed every time the Site Master's power is cycled.

Bytes to Follow: 1 byte

- 0 = Last sweep trace before entering remote mode (sweep trace in RAM)
- 1- 200 = Specific saved sweep number (stored sweeps in Flash memory)

Site Master Returns:

- 1-2) # of following bytes (total length - 2)
- 3) Current Instrument Date Format¹⁵⁰
- 4) Not Used
- 5-11) Model Number (7 bytes in ASCII)
- 12-15) Software Version (4 bytes ASCII)
- 16) Measurement Mode¹⁵¹
- 17-20) Time/Date (in Long Integer¹⁵²)
- 21-30) Date in String Format (mm/dd/yyyy)
- 31-38) Time in String Format (hh:mm:ss)
- 39-54) Reference number stamp (16 bytes in ASCII)
- 55-56) # data points (130, 259 or 517 or 401 or 100)

For all "Site Master VNA Modes" :

- 57) Start Frequency¹⁵³ (Highest byte)
- 58) Start Frequency
- 59) Start Frequency
- 60) Start Frequency (Lowest byte)
- 61) Stop Frequency¹⁵⁴ (Highest byte)
- 62) Stop Frequency
- 63) Stop Frequency
- 64) Stop Frequency (Lowest byte)
- 65) Minimum Frequency Step Size (Highest byte)
- 66) Minimum Frequency Step Size
- 67) Minimum Frequency Step Size
- 68) Minimum Frequency Step Size (Lowest byte)
- 69) Scale Top¹⁵⁵ (Highest byte)
- 70) Scale Top
- 71) Scale Top
- 72) Scale Top (Lowest byte)
- 73) Scale Bottom (Highest byte)
- 74) Scale Bottom
- 75) Scale Bottom
- 76) Scale Bottom (Lowest byte)
- 77) Frequency Marker 1¹⁵⁶ (Higher byte)

¹⁵⁰ 00h = MM/DD/YYYY, 01h = DD/MM/YYYY, 02h = YYYY/MM/DD

¹⁵¹ Refer to Control Byte #3 "Select Measurement Mode" for detailed value.

¹⁵² Time/Date long integer representation is in seconds since January 1, 1970

¹⁵³ Frequency is scaled by the frequency scale factor specified in bytes 268-269.

¹⁵⁴ Frequency is scaled by the frequency scale factor specified in bytes 268-269.

¹⁵⁵ See Control Byte #4 "Set Site Master Scale" for data format

- 78) Frequency Marker 1 (Lower byte)
- 79) Frequency Marker 2 (Higher byte)
- 80) Frequency Marker 2 (Lower byte)
- 81) Frequency Marker 3 (Higher byte)
- 82) Frequency Marker 3 (Lower byte)
- 83) Frequency Marker 4 (Higher byte)
- 84) Frequency Marker 4 (Lower byte)
- 85) Frequency Marker 5 (Higher byte)
- 86) Frequency Marker 5 (Lower byte)
- 87) Frequency Marker 6 (Higher byte)
- 88) Frequency Marker 6 (Lower byte)
- 89) Single Limit¹⁵⁷ (Highest byte)
- 90) Single Limit
- 91) Single Limit
- 92) Single Limit (Lowest byte)
- 93) Multiple Limit Segment # (1)
- 94) Multiple Limit Segment Status
- 95) Multiple Limit Start X¹⁵⁸ (Highest byte)
- 96) Multiple Limit Start X
- 97) Multiple Limit Start X
- 98) Multiple Limit Start X (Lowest byte)
- 99) Multiple Limit Start Y (Higher byte)
- 100) Multiple Limit Start Y (Lower byte)
- 101) Multiple Limit End X¹⁵⁹ (Highest byte)
- 102) Multiple Limit End X
- 103) Multiple Limit End X
- 104) Multiple Limit End X (Lowest byte)
- 105) Multiple Limit End Y (Higher byte)
- 106) Multiple Limit End Y (Lower byte)
- 107–162) Repeat bytes 93-106 for segments 2-5
- 163) Start Distance¹⁶⁰ (Highest byte)
- 164) Start Distance
- 165) Start Distance
- 166) Start Distance (Lowest byte)
- 167) Stop Distance (Highest byte)
- 168) Stop Distance
- 169) Stop Distance
- 170) Stop Distance (Lowest byte)
- 171) Distance Marker 1¹⁶¹ (Higher byte)
- 172) Distance Marker 1 (Lower byte)
- 173) Distance Marker 2 (Higher byte)
- 174) Distance Marker 2 (Lower byte)
- 175) Distance Marker 3 (Higher byte)
- 176) Distance Marker 3 (Lower byte)
- 177) Distance Marker 4 (Higher byte)
- 178) Distance Marker 4 (Lower byte)

¹⁵⁶ marker point = (# of data points – 1) * (marker freq – start freq) / (stop freq – start freq) where # of data points can be found in bytes 55-56, start freq is in bytes 57-60, and stop freq is in bytes 61-64.

¹⁵⁷ See Control Byte #6 “Set Site Master VNA Single Limit” for data format.

¹⁵⁸ See Control Byte #112 “Set Site Master VNA Segmented Limit Lines” for data format. Frequency is scaled by the frequency scale factor specified in bytes 268-269.

¹⁵⁹ Frequency is scaled by the frequency scale factor specified in bytes 268-269.

¹⁶⁰ Distance data uses units 1/100,000m (or feet)

¹⁶¹ Marker Point = (# data points – 1) * (marker dist – start dist) / (stop dist – start dist)

Where # of data points can be found in bytes 55-56, start dist is in bytes 163-166, and stop dist is in bytes 167-170.

- 179)Distance Marker 5 (Higher byte)
- 180)Distance Marker 5 (Lower byte)
- 181)Distance Marker 6 (Higher byte)
- 182)Distance Marker 6 (Lower byte)
- 183)Relative Propagation Velocity¹⁶² (Highest byte)
- 184)Relative Propagation Velocity
- 185)Relative Propagation Velocity
- 186)Relative Propagation Velocity (Lowest byte)
- 187)Cable Loss¹⁶³ (Highest byte)
- 188)Cable Loss
- 189)Cable Loss
- 190)Cable Loss (Lowest byte)
- 191)Average Cable Loss¹⁶⁴ (Highest byte)
- 192)Average Cable Loss
- 193)Average Cable Loss
- 194)Average Cable Loss (Lowest byte)
- 195)Status Byte 1: (0b = Off , 1b = On)
 - (LSB) bit 0 : Marker 1 On/Off
 - bit 1 : Marker 2 On/Off
 - bit 2 : Marker 3 On/Off
 - bit 3 : Marker 4 On/Off
 - bit 4 : Marker 5 On/Off
 - bit 5 : Marker 6 On/Off
 - bits 6-7 : Not Used
- 196)Status Byte 2: (0b = Off, 1b = On)
 - (LSB) bit 0 : Marker 2 Delta On/Off
 - bit 1 : Marker 3 Delta On/Off
 - bit 2 : Marker 4 Delta On/Off
 - bits 3-7 : Not Used
- 197)Status Byte 3: (0b = Off , 1b = On)
 - (LSB) bit 0 : Single Limit On/Off
 - bit 1: CW On/Off
 - bit 2: Trace Math On/Off
 - bits 3-5 : Not Used
 - bit 6 : Limit Type (0b = Single; 1b = Multiple)
 - bit 7 : Unit of Measurement (1b = Metric, 0b = English)
- 198)Status Byte 4:
 - (LSB) bit 0 - 1 : DTF Windowing Mode
 - bit: 1 0
 - | |
 - 0 0 - Rectangular (No Windowing)
 - 0 1 - Nominal Side Lobe
 - 1 0 - Low Side Lobe
 - 1 1 - Minimum Side Lobe
 - bits 2 – 7 : Not Used
- 199)Status Byte 5 (Cal Status):
 - 00h : Calibration Off
 - 01h : Standard Calibration On
 - 02h : InstaCal Calibration On
 - 03h : Standard FlexCal On
 - 04h : InstaCal FlexCal On
- 200)VNA Signal Standard¹⁶⁵ (Higher byte)

¹⁶² Relative Propagation Velocity uses units 1/100,000

¹⁶³ Cable Loss uses units 1/100,000 dB/m or 1/100,000 dB/ft.

¹⁶⁴ Average Cable Loss is dB * 1000.

201)	VNA Signal Standard (Lower byte)
202-205)	GPS Position – Latitude (long integer) ¹⁶⁶
206-209)	GPS Position – Longitude (long integer)
210-211)	GPS Position – Altitude (short integer)
212)	Signal Standard Link Type ¹⁶⁷
213-236)	Signal Standard Name, 24 bytes in ASCII
237-257)	Cable Name, 21 bytes in ASCII
258-267)	UTC Time, 10 bytes in ASCII
268)	Frequency Scale Factor ¹⁶⁸ (Higher Byte)
269)	Frequency Scale Factor (Lower Byte)
270-324)	Not Used
325-1364)	Sweep Data (130 points * 8 bytes/point = 1040 bytes)
325-2396)	Sweep Data (259 points * 8 bytes/point = 2072 bytes)
325-4460)	Sweep Data (517 points * 8 bytes/point = 4136 bytes)
	8 bytes for each data point
	1. gamma ¹⁶⁹ (Highest byte)
	2. gamma
	3. gamma
	4. gamma (Lowest byte)
	5. phase ¹⁷⁰ (Highest byte)
	6. phase
	7. phase
	8. phase (Lowest byte)

Notes:

return loss = $-20 * (\log(\text{gamma}) / \log(10))$

VSWR = $(1+\text{gamma})/(1-\text{gamma})$

phase compares the reflected to the incident (reference)

For Spectrum Analyzer Mode/Transmission Mode (Option 21 Only):

57)	Start Frequency ¹⁷¹ (Highest byte)
58)	Start Frequency
59)	Start Frequency
60)	Start Frequency (Lowest byte)
61)	Stop Frequency ¹⁷² (Highest byte)
62)	Stop Frequency
63)	Stop Frequency
64)	Stop Frequency (Lowest byte)
65)	Center Frequency ¹⁷³ (Highest byte)
66)	Center Frequency
67)	Center Frequency
68)	Center Frequency (Lowest byte)
69)	Frequency Span ¹⁷⁴ (Highest byte)

¹⁶⁵ Index into Standard List (use control byte #89 to retrieve the ASCII string name). “No Standard” sent as FFFEh

¹⁶⁶ Signed long integer is used to represent latitude and longitude. Positive latitude means North hemisphere, negative latitude means South hemisphere; Positive longitude means East hemisphere, negative longitude means West hemisphere. Degree = $\text{int}(\text{abs}(\text{value})/1,000,000)$; Minute = $(\text{float})(\text{abs}(\text{value})\%1,000,000)/10,000$

¹⁶⁷ 1 – Uplink, 2 – Downlink, 3 – Both, 0 – Invalid Link

¹⁶⁸ Frequency Scale Factor is in number of Hz.

¹⁶⁹ Gamma data uses 1/10,000 units.

¹⁷⁰ Phase data uses 1/10 degree unit.

¹⁷¹ Scaled by Frequency Scale Factor (bytes 335-336)

¹⁷² Scaled by Frequency Scale Factor (bytes 335-336)

¹⁷³ Scaled by Frequency Scale Factor (bytes 335-336)

¹⁷⁴ Scaled by Frequency Scale Factor (bytes 335-336)

- 70) Frequency Span
- 71) Frequency Span
- 72) Frequency Span (Lowest byte)
- 73) Minimum Frequency Step Size (Highest byte)
- 74) Minimum Frequency Step Size
- 75) Minimum Frequency Step Size
- 76) Minimum Frequency Step Size (Lowest byte)
- 77) Ref Level¹⁷⁵ (Highest byte)
- 78) Ref Level
- 79) Ref Level
- 80) Ref Level (Lowest byte)
- 81) Scale per div¹⁷⁶ (Highest byte)
- 82) Scale per div
- 83) Scale per div
- 84) Scale per div (Lowest byte)
- 85) Frequency Marker 1¹⁷⁷ (Higher byte)
- 86) Frequency Marker 1 (Lower byte)
- 87) Frequency Marker 2 (Higher byte)
- 88) Frequency Marker 2 (Lower byte)
- 89) Frequency Marker 3 (Higher byte)
- 90) Frequency Marker 3 (Lower byte)
- 91) Frequency Marker 4 (Higher byte)
- 92) Frequency Marker 4 (Lower byte)
- 93) Frequency Marker 5 (Higher byte)
- 94) Frequency Marker 5 (Lower byte)
- 95) Frequency Marker 6 (Higher byte)
- 96) Frequency Marker 6 (Lower byte)
- 97) Single Limit¹⁷⁸ (Highest byte)
- 98) Single Limit
- 99) Single Limit
- 100) Single Limit (Lowest byte)
- 101) Multiple Upper Limit 1 Start X¹⁷⁹ (Highest byte)
- 102) Multiple Upper Limit 1 Start X
- 103) Multiple Upper Limit 1 Start X
- 104) Multiple Upper Limit 1 Start X (Lowest byte)
- 105) Multiple Upper Limit 1 Start Y (Power Level¹⁸⁰) (Highest byte)
- 106) Multiple Upper Limit 1 Start Y (Power Level)
- 107) Multiple Upper Limit 1 Start Y (Power Level)
- 108) Multiple Upper Limit 1 Start Y (Power Level) (Lowest byte)
- 109) Multiple Upper Limit 1 End X¹⁸¹ (Highest byte)
- 110) Multiple Upper Limit 1 End X
- 111) Multiple Upper Limit 1 End X
- 112) Multiple Upper Limit 1 End X (Lowest byte)
- 113) Multiple Upper Limit 1 End Y (Power Level) (Highest byte)
- 114) Multiple Upper Limit 1 End Y (Power Level)
- 115) Multiple Upper Limit 1 End Y (Power Level)
- 116) Multiple Upper Limit 1 End Y (Power Level) (Lowest byte)
- 117-260) Multiple Upper Limits 2-5, Multiple Lower Limits 1-5 (see bytes 101-116 for format)

¹⁷⁵ Value sent as (Value in dBm * 1000) + 270,000

¹⁷⁶ Value sent as (Value * 1000)

¹⁷⁷ Value sent as data point on display. $\text{Freq} = (\text{Point} * \text{Span} / (\text{Total Data Points} - 1)) + \text{Start Freq}$

¹⁷⁸ Value sent as (Value in dBm * 1000) + 270,000

¹⁷⁹ Scaled by Frequency Scale Factor (bytes 335-336)

¹⁸⁰ Value sent as (value in dBm * 1000) + 270,000

¹⁸¹ Scaled by Frequency Scale Factor (bytes 335-336)

- 261) RBW Setting (Frequency in Hz) (Highest byte)
- 262) RBW Setting (Frequency in Hz)
- 263) RBW Setting (Frequency in Hz)
- 264) RBW Setting (Frequency in Hz) (Lowest byte)
- 265) VBW Setting (Frequency in Hz) (Highest byte)
- 266) VBW Setting (Frequency in Hz)
- 267) VBW Setting (Frequency in Hz)
- 268) VBW Setting (Frequency in Hz) (Lowest byte)
- 269) OCC BW Method (0b = % of power, 1b = dB down)
- 270) OCC BW % Value¹⁸²
- 271) OCC BW dBc¹⁸³
- 272) Attenuation¹⁸⁴ (Highest byte)
- 273) Attenuation
- 274) Attenuation
- 275) Attenuation (Lowest byte)
- 276-291) Antenna Name(16 bytes in ASCII)
- 292) Status Byte 1: (0b = Off , 1b = On)
 - (LSB) bit 0 : Marker 1 On/Off
 - bit 1 : Marker 2 On/Off
 - bit 2 : Marker 3 On/Off
 - bit 3 : Marker 4 On/Off
 - bit 4 : Marker 5 On/Off
 - bit 5 : Marker 6 On/Off
 - bits 6-7: Not Used
- 293) Status Byte 2: (0b = Off , 1b = On)
 - (LSB) bit 0 : Not Used
 - bit 1 : Marker 2 Delta On/Off
 - bit 2 : Marker 3 Delta On/Off
 - bit 3 : Marker 4 Delta On/Off
 - bit 4 : Pre Amp Mode (0b = Manual, 1b = Auto)
 - bit 5 : Pre Amp Status On/Off
 - bit 6 : Dynamic Attenuation On/Off
 - bit 7 : Normalization On/Off
- 294) Status Byte 3: (0b = Off, 1b = On)
 - (LSB) bit 0 : Antenna Factor Correction On/Off
 - bits 1-2 : Detection alg (00b = pos. peak 01b = RMS average 10b = neg. peak 11b = sampling mode)
 - bits 3-4 : Amplitude Units (Log) - (00b = dBm 01b = dBV 10b = dBmV 11b = dBuV) (Linear) – (00b = Watts 01b = Volts)
 - bit 5 : Channel Power On/Off
 - bit 6 : Adjacent Channel Power On/Off
 - bit 7 : Units Type (0b = Log 1b = Linear)
- 295) Status Byte 4¹⁸⁵
 - (0b = Off/Beep if data is BELOW line, 1b = On/Beep if data is ABOVE line)
 - (LSB) bit 0 : Limit Type (0b = Single, 1b = Multiple)
 - bit 1 : Not Used
 - bit 2 : Single Limit On/Off
 - bit 3 : Single Limit Beep Level ABOVE/BELOW
 - bit 4 : Multiple Limit Upper Segment 1 Status On/Off
 - bit 5 : Multiple Limit Upper Segment 1 Beep Level ABOVE/BELOW¹⁸⁶

¹⁸² % value is 0-99

¹⁸³ dBc value 0 – 120 dBc

¹⁸⁴ Value sent as (value in dB * 1000)

¹⁸⁵ For bits 2, 1 and 0 (“X” is “don’t care”): 0X0=no limit, 1X0=single limit, 0X1=multiple limit, 1X1=multiple limit.

¹⁸⁶ Upper limits always trigger an error beep if data is ABOVE the limit segment, for example, this bit is always 1b.

- bit 6 : Multiple Limit Upper Segment 2 Status On/Off
- bit 7 : Multiple Limit Upper Segment 2 Beep Level ABOVE/BELOW
- 296) Status Byte 5
(0b = Off/Beep if data is below line, 1b = On/Beep if data is above line)
- (LSB) bit 0 : Multiple Limit Upper Segment 3 Status On/Off
- bit 1 : Multiple Limit Upper Segment 3 Beep Level ABOVE/BELOW
- bit 2 : Multiple Limit Upper Segment 4 Status On/Off
- bit 3 : Multiple Limit Upper Segment 4 Beep Level ABOVE/BELOW
- bit 4 : Multiple Limit Upper Segment 5 Status On/Off
- bit 5 : Multiple Limit Upper Segment 5 Beep Level ABOVE/BELOW
- bit 6 : Multiple Limit Lower Segment 1 Status On/Off
- bit 7 : Multiple Limit Lower Segment 1 Beep Level ABOVE/BELOW¹⁸⁷
- 297) Status Byte 6
(0b = Off/Beep if data is BELOW line, 1b = On/Beep if data is ABOVE line)
- (LSB) bit 0 : Multiple Limit Lower Segment 2 Status On/Off
- bit 1 : Multiple Limit Lower Segment 2 Beep Level ABOVE/BELOW
- bit 2 : Multiple Limit Lower Segment 3 Status On/Off
- bit 3 : Multiple Limit Lower Segment 3 Beep Level ABOVE/BELOW
- bit 4 : Multiple Limit Lower Segment 4 Status On/Off
- bit 5 : Multiple Limit Lower Segment 4 Beep Level ABOVE/BELOW
- bit 6 : Multiple Limit Lower Segment 5 Status On/Off
- bit 7 : Multiple Limit Lower Segment 5 Beep Level ABOVE/BELOW
- 298) Status Byte 7
(LSB) bits 0-6: Number of sweeps to average (1-25, 1 implies averaging OFF)
- bit 7: Not Used
- 299) Reference Level Offset¹⁸⁸ (Highest byte)
- 300) Reference Level Offset
- 301) Reference Level Offset
- 302) Reference Level Offset (Lowest byte)
- 303) External Reference Frequency¹⁸⁹
- 304) Signal Standard¹⁹⁰ (Higher byte)
- 305) Signal Standard (Lower byte)
- 306) Channel Selection¹⁹¹ (Higher byte)
- 307) Channel Selection (Lower byte)
- 308) Interference Analysis Cellular Standard¹⁹²
- 309) Interference Analysis Estimated Bandwidth (Highest byte)
- 310) Interference Analysis Estimated Bandwidth
- 311) Interference Analysis Estimated Bandwidth
- 312) Interference Analysis Estimated Bandwidth (Lowest byte)
- 313) Interference Analysis Frequency¹⁹³ (Highest byte)
- 314) Interference Analysis Frequency
- 315) Interference Analysis Frequency
- 316) Interference Analysis Frequency (Lowest byte)
- 317-320) Reserved
- 321) Trigger Type¹⁹⁴
- 322) Trigger Position (0 – 100%)

¹⁸⁷ Lower limits always trigger an error beep if data is BELOW the limit segment, for example, this bit is always 0b.

¹⁸⁸ Value sent as (value in dBm * 1000) + 270,000

¹⁸⁹ 1 byte in MHz (i.e. 20 = 20MHz)

¹⁹⁰ Index into Standard List (use control byte #89 to retrieve the ASCII string name). “No Standard” sent as FFFEh

¹⁹¹ “No Channel” is sent as FFFEh

¹⁹² 4 Standards – 00h = 1250kHz CDMA, 01h = GSM, 02h = TDMA, 03h = AMPS, 04h = Unknown, FFh = Interference Analysis Measurement OFF

¹⁹³ Scaled by Frequency Scale Factor (bytes 335-336)

¹⁹⁴ Trigger Type – 00h = Single, 01h = Free Run, 02h = Video, 03h = External

- 323) Min Sweep Time (in μs) (Highest byte)
 324) Min Sweep Time (in μs)
 325) Min Sweep Time (in μs)
 326) Min Sweep Time (in μs) (Lowest byte)
 327) Video Trigger Level¹⁹⁵ (Highest byte)
 328) Video Trigger Level
 329) Video Trigger Level
 330) Video Trigger Level (Lowest byte)
 331) Status Byte 8 (0b = Off, 1b = On)
 (LSB) bit 0-1: Trace Math Operation (00b = A only, 01b = A-B, 10b = A+B)
 bit 2: Max Hold On/Off
 bit 3: Min Hold On/Off
 bit 4: Transmission Calibration On/Off (Option 21 Only)
 bit 5: Bias Tee On/Off (Option 10 Only)
 bit 6: Occupied BW Measurement On/Off
 bit 7: Not Used
 332) Impedance (00h = 50 Ω , 0Ah = 75 Ω Anritsu Adapter, 0Ch = 75 Ω Other Adapter)
 333) Impedance Loss¹⁹⁶ (Higher byte)
 334) Impedance Loss (Lower byte)
 335) Frequency Scale Factor¹⁹⁷ (Higher byte)
 336) Frequency Scale Factor (Lower byte)
 337) Frequency Range Minimum¹⁹⁸ (Highest byte)
 338) Frequency Range Minimum
 339) Frequency Range Minimum
 340) Frequency Range Minimum (Lowest byte)
 341) Frequency Range Maximum¹⁹⁹ (Highest byte)
 342) Frequency Range Maximum
 343) Frequency Range Maximum
 344) Frequency Range Maximum (Lowest byte)
 345) Linked Trace Number (1-200)
 346) Status Byte 9 (0b = Off, 1b = On)
 (LSB) bit 0: C/I Measurement On/Off
 bits 1-3: C/I Carrier Trace/Signal Type²⁰⁰
 bits 4-7: Not Used
 347) C/I Calculated Power²⁰¹ (Carrier or Interference – NB FHSS²⁰²) (Highest byte)
 348) C/I Calculated Power (Carrier or Interference – NB FHSS)
 349) C/I Calculated Power (Carrier or Interference – NB FHSS)
 350) C/I Calculated Power (Carrier or Interference – NB FHSS) (Lowest byte)
 351) C/I Calculated Power²⁰³ (Interference – WB FHSS²⁰⁴) (Highest byte)
 352) C/I Calculated Power (Interference – WB FHSS)
 353) C/I Calculated Power (Interference – WB FHSS)
 354) C/I Calculated Power (Interference – WB FHSS) (Lowest byte)
 355) C/I Calculated Power²⁰⁵ (Interference – Broadband²⁰⁶) (Highest byte)

¹⁹⁵ Value sent as (value in dBm * 1000) + 270,000

¹⁹⁶ Value sent as (value in dB * 1000), valid values are 0 to 20 dB

¹⁹⁷ In number of Hz

¹⁹⁸ Scaled by Frequency Scale Factor

¹⁹⁹ Scaled by Frequency Scale Factor

²⁰⁰ 000b = Carrier – NB FHSS, 001b = Carrier – WB FHSS, 010b = Carrier – Broadband, 111b = Interference

²⁰¹ Value sent as (value in dBm * 1000) + 270,000

²⁰² If Status Byte 9, bytes 1-3 equal 111b, then signal will be calculated power for the Interference – NB FHSS trace. Otherwise, these bytes represent the calculated Carrier power.

²⁰³ Value sent as (value in dBm * 1000) + 270,000

²⁰⁴ If Status Byte 9, bytes 1-3 equal 111b, then signal will be calculated power for the Interference – WB FHSS trace. Otherwise, these bytes should be ignored.

- 356) C/I Calculated Power (Interference – Broadband)
- 357) C/I Calculated Power (Interference – Broadband)
- 358) C/I Calculated Power (Interference – Broadband) (Lowest byte)
- 359) Occupied Bandwidth Power (Highest byte)²⁰⁷
- 360) Occupied Bandwidth Power
- 361) Occupied Bandwidth Power
- 362) Occupied Bandwidth Power (Lowest byte)
- 363) Marker Type²⁰⁸
- 364-367) GPS Position – Latitude (long integer)²⁰⁹
- 368-371) GPS Position – Longitude (long integer)
- 372-373) GPS Position – Altitude (short integer)
- 374) Signal Standard Link Type²¹⁰
- 375-398) Signal Standard Name, 24 bytes in ASCII
- 399) Measure Offset Status (0h = Off, 1h = On)
- 400-431) Not Used
- 432-2035) Sweep Data (401 points * 4 bytes/point= 1604 bytes)
 4 bytes for each data point
 - 1. dBm²¹¹ (Highest byte)
 - 2. dBm
 - 3. dBm
 - 4. dBm (Lowest byte)

For Power Meter Mode (both option 5 and narrow band):

- 57) Power Monitor Mode (00h = Off, 01h = On)
- 58) Power Meter Unit (00h = dBm, 01h = Watts)
- 59) Start Frequency²¹² (Highest byte)
- 60) Start Frequency
- 61) Start Frequency
- 62) Start Frequency (Lowest byte)
- 63) Stop Frequency²¹³ (Highest byte)
- 64) Stop Frequency
- 65) Stop Frequency
- 66) Stop Frequency (Lowest byte)
- 67) Center Frequency²¹⁴ (Highest byte)
- 68) Center Frequency
- 69) Center Frequency
- 70) Center Frequency (Lowest byte)
- 71) Frequency Span²¹⁵ (Highest byte)
- 72) Frequency Span
- 73) Frequency Span
- 74) Frequency Span (Lowest byte)

²⁰⁵ Value sent as (value in dBm * 1000) + 270,000

²⁰⁶ If Status Byte 9, bytes 1-3 equal 111b, then signal will be calculated power for the Interference – Broadband trace. Otherwise, these bytes should be ignored.

²⁰⁷ If Method is % of power then the value is db Down * 1000. If the method is db down, then the value is %

²⁰⁸ 00h = Regular Marker, 01h = Noise Marker

²⁰⁹ Signed long integer is used to represent latitude and longitude. Positive latitude means North hemisphere, negative latitude means South hemisphere; Positive longitude means East hemisphere, negative longitude means West hemisphere. Degree = int(abs(value)/1,000,000); Minute = (float)(abs(value)%1,000,000)/10,000

²¹⁰ 1 – Uplink, 2 – Downlink, 3 – Both, 0 – Invalid Link

²¹¹ Value sent as (value in dBm * 1000) + 270,000

²¹² Scaled by Frequency Scale Factor (bytes 96-97)

²¹³ Scaled by Frequency Scale Factor (bytes 96-97)

²¹⁴ Scaled by Frequency Scale Factor (bytes 96-97)

²¹⁵ Scaled by Frequency Scale Factor (bytes 96-97)

- 75) Power Offset Status (00h = Off, 01h = On)
- 76) Power Offset²¹⁶ (Highest byte)
- 77) Power Offset
- 78) Power Offset
- 79) Power Offset (Lowest byte)
- 80) Power Relative Status (00h = Off, 01h = On)
- 81) Power Relative Value²¹⁷ (Highest byte)
- 82) Power Relative Value
- 83) Power Relative Value
- 84) Power Relative Value (Lowest byte)
- 85) RMS Averaging Level (00h = Off, 01h = Low, 02h = Medium, 03h = High)
- 86) Power Zero Status (00h = Off, 01h = On)
- 87) External Reference Status (00h = Off, 01h = On)
- 88) External Reference Frequency (in Hz) (Highest byte)
- 89) External Reference Frequency (in Hz)
- 90) External Reference Frequency (in Hz)
- 91) External Reference Frequency (in Hz) (Lowest byte)
- 92) Signal Standard²¹⁸ (Highest byte)
- 93) Signal Standard (Lowest byte)
- 94) Channel Selection²¹⁹ (Highest byte)
- 95) Channel Selection (Lowest byte)
- 96) Frequency Scale Factor²²⁰ (Higher byte)
- 97) Frequency Scale Factor (Lower byte)
- 98) Frequency Range Minimum²²¹ (Highest byte)
- 99) Frequency Range Minimum
- 100) Frequency Range Minimum
- 101) Frequency Range Minimum (Lowest byte)
- 102) Frequency Range Maximum²²² (Highest byte)
- 103) Frequency Range Maximum
- 104) Frequency Range Maximum
- 105) Frequency Range Maximum (Lowest byte)
- 106 – 150) Not Used
- 151) Power Meter Reading²²³ (Highest byte)
- 152) Power Meter Reading
- 153) Power Meter Reading
- 154) Power Meter Reading (Lowest byte)
- 155) Measure Offset Status (0h = Off, 1h = On)

For T1 Tester / E1 Tester Mode (Option 50):

- 57) Receive Input (00h: Terminate, 01h: Bridged, 02h: Monitor)
- 58) Framing Mode²²⁴
- 59) Line Coding (01h: B8ZS, 02h: AMI, 03h: HDB3)
- 60) Tx Level (Valid for T1 Only) (01h: 0 dB, 02h: -7.5 dB, 03h: -15 dB)
- 61) Clock Source (00h: External, 01h: Internal)
- 62) Error Insert Type (00h: Frame Error, 01h: BPV, 02h: Bit Errors, 04h: RAI, 05h: AIS)

²¹⁶ Value sent as (value in dB * 1000), valid values are 0 to 60 dB

²¹⁷ Value sent as (value in dBm * 1000)

²¹⁸ Index into Standard List (use control byte #89 to retrieve the ASCII string name). “No Standard” sent as FFFEh

²¹⁹ “No Channel” is sent as FFFEh

²²⁰ In number of Hz

²²¹ Scaled by Frequency Scale Factor

²²² Scaled by Frequency Scale Factor

²²³ Power sent as (power in dBm * 1000). Use two’s-complement method to decode negative power levels.

²²⁴ T1 Mode: 01h: ESF, 02h: D4SF

E1 Mode: 03h: PCM30, 04h: PCM30CRC, 05h: PCM31, 06h: PCM31CRC

- 63) Loop Code (Valid for T1 Only) (00h: CSU, 01h: NIU, 02h: User 1, 03h: User 2)
- 64) Loop Type (Valid for T1 Only) (00h: In Band, 01h: Data Link)
- 65) CRC Method (Valid for T1 Only) (00h: ANSI CRC, 01h: Japanese CRC)
- 66) Display Type (00h: Histogram, 01h: Raw Data)
- 67) Impedance (Valid for E1 Only) (01h: 75 Ω , 02h: 120 Ω)
- 68) Pattern²²⁵
- 69) Pattern Invert Status (00h: Non-Inverted, 01h: Inverted)
- 70) Insert Bit Error Value (1-1000) (Higher byte)
- 71) Insert Bit Error Value (Lower byte)
- 72) Insert BPV Error Value (1-1000) (Higher byte)
- 73) Insert BPV Error Value (Lower byte)
- 74) Insert Frame Error Value (1-1000) (Higher byte)
- 75) Insert Frame Error Value (Lower byte)
- 76) Measurement Duration²²⁶
- 77) Histogram Resolution²²⁷
- 78) Frame Sync Status (00h: In Sync, 01h: Out-of-Sync)
- 79) Pattern Sync Status (00h: In Sync, 01h: Out-of-Sync)
- 80) Carrier Status (00h: In Sync, 01h: Out-of-Sync)
- 81) Rx Alarms (bit 0: Receiving AIS, bit 1: Receiving RAI, bit 2: Receiving E1 MMF error)
- 82) BPV Error Count (Highest byte)
- 83) BPV Error Count
- 84) BPV Error Count
- 85) BPV Error Count (Lowest byte)
- 86) CRC Error Count (Highest byte)
- 87) CRC Error Count
- 88) CRC Error Count
- 89) CRC Error Count (Lowest byte)
- 90) Frame Error Count (Highest byte)
- 91) Frame Error Count
- 92) Frame Error Count
- 93) Frame Error Count (Lowest byte)
- 94) LOF Error Count (Highest byte)
- 95) LOF Error Count
- 96) LOF Error Count
- 97) LOF Error Count (Lowest byte)
- 98) E Bit Error Count (E1 Only) (Highest byte)
- 99) E Bit Error Count (E1 Only)
- 100) E Bit Error Count (E1 Only)
- 101) E Bit Error Count (E1 Only) (Lowest byte)
- 102) Errored Seconds (Highest byte)
- 103) Errored Seconds
- 104) Errored Seconds
- 105) Errored Seconds (Lowest byte)
- 106) Bit Count (Highest byte)
- 107) Bit Count
- 108) Bit Count
- 109) Bit Count (Lowest byte)
- 110) Bit Errors (Highest byte)

²²⁵ Pattern: 01h: PRBS-9, 02h: PRBS-11, 03h: PRBS-15, 04h: PRBS-20(O.151), 05h: PRBS-20(O.153), 06h: PRBS-23, 07h: QRSS, 08h: 1 in 8, 09h: 2 in 8, 0Ah: 3 in 8, 0Bh: All Ones, 0Ch: All Zeros, 0Dh: T1-DALY, 0Eh: User Defined

²²⁶ Measurement Duration: 00h: Manual, 01h: 3 min, 02h: 15 min, 03h: 30 min, 04h: 1 hr, 05h: 3 hrs, 06h: 6 hrs, 07h: 12 hrs, 08h: 1 day, 09h: 2 days

²²⁷ Histogram Resolution: 00h: Auto, 01h: 1 sec, 02h: 15 sec, 03h: 30 sec, 04h: 45 sec, 05h: 1 min, 06h: 15 min, 07h: 30 min, 08h: 45 min, 09h: 60 min

- 111) Bit Errors
- 112) Bit Errors
- 113) Bit Errors (Lowest byte)
- 114) User Defined Pattern (convert to binary for pattern) (Highest byte)
- 115) User Defined Pattern
- 116) User Defined Pattern
- 117) User Defined Pattern (Lowest byte)
- 118 – 125) Measurement Start Time String (ASCII string: “HH:MM:SS”)
- 126 – 136) Measurement Stop Time String (ASCII string: “DD:HH:MM:SS”)
- 137 – 147) Elapsed Time String (ASCII string: “DD:HH:MM:SS”)
- 148 – 155) Bit Error Rate String (ASCII string in engineering format: x.xxE-xx)
- 156 – 655) 100 data points with 5 bytes for each data point.

1st byte has information about Carrier Loss, Frame Loss, BPV and CRC

Following 4 bytes corresponds to the Bit Error Count

Break down of the 1st byte :

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Not Used	Not Used	Not Used	Carrier Loss	Frame Loss	BPV Error	CRC / E- Bit Error	Any Error

656) Vpp or dBdsx (Higher byte) (Only in Vpp mode. See T1/E1 Read Vpp command for data format)

657) Vpp or dBdsx (Lower byte)

658) T1 or E1 Receive Frequency in Hz (Highest byte) (Only in BER mode)

659) T1 or E1 Receive Frequency in Hz

660) T1 or E1 Receive Frequency in Hz

661) T1 or E1 Receive Frequency in Hz (Lowest byte)

662 – 750) Not Used

For Channel Scanner Mode:

- 57) Reference Level (Highest Byte)
- 58) Reference Level
- 59) Reference Level
- 60) Reference Level (Lowest Byte)
- 61) Scale Division (Highest Byte)
- 62) Scale Division
- 63) Scale Division
- 64) Scale Division (Lowest Byte)
- 65) Start Frequency (Highest Byte)
- 66) Start Frequency
- 67) Start Frequency
- 68) Start Frequency (Lowest Byte)
- 69) Span Frequency (Highest Byte)
- 70) Span Frequency
- 71) Span Frequency
- 72) Span Frequency (Lowest Byte)
- 73) Channel Step (Highest Byte)
- 74) Channel Step (Lowest Byte)
- 75) Channel Frequency Step (Highest Byte)
- 76) Channel Frequency Step
- 77) Channel Frequency Step
- 78) Channel Frequency Step (Lowest Byte)
- 79) Number of Channels Displayed
- 80) External Reference Frequency²²⁸
- 81) Display Type Channels or Frequencies²²⁹

²²⁸ Frequency in MHz, OFF if 0

²²⁹ 0 – Channel, 1 - Frequency

- 82) Display Type Graph or Text²³⁰
- 83) Signal Standard (Highest Byte)
- 84) Signal Standard
- 85) Signal Standard
- 86) Signal Standard (Lowest Byte)
- 87-90) GPS Position – Latitude (long integer)²³¹
- 91-94) GPS Position – Longitude (long integer)
- 95-96) GPS Position – Altitude (short integer)
- 97) Start Channel (Highest Byte)
- 98) Start Channel
- 99) Start Channel
- 100) Start Channel (Lowest Byte)
- 101 – 124) Signal Standard Name, 24 bytes in ASCII
- 125 – 152) Reserved
- 153 – 272) Channel Scanner Data²³²

For Interference Analyzer RSSI Mode

- 57) Center Frequency (Highest Byte)
- 58) Center Frequency
- 59) Center Frequency
- 60) Center Frequency (Lowest Byte)
- 61) Reference Level (Highest Byte)
- 62) Reference Level
- 63) Reference Level
- 64) Reference Level (Lowest Byte)
- 65) Scale (Highest Byte)
- 66) Scale
- 67) Scale
- 68) Scale (Lowest Byte)
- 69) RBW (Highest Byte)
- 70) RBW
- 71) RBW
- 72) RBW (Lowest Byte)
- 73) VBW (Highest Byte)
- 74) VBW
- 75) VBW
- 76) VBW (Lowest Byte)
- 77) Status Byte 1
 - Bit 0 - Detection Algorithm (Lowest Bit)²³³
 - Bit 1 - Detection Algorithm
 - Bit 2 - Detection Algorithm (Highest Bit)
 - Bit 3 - Not Used
 - Bit 4 - Not Used
 - Bit 5 - Not Used
 - Bit 6 - Not Used
- 78) Reference Level Offset (Highest Byte)
- 79) Reference Level Offset
- 80) Reference Level Offset

²³⁰ 0 – Graph, 1 - Text

²³¹ Signed long integer is used to represent latitude and longitude. Positive latitude means North hemisphere, negative latitude means South hemisphere; Positive longitude means East hemisphere, negative longitude means West hemisphere. Degree = int(abs(value)/1,000,000); Minute = (float)(abs(value)%1,000,000)/10,000

²³² 20 points, 6 bytes per point. First 2 bytes are channel numbers(Invalid channels sent as 0xFFFF) and 4 bytes are values. Value sent as (value in dBm) * 1000 + 270,000

²³³ 000 - Positive Peak, 010 – RMS Averaging, 100 – Negative Peak, 110 – Sampling Mode

81)	Reference Level Offset (Lowest Byte)
82)	External Reference Frequency ²³⁴
83)	Signal Standard (Highest Byte)
84)	Signal Standard (Lowest Byte)
85)	Channel (Highest Byte) ²³⁵
86)	Channel (Lowest Byte)
87)	Min RSSI Measured (Highest Byte)
88)	Min RSSI Measured
89)	Min RSSI Measured
90)	Min RSSI Measured (Lowest Byte)
91)	Max RSSI Measured (Highest Byte)
92)	Max RSSI Measured
93)	Max RSSI Measured
94)	Max RSSI Measured (Lowest Byte)
95)	Measure Duration (Highest Byte) ²³⁶
96)	Measure Duration
97)	Measure Duration
98)	Measure Duration (Lowest Byte)
99)	Sweep Point Interval(Highest Byte) ²³⁷
100)	Sweep Point Interval
101)	Sweep Point Interval
102)	Sweep Point Interval (Lowest Byte)
103 – 106)	GPS Position – Latitude (long integer) ²³⁸
107 – 110)	GPS Position – Longitude (long integer)
111 – 112)	GPS Position – Altitude (short integer)
113)	Signal Standard
114 – 117)	Start GPS Position – Latitude (long integer) ²³⁹
118 – 121)	Start GPS Position – Longitude (long integer)
122 – 123)	Start GPS Position – Altitude (short integer)
124)	Attenuation (Highest Byte) ²⁴⁰
125)	Attenuation
126)	Attenuation
127)	Attenuation (Lowest Byte)
128 – 151)	Signal Standard Name, 24 bytes in ASCII
152)	Measure Offset Status (0h = Off, 1h = On)
153 – 207)	Reserved
208 – 3415)	RSSI Sweep data ²⁴¹

For High Accuracy Power Meter Mode

57)	Center Frequency(Highest Byte) ²⁴²
-----	---

²³⁴ Frequency in MHz, OFF if 0

²³⁵ Invalid channels are sent as 0xFFFF

²³⁶ Measure Duration time in minutes

²³⁷ Sweep Point Interval time in milliseconds

²³⁸ Signed long integer is used to represent latitude and longitude. Positive latitude means North hemisphere, negative latitude means South hemisphere; Positive longitude means East hemisphere, negative longitude means West hemisphere. Degree = $\text{int}(\text{abs}(\text{value})/1,000,000)$; Minute = $(\text{float})(\text{abs}(\text{value})\%1,000,000)/10,000$

²³⁹ Signed long integer is used to represent latitude and longitude. Positive latitude means North hemisphere, negative latitude means South hemisphere; Positive longitude means East hemisphere, negative longitude means West hemisphere. Degree = $\text{int}(\text{abs}(\text{value})/1,000,000)$; Minute = $(\text{float})(\text{abs}(\text{value})\%1,000,000)/10,000$

²⁴⁰ Attenuation is sent as (Att in dB * 1000)

²⁴¹ Sweep Data contains 401 display points, 8 bytes per display point. The first 4 bytes are the amplitude, the next 2 bytes are the latitude increments from the start GPS position and the following 2 bytes are the longitude increments from the Start GPS position.

²⁴² in kHz

58)	Center Frequency
59)	Center Frequency
60)	Center Frequency(Lowest Byte)
61)	Power Reading(Highest Byte) ²⁴³
62)	Power Reading(Lowest Byte)
63)	Max Hold Status (0h = Off, 1h = On)
64)	Offset Status (0h = Off, 1h = On)
65)	Offset Value(Highest Byte) ²⁴⁴
66)	Offset Value(Lowest Byte)
67)	Measure Offset Status (0h = Off, 1h = On)
68)	Measure Offset Value(Highest Byte) ²⁴⁵
69)	Measure Offset Value(Lowest Byte)
70)	Relative Value(Highest Byte) ²⁴⁶
71)	Relative Value(Lowest Byte)
72)	Relative Status (0h = Off, 1h = On)
73)	Running Averages Number(Highest Byte)
74)	Running Averages Number(Lowest Byte)
75 – 76)	Signal Standard ID
77 – 100)	Signal Standard Name
101)	Zero Status (0h = Off, 1h = On)
102)	Limit Status (0h = Off, 1h = On)
103)	Upper Limit dBm(Highest Byte) ²⁴⁷
104)	Upper Limit dBm(Lowest Byte)
105)	Lower Limit dBm(Highest Byte) ²⁴⁸
106)	Lower Limit dBm(Lowest Byte)
107)	Limit Unit Display
108)	Error Message Status ²⁴⁹
109 – 112)	GPS Position – Latitude (long integer) ²⁵⁰
113 – 116)	GPS Position – Longitude (long integer)
117 – 118)	GPS Position – Altitude (short integer)
119 – 128)	UTC Time, 10 bytes in ASCII
129 – 256)	Reserved Byte

Site Master Returns (For invalid sweeps/empty stored sweep locations): 11 bytes

- 1-2) Number of following bytes (9 bytes for invalid sweep recall)
- 3) Current Instrument Date Format²⁵¹
- 4) Model # (unsigned integer, 10h for Site Master model S331D, 11h for Site Master model S332D)
- 5-11) Extended Model # (7 bytes in ASCII)

Site Master Returns (Invalid sweep location): 1 byte

- 1) 224 (E0) Parameter Error: Invalid sweep location

²⁴³ in 2-complement and in dBm

²⁴⁴ in 2-complement and in dB

²⁴⁵ in 2-complement and in dB

²⁴⁶ in 2-complement and in dBm

²⁴⁷ in 2-complement

²⁴⁸ in 2-complement

²⁴⁹ Bit 0: set to 1 if there is power supply error in the power sensor module. Bit 1: set to 1 if there is too much RF power going into the sensor module. Bit 2: set to 1 if zeroing is done incorrectly. Bit 3: set to 1 if power sensor's operating temperature range is exceeded. Bit 4: set to 1 if temperature has drifted by more than specified degree since the last zeroing.

²⁵⁰ Signed long integer is used to represent latitude and longitude. Positive latitude means North hemisphere, negative latitude means South hemisphere; Positive longitude means East hemisphere, negative longitude means West hemisphere. Degree = int(abs(value)/1,000,000); Minute = (float)(abs(value)%1,000,000)/10,000

²⁵¹ 00h = MM/DD/YYYY, 01h = DD/MM/YYYY, 02h = YYYY/MM/DD

Set Site Master VNA Trace Overlay – Control Byte #34 (22h)

Description: Setup trace overlay operation and trace for VNA modes.

Bytes to Follow: 2 bytes

- 1) Trace Overlay Operation (0 or 1)
 - 00h = Off
 - 01h = On
- 2) Trace on which to Perform Overlay Operation (1 to 200)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error: Invalid Trace Overlay Operation
 - 238 (EEh) Time-out Error
-

Set SPA A/B Trace – Control Byte #35 (23h)

Description: Defines traces “A” and “B” for Spectrum Analyzer mode.

Trace A is always the currently measured data (with or without trace math). It is always visible.

Trace B is always stored data and may come from a saved sweep or a previous “A” trace. There is no default for trace B. Trace B can be ON (visible) or OFF.

Bytes to Follow: 3 bytes

- 1) “A” trace display (00h = A only, 01h = A-B, 02h = A+B)
- 2) “B” trace status (00h = Off, 01h = On)
- 3) “B” trace number
 - 0 = save current “A” data into “B” buffer, use that as “B”
 - 1-200 = trace number
 - 255 = no “B” trace defined

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error: Not enough bytes transferred, “B” trace requested to be used in calculations or displayed, but no trace or invalid trace specified
 - 238 (EEh) Time-out Error
-

Upload Sweep Trace – Control Byte #36 (24h)

This command is new to the S33xD. Use it instead of Control Bytes #26 and #28 to access the new features.

Description: Uploads a sweep trace to the Site Master.

Bytes to Follow:

For All Modes:

- 1-2) # of following bytes
- 3) Measurement Mode²⁵²
- 4-7) Time/Date (in Long Integer)
- 8-17) Date in String Format (MM/DD/YYYY)
- 18-25) Time in String Format (HH:MM:SS)

²⁵² See Control Byte #3 “Set Measurement Mode” for available measurement modes.

- 26-41) Reference number stamp (16 ASCII bytes)
- 42-43) # of data points (130, 259, 517 or 401 or 100)

For VNA Modes:

- 44) Start Frequency²⁵³ (Highest byte)
- 45) Start Frequency
- 46) Start Frequency
- 47) Start Frequency (Lowest byte)
- 48) Stop Frequency²⁵⁴ (Highest byte)
- 49) Stop Frequency
- 50) Stop Frequency
- 51) Stop Frequency (Lowest byte)
- 52) Minimum Frequency Step Size (Highest byte)
- 53) Minimum Frequency Step Size
- 54) Minimum Frequency Step Size
- 55) Minimum Frequency Step Size (Lowest byte)
- 56) Scale Top (Highest byte)²⁵⁵
- 57) Scale Top
- 58) Scale Top
- 59) Scale Top (Lowest byte)
- 60) Scale Bottom (Highest byte)
- 61) Scale Bottom
- 62) Scale Bottom
- 63) Scale Bottom (Lowest byte)
- 64) Frequency Marker 1 (Higher byte)²⁵⁶
- 65) Frequency Marker 1 (Lower byte)
- 66) Frequency Marker 2 (Higher byte)
- 67) Frequency Marker 2 (Lower byte)
- 68) Frequency Marker 3 (Higher byte)
- 69) Frequency Marker 3 (Lower byte)
- 70) Frequency Marker 4 (Higher byte)
- 71) Frequency Marker 4 (Lower byte)
- 72) Frequency Marker 5 (Higher byte)
- 73) Frequency Marker 5 (Lower byte)
- 74) Frequency Marker 6 (Higher byte)
- 75) Frequency Marker 6 (Lower byte)
- 76) Single Limit Line Value (Highest byte)²⁵⁷
- 77) Single Limit Line Value
- 78) Single Limit Line Value
- 79) Single Limit Line Value (Lowest byte)
- 80) Multiple Limit Segment # (1)
- 81) Multiple Limit Segment Status (00h = Off, 01h = On)
- 82) Multiple Limit Start X (Highest byte)²⁵⁸
- 83) Multiple Limit Start X
- 84) Multiple Limit Start X
- 85) Multiple Limit Start X (Lowest byte)
- 86) Multiple Limit Start Y (Higher byte)
- 87) Multiple Limit Start Y (Lower byte)

²⁵³ Frequency is scaled by the frequency scale factor specified in byte 245-246.

²⁵⁴ Frequency is scaled by the frequency scale factor specified in byte 245-246.

²⁵⁵ See Control Byte #4, "Set Site Master VNA Scale" for data format.

²⁵⁶ Marker point = (Number of data points – 1) * (marker freq – start freq) / (stop freq – start freq)

²⁵⁷ See Control Byte #6, "Set Site Master VNA Single Limit" for data format

²⁵⁸ See Control Byte #112, "Set Site Master VNA Segmented Limit Lines" for data format. Frequency is scaled by the frequency scale factor specified in bytes 245-246.

- 88) Multiple Limit End X (Highest byte)²⁵⁹
- 89) Multiple Limit End X
- 90) Multiple Limit End X
- 91) Multiple Limit End X (Lowest byte)
- 92) Multiple Limit End Y (Higher byte)
- 93) Multiple Limit End Y (Lower byte)
- 94-149) Repeat bytes 80-93 for segments 2-5
- 150) Start Distance (Highest byte)²⁶⁰
- 151) Start Distance
- 152) Start Distance
- 153) Start Distance (Lowest byte)
- 154) Stop Distance (Highest byte)
- 155) Stop Distance
- 156) Stop Distance
- 157) Stop Distance (Lowest byte)
- 158) Distance Marker 1 (Higher byte)²⁶¹
- 159) Distance Marker 1 (Lower byte)
- 160) Distance Marker 2 (Higher byte)
- 161) Distance Marker 2 (Lower byte)
- 162) Distance Marker 3 (Higher byte)
- 163) Distance Marker 3 (Lower byte)
- 164) Distance Marker 4 (Higher byte)
- 165) Distance Marker 4 (Lower byte)
- 166) Distance Marker 5 (Higher byte)
- 167) Distance Marker 5 (Lower byte)
- 168) Distance Marker 6 (Higher byte)
- 169) Distance Marker 6 (Lower byte)
- 170) Relative Propagation Velocity (Highest byte)²⁶²
- 171) Relative Propagation Velocity
- 172) Relative Propagation Velocity
- 173) Relative Propagation Velocity (Lowest byte)
- 174) Cable Loss (Highest byte)²⁶³
- 175) Cable Loss
- 176) Cable Loss
- 177) Cable Loss (Lowest byte)
- 178) Average Cable Loss²⁶⁴ (Highest byte)
- 179) Average Cable Loss
- 180) Average Cable Loss
- 181) Average Cable Loss (Lowest byte)
- 182) Status Byte 1: (0b = Off, 1b = On)
 - (LSB) bit 0 : Marker 1 On/Off
 - bit 1 : Marker 2 On/Off
 - bit 2 : Marker 3 On/Off
 - bit 3 : Marker 4 On/Off
 - bit 4 : Marker 5 On/Off
 - bit 5 : Marker 6 On/Off
 - bits 6-7 : Not Used
- 183) Status Byte 2: (0b = Off, 1b = On)
 - (LSB) bit 0 : Marker 2 Delta On/Off

²⁵⁹ Frequency is scaled by the frequency scale factor specified in bytes 245-246.

²⁶⁰ Distance data uses units 1/100,000m or 1/100,000 ft

²⁶¹ Marker point = (# of data points – 1) * (marker dist – start dist) / (stop dist – start dist)

²⁶² Relative Propagation Velocity uses units 1/100,000

²⁶³ Cable Loss uses units 1/100,000 dB/m or 1/100,000 dB/ft

²⁶⁴ Average Cable Loss is dB * 1000.

- bit 1 : Marker 3 Delta On/Off
- bit 2 : Marker 4 Delta On/Off
- bits 3-7: Not Used
- 184) Status Byte 3: (0b = Off , 1b = On)
 - (LSB) bit 0 : Single Limit On/Off
 - bit 1: CW On/Off
 - bit 2: Trace Math On/Off
 - bits 3-5: Not Used
 - bit 6 : Limit Type (0b = Single; 1b = Multiple)
 - bit 7 : Unit of measurement (1b = Metric, 0b = English)
- 185) Status Byte 4:
 - (LSB) bit 0 - 1 : DTF Windowing Mode
 - bit: 1 0
 - | |
 - 0 0 - Rectangular (No Windowing)
 - 0 1 - Nominal Side Lobe
 - 1 0 - Low Side Lobe
 - 1 1 - Minimum Side Lobe
 - bits 2 – 7 : Not Used
- 186) Status Byte 5 (Cal Status) :
 - 00h : Calibration Off
 - 01h : Standard Calibration On
 - 02h : InstaCal Calibration On
 - 03h : Standard FlexCal On
 - 04h : InstaCal FlexCal On
- 187) VNA Signal Standard²⁶⁵ (Higher byte)
- 188) VNA Signal Standard (Lower byte)
- 189-192) GPS Position – Latitude (long integer)²⁶⁶
- 193-196) GPS Position – Longitude (long integer)
- 197-198) GPS Position – Altitude (short integer)
- 199) Reserved
- 200-223) Signal Standard Name, 24 bytes in ASCII
- 224-244) Cable Name, 21 bytes in ASCII
- 245) Frequency Scale Factor²⁶⁷ (Higher byte)
- 246) Frequency Scale Factor (Lower byte)
- 248-314) Not Used
- 315-1354) Sweep Data (130 points * 8 bytes/point= 1040 bytes)
- 315-2386) (259 points * 8 bytes/point= 2072 bytes)
- 315-4450) (517 points * 8 bytes/point= 4136 bytes)
- 8 bytes for each data point
 - 1. Gamma²⁶⁸ (Highest byte)
 - 2. Gamma
 - 3. Gamma
 - 4. Gamma (Lowest byte)
 - 5. Phase²⁶⁹ (Highest byte)
 - 6. Phase
 - 7. Phase
 - 8. Phase (Lowest byte)

²⁶⁵ Index into Standard List (use control byte #89 to retrieve the ASCII string name). “No Standard” sent as FFFEh

²⁶⁶ Signed long integer is used to represent latitude and longitude. Positive latitude means North hemisphere, negative latitude means South hemisphere; Positive longitude means East hemisphere, negative longitude means West hemisphere. Degree = int(abs(value)/1,000,000); Minute = (float)(abs(value)%1,000,000)/10,000

²⁶⁷ Frequency Scale Factor is in number of Hz.

²⁶⁸ Gamma uses units scaled to 1/10,000

²⁶⁹ Phase is transmitted in 1/10ths of a degree

Notes:

return loss = $-20 * (\log(\text{Gamma}) / \log(10))$

VSWR = $(1+\text{Gamma})/(1-\text{Gamma})$

Phase compares the reflected to the incident (reference)

For Spectrum Analyzer Mode:

- 44) Start Frequency²⁷⁰ (Highest byte)
- 45) Start Frequency
- 46) Start Frequency
- 47) Start Frequency (Lowest byte)
- 48) Stop Frequency²⁷¹ (Highest byte)
- 49) Stop Frequency
- 50) Stop Frequency
- 51) Stop Frequency (Lowest byte)
- 52) Center Frequency²⁷² (Highest byte)
- 53) Center Frequency
- 54) Center Frequency
- 55) Center Frequency (Lowest byte)
- 56) Frequency Span²⁷³ (Highest byte)
- 57) Frequency Span
- 58) Frequency Span
- 59) Frequency Span (Lowest byte)
- 60) Ref Level²⁷⁴ (Highest byte)
- 61) Ref Level
- 62) Ref Level
- 63) Ref Level (Lowest byte)
- 64) Scale per div²⁷⁵ (Highest byte)
- 65) Scale per div
- 66) Scale per div
- 67) Scale per div (Lowest byte)
- 68) Marker 1²⁷⁶ (Higher byte)
- 69) Marker 1 (Lower byte)
- 70) Marker 2 (Higher byte)
- 71) Marker 2 (Lower byte)
- 72) Marker 3 (Higher byte)
- 73) Marker 3 (Lower byte)
- 74) Marker 4 (Higher byte)
- 75) Marker 4 (Lower byte)
- 76) Marker 5 (Higher byte)
- 77) Marker 5 (Lower byte)
- 78) Marker 6 (Higher byte)
- 79) Marker 6 (Lower byte)
- 80) Single Limit²⁷⁷ (Highest byte)
- 81) Single Limit
- 82) Single Limit

²⁷⁰ Scaled by Frequency Scale Factor (bytes 318-319)

²⁷¹ Scaled by Frequency Scale Factor (bytes 318-319)

²⁷² Scaled by Frequency Scale Factor (bytes 318-319)

²⁷³ Scaled by Frequency Scale Factor (bytes 318-319)

²⁷⁴ Value sent as (value in dBm * 1000) + 270,000

²⁷⁵ Value sent as (value * 1000)

²⁷⁶ Marker values are sent as # of data point on display.

See Control Byte #102, "Set Spectrum Analyzer Marker" for calculation of data point.

²⁷⁷ All amplitude values are sent as (value in dBm * 1000) + 270,000

- 83) Single Limit (Lowest byte)
- 84) Multiple Upper Limit 1 Start X²⁷⁸ (Highest byte)
- 85) Multiple Upper Limit 1 Start X
- 86) Multiple Upper Limit 1 Start X
- 87) Multiple Upper Limit 1 Start X (Lowest byte)
- 88) Multiple Upper Limit 1 Start Y (Power Level) (Highest byte)
- 89) Multiple Upper Limit 1 Start Y (Power Level)
- 90) Multiple Upper Limit 1 Start Y (Power Level)
- 91) Multiple Upper Limit 1 Start Y (Power Level) (Lowest byte)
- 92) Multiple Upper Limit 1 End X²⁷⁹ (Highest byte)
- 93) Multiple Upper Limit 1 End X
- 94) Multiple Upper Limit 1 End X
- 95) Multiple Upper Limit 1 End X (Lowest byte)
- 96) Multiple Upper Limit 1 End Y (Power Level) (Highest byte)
- 97) Multiple Upper Limit 1 End Y (Power Level)
- 98) Multiple Upper Limit 1 End Y (Power Level)
- 99) Multiple Upper Limit 1 End Y (Power Level) (Lowest byte)
- 100-243) Multiple Upper Limits 2-5, Multiple Lower Limits 1-5 (see bytes 84-99 for format)
- 244) RBW Setting²⁸⁰ (Highest byte)
- 245) RBW Setting
- 246) RBW Setting
- 247) RBW Setting (Lowest byte)
- 248) VBW Setting²⁸¹ (Highest byte)
- 249) VBW Setting
- 250) VBW Setting
- 251) VBW Setting (Lowest byte)
- 252) OCC BW Method (00h = % of power, 01h = dB down)
- 253) OCC BW % Value (0-99)
- 254) OCC BW dBc (0-120)
- 255) Attenuation²⁸² (Highest byte)
- 256) Attenuation
- 257) Attenuation
- 258) Attenuation (Lowest byte)
- 259-274) Antenna Name (16 bytes in ASCII)
- 275) Status Byte 1: (0b = Off, 1b = On)
 - (LSB) bit 0 : Marker 1 On/Off
 - bit 1 : Marker 2 On/Off
 - bit 2 : Marker 3 On/Off
 - bit 3 : Marker 4 On/Off
 - bit 4 : Marker 5 On/Off
 - bit 5 : Marker 6 On/Off
 - bits 6-7: Not Used
- 276) Status Byte 2: (0b = Off, 1b = On)
 - (LSB) bit 0 : Not Used
 - bit 1 : Marker 2 Delta On/Off
 - bit 2 : Marker 3 Delta On/Off
 - bit 3 : Marker 4 Delta On/Off
 - bit 4 : Pre Amp Mode (0b = Manual, 1b = Auto)
 - bit 5 : Pre Amp Status On/Off
 - bit 6 : Dynamic Attenuation On/Off

²⁷⁸ Scaled by Frequency Scale Factor (bytes 318-319)

²⁷⁹ Scaled by Frequency Scale Factor (bytes 318-319)

²⁸⁰ Valid frequencies (in Hz) are 100, 300, 1,000, 3,000, 10,000, 30,000, 100,000, 300,000, 1,000,000

²⁸¹ Valid frequencies (in Hz) are 100, 300, 1,000, 3,000, 10,000, 30,000, 100,000, 300,000

²⁸² Value sent as (value * 1000)

- bit 7 : Normalization On/Off
- 277) Status Byte 3: (0b = Off, 1b = On)
 (LSB) bit 0 : Antenna Factor Correction On/Off
 bits 1-2 : Detection alg (00b = pos. peak 01b = RMS Averaging 10b = neg. peak, 11 = Sampling Mode)
 bits 3-4 : Amplitude Units (log) (00b = dBm 01b = dBV 10b = dBmV 11b = dBuV)
 (Linear) – (00b = Watts 01b = Volts)
 bit 5: Channel Power On/Off
 bit 6: Adjacent Channel Power Ratio On/Off
 bit 7 : Units Type (0b = Log 1b = Linear)
- 278) Status Byte 4
 (0b = Off/Beep if data is BELOW line, 1b = On/Beep if data is ABOVE line)
 (LSB) bit 0 : Limit Type (0b = Single, 1b = Multiple)
 bit 1 : Single Limit On/Off
 bit 2 : Single Limit Beep Level (0b = beep when data is below line 1b = above)
 bit 3 : Not Used
 bit 4 : Multiple Limit Upper Segment 1 Status On/Off
 bit 5 : Multiple Limit Upper Segment 1 Beep Level ABOVE/BELOW
 bit 6 : Multiple Limit Upper Segment 2 Status On/Off
 bit 7 : Multiple Limit Upper Segment 2 Beep Level ABOVE/BELOW
- 279) Status Byte 5
 (0b = Off/Beep if data is BELOW line, 1b = On/Beep if data is ABOVE line)
 (LSB) bit 0 : Multiple Limit Upper Segment 3 Status On/Off
 bit 1 : Multiple Limit Upper Segment 3 Beep Level ABOVE/BELOW
 bit 2 : Multiple Limit Upper Segment 4 Status On/Off
 bit 3 : Multiple Limit Upper Segment 4 Beep Level ABOVE/BELOW
 bit 4 : Multiple Limit Upper Segment 5 Status On/Off
 bit 5 : Multiple Limit Lower Segment 5 Beep Level ABOVE/BELOW
 bit 6 : Multiple Limit Lower Segment 1 Status On/Off
 bit 7 : Multiple Limit Lower Segment 1 Beep Level ABOVE/BELOW
- 280) Status Byte 6
 (0b = Off/Beep if data is BELOW line, 1b = On/Beep if data is ABOVE line)
 (LSB) bit 0 : Multiple Limit Lower Segment 2 Status On/Off
 bit 1 : Multiple Limit Lower Segment 2 Beep Level ABOVE/BELOW
 bit 2 : Multiple Limit Lower Segment 3 Status On/Off
 bit 3 : Multiple Limit Lower Segment 3 Beep Level ABOVE/BELOW
 bit 4 : Multiple Limit Lower Segment 4 Status On/Off
 bit 5 : Multiple Limit Lower Segment 4 Beep Level ABOVE/BELOW
 bit 6 : Multiple Limit Lower Segment 5 Status On/Off
 bit 7 : Multiple Limit Lower Segment 5 Beep Level ABOVE/BELOW
- 281) Status Byte 7
 (LSB) bits 0-6: Number of Sweeps to Average (1-25, 1 implies averaging OFF)
 bit 7 : Not Used
- 282) Reference Level Offset²⁸³ (Highest byte)
 283) Reference Level Offset
 284) Reference Level Offset
 285) Reference Level Offset (Lowest byte)
 286) External Reference Frequency²⁸⁴
 287) Signal Standard²⁸⁵ (Higher byte)
 288) Signal Standard (Lower byte)
 289) Channel Selection²⁸⁶ (Higher byte)

²⁸³ Value sent as (Value in dBm * 1000) + 270,000

²⁸⁴ byte in MHz (i.e. 20 = 20MHz)

²⁸⁵ Index into Standard List (use control byte #89 to retrieve the ASCII string name). “No Standard” sent as FFFEh.

²⁸⁶ “No Channel” is sent as FFFEh.

- 290) Channel Selection (Lower byte)
 291) Interference Analysis Cellular Standard²⁸⁷
 292) Interference Analysis Estimated Bandwidth (Highest byte)
 293) Interference Analysis Estimated Bandwidth
 294) Interference Analysis Estimated Bandwidth
 295) Interference Analysis Estimated Bandwidth (Lowest byte)
 296) Interference Analysis Frequency²⁸⁸ (Highest byte)
 297) Interference Analysis Frequency
 298) Interference Analysis Frequency
 299) Interference Analysis Frequency (Lowest byte)
 300-303) Reserved
 304) Trigger Type²⁸⁹
 305) Trigger Position (0 – 100%)
 306) Min Sweep Time (in μ s) (Highest byte)
 307) Min Sweep Time (in μ s)
 308) Min Sweep Time (in μ s)
 309) Min Sweep Time (in μ s) (Lowest byte)
 310) Video Trigger Level²⁹⁰ (Highest byte)
 311) Video Trigger Level
 312) Video Trigger Level
 313) Video Trigger Level (Lowest byte)
 314) Status Byte 8 (0b = Off, 1b = On)
 (LSB) bit 0-1: Trace Math Operation (00b = A only, 01b = A-B, 10b = A+B)
 bit 2: Max Hold On/Off
 bit 3: Min Hold On/Off
 bit 4: Transmission Calibration Status (Option 21 Only)
 bit 5: Bias Tee On/Off (Option 10 Only)
 bit 6: Occupied BW Measurement On/Off
 bit 7: Not Used
 315) Impedance (00h = 50 Ω , 0Ah = 75 Ω Anritsu Adapter, 0Ch = 75 Ω Other Adapter)
 316) Impedance Loss²⁹¹ (Higher byte)
 317) Impedance Loss (Lower byte)
 318) Frequency Scale Factor²⁹² (Higher byte)
 319) Frequency Scale Factor (Lower byte)
 320) Frequency Range Minimum²⁹³ (Highest byte)
 321) Frequency Range Minimum
 322) Frequency Range Minimum
 323) Frequency Range Minimum (Lowest byte)
 324) Frequency Range Maximum²⁹⁴ (Highest byte)
 325) Frequency Range Maximum
 326) Frequency Range Maximum
 327) Frequency Range Maximum (Lowest byte)
 328) Linked Trace Number (1-200)
 329) Status Byte 9 (0b = Off, 1b = On)
 (LSB) bit 0: C/I Measurement On/Off

²⁸⁷ 4 Standards – 00h = 1250kHz CDMA, 01h = GSM, 02h = TDMA, 03h = AMPS, 04h = Unknown FFh = Interference Analysis Measurement OFF

²⁸⁸ Scaled by Frequency Scale Factor (bytes 318-319)

²⁸⁹ Trigger Type – 00h = Single, 01h = Free Run, 02h = Video, 03h = External

²⁹⁰ Value sent as (Value in dBm * 1000) + 270,000

²⁹¹ Value sent as (value in dB * 1000), valid values are 0 to 20 dB

²⁹² In number of Hz

²⁹³ Scaled by Frequency Scale Factor

²⁹⁴ Scaled by Frequency Scale Factor

- bits 1-3: C/I Carrier Trace/Signal Type²⁹⁵
bits 4-7: Not Used
- 330) C/I Calculated Power²⁹⁶ (Carrier or Interference – NB FHSS²⁹⁷) (Highest byte)
 - 331) C/I Calculated Power (Carrier or Interference – NB FHSS)
 - 332) C/I Calculated Power (Carrier or Interference – NB FHSS)
 - 333) C/I Calculated Power (Carrier or Interference – NB FHSS) (Lowest byte)
 - 334) C/I Calculated Power²⁹⁸ (Interference – WB FHSS²⁹⁹) (Highest byte)
 - 335) C/I Calculated Power (Interference – WB FHSS)
 - 336) C/I Calculated Power (Interference – WB FHSS)
 - 337) C/I Calculated Power (Interference – WB FHSS) (Lowest byte)
 - 338) C/I Calculated Power³⁰⁰ (Interference – Broadband³⁰¹) (Highest byte)
 - 339) C/I Calculated Power (Interference – Broadband)
 - 340) C/I Calculated Power (Interference – Broadband)
 - 341) C/I Calculated Power (Interference – Broadband) (Lowest byte)
 - 342) Marker Type³⁰²
 - 343-400) Not Used
 - 401-2004) Sweep Data (401 points * 4 bytes/point = 1604 bytes)
4 bytes for each data point
 - 1. dBm³⁰³ (Highest byte)
 - 2. dBm
 - 3. dBm
 - 4. dBm (Lowest byte)

For Power Meter:

- 44) Power Monitor Mode (00h = Off, 01h = On)
- 45) Power Meter Unit (00h = dBm, 01h = Watts)
- 46) Start Frequency³⁰⁴ (Highest byte)
- 47) Start Frequency
- 48) Start Frequency
- 49) Start Frequency (Lowest byte)
- 50) Stop Frequency³⁰⁵ (Highest byte)
- 51) Stop Frequency
- 52) Stop Frequency
- 53) Stop Frequency (Lowest byte)
- 54) Center Frequency³⁰⁶ (Highest byte)
- 55) Center Frequency
- 56) Center Frequency
- 57) Center Frequency (Lowest byte)
- 58) Frequency Span³⁰⁷ (Highest byte)

²⁹⁵ 000b = Carrier – NB FHSS, 001b = Carrier – WB FHSS, 010b = Carrier – Broadband, 111b = Interference

²⁹⁶ Value sent as (value in dBm * 1000) + 270,000

²⁹⁷ If Status Byte 9, bytes 1-3 equal 111b, then value will be calculated power for the Interference – NB FHSS trace. Otherwise, these bytes represent the calculated Carrier power.

²⁹⁸ Value sent as (value in dBm * 1000) + 270,000

²⁹⁹ If Status Byte 9, bytes 1-3 equal 111b, then value will be calculated power for the Interference – WB FHSS trace. Otherwise, these bytes should be ignored.

³⁰⁰ Value sent as (value in dBm * 1000) + 270,000

³⁰¹ If Status Byte 9, bytes 1-3 equal 111b, then value will be calculated power for the Interference – Broadband trace. Otherwise, these bytes should be ignored.

³⁰² 00h = Regular Marker, 01h = Noise Marker

³⁰³ Value sent as (Value in dBm * 1000) + 270,000

³⁰⁴ Scaled by Frequency Scale Factor (bytes 96-97)

³⁰⁵ Scaled by Frequency Scale Factor (bytes 96-97)

³⁰⁶ Scaled by Frequency Scale Factor (bytes 96-97)

³⁰⁷ Scaled by Frequency Scale Factor (bytes 96-97)

59)	Frequency Span
60)	Frequency Span
61)	Frequency Span (Lowest byte)
62)	Power Offset Status (00h = Off, 01h = On)
63)	Power Offset ³⁰⁸ (Highest byte)
64)	Power Offset
65)	Power Offset
66)	Power Offset (Lowest byte)
67)	Power Relative Status (00h = Off, 01h = On)
68)	Power Relative Value ³⁰⁹ (Highest byte)
69)	Power Relative Value
70)	Power Relative Value
71)	Power Relative Value (Lowest byte)
72)	RMS Averaging Level (00h = Off, 01h = Low, 02h = Medium, 03h = High)
73)	Power Zero Status (00h = Off, 01h = On)
74)	External Reference Status (00h = Off, 01h = On)
75)	External Reference Frequency (in Hz) (Highest byte)
76)	External Reference Frequency (in Hz)
77)	External Reference Frequency (in Hz)
78)	External Reference Frequency (in Hz) (Lowest byte)
79)	Signal Standard ³¹⁰ (higher byte)
80)	Signal Standard (lower byte)
81)	Channel Selection ³¹¹ (higher byte)
82)	Channel Selection (lower byte)
83)	Frequency Scale Factor ³¹² (higher byte)
84)	Frequency Scale Factor (lower byte)
85)	Frequency Range Minimum ³¹³ (Highest byte)
86)	Frequency Range Minimum
87)	Frequency Range Minimum
88)	Frequency Range Minimum (Lowest byte)
89)	Frequency Range Maximum ³¹⁴ (Highest byte)
90)	Frequency Range Maximum
91)	Frequency Range Maximum
92)	Frequency Range Maximum (Lowest byte)
93-96)	GPS Position – Latitude (long integer) ³¹⁵
97-100)	GPS Position – Longitude (long integer)
101-102)	GPS Position – Altitude (short integer)
103)	Reserved
104 – 127)	Signal Standard Name, 24 bytes in ASCII
128 – 150)	Not Used
151)	Power Meter Reading ³¹⁶ (Highest byte)
152)	Power Meter Reading
153)	Power Meter Reading
154)	Power Meter Reading (Lowest byte)

³⁰⁸ Value sent as (value in dB * 1000), valid values are 0 to 60 dB

³⁰⁹ Value sent as (value in dBm * 1000)

³¹⁰ Index into Standard List (use control byte #89 to retrieve the ASCII string name). “No Standard” sent as FFFEh

³¹¹ “No Channel” is sent as FFFEh

³¹² In number of Hz

³¹³ Scaled by Frequency Scale Factor

³¹⁴ Scaled by Frequency Scale Factor

³¹⁵ Signed long integer is used to represent latitude and longitude. Positive latitude means North hemisphere, negative latitude means South hemisphere; Positive longitude means East hemisphere, negative longitude means West hemisphere. Degree = int(abs(value)/1,000,000); Minute = (float)(abs(value)%1,000,000)/10,000

³¹⁶ Power sent as (power in dBm * 1000). Use two’s-complement method to decode negative power levels.

155) Measure Offset Status (00h = Off, 01h = On)

For T1/E1 Modes (Option 50):

- 44) Receive Input (00h: Terminate, 01h: Bridged, 02h: Monitor)
- 45) Framing Mode³¹⁷
- 46) Line Coding (01h: B8ZS, 02h: AMI, 03h: HDB3)
- 47) Tx Level (Valid for T1 Only) (01h: 0 dB, 02h: -7.5 dB, 03h: -15 dB)
- 48) Clock Source (00h: External, 01h: Internal)
- 49) Error Insert Type (00h: Frame Error, 01h: BPV, 02h: Bit Errors, 04h: RAI, 05h: AIS)
- 50) Loop Code (Valid for T1 Only) (00h: CSU, 01h: NIU, 02h: User 1, 03h: User 2)
- 51) Loop Type (Valid for T1 Only) (00h: In Band, 01h: Data Link)
- 52) CRC Method (Valid for T1 Only) (00h: ANSI CRC, 01h: Japanese CRC)
- 53) Display Type (00h: Histogram, 01h: Raw Data)
- 54) Impedance (Valid for E1 Only) (01h: 75 Ω, 02h: 120 Ω)
- 55) Pattern³¹⁸
- 56) Pattern Invert Status (00h: Non-Inverted, 01h: Inverted)
- 57) Insert Bit Error Value (1-1000) (Higher byte)
- 58) Insert Bit Error Value (Lower byte)
- 59) Insert BPV Error Value (1-1000) (Higher byte)
- 60) Insert BPV Error Value (Lower byte)
- 61) Insert Frame Error Value (1-1000) (Higher byte)
- 62) Insert Frame Error Value (Lower byte)
- 63) Measurement Duration³¹⁹
- 64) Histogram Resolution³²⁰
- 65) Frame Sync Status (00h: In Sync, 01h: Out-of-Sync)
- 66) Pattern Sync Status (00h: In Sync, 01h: Out-of-Sync)
- 67) Carrier Status (00h: In Sync, 01h: Out-of-Sync)
- 68) Rx Alarms (bit 0: Receiving AIS, bit 1: Receiving RAI, bit 2: Receiving E1 MMF error)
- 69) BPV Error Count (Highest byte)
- 70) BPV Error Count
- 71) BPV Error Count
- 72) BPV Error Count (Lowest byte)
- 73) CRC Error Count (Highest byte)
- 74) CRC Error Count
- 75) CRC Error Count
- 76) CRC Error Count (Lowest byte)
- 77) Frame Error Count (Highest byte)
- 78) Frame Error Count
- 79) Frame Error Count
- 80) Frame Error Count (Lowest byte)
- 81) LOF Error Count (Highest byte)
- 82) LOF Error Count
- 83) LOF Error Count
- 84) LOF Error Count (Lowest byte)
- 85) E Bit Error Count (E1 Only) (Highest byte)
- 86) E Bit Error Count (E1 Only)

³¹⁷ T1 Mode: 01h: ESF, 02h: D4SF

E1 Mode: 03h: PCM30, 04h: PCM30CRC, 05h: PCM31, 06h: PCM31CRC

³¹⁸ Pattern: 01h: PRBS-9, 02h: PRBS-11, 03h: PRBS-15, 04h: PRBS-20(O.151), 05h: PRBS-20(O.153), 06h: PRBS-23, 07h: QRSS, 08h: 1 in 8, 09h: 2 in 8, 0Ah: 3 in 8, 0Bh: All Ones, 0Ch: All Zeros, 0Dh: T1-DALY, 0Eh: User Defined

³¹⁹ Measurement Duration: 00h: Manual, 01h: 3 min, 02h: 15 min, 03h: 30 min, 04h: 1 hr, 05h: 3 hrs, 06h: 6 hrs, 07h: 12 hrs, 08h: 1 day, 09h: 2 days

³²⁰ Histogram Resolution: 00h: Auto, 01h: 1 sec, 02h: 15 sec, 03h: 30 sec, 04h: 45 sec, 05h: 1 min, 06h: 15 min, 07h: 30 min, 08h: 45 min, 09h: 60 min

- 87) E Bit Error Count (E1 Only)
- 88) E Bit Error Count (E1 Only) (Lowest byte)
- 89) Errored Seconds (Highest byte)
- 90) Errored Seconds
- 91) Errored Seconds
- 92) Errored Seconds (Lowest byte)
- 93) Bit Count (Highest byte)
- 94) Bit Count
- 95) Bit Count
- 96) Bit Count (Lowest byte)
- 97) Bit Errors (Highest byte)
- 98) Bit Errors
- 99) Bit Errors
- 100) Bit Errors (Lowest byte)
- 101) User Defined Pattern (convert to binary for pattern) (Highest byte)
- 102) User Defined Pattern
- 103) User Defined Pattern
- 104) User Defined Pattern (Lowest byte)
- 105 – 112) Measurement Start Time String (ASCII string: “HH:MM:SS”)
- 113 – 123) Measurement Stop Time String (ASCII string: “DD:HH:MM:SS”)
- 124 – 134) Elapsed Time String (ASCII string: “DD:HH:MM:SS”)
- 135 – 142) Bit Error Rate String (ASCII string in engineering format: x.xxE-xx)
- 143 – 642) 100 data points with 5 bytes for each data point.

1st byte has information about Carrier Loss, Frame Loss, BPV and CRC
 Following 4 bytes corresponds to the Bit Error Count

Break down of the 1st byte :

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Not Used	Not Used	Not Used	Carrier Loss	Frame Loss	BPV Error	CRC / E- Bit Error	Any Error

- 643) Vpp or dBdsx (Higher byte)
- 644) Vpp or dBdsx (Lower byte)
- 645) T1 or E1 Receive Frequency in Hz (Highest byte)
- 646) T1 or E1 Receive Frequency in Hz
- 647) T1 or E1 Receive Frequency in Hz
- 648) T1 or E1 Receive Frequency in Hz (Lowest byte)
- 649 – 750) Not Used

For Channel Scanner Mode:

- 44) Reference Level (Highest Byte)
- 45) Reference Level
- 46) Reference Level
- 47) Reference Level (Lowest Byte)
- 48) Scale Division (Highest Byte)
- 49) Scale Division
- 50) Scale Division
- 51) Scale Division (Lowest Byte)
- 52) Start Frequency (Highest Byte)
- 53) Start Frequency
- 54) Start Frequency
- 55) Start Frequency (Lowest Byte)
- 56) Span Frequency (Highest Byte)
- 57) Span Frequency
- 58) Span Frequency
- 59) Span Frequency (Lowest Byte)
- 60) Channel Step (Highest Byte)

61)	Channel Step (Lowest Byte)
62)	Channel Frequency Step (Highest Byte)
63)	Channel Frequency Step
64)	Channel Frequency Step
65)	Channel Frequency Step (Lowest Byte)
66)	Number of Channels Displayed
67)	External Reference Frequency ³²¹
68)	Display Type Channels or Frequencies ³²²
69)	Display Type Graph or Text ³²³
70)	Signal Standard (Highest Byte)
71)	Signal Standard (Lowest Byte)
72-75)	GPS Position – Latitude (long integer) ³²⁴
76-79)	GPS Position – Longitude (long integer)
80-81)	GPS Position – Altitude (short integer)
82)	Start Channel (Highest Byte)
83)	Start Channel
84)	Start Channel
85)	Start Channel (Lowest Byte)
86 – 109)	Signal Standard Name, 24bytes in ASCII
110 – 137)	Reserved
138 – 257)	Channel Scanner Data ³²⁵

For Interference Analyzer RSSI Mode

44)	Center Frequency (Highest Byte)
45)	Center Frequency
46)	Center Frequency
47)	Center Frequency (Lowest Byte)
48)	Reference Level (Highest Byte)
49)	Reference Level
50)	Reference Level
51)	Reference Level (Lowest Byte)
52)	Scale (Highest Byte)
53)	Scale
54)	Scale
55)	Scale (Lowest Byte)
56)	RBW (Highest Byte)
57)	RBW
58)	RBW
59)	RBW (Lowest Byte)
60)	VBW (Highest Byte)
61)	VBW
62)	VBW
63)	VBW (Lowest Byte)
64)	Status Byte 1
	Bit 0 - Detection Algorithm (Lowest Bit) ³²⁶
	Bit 1 - Detection Algorithm

³²¹ Frequency in MHz, OFF if 0

³²² 0 – Channel, 1 - Frequency

³²³ 0 – Graph, 1 - Text

³²⁴ Signed long integer is used to represent latitude and longitude. Positive latitude means North hemisphere, negative latitude means South hemisphere; Positive longitude means East hemisphere, negative longitude means West hemisphere. Degree = int(abs(value)/1,000,000); Minute = (float)(abs(value)%1,000,000)/10,000

³²⁵ 20 points, 6 bytes per point. First 2 bytes are channel numbers(Invalid channels sent as 0xFFFF) and 4 bytes are values. Value sent as (value in dBm) * 1000 + 270,000

³²⁶ 000 - Positive Peak, 010 – RMS Averaging, 100 – Negative Peak, 110 – Sampling Mode

	Bit 2 - Detection Algorithm (Highest Bit)
	Bit 3 - Not Used
	Bit 4 - Not Used
	Bit 5 - Not Used
	Bit 6 - Not Used
65)	Reference Level Offset (Highest Byte)
66)	Reference Level Offset
67)	Reference Level Offset
68)	Reference Level Offset (Lowest Byte)
69)	External Reference Frequency ³²⁷
70)	Signal Standard (Highest Byte)
71)	Signal Standard (Lowest Byte)
72)	Channel (Highest Byte) ³²⁸
73)	Channel (Lowest Byte)
74)	Min RSSI Measured (Highest Byte)
75)	Min RSSI Measured
76)	Min RSSI Measured
77)	Min RSSI Measured (Lowest Byte)
78)	Max RSSI Measured (Highest Byte)
79)	Max RSSI Measured
80)	Max RSSI Measured
81)	Max RSSI Measured (Lowest Byte)
82)	Measure Duration (Highest Byte) ³²⁹
83)	Measure Duration
84)	Measure Duration
85)	Measure Duration (Lowest Byte)
86)	Sweep Point Interval(Highest Byte) ³³⁰
87)	Sweep Point Interval
88)	Sweep Point Interval
89)	Sweep Point Interval (Lowest Byte)
90 - 93)	GPS Position – Latitude (long integer) ³³¹
94 - 97)	GPS Position – Longitude (long integer)
98 - 99)	GPS Position – Altitude (short integer)
100)	Signal Standard
101-104)	Start GPS Position – Latitude (long integer) ³³²
105-108)	Start GPS Position – Longitude (long integer)
109-110)	Start GPS Position – Altitude (short integer)
111)	Attenuation (Highest Byte) ³³³
112)	Attenuation
113)	Attenuation
114)	Attenuation (Lowest Byte)
115– 138)	Signal Standard Name, 24bytes in ASCII
139)	Measure Offset Status (0h = Off, 1h = On)
140– 194)	Reserved

³²⁷ Frequency in MHz, OFF if 0

³²⁸ Invalid channels are sent as 0xFFFF

³²⁹ Measure Duration time in minutes

³³⁰ Sweep Point Interval time in milliseconds

³³¹ Signed long integer is used to represent latitude and longitude. Positive latitude means North hemisphere, negative latitude means South hemisphere; Positive longitude means East hemisphere, negative longitude means West hemisphere. Degree = $\text{int}(\text{abs}(\text{value})/1,000,000)$; Minute = $(\text{float})(\text{abs}(\text{value})\%1,000,000)/10,000$

³³² Signed long integer is used to represent latitude and longitude. Positive latitude means North hemisphere, negative latitude means South hemisphere; Positive longitude means East hemisphere, negative longitude means West hemisphere. Degree = $\text{int}(\text{abs}(\text{value})/1,000,000)$; Minute = $(\text{float})(\text{abs}(\text{value})\%1,000,000)/10,000$

³³³ Attenuation is sent as (Att in dB * 1000)

195 – 3402) RSSI Sweep data³³⁴

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
- 224 (E0h) Parameter Error: Not enough bytes transferred
- 225 (E1h) Memory Error: Not enough memory to store data
- 238 (EEh) Time-out Error

Get Options – Control Byte #37 (25h)

Description: Queries the option(s) installed on the Site Master, returns a list as an ASCII string.

Bytes to Follow: 0 bytes

Site Master Returns: Number of bytes depends on the option(s) installed

- Option 2: "2/"
- Option 3: "3/"
- Option 5: "5/"
- Option 6: "6/"
- Option 10: "10/"
- Option 16: "16/"
- Option 19: "19/"
- Option 21: "21/"
- Option 25: "25/"
- Option 27: "27/"
- Option 29: "29/"
- Option 50: "50/"
- If NO options are installed: "None"

Query Power Level – Control Byte #39 (27h)

This command is available with Option 29 and/or Option 5.

Description: Return Power Level at the RF In port. Also returns power meter settings.

Bytes to Follow: 0 bytes

Site Master Returns: 30 bytes

- 1) Status Byte # 1 (0b = Off, 1b = On)
 - (LSB) bit 0 : Unit (0b - Watt/%, 1b - dBm/dBr)
 - bit 2 : Relative Mode On/Off
 - bit 3: Offset Mode On/Off
 - bit 4: Zero Mode On/Off
 - bits 5-7: Not Used
- 2) RMS Averaging Status³³⁵
- 3 - 6) Relative Mode Reference Power Level in dBm
- 7 - 10) Offset Mode Power Level
- 11 - 14) Zero Mode Power Level

³³⁴ Sweep Data contains 401 display points, 8 bytes per display point. The first 4 bytes are the amplitude, the next 2 bytes are the latitude increments from the start GPS position and the following 2 bytes are the longitude increments from the Start GPS position.

³³⁵ RMS Averaging – 00h = Off, 01h = Low, 02h = Medium, 03h = High

- 15 - 18) Absolute Power Level
- 19 - 22) Power
- 23 - 26) Center Frequency
- 27 - 30) Span Frequency

Notes:

Power is returned as (dBm * 1000)

Relative power is returned as (dB * 1000)

Offset is returned as (dB * 1000)

Frequencies are scaled by the frequency scale factor.

Set Power Meter Units – Control Byte #40 (28h)

This command is available with Option 29 and/or Option 5.

Description: Set Power Meter units to watts or dBm.

Bytes to Follow: 1 byte

- 1) Units
 - 00h = Watt (% if in relative mode)
 - 01h = dBm (dB if in relative mode)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
- 224 (E0h) Parameter Error: Invalid Units
- 238 (EEh) Time-out Error

Power Meter Relative Mode On/Off – Control Byte #41 (29h)

This command is available with Option 29 and/or Option 5.

Description: Enable or disable Power Meter Relative Mode.

Bytes to Follow: 1 byte

- 1) Relative Mode State
 - 00h = Off
 - 01h = On w/ trigger (use the current power level as a reference power level)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
- 224 (E0h) Parameter Error: Invalid parameter
- 238 (EEh) Time-out Error

Power Meter Offset Mode On/Off – Control Byte #42 (2Ah)

This command is available with Option 29 and/or Option 5.

Description: Enable or disable Power Meter Offset Mode.

Bytes to Follow: 5 bytes

- 1) On/Off (01h = On, 00h = Off)
- 2 - 5) Offset Power level in dB (Multiplied by 1000)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
- 224 (E0h) Parameter Error: Invalid parameter
- 238 (EEh) Time-out Error

Note:

If you turn the Offset mode off, you must still send the other bytes. Bytes 2 - 5 will be ignored.

Power Meter Zero Mode On/Off – Control Byte #43 (2Bh)

This command is available with Option 29 and/or Option 5.

Description: Enable or disable Power Meter Zeroing Mode.

Bytes to Follow: 1 byte

- 1) Zero Mode Status
 - 00h = Off
 - 01h = On with trigger (current power level is referenced as -80 dBm)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error: Invalid status
 - 238 (EEh) Time-out Error
-

Power Meter RMS Averaging On/Off – Control Byte #44 (2Ch)

This command is available with Option 29 only.

Description: Disable/enable Power Meter RMS Averaging. Enabling can be set to 3 different levels.

Bytes to Follow: 1 byte

- 1) RMS Averaging State
 - 00h = Off
 - 01h = On (Low) with trigger (current power level is referenced as -80 dBm)
 - 02h = On (Medium)
 - 03h = On (High)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error: Invalid state
 - 238 (EEh) Time-out Error
-

Power Meter Center Frequency and Span Setup – Control Byte #45 (2Dh)

This command is available with Option 29 only.

Description: Sets the center frequency and span frequency for the Power Meter mode.

If option 6 is installed and the frequency converter module is attached, the frequencies should be scaled by the scale factor of the module. If the module is not attached, the frequencies are sent in Hz. Use Control Word A203 to determine whether a module is attached and the appropriate scale factor.

Bytes to Follow: 8 bytes

- 1) Center Frequency (Highest byte)
- 2) Center Frequency
- 3) Center Frequency

- 4) Center Frequency (Lowest byte)
- 5) Span (Highest byte)
- 6) Span
- 7) Span
- 8) Span (Lowest byte)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
- 224 (E0h) Parameter Error: Invalid frequency range
- 238 (EEh) Time-out Error

Trigger Sweep – Control Byte #48 (30h)

Description: Causes the Site Master to perform a sweep if it is in single sweep mode.

This command works only when the Site Master is NOT in remote mode. Send this command, then wait for the "Sweep Complete Byte" to signify the end of the sweep.

Note: The "Sweep Complete Byte" is not returned unless serial echo status is turned on using command #10.

Bytes to Follow: 0 bytes

Site Master Returns: 1 byte

- 1) 192 (C0h) Sweep Complete Byte (at the end of the sweep)

Trigger Sweep – Control Word (AA30h)

Description: Causes the Site Master to perform a sweep if it is in single sweep mode.

This command works only when the Site Master is NOT in remote mode. Send this command, receive the "Operation Complete Byte" and then wait for the "Sweep Complete Byte" to signify the end of the sweep.

Note: The "Sweep Complete Byte" is not returned unless serial echo status is turned on using command #10.

Bytes to Follow: 0 bytes

Site Master Returns: 2 bytes

- 1) 255 (FFh) Operation Complete Byte (when the command is received)
- 2) 192 (C0h) Sweep Complete Byte (at the end of the sweep)

Sweep Data Echo On/Off – Control Byte #49 (31h)

Description: Sets the sweep data echo mode On/Off.

Sweep Data Echo Mode behaves much like the Serial Port Echo Mode (see Control Byte #10). It automatically puts the unit into single sweep mode. At the end of each sweep cycle, the Site Master sends a Sweep Complete Byte #192 (C0h) to the serial port. At this time, sweep data can be queried (see Control Byte #33) without having to enter remote mode first or exit remote mode when done. Depending on the value of the second following byte, the next sweep can be automatically triggered after the sweep data has been sent.

This mode activates once the Site Master exits from the remote mode. Sweep Data Echo status can't be saved to or recalled from saved setups. Cycling power resets the Sweep Data Echo status to Off.

The Sweep Data Echo Mode allows run-time handshaking between the Site Master and computer by doing the following:

- 1) Enter remote mode. Set Sweep Data Echo Mode On. Exit remote mode.
- 2) The Site Master sweeps once and then sends the Sweep Complete Byte.
- 3) After you receive it: Recall sweep 0 (last sweep trace in RAM).
- 4) If using auto triggering, repeat steps 2-3. If using manual triggering, go to step 5.
- 5) Send Sweep Triggering Byte #48 (30h) and wait for the next sweep cycle.
- 6) Repeat steps 2-5.

Note: To execute commands other than #33, you must use the traditional Enter Remote, Send Commands, Exit Remote communication sequence.

Bytes to Follow: 2 bytes

- 1) Sweep Data Echo Status
 - 00h : Off
 - 01h : On
- 2) Next Sweep Trigger
 - 00h : Manual
 - 01h : Automatic

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
- 224 (E0h) Parameter Error : Invalid sweep data echo status
- 238 (EEh) Time-out Error

Check Battery Status – Control Byte #50 (32h)

Description: Return Smart Battery status.

Bytes to Follow: 0 bytes

Site Master Returns: 17 bytes

- 1-2) Battery Status flags (Refer to Smart Battery Data Spec 5.1.2.1)
- 3-4) State of Charge (unsigned integer 0 to 100(%)Full)
- 5-6) Battery Voltage (unsigned integer 0 to 65535 in mV)
- 7-8) Battery Current (signed integer -32,768 to +32,7687 mA, positive = Charging)
- 9-10) Battery Average current (signed integer -32,768 to +32,7687 mA, positive = Charging)
- 11-12) Average time to empty (unsigned integer 0 to 65535 minute)
- 13-14) Battery Charge Cycle Count (unsigned integer 0 to 65535 cycles)
- 15-16) Battery Capacity at Full Charge in mA Hours (unsigned integer 0 to 65535 cycles)
- 17) Unit under battery power (1 = YES; 0 = NO)

Note:

The Smart Battery Data Spec can be found at <http://www.sbs-forum.org/specs/index.html>

Set SPA Minimum Sweep Time – Control Byte #53 (35h)

Description: Sets the minimum sweep time (in μ s) for the spectrum analyzer when the span is 0.

Valid range is 50 to 200,000,000.

Bytes to Follow: 4 bytes

- 1) Minimum Sweep Time (in μ s) (Highest byte)
- 2) Minimum Sweep Time (in μ s)
- 3) Minimum Sweep Time (in μ s)
- 4) Minimum Sweep Time (in μ s) (Lowest byte)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error: Invalid sweep time
 - 238 (EEh) Time-out Error
-

Set Trigger Position – Control Byte #54 (36h)

Description: Sets the trigger position (in percent) for the spectrum analyzer when the span is 0.

Bytes to Follow: 1 byte

- 1) Trigger Position (0 – 100%)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error: Invalid trigger position
 - 238 (EEh) Time-out Error
-

Set Video Trigger Level – Control Byte #55 (37h)

Description: Sets the trigger level (-120 - +20 dBm) for the spectrum analyzer when the span is 0 and trigger mode is video.

The trigger level should be sent as (value in dBm * 1000) + 120,000.

Bytes to Follow: 4 bytes

- 1) Trigger Level (Highest byte)
- 2) Trigger Level
- 3) Trigger Level
- 4) Trigger Level (Lowest byte)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error: Invalid trigger level
 - 238 (EEh) Time-out Error
-

Automatically Save Runtime Setup – Control Byte #64 (40h)

Description: Automatically save the runtime setup when exiting remote mode.

This flag must be set once per power cycle of the Site Master. It returns to its default value when the unit is turned off. The default value is (0), DO NOT automatically save the runtime setup.

Bytes to Follow: 1 byte

- 1) Save runtime setup On/Off
00h = Off (default)
01h = On

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
 - 238 (EEh) Time Out Error
-

Download Saved Setup – Control Byte #65 (41h)

Description: Returns parameters associated with the specified setup number. Since different modes have different numbers of setup locations available, the command requires the mode be specified as well as the setup number.

Bytes to Follow: 2 bytes

- 1) Measurement Mode³³⁶
- 2) Setup Number
 - 0 = Run time setup
 - 1 – 10 = Saved setups for Spectrum Analyzer/Transmission Measurement modes
 - 1 – 5 = Saved setups for Power Meter mode (Option 29 Only)
 - 255 = Default setup

Site Master Returns:

For All Modes:

- 1) Number of Following Bytes (Higher byte)
- 2) Number of Following Bytes (Lower byte)
- 3) Measurement Mode³³⁷
- 5-20) Not Used

For Site Master VNA Modes:

- 21) Number of Data Points (Higher byte)
- 22) Number of Data Points (Lower byte)
- 23) VNA Start Frequency³³⁸ (Highest byte)
- 24) VNA Start Frequency
- 25) VNA Start Frequency
- 26) VNA Start Frequency (Lowest byte)
- 27) VNA Stop Frequency³³⁹ (Highest byte)
- 28) VNA Stop Frequency
- 29) VNA Stop Frequency
- 30) VNA Stop Frequency (Lowest byte)
- 31) Return Loss Scale Start (Higher byte)³⁴⁰
- 32) Return Loss Scale Start (Lower byte)
- 33) Return Loss Scale Stop (Higher byte)
- 34) Return Loss Scale Stop (Lower byte)
- 35) SWR Scale Start (Higher byte)³⁴¹
- 36) SWR Scale Start (Lower byte)
- 37) SWR Scale Stop (Higher byte)
- 38) SWR Scale Stop (Lower byte)
- 39) Cable Loss Scale Start (Higher byte)³⁴²
- 40) Cable Loss Scale Start (Lower byte)
- 41) Cable Loss Scale Stop (Higher byte)
- 42) Cable Loss Scale Stop (Lower byte)
- 43) DTF-RL Scale Start (Higher byte)³⁴³
- 44) DTF-RL Scale Start (Lower byte)
- 45) DTF-RL Scale Stop (Higher byte)
- 46) DTF-RL Scale Stop (Lower byte)

³³⁶ Refer to Control Byte #3 “Select Measurement Mode” for valid measurement modes.

³³⁷ Refer to Control Byte #3 “Select Measurement Mode” for valid measurement modes.

³³⁸ Frequency is scaled by the frequency scale factor specified in bytes 465-466.

³³⁹ Frequency is scaled by the frequency scale factor specified in bytes 465-466.

³⁴⁰ See “Set Site Master VNA Scale” Control Byte #4 for data format.

³⁴¹ See “Set Site Master VNA Scale” Control Byte #4 for data format.

³⁴² See “Set Site Master VNA Scale” Control Byte #4 for data format.

³⁴³ See “Set Site Master VNA Scale” Control Byte #4 for data format.

- 47) DTF-SWR Scale Start (Higher byte)³⁴⁴
- 48) DTF-SWR Scale Start (Lower byte)
- 49) DTF-SWR Scale Stop (Higher byte)
- 50) DTF-SWR Scale Stop (Lower byte)
- 51) VNA Frequency Marker 1 (Higher byte)³⁴⁵
- 52) VNA Frequency Marker 1 (Lower byte)
- 53) VNA Frequency Marker 2 (Higher byte)
- 54) VNA Frequency Marker 2 (Lower byte)
- 55) VNA Frequency Marker 3 (Higher byte)
- 56) VNA Frequency Marker 3 (Lower byte)
- 57) VNA Frequency Marker 4 (Higher byte)
- 58) VNA Frequency Marker 4 (Lower byte)
- 59) VNA Frequency Marker 5 (Higher byte)
- 60) VNA Frequency Marker 5 (Lower byte)
- 61) VNA Frequency Marker 6 (Higher byte)
- 62) VNA Frequency Marker 6 (Lower byte)
- 63) Return Loss Single Limit (Higher byte)³⁴⁶
- 64) Return Loss Single Limit (Lower byte)
- 65) SWR Single Limit (Higher byte)³⁴⁷
- 66) SWR Single Limit (Lower byte)
- 67) Cable Loss Single Limit (Higher byte)³⁴⁸
- 68) Cable Loss Single Limit (Lower byte)
- 69) DTF-RL Single Limit (Higher byte)³⁴⁹
- 70) DTF-RL Single Limit (Lower byte)
- 71) DTF-SWR Single Limit (Higher byte)³⁵⁰
- 72) DTF-SWR Single Limit (Lower byte)
- 73) Return Loss Multiple Limit Segment # (1)
- 74) Return Loss Multiple Limit Segment Status (00h = Off, 01h = On)
- 75) Return Loss Multiple Limit Segment Start X (Highest byte)³⁵¹
- 76) Return Loss Multiple Limit Segment Start X
- 77) Return Loss Multiple Limit Segment Start X
- 78) Return Loss Multiple Limit Segment Start X (Lowest byte)
- 79) Return Loss Multiple Limit Segment Start Y (Higher byte)
- 80) Return Loss Multiple Limit Segment Start Y (Lowest byte)
- 81) Return Loss Multiple Limit Segment End X (Highest byte)³⁵²
- 82) Return Loss Multiple Limit Segment End X
- 83) Return Loss Multiple Limit Segment End X
- 84) Return Loss Multiple Limit Segment End X (Lowest byte)
- 85) Return Loss Multiple Limit Segment End Y (Higher byte)
- 86) Return Loss Multiple Limit Segment End Y (Lowest byte)
- 87-142) Repeat bytes 63 – 76 for segments 2 – 5
- 143-212) Repeat bytes 63 – 132 for SWR Multiple Limit
- 213-282) Repeat bytes 63 – 132 for Cable Loss Multiple Limit
- 283-352) Repeat bytes 63 – 132 for DTF-RL Multiple Limit

³⁴⁴ See “Set Site Master VNA Scale” Control Byte #4 for data format.

³⁴⁵ Marker Point = (# data points – 1) * (marker freq – start freq) / (stop freq – start freq)

Where # of data points can be found in bytes 2-3, start freq is in bytes 4-7, and stop freq is in bytes 8-11.

³⁴⁶ See Control Byte #6, “Set Site Master VNA Single Limit” for data format.

³⁴⁷ See Control Byte #6, “Set Site Master VNA Single Limit” for data format.

³⁴⁸ See Control Byte #6, “Set Site Master VNA Single Limit” for data format.

³⁴⁹ See Control Byte #6, “Set Site Master VNA Single Limit” for data format.

³⁵⁰ See Control Byte #6, “Set Site Master VNA Single Limit” for data format.

³⁵¹ See Control Byte #112, “Set Site Master VNA Segmented Limit Lines” for data format. Frequency is scaled by the frequency scale factor specified in bytes 465-466.

³⁵² Frequency is scaled by the frequency scale factor specified in bytes 465-466.

- 353-422) Repeat bytes 63 – 132 for DTF-SWR Multiple Limit
- 423) Start Distance (Highest byte)³⁵³
- 424) Start Distance
- 425) Start Distance
- 426) Start Distance (Lowest byte)
- 427) Stop Distance (Highest byte)
- 428) Stop Distance
- 429) Stop Distance
- 430) Stop Distance (Lowest byte)
- 431) Distance Marker 1 (Higher byte)³⁵⁴
- 432) Distance Marker 1 (Lower byte)
- 433) Distance Marker 2 (Higher byte)
- 434) Distance Marker 2 (Lower byte)
- 435) Distance Marker 3 (Higher byte)
- 436) Distance Marker 3 (Lower byte)
- 437) Distance Marker 4 (Higher byte)
- 438) Distance Marker 4 (Lower byte)
- 439) Distance Marker 5 (Higher byte)
- 440) Distance Marker 5 (Lower byte)
- 441) Distance Marker 6 (Higher byte)
- 442) Distance Marker 6 (Lower byte)
- 443) Relative Propagation Velocity (Highest byte)³⁵⁵
- 444) Relative Propagation Velocity
- 445) Relative Propagation Velocity
- 446) Relative Propagation Velocity (Lowest byte)
- 447) Cable Loss (Highest byte)³⁵⁶
- 448) Cable Loss
- 449) Cable Loss
- 450) Cable Loss (Lowest byte)
- 451) Average Cable Loss³⁵⁷ (Highest byte)
- 452) Average Cable Loss
- 453) Average Cable Loss
- 454) Average Cable Loss (Lowest byte)
- 455) Status Byte 1: (0b = Off , 1b = On)
 (LSB) bit 0 : Site Master Marker 1 On/Off
 bit 1 : Site Master Marker 2 On/Off
 bit 2 : Site Master Marker 3 On/Off
 bit 3 : Site Master Marker 4 On/Off
 bit 4 : Site Master Marker 5 On/Off
 bit 5 : Site Master Marker 6 On/Off
 bits 6- 7 : Not Used
- 456) Status Byte 2: (0b = Off, 1b = On)
 (LSB) bit 0 : Not Used
 bit 1 : Site Master Marker 2 Delta On/Off
 bit 2 : Site Master Marker 3 Delta On/Off
 bit 3 : Site Master Marker 4 Delta On/Off
 bits 4-7: Not Used
- 457) Status Byte 3: (0b = Off , 1b = On)
 (LSB) bit 0 : Site Master Limit Type (0b = Single, 1b = Multiple)

³⁵³ Distance data uses units 1/100,000m or 1/100,000 ft

³⁵⁴ Marker Point = (# data points – 1) * (marker dist – start dist) / (stop dist – start dist)

Where # of data points can be found in bytes 2-3, start dist is in bytes 106-109, and stop dist is in bytes 110-113.

³⁵⁵ Relative Propagation Velocity uses units 1/100,000.

³⁵⁶ Cable loss uses units 1/100,000 dB/m or 1/100,000 dB/ft.

³⁵⁷ Average Cable Loss is dB * 1000.

- bit 1 : Site Master Limit Beep On/Off
- bits 2-6 : Not Used
- bit 7 : Site Master Single Limit Status On/Off
- 458) Status Byte 4:
 - (LSB) bits 0 - 1 : DTF Windowing Mode
 - bit: 1 0
 - | |
 - 0 0 - Rectangular (No Windowing)
 - 0 1 - Nominal Side Lobe
 - 1 0 - Low Side Lobe
 - 1 1 - Minimum Side Lobe
 - bits 2 - 7 : Not Used
- 459) Status Byte 5: (0b = Off, 1b = On)
 - (LSB) bit 0 : Fixed CW Mode On/Off
 - bit 1 : Single Sweep On/Off
 - bit 2 : Trace Overlay On/Off
 - bit 3 : Measurement Unit Metric/English (0b = English, 1b = Metric)
 - bits 4-6: Not Used
 - bit 7 : Cal Mode (0b = OSL Cal, 1b = FlexCal)
- 460) VNA Signal Standard³⁵⁸ (Higher byte)
- 461) VNA Signal Standard (Lower byte)
- 462) Cable Index
- 463) Cable Folder³⁵⁹
- 464) Trace Overlay Index (1-200)
- 465) Frequency Scale Factor³⁶⁰ (Higher byte)
- 466) Frequency Scale Factor (Lower byte)
- 467-550) Not Used

For Spectrum Analyzer Mode:

- 21) Spectrum Analyzer Start Frequency³⁶¹ (Highest byte)
- 22) Spectrum Analyzer Start Frequency
- 23) Spectrum Analyzer Start Frequency
- 24) Spectrum Analyzer Start Frequency (Lowest byte)
- 25) Spectrum Analyzer Stop Frequency³⁶² (Highest byte)
- 26) Spectrum Analyzer Stop Frequency
- 27) Spectrum Analyzer Stop Frequency
- 28) Spectrum Analyzer Stop Frequency (Lowest byte)
- 29) Spectrum Analyzer Center Frequency³⁶³ (Highest byte)
- 30) Spectrum Analyzer Center Frequency
- 31) Spectrum Analyzer Center Frequency
- 32) Spectrum Analyzer Center Frequency (Lowest byte)
- 33) Spectrum Analyzer Frequency Span³⁶⁴ (Highest byte)
- 34) Spectrum Analyzer Frequency Span
- 35) Spectrum Analyzer Frequency Span
- 36) Spectrum Analyzer Frequency Span (Lowest byte)
- 37) Ref Level (Highest byte)³⁶⁵
- 38) Ref Level

³⁵⁸ Index into Standard List (use control byte #89 to retrieve the ASCII string name). "No Standard" sent as FFFEh

³⁵⁹ 00h=Standard at 1000 MHz, 01h=Standard at 2000 MHz, 02h=Standard at 2500 MHz, 03h=Custom

³⁶⁰ Frequency Scale Factor is in number of Hz.

³⁶¹ Scaled by Frequency Scale Factor (bytes 301-302)

³⁶² Scaled by Frequency Scale Factor (bytes 301-302)

³⁶³ Scaled by Frequency Scale Factor (bytes 301-302)

³⁶⁴ Scaled by Frequency Scale Factor (bytes 301-302)

³⁶⁵ Value sent as (value in dBm * 1000) + 270,000)

- 39) Ref Level
- 40) Ref Level (Lowest byte)
- 41) Scale per div (Highest byte)³⁶⁶
- 42) Scale per div
- 43) Scale per div
- 44) Scale per div (Lowest byte)
- 45) Spectrum Analyzer Frequency Marker 1 (Higher byte)³⁶⁷
- 46) Spectrum Analyzer Frequency Marker 1 (Lower byte)
- 47) Spectrum Analyzer Frequency Marker 2 (Higher byte)
- 48) Spectrum Analyzer Frequency Marker 2 (Lower byte)
- 49) Spectrum Analyzer Frequency Marker 3 (Higher byte)
- 50) Spectrum Analyzer Frequency Marker 3 (Lower byte)
- 51) Spectrum Analyzer Frequency Marker 4 (Higher byte)
- 52) Spectrum Analyzer Frequency Marker 4 (Lower byte)
- 53) Spectrum Analyzer Frequency Marker 5 (Higher byte)
- 54) Spectrum Analyzer Frequency Marker 5 (Lower byte)
- 55) Spectrum Analyzer Frequency Marker 6 (Higher byte)
- 56) Spectrum Analyzer Frequency Marker 6 (Lower byte)
- 57) Spectrum Analyzer Single Limit (Highest byte)³⁶⁸
- 58) Spectrum Analyzer Single Limit
- 59) Spectrum Analyzer Single Limit
- 60) Spectrum Analyzer Single Limit (Lowest byte)
- 61) SPA Multiple Upper Limit 1 Start X³⁶⁹ (Highest byte)
- 62) SPA Multiple Upper Limit 1 Start X
- 63) SPA Multiple Upper Limit 1 Start X
- 64) SPA Multiple Upper Limit 1 Start X (Lowest byte)
- 65) SPA Multiple Upper Limit 1 Start Y (Power Level) (Highest byte)³⁷⁰
- 66) SPA Multiple Upper Limit 1 Start Y (Power Level)
- 67) SPA Multiple Upper Limit 1 Start Y (Power Level)
- 68) SPA Multiple Upper Limit 1 Start Y (Power Level) (Lowest byte)
- 69) SPA Multiple Upper Limit 1 End X³⁷¹ (Highest byte)
- 70) SPA Multiple Upper Limit 1 End X
- 71) SPA Multiple Upper Limit 1 End X
- 72) SPA Multiple Upper Limit 1 End X (Lowest byte)
- 73) SPA Multiple Upper Limit 1 End Y (Power Level) (Highest byte)³⁷²
- 74) SPA Multiple Upper Limit 1 End Y (Power Level)
- 75) SPA Multiple Upper Limit 1 End Y (Power Level)
- 76) SPA Multiple Upper Limit 1 End Y (Power Level) (Lowest byte)
- 77-220) SPA Multiple Upper Limits 2-5, SA Multiple Lower Limits 1-5 (see bytes 61-76 for format)
- 221) RBW Setting (Highest byte)³⁷³
- 222) RBW Setting
- 223) RBW Setting
- 224) RBW Setting (Lowest byte)
- 225) VBW Setting (Highest byte)³⁷⁴
- 226) VBW Setting

³⁶⁶ Value sent as (value * 1000)

³⁶⁷ Value sent as data point on the display. Equivalent frequency = (point * span / (# data points – 1)) + start frequency.

³⁶⁸ Value sent as (value in dBm * 1000) + 270000

³⁶⁹ Scaled by Frequency Scale Factor (bytes 301-302)

³⁷⁰ Value sent as (value in dBm * 1000) + 270000

³⁷¹ Scaled by Frequency Scale Factor (bytes 301-302)

³⁷² Value sent as (value in dBm * 1000) + 270000

³⁷³ RBW frequency sent in Hz.

³⁷⁴ VBW frequency sent in Hz.

- 227) VBW Setting
- 228) VBW Setting (Lowest byte)
- 229) OCC BW Method³⁷⁵
- 230) OCC BW % Value³⁷⁶
- 231) OCC BW dBc³⁷⁷
- 232) Attenuation
- 233) Antenna Index (0-14)
- 234-249) Antenna Name (16 bytes in ASCII)
- 250) Status Byte 1: (0b = Off , 1b = On)
- (LSB) bit 0 : Spectrum Analyzer Mode Marker 1 On/Off
bit 1 : Spectrum Analyzer Mode Marker 2 On/Off
bit 2 : Spectrum Analyzer Mode Marker 3 On/Off
bit 3 : Spectrum Analyzer Mode Marker 4 On/Off
bit 4 : Spectrum Analyzer Mode Marker 5 On/Off
bit 5 : Spectrum Analyzer Mode Marker 6 On/Off
bits 6 - 7 : Not Used
- 251) Status Byte 2: (0b = Off, 1b = On)
- (LSB) bit 0 : Not Used
bit 1 : Spectrum Analyzer Mode Marker 2 Delta On/Off
bit 2 : Spectrum Analyzer Mode Marker 3 Delta On/Off
bit 3 : Spectrum Analyzer Mode Marker 4 Delta On/Off
bit 4 : Pre Amp Mode (0b = Manual, 1b = Auto)
bit 5 : Pre Amp Status On/Off
bit 6 : Dynamic Attenuation On/Off
bit 7 : Normalization On/Off
- 252) Status Byte 3: (0b = Off/Beep if data is BELOW line ,
1b = On/Beep if data is ABOVE line)
- (LSB) bit 0 : SPA Limit Type (0b = Single, 1b = Multiple)
bit 1 : SPA Single Limit Beep On/Off
bit 2 : SPA Single Limit Status On/Off
bit 3 : SPA Single Limit Beep Level ABOVE/BELOW
bit 4 : SPA Multiple Limit Upper Segment 1 Status On/Off
bit 5 : SPA Multiple Limit Upper Segment 1 Beep Level ABOVE/BELOW³⁷⁸
bit 6 : SPA Multiple Limit Upper Segment 2 Status On/Off
bit 7 : SPA Multiple Limit Upper Segment 2 Beep Level ABOVE/BELOW
- 253) Status Byte 4: (0b = Off/Beep if data is BELOW line ,
1b = On/Beep if data is ABOVE line)
- (LSB) bit 0 : SPA Multiple Limit Upper Segment 3 Status On/Off
bit 1 : SPA Multiple Limit Upper Segment 3 Beep Level ABOVE/BELOW
bit 2 : SPA Multiple Limit Upper Segment 4 Status On/Off
bit 3 : SPA Multiple Limit Upper Segment 4 Beep Level ABOVE/BELOW
bit 4 : SPA Multiple Limit Upper Segment 5 Status On/Off
bit 5 : SPA Multiple Limit Upper Segment 5 Beep Level ABOVE/BELOW
bit 6 : SPA Multiple Limit Lower Segment 1 Status On/Off
bit 7 : SPA Multiple Limit Lower Segment 1 Beep Level ABOVE/BELOW³⁷⁹
- 254) Status Byte 5: (0b = Off/Beep if data is BELOW line ,
1b = On/Beep if data is ABOVE line)
- (LSB) bit 0 : SPA Multiple Limit Lower Segment 2 Status On/Off
bit 1 : SPA Multiple Limit Lower Segment 2 Beep Level ABOVE/BELOW
bit 2 : SPA Multiple Limit Lower Segment 3 Status On/Off

³⁷⁵ 00h = % of power, 01h = dB down

³⁷⁶ 0 – 99%

³⁷⁷ 0 – 120 dBc

³⁷⁸ Beep level is always 1b for upper segmented limit line

³⁷⁹ Beep level is always 0b for lower segmented limit line

- bit 3 : SPA Multiple Limit Lower Segment 3 Beep Level ABOVE/BELOW
- bit 4 : SPA Multiple Limit Lower Segment 4 Status On/Off
- bit 5 : SPA Multiple Limit Lower Segment 4 Beep Level ABOVE/BELOW
- bit 6 : SPA Multiple Limit Lower Segment 5 Status On/Off
- bit 7 : SPA Multiple Limit Lower Segment 5 Beep Level ABOVE/BELOW
- 255) Status Byte 6: (0b = Off, 1b = On)
 - (LSB) bit 0 : Antenna Factors Correction On/Off
 - bit 1 : Bias Tee On/Off (Option 10)
 - bit 2 : Amplitude Units (Linear) – 00b = Watts 01b = Volts
 - bits 3-4 : Amplitude Units (Log) - 00b = dBm 01b = dBV 10b = dBmV 11b = dBuV
 - bits 5-6 : Detection Alg (00b = pos. peak 01b = RMS Averaging 10b = neg. peak 11b = Sampling Mode)
 - bit 7 : Units Type (0b = Log 1b = Linear)
- 256) Status Byte 7: (0b = Off, 1b = On)
 - (LSB) bit 0: Interference Analysis On/Off
 - bit 1: C/I Measurement On/Off
 - bit 2: RBW Coupling (1b = Auto, 0b = Manual)
 - bit 3: VBW Coupling (1b = Auto, 0b = Manual)
 - bit 4: Attenuation Coupling (1b = Auto, 0b = Manual)
 - bit 5: Channel Power On/Off
 - bit 6: Adjacent Channel Power On/Off
 - bit 7: Occupied BW Measurement On/Off
- 257) Reference Level Offset³⁸⁰ (Highest byte)
- 258) Reference Level Offset
- 259) Reference Level Offset
- 260) Reference Level Offset (Lowest byte)
- 261) External Reference Frequency³⁸¹
- 262) Signal Standard³⁸² (Higher byte)
- 263) Signal Standard (Lower byte)
- 264) Channel Selection³⁸³ (Higher byte)
- 265) Channel Selection (Lower byte)
- 266) Trigger Type³⁸⁴
- 267) Interference Analysis Frequency³⁸⁵ (Highest byte)
- 268) Interference Analysis Frequency
- 269) Interference Analysis Frequency
- 270) Interference Analysis Frequency (Lowest byte)
- 271) Trigger Position (0 – 100%)
- 272) Min Sweep Time (in μ s) (Highest byte)
- 273) Min Sweep Time (in μ s)
- 274) Min Sweep Time (in μ s)
- 275) Min Sweep Time (in μ s) (Lowest byte)
- 276) Video Trigger Level³⁸⁶ (Highest byte)
- 277) Video Trigger Level
- 278) Video Trigger Level
- 279) Video Trigger Level (Lowest byte)
- 280) Status Byte 8
 - (LSB) bit 0: Reserved
 - bits 1-7: Not Used

³⁸⁰ Value sent as (value in dBm * 1000) + 270,000

³⁸¹ 1 byte in MHz (i.e. 20 = 20MHz)

³⁸² Index into Standard List (use control byte #89 to retrieve the ASCII string name). “No Standard” sent as FFFEh

³⁸³ “No Channel” is sent as FFFEh

³⁸⁴ Trigger Type – 00h = Single, 01h = Free Run, 02h = Video, 03h = External

³⁸⁵ Scaled by Frequency Scale Factor (bytes 301-302)

³⁸⁶ Value sent as (value in dBm * 1000) + 270,000

- 281) Status Byte 9
(LSB) bits 0-6: Number of sweeps to average (1-25, 1 implies averaging OFF)
bit 7: Not Used
- 282) Status Byte 10: (0b = Off, 1b = On)
(LSB) bits 0-1: Trace Math Operation (00b = A only, 01b = A-B, 10b = A+B)
bit 2: Max Hold On/Off
bit 3: Min Hold On/Off
bit 4: View B On/Off
bit 5: External Reference Frequency On/Off
bits 6-7: Not Used
- 283) Impedance (00h = 50Ω, 10h = 75Ω Anritsu Adapter, 12h = 75Ω Other Adapter)
- 284) Impedance Loss³⁸⁷ (Higher byte)
- 285) Impedance Loss (Lower byte)
- 286) AM/FM Demod Type³⁸⁸
- 287) AM/FM Demod Status (01h = On, 00h = Off)
- 288) AM/FM Demod Volume (0 to 100)
- 289) AM/FM Demod Frequency³⁸⁹ (Highest byte)
- 290) AM/FM Demod Frequency
- 291) AM/FM Demod Frequency
- 292) AM/FM Demod Frequency (Lowest byte)
- 293) AM/FM Demod Time (in ms) (Highest byte)
- 294) AM/FM Demod Time (in ms)
- 295) AM/FM Demod Time (in ms)
- 296) AM/FM Demod Time (in ms) (Lowest byte)
- 297) SSB BFO Offset³⁹⁰ (Highest byte)
- 298) SSB BFO Offset
- 299) SSB BFO Offset
- 300) SSB BFO Offset (Lowest byte)
- 301) Frequency Scale Factor³⁹¹ (Higher byte)
- 302) Frequency Scale Factor (Lower byte)
- 303) Frequency Range Minimum³⁹² (Highest byte)
- 304) Frequency Range Minimum
- 305) Frequency Range Minimum
- 306) Frequency Range Minimum (Lowest byte)
- 307) Frequency Range Maximum³⁹³ (Highest byte)
- 308) Frequency Range Maximum
- 309) Frequency Range Maximum
- 310) Frequency Range Maximum (Lowest byte)
- 311) Marker Type³⁹⁴
- 312) Channel Power Int BW³⁹⁵ (Highest byte)
- 313) Channel Power Int BW
- 314) Channel Power Int BW
- 315) Channel Power Int BW (Lowest byte)
- 316) ACPR Main Channel BW³⁹⁶ (Highest byte)

³⁸⁷ Value sent as (value in dB * 1000), valid values are 0 to 20 dB

³⁸⁸ AM/FM Demod Type: 00h = FM-Wide Band, 01h = FM-Narrow Band, 02h = AM, 03h = SSB Lower, 04h = SSB Upper

³⁸⁹ Scaled by Frequency Scale Factor (bytes 301-302)

³⁹⁰ Value sent as ((value in Hz) – 10,000)

³⁹¹ In number of Hz

³⁹² Scaled by Frequency Scale Factor (bytes 301-302)

³⁹³ Scaled by Frequency Scale Factor (bytes 301-302)

³⁹⁴ 00h = Regular Marker, 01h = Noise Marker

³⁹⁵ Scaled by Frequency Scale Factor (bytes 301-302)

³⁹⁶ Scaled by Frequency Scale Factor (bytes 301-302)

- 317) ACPR Main Channel BW
- 318) ACPR Main Channel BW
- 319) ACPR Main Channel BW (Lowest byte)
- 320) ACPR Adjacent Channel BW³⁹⁷ (Highest byte)
- 321) ACPR Adjacent Channel BW
- 322) ACPR Adjacent Channel BW
- 323) ACPR Adjacent Channel BW (Lowest byte)
- 324) ACPR Channel Spacing³⁹⁸ (Highest byte)
- 325) ACPR Channel Spacing
- 326) ACPR Channel Spacing
- 327) ACPR Channel Spacing (Lowest byte)
- 328) Interference Analysis Cell Std³⁹⁹
- 329) Interference Analysis Est. BW⁴⁰⁰ (Highest byte)
- 330) Interference Analysis Est. BW
- 331) Interference Analysis Est. BW
- 332) Interference Analysis Est. BW (Lowest byte)
- 333) Trace B Trace Id⁴⁰¹
- 334-500) Not Used

For Transmission Mode (Option 21):

- 21) Start Frequency⁴⁰² (Highest byte)
- 22) Start Frequency
- 23) Start Frequency
- 24) Start Frequency (Lowest byte)
- 25) Stop Frequency⁴⁰³ (Highest byte)
- 26) Stop Frequency
- 27) Stop Frequency
- 28) Stop Frequency (Lowest byte)
- 29) Center Frequency⁴⁰⁴ (Highest byte)
- 30) Center Frequency
- 31) Center Frequency
- 32) Center Frequency (Lowest byte)
- 33) Frequency Span⁴⁰⁵ (Highest byte)
- 34) Frequency Span
- 35) Frequency Span
- 36) Frequency Span (Lowest byte)
- 37) Ref Level (Highest byte)⁴⁰⁶
- 38) Ref Level
- 39) Ref Level
- 40) Ref Level (Lowest byte)
- 41) Scale per div (Highest byte)⁴⁰⁷
- 42) Scale per div
- 43) Scale per div

³⁹⁷ Scaled by Frequency Scale Factor (bytes 301-302)

³⁹⁸ Scaled by Frequency Scale Factor (bytes 301-302)

³⁹⁹ 4 Standards – 00h = 1250 kHz CDMA, 01h = GSM, 02h = TDMA, 03h = AMPS, 04h = Unknown, FFh = Interference Analysis Measurement OFF

⁴⁰⁰ Frequency in Hz

⁴⁰¹ FFh indicates no trace selected

⁴⁰² Scaled by Frequency Scale Factor (bytes 244-245)

⁴⁰³ Scaled by Frequency Scale Factor (bytes 244-245)

⁴⁰⁴ Scaled by Frequency Scale Factor (bytes 244-245)

⁴⁰⁵ Scaled by Frequency Scale Factor (bytes 244-245)

⁴⁰⁶ Value sent as (value in dBm * 1000) + 270,000

⁴⁰⁷ Value sent as (value * 1000)

- 44) Scale per div (Lowest byte)
- 45) Frequency Marker 1 (Higher byte)⁴⁰⁸
- 46) Frequency Marker 1 (Lower byte)
- 47) Frequency Marker 2 (Higher byte)
- 48) Frequency Marker 2 (Lower byte)
- 49) Frequency Marker 3 (Higher byte)
- 50) Frequency Marker 3 (Lower byte)
- 51) Frequency Marker 4 (Higher byte)
- 52) Frequency Marker 4 (Lower byte)
- 53) Frequency Marker 5 (Higher byte)
- 54) Frequency Marker 5 (Lower byte)
- 55) Frequency Marker 6 (Higher byte)
- 56) Frequency Marker 6 (Lower byte)
- 57) Single Limit (Highest byte)⁴⁰⁹
- 58) Single Limit
- 59) Single Limit
- 60) Single Limit (Lowest byte)
- 61) Multiple Upper Limit 1 Start X⁴¹⁰ (Highest byte)
- 62) Multiple Upper Limit 1 Start X
- 63) Multiple Upper Limit 1 Start X
- 64) Multiple Upper Limit 1 Start X (Lowest byte)
- 65) Multiple Upper Limit 1 Start Y (Power Level) (Highest byte)⁴¹¹
- 66) Multiple Upper Limit 1 Start Y (Power Level)
- 67) Multiple Upper Limit 1 Start Y (Power Level)
- 68) Multiple Upper Limit 1 Start Y (Power Level) (Lowest byte)
- 69) Multiple Upper Limit 1 End X⁴¹² (Highest byte)
- 70) Multiple Upper Limit 1 End X
- 71) Multiple Upper Limit 1 End X
- 72) Multiple Upper Limit 1 End X (Lowest byte)
- 73) Multiple Upper Limit 1 End Y (Power Level) (Highest byte)⁴¹³
- 74) Multiple Upper Limit 1 End Y (Power Level)
- 75) Multiple Upper Limit 1 End Y (Power Level)
- 76) Multiple Upper Limit 1 End Y (Power Level) (Lowest byte)
- 77-220) Multiple Upper Limits 2-5, SA Multiple Lower Limits 1-5 (see bytes 61-76 for format)
- 221) RBW Setting (Highest byte)⁴¹⁴
- 222) RBW Setting
- 223) RBW Setting
- 224) RBW Setting (Lowest byte)
- 225) VBW Setting (Highest byte)⁴¹⁵
- 226) VBW Setting
- 227) VBW Setting
- 228) VBW Setting (Lowest byte)
- 229) Attenuation
- 230) Status Byte 1: (0b = Off , 1b = On)
 (LSB) bit 0 : Marker 1 On/Off
 bit 1 : Marker 2 On/Off

⁴⁰⁸ Value sent as data point on the display. Equivalent frequency = (point * span / (# data points – 1)) + start frequency.

⁴⁰⁹ Value sent as (value in dBm * 1000) + 270000

⁴¹⁰ Scaled by Frequency Scale Factor (bytes 244-245)

⁴¹¹ Value sent as (value in dBm * 1000) + 270000

⁴¹² Scaled by Frequency Scale Factor (bytes 244-245)

⁴¹³ Value sent as (value in dBm * 1000) + 270000

⁴¹⁴ RBW frequency sent in Hz.

⁴¹⁵ VBW frequency sent in Hz.

- bit 2 : Marker 3 On/Off
bit 3 : Marker 4 On/Off
bit 4 : Marker 5 On/Off
bit 5 : Marker 6 On/Off
bits 6 - 7 : Not Used
- 231) Status Byte 2: (0b = Off, 1b = On)
(LSB) bit 0 : S21 Spa Cal Status (0 – Cal OFF, 1 – Cal ON)
bit 1 : Marker 2 Delta On/Off
bit 2 : Marker 3 Delta On/Off
bit 3 : Marker 4 Delta On/Off
bit 4 : Pre Amp Mode (0b = Manual, 1b = Auto)
bit 5 : Pre Amp Status On/Off
bit 6 : Dynamic Attenuation On/Off
bit 7 : Not Used
- 232) Status Byte 3: (0b = Off/Beep if data is BELOW line ,
1b = On/Beep if data is ABOVE line)
(LSB) bit 0 : Limit Type (0b = Single, 1b = Multiple)
bit 1 : Single Limit Beep On/Off
bit 2 : Single Limit Status On/Off
bit 3 : Single Limit Beep Level ABOVE/BELOW
bit 4 : Multiple Limit Upper Segment 1 Status On/Off
bit 5 : Multiple Limit Upper Segment 1 Beep Level ABOVE/BELOW⁴¹⁶
bit 6 : Multiple Limit Upper Segment 2 Status On/Off
bit 7 : Multiple Limit Upper Segment 2 Beep Level ABOVE/BELOW
- 233) Status Byte 4: (0b = Off/Beep if data is BELOW line ,
1b = On/Beep if data is ABOVE line)
(LSB) bit 0 : Multiple Limit Upper Segment 3 Status On/Off
bit 1 : Multiple Limit Upper Segment 3 Beep Level ABOVE/BELOW
bit 2 : Multiple Limit Upper Segment 4 Status On/Off
bit 3 : Multiple Limit Upper Segment 4 Beep Level ABOVE/BELOW
bit 4 : Multiple Limit Upper Segment 5 Status On/Off
bit 5 : Multiple Limit Upper Segment 5 Beep Level ABOVE/BELOW
bit 6 : Multiple Limit Lower Segment 1 Status On/Off
bit 7 : Multiple Limit Lower Segment 1 Beep Level ABOVE/BELOW⁴¹⁷
- 234) Status Byte 5: (0b = Off/Beep if data is BELOW line ,
1b = On/Beep if data is ABOVE line)
(LSB) bit 0 : Multiple Limit Lower Segment 2 Status On/Off
bit 1 : Multiple Limit Lower Segment 2 Beep Level ABOVE/BELOW
bit 2 : Multiple Limit Lower Segment 3 Status On/Off
bit 3 : Multiple Limit Lower Segment 3 Beep Level ABOVE/BELOW
bit 4 : Multiple Limit Lower Segment 4 Status On/Off
bit 5 : Multiple Limit Lower Segment 4 Beep Level ABOVE/BELOW
bit 6 : Multiple Limit Lower Segment 5 Status On/Off
bit 7 : Multiple Limit Lower Segment 5 Beep Level ABOVE/BELOW
- 235) Status Byte 6: (0b = Off, 1b = On)
(LSB) bit 0 : Not Used
bit 1 : Bias Tee On/Off (Option 10)
bit 2 : External Reference Freq On/Off
bits 3-4 : Amplitude Units (Log) - 00b = dBm 01b = dBV 10b = dBmV 11b = dBuV
(Linear) – 00b = Watts 01b = Volts
bits 5-6 : Detection Alg (00b = pos. peak 01b = RMS Averaging 10b = neg. peak 11b =
Sampling Mode)
bit 7 : Units Type (0b = Log 1b = Linear)

⁴¹⁶ Beep level is always 1b for upper segmented limit line

⁴¹⁷ Beep level is always 0b for lower segmented limit line

- 236) External Reference Frequency⁴¹⁸
 - 237) Signal Standard⁴¹⁹ (Higher byte)
 - 238) Signal Standard (Lower byte)
 - 239) Channel Selection⁴²⁰ (Higher byte)
 - 240) Channel Selection (Lower byte)
 - 241) Trigger Type⁴²¹
 - 242) Status Byte 7
 - (LSB) bits 0-6: Number of sweeps to average (1-25, 1 implies averaging OFF)
 - bit 7: Not Used
 - 243) Status Byte 8: (0b = Off, 1b = On)
 - (LSB) bits 0-1: Trace Math Operation (00b = A only, 01b = A-B, 10b = A+B)
 - bit 2: Max Hold On/Off
 - bit 3: Min Hold On/Off
 - bit 4: RBW Coupling (1b = Auto, 0b = Manual)
 - bit 5: VBW Coupling (1b = Auto, 0b = Manual)
 - bit 6: Attenuation Coupling (1b = Auto, 0b = Manual)
 - bit 7: View B On/Off
 - 244) Frequency Scale Factor⁴²² (Higher byte)
 - 245) Frequency Scale Factor (Lower byte)
 - 246) Frequency Range Minimum⁴²³ (Highest byte)
 - 247) Frequency Range Minimum
 - 248) Frequency Range Minimum
 - 249) Frequency Range Minimum (Lowest byte)
 - 250) Frequency Range Maximum⁴²⁴ (Highest byte)
 - 251) Frequency Range Maximum
 - 252) Frequency Range Maximum
 - 253) Frequency Range Maximum (Lowest byte)
 - 254) Marker Type⁴²⁵
 - 255) Trace B Trace Id⁴²⁶
 - 256) Status Byte 9
 - (LSB) bit 0: Reserved
 - bits 1-7: Not Used
- 257-400) Not Used

For Power Meter Mode (Option 29 Only):

- 21) Power Meter Start Freq⁴²⁷ (Highest byte)
- 22) Power Meter Start Freq
- 23) Power Meter Start Freq
- 24) Power Meter Start Freq⁴²⁸ (Lowest byte)
- 25) Power Meter Stop Freq (Highest byte)
- 26) Power Meter Stop Freq
- 27) Power Meter Stop Freq
- 28) Power Meter Stop Freq (Lowest byte)
- 29) Power Meter Center Freq⁴²⁹ (Highest byte)

⁴¹⁸ 1 byte in MHz (i.e. 20 = 20MHz)

⁴¹⁹ Index into Standard List (use control byte #89 to retrieve the ASCII string name). “No Standard” sent as FFFEh

⁴²⁰ “No Channel” is sent as FFFEh

⁴²¹ Trigger Type – 00h = Single, 01h = Free Run, 02h = Video, 03h = External

⁴²² In number of Hz

⁴²³ Scaled by Frequency Scale Factor (bytes 244-245)

⁴²⁴ Scaled by Frequency Scale Factor (bytes 244-245)

⁴²⁵ 00h = Regular Marker, 01h = Noise Marker

⁴²⁶ FFh indicates no trace selected

⁴²⁷ Scaled by Frequency Scale Factor (bytes 54-55)

⁴²⁸ Scaled by Frequency Scale Factor (bytes 54-55)

- 30) Power Meter Center Freq
- 31) Power Meter Center Freq
- 32) Power Meter Center Freq (Lowest byte)
- 33) Power Meter Span⁴³⁰ (Highest byte)
- 34) Power Meter Span
- 35) Power Meter Span
- 36) Power Meter Span (Lowest byte)
- 37) Signal Standard⁴³¹ (Higher byte)
- 38) Signal Standard (Lower byte)
- 39) Channel Selection⁴³² (Higher byte)
- 40) Channel Selection (Lower byte)
- 41) Power Meter Offset⁴³³ (Highest byte)
- 42) Power Meter Offset
- 43) Power Meter Offset
- 44) Power Meter Offset (Lowest byte)
- 45) Power Meter Relative (Highest byte)⁴³⁴
- 46) Power Meter Relative
- 47) Power Meter Relative
- 48) Power Meter Relative (Lowest byte)
- 49) Not Used
- 50) Power Meter Unit (00h = Watts, 01h = dBm)
- 51) Power Meter Relative Status (00h = Off, 01h = On)
- 52) Power Meter Offset Status (00h = Off, 01h = On)
- 53) Power Meter RMS Averaging Level (00h = Off, 01h = Low, 02h = Medium, 03h = High)
- 54) Frequency Scale Factor⁴³⁵ (Higher byte)
- 55) Frequency Scale Factor (Lower byte)
- 56) Frequency Range Minimum⁴³⁶ (Highest byte)
- 57) Frequency Range Minimum
- 58) Frequency Range Minimum
- 59) Frequency Range Minimum (Lowest byte)
- 60) Frequency Range Maximum⁴³⁷ (Highest byte)
- 61) Frequency Range Maximum
- 62) Frequency Range Maximum
- 63) Frequency Range Maximum (Lowest byte)
- 64) Zero Status (00h = Off, 01h = On)
- 65) Zero Value⁴³⁸ (Highest byte)
- 66) Zero Value
- 67) Zero Value
- 68) Zero Value (Lowest byte)
- 69-120) Not Used

For T1 Mode (Option 50):

- 21) T1 Receive Input (00h = Terminate, 01h = Bridged, 02h = Monitor)
- 22) T1 Framing Mode (01h = ESF, 02h = D4SF)
- 23) T1 Line Coding (01h = B8ZS, 02h = AMI)

⁴²⁹ Scaled by Frequency Scale Factor (bytes 54-55)

⁴³⁰ Scaled by Frequency Scale Factor (bytes 54-55)

⁴³¹ Index into Standard List (use control byte #89 to retrieve the ASCII string name). "No Standard" sent as FFFEh

⁴³² "No Channel" is sent as FFFEh

⁴³³ Value sent as (value in dB * 1000)

⁴³⁴ Value sent as ((value in dBm * 1000) + 100)

⁴³⁵ In number of Hz

⁴³⁶ Scaled by Frequency Scale Factor

⁴³⁷ Scaled by Frequency Scale Factor

⁴³⁸ Value sent as ((value in dBm * 1000) + 100)

- 24) T1 Clock Source (00h = External, 01h = Internal)
- 25) T1 Tx Level (01h = 0 dB, 02h = -7.5 dB, 03h = -15 dB)
- 26) T1 Error Insert Type (00h = Frame Error, 01h = BPV, 02h = Bit Errors, 04h = RAI, 05h = AIS)
- 27) T1 Loop Code (00h = CSU, 01h = NIU, 02h = User 1, 03h = User 2)
- 28) T1 CRC Method (00h = ANSI CRC, 01h = Japanese CRC)
- 29) T1 Loop Type (00h = In Band, 01h = Data Link)
- 30) T1 Pattern (Higher byte)
- 31) T1 Pattern (Lower byte) 01h = PRBS-9, 02h = PRBS-11, 03h = PRBS-15, 04h = PRBS-20(O.151),
05h = PRBS-20(O.153), 06h = PRBS-23, 07h = QRSS, 08h = 1 in 8, 09h = 2 in 8, 0Ah = 3 in 8, 0Bh =
All Ones, 0Ch = All Zeros, 0Dh = T1-DALY, 0Eh = User Defined)
- 32) T1 Pattern Invert Status (00h = Non-Inverted, 01h = Inverted)
- 33) T1 Display Type (00h = Histogram, 01h = Raw Data)
- 34) T1 Impedance
- 35 - 50) First User Defined Loop Code Down (16 bytes)
- 51 - 66) Second User Defined Loop Code Down (16 bytes)
- 67 - 82) First User Defined Loop Code Up (16 bytes)
- 83 - 98) Second User Defined Loop Code Up (16 bytes)
- 99 - 130) User Defined Pattern (32 bytes)
- 131) T1 1st User Defined Loop Up (Highest byte)
- 132) T1 1st User Defined Loop Up (Lowest byte)
- 133) T1 2nd User Defined Loop Up (Highest byte)
- 134) T1 2nd User Defined Loop Up (Lowest byte)
- 135) T1 1st User Defined Loop Down (Highest byte)
- 136) T1 1st User Defined Loop Down (Lowest byte)
- 137) T1 2nd User Defined Loop Down (Highest byte)
- 138) T1 2nd User Defined Loop Down (Lowest byte)
- 139) T1 User Defined Pattern (Highest byte)
- 140) T1 User Defined Pattern
- 141) T1 User Defined Pattern
- 142) T1 User Defined Pattern (Lowest Byte)
- 143) T1 Bit Error Insert Value (1-1000) (Highest byte)
- 144) T1 Bit Error Insert Value (Lowest byte)
- 145) T1 Frame Error Insert Value (1-1000) (Highest byte)
- 146) T1 Frame Error Insert Value (Lowest byte)
- 147) T1 BPV Error Insert Value (1-1000) (Highest byte)
- 148) T1 BPV Error Insert Value (Lowest byte)
- 149) T1 Graph Resolution⁴³⁹
- 150) T1 Measurement Duration⁴⁴⁰
- 151) T1 Voltage Measurement Scale (00h = Vpp, 01h = dBdsx)
- 152) T1 Auto Framing Mode (00h = fixed framing, >00h = auto framing mode)
- 153) T1 Auto Pattern Sync Status (00h = Off, 01h = On)
- 154) Vpp Input Config (00h = Terminate, 01h = Bridged)
- 155) Data Logging Status (00h = Off, 01h = On)
- 156 – 250) Not Used

For E1 Mode (Option 50):

- 21) E1 Receive Input (00h = Terminate, 01h = Bridged, 02h = Monitor)
- 22) E1 Framing Mode (03h = PCM30, 04h = PCM30CRC, 05h = PCM31, 06h = PCM31CRC)
- 23) E1 Line Coding (02h = AMI, 03h = HDB3)
- 24) E1 Clock Source (00h = External, 01h = Internal)
- 25) E1 Tx Level

⁴³⁹ Graph Resolution: 00h: Auto, 01h: 1 sec, 02h: 15 sec, 03h: 30 sec, 04h 45 sec, 05h 1 min, 06h: 15 min, 07h: 30 min, 08h: 45 min, 09h: 60 min

⁴⁴⁰ Measurement Duration: 00h: Manual, 01h: 3 min, 02h: 15 min, 03h: 30 min, 04h: 1 hr, 05h: 3 hrs, 06h: 6 hrs, 07h: 12 hrs, 08h: 1 day, 09h: 2 days

- 26) E1 Error Insert Type (00h = Frame Error, 01h = BPV, 02h = Bit Errors, 04h = RAI, 05h = AIS)
- 27) E1 Loop Code
- 28) E1 CRC Method
- 29) E1 Loop Type
- 30) E1 Pattern (Higher byte)
- 31) E1 Pattern (Lower byte) (01h = PRBS-9, 02h = PRBS-11, 03h = PRBS-15, 04h = PRBS-20(O.151), 05h = PRBS-20(O.153), 06h = PRBS-23, 07h = QRSS, 08h = 1 in 8, 09h = 2 in 8, 0Ah = 3 in 8, 0Bh = All Ones, 0Ch = All Zeros, 0Dh = T1-DALY, 0Eh = User Defined)
- 32) E1 Pattern Invert (00h = Non-Inverted, 01h = Inverted)
- 33) E1 Display Type (00h = Histogram, 01h = Raw Data)
- 34) E1 Impedance (01h = 75 Ω , 02h = 120 Ω)
- 35 - 50) First User Defined Loop Code Down (16 bytes)
- 51 - 66) Second User Defined Loop Code Down (16 bytes)
- 67 - 82) First User Defined Loop Code Up (16 bytes)
- 83 - 98) Second User Defined Loop Code Up (16 bytes)
- 99 - 130) User Defined Pattern (32 bytes)
 - 131) E1 1st User Defined Loop Up (Higher byte)
 - 132) E1 1st User Defined Loop Up (Lower byte)
 - 133) E1 2nd User Defined Loop Up (Higher byte)
 - 134) E1 2nd User Defined Loop Up (Lower byte)
 - 135) E1 1st User Defined Loop Down (Higher byte)
 - 136) E1 1st User Defined Loop Down (Lower byte)
 - 137) E1 2nd User Defined Loop Down (Higher byte)
 - 138) E1 2nd User Defined Loop Down (Lower byte)
 - 139) E1 User Defined Pattern (Highest byte)
 - 140) E1 User Defined Pattern
 - 141) E1 User Defined Pattern
 - 142) E1 User Defined Pattern (Lowest byte)
 - 143) E1 Bit Error Insert Value (1-1000) (Higher byte)
 - 144) E1 Bit Error Insert Value (Lower byte)
 - 145) E1 Frame Error Insert Value (1-1000) (Higher byte)
 - 146) E1 Frame Error Insert Value (Lower byte)
 - 147) E1 BPV Error Insert Value (1-1000) (Higher byte)
 - 148) E1 BPV Error Insert Value (Lower byte)
 - 149) E1 Graph Resolution⁴⁴¹
 - 150) E1 Measurement Duration⁴⁴²
 - 151) E1 Voltage Measurement Scale (00h = Vpp, 01h = dBdsx)
 - 152) E1 Auto Framing Mode (00h = fixed framing, >00h = auto framing mode)
 - 153) E1 Auto Pattern Sync Status (00h = Off, 01h = On)
 - 154) Vpp Input Config (00h = Terminate, 01h = Bridged)
 - 155) Data Logging Status (00h = Off, 01h = On)
 - 156) E1 Vpp Input Impedance (01h = 75 Ω , 02h = 120 Ω)
 - 157-250) Not Used

Upload Setup – Control Byte #66 (42h)

Description: Receives parameters defining a setup and saves them in the memory location associated with the specified setup number. Since different modes have different numbers of setup locations available, the command requires the mode be specified as well as the setup number.

Setup numbers as follows:

⁴⁴¹ Graph Resolution: 00h: Auto, 01h: 1 sec, 02h: 15 sec, 03h: 30 sec, 04h 45 sec, 05h 1 min, 06h: 15 min, 07h: 30 min, 08h: 45 min, 09h: 60 min

⁴⁴² Measurement Duration: 00h: Manual, 01h: 3 min, 02h: 15 min, 03h: 30 min, 04h: 1 hr, 05h: 3 hrs, 06h: 6 hrs, 07h: 12 hrs, 08h: 1 day, 09h: 2 days

- 0 = Run time setup
- 1 – 10 = Saved setups for Spectrum Analyzer/Transmission Measurement modes
- 1 – 5 = Saved setups for Power Meter mode (Option 29 Only)

Bytes to Follow: 2 bytes

For All Modes:

- 1) Number of Following Bytes (Higher byte)
- 2) Number of Following Bytes (Lower byte)
- 3) Measurement Mode⁴⁴³
- 4) Setup Number in which to store setup
- 5-20) Not Used

For Site Master VNA Modes:

- 21) Number of Data Points (Higher byte)
- 22) Number of Data Points (Lower byte)
- 23) VNA Start Frequency⁴⁴⁴ (Highest byte)
- 24) VNA Start Frequency
- 25) VNA Start Frequency
- 26) VNA Start Frequency (Lowest byte)
- 27) VNA Stop Frequency⁴⁴⁵ (Highest byte)
- 28) VNA Stop Frequency
- 29) VNA Stop Frequency
- 30) VNA Stop Frequency (Lowest byte)
- 31) Return Loss Scale Start (Higher byte)⁴⁴⁶
- 32) Return Loss Scale Start (Lower byte)
- 33) Return Loss Scale Stop (Higher byte)
- 34) Return Loss Scale Stop (Lower byte)
- 35) SWR Scale Start (Higher byte)⁴⁴⁷
- 36) SWR Scale Start (Lower byte)
- 37) SWR Scale Stop (Higher byte)
- 38) SWR Scale Stop (Lower byte)
- 39) Cable Loss Scale Start (Higher byte)⁴⁴⁸
- 40) Cable Loss Scale Start (Lower byte)
- 41) Cable Loss Scale Stop (Higher byte)
- 42) Cable Loss Scale Stop (Lower byte)
- 43) DTF-RL Scale Start (Higher byte)⁴⁴⁹
- 44) DTF-RL Scale Start (Lower byte)
- 45) DTF-RL Scale Stop (Higher byte)
- 46) DTF-RL Scale Stop (Lower byte)
- 47) DTF-SWR Scale Start (Higher byte)⁴⁵⁰
- 48) DTF-SWR Scale Start (Lower byte)
- 49) DTF-SWR Scale Stop (Higher byte)
- 50) DTF-SWR Scale Stop (Lower byte)
- 51) VNA Frequency Marker 1 (Higher byte)⁴⁵¹
- 52) VNA Frequency Marker 1(Lower byte)

⁴⁴³ Refer to Control Byte #3 “Select Measurement Mode” for valid measurement modes.

⁴⁴⁴ Frequency is scaled by the frequency scale factor specified in bytes 465-466.

⁴⁴⁵ Frequency is scaled by the frequency scale factor specified in bytes 465-466.

⁴⁴⁶ See “Set Site Master VNA Scale” Control Byte #4 for data format.

⁴⁴⁷ See “Set Site Master VNA Scale” Control Byte #4 for data format.

⁴⁴⁸ See “Set Site Master VNA Scale” Control Byte #4 for data format.

⁴⁴⁹ See “Set Site Master VNA Scale” Control Byte #4 for data format.

⁴⁵⁰ See “Set Site Master VNA Scale” Control Byte #4 for data format.

⁴⁵¹ Marker Point = (# data points – 1) * (marker freq – start freq) / (stop freq – start freq)

Where # of data points can be found in bytes 2-3, start freq is in bytes 4-7, and stop freq is in bytes 8-11.

- 53) VNA Frequency Marker 2 (Higher byte)
- 54) VNA Frequency Marker 2 (Lower byte)
- 55) VNA Frequency Marker 3 (Higher byte)
- 56) VNA Frequency Marker 3 (Lower byte)
- 57) VNA Frequency Marker 4 (Higher byte)
- 58) VNA Frequency Marker 4 (Lower byte)
- 59) VNA Frequency Marker 5 (Higher byte)
- 60) VNA Frequency Marker 5 (Lower byte)
- 61) VNA Frequency Marker 6 (Higher byte)
- 62) VNA Frequency Marker 6 (Lower byte)
- 63) Return Loss Single Limit (Higher byte)⁴⁵²
- 64) Return Loss Single Limit (Lower byte)
- 65) SWR Single Limit (Higher byte)⁴⁵³
- 66) SWR Single Limit (Lower byte)
- 67) Cable Loss Single Limit (Higher byte)⁴⁵⁴
- 68) Cable Loss Single Limit (Lower byte)
- 69) DTF-RL Single Limit (Higher byte)⁴⁵⁵
- 70) DTF-RL Single Limit (Lower byte)
- 71) DTF-SWR Single Limit (Higher byte)⁴⁵⁶
- 72) DTF-SWR Single Limit (Lower byte)
- 73) Return Loss Multiple Limit Segment # (1)
- 74) Return Loss Multiple Limit Segment Status (00h = Off, 01h = On)
- 75) Return Loss Multiple Limit Segment Start X (Highest byte)⁴⁵⁷
- 76) Return Loss Multiple Limit Segment Start X
- 77) Return Loss Multiple Limit Segment Start X
- 78) Return Loss Multiple Limit Segment Start X (Lowest byte)
- 79) Return Loss Multiple Limit Segment Start Y (Higher byte)
- 80) Return Loss Multiple Limit Segment Start Y (Lowest byte)
- 81) Return Loss Multiple Limit Segment End X (Highest byte)⁴⁵⁸
- 82) Return Loss Multiple Limit Segment End X
- 83) Return Loss Multiple Limit Segment End X
- 84) Return Loss Multiple Limit Segment End X (Lowest byte)
- 85) Return Loss Multiple Limit Segment End Y (Higher byte)
- 86) Return Loss Multiple Limit Segment End Y (Lowest byte)
- 87-142) Repeat bytes 63 – 76 for segments 2 – 5
- 143-212) Repeat bytes 63 – 132 for SWR Multiple Limit
- 213-282) Repeat bytes 63 – 132 for Cable Loss Multiple Limit
- 283-352) Repeat bytes 63 – 132 for DTF-RL Multiple Limit
- 353-422) Repeat bytes 63 – 132 for DTF-SWR Multiple Limit
- 423) Start Distance (Highest byte)⁴⁵⁹
- 424) Start Distance
- 425) Start Distance
- 426) Start Distance (Lowest byte)
- 427) Stop Distance (Highest byte)
- 428) Stop Distance
- 429) Stop Distance

⁴⁵² See Control Byte #6, “Set Site Master VNA Single Limit” for data format.

⁴⁵³ See Control Byte #6, “Set Site Master VNA Single Limit” for data format.

⁴⁵⁴ See Control Byte #6, “Set Site Master VNA Single Limit” for data format.

⁴⁵⁵ See Control Byte #6, “Set Site Master VNA Single Limit” for data format.

⁴⁵⁶ See Control Byte #6, “Set Site Master VNA Single Limit” for data format.

⁴⁵⁷ See Control Byte #112, “Set Site Master VNA Segmented Limit Lines” for data format. Frequency is scaled by the frequency scale factor specified in bytes 465-466.

⁴⁵⁸ Frequency is scaled by the frequency scale factor specified in bytes 465-466.

⁴⁵⁹ Distance data uses units 1/100,000m or 1/100,000 ft

- 430) Stop Distance (Lowest byte)
- 431) Distance Marker 1 (Higher byte)⁴⁶⁰
- 432) Distance Marker 1 (Lower byte)
- 433) Distance Marker 2 (Higher byte)
- 434) Distance Marker 2 (Lower byte)
- 435) Distance Marker 3 (Higher byte)
- 436) Distance Marker 3 (Lower byte)
- 437) Distance Marker 4 (Higher byte)
- 438) Distance Marker 4 (Lower byte)
- 439) Distance Marker 5 (Higher byte)
- 440) Distance Marker 5 (Lower byte)
- 441) Distance Marker 6 (Higher byte)
- 442) Distance Marker 6 (Lower byte)
- 443) Relative Propagation Velocity (Highest byte)⁴⁶¹
- 444) Relative Propagation Velocity
- 445) Relative Propagation Velocity
- 446) Relative Propagation Velocity (Lowest byte)
- 447) Cable Loss (Highest byte)⁴⁶²
- 448) Cable Loss
- 449) Cable Loss
- 450) Cable Loss (Lowest byte)
- 451) Average Cable Loss⁴⁶³ (Highest byte)
- 452) Average Cable Loss
- 453) Average Cable Loss
- 454) Average Cable Loss (Lowest byte)
- 455) Status Byte 1: (0b = Off , 1b = On)
 - (LSB) bit 0 : Site Master Marker 1 On/Off
 - bit 1 : Site Master Marker 2 On/Off
 - bit 2 : Site Master Marker 3 On/Off
 - bit 3 : Site Master Marker 4 On/Off
 - bit 4 : Site Master Marker 5 On/Off
 - bit 5 : Site Master Marker 6 On/Off
 - bits 6- 7 : Not Used
- 456) Status Byte 2: (0b = Off, 1b = On)
 - (LSB) bit 0 : Not Used
 - bit 1 : Site Master Marker 2 Delta On/Off
 - bit 2 : Site Master Marker 3 Delta On/Off
 - bit 3 : Site Master Marker 4 Delta On/Off
 - bits 4-7: Not Used
- 457) Status Byte 3: (0b = Off , 1b = On)
 - (LSB) bit 0 : Site Master Limit Type (0b = Single, 1b = Multiple)
 - bit 1 : Site Master Limit Beep On/Off
 - bits 2-6 : Not Used
 - bit 7 : Site Master Single Limit Status On/Off
- 458) Status Byte 4:
 - (LSB) bits 0 - 1 : DTF Windowing Mode
 - bit: 1 0
 - | |
 - 0 0 - Rectangular (No Windowing)
 - 0 1 - Nominal Side Lobe

⁴⁶⁰ Marker Point = (# data points – 1) * (marker dist – start dist) / (stop dist – start dist)

Where # of data points can be found in bytes 2-3, start dist is in bytes 106-109, and stop dist is in bytes 110-113.

⁴⁶¹ Relative Propagation Velocity uses units 1/100,000.

⁴⁶² Cable loss uses units 1/100,000 dB/m or 1/100,000 dB/ft.

⁴⁶³ Average Cable Loss is dB * 1000.

- 1 0 - Low Side Lobe
- 1 1 - Minimum Side Lobe
- bits 2 – 7 : Not Used
- 459) Status Byte 5: (0b = Off, 1b = On)
 - (LSB) bit 0 : Fixed CW Mode On/Off
 - bit 1 : Single Sweep On/Off
 - bit 2 : Trace Overlay On/Off
 - bit 3 : Measurement Unit Metric/English (0b = English, 1b = Metric)
 - bits 4-6: Not Used
 - bit 7 : Cal Mode (0b = OSL Cal, 1b = FlexCal)
- 460) VNA Signal Standard⁴⁶⁴ (Higher byte)
- 461) VNA Signal Standard (Lower byte)
- 462) Cable Index
- 463) Cable Folder⁴⁶⁵
- 464) Trace Overlay Index (1-200)
- 465) Frequency Scale Factor (Higher byte)⁴⁶⁶
- 466) Frequency Scale Factor (Lower byte)
- 467-550) Not Used

For Spectrum Analyzer Mode:

- 21) Spectrum Analyzer Start Frequency⁴⁶⁷ (Highest byte)
- 22) Spectrum Analyzer Start Frequency
- 23) Spectrum Analyzer Start Frequency
- 24) Spectrum Analyzer Start Frequency (Lowest byte)
- 25) Spectrum Analyzer Stop Frequency⁴⁶⁸ (Highest byte)
- 26) Spectrum Analyzer Stop Frequency
- 27) Spectrum Analyzer Stop Frequency
- 28) Spectrum Analyzer Stop Frequency (Lowest byte)
- 29) Spectrum Analyzer Center Frequency⁴⁶⁹ (Highest byte)
- 30) Spectrum Analyzer Center Frequency
- 31) Spectrum Analyzer Center Frequency
- 32) Spectrum Analyzer Center Frequency (Lowest byte)
- 33) Spectrum Analyzer Frequency Span⁴⁷⁰ (Highest byte)
- 34) Spectrum Analyzer Frequency Span
- 35) Spectrum Analyzer Frequency Span
- 36) Spectrum Analyzer Frequency Span (Lowest byte)
- 37) Ref Level (Highest byte)⁴⁷¹
- 38) Ref Level
- 39) Ref Level
- 40) Ref Level (Lowest byte)
- 41) Scale per div (Highest byte)⁴⁷²
- 42) Scale per div
- 43) Scale per div
- 44) Scale per div (Lowest byte)
- 45) Spectrum Analyzer Frequency Marker 1 (Higher byte)⁴⁷³

⁴⁶⁴ Index into Standard List (use control byte #89 to retrieve the ASCII string name). “No Standard” sent as FFFEh

⁴⁶⁵ 00h=Standard at 1000 MHz, 01h=Standard at 2000 MHz, 02h=Standard at 2500 MHz, 03h=Custom

⁴⁶⁶ Frequency Scale Factor is in number of Hz.

⁴⁶⁷ Scaled by Frequency Scale Factor (bytes 301-302)

⁴⁶⁸ Scaled by Frequency Scale Factor (bytes 301-302)

⁴⁶⁹ Scaled by Frequency Scale Factor (bytes 301-302)

⁴⁷⁰ Scaled by Frequency Scale Factor (bytes 301-302)

⁴⁷¹ Value sent as (value in dBm * 1000) + 270,000)

⁴⁷² Value sent as (value * 1000)

- 46) Spectrum Analyzer Frequency Marker 1 (Lower byte)
- 47) Spectrum Analyzer Frequency Marker 2 (Higher byte)
- 48) Spectrum Analyzer Frequency Marker 2 (Lower byte)
- 49) Spectrum Analyzer Frequency Marker 3 (Higher byte)
- 50) Spectrum Analyzer Frequency Marker 3 (Lower byte)
- 51) Spectrum Analyzer Frequency Marker 4 (Higher byte)
- 52) Spectrum Analyzer Frequency Marker 4 (Lower byte)
- 53) Spectrum Analyzer Frequency Marker 5 (Higher byte)
- 54) Spectrum Analyzer Frequency Marker 5 (Lower byte)
- 55) Spectrum Analyzer Frequency Marker 6 (Higher byte)
- 56) Spectrum Analyzer Frequency Marker 6 (Lower byte)
- 57) Spectrum Analyzer Single Limit (Highest byte)⁴⁷⁴
- 58) Spectrum Analyzer Single Limit
- 59) Spectrum Analyzer Single Limit
- 60) Spectrum Analyzer Single Limit (Lowest byte)
- 61) SPA Multiple Upper Limit 1 Start X⁴⁷⁵ (Highest byte)
- 62) SPA Multiple Upper Limit 1 Start X
- 63) SPA Multiple Upper Limit 1 Start X
- 64) SPA Multiple Upper Limit 1 Start X (Lowest byte)
- 65) SPA Multiple Upper Limit 1 Start Y (Power Level) (Highest byte)⁴⁷⁶
- 66) SPA Multiple Upper Limit 1 Start Y (Power Level)
- 67) SPA Multiple Upper Limit 1 Start Y (Power Level)
- 68) SPA Multiple Upper Limit 1 Start Y (Power Level) (Lowest byte)
- 69) SPA Multiple Upper Limit 1 End X⁴⁷⁷ (Highest byte)
- 70) SPA Multiple Upper Limit 1 End X
- 71) SPA Multiple Upper Limit 1 End X
- 72) SPA Multiple Upper Limit 1 End X (Lowest byte)
- 73) SPA Multiple Upper Limit 1 End Y (Power Level) (Highest byte)⁴⁷⁸
- 74) SPA Multiple Upper Limit 1 End Y (Power Level)
- 75) SPA Multiple Upper Limit 1 End Y (Power Level)
- 76) SPA Multiple Upper Limit 1 End Y (Power Level) (Lowest byte)
- 77-220) SPA Multiple Upper Limits 2-5, SA Multiple Lower Limits 1-5 (see bytes 61-76 for format)
- 221) RBW Setting (Highest byte)⁴⁷⁹
- 222) RBW Setting
- 223) RBW Setting
- 224) RBW Setting (Lowest byte)
- 225) VBW Setting (Highest byte)⁴⁸⁰
- 226) VBW Setting
- 227) VBW Setting
- 228) VBW Setting (Lowest byte)
- 229) OCC BW Method⁴⁸¹
- 230) OCC BW % Value⁴⁸²
- 231) OCC BW dBc⁴⁸³

⁴⁷³ Value sent as data point on the display. Equivalent frequency = (point * span / (# data points – 1)) + start frequency.

⁴⁷⁴ Value sent as (value in dBm * 1000) + 270000

⁴⁷⁵ Scaled by Frequency Scale Factor (bytes 301-302)

⁴⁷⁶ Value sent as (value in dBm * 1000) + 270000

⁴⁷⁷ Scaled by Frequency Scale Factor (bytes 301-302)

⁴⁷⁸ Value sent as (value in dBm * 1000) + 270000

⁴⁷⁹ RBW frequency sent in Hz.

⁴⁸⁰ VBW frequency sent in Hz.

⁴⁸¹ 00h = % of power, 01h = dB down

⁴⁸² 0 – 99%

⁴⁸³ 0 – 120 dBc

- 232) Attenuation
- 233) Antenna Index (0-14)
- 234-249) Antenna Name (16 bytes in ASCII)
- 250) Status Byte 1: (0b = Off , 1b = On)
- (LSB) bit 0 : Spectrum Analyzer Mode Marker 1 On/Off
bit 1 : Spectrum Analyzer Mode Marker 2 On/Off
bit 2 : Spectrum Analyzer Mode Marker 3 On/Off
bit 3 : Spectrum Analyzer Mode Marker 4 On/Off
bit 4 : Spectrum Analyzer Mode Marker 5 On/Off
bit 5 : Spectrum Analyzer Mode Marker 6 On/Off
bits 6 - 7 : Not Used
- 251) Status Byte 2: (0b = Off, 1b = On)
- (LSB) bit 0 : Not Used
bit 1 : Spectrum Analyzer Mode Marker 2 Delta On/Off
bit 2 : Spectrum Analyzer Mode Marker 3 Delta On/Off
bit 3 : Spectrum Analyzer Mode Marker 4 Delta On/Off
bit 4 : Pre Amp Mode (0b = Manual, 1b = Auto)
bit 5 : Pre Amp Status On/Off
bit 6 : Dynamic Attenuation On/Off
bit 7 : Normalization On/Off
- 252) Status Byte 3: (0b = Off/Beep if data is BELOW line ,
1b = On/Beep if data is ABOVE line)
- (LSB) bit 0 : SPA Limit Type (0b = Single, 1b = Multiple)
bit 1 : SPA Single Limit Beep On/Off
bit 2 : SPA Single Limit Status On/Off
bit 3 : SPA Single Limit Beep Level ABOVE/BELOW
bit 4 : SPA Multiple Limit Upper Segment 1 Status On/Off
bit 5 : SPA Multiple Limit Upper Segment 1 Beep Level ABOVE/BELOW⁴⁸⁴
bit 6 : SPA Multiple Limit Upper Segment 2 Status On/Off
bit 7 : SPA Multiple Limit Upper Segment 2 Beep Level ABOVE/BELOW
- 253) Status Byte 4: (0b = Off/Beep if data is BELOW line ,
1b = On/Beep if data is ABOVE line)
- (LSB) bit 0 : SPA Multiple Limit Upper Segment 3 Status On/Off
bit 1 : SPA Multiple Limit Upper Segment 3 Beep Level ABOVE/BELOW
bit 2 : SPA Multiple Limit Upper Segment 4 Status On/Off
bit 3 : SPA Multiple Limit Upper Segment 4 Beep Level ABOVE/BELOW
bit 4 : SPA Multiple Limit Upper Segment 5 Status On/Off
bit 5 : SPA Multiple Limit Upper Segment 5 Beep Level ABOVE/BELOW
bit 6 : SPA Multiple Limit Lower Segment 1 Status On/Off
bit 7 : SPA Multiple Limit Lower Segment 1 Beep Level ABOVE/BELOW⁴⁸⁵
- 254) Status Byte 5: (0b = Off/Beep if data is BELOW line ,
1b = On/Beep if data is ABOVE line)
- (LSB) bit 0 : SPA Multiple Limit Lower Segment 2 Status On/Off
bit 1 : SPA Multiple Limit Lower Segment 2 Beep Level ABOVE/BELOW
bit 2 : SPA Multiple Limit Lower Segment 3 Status On/Off
bit 3 : SPA Multiple Limit Lower Segment 3 Beep Level ABOVE/BELOW
bit 4 : SPA Multiple Limit Lower Segment 4 Status On/Off
bit 5 : SPA Multiple Limit Lower Segment 4 Beep Level ABOVE/BELOW
bit 6 : SPA Multiple Limit Lower Segment 5 Status On/Off
bit 7 : SPA Multiple Limit Lower Segment 5 Beep Level ABOVE/BELOW
- 255) Status Byte 6: (0b = Off, 1b = On)
- (LSB) bit 0 : Antenna Factors Correction On/Off
bit 1 : Bias Tee On/Off (Option 10)

⁴⁸⁴ Beep level is always 1b for upper segmented limit line

⁴⁸⁵ Beep level is always 0b for lower segmented limit line

- bit 2 : Amplitude Units (Linear) – 00b = Watts 01b = Volts
bits 3-4 : Amplitude Units (Log) - 00b = dBm 01b = dBV 10b = dBmV 11b = dBuV
bits 5-6 : Detection Alg (00b = pos. peak 01b = RMS Averaging 10b = neg. peak 11b = Sampling Mode)
bit 7 : Units Type (0b = Log 1b = Linear)
- 256) Status Byte 7: (0b = Off, 1b = On)
(LSB) bit 0: Interference Analysis On/Off
bit 1: C/I Measurement On/Off
bit 2: RBW Coupling (1b = Auto, 0b = Manual)
bit 3: VBW Coupling (1b = Auto, 0b = Manual)
bit 4: Attenuation Coupling (1b = Auto, 0b = Manual)
bit 5: Channel Power On/Off
bit 6: Adjacent Channel Power On/Off
bit 7: Occupied BW Measurement On/Off
- 257) Reference Level Offset⁴⁸⁶ (Highest byte)
258) Reference Level Offset
259) Reference Level Offset
260) Reference Level Offset (Lowest byte)
261) External Reference Frequency⁴⁸⁷
262) Signal Standard⁴⁸⁸ (Higher byte)
263) Signal Standard (Lower byte)
264) Channel Selection⁴⁸⁹ (Higher byte)
265) Channel Selection (Lower byte)
266) Trigger Type⁴⁹⁰
267) Interference Analysis Frequency⁴⁹¹ (Highest byte)
268) Interference Analysis Frequency
269) Interference Analysis Frequency
270) Interference Analysis Frequency (Lowest byte)
271) Trigger Position (0 – 100%)
272) Min Sweep Time (in μ s) (Highest byte)
273) Min Sweep Time (in μ s)
274) Min Sweep Time (in μ s)
275) Min Sweep Time (in μ s) (Lowest byte)
276) Video Trigger Level⁴⁹² (Highest byte)
277) Video Trigger Level
278) Video Trigger Level
279) Video Trigger Level (Lowest byte)
280) Status Byte 8
(LSB) bit 0: Reserved
bits 1-7: Not Used
- 281) Status Byte 9
(LSB) bits 0-6: Number of sweeps to average (1-25, 1 implies averaging OFF)
bit 7: Not Used
- 282) Status Byte 10: (0b = Off, 1b = On)
(LSB) bits 0-1: Trace Math Operation (00b = A only, 01b = A-B, 10b = A+B)
bit 2: Max Hold On/Off
bit 3: Min Hold On/Off
bit 4: View B On/Off

⁴⁸⁶ Value sent as (value in dBm * 1000) + 270,000

⁴⁸⁷ 1 byte in MHz (i.e. 20 = 20MHz)

⁴⁸⁸ Index into Standard List (use control byte #89 to retrieve the ASCII string name). “No Standard” sent as FFFEh

⁴⁸⁹ “No Channel” is sent as FFFEh

⁴⁹⁰ Trigger Type – 00h = Single, 01h = Free Run, 02h = Video, 03h = External

⁴⁹¹ Scaled by Frequency Scale Factor (bytes 301-302)

⁴⁹² Value sent as (value in dBm * 1000) + 270,000

bit 5: External Reference Frequency On/Off

bits 6-7: Not Used

- 283) Impedance (00h = 50Ω, 10h = 75Ω Anritsu Adapter, 12h = 75Ω Other Adapter)
- 284) Impedance Loss⁴⁹³ (Higher byte)
- 285) Impedance Loss (Lower byte)
- 286) AM/FM Demod Type⁴⁹⁴
- 287) AM/FM Demod Status (01h = On, 00h = Off)
- 288) AM/FM Demod Volume (0 to 100)
- 289) AM/FM Demod Frequency⁴⁹⁵ (Highest byte)
- 290) AM/FM Demod Frequency
- 291) AM/FM Demod Frequency
- 292) AM/FM Demod Frequency (Lowest byte)
- 293) AM/FM Demod Time (in ms) (Highest byte)
- 294) AM/FM Demod Time (in ms)
- 295) AM/FM Demod Time (in ms)
- 296) AM/FM Demod Time (in ms) (Lowest byte)
- 297) SSB BFO Offset⁴⁹⁶ (Highest byte)
- 298) SSB BFO Offset
- 299) SSB BFO Offset
- 300) SSB BFO Offset (Lowest byte)
- 301) Frequency Scale Factor⁴⁹⁷ (Higher byte)
- 302) Frequency Scale Factor (Lower byte)
- 303) Frequency Range Minimum⁴⁹⁸ (Highest byte)
- 304) Frequency Range Minimum
- 305) Frequency Range Minimum
- 306) Frequency Range Minimum (Lowest byte)
- 307) Frequency Range Maximum⁴⁹⁹ (Highest byte)
- 308) Frequency Range Maximum
- 309) Frequency Range Maximum
- 310) Frequency Range Maximum (Lowest byte)
- 311) Marker Type⁵⁰⁰
- 312) Channel Power Int BW⁵⁰¹ (Highest byte)
- 313) Channel Power Int BW
- 314) Channel Power Int BW
- 315) Channel Power Int BW (Lowest byte)
- 316) ACPR Main Channel BW⁵⁰² (Highest byte)
- 317) ACPR Main Channel BW
- 318) ACPR Main Channel BW
- 319) ACPR Main Channel BW (Lowest byte)
- 320) ACPR Adjacent Channel BW⁵⁰³ (Highest byte)
- 321) ACPR Adjacent Channel BW
- 322) ACPR Adjacent Channel BW
- 323) ACPR Adjacent Channel BW (Lowest byte)

⁴⁹³ Value sent as (value in dB * 1000), valid values are 0 to 20 dB

⁴⁹⁴ AM/FM Demod Type: 00h = FM-Wide Band, 01h = FM-Narrow Band, 02h = AM, 03h = SSB Lower, 04h = SSB Upper

⁴⁹⁵ Scaled by Frequency Scale Factor (bytes 301-302)

⁴⁹⁶ Value sent as ((value in Hz) – 10,000)

⁴⁹⁷ In number of Hz

⁴⁹⁸ Scaled by Frequency Scale Factor (bytes 301-302)

⁴⁹⁹ Scaled by Frequency Scale Factor (bytes 301-302)

⁵⁰⁰ 00h = Regular Marker, 01h = Noise Marker

⁵⁰¹ Scaled by Frequency Scale Factor (bytes 301-302)

⁵⁰² Scaled by Frequency Scale Factor (bytes 301-302)

⁵⁰³ Scaled by Frequency Scale Factor (bytes 301-302)

- 324) ACPR Channel Spacing⁵⁰⁴ (Highest byte)
- 325) ACPR Channel Spacing
- 326) ACPR Channel Spacing
- 327) ACPR Channel Spacing (Lowest byte)
- 328) Interference Analysis Cell Std⁵⁰⁵
- 329) Interference Analysis Est. BW⁵⁰⁶ (Highest byte)
- 330) Interference Analysis Est. BW
- 331) Interference Analysis Est. BW
- 332) Interference Analysis Est. BW (Lowest byte)
- 333) Trace B Trace Id⁵⁰⁷
- 334-500) Not Used

For Transmission Mode (Option 21 Only):

- 21) Start Frequency⁵⁰⁸ (Highest byte)
- 22) Start Frequency
- 23) Start Frequency
- 24) Start Frequency (Lowest byte)
- 25) Stop Frequency⁵⁰⁹ (Highest byte)
- 26) Stop Frequency
- 27) Stop Frequency
- 28) Stop Frequency (Lowest byte)
- 29) Center Frequency⁵¹⁰ (Highest byte)
- 30) Center Frequency
- 31) Center Frequency
- 32) Center Frequency (Lowest byte)
- 33) Frequency Span⁵¹¹ (Highest byte)
- 34) Frequency Span
- 35) Frequency Span
- 36) Frequency Span (Lowest byte)
- 37) Ref Level (Highest byte)⁵¹²
- 38) Ref Level
- 39) Ref Level
- 40) Ref Level (Lowest byte)
- 41) Scale per div (Highest byte)⁵¹³
- 42) Scale per div
- 43) Scale per div
- 44) Scale per div (Lowest byte)
- 45) Frequency Marker 1 (Higher byte)⁵¹⁴
- 46) Frequency Marker 1 (Lower byte)
- 47) Frequency Marker 2 (Higher byte)
- 48) Frequency Marker 2 (Lower byte)
- 49) Frequency Marker 3 (Higher byte)

⁵⁰⁴ Scaled by Frequency Scale Factor (bytes 301-302)

⁵⁰⁵ 4 Standards – 00h = 1250 kHz CDMA, 01h = GSM, 02h = TDMA, 03h = AMPS, 04h = Unknown, FFh =

Interference Analysis Measurement OFF

⁵⁰⁶ Frequency in Hz

⁵⁰⁷ FFh indicates to trace selected

⁵⁰⁸ Scaled by Frequency Scale Factor (bytes 244-245)

⁵⁰⁹ Scaled by Frequency Scale Factor (bytes 244-245)

⁵¹⁰ Scaled by Frequency Scale Factor (bytes 244-245)

⁵¹¹ Scaled by Frequency Scale Factor (bytes 244-245)

⁵¹² Value sent as (value in dBm * 1000) + 270,000

⁵¹³ Value sent as (value * 1000)

⁵¹⁴ Value sent as data point on the display. Equivalent frequency = (point * span / (# data points – 1)) + start frequency.

- 50) Frequency Marker 3 (Lower byte)
- 51) Frequency Marker 4 (Higher byte)
- 52) Frequency Marker 4 (Lower byte)
- 53) Frequency Marker 5 (Higher byte)
- 54) Frequency Marker 5 (Lower byte)
- 55) Frequency Marker 6 (Higher byte)
- 56) Frequency Marker 6 (Lower byte)
- 57) Single Limit (Highest byte)⁵¹⁵
- 58) Single Limit
- 59) Single Limit
- 60) Single Limit (Lowest byte)
- 61) Multiple Upper Limit 1 Start X⁵¹⁶ (Highest byte)
- 62) Multiple Upper Limit 1 Start X
- 63) Multiple Upper Limit 1 Start X
- 64) Multiple Upper Limit 1 Start X (Lowest byte)
- 65) Multiple Upper Limit 1 Start Y (Power Level) (Highest byte)⁵¹⁷
- 66) Multiple Upper Limit 1 Start Y (Power Level)
- 67) Multiple Upper Limit 1 Start Y (Power Level)
- 68) Multiple Upper Limit 1 Start Y (Power Level) (Lowest byte)
- 69) Multiple Upper Limit 1 End X⁵¹⁸ (Highest byte)
- 70) Multiple Upper Limit 1 End X
- 71) Multiple Upper Limit 1 End X
- 72) Multiple Upper Limit 1 End X (Lowest byte)
- 73) Multiple Upper Limit 1 End Y (Power Level) (Highest byte)⁵¹⁹
- 74) Multiple Upper Limit 1 End Y (Power Level)
- 75) Multiple Upper Limit 1 End Y (Power Level)
- 76) Multiple Upper Limit 1 End Y (Power Level) (Lowest byte)
- 77-220) Multiple Upper Limits 2-5, SA Multiple Lower Limits 1-5 (see bytes 67-82 for format)
- 221) RBW Setting (Highest byte)⁵²⁰
- 222) RBW Setting
- 223) RBW Setting
- 224) RBW Setting (Lowest byte)
- 225) VBW Setting (Highest byte)⁵²¹
- 226) VBW Setting
- 227) VBW Setting
- 228) VBW Setting (Lowest byte)
- 229) Attenuation
- 230) Status Byte 1: (0b = Off , 1b = On)
 - (LSB) bit 0 : Marker 1 On/Off
 - bit 1 : Marker 2 On/Off
 - bit 2 : Marker 3 On/Off
 - bit 3 : Marker 4 On/Off
 - bit 4 : Marker 5 On/Off
 - bit 5 : Marker 6 On/Off
 - bits 6 - 7 : Not Used
- 231) Status Byte 2: (0b = Off, 1b = On)
 - (LSB) bit 0 : S21 Spa Cal Status (0 – Cal OFF, 1 – Cal ON)
 - bit 1 : Marker 2 Delta On/Off

⁵¹⁵ Value sent as (value in dBm * 1000) + 270000

⁵¹⁶ Scaled by Frequency Scale Factor (bytes 244-245)

⁵¹⁷ Value sent as (value in dBm * 1000) + 270000

⁵¹⁸ Scaled by Frequency Scale Factor (bytes 244-245)

⁵¹⁹ Value sent as (value in dBm * 1000) + 270000

⁵²⁰ RBW frequency sent in Hz.

⁵²¹ VBW frequency sent in Hz.

- bit 2 : Marker 3 Delta On/Off
 - bit 3 : Marker 4 Delta On/Off
 - bit 4 : Pre Amp Mode (0b = Manual, 1b = Auto)
 - bit 5 : Pre Amp Status On/Off
 - bit 6 : Dynamic Attenuation On/Off
 - bit 7 : Not Used
- 232) Status Byte 3: (0b = Off/Beep if data is BELOW line ,
1b = On/Beep if data is ABOVE line)
- (LSB) bit 0 : Limit Type (0b = Single, 1b = Multiple)
- bit 1 : Single Limit Beep On/Off
 - bit 2 : Single Limit Status On/Off
 - bit 3 : Single Limit Beep Level ABOVE/BELOW
 - bit 4 : Multiple Limit Upper Segment 1 Status On/Off
 - bit 5 : Multiple Limit Upper Segment 1 Beep Level ABOVE/BELOW⁵²²
 - bit 6 : Multiple Limit Upper Segment 2 Status On/Off
 - bit 7 : Multiple Limit Upper Segment 2 Beep Level ABOVE/BELOW
- 233) Status Byte 4: (0b = Off/Beep if data is BELOW line ,
1b = On/Beep if data is ABOVE line)
- (LSB) bit 0 : Multiple Limit Upper Segment 3 Status On/Off
- bit 1 : Multiple Limit Upper Segment 3 Beep Level ABOVE/BELOW
 - bit 2 : Multiple Limit Upper Segment 4 Status On/Off
 - bit 3 : Multiple Limit Upper Segment 4 Beep Level ABOVE/BELOW
 - bit 4 : Multiple Limit Upper Segment 5 Status On/Off
 - bit 5 : Multiple Limit Upper Segment 5 Beep Level ABOVE/BELOW
 - bit 6 : Multiple Limit Lower Segment 1 Status On/Off
 - bit 7 : Multiple Limit Lower Segment 1 Beep Level ABOVE/BELOW⁵²³
- 234) Status Byte 5: (0b = Off/Beep if data is BELOW line ,
1b = On/Beep if data is ABOVE line)
- (LSB) bit 0 : Multiple Limit Lower Segment 2 Status On/Off
- bit 1 : Multiple Limit Lower Segment 2 Beep Level ABOVE/BELOW
 - bit 2 : Multiple Limit Lower Segment 3 Status On/Off
 - bit 3 : Multiple Limit Lower Segment 3 Beep Level ABOVE/BELOW
 - bit 4 : Multiple Limit Lower Segment 4 Status On/Off
 - bit 5 : Multiple Limit Lower Segment 4 Beep Level ABOVE/BELOW
 - bit 6 : Multiple Limit Lower Segment 5 Status On/Off
 - bit 7 : Multiple Limit Lower Segment 5 Beep Level ABOVE/BELOW
- 235) Status Byte 6: (0b = Off, 1b = On)
- (LSB) bit 0 : External Reference Frequency On/Off
- bit 1 : Bias Tee On/Off (Option 10)
 - bit 2 : Amplitude Units (Linear) – 00b = Watts 01b = Volts
 - bits 3-4 : Amplitude Units (Log) - 00b = dBm 01b = dBV 10b = dBmV 11b = dBuV
 - bits 5-6 : Detection Alg (00b = pos. peak 01b = RMS Averaging 10b = neg. peak 11b = Sampling Mode)
 - bit 7 : Units Type (0b = Log 1b = Linear)
- 236) External Reference Frequency⁵²⁴
- 237) Signal Standard⁵²⁵ (Higher byte)
- 238) Signal Standard (Lower byte)
- 239) Channel Selection⁵²⁶ (Higher byte)
- 240) Channel Selection (Lower byte)
- 241) Trigger Type⁵²⁷

⁵²² Beep level is always 1b for upper segmented limit line

⁵²³ Beep level is always 0b for lower segmented limit line

⁵²⁴ 1 byte in MHz (i.e. 20 = 20MHz)

⁵²⁵ Index into Standard List (use control byte #89 to retrieve the ASCII string name). “No Standard” sent as FFFEh

⁵²⁶ “No Channel” is sent as FFFEh

- 242) Status Byte 7
(LSB) bits 0-6: Number of sweeps to average (1-25, 1 implies averaging OFF)
bit 7: Not Used
 - 243) Status Byte 8: (0b = Off, 1b = On)
(LSB) bits 0-1: Trace Math Operation (00b = A only, 01b = A-B, 10b = A+B)
bit 2: Max Hold On/Off
bit 3: Min Hold On/Off
bit 4: RBW Coupling (1b = Auto, 0b = Manual)
bit 5: VBW Coupling (1b = Auto, 0b = Manual)
bit 6: Attenuation Coupling (1b = Auto, 0b = Manual)
bit 7: View B On/Off
 - 244) Frequency Scale Factor⁵²⁸ (Higher byte)
 - 245) Frequency Scale Factor (Lower byte)
 - 246) Frequency Range Minimum⁵²⁹ (Highest byte)
 - 247) Frequency Range Minimum
 - 248) Frequency Range Minimum
 - 249) Frequency Range Minimum (Lowest byte)
 - 250) Frequency Range Maximum⁵³⁰ (Highest byte)
 - 251) Frequency Range Maximum
 - 252) Frequency Range Maximum
 - 253) Frequency Range Maximum (Lowest byte)
 - 254) Marker Type⁵³¹
 - 255) Trace B Trace Id⁵³²
 - 256) Status Byte 9
(LSB) bit 0: Reserved
bits 1-7: Not Used
- 257-400) Not Used

For Power Meter Mode (Option 29 Only):

- 21) Power Meter Start Freq⁵³³ (Highest byte)
- 22) Power Meter Start Freq
- 23) Power Meter Start Freq
- 24) Power Meter Start Freq⁵³⁴ (Lowest byte)
- 25) Power Meter Stop Freq (Highest byte)
- 26) Power Meter Stop Freq
- 27) Power Meter Stop Freq
- 28) Power Meter Stop Freq (Lowest byte)
- 29) Power Meter Center Freq⁵³⁵ (Highest byte)
- 30) Power Meter Center Freq
- 31) Power Meter Center Freq
- 32) Power Meter Center Freq (Lowest byte)
- 33) Power Meter Span⁵³⁶ (Highest byte)
- 34) Power Meter Span
- 35) Power Meter Span
- 36) Power Meter Span (Lowest byte)

⁵²⁷ Trigger Type – 00h = Single, 01h = Free Run, 02h = Video, 03h = External

⁵²⁸ In number of Hz

⁵²⁹ Scaled by Frequency Scale Factor (bytes 244-245)

⁵³⁰ Scaled by Frequency Scale Factor (bytes 244-245)

⁵³¹ 00h = Regular Marker, 01h = Noise Marker

⁵³² FFh indicates no trace selected

⁵³³ Scaled by Frequency Scale Factor (bytes 54-55)

⁵³⁴ Scaled by Frequency Scale Factor (bytes 54-55)

⁵³⁵ Scaled by Frequency Scale Factor (bytes 54-55)

⁵³⁶ Scaled by Frequency Scale Factor (bytes 54-55)

- 37) Signal Standard⁵³⁷ (Higher byte)
- 38) Signal Standard (Lower byte)
- 39) Channel Selection⁵³⁸ (Higher byte)
- 40) Channel Selection (Lower byte)
- 41) Power Meter Offset⁵³⁹ (Highest byte)
- 42) Power Meter Offset
- 43) Power Meter Offset
- 44) Power Meter Offset (Lowest byte)
- 45) Power Meter Relative (Highest byte)⁵⁴⁰
- 46) Power Meter Relative
- 47) Power Meter Relative
- 48) Power Meter Relative (Lowest byte)
- 49) Not Used
- 50) Power Meter Unit (00h = Watts, 01h = dBm)
- 51) Power Meter Relative Status (00h = Off, 01h = On)
- 52) Power Meter Offset Status (00h = Off, 01h = On)
- 53) Power Meter RMS Averaging Level (00h = Off, 01h = Low, 02h = Medium, 03h = High)
- 54) Frequency Scale Factor⁵⁴¹ (Higher byte)
- 55) Frequency Scale Factor (Lower byte)
- 56) Frequency Range Minimum⁵⁴² (Highest byte)
- 57) Frequency Range Minimum
- 58) Frequency Range Minimum
- 59) Frequency Range Minimum (Lowest byte)
- 60) Frequency Range Maximum⁵⁴³ (Highest byte)
- 61) Frequency Range Maximum
- 62) Frequency Range Maximum
- 63) Frequency Range Maximum (Lowest byte)
- 64) Zero Status (00h = Off, 01h = On)
- 65) Zero Value⁵⁴⁴ (Highest byte)
- 66) Zero Value
- 67) Zero Value
- 68) Zero Value (Lowest byte)
- 69-120) Not Used

For T1 Mode (Option 50):

- 21) T1 Receive Input (00h = Terminate, 01h = Bridged, 02h = Monitor)
- 22) T1 Framing Mode (01h = ESF, 02h = D4SF)
- 23) T1 Line Coding (01h = B8ZS, 02h = AMI)
- 24) T1 Clock Source (00h = External, 01h = Internal)
- 25) T1 Tx Level (01h = 0 dB, 02h = -7.5 dB, 03h = -15 dB)
- 26) T1 Error Insert Type (00h = Frame Error, 01h = BPV, 02h = Bit Errors, 04h = RAI, 05h = AIS)
- 27) T1 Loop Code (00h = CSU, 01h = NIU, 02h = User 1, 03h = User 2)
- 28) T1 CRC Method (00h = ANSI CRC, 01h = Japanese CRC)
- 29) T1 Loop Type (00h = In Band, 01h = Data Link)
- 30) T1 Pattern (Higher byte)
- 31) T1 Pattern (Lower byte) (01h = PRBS-9, 02h = PRBS-11, 03h = PRBS-15, 04h = PRBS-20(O.151), 05h = PRBS-20(O.153), 06h = PRBS-23, 07h = QRSS, 08h = 1 in 8, 09h = 2 in 8, 0Ah = 3 in 8, 0Bh =

⁵³⁷ Index into Standard List (use control byte #89 to retrieve the ASCII string name). “No Standard” sent as FFFEh

⁵³⁸ “No Channel” is sent as FFFEh

⁵³⁹ Value sent as (value in dB * 1000)

⁵⁴⁰ Value sent as ((value in dBm * 1000) + 100)

⁵⁴¹ In number of Hz

⁵⁴² Scaled by Frequency Scale Factor

⁵⁴³ Scaled by Frequency Scale Factor

⁵⁴⁴ Value sent as ((value in dBm * 1000) + 100)

- All Ones, 0Ch = All Zeros, 0Dh = T1-DALY, 0Eh = User Defined)
- 32) T1 Pattern Invert Status (00h = Non-Inverted, 01h = Inverted)
 - 33) T1 Display Type (00h = Histogram, 01h = Raw Data)
 - 34) T1 Impedance
 - 35 - 50) First User Defined Loop Code Down (16 bytes)
 - 51 - 66) Second User Defined Loop Code Down (16 bytes)
 - 67 - 82) First User Defined Loop Code Up (16 bytes)
 - 83 - 98) Second User Defined Loop Code Up (16 bytes)
 - 99 - 130) User Defined Pattern (32 bytes)
 - 131) T1 1st User Defined Loop Up (Highest byte)
 - 132) T1 1st User Defined Loop Up (Lowest byte)
 - 133) T1 2nd User Defined Loop Up (Highest byte)
 - 134) T1 2nd User Defined Loop Up (Lowest byte)
 - 135) T1 1st User Defined Loop Down (Highest byte)
 - 136) T1 1st User Defined Loop Down (Lowest byte)
 - 137) T1 2nd User Defined Loop Down (Highest byte)
 - 138) T1 2nd User Defined Loop Down (Lowest byte)
 - 139) T1 User Defined Pattern (Highest byte)
 - 140) T1 User Defined Pattern
 - 141) T1 User Defined Pattern
 - 142) T1 User Defined Pattern (Lowest Byte)
 - 143) T1 Bit Error Insert Value (1-1000) (Highest byte)
 - 144) T1 Bit Error Insert Value (Lowest byte)
 - 145) T1 Frame Error Insert Value (1-1000) (Highest byte)
 - 146) T1 Frame Error Insert Value (Lowest byte)
 - 147) T1 BPV Error Insert Value (1-1000) (Highest byte)
 - 148) T1 BPV Error Insert Value (Lowest byte)
 - 149) T1 Graph Resolution⁵⁴⁵
 - 150) T1 Measurement Duration⁵⁴⁶
 - 151) T1 Voltage Measurement Scale (00h = Vpp, 01h = dBdsx)
 - 152) T1 Auto Framing Mode (00h = fixed framing, >00h = auto framing mode)
 - 153) T1 Auto Pattern Sync Status (00h = Off, 01h = On)
 - 154) Vpp Input Config (00h = Terminate, 01h = Bridged)
 - 155) Data Logging Status (00h = Off, 01h = On)
 - 156 – 250) Not Used

For E1 Mode (Option 50):

- 21) E1 Receive Input (00h = Terminate, 01h = Bridged, 02h = Monitor)
- 22) E1 Framing Mode (03h = PCM30, 04h = PCM30CRC, 05h = PCM31, 06h = PCM31CRC)
- 23) E1 Line Coding (02h = AMI, 03h = HDB3)
- 24) E1 Clock Source (00h = External, 01h = Internal)
- 25) E1 Tx Level
- 26) E1 Error Insert Type (00h = Frame Error, 01h = BPV, 02h = Bit Errors, 04h = RAI, 05h = AIS)
- 27) E1 Loop Code
- 28) E1 CRC Method
- 29) E1 Loop Type
- 30) E1 Pattern (Higher byte)
- 31) E1 Pattern (Lower byte) (01h = PRBS-9, 02h = PRBS-11, 03h = PRBS-15, 04h = PRBS-20(O.151), 05h = PRBS-20(O.153), 06h = PRBS-23, 07h = QRSS, 08h = 1 in 8, 09h = 2 in 8, 0Ah = 3 in 8, 0Bh = All Ones, 0Ch = All Zeros, 0Dh = T1-DALY, 0Eh = User Defined)
- 32) E1 Pattern Invert (00h = Non-Inverted, 01h = Inverted)

⁵⁴⁵ Graph Resolution: 00h: Auto, 01h: 1 sec, 02h: 15 sec, 03h: 30 sec, 04h 45 sec, 05h 1 min, 06h: 15 min, 07h: 30 min, 08h: 45 min, 09h: 60 min

⁵⁴⁶ Measurement Duration: 00h: Manual, 01h: 3 min, 02h: 15 min, 03h: 30 min, 04h: 1 hr, 05h: 3 hrs, 06h: 6 hrs, 07h: 12 hrs, 08h: 1 day, 09h: 2 days

- 33) E1 Display Type (00h = Histogram, 01h = Raw Data)
- 34) E1 Impedance (01h = 75 Ω, 02h = 120 Ω)
- 35 - 50) First User Defined Loop Code Down (16 bytes)
- 51 - 66) Second User Defined Loop Code Down (16 bytes)
- 67 - 82) First User Defined Loop Code Up (16 bytes)
- 83 - 98) Second User Defined Loop Code Up (16 bytes)
- 99 - 130) User Defined Pattern (32 bytes)
- 131) E1 1st User Defined Loop Up (Higher byte)
- 132) E1 1st User Defined Loop Up (Lower byte)
- 133) E1 2nd User Defined Loop Up (Higher byte)
- 134) E1 2nd User Defined Loop Up (Lower byte)
- 135) E1 1st User Defined Loop Down (Higher byte)
- 136) E1 1st User Defined Loop Down (Lower byte)
- 137) E1 2nd User Defined Loop Down (Higher byte)
- 138) E1 2nd User Defined Loop Down (Lower byte)
- 139) E1 User Defined Pattern (Highest byte)
- 140) E1 User Defined Pattern
- 141) E1 User Defined Pattern
- 142) E1 User Defined Pattern (Lowest byte)
- 143) E1 Bit Error Insert Value (1-1000) (Higher byte)
- 144) E1 Bit Error Insert Value (Lower byte)
- 145) E1 Frame Error Insert Value (1-1000) (Higher byte)
- 146) E1 Frame Error Insert Value (Lower byte)
- 147) E1 BPV Error Insert Value (1-1000) (Higher byte)
- 148) E1 BPV Error Insert Value (Lower byte)
- 149) E1 Graph Resolution⁵⁴⁷
- 150) E1 Measurement Duration⁵⁴⁸
- 151) E1 Voltage Measurement Scale (00h = Vpp, 01h = dBdsx)
- 152) E1 Auto Framing Mode (00h = fixed framing, >00h = auto framing mode)
- 153) E1 Auto Pattern Sync Status (00h = Off, 01h = On)
- 154) Vpp Input Config (00h = Terminate, 01h = Bridged)
- 155) Data Logging Status (00h = Off, 01h = On)
- 156) E1 Vpp Input Impedance (01h = 75 Ω, 02h = 120 Ω)
- 157-250) Not Used

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
- 224 (E0h) Parameter Error
- 238 (EEh) Time Out Error

Read Parameter Limits – Control Byte #67 (43h)

Description: Returns limits (minimum and maximum values) associated with each parameter defined for the specified measurement mode.

“Frequency Parameters (for SPA, TM and PM)” are start, stop, and center frequencies, multiple limit “x” parameters and AM/FM demod frequency parameters.

“Frequency Parameters (for VNA modes)” are start and stop frequencies and multiple limit “x” parameters.

“Distance Parameters” are start and stop distances, multiple limit “x” parameters and cable loss.

⁵⁴⁷ Graph Resolution: 00h: Auto, 01h: 1 sec, 02h: 15 sec, 03h: 30 sec, 04h 45 sec, 05h 1 min, 06h: 15 min, 07h: 30 min, 08h: 45 min, 09h: 60 min

⁵⁴⁸ Measurement Duration: 00h: Manual, 01h: 3 min, 02h: 15 min, 03h: 30 min, 04h: 1 hr, 05h: 3 hrs, 06h: 6 hrs, 07h: 12 hrs, 08h: 1 day, 09h: 2 days

Bytes to Follow: 2 bytes

- 1) Measurement Mode⁵⁴⁹
- 2) Limits to Read (00h = Frequency Parameter Limits (Spectrum Analyzer, Transmission Mode, Power Meter), 01h = Available RBWs, 02h = Available VBWs, 03h = Distance Parameter Limits (Metric Units, VNA DTF Modes) 04h = Distance Parameter Limits (English Units, VNA DTF Modes), FFh = All Other Parameter Limits)

Site Master Returns:

For All Modes:

- 1) Number of Following Bytes (Higher byte)
- 2) Number of Following Bytes (Lower byte)
- 3) Measurement Mode⁵⁵⁰
- 5-20) Not Used

For Spectrum Analyzer, Transmission (Option 21) and Power Meter (Option 29) Modes, Frequency Parameter Limits:

- 21) Number of Valid Frequency Ranges

For each range:

- 1) Range Scale Factor⁵⁵¹ (Higher byte)
- 2) Range Scale Factor (Lower byte)
- 3) Range Start Frequency⁵⁵² (Highest byte)
- 4) Range Start Frequency
- 5) Range Start Frequency
- 6) Range Start Frequency (Lowest byte)
- 7) Range Stop Frequency⁵⁵³ (Highest byte)
- 8) Range Stop Frequency
- 9) Range Stop Frequency
- 10) Range Stop Frequency (Lowest byte)

For Spectrum Analyzer, Transmission (Option 21) Modes, Available RBWS:

- 21) Number of Valid RBWs

For each RBW:

- 1) RBW Frequency (in Hz) (Highest byte)
- 2) RBW Frequency (in Hz)
- 3) RBW Frequency (in Hz)
- 4) RBW Frequency (in Hz) (Lowest byte)

For Spectrum Analyzer, Transmission (Option 21) Modes, Available VBWS:

- 21) Number of Valid VBWs

For each VBW:

- 1) VBW Frequency (in Hz) (Highest byte)
- 2) VBW Frequency (in Hz)
- 3) VBW Frequency (in Hz)
- 4) VBW Frequency (in Hz) (Lowest byte)

For VNA Modes, Distance Parameter Limits, in Metric Units:

⁵⁴⁹ Refer to Control Byte #3 “Select Measurement Mode” for valid measurement modes.

⁵⁵⁰ Refer to Control Byte #3 “Select Measurement Mode” for valid measurement modes.

⁵⁵¹ Scale Factor in number of Hz

⁵⁵² Scaled by Span Scale Factor

⁵⁵³ Scaled by Span Scale Factor

- 21) Distance Minimum⁵⁵⁴ (Highest byte)
- 22) Distance Minimum
- 23) Distance Minimum
- 24) Distance Minimum (Lowest byte)
- 25) Distance Maximum⁵⁵⁵ (Highest byte)
- 26) Distance Maximum
- 27) Distance Maximum
- 28) Distance Maximum (Lowest byte)
- 29) Cable Loss Minimum⁵⁵⁶ (Highest byte)
- 30) Cable Loss Minimum
- 31) Cable Loss Minimum
- 32) Cable Loss Minimum (Lowest byte)
- 33) Cable Loss Maximum⁵⁵⁷ (Highest byte)
- 34) Cable Loss Maximum
- 35) Cable Loss Maximum
- 36) Cable Loss Maximum (Lowest byte)

For VNA Modes, Distance Parameter Limits, in English Units:

- 21) Distance Minimum⁵⁵⁸ (Highest byte)
- 22) Distance Minimum
- 23) Distance Minimum
- 24) Distance Minimum (Lowest byte)
- 25) Distance Maximum⁵⁵⁹ (Highest byte)
- 26) Distance Maximum
- 27) Distance Maximum
- 28) Distance Maximum (Lowest byte)
- 29) Cable Loss Minimum⁵⁶⁰ (Highest byte)
- 30) Cable Loss Minimum
- 31) Cable Loss Minimum
- 32) Cable Loss Minimum (Lowest byte)
- 33) Cable Loss Maximum⁵⁶¹ (Highest byte)
- 34) Cable Loss Maximum
- 35) Cable Loss Maximum
- 36) Cable Loss Maximum (Lowest byte)

For VNA Modes, All Other Parameter Limits:

- 21) Frequency Minimum⁵⁶² (Highest byte)
- 22) Frequency Minimum
- 23) Frequency Minimum
- 24) Frequency Minimum (Lowest byte)
- 25) Frequency Maximum⁵⁶³ (Highest byte)
- 26) Frequency Maximum
- 27) Frequency Maximum
- 28) Frequency Maximum (Lowest byte)
- 29) Return Loss Scale/Limit Y Minimum⁵⁶⁴ (Highest byte)

⁵⁵⁴ Distance sent as (distance in meters * 100,000)

⁵⁵⁵ Distance sent as (distance in meters * 100,000)

⁵⁵⁶ Cable loss sent as (loss in dB/m * 100,000)

⁵⁵⁷ Cable loss sent as (loss in dB/m * 100,000)

⁵⁵⁸ Distance sent as (distance in feet * 100,000)

⁵⁵⁹ Distance sent as (distance in feet * 100,000)

⁵⁶⁰ Cable loss sent as (loss in dB/ft * 100,000)

⁵⁶¹ Cable loss sent as (loss in dB/ft * 100,000)

⁵⁶² Frequency is scaled by the frequency scale factor specified in bytes 69-70.

⁵⁶³ Frequency is scaled by the frequency scale factor specified in bytes 69-70.

- 30) Return Loss Scale/Limit Y Minimum
- 31) Return Loss Scale/Limit Y Minimum
- 32) Return Loss Scale/Limit Y Minimum (Lowest byte)
- 33) Return Loss Scale/Limit Y Maximum⁵⁶⁵ (Highest byte)
- 34) Return Loss Scale/Limit Y Maximum
- 35) Return Loss Scale/Limit Y Maximum
- 36) Return Loss Scale/Limit Y Maximum (Lowest byte)
- 37) Cable Loss Scale/Limit Y Minimum⁵⁶⁶ (Highest byte)
- 38) Cable Loss Scale/Limit Y Minimum
- 39) Cable Loss Scale/Limit Y Minimum
- 40) Cable Loss Scale/Limit Y Minimum (Lowest byte)
- 41) Cable Loss Scale/Limit Y Maximum⁵⁶⁷ (Highest byte)
- 42) Cable Loss Scale/Limit Y Maximum
- 43) Cable Loss Scale/Limit Y Maximum
- 44) Cable Loss Scale/Limit Y Maximum (Lowest byte)
- 45) SWR Scale/Limit Y Minimum⁵⁶⁸ (Highest byte)
- 46) SWR Scale/Limit Y Minimum
- 47) SWR Scale/Limit Y Minimum
- 48) SWR Scale/Limit Y Minimum (Lowest byte)
- 49) SWR Scale/Limit Y Maximum⁵⁶⁹ (Highest byte)
- 50) SWR Scale/Limit Y Maximum
- 51) SWR Scale/Limit Y Maximum
- 52) SWR Scale/Limit Y Maximum (Lowest byte)
- 53) Marker Minimum⁵⁷⁰ (Higher byte)
- 54) Marker Minimum (Lower byte)
- 55) Marker Maximum⁵⁷¹ (Higher byte)
- 56) Marker Minimum (Lower byte)
- 57) Propagation Velocity Minimum (Highest byte)
- 58) Propagation Velocity Minimum
- 59) Propagation Velocity Minimum
- 60) Propagation Velocity Minimum (Lowest byte)
- 61) Propagation Velocity Maximum⁵⁷² (Highest byte)
- 62) Propagation Velocity Maximum
- 63) Propagation Velocity Maximum
- 64) Propagation Velocity Maximum (Lowest byte)
- 65) Cable Folder Minimum
- 66) Cable Folder Maximum
- 67) Trace Overlay Index Minimum
- 68) Trace Overlay Index Maximum
- 69) Frequency Scale Factor⁵⁷³ (Higher byte)
- 70) Frequency Scale Factor (Lower byte)
- 71-200) Not Used

⁵⁶⁴ Scale sent in (dB * 1000)

⁵⁶⁵ Scale sent in (dB * 1000)

⁵⁶⁶ Scale sent in (dB * 1000)

⁵⁶⁷ Scale sent in (dB * 1000)

⁵⁶⁸ Scale sent in (ratio * 1000)

⁵⁶⁹ Scale sent in (ratio * 1000)

⁵⁷⁰ Value sent as data point on the display. Equivalent frequency (or distance) = (# data points - 1) * (marker X - start X) / (stop X - start X)

⁵⁷¹ Value sent as data point on the display. Equivalent frequency (or distance) = (# data points - 1) * (marker X - start X) / (stop X - start X)

⁵⁷² Propagation velocity sent as (velocity * 100,000)

⁵⁷³ Frequency Scale Factor is in number of Hz.

For T1 Mode (Option 50), All Other Parameter Limits:

- 21) Receive Input Minimum
- 22) Receive Input Maximum
- 23) Framing Mode Minimum
- 24) Framing Mode Maximum
- 25) Line Coding Minimum
- 26) Line Coding Maximum
- 27) Clock Source Minimum
- 28) Clock Source Maximum
- 29) Tx Level Minimum
- 30) Tx Level Maximum
- 31) Error Insert Type Minimum
- 32) Error Insert Type Maximum
- 33) Loop Code Minimum
- 34) Loop Code Maximum
- 35) CRC Method Minimum
- 36) CRC Method Maximum
- 37) Loop Type Minimum
- 38) Loop Type Maximum
- 39) Pattern Minimum
- 40) Pattern Maximum
- 41) Display Type Minimum
- 42) Display Type Maximum
- 43) Bit Error Insert Value Minimum (Higher byte)
- 44) Bit Error Insert Value Minimum (Lower byte)
- 45) Bit Error Insert Value Maximum (Higher byte)
- 46) Bit Error Insert Value Maximum (Lower byte)
- 47) Frame Error Insert Value Minimum (Higher byte)
- 48) Frame Error Insert Value Minimum (Lower byte)
- 49) Frame Error Insert Value Maximum (Higher byte)
- 50) Frame Error Insert Value Maximum (Lower byte)
- 51) BPV Error Insert Value Minimum (Higher byte)
- 52) BPV Error Insert Value Minimum (Lower byte)
- 53) BPV Error Insert Value Maximum (Higher byte)
- 54) BPV Error Insert Value Maximum (Lower byte)
- 55) Graph Resolution Minimum
- 56) Graph Resolution Maximum
- 57) Measurement Duration Minimum
- 58) Measurement Duration Maximum
- 59) Voltage Scale Minimum
- 60) Voltage Scale Maximum
- 61) Vpp Input Config Minimum
- 62) Vpp Input Config Maximum
- 63-150) Not Used

For E1 Mode (Option 50), All Other Parameter Limits:

- 21) Receive Input Minimum
- 22) Receive Input Maximum
- 23) Framing Mode Minimum
- 24) Framing Mode Maximum
- 25) Line Coding Minimum
- 26) Line Coding Maximum
- 27) Clock Source Minimum
- 28) Clock Source Maximum
- 29) Tx Level Minimum
- 30) Tx Level Maximum

- 31) Error Insert Type Minimum
- 32) Error Insert Type Maximum
- 33) Loop Code Minimum
- 34) Loop Code Maximum
- 35) CRC Method Minimum
- 36) CRC Method Maximum
- 37) Loop Type Minimum
- 38) Loop Type Maximum
- 39) Pattern Minimum
- 40) Pattern Maximum
- 41) Display Type Minimum
- 42) Display Type Maximum
- 43) Bit Error Insert Value Minimum (Higher byte)
- 44) Bit Error Insert Value Minimum (Lower byte)
- 45) Bit Error Insert Value Maximum (Higher byte)
- 46) Bit Error Insert Value Maximum (Lower byte)
- 47) Frame Error Insert Value Minimum (Higher byte)
- 48) Frame Error Insert Value Minimum (Lower byte)
- 49) Frame Error Insert Value Maximum (Higher byte)
- 50) Frame Error Insert Value Maximum (Lower byte)
- 51) BPV Error Insert Value Minimum (Higher byte)
- 52) BPV Error Insert Value Minimum (Lower byte)
- 53) BPV Error Insert Value Maximum (Higher byte)
- 54) BPV Error Insert Value Maximum (Lower byte)
- 55) Graph Resolution Minimum
- 56) Graph Resolution Maximum
- 57) Measurement Duration Minimum
- 58) Measurement Duration Maximum
- 59) Voltage Scale Minimum
- 60) Voltage Scale Maximum
- 61) Vpp Input Config Minimum
- 62) Vpp Input Config Maximum
- 63) Impedance Minimum
- 64) Impedance Maximum
- 65-150) Not Used

For Spectrum Analyzer Mode, All Other Parameter Limits:

- 21) Frequency Scale Factor Minimum⁵⁷⁴ (Higher byte)
- 22) Frequency Scale Factor Minimum (Lower byte)
- 23) Frequency Scale Factor Maximum⁵⁷⁵ (Higher byte)
- 24) Frequency Scale Factor Maximum (Lower byte)
- 25) Span Minimum⁵⁷⁶ (Highest byte)
- 26) Span Minimum
- 27) Span Minimum
- 28) Span Minimum (Lowest byte)
- 29) Span Maximum⁵⁷⁷ (Highest byte)
- 30) Span Maximum
- 31) Span Maximum
- 32) Span Maximum (Lowest byte)
- 33) Reference Level Minimum⁵⁷⁸ (Highest byte)

⁵⁷⁴ Scale Factor in number of Hz

⁵⁷⁵ Scale Factor in number of Hz

⁵⁷⁶ Scaled by Span Scale Factor

⁵⁷⁷ Scaled by Span Scale Factor

⁵⁷⁸ Value sent as (value * 1000) + 270,000

- 34) Reference Level Minimum
- 35) Reference Level Minimum
- 36) Reference Level Minimum (Lowest byte)
- 37) Reference Level Maximum⁵⁷⁹ (Highest byte)
- 38) Reference Level Maximum
- 39) Reference Level Maximum
- 40) Reference Level Maximum (Lowest byte)
- 41) Scale Minimum⁵⁸⁰ (Highest byte)
- 42) Scale Minimum
- 43) Scale Minimum
- 44) Scale Minimum (Lowest byte)
- 45) Scale Maximum⁵⁸¹ (Highest byte)
- 46) Scale Maximum
- 47) Scale Maximum
- 48) Scale Maximum (Lowest byte)
- 49) Marker Minimum⁵⁸² (Higher byte)
- 50) Marker Minimum (Lower byte)
- 51) Marker Maximum⁵⁸³ (Higher byte)
- 52) Marker Maximum (Lower byte)
- 53) Limit Y Minimum⁵⁸⁴ (Highest byte)
- 54) Limit Y Minimum
- 55) Limit Y Minimum
- 56) Limit Y Minimum (Lowest byte)
- 57) Limit Y Maximum⁵⁸⁵ (Highest byte)
- 58) Limit Y Maximum
- 59) Limit Y Maximum
- 60) Limit Y Maximum (Lowest byte)
- 61) OBW Method Minimum
- 62) OBW Method Maximum
- 63) OBW % of Power Minimum
- 64) OBW % of Power Maximum
- 65) OBW dBc Minimum
- 66) OBW dBc Maximum
- 67) Attenuation Minimum
- 68) Attenuation Maximum
- 69) Amplitude Units Minimum
- 70) Amplitude Units Maximum
- 71) Detection Algorithm Minimum
- 72) Detection Algorithm Maximum
- 73) RL Offset Minimum⁵⁸⁶ (Highest byte)
- 74) RL Offset Minimum
- 75) RL Offset Minimum
- 76) RL Offset Minimum (Lowest byte)
- 77) RL Offset Maximum⁵⁸⁷ (Highest byte)

⁵⁷⁹ Value sent as (value * 1000) + 270,000

⁵⁸⁰ Value sent as (value * 1000)

⁵⁸¹ Value sent as (value * 1000)

⁵⁸² Value sent as data point on the display. Equivalent frequency = (point * span / (# data points - 1)) + start frequency.

⁵⁸³ Value sent as data point on the display. Equivalent frequency = (point * span / (# data points - 1)) + start frequency.

⁵⁸⁴ Value sent as (value * 1000) + 270,000

⁵⁸⁵ Value sent as (value * 1000) + 270,000

⁵⁸⁶ Value sent as (value * 1000) + 270,000

⁵⁸⁷ Value sent as (value * 1000) + 270,000

- 78) RL Offset Maximum
- 79) RL Offset Maximum
- 80) RL Offset Maximum (Lowest byte)
- 81) External Reference Frequency Minimum⁵⁸⁸ (Highest byte)
- 82) External Reference Frequency Minimum
- 83) External Reference Frequency Minimum
- 84) External Reference Frequency Minimum (Lowest byte)
- 85) External Reference Frequency Maximum⁵⁸⁹ (Highest byte)
- 86) External Reference Frequency Maximum
- 87) External Reference Frequency Maximum
- 88) External Reference Frequency Maximum (Lowest byte)
- 89) Trigger Type Minimum
- 90) Trigger Type Maximum
- 91) Minimum Sweep Type (in μ s) Minimum (Highest byte)
- 92) Minimum Sweep Type (in μ s) Minimum
- 93) Minimum Sweep Type (in μ s) Minimum
- 94) Minimum Sweep Type (in μ s) Minimum (Lowest byte)
- 95) Minimum Sweep Type (in μ s) Maximum (Highest byte)
- 96) Minimum Sweep Type (in μ s) Maximum
- 97) Minimum Sweep Type (in μ s) Maximum
- 98) Minimum Sweep Type (in μ s) Maximum (Lowest byte)
- 99) Video Trigger Level Minimum⁵⁹⁰ (Highest byte)
- 100) Video Trigger Level Minimum
- 101) Video Trigger Level Minimum
- 102) Video Trigger Level Minimum (Lowest byte)
- 103) Video Trigger Level Maximum⁵⁹¹ (Highest byte)
- 104) Video Trigger Level Maximum
- 105) Video Trigger Level Maximum
- 106) Video Trigger Level Maximum (Lowest byte)
- 107) Sweep Average Minimum
- 108) Sweep Average Maximum
- 109) Trace Math Minimum
- 110) Trace Math Maximum
- 111) Impedance Loss Minimum⁵⁹² (Highest byte)
- 112) Impedance Loss Minimum
- 113) Impedance Loss Minimum
- 114) Impedance Loss Minimum (Lowest byte)
- 115) Impedance Loss Maximum⁵⁹³ (Highest byte)
- 116) Impedance Loss Maximum
- 117) Impedance Loss Maximum
- 118) Impedance Loss Maximum (Lowest byte)
- 119) Demod Type Minimum
- 120) Demod Type Maximum
- 121) Demod Volume Minimum
- 122) Demod Volume Maximum
- 123) Demod Time Minimum (in ms) (Highest byte)
- 124) Demod Time Minimum (in ms)
- 125) Demod Time Minimum (in ms)
- 126) Demod Time Minimum (in ms) (Lowest byte)

⁵⁸⁸ Reference frequency in Hz

⁵⁸⁹ Reference frequency in Hz

⁵⁹⁰ Value sent as (value * 1000) + 270,000

⁵⁹¹ Value sent as (value * 1000) + 270,000

⁵⁹² Value sent as (value in dB * 1000)

⁵⁹³ Value sent as (value in dB * 1000)

- 127) Demod Time Maximum (in ms) (Highest byte)
- 128) Demod Time Maximum (in ms)
- 129) Demod Time Maximum (in ms)
- 130) Demod Time Maximum (in ms) (Lowest byte)
- 131) SSB BFO Offset Minimum⁵⁹⁴ (Highest byte)
- 132) SSB BFO Offset Minimum
- 133) SSB BFO Offset Minimum
- 134) SSB BFO Offset Minimum (Lowest byte)
- 135) SSB BFO Offset Maximum⁵⁹⁵ (Highest byte)
- 136) SSB BFO Offset Maximum
- 137) SSB BFO Offset Maximum
- 138) SSB BFO Offset Maximum (Lowest byte)
- 139) ACPR Main Channel BW Minimum (in Hz) (Highest byte)
- 140) ACPR Main Channel BW Minimum (in Hz)
- 141) ACPR Main Channel BW Minimum (in Hz)
- 142) ACPR Main Channel BW Minimum (in Hz) (Lowest byte)
- 143) ACPR Main Channel BW Maximum (in Hz) (Highest byte)
- 144) ACPR Main Channel BW Maximum (in Hz)
- 145) ACPR Main Channel BW Maximum (in Hz)
- 146) ACPR Main Channel BW Maximum (in Hz) (Lowest byte)
- 147) ACPR Adjacent Channel BW Minimum (in Hz) (Highest byte)
- 148) ACPR Adjacent Channel BW Minimum (in Hz)
- 149) ACPR Adjacent Channel BW Minimum (in Hz)
- 150) ACPR Adjacent Channel BW Minimum (in Hz) (Lowest byte)
- 151) ACPR Adjacent Channel BW Maximum (in Hz) (Highest byte)
- 152) ACPR Adjacent Channel BW Maximum (in Hz)
- 153) ACPR Adjacent Channel BW Maximum (in Hz)
- 154) ACPR Adjacent Channel BW Maximum (in Hz) (Lowest byte)
- 155) ACPR Channel Spacing Minimum (in Hz) (Highest byte)
- 156) ACPR Channel Spacing Minimum (in Hz)
- 157) ACPR Channel Spacing Minimum (in Hz)
- 158) ACPR Channel Spacing Minimum (in Hz) (Lowest byte)
- 159) ACPR Channel Spacing Maximum (in Hz) (Highest byte)
- 160) ACPR Channel Spacing Maximum (in Hz)
- 161) ACPR Channel Spacing Maximum (in Hz)
- 162) ACPR Channel Spacing Maximum (in Hz) (Lowest byte)
- 163) Channel Power Integration BW Minimum (in Hz) (Highest byte)
- 164) Channel Power Integration BW Minimum (in Hz)
- 165) Channel Power Integration BW Minimum (in Hz)
- 166) Channel Power Integration BW Minimum (in Hz) (Lowest byte)
- 167) Channel Power Integration BW Maximum (in Hz) (Highest byte)
- 168) Channel Power Integration BW Maximum (in Hz)
- 169) Channel Power Integration BW Maximum (in Hz)
- 170) Channel Power Integration BW Maximum (in Hz) (Lowest byte)
- 171-300) Not Used

For Transmission Measurement Mode (Option 21 Only), All Other Parameter Limits:

- 21) Span Scale Factor Minimum⁵⁹⁶ (Higher byte)
- 22) Span Scale Factor Minimum (Lower byte)
- 23) Span Scale Factor Maximum⁵⁹⁷ (Higher byte)
- 24) Span Scale Factor Maximum (Lower byte)

⁵⁹⁴ Value sent as ((value in Hz) – 10,000)

⁵⁹⁵ Value sent as ((value in Hz) – 10,000)

⁵⁹⁶ Scale Factor in number of Hz

⁵⁹⁷ Scale Factor in number of Hz

- 25) Span Minimum⁵⁹⁸ (Highest byte)
- 26) Span Minimum
- 27) Span Minimum
- 28) Span Minimum (Lowest byte)
- 29) Span Maximum⁵⁹⁹ (Highest byte)
- 30) Span Maximum
- 31) Span Maximum
- 32) Span Maximum (Lowest byte)
- 33) Reference Level Minimum⁶⁰⁰ (Highest byte)
- 34) Reference Level Minimum
- 35) Reference Level Minimum
- 36) Reference Level Minimum (Lowest byte)
- 37) Reference Level Maximum⁶⁰¹ (Highest byte)
- 38) Reference Level Maximum
- 39) Reference Level Maximum
- 40) Reference Level Maximum (Lowest byte)
- 41) Scale Minimum⁶⁰² (Highest byte)
- 42) Scale Minimum
- 43) Scale Minimum
- 44) Scale Minimum (Lowest byte)
- 45) Scale Maximum⁶⁰³ (Highest byte)
- 46) Scale Maximum
- 47) Scale Maximum
- 48) Scale Maximum (Lowest byte)
- 49) Marker Minimum⁶⁰⁴ (Higher byte)
- 50) Marker Minimum (Lower byte)
- 51) Marker Maximum⁶⁰⁵ (Higher byte)
- 52) Marker Maximum (Lower byte)
- 53) Limit Y Minimum⁶⁰⁶ (Highest byte)
- 54) Limit Y Minimum
- 55) Limit Y Minimum
- 56) Limit Y Minimum (Lowest byte)
- 57) Limit Y Maximum⁶⁰⁷ (Highest byte)
- 58) Limit Y Maximum
- 59) Limit Y Maximum
- 60) Limit Y Maximum (Lowest byte)
- 61) Attenuation Minimum
- 62) Attenuation Maximum
- 63) Amplitude Units Minimum
- 64) Amplitude Units Maximum
- 65) Detection Algorithm Minimum
- 66) Detection Algorithm Maximum
- 67) External Reference Frequency Minimum⁶⁰⁸ (Highest byte)

⁵⁹⁸ Scaled by Span Scale Factor

⁵⁹⁹ Scaled by Span Scale Factor

⁶⁰⁰ Value sent as (value * 1000) + 270,000

⁶⁰¹ Value sent as (value * 1000) + 270,000

⁶⁰² Value sent as (value * 1000)

⁶⁰³ Value sent as (value * 1000)

⁶⁰⁴ Value sent as data point on the display. Equivalent frequency = (point * span / (# data points - 1)) + start frequency.

⁶⁰⁵ Value sent as data point on the display. Equivalent frequency = (point * span / (# data points - 1)) + start frequency.

⁶⁰⁶ Value sent as (value * 1000) + 270,000

⁶⁰⁷ Value sent as (value * 1000) + 270,000

- 68) External Reference Frequency Minimum
- 69) External Reference Frequency Minimum
- 70) External Reference Frequency Minimum (Lowest byte)
- 71) External Reference Frequency Maximum⁶⁰⁹ (Highest byte)
- 72) External Reference Frequency Maximum
- 73) External Reference Frequency Maximum
- 74) External Reference Frequency Maximum (Lowest byte)
- 75) Trigger Type Minimum
- 76) Trigger Type Maximum
- 77) Sweep Average Minimum
- 78) Sweep Average Maximum
- 79) Trace Math Minimum
- 80) Trace Math Maximum
- 81-200) Not Used

For Power Meter Mode (Option 29 Only), All Other Parameter Limits:

- 21) Span Scale Factor Minimum⁶¹⁰ (Higher byte)
- 22) Span Scale Factor Minimum (Lower byte)
- 23) Span Scale Factor Maximum⁶¹¹ (Higher byte)
- 24) Span Scale Factor Maximum (Lower byte)
- 25) Span Minimum⁶¹² (Highest byte)
- 26) Span Minimum
- 27) Span Minimum
- 28) Span Minimum (Lowest byte)
- 29) Span Maximum⁶¹³ (Highest byte)
- 30) Span Maximum
- 31) Span Maximum
- 32) Span Maximum (Lowest byte)
- 33) Power Meter Offset Minimum (Highest byte)
- 34) Power Meter Offset Minimum
- 35) Power Meter Offset Minimum
- 36) Power Meter Offset Minimum (Lowest byte)
- 37) Power Meter Offset Maximum (Highest byte)
- 38) Power Meter Offset Maximum
- 39) Power Meter Offset Maximum
- 40) Power Meter Offset Maximum (Lowest byte)
- 41) Power Meter Relative Minimum⁶¹⁴ (Highest byte)
- 42) Power Meter Relative Minimum
- 43) Power Meter Relative Minimum
- 44) Power Meter Relative Minimum (Lowest byte)
- 45) Power Meter Relative Maximum⁶¹⁵ (Highest byte)
- 46) Power Meter Relative Maximum
- 47) Power Meter Relative Maximum
- 48) Power Meter Relative Maximum (Lowest byte)
- 49-150) Not Used

⁶⁰⁸ Reference frequency in MHz

⁶⁰⁹ Reference frequency in MHz

⁶¹⁰ Scale Factor in number of Hz

⁶¹¹ Scale Factor in number of Hz

⁶¹² Scaled by Span Scale Factor

⁶¹³ Scaled by Span Scale Factor

⁶¹⁴ Value sent as ((value in dBm + 100) * 1000)

⁶¹⁵ Value sent as ((value in dBm + 100) * 1000)

Query Saved Setups – Control Byte #68 (44h)

Description: Returns a list of setups saved for the specified measurement mode. Modes that are stored in the same table (i.e. Spectrum Analyzer and Transmission Measurement modes or RL, CL and SWR modes) will be returned by this command when any of the modes in that list are specified.

Bytes to Follow: 1 byte

- 1) Measurement Mode⁶¹⁶

Site Master Returns:

For All Modes:

- 1) Number of Following Bytes (Higher byte)
- 2) Number of Following Bytes (Lower byte)
- 3) Number of Setups

For Each Setup, VNA Modes – Frequency Domain:

- 1) Setup Number
- 2) Attributes
bit 0: Read Only Status (00h = Write-able, 01h = Read Only)
bits 1-7: Not Used
- 3) Measurement Mode⁶¹⁷
- 4) Cal Status⁶¹⁸
- 5) Frequency Scale Factor⁶¹⁹ (Higher byte)
- 6) Frequency Scale Factor (Lower byte)
- 7) Start Frequency⁶²⁰ (Highest byte)
- 8) Start Frequency
- 9) Start Frequency
- 10) Start Frequency (Lowest byte)
- 11) Stop Frequency⁶²¹ (Highest byte)
- 12) Stop Frequency
- 13) Stop Frequency
- 14) Stop Frequency (Lowest byte)
- 15-20) Not Used

For Each Setup, VNA Modes – Time Domain (i.e. DTF):

- 1) Setup Number
- 2) Attributes
bit 0: Read Only Status (00h = Write-able, 01h = Read Only)
bits 1-7: Not Used
- 3) Measurement Mode⁶²²
- 4) Cal Status⁶²³
- 5) Not Used
- 6) Measurement Units (00h = Feet, 01h = Meters)
- 7) Start Distance⁶²⁴ (Highest byte)
- 8) Start Distance
- 9) Start Distance

⁶¹⁶ Refer to Control Byte #3 “Select Measurement Mode” for valid measurement modes.

⁶¹⁷ Refer to Control Byte #3 “Select Measurement Mode” for valid measurement modes.

⁶¹⁸ 00h = Cal Off, 01h = OSL Cal On, 02h = OSL InstaCal On, 03h = FlexCal On, 04h = FlexCal InstaCal On

⁶¹⁹ Frequency Scale Factor is in number of Hz

⁶²⁰ Frequency is scaled by the frequency scale factor specified in bytes 5-6.

⁶²¹ Frequency is scaled by the frequency scale factor specified in bytes 5-6.

⁶²² Refer to Control Byte #3 “Select Measurement Mode” for valid measurement modes.

⁶²³ 00h = Cal Off, 01h = OSL Cal On, 02h = OSL InstaCal On, 03h = FlexCal On, 04h = FlexCal InstaCal On

⁶²⁴ Distance sent as (distance * 100,000) where “distance” is in the units specified in byte 6.

- 10) Start Distance (Lowest byte)
- 11) Stop Distance⁶²⁵ (Highest byte)
- 12) Stop Distance
- 13) Stop Distance
- 14) Stop Distance (Lowest byte)
- 15-20) Not Used

For Each Setup, Spectrum Analyzer, Transmission Mode, Power Meter Modes:

- 1) Setup Number
- 2) Attributes
 - bit 0: Read Only Status (00h = Write-able, 01h = Read Only)
 - bits 1-7: Not Used
- 3) Measurement Mode⁶²⁶
- 4) Cal Status (Transmission Mode Setup Only, 00h = Off, 01h = On)
- 5) Frequency Scale Factor⁶²⁷ (Higher byte)
- 6) Frequency Scale Factor (Lower byte)
- 7) Start Frequency⁶²⁸ (Highest byte)
- 8) Start Frequency
- 9) Start Frequency
- 10) Start Frequency (Lowest byte)
- 11) Stop Frequency⁶²⁹ (Highest byte)
- 12) Stop Frequency
- 13) Stop Frequency
- 14) Stop Frequency (Lowest byte)
- 15-20) Not Used

For Each Setup, T1 and E1 Modes:

- 1) Setup Number
- 2) Attributes
 - bit 0: Read Only Status (00h = Write-able, 01h = Read Only)
 - bits 1-7: Not Used
- 3) Measurement Mode⁶³⁰
- 4) Framing Mode⁶³¹
- 5) Pattern⁶³²
- 6) Pattern Invert Status (00h = Not Inverted, 01h = Inverted)
- 7-20) Not Used

Enter Remote Mode – Control Byte #69 (45h)

Description: Enter remote mode at the end of a sweep then send model number and firmware version to the computer.

The computer sends Enter Remote mode byte #69 (45h) to the Site Master and waits for response.

⁶²⁵ Distance sent as (distance * 100,000) where “distance” is in the units specified in byte 6.

⁶²⁶ Refer to Control Byte #3 “Select Measurement Mode” for valid measurement modes.

⁶²⁷ Frequency Scale Factor is in number of Hz

⁶²⁸ Frequency is scaled by the frequency scale factor specified in bytes 5-6.

⁶²⁹ Frequency is scaled by the frequency scale factor specified in bytes 5-6.

⁶³⁰ Refer to Control Byte #3 “Select Measurement Mode” for valid measurement modes.

⁶³¹ 01h = ESF (T1), 02h = D4SF (T1),

03h = PCM30 (E1), 04h = PCM30CRC (E1), 05h = PCM31 (E1), 06h = PCM31CRC (E1)

⁶³² 01h = PRBS-9, 02h = PRBS-11, 03h = PRBS-15, 04h = PRBS-20(O.151), 05h = PRBS-20(O.153), 06h = PRBS-23, 07h = QRSS, 08h = 1 in 8, 09h = 2 in 8, 0Ah = 3 in 8, 0Bh = All Ones, 0Ch = All Zeros, 0Dh = T1-DALY, 0Eh = User Defined

Since the Site Master polls its serial port buffer at the end of each sweep, the computer must wait until the Site Master sends the return bytes before sending a new control byte. Otherwise, the new control byte overwrites the old one (saying enter remote) and the Site Master does not respond as expected.

Once in remote mode, the Site Master stops sweeping. A Remote Mode Indicator appears on the LCD.

The Site Master sends its model and software version numbers to the computer. The Site Master is now able to take multiple control bytes. It waits for the next control byte.

Bytes to Follow: 0 bytes

Site Master Returns: 13 bytes

- 1-2) Model # (unsigned integer, 14h for Site Master S331D, 15h for S332D)
 - 3-9) Extended Model # (7 bytes in ASCII)
 - 10-13) Software Version - 4 bytes (ASCII)
-

Enter Remote Mode Immediately – Control Byte #70 (46h)

Description: Enter remote mode in the middle of a sweep, then send the model number and firmware version to the computer.

The computer sends Enter Remote Mode Immediately byte #70 (46h) to the Site Master and waits for a response. This control byte causes the unit to enter remote mode immediately. Note that this could result in incomplete sweep data. Use control byte #69 if complete data is required.

Once in remote mode, the Site Master stops sweeping. A Remote Mode Indicator appears on the LCD.

The Site Master sends its model and software version numbers to the computer. The Site Master is now able to take multiple control bytes. It waits for the next control byte.

Bytes to Follow: 0 bytes

Site Master Returns: 13 bytes

- 1-2) Model # (unsigned integer, 14h for Site Master S331D, 15h for S332D)
 - 3-9) Extended Model # (7 bytes in ASCII)
 - 10-13) Software Version (4 bytes in ASCII)
-

Write Protect Setup – Control Byte #71 (47h)

Description: Makes a saved setup either read-only or write-able.

Setup numbers as follows:

- 255 = All Setups in the Specified Mode
- 1 – 10 = Saved setups for Spectrum Analyzer/Transmission Measurement modes
- 1 – 5 = Saved setups for Power Meter mode (Option 29 Only)

Bytes to Follow: 3 bytes

- 1) Measurement Mode⁶³³
- 2) Setup Number
- 3) Write-Protect Status (00h = Allow Writes (default), 01h = Lock Setup (i.e. “read only”))

Spectrum Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error
 - 238 (EEh) Time Out Error
-

⁶³³ Refer to Control Byte #3 “Select Measurement Mode” for valid measurement modes.

Clear Setup Memory Location – Control Byte #72 (48h)

Description: Clears a setup memory location such that it appears as “<EMPTY>” in the Recall Setup list.

Setup numbers as follows:

- 255 = All Setups in the Specified Mode
- 1 – 10 = Saved setups for Spectrum Analyzer/Transmission Measurement modes
- 1 – 5 = Saved setups for Power Meter mode (Option 29 Only)

Bytes to Follow: 2 bytes

- 1) Measurement Mode⁶³⁴
- 2) Setup Number

Spectrum Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error
 - 238 (EEh) Time Out Error
-

Write Signal Standards – Control Byte #78 (4Eh)

Description: Write user-defined signal standards to the unit.

Bytes to Follow: Variable bytes

- 1-2) Version # (integer, e.g. 100 for 1.00)
- 3-4) Total number of records in this package (Maximum 200)
(1st record)
- 5) Type of record (bit7: selected in SPA mode; bit6: selected in VNA mode; bit1: CDMA std; bit2: GSM std; Others are reserved)
- 6) # of sub-band (When the standard includes multiple sub-bands)
- 7-30) Name of Standard (ASCII 24 bytes)
- 31-34) Uplink Frequency (integer)
- 35-38) Downlink Frequency (integer)
- 39-40) Start Ch# (integer)
- 41-42) Stop Ch# (integer)
- 43-46) Channel occupied band width (integer)
- 47-50) Channel spacing (integer)
- 51-52) Channel step (integer)
(2nd record)
- 53-100) Repeat from 5 to 52
... ..

Cell Master Returns: 1 byte

- 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error
 - 238 (EEh) Time Out Error
-

⁶³⁴ Refer to Control Byte #3 “Select Measurement Mode” for valid measurement modes.

Recall Signal Standards – Control Byte #79 (4Fh)

Description: Download signal standards to PC.

Bytes to Follow: 0 byte

Cell Master Returns:

Command received correctly : Variable bytes

- 1-2) Version # (integer, e.g. 100 for 1.00)
- 3-4) Total number of records in this package (Maximum 200)
(1st record)
- 5-6) Type of record
- 7-30) Name of Standard (ASCII 24 bytes)
- 31-34) Start Frequency (integer)
- 35-38) Stop Frequency (integer)
- 39-40) Start Ch# (integer)
- 41-42) Stop Ch# (integer)
- 43-46) Channel occupied band width (integer)
- 47-50) Channel spacing (integer)
- 51-52) Channel step (integer)
(2nd record)
- 53-100) Repeat from 5 to 52

... ..

Last byte) FF (End of the return bytes)

Command error : 1 byte

- 224 (E0h) Parameter Error
- 238 (EEh) Time Out Error

Write Custom Cable – Control Byte #80 (50h)

Description: Write a cable parameter in the custom cable list.

Bytes to Follow: 25 bytes

- 1) Not Used
- 2) Cable List index (0 - 49)
- 3 – 17) Cable Description (string)
- 18) Propagation Velocity (Highest byte)⁶³⁵
- 19) Propagation Velocity
- 20) Propagation Velocity
- 21) Propagation Velocity (Lowest byte)
- 22) Insertion Loss (Highest byte)⁶³⁶
- 23) Insertion Loss
- 24) Insertion Loss
- 25) Insertion Loss (Lowest byte)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
- 224 (E0h) Parameter Error
- 238 (EEh) Time Out Error

⁶³⁵ Propagation Velocity in units 1/100,000

⁶³⁶ Insertion Loss in units 1/100,000 dB/m or 1/100,000 dB/ft

Recall Custom Cable – Control Byte #81 (51h)

Description: Query a cable in the custom cable list.

Bytes to Follow: 2 bytes

- 1) Not Used
- 2) Cable list index (0-49)

Site Master Returns: 24 bytes

- 1) Upper bound of Custom Cable Index
 - 2 – 16) Cable Description (string)
 - 17) Propagation Velocity (Highest byte)⁶³⁷
 - 18) Propagation Velocity
 - 19) Propagation Velocity
 - 20) Propagation Velocity (Lowest byte)
 - 21) Insertion Loss (Highest byte)⁶³⁸
 - 22) Insertion Loss
 - 23) Insertion Loss
 - 24) Insertion Loss (Lowest byte)
-

Write Antenna – Control Byte #82 (52h)

Description: Receives an antenna to the Site Master via the serial port.

An antenna is described with an index into the list (1-10) and an ASCII name that appears in the list on the Site Master. Each antenna can have up to 60 antenna factors. Each antenna factor has an associated frequency and value. These are specified one at a time.

Frequencies are sent in Hz scaled by the Scale Factor.

The value of the antenna factor should be sent as (value * 100).

Bytes to Follow: 26 – 380, depending on the number of antenna factors

- 1) Antenna List Index (1-10)
 - 2-17) Antenna Name (in ASCII)
 - 18) Number of Antenna Factors (max = 60)
 - 19-20) Frequency Scale Factor (in Hz)
- For each antenna factor:
- 1) Frequency (scaled by Scale Factor) (Highest byte)
 - 2) Frequency (scaled by Scale Factor)
 - 3) Frequency (scaled by Scale Factor)
 - 4) Frequency (scaled by Scale Factor) (Lowest byte)
 - 5) Antenna Factor (Higher byte)
 - 6) Antenna Factor (Lower byte)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error
 - 238 (EEh) Time Out Error
-

⁶³⁷ Propagation Velocity in units 1/100,000

⁶³⁸ Insertion Loss in units 1/100,000 dB/m or 1/100,000 dB/ft

Recall Antenna – Control Byte #83 (53h)

Description: Sends an antenna from the Site Master via the serial port.

An antenna is described with an index into the list (1-10) and an ASCII name that appears in the list on the Site Master. Each antenna can have up to 60 antenna factors. The number of antenna factors will be sent before the actual values are sent. Each antenna factor has an associated frequency and value. These are specified one at a time.

Frequencies are sent in Hz scaled by the Scale Factor.

The value of the antenna factor should be sent as (value * 100).

Bytes to Follow: 1 byte

- 1) Antenna List index (1-10)

Site Master Returns: (28-382 bytes, depending on the number of antenna factors)

- 1) Maximum Antenna Number (10)
- 2-17) Antenna Name (in ASCII)
- 18) Number of Antenna Factors (max = 60)
- 19-20) Frequency Scale Factor (in Hz)
- 21-22) Number of Following Bytes

For each antenna factor:

- 1) Frequency (scaled by Scale Factor) (Highest byte)
- 2) Frequency (scaled by Scale Factor)
- 3) Frequency (scaled by Scale Factor)
- 4) Frequency (scaled by Scale Factor) (Lowest byte)
- 5) Antenna Factor (Higher byte)
- 6) Antenna Factor (Lower byte)

Set Field Strength Measurement – Control Byte #84 (54h)

Description: Sets the state of the measurement (ON or OFF) and the antenna index for the field strength measurement. Antennas 1-10 are custom antennas. Antennas 11-15 are the standard antennas. The standard antennas are as follows:

11. Anritsu #2000-1030 (MAXRAD MPA1750) – 1710-1880 MHz
12. Anritsu #2000-1031 (MAXRAD MPA1850) – 1850-1990 MHz
13. Anritsu #2000-1032 (MAXRAD MPA2450) – 2400-2483.5 MHz
14. Anritsu #2000-1200 (Centurion EXCSM806) – 806-899 MHz
15. Anritsu #2000-1035 (Centurion EXE-902-SM) – 896-941 MHz

If the FCN4760 frequency converter module is attached, the standard antenna is:

11. Anritsu #2000-1361 – 5725-5825 MHz

Note that if the field strength measurement is turned ON, all other measurements (channel power, adjacent channel power) are turned OFF.

Bytes to Follow: 2 bytes

- 1) Field Strength Measurement State (On/Off)
- 2) Antenna List index (1-15)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
224 (E0h) Parameter Error: Invalid state or index
238 (EEh) Time Out Error
-

Set Channel Power – Control Byte #85 (55h)

Description: Sets the state of the measurement (ON or OFF), and the setup parameters to perform the channel power measurement.

Send a 0 (zero) following the command to set the channel power measurement in the current setup.

Send a 1 (one) to set the channel power associated with the trace that was most recently uploaded by command #36, Upload Sweep Trace.

If option 6 is installed and the frequency converter module is attached, the frequencies should be scaled by the scale factor of the module. If the module is not attached, the frequencies are sent in Hz. Use Control Word A203 to determine whether a module is attached and the appropriate scale factor.

Note that if the channel power measurement is turned ON, all other measurements (field strength, adjacent channel power) are turned OFF.

Bytes to Follow: 14 bytes

- 1) Channel Power Location (0 = current setup, 1 = last uploaded trace)
- 2) Channel Power Measurement State (On/Off)
- 3-6) Center Frequency
- 7-10) Integration Bandwidth
- 11-14) Span Frequency

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error
 - 238 (EEh) Time Out Error
-

Read Channel Power – Control Byte #86 (56h)

Description: Read the current channel power or the channel power of a stored trace.

Send a 0 (zero) following the command to read the current channel power measurement (i.e. the one that is updated as the unit is sweeping).

Send 1-200 to read the channel power associated with a stored trace (use Query Trace Names, #24, to obtain trace numbers).

If option 6 is installed and the frequency converter module is attached, the frequencies will be scaled by the scale factor of the module. If the module is not attached, the frequencies are sent in Hz. Use Control Word A203 to determine whether a module is attached and the appropriate scale factor.

Bytes to Follow: 1 byte

- 1) Channel Power Location (0 = current measured value, 1-200 = value in stored trace)

Site Master Returns: 21 bytes

- 1) Channel Power On/Off
 - 2-5) Channel Center Frequency
 - 6-9) Integration Bandwidth
 - 10-13) Channel Span Frequency
 - 14-17) Channel Power (= (power in dBm * 100) + 270000)
 - 18-21) Channel Power Density (= (density in dBm/Hz * 100) + 270000)
-

Set Adjacent Channel Power Ratio (ACPR) – Control Byte #87 (57h)

Description: Sets the state of the measurement (ON or OFF), the center frequency, the main channel bandwidth, the adjacent channel bandwidth and the channel spacing.

Send a 0 (zero) following the command to set the channel power measurement in the current setup.

Send a 1 (one) to set the adjacent channel power associated with the trace that was most recently uploaded by command #36, Upload Sweep Trace.

If option 6 is installed and the frequency converter module is attached, the frequencies should be scaled by the scale factor of the module. If the module is not attached, frequencies are sent in Hz. Use Control Word A203 to determine whether a module is attached and the appropriate scale factor.

Note that if the ACPR measurement is turned ON, all other measurements (field strength, channel power) are turned OFF.

Bytes to Follow: 18 bytes

- 1) Adjacent Channel Power Location (0 = current setup, 1 = last uploaded trace)
- 2) Adjacent Channel Power Measurement State (On/Off)
- 3-6) Center Frequency
- 7-10) Main Channel Bandwidth
- 11-14) Adjacent Channel Bandwidth
- 15-18) Channel Spacing

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
- 224 (E0h) Parameter Error
- 238 (EEh) Time Out Error

Read Adjacent Channel Power (ACPR) – Control Byte #88 (58h)

Description: Read the current adjacent channel power or the adjacent channel power of a stored trace.

Send a 0 (zero) following the command to read the current adjacent channel power measurement (i.e. the one that is updated as the unit is sweeping).

Send 1-200 to read the channel power associated with a stored trace (use Query Trace Names, #24, to obtain trace numbers).

If option 6 is installed and the frequency extension module is attached, the frequencies will be scaled by the scale factor of the module. If the module is not attached, frequencies are sent in Hz. Use Control Word A203 to determine whether a module is attached and the appropriate scale factor.

Bytes to Follow: 1 byte

- 1) Adjacent Channel Power Ratio Location (0 = current measured value, 1-200 = value in stored trace)

Site Master Returns: 29 bytes

- 1) ACPR On/Off
- 2-5) Main Channel Center Frequency
- 6-9) Main Channel Bandwidth
- 10-13) Adjacent Channel Bandwidth
- 14-17) Channel Spacing
- 18-21) Main Channel Power (= (power in *dBm* * 100) + 270000)
- 22-25) Lower Adjacent Channel Power (= (power in *dBm* * 100) + 270000)
- 26-29) Upper Adjacent Channel Power (= (power in *dBm* * 100) + 270000)

Read Signal Standard Name – Control Byte #89 (59h)

Description: Returns the name corresponding to the desired signal standard index as an ASCII string in English.

Bytes to Follow: 3 bytes

- 1) Mode (00h = VNA, 01h = Spectrum Analyzer/Transmission)
- 2) Signal Standard Index (higher byte)
- 3) Signal Standard Index (lower byte)

Site Master Returns: 2 bytes + number of bytes in string (or 1 byte on error)

- 1) String length (in number of bytes – referred to as “X” on the next line)
- 2-(X+1)) Standard Name in ASCII
- X+2) 255 (FFh) Operation Complete Byte

OR

- 1) 224 (E0h) Parameter Error
 - 238 (EEh) Time Out Error
-

Measure OCC BW % of Power – Control Byte #96 (60h)

Description: Measure OCC BW with % of Power method.

If option 6 is installed and the frequency extension module is attached, the OBW frequencies will be scaled by the scale factor of the module. If the module is not attached, the OBW frequencies are sent in Hz. Use Control Word A203 to determine whether a module is attached and the appropriate scale factor.

Bytes to Follow: 4 bytes

- 1) % of Power (Highest byte)
- 2) % of Power
- 3) % of Power
- 4) % of Power (Lowest byte) (in 100th of %, 9123 = 91.23%)

Site Master Returns: 16 bytes

- 1-4) Occupied Bandwidth (in Hz)
 - 5-8) Measure dB down (dB * 100,000)
 - 9-12) Low Frequency OCC BW
 - 13-16) High Frequency OCC BW
-

Measure OCC BW dB Down – Control Byte #97 (61h)

Description: Measure OCC BW with dB down method.

If option 6 is installed and the frequency converter module is attached, the OBW frequencies will be scaled by the scale factor of the module. If the module is not attached, the OBW frequencies are sent in Hz. Use Control Word A203 to determine whether a module is attached and the appropriate scale factor.

Bytes to Follow: 4 bytes

- 1-4) dB down (in 100th of dB, 1234 = 12.34dB)

Site Master Returns: 16 bytes

- 1-4) Occupied Bandwidth (in Hz)
 - 5-8) Measure % of Power (% of power * 100)
 - 9-12) Low Frequency OCC BW
 - 13-16) High Frequency OCC BW
-

Set Bias Tee Function - Control Byte #98 (62h)

This command is available only with Option 10.

Description: Set the Bias Tee function On/Off. If the Bias Tee is turned on, the Spectrum Master returns the results of Bias Tee.

Bytes to Follow: 1 byte

- 00h – Turns the Bias Tee Off
- 01h – Turns the Bias Tee On

Site Master Returns:

If bias tee is turned Off (1 byte)

- 1) 255 (FFh) Operation Complete Byte
- 224 (E0h) Parameter Error: Invalid state
- 238 (EEh) Time-out Error

If bias tee is turned On (10 bytes)

- 1) Bias Tee Board Indicator (00h = No Hardware Installed, 01h = Hardware Installed)
- 2) Bias Tee Current (Highest byte)
- 3) Bias Tee Current
- 4) Bias Tee Current
- 5) Bias Tee Current (Lowest byte)
- 6) 10 * Bias Tee Voltage (Highest byte) : voltage value is in volt/10
- 7) 10 * Bias Tee Voltage
- 8) 10 * Bias Tee Voltage
- 9) 10 * Bias Tee Voltage (Lowest byte)
- 10) 255 (FFh) Operation Complete Byte
- 224 (E0h) Parameter Error
- 238 (EEh) Time-out Error

Note: Due to the hardware delay, the Spectrum Master does not return the results of the Bias Tee until approximately 3 seconds after the Bias Tee is turned on.

Set Spectrum Analyzer Start/Stop Frequency – Control Byte #99 (63h)

Description: Sets the spectrum analyzer start and stop frequencies.

If option 6 is installed and the frequency converter module is attached, the frequencies should be scaled by the scale factor of the module. If the module is not attached, the frequencies are sent in Hz. Use Control Word A203 to determine whether a module is attached and the appropriate scale factor.

Bytes to Follow: 8 bytes

- 1) Start Frequency (Highest byte)
- 2) Start Frequency
- 3) Start Frequency
- 4) Start Frequency (Lowest byte)
- 5) Stop Frequency (Highest byte)
- 6) Stop Frequency
- 7) Stop Frequency
- 8) Stop Frequency (Lowest byte)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error: Invalid frequency range
 - 238 (EEh) Time Out Error
-

Set Spectrum Analyzer Center Freq./Span – Control Byte #100 (64h)

Description: Sets the spectrum analyzer center frequency and span.

If option 6 is installed and the frequency converter module is attached, the frequencies should be scaled by the scale factor of the module. If the module is not attached, the frequencies are sent in Hz. Use Control Word A203 to determine whether a module is attached and the appropriate scale factor.

Bytes to Follow: 8 bytes

- 1) Center Frequency (Highest byte)
- 2) Center Frequency
- 3) Center Frequency
- 4) Center Frequency (Lowest byte)
- 5) Frequency Span (Highest byte)
- 6) Frequency Span
- 7) Frequency Span
- 8) Frequency Span (Lowest byte)

Spectrum Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error: Invalid frequency range
 - 238 (EEh) Time Out Error
-

Set Spectrum Analyzer Scale – Control Byte #101 (65h)

Description: Sets the reference level and the number of dB represented by each graph division.

Ref Level will be the “top” scale of the graph, and there are total of 10 division, so bottom scale can be determined by : Ref level + 10 x dB/div.

Bytes to Follow: 8 bytes

- 1) Ref Level (Highest byte)
- 2) Ref Level
- 3) Ref Level
- 4) Ref Level (Lowest byte)
- 5) dB/div (Highest byte)
- 6) dB/div
- 7) dB/div
- 8) dB/div (Lowest byte)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
- 224 (E0h) Parameter Error: Invalid scale
- 238 (EEh) Time Out Error

Notes:

Ref Level is sent as the (Ref Level * 1000) + 270,000 (0 dBm = 270,000, 20 dBm = 290000, -120 dBm = 150,000)
Scale should be sent as (dBm * 1000) (e.g. -12.34 dBm = -12340)

Set Spectrum Analyzer Marker – Control Byte #102 (66h)

Description: Sets an individual Spectrum Analyzer marker.

Bytes to Follow: 5 bytes

- 1) Marker Number (01h = marker 1, 02h = marker 2, 03h = marker 3, 04h = marker 4, 05h = marker 5, 06h = marker 6)

- 2) Marker Line On/Off (01h = On, 00h = Off)
- 3) Marker Delta Status On/Off (01h = On, 00h = Off)
- 4) Marker Value (Higher byte)
- 5) Marker Value (Lower byte)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
- 224 (E0h) Parameter Error: Invalid marker number, status or position
- 238 (EEh) Time Out Error

Note:

Marker Value is between 0 and 400, inclusive: $\text{Point} = (400 * (\text{marker freq} - \text{start freq})) / \text{span}$

Set Spectrum Analyzer Single Limit – Control Byte #103 (67h)

Description: Sets the position and On/Off Status of the Limit Line.

Bytes to Follow: 6 bytes

- 1) Limit Number (1 for Site Master)
- 2) Limit Line On/Off (01h = On, 00h = Off)
- 3) Beep at Limit On/Off (01h = On, 00h = Off)
- 4) Limit Value (Highest byte)
- 5) Limit Value
- 6) Limit Value
- 7) Limit Value (Lowest byte)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
- 224 (E0h) Parameter Error: Invalid limit number, status or value
- 238 (EEh) Time Out Error

Note:

Limit Value is sent as the $(\text{Limit Value} * 1000) + 270,000$ (0 dBm=270,000, 20 dBm=290000, -120 dBm=150,000)

Set Spectrum Analyzer Peak Hold – Control Byte #105 (69h)

Description: Sets the max hold and min hold settings on the Spectrum Analyzer.

Bytes to Follow: 1 byte

- 1) Peak Hold State
 - 00h – Peak Hold Off
 - 01h – Max Hold On
 - 02h – Min Hold On

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error: Invalid state
 - 238 (EEh) Time Out Error
-

OBSOLETE: Set Spectrum Analyzer Resolution Bandwidth – Control Byte #106 (6Ah)

This command exists for backward compatibility with the S33xC models. Features new to the S33xD models

are not available here. To access the new features use Control Byte #141 (8Dh).

Description: Sets the resolution BW frequency for the Spectrum Analyzer.

Bytes to Follow: 1 byte

- 1) Resolution Bandwidth Index
 - 00h – 10 kHz BW
 - 01h – 30 kHz BW
 - 02h – 100 kHz BW
 - 03h – 1 MHz BW

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error: Invalid RBW Index
 - 238 (EEh) Time Out Error
-

OBSOLETE: Set Spectrum Analyzer Video Bandwidth – Control Byte #107 (6Bh)

This command exists for backward compatibility with the S33xC models. Features new to the S33xD models are not available here. To access the new features use Control Byte #142 (8Eh).

Description: Sets the video BW frequency for the Spectrum Analyzer.

Bytes to Follow: 1 byte

- 1) Video Bandwidth Index
 - 00h – 100 Hz BW
 - 01h – 300 Hz BW
 - 02h – 1 kHz BW
 - 03h – 3 kHz BW
 - 04h – 10 kHz BW
 - 05h – 30 kHz BW
 - 06h – 100 kHz BW
 - 07h – 300 kHz BW

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error: Invalid VBW Index
 - 238 (EEh) Time Out Error
-

Set Spectrum Analyzer Sweep Mode – Control Byte #108 (6Ch)

Description: Enables or disables the Single Sweep Mode during Spectrum Analyzer mode of operation.

Single Sweep Mode activates once the Site Master exits from the remote mode.

For Single Sweep Mode during Site Master VNA modes of operation see control byte #11 (0Bh).

Bytes to Follow: 1 byte

- 1) Sweep Mode
 - 00h – Single Sweep
 - 01h – Continuous Sweep
 - 02h – Video Trigger (span must be 0)
 - 03h – External Trigger (span must be 0)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
- 224 (E0h) Parameter Error: Invalid Mode

Set Spectrum Analyzer Marker to Peak – Control Byte #109 (6Dh)

Description: Sets the specified marker to the peak value of the sweep.

Bytes to Follow: 1 byte

- 1) Marker Number (1-6)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
224 (E0h) Parameter Error: Invalid Marker Number
238 (EEh) Time Out Error
-

Set Spectrum Analyzer Marker to Center – Control Byte #110 (6Eh)

Description: Sets the center frequency equal to the frequency of the specified marker.

Bytes to Follow: 1 byte

- 1) Marker Number (1-4)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
224 (E0h) Parameter Error: Invalid Marker Number
238 (EEh) Time Out Error
-

OBSOLETE: Set Spectrum Analyzer Attenuation – Control Byte #111 (6Fh)

This command exists for backward compatibility with the S33xC models. Features new to the S33xD models are not available here. To access the new features use Control Byte #143 (8Fh).

Description: Sets the attenuation for the Site Master Spectrum Analyzer mode. Send a value of 255 (FFh) to enable dynamic attenuation.

Automatic control couples the attenuation to the reference level. Note that setting the attenuation using this command automatically sets the attenuation coupling to “MANUAL”, thereby allowing it to be defined independently of the reference level.

Bytes to Follow: 1 byte

- 1) Attenuation Index
00h – 0 dB
01h – 10 dB
02h – 20 dB
03h – 30 dB
04h – 40 dB
05h – 50 dB

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
224 (E0h) Parameter Error: Invalid Attenuation Index
238 (EEh) Time Out Error
-

Set Site Master VNA Segmented Limit Lines – Control Byte #112 (70h)

Description: Sets the position and On/Off status of the limit lines.

Site Master VNA modes support 5 limit segments. Each segment may have any finite slope and can be enabled and disabled independently of every other segment. The limit beep is enabled for all segments or no segments.

Limit segments are specified by their end points (starting and ending “x” and “y” values).

See control byte #29 (1Dh) response bytes 60 to 129 for the current Site Master configuration.

Bytes to Follow: 14 bytes

- 1) Limit Number
- 2) Limit Line On/Off (01h = On, 00h = Off)
- 3) Starting X (Highest byte)⁶³⁹
- 4) Starting X
- 5) Starting X
- 6) Starting X (Lowest byte)
- 7) Starting Y (Higher byte)
- 8) Starting Y (Lower byte)
- 9) Ending X (Highest byte)⁶⁴⁰
- 10) Ending X
- 11) Ending X
- 12) Ending X (Lowest byte)
- 13) Ending Y (Higher byte)
- 14) Ending Y (Lower byte)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
224 (E0h) Parameter Error: Invalid limit segment, status or value
238 (EEh) Time Out Error

Notes:

Limit Value depends on the current display mode selected.

Return Loss &: Limit should be sent as (dB * 1000)

Cable Loss Maximum value sent is 60000 which represents 60.00 dB
Minimum value sent is 0 which represents 0.0 dB

SWR: Limit is in thousandths (of ratio), so it should be sent as (ratio * 1000)
Maximum value sent is 65530 which represents 65.53
Minimum value sent is 1000 which represents 1.00

Set Spectrum Analyzer Multiple Limit – Control Byte #113 (71h)

Description: Sets the position and On/Off Status of a limit segment.

Multiple limits are defined by multiple limit segments, each with a different finite slope. The single limit is a single, horizontal line that can be defined to act as an upper limit or as a lower limit. See control byte #103 for information about the single limit.

The limit types are mutually exclusive. That is, you cannot have both single and multiple limits at the same time. Note that setting a limit segment ON automatically makes the limit type “MULTIPLE”.

One segment is defined each time this command is sent to the Spectrum Master. The first two bytes of the command specify which segment is being defined. There are 5 upper limits and 5 lower limits available in Spectrum Analyzer mode. Byte 1 selects the segment number. Byte 2 specifies whether it is an upper limit or a lower limit. Byte 3 turns the segment ON or OFF. Byte 4 specifies whether the error beep sounds when the bound set by the segment is exceeded by the measured data.

⁶³⁹ Frequency in Hz or Distance in 1/100,000 ft (or meters)

⁶⁴⁰ Frequency in Hz or Distance in 1/100,000 ft (or meters)

The segment location is defined by its endpoints. The “Start” endpoint must appear to the left of the “End” endpoint on the graph. That is, Start X < End X. If Start X = End X then Start Y must equal End Y. Vertical segments are not allowed.

Bytes to Follow: 20 bytes

- 1) Segment number (1-5)
- 2) Segment type (00h = LOWER limit, 01h = UPPER limit)
- 3) Limit Line On/Off (01h = On, 00h = Off)
- 4) Limit Beep On/Off (01h = On, 00h = Off)
- 5) Limit Value Start X ⁶⁴¹ (Highest byte)
- 6) Limit Value Start X
- 7) Limit Value Start X
- 8) Limit Value Start X (Lowest byte)
- 9) Limit Value Start Y ⁶⁴² (Highest byte)
- 10) Limit Value Start Y
- 11) Limit Value Start Y
- 12) Limit Value Start Y (Lowest byte)
- 13) Limit Value End X ⁶⁴³ (Highest byte)
- 14) Limit Value End X
- 15) Limit Value End X
- 16) Limit Value End X (Lowest byte)
- 17) Limit Value End Y ⁶⁴⁴ (Highest byte)
- 18) Limit Value End Y
- 19) Limit Value End Y
- 20) Limit Value End Y (Lowest byte)

Spectrum Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
224 (E0h) Parameter Error: Invalid limit segment, status or value
238 (EEh) Time Out Error

Set Return Spectrum Analyzer Sweep Time – Control Byte #114 (72h)

Description: If this is enabled, the duration of the current sweep (in milliseconds) will be returned as 4 bytes via the serial port at the end of the sweep. If Serial Echo Status is enabled, the 4 bytes will be returned AFTER the sweep complete byte.

Bytes to Follow: 1 byte

- 1) Return SPA Sweep Time flag state
00h = Don't Return Sweep Time
01h = Return Sweep Time

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
224 (E0h) Parameter Error: Invalid state
238 (EEh) Time Out Error

⁶⁴¹ If option 6 is installed and the frequency converter module is attached, the frequencies should be scaled by the scale factor of the module. If the module is not attached, the frequencies are sent in Hz. Use Control Word A203 to determine whether a module is attached and the appropriate scale factor.

⁶⁴² (Value in dBm * 1000) + 270,000

⁶⁴³ If option 6 is installed and the frequency converter module is attached, the frequencies should be scaled by the scale factor of the module. If the module is not attached, the frequencies are sent in Hz. Use Control Word A203 to determine whether a module is attached and the appropriate scale factor.

⁶⁴⁴ (Value in dBm * 1000) + 270,000

Set Reference Level Offset – Control Byte #115 (73h)

Description: Set the value of the reference level offset.

The reference level offset allows the user to view the result of trace math (A+B, A-B) even if it is greater than +20 dBm or less than -120 dBm. The offset is a constant that is subtracted from the reference level.

Note that the valid range is -100 to +100 dB.

Send the value as (value in dB * 1000) + 270,000.

For example, to compensate for a 30 dB attenuator, the reference level offset should be -30 dB. That value would be sent over the serial port as $(-30 * 1000) + 270,000 = 240,000$.

Bytes to Follow: 4 bytes

- 1) Reference Level Offset (Highest byte)
- 2) Reference Level Offset
- 3) Reference Level Offset
- 4) Reference Level Offset (Lowest byte)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
224 (E0h) Parameter Error
238 (EEh) Time Out Error

Set Spectrum Analyzer Impedance – Control Byte #116 (74h)

Description: Set the impedance and the loss value due to an adapter.

The Site Master can automatically compensate for the effects of impedance adapters. The impedance of the Site Master is 50Ω, so there is no need for an adapter in this case. The loss for the Anritsu 75Ω adapter 12N50-75B is known by the Site Master.

This control byte also allows for the specification of the impedance and the loss due to an adapter the system does not know. In either case, 5 bytes must be sent to the unit. If the impedance is 50Ω or one of the known adapters is specified, bytes 2-5 are ignored. If an unknown adapter is specified, the unit uses bytes 2-5 to correct for the adapter.

Bytes to Follow: 5 bytes

- 1) Impedance Adapter⁶⁴⁵
- 2) Impedance Loss⁶⁴⁶ (Highest byte)
- 3) Impedance Loss
- 4) Impedance Loss
- 5) Impedance Loss (Lowest byte)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
224 (E0h) Parameter Error
238 (EEh) Time Out Error

Read Marker Value – Control Byte #117 (75h)

Description: Returns the frequency location of the specified marker, and the value at that location.

⁶⁴⁵ Impedance Adapter: 00h = 50 Ω 0Ah = 75Ω, adapter 12N50-75B 0Ch = 75Ω, other adapter offset

⁶⁴⁶ Send the loss value as value in dB* 1,000

If option 6 is installed and the frequency converter module is attached, the frequency will be scaled by the scale factor of the module. If the module is not attached, the frequency is sent in Hz. Use Control Word A203 to determine whether a module is attached and the appropriate scale factor.

Bytes to Follow: 1 byte

- 1) Marker number (1-6)

Spectrum Master Returns: 8 bytes (1 byte if an error occurs)

- 1) Frequency (Highest byte)
- 2) Frequency
- 3) Frequency
- 4) Frequency (Lowest byte)
- 5) Value at Marker (Highest byte)
- 6) Value at Marker
- 7) Value at Marker
- 8) Value at Marker (Lowest byte)

OR

- 1) 224 (E0h) Parameter Error: Invalid marker number
238 (EEh) Time-out Error

Note:

Marker value sent as (value in dBm * 1,000) + 270,000

If markers are set to be noise markers, convert the returned dBm value to dBm/Hz using this formula (only if detection method is RMS Average):

$$\text{marker (in dBm/Hz)} = \text{marker value (in dBm)} - 10 * \log_{10}(\text{RBW}) - 0.13$$

Set Sweep Averaging – Control Byte #118 (76h)

Description: Sets the number of sweeps to average. The maximum number is 25. Sending a 1 turns averaging off.

Note: This only works in Spectrum Analyzer mode.

Bytes to Follow: 1 byte

- 1) Number of sweeps to average (1-25, 1 turns averaging OFF)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
224 (E0h) Parameter Error
238 (EEh) Time Out Error

Field InstaCal – Control Byte #120 (78h)

Description: This command is used by the customer in the field to start an InstaCal sequence.

Prior to sending this command to the Site Master, the InstaCal module should be connected to the R/F Out port. To execute this command, exit remote mode after sending this command.

Byte to Follow: 0 bytes

Site Master Returns: 2 bytes

- 1) 255 (FFh): Operation Complete Byte
- 2) 240 (F0h): Calibration completes

254 (FEh): Operation complete with some conditions⁶⁴⁷

224 (E0h): Communication Error : Cell Master was unable to communicate with InstaCal module

238 (EEh): Field InstaCal sequence was unable to complete

Read InstaCal Module ASCII Serial Number – Control Byte #124 (7Ch)

Description: Returns the InstaCal Module serial number in ASCII.

Bytes to Follow: 1 byte

- 1) Serial number storage location (01h=main serial, 02h=secondary)

Site Master Returns: 8 bytes

- 1-8) Serial Number, in ASCII
-

Set Site Master Marker (Peak/Valley) – Control Byte #129 (81h)

Description: Sets an individual marker in current measurement mode to either peak (maximum) signal or valley (minimum) signal.

Bytes to Follow: 2 bytes

- 1) Marker Number (01h = marker 1, 02h = marker 2, 03h = marker 3, 04h = marker 4, 05h = marker 5, 06h = marker 6)
- 2) Marker Line Search Status (01h = Peak , 00h = Valley)

Site Master Returns: 3 bytes (1 byte if an error occurs)

- 1) Marker Position (Higher byte)⁶⁴⁸
- 2) Marker Position (Lower byte)
- 3) 255 (FFh) Operation Complete Byte

OR

- 1) 224 (E0h) Parameter Error : Invalid marker or marker search status
238 (EEh) Time Out Error
-

Set / Reset Spectrum Analyzer External Reference – Control Byte #133 (85h)

Description: Sets the external reference frequency for the spectrum analyzer in increments of 1 MHz from 2 – 20 MHz. The frequencies are sent in Hz.

Bytes to Follow: 1 byte if turning the reference OFF, 5 bytes if turning the reference ON

Turn OFF the external reference:

- 1) 00h - Turn OFF the frequency reference

OR

Turn ON the external reference (the reference frequency is also sent):

- 1) 01h - Turn ON the frequency reference
- 2) External Reference Frequency (in Hz) (Highest byte)
- 3) External Reference Frequency (in Hz)

⁶⁴⁷ Attached instacal module's serial number is different from the one whose characterization data is in the instrument's memory. It's recommended to issue instacal module characterization command byte #242 (F2h).

⁶⁴⁸ The marker position is sent as a data point on the display. Equivalent Frequency = (position * span / (# data points – 1)) + start frequency

- 4) External Reference Frequency (in Hz)
- 5) External Reference Frequency (in Hz) (Lowest byte)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
- 224 (E0h) Parameter Error
- 238 (EEh) Time Out Error

Check Spectrum Analyzer External Reference – Control Byte #134 (86h)

Description: Checks to see if Spectrum Analyzer external reference is present. If it is, it then checks to see if it is at the correct frequency for PLL locking.

Bytes to Follow: 0 bytes

Site Master Returns: 1 byte

On Success:

- 1) 00h – Reference present and at the correct frequency (PLL functioning)
- 01h – Reference is not present
- 02h – Reference is present, but internal PLL and external frequency do not match up.

OR

On Error:

- 1) 224 (E0h) Parameter Error – Not in External reference mode
- 238 (EEh) Time-out Error.

Set SA Preamp State (On/Off/Auto) – Control Byte #136 (88h)

Description: Sets the state of Spectrum Analyzer preamplifier.

Setting the preamp state to ON or OFF sets the preamp coupling to manual. That is, the preamplifier state is controlled independently of all other parameters.

Setting the preamp state to AUTO couples the preamp state to the reference level and the attenuation. If the attenuation is automatically coupled to the reference level, the preamp will turn on when the reference level is set less than -26 dBm. If the attenuation is manually coupled to the reference level, the preamp will turn on when the value of (attenuation – reference level) ≥ 51 .

Bytes to Follow: 1 byte

- 1) Mode (00h = Off, 01h = On, 02h = Auto)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
- 224 (E0h) Parameter Error: Invalid state
- 238 (EEh) Time Out Error

Set Spectrum Analyzer Units – Control Byte #140 (8Ch)

Description: Sets the scale type (logarithmic or linear) and the units.

Linear units can be:

- 01h = Volts
- 02h = Watts

Logarithmic units can be:

- 03h = dBm
- 04h = dBV
- 05h = dBmV
- 06h = dB μ V

Bytes to Follow: 2 bytes

- 1) Scale Type (00h = Linear, 01h = Logarithmic)
- 2) Units

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error
 - 238 (EEh) Time-out Error
-

Set Spectrum Analyzer Resolution Bandwidth – Control Byte #141 (8Dh)

This command is new to the S33xD. Use it instead of Control Byte #106 to access the new RBWs.

Description: Sets the resolution BW frequency for the Spectrum Analyzer.

Bytes to Follow: 4 bytes

- 1) Resolution Bandwidth (frequency in Hz) (Highest byte)
- 2) Resolution Bandwidth (frequency in Hz)
- 3) Resolution Bandwidth (frequency in Hz)
- 4) Resolution Bandwidth (frequency in Hz) (Lowest byte)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error: Invalid RBW
 - 238 (EEh) Time Out Error
-

Set Spectrum Analyzer Video Bandwidth – Control Byte #142 (8Eh)

This command is new to the S33xD. Use it instead of Control Byte #107 to access the new VBWs.

Description: Sets the video BW frequency for the Spectrum Analyzer.

Bytes to Follow: 4 bytes

- 1) Video Bandwidth (frequency in Hz) (Highest byte)
- 2) Video Bandwidth (frequency in Hz)
- 3) Video Bandwidth (frequency in Hz)
- 4) Video Bandwidth (frequency in Hz) (Lowest byte)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error: Invalid VBW
 - 238 (EEh) Time Out Error
-

Set Spectrum Analyzer Attenuation – Control Byte #143 (8Fh)

This command is new to the S33xD. Use it instead of Control Byte #111 to access the new attenuations.

Description: Sets the attenuation of the Spectrum Analyzer. Send a byte-to-follow value of 255 (FFh) to enable dynamic attenuation.

Automatic control couples the attenuation to the reference level. Dynamic control let the instrument sets appropriate attenuation on each sweep based on the total power coming into the RF-in port. Note that setting the attenuation using this command automatically sets the attenuation coupling to “MANUAL”, thereby allowing it to be defined independently of the reference level.

Bytes to Follow: 1 byte

- 1) Attenuation (0 – 51)
Or
255 (for dynamic attenuation)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
224 (E0h) Parameter Error: Invalid attenuation
238 (EEh) Time Out Error

Set AM/FM Demodulation – Control Byte #145 (91h)

Description: Sets the AM/FM/SSB Demodulation state. This command is also used to set the type of Modulation, volume, Demodulation Frequency, BFO Adjust (SSB only) and the Demodulation time. On turning demodulation ON, after exiting remote, at the end of every sweep, demodulation is performed at the Demodulation frequency for a period of time specified in the Demod Time.

Bytes to Follow: 16 bytes

- 1) Set AM/FM/SSB Demod On/Off⁶⁴⁹
- 2) Demodulation Type⁶⁵⁰
- 3) Speaker Volume (Higher byte)⁶⁵¹
- 4) Speaker Volume (Lower byte)
- 5) Demodulation Time⁶⁵² (Highest byte)
- 6) Demodulation Time
- 7) Demodulation Time
- 8) Demodulation Time (Lowest byte)
- 9) Demodulation Frequency⁶⁵³ (Highest byte)
- 10) Demodulation Frequency
- 11) Demodulation Frequency
- 12) Demodulation Frequency (Lowest byte)
- 13) SSB BFO Adjust⁶⁵⁴ (Highest byte)
- 14) SSB BFO Adjust
- 15) SSB BFO Adjust
- 16) SSB BFO Adjust (Lowest byte)

Spectrum Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
224 (E0h) Parameter Error
238 (EEh) Time Out Error

⁶⁴⁹ 00h = Off, 01h = On

⁶⁵⁰ 00h = FM Wideband, 01h = FM Narrowband, 02h = AM, 03h = SSB Lower, 04h = SSB Upper

⁶⁵¹ Speaker Volume is from 0 to 100 in steps of 10

⁶⁵² Demodulation time in milliseconds from 100 millisecond to 500 seconds

⁶⁵³ If option 6 is installed and the frequency converter module is attached, the frequencies should be scaled by the scale factor of the module. If the module is not attached, the frequencies are sent in Hz. Use Control Word A203 to determine whether a module is attached and the appropriate scale factor.

⁶⁵⁴ BFO Valid Values are -10 kHz to +10 kHz. Send value as BFO(in Hz) + 10,000. For Example -10 kHz would be sent as 0, 0 would be sent as 10000 and +10 kHz would be 20000

Set Baud Rate – Control Byte #197 (C5h)

Description: Set baud rate for this session. An invalid setting returns the baud rate to 9600.

Bytes to Follow: 1 byte

- 1) Baud Rate Index
 - 00h = 9600 baud
 - 01h = 19200 baud
 - 02h = 38400 baud
 - 03h = 56000 baud
 - 04h = 115200 baud

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error: Invalid baud rate index
 - 238 (EEh) Time Out Error
-

Set Language – Control Byte #198 (C6h)

Description: Set the Site Master display language.

Bytes to Follow: 1 byte

- 1) Language Index
 - 00h = English
 - 01h = French
 - 02h = German
 - 03h = Spanish
 - 04h = Chinese
 - 05h = Japanese

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error: Invalid language index
 - 238 (EEh) Time Out Error
-

Query Time – Control Byte #208 (D0h)

Description: Queries the Site Master for the current time in ASCII format.

Bytes to Follow: 0 bytes

Site Master Returns: 8 bytes (HH:MM:SS)

- 1) Hour (Higher byte)
 - 2) Hour (Lower byte)
 - 3) :
 - 4) Minute (Higher byte)
 - 5) Minute (Lower byte)
 - 6) :
 - 7) Second (Higher byte)
 - 8) Second (Lower byte)
-

Read Main Serial Number – Control Byte #221 (DDh)

Description: Returns the Main (External) Serial Number as four bytes. This command remains for backward

compatibility.

A better command to use would be “Read ASCII Serial Number” #225 (E1h) which returns the serial number in ASCII format.

Bytes to Follow: 0 bytes

Site Master Returns: 4 bytes

- 1) Main Serial Number (Highest byte)
- 2) Main Serial Number
- 3) Main Serial Number
- 4) Main Serial Number (Lowest byte)

Read ASCII Serial Number – Control Byte #225 (E1h)

Description: Reads and returns the Site Master serial number as 8 ASCII bytes.

Bytes to Follow: 1 byte

- 1) Serial number storage location
 - 01h = Main (External) Serial Number
 - 02h = Secondary (Motherboard) Serial Number
 - 03h = T1/E1 Serial Number

Site Master Returns: 8 bytes

1-8) Serial Number (in ASCII)

GPS Power – Control Byte #237 (EDh)

Description: Turn On/Off power of GPS module.

Bytes to Follow: 1 bytes

Power Switch (1=ON, others=OFF)

Cell Master Returns: 1 byte

- 255 (FFh) Operation Complete Byte
- 224 (E0h) Parameter Error
- 238 (EEh) Time Out Error

Read GPS Position – Control Byte #238 (EEh)

Description: Read current GPS position data: Latitude, longitude, and Altitude.

Bytes to Follow: 0 byte

Cell Master Returns: 13 byte (if Ok)

- 1-2) Number of satellites in use (< 3 if not locked)
- 3-6) GPS Position – Latitude (long integer)⁶⁵⁵ (= -1 if not valid)
- 7-10) GPS Position – Longitude (long integer) (= -1 if not valid)
- 11-12) GPS Position – Altitude (short integer) (= -30000 if not valid)
- 13) 255 (FFh) Operation Complete Byte

Error code : 1 byte

⁶⁵⁵ Signed long integer is used to represent latitude and longitude. Positive latitude means North hemisphere, negative latitude means South hemisphere; Positive longitude means East hemisphere, negative longitude means West hemisphere. Degree = int(abs(value)/1,000,000); Minute = (float)(abs(value)%1,000,000)/10,000

224 (E0h) Parameter Error
238 (EEh) Time Out Error

Automatic Cal Disable – Control Byte #241 (F1h)

Description: Disable automatic calibration.

Bytes to Follow: 1 byte

1: to disable automatic calibration
0: to enable automatic calibration

Cell Master Returns: 1 byte

255 (FFh) Operation Complete Byte
224 (E0h) Parameter Error : Invalid Parameter
238 (Eeh) Time-out Error

Instacal Module Characterization – Control Byte #242 (F2h)

Description: This command can either be a query or a request depending on the argument (parameter). If the argument is 1 (01h), then this is a request to load the attached instacal module characterization. This needs to be done only once whenever there is a change in the module being used to calibrate. It makes future calibration using the same module a lot quicker. If the argument is 0 (00h), then this is a query asking if the attached instacal module's characterization had been recorded in the instrument's memory.

Bytes to Follow: 1 byte

0 (00h): To ask if the attached instacal module's characterization is in the instrument's memory
1 (01h): To record the attached instacal module's characterization into the instrument's memory

Cell Master Returns: 1 byte⁶⁵⁶

0 (00h): Attached instacal module's characterization is in the instrument's memory OR attempt to record the attached instacal's characterization into the instrument's memory succeeded.
1 (01h): Attached instacal module's characterization is not in the instrument's memory OR attempt to record the attached instacal's characterization into the instrument's memory failed.
224 (E0h): Parameter error - invalid parameter
238 (EEh): Time-out error
254 (FEh): Cannot detect an instacal module from the RF out port.

Recall Sweep Trace – Control Byte #243 (F3h)

Description: This command is similar to another recall sweep trace with control byte #33 (21h). The only different between this command and command #33 (21h) is that this command requires 2 bytes to follow whereas command #33 (21h) requires 1 byte. This makes it possible to recall traces whose indices are bigger than 255, which is not possible with command #33 (21h).

Bytes to Follow: 2 bytes

0 = Last sweep trace before entering remote mode (sweep trace in RAM)
1- 300 = Specific saved sweep number (stored sweeps in Flash memory)

1) Trace Index (Higher Byte)
2) Trace Index (Lower Byte)

⁶⁵⁶ If there are 2 possible interpretations to the return byte, then the first interpretation is intended for the query type and the second one is intended for the request type.

Cell Master Returns:

Exactly like command #33 (21h), so please refer to that section.

Set Site Master VNA Extended Frequency – Control Byte #244 (F4h)

Description: Sets the Site Master frequency range. Start and stop frequencies are given in terms of 10-Hz steps. (e.g. 5000.3 MHz would be sent as 500030000 = 500,030,000 (10-Hz).)

Valid range is 25 MHz – 4000 MHz.

Low end is extended to 2 MHz with option 2; and high end is extended to 6000 MHz with option 16.

See control byte #29 (1Dh) response bytes 28 to 35 for current Site Master start and stop frequencies.

This command handles frequency up to 6 GHz. However, it must be entered in 10-Hz steps.

Bytes to Follow: 8 bytes

- 9) Start Frequency (Highest byte)
- 10) Start Frequency
- 11) Start Frequency
- 12) Start Frequency (Lowest byte)
- 13) Stop Frequency (Highest byte)
- 14) Stop Frequency
- 15) Stop Frequency
- 16) Stop Frequency (Lowest byte)

Site Master Returns: 1 byte

- 2) 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error : Invalid frequency range
 - 238 (EEh) Time-out Error
-

Exit Remote Mode – Control Byte #255 (FFh)

Description: Site Master exits remote mode.

The computer sends the Exit Remote command #255 (FFh) to the Site Master. Site Master returns a confirm flag (FFh). The Site Master resumes sweeping, either continuously or singly.

You may also press the “ESCAPE” key on the Site Master key pad to exit from remote mode (given that the serial communication is still in sync). In this case, the Site Master does not return a confirm byte to the serial port.

When exiting remote mode, system parameters changed during remote mode are used immediately.

System parameters changed during remote mode are not written to the non-volatile EEPROM.

You may want to save the change to the run-time setup (saved setup location 0, which holds the power-on setup) or one of the saved setups for the current measurement mode. See control byte #18 (12h) for details.

Bytes to Follow: 0 bytes

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete
-

Set T1 Transmission Level – Control Word (A001h)

This control byte is available with Option 50 only.

Description: Sets the transmission level of T1 measurement mode.

Bytes to Follow: 1 byte

- 1) Transmission Level
 - 00h: 0 dB
 - 01h: -7.5 dB
 - 02h: -15 dB
 - 03h: -22 dB

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error: Invalid transmission level
 - 238 (EEh) Time Out Error
-

Set T1/E1 Clock Source – Control Word (A002h)

This control byte is available with Option 50 only.

Description: Sets the Clock Source of T1/E1 measurement mode.

Bytes to Follow: 1 byte

- 1) Clock Source
 - 00h: Internal
 - 01h: External

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error: Invalid clock source
 - 238 (EEh) Time Out Error
-

Set T1/E1 Pattern – Control Word (A003h)

This control byte is available with Option 50 only.

Description: Sets the data pattern of T1/E1 measurement mode.

Bytes to Follow: 2 bytes

- 1) Data Pattern
 - 00h: AUTO_DETECT
 - 01h: PRBS_9
 - 02h: PRBS_11
 - 03h: PRBS_15
 - 04h: PRBS_20 (O.151)
 - 05h: PRBS_20 (O.153)
 - 06h: PRBS_23
 - 07h: QRSS
 - 08h: ONE_IN_8
 - 09h: TWO_IN_8
 - 0Ah: THREE_IN_24
 - 0Bh: ALL_ONES

- 0Ch: ALL_ZEROS
 - 0Dh: T1_DALY
 - 0Eh: BLUE_ALARM
 - 0Fh: YELLOW_ALARM
 - 10h: USER_DEFINED
- 2) Inverted Pattern Option (01h: Inverted; 00h: Non-inverted)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
- 224 (E0h) Parameter Error: Invalid pattern index
- 238 (EEh) Time Out Error

Set T1/E1 Error Insert Type/Value – Control Word (A004h)

This control byte is available with Option 50 only.

Description: Sets the Insertion Error type and the number of errors.

Bytes to Follow: 5 bytes

- 1) Error Type
 - 00h: Bit
 - 01h: Bert
 - 02h: BPV
 - 03h: Framing
- 2) Number of Errors (Highest byte)
- 3) Number of Errors
- 4) Number of Errors
- 5) Number of Errors (Lowest byte)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
- 224 (E0h) Parameter Error: Invalid error type or value
- 238 (EEh) Time Out Error

Set T1/E1 Framing Mode – Control Word (A005h)

This control byte is available with Option 50 only.

Description: Sets the Framing Mode of T1/E1 measurement.

Bytes to Follow: 1 byte

- 1) Framing Mode
 - 00h: Auto
 - (T1 Tester Only)
 - 01h: D4 SF
 - 02h: ESF
 - (E1 Tester Only)
 - 03h: PCM30
 - 04h: PCM30 CRC
 - 05h: PCM31
 - 06h: PCM31 CRC

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
- 224 (E0h) Parameter Error: Invalid framing mode

Start and Stop T1/E1 Measurement – Control Word (A006h)

This control byte is available with Option 50 only.

Description: This command toggles the Run/Stop state of the T1/E1 measurement. That is, if the command is sent while the measurement is running, the command stops the measurement. If the command is sent when the measurement is stopped, the command starts the measurement.

Bytes to Follow: 0 bytes

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
 - 238 (EEh) Time Out Error
-

Insert Error for T1/E1 Measurement – Control Word (A007h)

This control byte is available with Option 50 only.

Description: This command inserts the error defined into the data flow.

Bytes to Follow: 0 bytes

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
 - 238 (EEh) Time Out Error
-

Get T1/E1 Pattern – Control Word (A008h)

This control byte is available with Option 50 only.

Description: Get the current T1/E1 pattern.

Bytes to Follow: 0 bytes

Site Master Returns: 1 byte

- 1) T1 Pattern

OR

- 1) 238 (EEh) Time Out Error
-

Get T1/E1 Frame Sync Status – Control Word (A009h)

This control byte is available with Option 50 only.

Description: Get the frame sync status of T1 /E1.

Bytes to Follow: 0 bytes

Site Master Returns: 1 byte

- 1) Frame Sync Status (00h: Framed; 01h: Unframed)

OR

- 1) 238 (EEh) Time Out Error
-

Get T1/E1 Pattern Sync Status – Control Word (A00Ah)

This control byte is available with Option 50 only.

Description: Get the pattern sync status of T1/ E1.

Bytes to Follow: 0 bytes

Site Master Returns: 1 byte

- 1) Pattern Sync Status (00h: In-sync; 01h: Out-of-sync)

OR

- 1) 238 (EEh) Time Out Error
-

Get T1/E1 Carrier Status – Control Word (A00Bh)

This control byte is available with Option 50 only.

Description: Get the carrier status of T1/E1.

Bytes to Follow: 0 bytes

Site Master Returns: 1 byte

- 1) Carrier Status (00h: Carrier present; 01h: No carrier)

OR

- 1) 238 (EEh) Time Out Error
-

Get T1/E1 Error Type and Number – Control Word (A00Ch)

This control byte is available with Option 50 only.

Description: Get the error type and number of T1/E1.

Bytes to Follow: 0 bytes

Site Master Returns: 16 bytes in T1 mode, 18 bytes in E1 mode, 1 byte on error

- 1) Frame Loss (Higher byte)
- 2) Frame Loss (Lower byte)
- 3) Bit Errors (Highest byte)
- 4) Bit Errors
- 5) Bit Errors
- 6) Bit Errors (Lowest byte)
- 7) BER (Higher byte)
- 8) BER (Lower byte)
- 9) BPV (Higher byte)
- 10) BPV (Lower byte)
- 11) CRC (Higher byte)
- 12) CRC (Lower byte)

T1:

- 13) Errored Seconds (Highest byte)

- 14) Errored Seconds
- 15) Errored Seconds
- 16) Errored Seconds (Lowest byte)

E1:

- 13) E Bits (Higher byte)
- 14) E Bits (Lower byte)
- 15) Errored Seconds (Highest byte)
- 16) Errored Seconds
- 17) Errored Seconds
- 18) Errored Seconds (Lowest byte)

OR

- 1) 238 (EEh) Time Out Error
-

Set T1/E1 Line Coding Options – Control Word (A00Dh)

This control byte is available with Option 50 only.

Description: Sets the line coding options of T1/E1 measurement mode.

Bytes to Follow: 1 byte

- 1) Line Coding
 - 00h: B8ZS (For T1 Only)
 - 01h: AMI
 - 02h: HDB3 (For E1 Only)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error: Invalid line coding option
 - 238 (EEh) Time Out Error
-

Set E1 Impedance Options – Control Word (A00Eh)

This control byte is available with Option 50 only.

Description: Sets the impedance for the E1 mode. Note that impedance is set separately for BERT and Vpp measurements.

Bytes to Follow: 2 bytes

- 1) E1 Measurement (00h: BERT, 01h: Vpp)
- 2) Impedance
 - 00h: 75 Ω
 - 01h: 120 Ω

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error: Invalid impedance setting
 - 238 (EEh) Time Out Error
-

Read T1/E1 Volts Peak-to-Peak – Control Word (A00Fh)

This control byte is available with Option 50 only.

Description: Initiates the Vpp measurement on the T1 board and returns the result.

Vpp is sent as (Vpp * 10).

Bytes to Follow: 0 bytes

Site Master Returns: 3 bytes

- 1) Volts peak-to-peak (Higher byte)
 - 2) Volts peak-to-peak (Lower byte)
 - 3) Status Byte
 - 255 (FFh) Operation Complete Byte
 - 238 (EEh) Time-out Error
-

Set T1/E1 Receive Input Configuration Options – Control Word (A013h)

This control byte is available with Option 50 only.

Description: Sets the Rx Input Configuration for the T1/E1 modes.

Bytes to Follow: 2 bytes

- 1) T1/E1 Measurement (00h: BERT, 01h: Vpp)
- 2) Rx Input Config
 - 00h: Terminate
 - 01h: Bridged
 - 02h: Monitor +20 dB (BERT only)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error: Invalid measurement or configuration
 - 238 (EEh) Time Out Error
-

Set T1/E1 Measurement Duration – Control Word (A014h)

This control byte is available with Option 50 only.

Description: Sets the measurement duration for the current mode (T1 or E1).

Bytes to Follow: 1 byte

- 1) Measurement Duration Index
 - 00h: Manual
 - 01h: 3 minutes
 - 02h: 15 minutes
 - 03h: 30 minutes
 - 04h: 1 hour
 - 05h: 3 hours
 - 06h: 6 hours
 - 07h: 12 hours
 - 08h: 1 day
 - 09h: 2 days

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
- 224 (E0h) Parameter Error: Invalid duration or not in T1 or E1 mode

Set T1/E1 Data Logging – Control Word (A015h)

This control byte is available with Option 50 only.

Description: Enables and disables data logging for T1/E1 modes. The ability to log data depends on the amount of available memory..

Bytes to Follow: 1 byte

- 1) Data Logging Status
00h: Off
01h: On

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
224 (E0h) Parameter Error: Invalid status or not enough memory
238 (EEh) Time Out Error
-

Read T1/E1 dBdsx – Control Word (A016h)

This control byte is available with Option 50 only.

Description: Initiates a voltage measurement on the T1 board and returns the result in dBdsx. The resolution is 0.1 dB and is offset by 350 so that only positive values are returned. For example, -5.0 dB will be reported as 300. Results less than -20 dB are not accurate to 0.1 dB and should be divided by 10.

Bytes to Follow: 2 bytes

- 1) dBdsx (Higher byte)
- 2) dBdsx (Lower byte)

Site Master Returns: 1 byte

- 1) Status Byte
255 (FFh) Operation Complete Byte
238 (EEh) Time-out Error
-

Read T1/E1 Frequency – Control Word (A017h)

This control byte is available with Option 50 only.

Description: Reports the last T1/E1 frequency measurement result in Hz if available. The DSP CPLD U80 must be version 7 or higher and the T1E1 board version number must be 1 or higher for this measurement. The Cell Master must be configured for a BER measurement and a BER measurement must be running before this command is executed. The firmware must version V1.88 or higher.

Bytes to Follow: 0 bytes

Site Master Returns: 4 bytes

- 1) Frequency (Highest byte)
 - 2) Frequency
 - 3) Frequency
 - 4) Frequency (Lowest byte)
-

Read T1/E1 Frequency Cal – Control Word (A018h)

This control byte is available with Option 50 only.

Description: Reports the current T1/E1 frequency calibration setting. The value is in Hz offset from 0 by 100, with a range of 0 to 200 Hz (equivalent to +/- 100 Hz).

Bytes to Follow: 0 bytes

Site Master Returns: 1 byte

- 1) Frequency Calibration Setting in Hz
-

Set T1/E1 Frequency Cal – Control Word (A019h)

This control byte is available with Option 50 only.

Description: Sets the T1/E1 frequency calibration value. The value is in Hz offset from 0 by 100, with a range of 0 to 200 Hz (equivalent to +/- 100 Hz).

Bytes to Follow: 1 byte

- 1) Frequency Calibration Setting in Hz

Site Master Returns: 1 byte

- 1) Status Byte
255 (FFh) Operation Complete Byte
-

Configure DS0/E0 Channel Tests – Control Word (A01Ah)

This control byte is available with Option 50 only.

Description: Configures DS0/E0 channel access

Bytes to Follow: 3 bytes

- 1) Channel insert ON/OFF. 1 for ON, 0 for OFF.
- 2) Channel number. 1 – 24 for DS1, 1- 32 for E1
- 3) Audio monitor volume in percent, 0 – 100%

Cell Master Returns: 1 byte

- Status Byte
- 255 (FFh) Operation Complete Byte
 - 238 (EEh) Time-out Error
-

Read DS0/E0 Level and Frequency – Control Word (A01Bh)

This control byte is available with Option 50 only.

Description: Reports the level and frequency of the received signal on the selected DS0/E0 channel. The range of the level measurement is -40.0 to +3.0 dBm. The result is reported with 0.1 dB resolution, offset by 401. A report of 401 corresponds to 0.0 dBm, a report of 0 is under range and a report of 432 is over range. The frequency is reported in Hz.

Bytes to Follow: 0 bytes

Cell Master Returns: 4 bytes

- 1) Level high byte
- 2) Level low byte

- 3) Frequency high byte
- 4) Frequency low byte

Set DS0/E0 Level and Frequency – Control Word (A01Ch)

This control byte is available with Option 50 only.

Description: Sets the level and frequency of the sinusoidal signal to transmit on the selected channel. The range of the level setting is 0 to –30 dBm. The level setting is offset by 30 where 30 corresponds to 0 dBm and 0 to –30 dBm. The frequency is in Hz with a range of 100 to 3000 Hz.

Bytes to Follow: 3 bytes

- 1) Level
- 2) Frequency high byte
- 3) Frequency low byte

Cell Master Returns: 1 byte

Status Byte

- 255 (FFh) Operation Complete Byte
- 238 (EEh) Time-out Error

Select SPA/Power Meter Signal Standard – Control Word (A103h)

Description: Selects a Signal Standard. Use this command for both Spectrum Analyzer and Power Meter modes.

Bytes to Follow: 1 byte

- 1) Signal Standard – See the section “Signal Standards” for a list of standards and their indices.

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
- 224 (E0h) Parameter Error: Invalid signal standard
- 238 (EEh) Time Out Error

Select SPA/Power Meter Channel – Control Word (A104h)

Description: Selects a channel within the range of the currently selected signal standard. Use this command for both Spectrum Analyzer and Power Meter modes.

See the section “Signal Standards” for a list of valid channels for the selected channel.

Bytes to Follow: 2 bytes

- 1) Channel (Higher byte)
- 2) Channel (Lower byte)

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
- 224 (E0h) Parameter Error: Invalid channel
- 238 (EEh) Time Out Error

Read External Module Name – Control Word (A201h)

This command is available only with option 6.

Description: Returns the name of the attached frequency converter module (option 6).

For example, module name “FCN4760” will be received as:
c,46,43,4e,34,37,36,30,0,0,0,0,ff

Bytes to Follow: 0 bytes

Site Master Returns: 14 bytes (success) OR 1 byte (failure)

- 1) Length of Name (12)
- 2-13) Module Name
- 14) 255 (FFh) Operation Complete Byte
- 224 (E0h) Parameter Error: Module not attached
- 238 (EEh) Time Out Error

OR

- 1) 255 (FFh) Operation Complete Byte
- 224 (E0h) Parameter Error: Module not attached
- 238 (EEh) Time Out Error

Read External Module Serial Number – Control Word (A202h)

This command is available only with option 6.

Description: Sets the serial number of the attached frequency converter module (option 6).

For example, serial number 12345678 will be received as:
8,1,2,3,4,5,6,7,8,ff

Bytes to Follow: 0 bytes

Site Master Returns: 10 bytes

- 1) Length of Serial Number (8)
- 2-9) Serial Number
- 10) 255 (FFh) Operation Complete Byte
- 224 (E0h) Parameter Error: Module not attached
- 238 (EEh) Time Out Error

OR

- 1) 255 (FFh) Operation Complete Byte
- 224 (E0h) Parameter Error: Module not attached
- 238 (EEh) Time Out Error

Read External Module Frequency Range – Control Word (A203h)

This command is available only with option 6.

Description: Sets the frequency range of the attached frequency converter module (option 6). Frequency values are scaled by the scale factor value.

For example, the frequency range of the FCN4760 is as follows:

Scale factor: 10

Input Start Frequency: 4700 MHz (scaled, this number is 470 MHz)

Input End Frequency: 6000 MHz (scaled, this number is 600 MHz)

Output Start Frequency: 450 MHz (scaled, this number is 45 MHz)

Output End Frequency: 1750 MHz (scaled, this number is 175 MHz)

So the response will look like:

12,0,a,1c,3,a1,80,23,c3,46,0,2,ae,a5,40,a,6e,49,c0,ff

Bytes to Follow: 0 bytes

Site Master Returns: 20 bytes (success) OR 1 byte (failure)

- 1) Length of Frequency Data (18)
- 2-3) Scale Factor (in Hz)
- 4-7) Input Start Frequency (scaled by Scale Factor)
- 8-11) Input End Frequency (scaled by Scale Factor)
- 12-15) Output Start Frequency (scaled by Scale Factor)
- 16-19) Output End Frequency (scaled by Scale Factor)
- 20) 255 (FFh) Operation Complete Byte
- 224 (E0h) Parameter Error: Module not attached
- 238 (EEh) Time Out Error

OR

- 1) 255 (FFh) Operation Complete Byte
- 224 (E0h) Parameter Error: Module not attached
- 238 (EEh) Time Out Error

Read Module Fail Counter – Control Word (A204h)

This command is available only with option 6.

Description: Returns the value of the module lock fail counter.

Bytes to Follow: 0 bytes

Site Master Returns: 3 bytes (success) OR 1 byte (failure)

- 1) Fail Counter (Higher byte)
- 2) Fail Counter (Lower byte)
- 3) 255 (FFh) Operation Complete Byte

OR

- 1) 255 (FFh) Operation Complete Byte
- 224 (E0h) Parameter Error: Module not attached
- 238 (EEh) Time Out Error

Clear Module Fail Counter – Control Word (A205h)

This command is available only with option 6.

Description: Sets the module lock fail counter to 0.

Bytes to Follow: 0 bytes

Site Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte
- 224 (E0h) Parameter Error: Module not attached
- 238 (EEh) Time Out Error

Perform Transmission Mode Calibration – Control Word (A301h)

This command is available only with option 21.

Description: Perform Transmission Mode Calibration.

Bytes to Follow: 0 bytes

Cell Master Returns: 1 byte

- 1) 255 (FFh) Operation Complete Byte

224 (E0h) Parameter Error: Invalid channel
238 (EEh) Time Out Error

Turn OFF Transmission Mode Calibration – Control Word (A302h)

This command is available only with option 21.

Description: Turn OFF Transmission Mode Calibration

Bytes to Follow: 0 bytes

Cell Master Returns: 1 byte

Get Signal Standard Name – Control Word (A501h)

Description: Get the ASCII signal standard corresponding to a specified Index. This command can be used in any measurement mode.

Bytes to follow: 2

- 1) Index (Highest Byte)
- 2) Index (Lowest Byte)

Cell Master Returns: 20 bytes

1 – 20) Standard Name in ASCII

Set Signal Standard Link Direction – Control Word (A502h)

Description: Set the link direction of current selected signal standard. This command can be used in any measurement mode.

Bytes to follow: 1 byte

- 1) Type⁶⁵⁷

Cell Master Returns: 1 byte

255 (FFh) Operation Complete Byte
224 (E0h) Parameter Error: Invalid channel
238 (EEh) Time Out Error

Perform Noise Diode Cal – Control Word (A505h)

Description: Performs noise diode calibration on SPA board

Bytes to follow: 0

Cell Master Returns: 1 byte

255 (FFh) Operation Complete Byte
224 (E0h) Parameter Error: Invalid channel
238 (EEh) Time Out Error

Set Bias T Voltage – Control Word (A506h)

⁶⁵⁷ 1 = downlink, 2 = uplink, 3 = up and downlink

Description: Motherboards beginning with 64968 have a programmable Bias T. This command sets the Bias T voltage between 12 and 24 volts.

Bytes to follow: 1

- 1) Bias T Voltage

Cell Master Returns: 1 byte

- 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error: Invalid channel
 - 238 (EEh) Time Out Error
-

Select Function in IA Measurement Mode – Control Word (A700h)

This command is available only with option 25.

Description: Selects measurement function in Interference Analysis mode.

Bytes to Follow: 1 bytes

- 1) Function ID (0: Spectrum; 1: Spectrogram; 2: Signal strength; 3: RSSI; 4: Signal ID)

Cell Master Returns: 1 byte

- 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error: Module not attached
 - 238 (EEh) Time Out Error
-

Spectrogram: Set Sweep Interval – Control Word (A721h)

This command is available only with option 25.

Description: Sets the sweep interval in spectrogram mode.

Bytes to Follow: 2 bytes

- a. Sweep interval in seconds (Highest byte)
- b. Sweep interval in seconds (Lowest byte)

Cell Master Returns: 1 byte

- 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error: Module not attached
 - 238 (EEh) Time Out Error
-

Spectrogram: Set Time Span of Measurement – Control Word (A722h)

This command is available only with option 25.

Description: Sets the time span of spectrogram measurement. Maximum time span is 72 hours (4320 minutes) when “Auto Save” is turned on. Minimum time span is 0 which means the fastest sweep time of current setting is used.

Bytes to Follow: 2 bytes

- 1) Time span in minutes (MSB)
- 2) Time span in minutes (LSB)

Cell Master Returns: 1 byte

- 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error: Module not attached
 - 238 (EEh) Time Out Error
-

Spectrogram: Turn On/Off Auto Save – Control Word (A723h)

This command is available only with option 25.

Description: Turns On or Off Auto Save switch of spectrogram mode. When Auto Save is turned on, the first 5 screens of records are saved automatically into 5 memory slots. Once all 5 memory slots have been occupied, Auto Save is going to be turned off.

Bytes to Follow: 1 bytes

On/Off Switch (0:Off; 1:On)

Cell Master Returns: 1 byte

255 (FFh) Operation Complete Byte

224 (E0h) Parameter Error: Module not attached

238 (EEh) Time Out Error

Spectrogram: Get Trace Name – Control Word (A724h)

This command is available only with option 25.

Description: Get the Trace names saved in five spectrogram memory slots. The name is composed with Time & Date when the trace is saved. If the memory slot is empty, the date field is set with "--/--/----" and the time field is set with "--:--:--".

Bytes to Follow: 0 bytes

Cell Master Returns:

When control word is received correctly: 101 bytes

1-2) Index of trace (from 0 to 4)

3-12) Date of save in ASCII string, format: "--/--/----"

13-20) Time of save in ASCII string, format: "--:--:--"

21-100) Repeat the information of 1) to 20) four times

101) FFh

When error occurs: 1 byte

224 (E0h) Parameter Error: Module not attached

238 (EEh) Time Out Error

Spectrogram: Recall Trace – Control Word (A725h)

This command is available only with option 25.

Description: Recall a spectrogram trace by sending the trace index (0-4) of the memory slots.

Bytes to Follow: 1 bytes

1) Index of memory slots (0-4)

Cell Master Returns:

When control word is received correctly: 32448 bytes

1-10) Date of save (ASCII, format: "--/--/----")

11-18) Time of save (ASCII, format: "--:--:--")

19-22) Center Frequency (Integer – MSB to LSB)

23-26) Span (Integer – MSB to LSB)

27-30) RBW (Integer – MSB to LSB)

31-34) VBW (Integer – MSB to LSB)

35-38) Reference level (Integer – MSB to LSB)

- 39-42) Scale (Integer – MSB to LSB)
- 43-46) Time Span (Integer – MSB to LSB)
- 47-48) Sweep Interval (Integer – MSB to LSB)
- 49-52) GPS Position – Latitude (long integer)⁶⁵⁸
- 53-56) GPS Position – Longitude (long integer)
- 57-58) GPS Position – Altitude (short integer)
- 59-32458) 80 records of spectrogram data. Each record has the following format:
 - 1-401) Color indices of 401 sweep data points, The formula of color index is as following:
Color Index = (Ref Level - SaMeasData) * 255 / (Division * 10)
 - 402-405) Time Stamp of the record being generated.
- Status byte: 1 byte
 - 255 (FFh) Operation Complete Byte
 - 224 (E0h) Parameter Error: Module not attached
 - 238 (EEh) Time Out Error

Remote Self Test – Control Word (AA15h)

This control byte is for **INTERNAL** use only and should not be distributed.

Description: Trigger the equivalent of a “key press” selftest.

Note: The response bytes will not all be returned immediately. The first 12 will be returned, then there will be a slight delay before the next 14 are returned, then a final delay while the T1/E1 selftest is performed and the final 12 bytes are returned.

Bytes to Follow: 0 bytes

Site Master Returns:

S331D (No Options/Option 3): 25 bytes

- 1) Temperature in 1/10th of degree Celsius (e.g. 362 = 36.2 °C) (Higher byte)
- 2) Temperature in 1/10th of degree Celsius (e.g. 362 = 36.2 °C) (Lower byte)
- 3) Memory Check (01h: Pass, 00h: Fail)
- 4) RTC Voltage Check (01h: Pass, 00h: Fail)
- 5) Power Voltage in 1/10ths of a Volt (e.g. 124 = 12.4 Volts) (Higher byte)
- 6) Power Voltage in 1/10ths of a Volt (e.g. 124 = 12.4 Volts) (Lower byte)
- 7) VNA Lock Failure Counter (Higher byte)
- 8) VNA Lock Failure Counter (Lower byte)
- 9) VNA Integrator Failure Counter (Higher byte)
- 10) VNA Integrator Failure Counter (Lower byte)
- 11) SPA LO Failure Counter (Higher byte)
- 12) SPA LO Failure Counter (Lower byte)
- 13) H/W Config - Mother Board ID
- 14) H/W Config - SPA Board ID
- 15) H/W Config - T1E1 Board ID
- 16) H/W Config - PLD1 ID
- 17) H/W Config - PLD2 ID
- 18) H/W Config – T1E1 COLD ID
- 19) VNA PLL Lock Failure Test - Status (01h: Pass, 00h: Fail)
- 20) VNA PLL Lock Failure Test - Failed data point # (Ignore this byte if the Lock Fail Test Status was Pass)

⁶⁵⁸ Signed long integer is used to represent latitude and longitude. Positive latitude means North hemisphere, negative latitude means South hemisphere; Positive longitude means East hemisphere, negative longitude means West hemisphere. Degree = int(abs(value)/1,000,000); Minute = (float)(abs(value)%1,000,000)/10,000

- 21) VNA PLL Lock Failure Test - Failed PLL # (Ignore this byte if the Lock Fail Test Status was Pass)
- 22) VNA Integration Test - Status (01h: Pass, 00h: Fail)
- 23) VNA Integration Test - Failed data point # (Ignore this byte if the Integration Test Status was Pass)
- 24) VNA Integration Test - Reserved
- 25) SPA LO Test - Status (01h: Pass, 00h: Fail, FFh: SPA board not installed)
- 26) SPA LO Test - Failed data point #
- 27) SPA LO Test - Failed LO #
- 28) End of Data (FFh)

S331D + Option 29 or S332D (w/o Option 6): 28 bytes

- 1) Temperature in 1/10th of degree Celsius (e.g. 362 = 36.2 °C) (Higher byte)
- 2) Temperature in 1/10th of degree Celsius (e.g. 362 = 36.2 °C) (Lower byte)
- 3) Memory Check (01h: Pass, 00h: Fail)
- 4) RTC Voltage Check (01h: Pass, 00h: Fail)
- 5) Power Voltage in 1/10ths of a Volt (e.g. 124 = 12.4 Volts) (Higher byte)
- 6) Power Voltage in 1/10ths of a Volt (e.g. 124 = 12.4 Volts) (Lower byte)
- 7) VNA Lock Failure Counter (Higher byte)
- 8) VNA Lock Failure Counter (Lower byte)
- 9) VNA Integrator Failure Counter (Higher byte)
- 10) VNA Integrator Failure Counter (Lower byte)
- 11) SPA LO Failure Counter (Higher byte)
- 12) SPA LO Failure Counter (Lower byte)
- 13) H/W Config - Mother Board ID
- 14) H/W Config - SPA Board ID
- 15) H/W Config - T1E1 Board ID
- 16) H/W Config - PLD1 ID
- 17) H/W Config - PLD2 ID
- 18) H/W Config - T1E1 COLD ID
- 19) VNA PLL Lock Failure Test - Status (01h: Pass, 00h: Fail)
- 20) VNA PLL Lock Failure Test - Failed data point # (Ignore this byte if the Lock Fail Test Status was Pass)
- 21) VNA PLL Lock Failure Test - Failed PLL # (Ignore this byte if the Lock Fail Test Status was Pass)
- 22) VNA Integration Test - Status (01h: Pass, 00h: Fail)
- 23) VNA Integration Test - Failed data point # (Ignore this byte if the Integration Test Status was Pass)
- 24) VNA Integration Test - Reserved
- 25) SPA LO Test - Status (01h: Pass, 00h: Fail, FFh: SPA board not installed)
- 26) SPA LO Test - Failed data point #
- 27) SPA LO Test - Failed LO #
- 28) End of Data (FFh)

S332D + Option 6: 33 bytes

- 1) Temperature in 1/10th of degree Celsius (e.g. 362 = 36.2 °C) (Higher byte)
- 2) Temperature in 1/10th of degree Celsius (e.g. 362 = 36.2 °C) (Lower byte)
- 3) Memory Check (01h: Pass, 00h: Fail)
- 4) RTC Voltage Check (01h: Pass, 00h: Fail)
- 5) Power Voltage in 1/10ths of a Volt (e.g. 124 = 12.4 Volts) (Higher byte)
- 6) Power Voltage in 1/10ths of a Volt (e.g. 124 = 12.4 Volts) (Lower byte)
- 7) VNA Lock Failure Counter (Higher byte)
- 8) VNA Lock Failure Counter (Lower byte)
- 9) VNA Integrator Failure Counter (Higher byte)
- 10) VNA Integrator Failure Counter (Lower byte)
- 11) SPA LO Failure Counter (Higher byte)
- 12) SPA LO Failure Counter (Lower byte)
- 13) H/W Config - Mother Board ID
- 14) H/W Config - SPA Board ID
- 15) H/W Config - T1E1 Board ID

- 16) H/W Config - PLD1 ID
- 17) H/W Config - PLD2 ID
- 18) H/W Config – T1E1 COLD ID
- 19) VNA PLL Lock Failure Test - Status (01h: Pass, 00h: Fail)
- 20) VNA PLL Lock Failure Test - Failed data point # (Ignore this byte if the Lock Fail Test Status was Pass)
- 21) VNA PLL Lock Failure Test - Failed PLL # (Ignore this byte if the Lock Fail Test Status was Pass)
- 22) VNA Integration Test - Status (01h: Pass, 00h: Fail)
- 23) VNA Integration Test - Failed data point # (Ignore this byte if the Integration Test Status was Pass)
- 24) VNA Integration Test - Reserved
- 25) SPA LO Test - Status (01h: Pass, 00h: Fail, FFh: SPA board not installed)
- 26) SPA LO Test - Failed data point #
- 27) SPA LO Test - Failed LO #
- 28) Module PLD Version
- 29) Module Attached
- 30) Module Lock (01h = Locked, 00h = Not Locked)
- 31) Module Lock Fail Counter (Higher byte)
- 32) Module Lock Fail Counter (Lower byte)
- 33) End of Data (FFh)

S331D + Option 50: 36 bytes

- 1) Temperature in 1/10th of degree Celsius (e.g. 362 = 36.2 °C) (Higher byte)
- 2) Temperature in 1/10th of degree Celsius (e.g. 362 = 36.2 °C) (Lower byte)
- 3) Memory Check (01h: Pass, 00h: Fail)
- 4) RTC Voltage Check (01h: Pass, 00h: Fail)
- 5) Power Voltage in 1/10ths of a Volt (e.g. 124 = 12.4 Volts) (Higher byte)
- 6) Power Voltage in 1/10ths of a Volt (e.g. 124 = 12.4 Volts) (Lower byte)
- 7) VNA Lock Failure Counter (Higher byte)
- 8) VNA Lock Failure Counter (Lower byte)
- 9) VNA Integrator Failure Counter (Higher byte)
- 10) VNA Integrator Failure Counter (Lower byte)
- 11) SPA LO Failure Counter (Higher byte)
- 12) SPA LO Failure Counter (Lower byte)
- 13) H/W Config - Mother Board ID
- 14) H/W Config - SPA Board ID
- 15) H/W Config - T1E1 Board ID
- 16) H/W Config - PLD1 ID
- 17) H/W Config - PLD2 ID
- 18) H/W Config – T1E1 COLD ID
- 19) VNA PLL Lock Failure Test - Status (01h: Pass, 00h: Fail)
- 20) VNA PLL Lock Failure Test - Failed data point # (Ignore this byte if the Lock Fail Test Status was Pass)
- 21) VNA PLL Lock Failure Test - Failed PLL # (Ignore this byte if the Lock Fail Test Status was Pass)
- 22) VNA Integration Test - Status (01h: Pass, 00h: Fail)
- 23) VNA Integration Test - Failed data point # (Ignore this byte if the Integration Test Status was Pass)
- 24) VNA Integration Test - Reserved
- 25) Status (01h: Pass, 00h: Fail, FFh: T1/E1 board not installed)
- 26) Carrier Status (01h: carrier present, 00h: No carrier)
- 27) Frame Sync Status (01h: in frame sync, 00h: Not in frame sync)
- 28) QRSS pattern sync status (01h: Pattern sync, 00h: Not in sync)
- 29) QRSS bit error count (01h: Bit error found, 00h: No bit error)
- 30) T1 – Daly pattern sync status (01h: Pattern sync, 00h: Not in pattern sync)
- 31) 0 dB CSU Tx Level Check (00h: Pass (> - 2.5 dB), XXh: Value reported by DS2155)
- 32) -7.5 dB CSU Tx Level Check (00h: Pass (-5.0 to –12.5 dB), XXh: Value reported by DS2155)
- 33) -15 dB CSU Tx Level Check (00h: Pass (-12.5 to –20.0 dB), XXh: Value reported by DS2155)
- 34) -22.5 dB CSU Tx Level Check (00h: Pass (-20.0 to –30.0 dB), XXh: Value reported by DS2155)

- 35) Vpp measurement of 0 dB signal in 1/10ths of a Volt (e.g. 124 = 12.4 Volts)
- 36) End of Data (FFh)

Parameter Definitions

Parameter	# of bytes	Step	Example / Description
Frequency	4 bytes unsigned	1 Hz	1000.3 MHz = 1000300000
Frequency	4 bytes unsigned	10-Hz	1000.3 MHz = 100030000
Scale (RL, CL)	2 bytes unsigned	1 / 1000 dB	51.3 dB = 51300
(SWR)	2 bytes unsigned	1 / 1000 (ratio)	65.53 = 65530
Limit (RL, CL)	2 bytes unsigned	1 / 1000 dB	51.3 dB = 51300
(SWR)	2 bytes unsigned	1 / 1000 (ratio)	65.53 = 65530
Markers (Frequency & distance marker)	2 bytes unsigned	1 sweep point	Marker Values are given in relative position of the graph. The lowest value is 0, while the highest is (# of data points - 1).
Distance	4 bytes unsigned	1/100,000 m/ft	12.34 m = 1234000
Relative Propagation Velocity	4 bytes unsigned	1 / 100,000	0.837 = 83700
Cable Loss	4 bytes unsigned	1 / 100,000 dB	-0.345 dB/m = 34500
Gamma	4 bytes signed	1 / 10,000 (ratio)	Gamma value is the ratio of magnitude of reflected signal over the magnitude of incident signal.
Phase	4 bytes signed	1 / 10 degree	Phase value is the difference in phase between the incident and reflected signal.
Power: dBm/dB	4 bytes signed	1 / 1000 dBm 1 / 1000 dB	51.3 dBm = 51300 10.4 dB = 10400
Lock Fail Counter	2 bytes unsigned	1 error count	234 fails = 234
Integrator Fail Counter	2 bytes unsigned	1 error count	123 fails = 123

Programming Examples

This section contains several sample functions written in C, (and one in Visual Basic) that can be used as references when programming the Anritsu Handheld Products. These include functions to set up the comm Port, enter and exit remote mode and set the reference level of the spectrum analyzer.

Examples in C:

```

/*****
/*   unsigned char EnterRemote(BYTE *ResponseBytes)           */
/*   Description: This function implements control byte #69, Enter */
/*               Remote Mode.  If successful, the unit will be in */
/*               remote mode, waiting to accept additional serial */
/*               commands.                                       */
/*   Inputs  :   ResponseBytes = pointer to an array of bytes at */
/*               least 13 elements long (13 bytes are expected in */
/*               response to the Enter Remote command).          */
/*   Returns:   SUCCESS if the unit is in remote mode           */
/*               FAILURE if the command fails                   */
/*               Response bytes are returned in the variable    */
/*               ResponseBytes.                                  */
*****/
unsigned char EnterRemote(BYTE *ResponseBytes)
{
    BYTE *SendEnterRemoteCharPointer; // Data to send
    BYTE SerialCommand;

    SendEnterRemoteCharPointer = &SerialCommand;
    SerialCommand = 69; // 69 is the Enter Remote Mode serial command

    // Write 1 byte of data from SendEnterRemoteCharPointer to the
    // COM Port
    WriteToPort(SendEnterRemoteCharPointer, 1);

    // Read the data returned by the SiteMaster - expecting 13 bytes,
    // give the unit 30 seconds to respond before timing out.
    if(!ReadfromPort(13, ResponseBytes, 30))
    {
        return FAILURE;
    }
    else
    {
        return SUCCESS;
    }
} /* EnterRemote */

/*****
/*   unsigned char SetSPAScale(unsigned long ReferenceLevel,    */
/*                             unsigned long dBScale, BYTE *ResponseBytes) */
/*   Description: This function implements control byte #101, Set */
/*               Spectrum Analyzer Scale.  It sets the spectrum */
/*               analyzer reference level and scale (dB/div).    */
/*   Inputs  :   RefLevel = reference level value               */
/*               dBScale = scale value                           */
*****/

```

```

/*          NOTE: This function assumes the values have          */
/*          already been checked to fall in the valid range      */
/*          and scaled according to the formulas in the          */
/*          Programming Manual.                                   */
/*          ResponseBytes = pointer to an array of bytes at      */
/*          least 1 element long (1 byte is expected in         */
/*          response to the Set Spectrum Analyzer Scale          */
/*          command).                                           */
/* Returns:  SUCCESS if the values are set                       */
/*          FAILURE if the command fails                         */
/*          Response bytes are returned in the variable         */
/*          ResponseBytes.                                       */
/*****/
unsigned char SetSPAScale(unsigned long RefLevel,
                          unsigned long dBScale, BYTE *ResponseBytes)
{
    BYTE *SendScalePointer;          // Data to send
    BYTE  SendBytes[9];
    BYTE  SerialCommand;

    // Serial Command to Set Scale on the SPA.
    SerialCommand = 101;

    // Data pointer.
    SendScalePointer = &SendByte[0];

    // First byte to send is the serial command, #101.
    SendBytes[0] = SerialCommand;

    // Convert the reference level and scale into 8 bytes
    // (4 bytes each) for the SPA. Put the bytes in the
    // SendBytes variable, starting with byte 1 (leave byte 0
    // as the command byte).
    Get8Bytes(RefLevel, Scale, &SendBytes[1]);

    // Write 9 bytes of data in SendScalePointer to the port.
    WriteToPort(SendScalePointer, 9);

    // Expecting 1 byte back (give the unit 5 seconds to respond):
    // 0xFF = success
    // 0xE0 = parameter failure (invalid value)
    // 0xEE = time-out (insufficient # of bytes received by SPA)
    if(!ReadFromPort(1, ResponseBytes, 5))
    {
        return FAILURE;
    }
    else
    {
        if(*ResponseBytes != 0xFF)
        {
            return FAILURE;
        }
        else
        {
            return SUCCESS;
        }
    }
}

```

```

    }
} /* SetSPAScale */

/*****
/*   unsigned char ExitRemote(BYTE *ResponseBytes)          */
/*   Description: This function implements control byte #255, Exit */
/*               Remote Mode.  If successful, the unit will leave */
/*               remote mode and resume sweeping.             */
/*   Inputs :    ResponseBytes = pointer to an array of bytes at */
/*               least 1 element long (1 byte is expected in   */
/*               response to the Exit Remote command).         */
/*   Returns:    SUCCESS if the unit exits remote mode        */
/*               FAILURE if the command fails                 */
/*               Response bytes are returned in the variable  */
/*               ResponseBytes.                               */
*****/
unsigned char ExitRemote(BYTE *ResponseBytes)
{
    BYTE *SendExitRemoteCharPointer;    // Data to send
    BYTE SerialCommand;

    SendExitRemoteCharPointer = &SerialCommand;
    SerialCommand = 255; // 255 is the Exit Remote Serial Command

    // Write 1 byte of data from SendExitRemoteCharPointer to the
    // COM Port
    WriteToPort(SendExitRemoteCharPointer, 1);

    // Expecting 1 byte back (give the unit 5 seconds to respond):
    // 0xFF = success
    if(!ReadFromPort(1, ResponseBytes, 1))
    {
        return FAILURE;
    }
    else
    {
        if(*ResponseBytes != 0xFF)
        {
            return FAILURE;
        }
        else
        {
            return SUCCESS;
        }
    }
} /* ExitRemote */

/*****
/*   void Get8Bytes(unsigned long parm1, unsigned long parm2,    */
/*                 BYTE* ByteData )                             */
/*   Description: This function converts the 2 four byte values to */
/*   8 bytes for transmission to the SiteMaster.  parm1 occupies */
/*   the first four bytes, parm2 occupies the second 4 bytes.    */
/*   Inputs:    parm1 - 4 byte unsigned long integer             */
*****/

```



```

/*          parm2 - 4 byte unsigned long integer          */
/* Returns:  SUCCESS if the unit is in remote mode      */
/*          FAILURE if the command fails                */
/*          The resulting bytes are returned in the     */
/*          memory location pointed to by ByteData. This */
/*          location must have at least 8 empty bytes.  */
/*****
void Get8Bytes(unsigned long parm1, unsigned long parm2,
               BYTE* ByteData)
{
    // MSB of 1st parameter
    *ByteData = (BYTE)((parm1 & 0xFF000000)>>24);
    *(ByteData+1) = (BYTE)((parm1 & 0x00FF0000)>>16);
    *(ByteData+2) = (BYTE)((parm1 & 0x0000FF00)>>8);
    // LSB of 1st parameter
    *(ByteData+3) = (BYTE)(parm1 & 0x000000FF);

    // MSB of 2nd parameter
    *(ByteData+4) = (BYTE)((parm2 & 0xFF000000)>>24);
    *(ByteData+5) = (BYTE)((parm2 & 0x00FF0000)>>16);
    *(ByteData+6) = (BYTE)((parm2 & 0x0000FF00)>>8);
    // LSB of 2nd parameter
    *(ByteData+7) = (BYTE)(parm2 & 0x000000FF);
} /* Get8Bytes */

/*****
BOOL OpenCommunications(int ComPort, int ComBaud)
/* Description : This function is to Open the communication port
/* and set the port settings
/* Inputs :    int - ComPor- entered as a command line argument
/*            int - ComBau- The Baud rate for Communication
/* Returns:    SUCCESS - If the-Communication link was established*
/*            FAIL - IF the-e was an error opening the COM Port
/*****
BOOL OpenCommunications(int ComPort, int ComBaud)
{
    DCB      CommSettings; // Structure with COM Port settings
    LPCTSTR ComPortNumber; // Pointer to the COM port number
    BOOL PortReady;        // Return val after setting the COM Port
    COMMTIMEOUTS timeout;  // Structure with Time out values

    switch (ComPort)
    {
        case '1':
            ComPortNumber = "COM1";
            break;
        case '2':
            ComPortNumber = "COM2";
            break;
        case '3':
            ComPortNumber = "COM3";
            break;
        case '4':
            ComPortNumber = "COM4";
            break;
    }
}

```

```

        default:
            CloseHandle(ComHandle);
            fclose(fp);
            exit(0);
        break;
    }

/* Creating a File to Open a COM Port*/
ComHandle = CreateFile( ComPortNumber,
                        GENERIC_READ | GENERIC_WRITE,
                        0, // exclusive access
                        NULL, // no security
                        OPEN_EXISTING,
                        0, // no overlapped I/O
                        NULL); // null template

/* Set up the COM Ports Input and Output Buffer
Syntax -
BOOL-SetupComm(
HANDLE hFile,      // handle to communications device
DWORD dwInQueue,  // size of input buffer
DWORD dwOutQueue  // size of output buffer
);
*/
PortReady = SetupComm(ComHandle, 5000, 5000);

/* Open the existing COM Settings
Syntax -
BOOL-GetCommState(
HANDLE hFile,      // handle to communications device
LPDCB lpDCB        // pointer to device-control block
// structure
);
*/
PortReady = GetCommState(ComHandle, &CommSettings);

/*Check to see if it was successful*/
if(!PortReady)
{
    CloseHandle(ComHandle);
    fclose(fp);
    exit(0);
}

/* This is used to update the CommSettings Structure Variables*/
// Setting the Baud Rate
switch (ComBaud)
{
    case '1':
        CommSettings.BaudRate = CBR_9600;    // rate - 9600
        break;
    case '2':
        CommSettings.BaudRate = CBR_19200;   // rate - 19200
        break;
    case '3':
        CommSettings.BaudRate = CBR_38400;   // rate - 38400
        break;
}

```

```

        case '4':
            CommSettings.BaudRate = CBR_56000; // rate - 56000
        break;
        case '5':
            CommSettings.BaudRate = CBR_115200; // rate - 115200-
        break;
        default:
            CommSettings.BaudRate = CBR_9600; //Default - 9600
        break;
    }

    // disable null stripping
    CommSettings.fNull = FALSE;
    // RTS flow control
    CommSettings.fRtsControl = RTS_CONTROL_ENABLE;
    // XON/XOFF in flow control
    CommSettings.fInX = FALSE;
    // XON/XOFF out flow control
    CommSettings.fOutX = FALSE;
    // DTR flow control type
    CommSettings.fDtrControl = DTR_CONTROL_ENABLE;
    // number of bits/byte, 4-8
    CommSettings.ByteSize = 8;
    // 0-4=no, odd, even, mark, space
    CommSettings.Parity = NOPARITY;
    // 0,1,2 = 1, 1.5, 2
    CommSettings.StopBits = ONESTOPBIT;

    /* Setting the COM State with the changed parameters
    Syntax -
        BO-L SetCommState(
            HANDLE hFile, // handle to communications device
            LPDCB lpDCB // pointer to device-control block structure
        );
    */

    PortReady = SetCommState (ComHandle, &CommSettings);

    /* Setting the parameters for the timeouts.
    NOTE: Without Timeout Settings, Reading the COM Port will not work
    properly*/

    // This gives the Timeout value for each bytes received
    timeout.ReadIntervalTimeout = MAXDWORD;
    timeout.ReadTotalTimeoutConstant = 0;
    timeout.ReadTotalTimeoutMultiplier = 0;

    /* Sets the communication timeouts
    Syntax -
        BOO- SetCommTimeouts(
            HANDLE hFile, // handle to comm dev□omm.
            LPCOMMTIMEOUTS lpCommTimeouts /* pointer to comm tim□omm.t structure */
        );
    */
    SetCommTimeouts(ComHandle, &timeout);

    if(PortReady)

```

```

    {
        return SUCCESS;
    }
else
    {
        CloseHandle (ComHandle);
        fclose(fp);
        return FAIL;
        exit(0);
    }
}

```

Example in Visual Basic

```

Private Sub cmdSetBaudRateSM_Click()
    Dim ChangeBaudSerialCmd As Integer
    Dim BaudRate As Integer
    Dim strInputBuf As Variant
    Dim PreviousSettings As String

    PreviousSettings = commCtrl.Settings

    'Check that we're in remote and have selected a baud rate
    If CheckInitialConditions(True, False, True) = False Then
        GoTo SetSMBaud_err_handler
    End If

    ChangeBaudSerialCmd = 197      'Setting Baud rate Serial Command
    BaudRate = GetBaudSerialCmd    'Get the Serial cmd for the specific
                                   'baud rate
    commCtrl.Output = Chr$(ChangeBaudSerialCmd) + Chr$(BaudRate)  'Sending
                                                                    'the data

    Delay (300)

    'Change the Baud setting for the application also
    If BaudRate = 0 Then
        commCtrl.Settings = "9600,n,8,1"
    ElseIf BaudRate = 1 Then
        commCtrl.Settings = "19200,n,8,1"
    ElseIf BaudRate = 2 Then
        commCtrl.Settings = "38400,n,8,1"
    ElseIf BaudRate = 3 Then
        commCtrl.Settings = "56000,n,8,1"
    ElseIf BaudRate = 4 Then
        commCtrl.Settings = "115200,n,8,1"
    Else
        'Box will fail, set back to 9600.
        commCtrl.Settings = "9600,n,8,1"
    End If

    Delay (1000)
    strInputBuf = CStr(commCtrl.Input)
    strInputBuf = Mid(strInputBuf, 1, 1)
    If strInputBuf = "" Then

```

```

        MsgBox "Invalid Baud Rate - NO STRING"
        GoTo SetSMBaud_err_handler
    End If

    If Asc(strInputBuf) = 255 Then
        MsgBox "Set Baud Rate Succesfully"
    ElseIf Asc(strInputBuf) = 238 Then
        MsgBox "SiteMaster Timed out"
        GoTo SetSMBaud_err_handler

    ElseIf Asc(strInputBuf) = 224 Then
        MsgBox "Invalid Baud Rate - ERR 22-"
        GoTo SetSMBaud_err_handler
    Else
        MsgBox "Invalid Baud Rate - ERR " + CStr(Asc(strInputBuf))
        GoTo SetSMBaud_err_handler

    End If

    Exit Sub
SetSMBaud_err_handler:
    commCtrl.Settings = PreviousSettings
End Sub

```

Signal Standards

Index	Standard	Valid Channels
01h	AMPS / EIA 553	1-799, 990-1023
04h	C-450 (P)	1-800
05h	C-450 (SA)	1-247
06h	CDMA China 1	0-1000, 1329-2047
09h	CDMA China 2	0-1000, 1329-2047
0Ch	CDMA Japan	1-799, 801-1039, 1041-1199
10h	CDMA Korea PCS	1-598
11h	CDMA US Cellular	1-799, 990-1023
14h	CDMA US PCS	1-1199
15h	CDMA2000 Class 0 Korea Cellular	1-799, 990-1023
18h	CDMA2000 Class 0 N.A. Cellular	1-799, 990-1023
1Bh	CDMA2000 Class 1 N.A. PCS	0-1199
1Ch	CDMA2000 Class 2 (TACS Band)	0-1000, 1329-2047
1Fh	CDMA2000 Class 3 (JTACS Band)	1-1039, 1041-1199
22h	CDMA2000 Class 4 Korea PCS	0-599
23h	CDMA2000 Class 5 (NMT-450-20 kHz)	1039-1473, 1792-2016
26h	CDMA2000 Class 5 (NMT-450-25 kHz)	1-300, 539-871
29h	CDMA2000 Class 6 IMT-2000	0-1199
2Ah	CDMA2000 Class 7 N.A. 700 MHz Cellular	0-359
2Bh	DCS 1800	512-885
2Ch	ETACS	0-1000, 1329-2047
2Fh	GSM 450	259-293
30h	GSM 480	306-340
31h	GSM 850	128-251
32h	GSM 900	0-124, 975-1023
35h	P-GSM 900	1-124
36h	E-GSM 900	0-124, 975-1023
39h	R-GSM 900	0-124, 955-1023
3Ch	GSM 1800	512-885
3Dh	GSM 1900	512-810
3Eh	MATS-E	1-1000
3Fh	N-AMPS / IS-88L	1-799, 990-1023
42h	N-AMPS / IS-88M	1-799, 990-1023
45h	N-AMPS / IS-88U	1-1023
46h	NADC IS136 Cellular	1-1023
47h	NADC IS136 PCS	1-1999
48h	NMT-411-25kHz	539-871
49h	NMT-450-20kHz	1039-1473
4Ah	NMT-450-25kHz	1-300
4Bh	NMT-470-20kHz	1792-2016
4Ch	NMT-900	1-1000
4Dh	NMT-900 (Offset)	1025-2023
4Eh	NTACS	1-799, 800-1039, 1040-1199
52h	PCS 1900	512-810
53h	PDC 800 Analog	0-799

54h	PDC 1500 (JDC)	0-960
55h	PHS	1-77
56h	SMR 800 -12.5 kHz	1-1199
57h	SMR 800 - 25 kHz	1-600
58h	SMR 1500	1-479
59h	TACS	1-1000
5Ah	802.11a	34-64, 149-161
5Dh	802.11b	1-14
60h	802.11 FH	2-95
61h	802.11 DS	1-14
62h	802.11g	1-14
65h	Tetra 380-390 MHz Uplink	3600-4000
66h	Tetra 390-400 MHz Downlink	3600-4000
67h	Tetra 410-420 MHz Uplink	800-1200
68h	Tetra 420-430 MHz Downlink	800-1200
69h	Tetra 450-460 MHz Uplink	2400-2800
6Ah	Tetra 460-470 MHz Downlink	2400-2800
6Bh	Tetra 805-825 MHz Uplink	2000-2800
6Ch	Tetra 850-870 MHz Downlink	2000-2800
6Dh	Tetra 870-876 MHz Uplink	600-840
6Eh	Tetra 915-921 MHz Downlink	600-840
6Fh	700 MHz 6.25 kHz 764-806 MHz 1-1920	1-480, 481-960, 961-1440, 1441-1920
74h	700 MHz 50 kHz 767-803 MHz 1-240	1-120

